#### DOT/FAA/AR-96/46

Office of Aviation Research Washington, D.C. 20591

### User's Guide for FAR23 Loads Program

March 1997

**Final Report** 

This document is available to the U.S. public through the National Technical Information Service, Springfield, Virginia 22161.



U.S. Department of Transportatic **Federal Aviation Administratio** 

# 19970515 012

DTIC QUALERY INSPECTED 1

#### NOTICE

This document is disseminated under the sponsorship of the U.S. Department of Transportation in the interest of information exchange. The United States Government assumes no liability for the contents or use thereof. The United States Government does not endorse products or manufacturers. Trade or manufacturer's names appear herein solely because they are considered essential to the objective of this report.

			Technical Report	Documentation Page
1. Report No.	2. Government Accession No.		3. Recipient's Catalog No.	
DOT/FAA/AR-96/46				
4. Title and Subtitle			5. Report Date	
USER'S GUIDE FOR FAR23 LOADS PI	ROGRAM		March 1997	
			6. Performing Organization C	ode
7. Author(s)			8. Performing Organization R	leport No.
D Miedlar			UDR-TR-96-83	
9. Performing Organization Name and Address			10. Work Unit No. (TRAIS)	
University of Dayton Passarch Institute			RPD-510	
Structural Integrity Division				
300 College Park			11. Contract or Grant No.	
Davton, OH 45469-0120			93-G-051	
12. Sponsoring Agency Name and Address			13. Type of Report and Perio	d Covered
U.S. Department of Transportation			Final Report	
Federal Aviation Administration			14. Sponsoring Agency Code	)
Weshington DC 20591			AAR-432	
15. Supplementary Notes				
FAA William I Hughes Technical Center	r Monitors: Thomas De	Fiore, AAR-432; Tere	nce Barnes, ANM-105	ν
1 Anstract				·····
The FAR23 Loads program provides a procedure for calculating the loads on an airplane according to the Code of Federal Regulations, Title 14—Aeronautics and Space, Chapter I—Federal Aviation Administration, Subchapter C—Aircraft, Part 23—Airworthiness Standards: Normal, Utility, Aerobatics, and Commuter Category Airplanes, Subpart C—Structures. Most of the detail flight loads are developed from the flight envelopes specified in FARs 23.333 and 23.345. At every point specified in the flight envelope, the airplane is balanced by a tail load reacting to the specified liner normal acceleration and the aerodynamic lift, drag, and moment about the center of gravity. The data needed to make these balancing calculations consists of (1) weight and center of gravity, (2) aerodynamic surface geometry, (3) structural speeds, and (4) aerodynamic coefficients. After the balanced load data are developed, the critical structural loads are determined for each component. For the critical conditions, the air loads, inertial loads, and net loads are calculated. Aileron, flap, tab, engine mount, landing, and one engine out loads are also calculated. Landing loads are calculated from the landing gear geometry, landing load factor, weight, and center of gravity data. The FAR23 Loads program was developed by Aero Science Software to calculate the loads on an airplane using methods acceptable to the FAA. The program includes 20 modules that are each self-contained programs designed for a specific application.				
17. Key Words		18. Distribution Statement		
FAR23, Airplane loads, Balanced tail loa	d, Flight envelope,	This document is ava	ilable to the public thr	ough the National
Component structural load	. U -r-/	Technical Informatio 22161.	n Service (NTIS), Spri	ingfield, Virginia
19. Security Classif. (of this report)	20. Security Classif. (of this	page)	21. No. of Pages	22. Price
Unclassified	Unclassified		143	

Б.

•

۹

۶

#### PREFACE

This User's Guide for the FAR23 Loads program was developed by the University of Dayton Research Institute for use by the Federal Aviation Administration (FAA). The FAR23 Loads computer program was developed by Hal C. McMaster, under contract to the University of Dayton Research Institute, as part of the FAA Grant No. 93-G-051 entitled "Research Leading to the Development of Commuter Airlines Structural Integrity Management." The program monitor for the FAA is Mr. Thomas DeFiore of the FAA William J. Hughes Technical Center at Atlantic City International Airport, New Jersey, and the Program Technical Advisor is Mr. Terence Barnes of the FAA Aircraft Certification Office in Seattle, Washington. Dr. Joseph Gallagher is the principal investigators. Ms. Peggy Miedlar was the lead engineer for this project.

#### TABLE OF CONTENTS

•

•

۹

**#**.,

EXE	EXECUTIVE SUMMARY		
1.	INTF	RODUCTION	1-1
	1.1	About FAR23 Loads	1-1
	1.2	Federal Regulations	1-1
	1.3	Using the Manual	1-1
2.	2. GETTING STARTED SYSTEM REQUIREMENTS		2-1
	2.1	Systems Requirements	2-1
	2.2	FAR23 Loads Disks	2-1
	2.3	Installing FAR23 Loads	2-1
	2.4	Running FAR23 Loads Program	2-4
	2.5	Running FAR23 Loads Modules	2-4
	2.6	Special Cases and Exceptions	2-8
	2.7	FAR23 Plot Programs	2-9
3.	3. WEIGHT ESTIMATION		3-1
	3.1	WTESTIMA Description	3-1
	3.2	Running WTESTIMA	3-3
	3.3	WTESTIMA Output	3-4
4.	WEI	GHT AND INERTIA	4-1
	4.1	WTONECG Description	4-1
	4.2	Developing the Weight Database	4-1
	4.3	FAR 23 Regulations	4-2
	4.4	Running WTONECG	4-3
	4.5	WTONECG Output	4-6
5.	ENV	ELOPE OF LOADING CONDITIONS	5-1
	5.1	WTENV Description	5-1
	5.2	Running WTENV	5-1
	5.3	WTENV Output	5-3
	5.4	Graphics	5-3

6.	AER	ODYNAMIC SURFACE GEOMETRY	6-1
	6.1	WINGGEOM Description	6-1
	6.2	Running WINGGEOM	6-1
	6.3	WINGGEOM Output	6-3
	6.4	Graphics	6-3
7 <sub>:</sub>	STRU	JCTURAL DESIGN SPEEDS AND MANEUVERING LOAD FACTORS	7-1
	7.1	STRSPEED Description	7-1
	7.2	FAR 23 Regulations	7-2
	7.3	Running STRSPEED	7-4
	7.4	STRSPEED Output	7-6
8.	MAC	THLIMITATIONS	8-1
	8.1	MACHLIM Description	8-1
	8.2	Running MACHLIM	8-1
	8.3	MACHLIM Output	8-2
	8.4	Graphics	8-2
9.	AERO	ODYNAMIC COEFFICIENTS AND AIRLOADS	9-1
	9.1	AIRLOADS Description	9-1
	9.2	FAR 23 Regulations	9-2
	9.3	Running AIRLOADS	9-4
	9.4	AIRLOADS Output	9-11
	9.5	Graphics	9-11
10.	ADD	ITIONAL AERODYNAMIC COEFFICIENTS AND AIRLOADS	10-1
	10.1	AIRLOAD4 Description	10-1
	10.2	FAR 23 Regulations	10-1
	10.3	Running AIRLOAD4	10-1
	10.4	AIRLOAD4 Output	10-3
	10.5	Graphics	10-3
11.	FLIG	HT ENVELOPE	11-1
	11.1	FLTLOADS Description	11-1
	11.2	FAR 23 Regulations	11-1
	11.3	Running FLTLOADS	11-4
	11.4	FLTLOADS Output	11-9
	11.5	Graphics	11-9

12.	2. SELECTION OF CRITICAL LOADS	
	12.1 SELECT Description	12-1
	12.2 FAR 23 Regulations	12-4
	12.3 Running SELECT	12-10
	12.4 SELECT Output	12-16
13.	AILERON LOADS	13-1
	13.1 AILERON Description	13-1
	13.2 FAR 23 Regulations	13-2
	13.3 Running AILERON	13-3
	13.4 AILERON Output	13-4
14.	FLAP LOADS	14-1
	14.1 FLAPLOAD Description	14-1
	14.2 FAR 23 Regulations	14-1
	14.3 Running FLAPLOAD	14-2
	14.4 FLAPLOAD Output	14-4
15.	WING INERTIA	15-1
	15.1 WINGINER Description	15-1
	15.2 FAR 23 Regulations	15-1
	15.3 Running WINGINER	15-2
	15.4 WINGINER Output	15-5
16.	NET WING LOADS	16-1
	16.1 NETLOADS Description	16-1
	16.2 FAR 23 Regulations	16-1
	16.3 Running NETLOADS	16-1
	16.4 NETLOADS Output	16-3
	16.5 Graphics	16-3
17.	ENGINE MOUNT LOADS	. 17-1
	17.1 ENGLOADS Description	17-1
	17.2 FAR 23 Regulations	17-1
	17.3 Running ENGLOADS	17-2
	17.4 ENGLOADS Output	17-5

W

.

#### vii

18.	18. LANDING LOADS		18-1
	18.1	LANDLOAD Description	18-1
	18.2	FAR 23 Regulations	18-1
	18.3	Running LANDLOAD	18-5
	18.4	LANDLOAD Output	18-7
19.	LAN	IDING LOAD FACTOR	19-1
	19.1	LGFACTOR Description	19-1
	19.2	FAR 23 Regulations	19-1
	19.3	Running LGFACTOR	19-2
	19.4	LGFACTOR Output	19-3
20.	DIST	TRIBUTION OF TAIL LOADS	20-1
	20.1	TAILDIST Description	20-1
	20.2	Running TAILDIST	20-1
	20.3	TAILDIST Output	20-9
	20.4	Graphics	20-9
21.	TAB	LOADS	21-1
	21.1	TABLOADS Description	21-1
	21.2	FAR 23 Regulations	21-1
	21.3	Running TABLOADS	21-1
	21.4	TABLOADS Output	21-2
22.	ONE	ENGINE OUT LOADS	22-1
	22.1	ONENGOUT Description	22-1
	22.2	FAR 23 Regulations	22-1
	22.3	Running ONENGOUT	22-2
	22.4	ONENGOUT Output	22-4
23.	REFF	ERENCES	23-1

#### LIST OF FIGURES

۲

.

۹

**H**.

Figure		Page
2.1	FAR23 Loads Main Menu Window	2-4
2.2	FAR Loads Window for Opening Files	2-5
3.1	WTESTIMA Input Window	3-3
4.1	WTONECG First Window	4-3
4.2	Message Window for WTONECG and WTENV	4-4
4.3	Size Option for WTONECG and WTENV	4-5
4.4	WTONECG Input Window	4-5
5.1	WTENV Input Window	5-2
5.2	Example of Useful Load Envelope and Structural Limits	5-3
6.1	WINGGEOM Input Window	6-1
6.2	Example of Aerodynamic Surfaces Plot	6-3
7.1	STRSPEED Input Window	7-5
7.2	STRSPEED Alternate Input Window	7-6
8.1	MACHLIM Input Window	8-1
8.2	Example of Flight Limit Diagram	8-3
9.1	AIRLOADS First Input Window	9-4
9.2	AIRLOADS Second Input Window	9-5
9.3	AIRLOADS Third Input Window	9-6
9.4a	AIRLOADS Fourth Input Window	9-6
9.4b	AIRLOADS Alternate Fourth Input Window	9-7

9.5	AIRLOADS Fifth Input Window	9-7
9.6	AIRLOADS Sixth Input Window	9-8
9.7a	AIRLOADS Seventh Input Window	9-8
9.7b	AIRLOADS Alternate Seventh Input Window	9-9
9.8	AIRLOADS Eighth Input Window	9-9
9.9a	AIRLOADS Ninth Input Window	9-10
9.9b	AIRLOADS Ninth Input Window with Tau	9-10
9.10	Example of Lift Distribution Plot	9-12
10.1	AIRLOAD4 First Input Window	10-1
10.2	AIRLOAD4 Second Input Window	10-2
10.3	AIRLOAD4 Fifth Input Window	10-3
11.1	Flight Envelope from FAR 23.333(d)	11-2
11.2	FLTLOADS First Input Window	11-4
11.3	FLTLOADS Second Input Window	. 11-5
11.4	FLTLOADS Third Input Window	11-6
11.5	FLTLOADS Fourth Input Window	11-6
11.6	FLTLOADS Fifth Input Window	11-7
11.7	FLTLOADS Sixth Input Window	11-7
11.8	FLTLOADS Seventh Input Window	11-8
11.9	FLTLOADS Eighth Input Window	11-8
11.10	Example of a Flight Envelope	11-10
12.1	Geometric Relation Between Angle of Attack of Wing and Tail	12-3

12.2	SELECT Main Window	12-10
12.3	SELECT Secondary Window	12-11
12.4	SELECT "Search Critical Wing Loads" Window	12-12
12.5	SELECT "Search Critical Fuselage Loads" Window	12-13
12.6	SELECT "Search Critical Horizontal Tail Loads" Window	12-14
12.7a	SELECT "Search Critical Vertical Tail Loads" Window	12-15
12.7b	SELECT "Search Critical Vertical Tail Loads" Window	12-15
13.1	AILERON Input Window	13-3
14.1	FLAPLOAD Input Window	14-3
15.1	WINGINER First Input Window	15-2
15.2	WINGINER Second Input Window	15-3
15.3	WINGINER Third Input Window	15-4
16.1	NETLOADS Input Window	16-2
16.2	Example of Net Loads Plot	16-4
17.1	ENGLOADS First Input Window	17-3
17.2a	ENGLOADS Second Input Window for Reciprocating Engines	17-4
17.2b	ENGLOADS Second Input Window for Turboprop Engines	17-5
18.1	LANDLOAD First Input Window	18-5
18.2	LANDLOAD Second Input Window	18-6
19.1	LGFACTOR Input Window	19-2
20.1	TAILDIST Menu Window	20-1
20.2	TAILDIST "13 Critical Horizontal Loads" First Input Window	20-3

٩

xi

20.3	TAILDIST "13 Critical Horizontal Loads" Second Input Window	20-3
20.4	TAILDIST "13 Critical Horizontal Loads" Third Input Window	20-4
20.5	TAILDIST "Four Critical Vertical Loads" First Input Window	20-5
20.6	TAILDIST "Four Critical Vertical Loads" Second Input Window	20-5
20.7	TAILDIST "Critical Horizontal Load Distributed on Stations" First Input Window	20-6
20.8	TAILDIST "Critical Horizontal Load Distributed on Stations" Second Input Window	20-7
20.9	TAILDIST "Critical Vertical Load Distributed on Stations" First Input Window	20-8
20.10	TAILDIST "Critical Vertical Load Distributed on Stations" Second Input Window	20-8
20.11	Example of Rational Tail Loads Graph	20-10
21.1	TABLOADS Input Window	21-1
22.1	ONENGOUT First Input Window	22-2
22.2	ONENGOUT Second Input Window	22-4

#### LIST OF TABLES

Table		Page
1.1	Summary of Modules in the FAR23 Loads Program	1-2
2.1	Summary of Files Extracted from FAR23 Loads Program Installation Disks	2-2
2.2	Summary of Modules in the FAR23 Loads Program	2-7
2.3	Summary of Plot Files	2-10
3.1	Adjustment Factors for K	3-2
3.2	Component Weight as Percentage of Takeoff Weight	3-2
7.1	Maneuvering Load Factor Limits	7-1
15.1	Description of Variables Used in the WINGINER Output File	15-5
16.1	Description of Variables Used in the NETLOADS Output File	16-3
22.1	Description of Variables Used in the ONENGOUT Output File	22-5

#### LIST OF SYMBOLS AND ABBREVIATIONS

$A_t$	absolute angle at the tail
$AR_w$	aspect ratio of the wing
а	speed of sound
b	wing span
cg	center of gravity
$C_D$	drag coefficient
$C_L$	lift coefficient
$C_{L-ail}$	lift coefficient of the aileron
$C_{L-f}$	lift coefficient of the flap
$C_{L-w}$	lift coefficient of the wing
$C_M$	pitching moment coefficient
$D_x$	drag load
$d_y$	number of increments to divide the surface into
EAS	equivalent air speed
h	altitude
<i>i</i> <sub>t</sub>	incidence of tail, angle from waterline to zero lift line of tail
$i_w$	incidence of wing, angle from waterline to zero lift line of wing
I <sub>ZZ</sub>	moment of inertia about vertical axis (z-axis)
K	ratio of empty weight to takeoff weight
KEAS	knots, equivalent airspeed
L	load
$L_{ail}$	load on the aileron
L <sub>flap</sub>	load on flap
$L_t$	load at the 25% chord of the tail
$M_C$	Mach number at the design cruise speed $V_C$
$M_D$	Mach number at the design dive speed $V_D$
MAC	mean aerodynamic chord (mean geometric chord)
n	load factor (positive or negative)
$n_x$	horizontal load factor
$n_z$	normal load factor
Р	pressure
$P_{LE}$	pressure at the leading edge
q	dynamic pressure (= $\frac{1}{2} \rho V^2$ )
RN	Reynolds number
Sail	surface area of the aileron
S <sub>ail-aft</sub>	surface area of aileron aft of the hinge line
S <sub>ail-fwd</sub>	surface area of aileron forward of the hinge line
C	surface area of flan

.

$S_t$	surface area of the tail
Т	temperature
TAS	true air speed
V	equivalent air speed
$V_A$	design maneuvering speed
$V_C$	design cruise speed
$V_D$	design dive speed
$V_F$	design flap speed
$V_H$	maximum speed at sea level
$V_S$	computed stalling speed
W	weight
$W_{TO}$	takeoff weight
$W_{empty}$	empty weight
W <sub>use</sub>	useful load
WL	water line
у	wing station
Λ	angle of sweepback
α	angle of attack
$\alpha_t$	angle of attack at tail
$\alpha_{wing}$	angle of attack of wing
$\delta_A$	maximum deflection at $V_A$
$\delta_{ail}$	deflection of aileron
$\delta_C$	deflection at $V_C$
$\delta_D$	deflection at $V_D$
Δα	change in angle of attack
$\Delta C_{L-t}$	change in lift coefficient of the tail
$\Delta Tab$	maximum tab deflection
$\Delta T$	time increment
3	downwash at the tail
ρ	air density
$\rho_0$	air density at sea level
σ	ratio of density at altitude to density at sea level
τ	correction factor for slope of lift curve
Ψ	yaw angle
v	yaw rate
า พั	vaw acceleration
Ψ	juii accolotation

#### EXECUTIVE SUMMARY

The FAR23 Loads program is designed to calculate loads for airplanes that will be certified under FAR Part 23 requirements. The FAR23 Loads program was developed for the FAA by Hal C. McMaster of Aero Science Software. This manual is a User's Guide for the program FAR23 Loads and is intended as a guide for running the individual modules that make up FAR23 Loads. The theoretical development of FAR23 Loads is explained in the manual "FAR23 Loads" by Hal C. McMaster.

#### 1. INTRODUCTION.

#### 1.1 ABOUT FAR23 LOADS.

The FAR23 Loads program was developed by Aero Science Software to calculate the loads on an airplane using methods acceptable to the FAA. The program includes 20 modules that are each self-contained programs designed for a specific application.

Most of the detailed flight loads are developed from the flight envelopes specified in the federal requirements FARs 23.333 and 23.345. At every point specified in the flight envelope, the airplane is balanced by a tail load reacting to the specified linear normal acceleration and the aerodynamic lift, drag, and moment about the center of gravity. The data needed to make these balancing calculations consist of (1) weight and center of gravity, (2) aerodynamic surface geometry, (3) structural speeds, and (4) aerodynamic coefficients. These data are developed by modules in the FAR23 Loads program.

After the data needed to calculate the balancing loads are developed, the critical structural loads are determined for each component. For the critical conditions, the air loads, inertia loads, and net loads are calculated. Aileron, flap, tab, engine mount, landing, and one engine out loads are also calculated.

The landing loads are calculated from the landing gear geometry, landing load factor, weight, and center of gravity data.

#### 1.2 FEDERAL REGULATIONS.

The program FAR23 Loads provides a procedure for calculating the loads on an airplane according to the Code of Federal Regulations, Title 14—Aeronautics and Space, Chapter I—Federal Aviation Administration, Subchapter C—Aircraft, Part 23—Airworthiness Standards: Normal, Utility, Acrobatic, and Commuter Category Airplanes, Subpart C—Structures. This is referred to as FAR Part 23. The regulations through Amendment 42 have been included in the FAR23 Loads program.

#### 1.3 USING THE MANUAL.

This manual is a guide to run the FAR23 Loads program and is intended to be a supplement to reference 1. Reference 1 provides the theoretical development of the equations used in the computer program.

Section 2 tells the user how to install the program and run FAR23 Loads. Section 2 also includes general information on how to run the individual modules, how to enter data, how to save the results, and how to print the output.

Sections 3 through 22 are each devoted to a separate module of the FAR23 Loads program and are organized according to the order that the modules appear in the main menu. Each section has up to five sections: description, FAR 23 regulations, running the module, output, and graphics.

The section on FAR 23 regulations is included only if there are applicable regulations. The graphics section is included only if the output can be plotted with the FAR23 Plot modules.

Table 1.1 is a summary of the modules in FAR23 Loads.

TABLE 1.1 SUMMARY OF MODULES IN THE FAR23 LOADS PROGRA
--

MODULE	SECTION	DESCRIPTION
WESTIMA	3	Weight estimate of airplane and components
WTONECG	4	Weight, center of gravity, and inertia calculations
WTENV	5	Envelope of discretionary loading
WINGGEOM	6	Calculate geometric properties for aerodynamic surfaces
STRSPEED	7	Determine structural design speeds
MACHLIM	8	Determine Mach limitations
AIRLOADS	9	Calculate aerodynamic coefficients and wing air loads
AIRLOAD4	10	Calculate aerodynamic coefficients and wing air loads
FLTLOADS	11	Calculates loads within the flight envelope
SELECT	12	Selects the critical flight loads
AILERON	13	Calculates loads on the aileron
FLAPLOAD	14	Calculates loads on the flaps
WINGINER	15	Calculates spanwise inertia loads for critical wing conditions
NETLOADS	16	Calculates the net wing loads
ENGLOADS	17	Calculates engine mount loads
LANDLOAD	18	Calculates landing loads
LGFACTOR	19	Calculates landing load factor
TAILDIST	20	Calculates the chordwise distribution for tail loads
TABLOADS	21	Calculates tab loads
ONENGOUT	22	Calculates loads with one engine out

#### 2. GETTING STARTED.

#### 2.1 SYSTEM REQUIREMENTS.

The program FAR23 Loads is designed to run on a personal computer. The minimum system requirements are:

- a DOS-compatible personal computer with at least an 80286 processor,
- minimum 640K RAM,
- 580K of free conventional memory,
- MS-DOS version 3.1 or higher,
- a hard drive, not bigger than 2GB, with at least 720K of free space,
- a 3.5-inch floppy disk drive, and
- a mouse is recommended, but not required.

For best performance, it is recommended that you exit Windows before running FAR23 Loads. If you are running Windows, most of the modules in FAR23 Loads can be run by opening a DOS window. Some of the modules require a full-window DOS window.

#### 2.2 FAR23 LOADS DISKS.

The FAR23 Loads program is contained on nine disks. Five of the disks are the installation disks for the FAR23 Loads program, two data disks contain the data files and output for the sample airplanes, one disk contains the plotting modules FAR23 Plot and related files, and the final disk includes the Qbasic programs for the modules in FAR23 Loads. Table 2.1 lists the files included in the FAR23 Loads program disks and provides a description of each file.

#### 2.3 INSTALLING FAR23 LOADS.

The FAR23 Loads program must be installed on your computer using the DOS *setup* program provided. To do this, follow these steps.

- Insert the disk labeled "Disk 1 Setup" into your disk drive. This drive is assumed to be the "a" drive in these instructions.
- From DOS: At the DOS prompt, type the following: a:setup.
- From Windows 3.1: Go to the File menu of the Program Manager and select Run. At the command, type: a:setup, then press Enter.
- From Windows 95: Go to Start, select Run, then type: a:setup and press Enter.
- You will be asked to "Specify the source directory containing the FAR23 Loads Program files." This is "a:\".

## TABLE 2.1SUMMARY OF FILES EXTRACTED FROM THE FAR23 LOADS PROGRAM<br/>INSTALLATION DISKS

FILE NAME	DESCRIPTION
FAR23LDS.EXE	FAR23 Loads start-up program
WTESTIMA.EXE	Weight estimate for empty, gross, and components
WTONECG.EXE	Weight vs. c.g. for a single loading
WTENV.EXE	Weight vs. c.g. for a range of loadings
WINGGEOM.EXE	Aerodynamic surface geometry
STRSPEED.EXE	Structural design speeds and load factors
MACHLIM.EXE	Mach limits
AIRLOADS.EXE	Aerodynamic coefficients and air loads
AIRLOAD4.EXE	Aerodynamic coefficients and air loads for sweepback and high Mach air loads
FLTLOADS.EXE	Balancing calculations for flight envelope
SELECT.EXE	Selection of critical loads
AILERON.EXE	Selection of critical aileron loads
FLAPLOAD.EXE	Selection of critical flap loads
WINGINER.EXE	Wing inertia loads
NETLOADS.EXE	Net wing loads
ENGLOADS.EXE	Engine mount loads
LANDLOAD.EXE	Landing loads for tricycle gear
LGFACTOR.EXE	Estimate landing load factor
TAILDIST.EXE	Rational tail loads
TABLOADS.EXE	Tab loads
ONENGOUT.EXE	One engine out vertical tail loads
TAU.EXE	Correction factor for lift curve of wing
M2002576	Sample data file for input to WTONECG and WTENV
WTENV356	Sample data file for input to WTENV
WTAFTCG	Sample data file for input to WTONECG
BBFLTLDR	Sample data file for input to FLTLOADS
BBSELECT	Sample data file for input to SELECT
PHAABB36	Sample data file for input to NETLOADS
ACCELROL	Sample data file for input to NETLOADS
TORBB36	Sample data file for input to NETLOADS

- Next you will be asked to "Specify destination directory for FAR23 Loads program files." Enter the full path of the directory where you want the files, such as C:\FAR23LDS. If the directory does not exist, it will be created.
- Follow the on-screen instructions to continue the installation. You will be prompted to insert disks 2, 3, 4, and 5.
- The input and output data files for two sample airplanes are included on the data disks. If you want to copy this data to your hard drive, you should use a separate subdirectory for each set of data. Note that some of the files names are the same for the two airplanes, and if you copy both sets of data to the same directory, you will overwrite some data files.
- Insert the disk labeled "Data Disk 1" into your disk drive. From the DOS prompt, type XCOPY A:\*.\* C:\FAR23LDS\DATA1\\*.\*. This command assumes that you installed the FAR23 Loads programs in the directory C:\FAR23LDS. The XCOPY command will create the directory DATA1 if it does not exist.
- Insert the disk labeled "Data Disk 2" into your disk drive. From the DOS prompt, type XCOPY A:\*.\* C:\FAR23LDS\DATA2\\*.\*. This command assumes that you installed the FAR23 Loads programs in the directory C:\FAR23LDS.
- If you are running from Windows 3.1, you can create an icon for the program. First, create a program group, then create a program item. To do this, from Program Manager, select the File menu. Select the New option, then choose Program Group. Enter the following information, then click OK:

Description:	FAR23 Loads
Group File:	(you can leave this blank)

To create the program item, from Program Manager, select the File menu. Select the New option, then choose Program Item. Enter the following information and click OK:

Description:	FAR23 Loads
Command Line:	C:\FAR23LDS\FAR23LDS.EXE
Working Directory:	C:\FAR23LDS

The installation of the plotting programs is described later in this section.

To install the Qbasic programs, copy the files from the disk to a directory on your hard drive. You can run these programs by typing the filename at the DOS prompt.

#### 2.4 RUNNING FAR23 LOADS PROGRAM.

To run the program FAR23 Loads, at the DOS prompt, type

FAR23LDS

When the program starts, the main menu appears as shown in figure 2.1. This window has two options: File and Color.

The File menu has only one item, which is to exit FAR23 Loads. Selecting this option returns you to the DOS prompt.

The Color option allows you to change the color scheme displayed on your window.

From the main menu window, the individual modules are selected. You can use the mouse to select the module. Or you can use the TAB key to move to the appropriate module, then press Enter to start the module.



FIGURE 2.1 FAR23 LOADS MAIN MENU WINDOW

#### 2.5 RUNNING FAR23 LOADS MODULES.

After selecting the module from the main menu, the input window for that module will appear.

#### 2.5.1 Input Windows.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window usually includes three menu options: File, View (or Notepad), and Color. If there are multiple windows for input, these appear as menu options. For WTONECG and WTENV, there are two other options, Size and Edit.

The File menu is used to store and retrieve data from the program. The *New* command generates a new input window. *Open* allows you to retrieve a previously created and saved input file. *Save Input As* will allow the input data to be saved to a file. *Save Output As* will allow the output file to be saved to a file. *Print Output* allows you to perform the calculations and print the output file. *Return to Main Menu* exits the module and returns to the FAR23 Loads Main Menu.

The *Open* command is used to retrieve a previously created and saved file. When you select *Open*, a window appears as shown in figure 2.2. There are three main areas of the window. At the top, the File Name appears. Below this, the current path name is given, and below that are two boxes. The box on the left lists the files in the directory, and the box on the right is the directory tree. Each box has a scroll bar so that you can move through the list. To select a file, move the cursor to the file so that it is highlighted, then click the mouse button. The file should appear in the File Name box. Use the "OK" button when you find the file you want to open, or "Cancel" to close this window without opening a file. Note that when you select "OK", the file that appears in the File Name box will be opened.



FIGURE 2.2 FAR23 LOADS WINDOW FOR OPENING FILES

In the file name field, you can specify the file that you want. Enter the name or \*.\*, then press enter. In the left box, the list of files will appear. To change directories, in the right box, select the appropriate directory. When you change directories, the file list in the left box will be updated.

To search for all files, enter \*.\* for the file name and press Enter. Now all files in the directory will appear Note that if you enter "\*", only files without a file name extension will appear. For example, if you enter "\*", AILERON.INP will not appear, but BBFLTLDR will. If you use "\*.\*", then both files will appear. For the sample airplanes, there are files without file extensions.

The Notepad (or View) option opens a Notepad program where you can review your input and output files on the window.

The Color option allows you to change the color scheme displayed on your window.

The input data that is required depends on the module. Each input that is required will be displayed with a field for entering the data. Some of the modules have more than one page of required input. Be sure to enter all required data before calculating the results, as most modules will calculate the results even without all the input.

Some of the fields will have default values. If you want to change this value, delete the data in the field first before entering your new data.

The input can usually be printed by selecting the print option from the File menu. You can save your input data to a file by selecting this option from the File menu.

As mentioned, several modules have more than one input window. These modules are AIRLOADS, AIRLOAD4, FLTLOAD5, AILERON, FLAPLOAD, WINGINER, ENGLOAD5, LANDLOAD, TAILDIST, and ONENGOUT. In these modules, there is no indication as to which page you are on or which pages you have already filled in. However, you should enter the data in all the windows before doing the analysis. If you do the analysis before entering all the data, you may get error messages, such as divide by zero, or you may get incorrect results since all input data was not entered.

The SELECT module also includes multiple input windows. In this module, the analysis must be run while you are on the appropriate input window. You will have to run the analysis four times, once for each component (wing, fuselage, horizontal tail, and vertical tail).

Some input data must be entered on more than one input window in more than one module. However, the input format may not be consistent. For example, sometimes area is entered as  $in^2$ , while other times it's entered as  $ft^2$ . And, for tail areas, sometimes the total area is needed, and other times the required area is the area for only one side. Some modules require angles as input, but the convention for positive and negative angles is not consistent throughout the program.

Note: It is recommended that you use *Tab* to move to the next input field. If you use the mouse to move between fields, you may get a "Divide by zero" error. In STRSPEED, if you open a previously created file, you must tab through all the fields even though you are not changing every field to complete the data entry. Otherwise the program will give a "Divide by zero" error.

#### 2.5.2 Running the Analysis.

For most modules, after all input are entered in the input window, the analysis is started by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results; the first option saves the output to a file, and the second option sends the output data to a printer or file.

For the modules with more than one input window, you can run the analysis from any window. Be sure you have filled in the data for all input windows before doing the analysis.

The output from some of the modules will be used as input for other modules. Table 2.2 lists each module, the section that describes it, the module that the input comes from, and the modules that use the output.

MODULE	SECTION	INPUT FROM	OUTPUT TO
WESTIMA	3		WTONECG, WTENV
WTONECG	4	WTESTIMA	FLTLOADS, SELECT, LANDLOAD, ONENGOUT
WTENV	5	WTESTIMA	FLTLOADS
WINGGEOM	6		STRSPEED, AIRLOADS, AIRLOAD4, FLTLOADS, SELECT, ONENGOUT
STRSPEED	7	WINGGEOM	MACHLIM, FLTLOADS, AILERON, FLAPLOAD
MACHLIM	8	STRSPEED	
AIRLOADS	9	WINGGEOM, SELECT	SELECT, NETLOADS
AIRLOAD4	10	WINGGEOM, SELECT	SELECT, NETLOADS
FLTLOADS	11	WTONECG, WTENV, WINGGEOM STRSPEED, AIRLOADS, AIRLOAD4	SELECT, WINGINER
SELECT	12	WTONECG, WINGGEOM, FLTLOADS	AIRLOADS, AIRLOAD4, WINGINER, TAILDIST
AILERON	13	STRSPEED	
FLAPLOAD	14	STRSPEED	
WINGINER	15	FLTLOADS, SELECT	NETLOADS
NETLOADS	16	AIRLOADS, AIRLOAD4, WINGINER	
ENGLOADS	17		
LANDLOAD	18	WTONECG, LGFACTOR	
LGFACTOR	19		LANDLOAD
TAILDIST	20	SELECT	
TABLOADS	21		
ONENGOUT	22	WINGGEOM, WTONECG	

 TABLE 2.2
 SUMMARY OF MODULES IN THE FAR23 LOADS PROGRAM

.

#### 2.5.3 Saving and Printing Results.

Each module can create an output file which contains the input and the results of the analysis. This output can also be sent directly to the printer, in which case no output file is created. This choice is made when you run the analysis.

To save the results of the analysis to a file, select *Save Output As* from the File menu. Then enter the name of the file. If this file already exists, it will be overwritten. You will not be warned before this happens. For most modules, you can also select *Print Output* from the File menu, and then send the output to a file.

To print the results of the analysis, select *Print Output* from the File menu. Generally, this option lets you print to LPT1, LPT2, LPT3 or a file. If you send the output to a printer, you can select the number of copies to print.

If you want to print the results and save the output to a file, you must select both options.

Notes: In TAILDIST and LANDLOAD, the *Print Output* option does not work. You should save the output to a file, then print the file from DOS or from a program such as Notepad.

Some of the output files, especially from LANDLOAD, contain data strings that are longer than 80 columns. Depending on the printer, these lines will either wrap to the next line or be cut off. If your printer has options such as condensed print mode or landscape mode, use these to get a better printout. The FAR23 Loads program has no printer options for changing fonts or page orientation, so all changes must be made using your printer controls. Another option for printing the files is to bring the output file into word processor and then change font size or page orientation so the data fits on the page.

#### 2.6 SPECIAL CASES AND EXCEPTIONS.

In AIRLOADS and AIRLOAD4, if you open an existing data file, you may get an error message about reading past the end of file. This means that the data file does not have enough data for all the input windows, and is probably missing data for the seventh and eighth windows. As much data as possible will be filled in. You should check all the windows to verify the data before running the analysis.

In SELECT, the data from FLTLOADS must be read in before any analysis can be done, so the File menu includes only the options *Read V-n FLTLOAD data from disk* and *Return to Main Menu*.

In TAILDIST, the only option in File menu is *Return to Main Menu*. The options for the types of analysis are included in the window.

If you have trouble running any of the FAR23 Loads modules from the main menu, you may have a problem with memory. The program requires enough memory for the main program FAR23LDS plus the module that you are running. A minimum of 580K of free conventional

memory is required to run all modules. If your computer does not have enough memory available, the module will not run. To check your memory, at the DOS prompt type

 $C: \setminus MEM$ 

If you have problems running the modules from the main menu, try running them as stand-alone programs. To do this, at the DOS prompt, type

C:\ program password

where program is the name of the module, and the password is 8191995.

#### 2.7 FAR23 PLOT PROGRAMS.

The graphics programs FARPLOT and GEOMPLOT are stand-alone programs for plotting data and drawing airplane geometries. These programs read the output data from FAR23 Loads programs and graph it using a variety of options. The plotting programs are designed so that the user can customize the graphs for use in reports.

GEOMPLOT is used to plot the geometric surfaces using the data from WINGGEOM (section 6). FARPLOT is used to plot all other results. Table 2.3 shows the data that can be plotted.

In this manual, the plotting programs are discussed in each section if there are results that can be plotted. Detailed instructions for using the plotting programs are included in the appendix of reference 1.

#### 2.7.1 Installing FAR23 Plot.

To install the plotting programs, follow these steps:

- Insert the disk labeled "FAR23 Plot" into your disk drive. This drive is assumed to be the "a" drive in these instructions.
- DOS prompt: At the DOS prompt, type the following: a:setup.
- Windows 3.1: Go to File menu option in the Program Manager and select the "RUN" option. At the command line field, type a:setup, then press Enter.
- Windows 95: Go to Start, select Run, then type a:setup at the prompt.
- You will be asked to specify the source directory containing files. This is "a:\".
- Next you will be asked to specify the destination directory. Enter the full path of the directory where you want the files. If the directory does not exist, it will be created.

• If you are running from Windows 3.1, you can create an icon for the program. This icon can be in the FAR23LDS program group. To create the program item, from Program Manager, select the File menu. Select the New option, then choose Program Item.

Enter the following information:

Description:	FAR23 Plot
Command Line:	C:\FAR23LDS\FAR23PLT.BAT
Working Directory:	C:\FAR23PLT

If you want to print your plot, you need to select your printer before running either FARPLOT or GEOMPLOT. Two batch files, FAR23PLT and PLOT, are set up to select the printer and run the plotting program. FAR23PLT will run FARPLOT, and PLOT will run GEOMPLOT.

When plotting your results, the file containing the analysis results must have the correct filename extension. If the file is not correctly named, the plotting program can not open it. These filename extensions are given in table 2.3.

To print the plot, hold down the shift key and press the print screen key.

After you plot your data, press any key to return to the main window.

FILE			
EXTENSION	DESCRIPTION	CREATED BY	SECTION
*.WTS	Plots the useful load envelope for an airplane.	WTENV	5
	Weight versus fuselage station.		
*.WT~	Plots the useful load envelope for an airplane	WTENV and	5
	with labels saved from a previous session.	FARPLOT	
*.PLT	Geometry file. Plots the airplane's geometry.	WINGGEOM	6
*.SPD	Structural speeds file. Plot altitude versus the	MACHLIM	8
	operating limit speeds $M_C$ , $M_{NE}$ , $M_D$ , and $M_{FC}$ .		
*.AIR	Airloads file. Plots the spanwise aerodynamic	AIRLOADS,	9, 10
	coefficients $C_L$ , $C_{DI}$ , $C_{PD}$ , $C_D$ , and $C_M$ .	AIRLOAD4	
*.LDS	V-n diagram file. Plots the basic V-n diagram	FLTLOADS	11
	data and the V-n diagram data from the critical		
	loads program.		
*.NET	Netloads file. Plots the spanwise net load for	NETLOADS	16
	both the dimensional values and the coefficients		
	of $M_{xx}$ , $M_{yy}$ , $M_{zz}$ , $S_x$ , $S_z$ , $F_x$ , and $F_z$ .		
*.TLD	Rational tail loads file. Plots the rational tail	TAILDIST	20
	loads for the horizontal and vertical tail		
	surfaces.		

TABLE 2.3 SUMMARY OF PLOT FILES

#### 3. WEIGHT ESTIMATION.

#### 3.1 WTESTIMA DESCRIPTION.

There are three weight estimation modules in the FAR23 Loads program. The first module, WTESTIMA, estimates the weight of the airplane and its major components. The other two modules, WTONECG and WTENV, are discussed in sections 4 and 5, respectively.

To estimate the weight of the airplane and components, the following information is required:

- number of engines,
- total horse power,
- type of engine (4-cycle reciprocal, 2-cycle reciprocal, turbocharged, turboprop, liquid-cooled),
- hours of endurance at cruise speed,
- number of seats,
- total baggage weight, and
- whether the cabin is pressurized.

The takeoff weight is a function of the useful load, and the useful load consists of three items: the weights of passengers, baggage, and fuel. The passenger weight is assumed to be 170 pounds per seat. The fuel weight is calculated for the chosen endurance time at cruise altitude and is based on the total horsepower and engine type.

Statistically, the ratio of empty weight to takeoff weight has been found to be 0.62. The empty weight  $(W_{empty})$  is calculated as the takeoff weight minus the useful load,  $W_{empty}=W_{TO}$ . By knowing the useful load  $(W_{use})$ , the takeoff weight  $(W_{TO})$  can be determined as

$$WTO = \frac{Wuse}{(1-K)}$$

where K is 0.62 plus a factor to adjust for the engine type and pressurized cabins. For an unpressurized 4-cycle reciprocal single engine, the adjustment factor is zero. Table 3-1 lists the adjustments to K for various engine types.

	FACTOR FOR ADJUSTING K
single engine	К - 0.0
multiengine	K + 0.01
liquid-cooled engine	K + 0.01
super or turbo charge engine	K + 0.01
turboprop engine	K - 0.05
if pressurized cabin	K + 0.02
if one seat	K - 0.04

#### TABLE 3.1 ADJUSTMENT FACTORS FOR K

The component weights, except for the powerplant, follow statistical percentages of the takeoff weight. Table 3-2 shows the percentage of takeoff weight that is used for each component. These percentages are derived from data on typical airplanes under 12,500 pounds takeoff weight [1].

The weight of the powerplant and its components are a percentage of the installed engine weight, which is a function of the rated horsepower of the engine.

COMPONENT	PERCENTAGE OF	TAKEOFF WEIGHT
Fuselage	9.8	2%
Wing	10.3	36%
Tail	2.3	4%
Nacelle	1.4	6%
Landing gear	5.7	1%
Controls	1.5	0%
	1 Engine	2 Engines
Instruments and navigational equipment	0.44%	1.18%
Pneumatics	0.099%	0%
Electrical	2.41%	2.69%
Electronics	0%	0.24%
Furnishings and equipment	4.41%	4.58%
Environmental and anti-ice	0.31%	1.18%
Miscellaneous other systems	0.22%	0.79%

#### TABLE 3.2 COMPONENT WEIGHT AS PERCENTAGE OF TAKEOFF WEIGHT

#### 3.2 RUNNING WTESTIMA.

To run WTESTIMA, select the module from the main menu window. You will see the main input window as shown in figure 3.1.

Airplane Weight Estimation (C) File Notepad Color	) Hal C McMaster 1989, 1990, 1993 👘
Name and Model of Your Airplane: 6	PLACE SINGLE ENGINE GENERAL AVIATION AT
Total Max HP of Engines: 265 How Many Engi	ines: 1 How Many Seats: 6
Hours for Your Airplane to Fly on Full Tanks at Cruise Power: 3	What Is Total Baggage Weight, Pounds: Ø
Is Airplane (P)Pressurized or (U)Unpressurized:	Enter 2 Letter Symbol for Engine Type: RF for 4 Cycle Recip RT for 2 Cycle Recip IC for turbocharged IP for turbprop LC for Liquidcooled

FIGURE 3.1 WTESTIMA INPUT WINDOW

#### 3.2.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes the three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The *New* command generates a new input window. *Open* allows you to retrieve a previously created and saved input file. *Save Input As* will allow the input data to be saved to a file. *Save Output As* will perform calculations and allow the output data to be saved to a file. *Print Output* allows you to perform the calculations and print the output data to a printer or a file. *Return to Main Menu* exits from WTESTIMA and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program, where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input that is required includes the title, maximum continuous horsepower, number of engines, number of seats, endurance at cruise power, total baggage weight, if the cabin is pressurized, and the type of engine.

#### 3.2.2 Running the Analysis.

After all input are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second selection can also print the output.

#### 3.3 WTESTIMA OUTPUT.

The output from the program WTESTIMA consists of the maximum takeoff weight, empty weight, and weights of the major components of the airplane. The components are grouped into structure, powerplant, and systems.

The results of WTESTIMA are used in the programs WTONECG (section 4) and WTENV (section 5) to determine the envelope of useful loadings and to calculate weight, center of gravity, and inertia of the airplane.

#### 4. WEIGHT AND INERTIA.

#### 4.1 WTONECG DESCRIPTION.

WTONECG calculates the weight, center of gravity, and inertia of the airplane for any specific loading configuration. These calculations are done at the four c.g. locations defining the weight structural limits diagram. These c.g. locations are the aft gross weight, the forward gross weight, the most forward reduced weight, and the minimum weight. On an airplane with retractable landing gear, it is usually necessary to account for the shift in c.g. due to retraction of the gear with a second set of four loading conditions.

The weight limits are defined in FAR 23.25. The maximum weight must not be less than the empty weight plus 170 pounds for each seat for normal and commuter categories (or 190 pounds for utility and acrobatic category airplanes) plus oil at full capacity and a half hour of fuel at maximum continuous power. Also, the maximum weight must not be less than the empty weight plus minimum crew and full tank capacity of fuel and oil.

The minimum weight is not more than the empty weight (including unusable fuel, full oil, and fluids) plus the minimum crew (usually the pilot) and a half hour of fuel at maximum continuous power. For turbojet powered airplanes, the required fuel is 5 percent of the total fuel capacity.

The location of the weight components can be established from the three-view drawing or inboard profile drawing. The weight can be obtained from the component manufacturer, from actual weighing of the part, by calculation from drawing dimensions and material density, or from WTESTIMA (see section 3).

The input data that are required are the coordinates, weight and moment of inertia for each of the components of the airplane, and useful loads for the loading. The inertia of small components may be neglected with no appreciable effect on the total inertia of the airplane.

The component data is entered in the weight database. This is the same database file use by WTENV. The database file can be created and modified in either WTONECG or WTENV.

#### 4.2 DEVELOPING THE WEIGHT DATABASE.

The database contains the component weight data and the location dimensions for all components that you wish to consider. The same database is used for both WTENV and WTONECG.

The default value for the maximum number of components in the database is 100, although the user may change this value. The database is divided into three sections: empty weight items, minimum weight items, and discretionary items. Fifty percent of the items are considered empty weight items, ten percent are minimum weight items, and forty percent are discretionary items. The type of item is indicated by the item number. If you use the default value of 100 items, then items 1 through 50 are empty weight items, items 51 through 60 are minimum weight items, and

items 61 through 100 are discretionary items. When you enter data into the database, you must enter it at the proper item number, or you can use the Edit option to move items.

#### 4.3 FAR 23 REGULATIONS.

The regulations for weight limits are defined in FAR 23.25, and repeated here for convenience.

#### 4.3.1 FAR 23.25 Weight Limits.

#### 4.3.1.1 Maximum Weight.

The maximum weight is the highest weight at which compliance with each applicable requirement of Part 23 (other than those complied with at the design landing weight) is shown. In addition, for commuter category airplanes, the applicant must establish a maximum zero fuel weight. The maximum weight must be established so that it is

- a. not more than
  - (1) the highest weight selected by the applicant;
  - (2) the design maximum weight, which is the highest weight at which compliance with each applicable structural loading condition of Part 23 (other than those complied with at the design landing weight) is shown; cr
  - (3) the highest weight at which compliance with each applicable flight requirement is shown, except for airplanes equipped with standby power rocket engines, in which case it is the highest weight established in accordance with Appendix E of Part 23; or
- b. not less than the weight with
  - (1) each seat occupied, assuming a weight of 170 pounds for each occupant for normal and commuter category airplanes, and 190 pounds for utility and acrobatic category airplanes, except that seats other than pilot seats may be placarded for a lesser weight; and
    - (a) oil at full capacity, and
    - (b) at least enough fuel for maximum continuous power operation of at least 30 minutes for day-VFR approved airplanes and at least 45 minutes for night-VFR and IFR approved airplanes; or
  - (2) the required minimum crew, and fuel and oil to full tank capacity.

#### 4.3.1.2 Minimum Weight.

The minimum weight (the lowest weight at which compliance with each applicable requirement of Part 23 is shown) must be established so that it is not more than the sum of

- a. the empty weight determined under FAR 23.29,
- b. the weight of the required minimum crew (assuming a weight of 170 pounds for each crewmember), and
- c. the weight of
  - (1) (for turbojet powered airplanes), 5 percent of the total fuel capacity of that particular fuel tank arrangement under investigation and
  - (2) (for other airplanes), the fuel necessary for one-half hour of operation at maximum continuous power.

#### 4.4 RUNNING WTONECG.

To run WTONECG, select WTONECG from the main menu window. The first WTONECG window is shown in figure 4.1. You must open an existing file before you can enter data.



#### FIGURE 4.1 WTONECG FIRST WINDOW

#### 4.4.1 First Window.

The first window is displayed when the module starts; it includes four menu options: File, Notepad, Size, and Color. When the WTONECG module is first opened, the File menu includes

only two options: *Open Weight Database* or *Return to Main Menu*. You must select *Open Weight Database* to open an existing database or to create a new database.

4.4.2 Input Window.

When you open a file, you will see the message shown in figure 4.2. Click *OK* to continue. The file that you select is not checked to be sure it is a database file. If the data in the input window appears strange, then you may not have opened a database file. Two example database files, WTENV36 and M2002576, are included on the installation disk.

After the database file is opened, there are five menu options: File, Notepad, Edit, Size, and Color.

tem No Co	em No Component De Note: This is an old file.		lle.	
Weight 1b	X		ly 1b-in^2	Iz 1b-in^2

FIGURE 4.2 MESSAGE WINDOW FOR WTONECG AND WTENV

After a database file is opened, the File menu can be used to store and print data. Open Weight Database allows you to retrieve a previously created and saved database file. Save Weight Database As will allow the data to be saved with a new name. Save Weight Calculation As will allow the calculations to be saved with a new name. Print Weight Database and Calculation allows you to perform the calculations and print both the database and the results of the calculations to a file or printer. Print Weight Calculation only allows you to perform the calculations to a file or printer. Return to Main Menu exits from the WTONECG program and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Edit option allows you to move or delete items in the database. To move an item in the database, scroll through the database to that item. Then select Edit, select *Move Current Item To*, and enter the new number to move to. Select OK to complete the move. To delete an item from

the database, scroll through the database to that item. Then select Edit and select *Delete Current Item.* The current item is immediately deleted—you will not be asked to confirm the deletion!

The Size option sets the number of items in the database. Figure 4.3 shows this option. The default value is 100. The Color option allows you to change the color scheme displayed on your window.

Weight databa Item No <u>Comp</u>	What is the maximum number of weight items you will include in you weight data base?	ОК	
1 WING,	(Default is 100)	Cance 1	
Weight 1b			12 ^2 1b-in^2
330 9	100-		

FIGURE 4.3 SIZE OPTION FOR WTONECG AND WTENV

Figure 4.4 shows the input window. The data that is required are the coordinates, weight, moment of inertia for each of the components of the airplane, and useful loads for the loading. The inertia of small components may be neglected with no appreciable effect on the total inertia of the airplane.

Item No Component Description						
1 WING, OUTBOARD						
Weight	X inch	y jach	Z	Ix lb=in^2	ly lb-in^2	lz lb-in^2
330	97.869	0	87.734			

FIGURE 4.4 WTONECG INPUT WINDOW
### 4.4.3 Running the Analysis.

After all data are entered in the database, run the analysis by opening the File menu and selecting *Save Weight Calculation As, Print Weight Database and Calculation,* or *Print Weight Calculation only.* Any of these options will calculate the results and save the output to a file. The last two options will also print the output.

# 4.5 WTONECG OUTPUT.

The WTONECG output includes the weight, center of gravity, the inertias with respect to airplane coordinates, the inertias with respect to principal axes, and the angle  $\theta$  for a single load configuration. Inertias are given in both slugs-ft<sup>2</sup> and lbs-in<sup>2</sup>. The airplane weight and center of gravity are needed for the calculation of balanced flight and landing conditions in modules FLTLOADS and LANDLOAD (sections 11 and 18). The airplane inertia is needed for the calculation of maneuver and gust flight conditions and unbalanced landing conditions in modules SELECT and ONENGOUT (sections 12 and 22).

### 5. ENVELOPE OF LOADING CONDITIONS.

### 5.1 WTENV DESCRIPTION.

The module WTENV calculates the envelope of discretionary useful loading. It uses the same database as WTONECG (section 4). The database contains the component weight data and location dimensions. This weight data comes from WTESTIMA or actual known weights; the location dimensions come from the three-view drawing.

WTENV can be used to create or modify the database by adding, deleting, changing, and moving component data. The minimum flight weight is calculated, and the envelope of enclosing all possible loadings is calculated. From the plot of the envelope of useful loadings, the four structural limit points can be selected to include the most desirable and practical loadings. See section 4 for additional discussion of the weight database.

### 5.2 RUNNING WTENV.

To run WTENV, select it from the main menu window. The first window for WTENV (as in WTONECG) is used to open a database; it includes four menu options: File, Notepad, Size, and Color.

WTENV uses the same database file as WTONECG. When the WTENV module is first opened, the File menu includes only two options: *Open Weight Database* or *Return to Main Menu*. You must select *Open Weight Database* to open an existing file or to create a new database. When you open a file, you will see a message shown in figure 4.2. Click *OK* to continue. The file that you select is not checked to be sure it is a database file. If the data in the input window appears strange, then you did not open a database file. Two examples of database files, WTENV36 and M2002576, are included on the installation disk.

### 5.2.1 Input Window.

After a file is opened, the input window appears as shown in figure 5.1. The window also includes five menu options: File, Notepad, Edit, Size, and Color.

After a database file is opened, the File menu is used to store and print data. Open Weight Database allows you to retrieve a previously created and saved database file. Save Weight Database As will allow the database to be saved to a file. Save Weight Envelope As allows the calculations to be saved to a file. Print Weight Database and Envelope allows you to perform the calculations and print both the database and the results of the calculations to a printer or file. Print Weight Envelope only allows you to perform the calculations and send only the results to a file or printer. Return to Main Menu exits from WTENV and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program, where you can review your input and output files.

deight dat	abase file:	C:\FAR23L	DSNM200257	6 is opend.		
tem No	Component C.S.NOSE	Descripti	on			
-	<u>u u nooz</u>				L.	<b>7</b> -
Veight 1b	x inch	inch	inch	lb-in^2	lb-in^2	12 1b-in^2
108.8	102	0	57	261229	Ø	261229

FIGURE 5.1 WTENV INPUT WINDOW

The Edit option allows you to move or delete items in the database. To move an item in the database, scroll through the database to that item. Then select Edit, select *Move Current Item To*, and enter the new number to move to. Select OK to complete the move. To delete an item from the database, scroll through the database to that item. Then select Edit and select *Delete Current Item*. The current item is immediately deleted—you will not be asked to confirm the deletion!

The Size option sets the number of items in the database. The default value is 100. The Color option allows you to change the color scheme displayed on your window.

The input for the weight database consists of the component description, weight, and location coordinates. To enter the data, use the mouse to move to the appropriate cell. To move through the database, use the up and down arrows or use the mouse to move the scroll bar. The tab key will move between input cells.

To start a new weight database file, open an existing file and remove all the existing data. Then you can enter the data for the new airplane. Two files, WTENV36 and M2002576, are included on the installation disk as sample database files.

# 5.2.2 Running the Analysis.

After all data are entered in the database, run the analysis by opening the File menu and selecting *Save Weight Envelope, Print Weight Database and Envelope*, or *Print Weight Envelope*. Any of these options will calculate the results and save the output to a file. The last two options print the output. After selecting an option to do the calculations, you will be asked to enter the airplane designation. This designation is written in the output file.

If you want to plot the flight envelope, you should save the database and envelope to a file. To use the FAR23 Plot program, the filename must have the extension *.WTS*.

## 5.3 WTENV OUTPUT.

The output from WTENV is the envelope of useful loads and includes the weight and c.g. of the airplane for given loading conditions. This data is used in FLTLOADS (section 11).

## 5.4 GRAPHICS.

The separate graphics program FAR23 Plot can be used to draw the weight envelope of discretionary useful loading and the envelope of structural weight limits. An example of this plot is shown in figure 5.2. The FAR23 Plot program is described in the appendix of reference 1.

To use the FAR23 Plot program, the filename must have the extension .WTS.



### FIGURE 5.2 EXAMPLE OF USEFUL LOAD ENVELOPE AND STRUCTURAL LIMITS

# 6. AERODYNAMIC SURFACE GEOMETRY.

### 6.1 WINGGEOM DESCRIPTION.

The geometric properties for all aerodynamic surfaces on the airplane are calculated by the program WINGGEOM. The aerodynamic surfaces include the wing, aileron, aileron tab, flap, horizontal tail, elevator, elevator tab, vertical tail, rudder, and rudder tab.

WINGGEOM must be used to analyze each aerodynamic surface. For each surface, the user enters the coordinates to define the leading and trailing edges of the surface. The program divides the surface into elements, and calculates the area of each element.

The input required for this program includes the coordinates of the leading and trailing edge of the aerodynamic surface. Two points define a straight leading or trailing edge. Three points can be used to define the leading edge of a wing with a leading edge extension at the inboard end of the wing. Three points would also be used to define a straight leading edge with a raked tip. A complex or curved leading or trailing edge can be defined by a series of points assuming short straight lines between points.

### 6.2 RUNNING WINGGEOM.

To run WINGGEOM, select the WINGGEOM button from the main menu window. You will see the main window for this program as shown in figure 6.1.

Aerodynamic Surface Geometry	C) Hal C. McMaster 1988
Enter name of wing or surface - such as 'HORIZONTAL STABILIZER' without quotes:	WING SURFACE GEOM PROP FOR 6 PL GENE
Is surface symmetrical about Y=0 <y n<="" or="" td=""><td>D? If surface is Y</td></y>	D? If surface is Y
symmetrical, then enter data for one sid	le only.
How many points define	How many points define
the leading edge ? 3	the trailing edge ? 2
Enter coordinates (INCHES) of leading	Enter coordinates (INCHES) of trailing
edge X, Y (+X is aft +Y is outboard)	edge X, Y (+X is aft +Y is outboard)
starting at lowest wing station Y.	starting at lowest wing station Y.
Point No X (INCHES> Y (INCHES) 1	Point No X (INCHES) Y (INCHES) †
1 45 0	1 146 Ø
The surface is devided into 20 how many increments of DY ?	Do you want to print Y out of element data?

FIGURE 6.1 WINGGEOM INPUT WINDOW

# 6.2.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The *New* command generates a new input window. *Open* allows you to retrieve a previously created and saved input file. *Save Input As* will allow the input data to be saved to a file. *Save Output As* will allow the output data to be saved to a file. *Print Output* allows you to perform the calculations and print the output file to a printer or a file. *Return to Main Menu* exits from WINGGEOM and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program, where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input that is required is the name of the aerodynamic surface, whether the surface is symmetrical about the x-x axis (y=0), the number of increments to divide the surface into, and the coordinates for the leading and trailing edge of the surface. For the coordinates, the x value is the fuselage station and the y value is the wing station. Start your input with the lowest fuselage station.

To enter the leading edge points, first enter the number of points. Move to the area for the x and y coordinates. For the first point, enter the x value, then the y value. Now using the mouse, click on the bar next to the y-coordinate entry field. The point number should advance to the next number. Now enter the next pair of x-y coordinates. Be sure to press Enter or <TAB> after entering your value, before using the mouse. Continue until all data are entered. If you make an error, you can go back to review the data or make corrections by clicking at the top of the bar.

The data for the trailing edge are entered in the same way as the leading edge.

The final input is the number of increments to divide the surface into. Enter Y or N if you want the element data printed out.

# 6.2.2 Running the Analysis.

After all inputs are entered in the input window, start the analysis by opening the File menu and selecting either *Save Output As* or *Print Output*. Both options will calculate the results and save the output to a file. The second option will also print the output.

To do the calculations for multiple aerodynamic surfaces, enter the data for the first surface, and save your input and output. Then, from the File menu, select *New* to clear the data from the window. Now enter the data for the next surface.

### 6.3 WINGGEOM OUTPUT.

The module WINGGEOM calculates the area, aspect ratio, mean aerodynamic chord (MAC), and the butt line and fuselage station of the leading edge of the MAC. This output data is needed as input to the modules STRSPEED for structural speeds (section 7), AIRLOADS and AIRLOAD4 for air loads (sections 9 and 10), FLTLOADS for the flight envelope (section 11), SELECT for the selection of critical loads (section 12), and ONENGOUT for the one-engine-out loads (section 22).

The output echoes the input parameters, including the coordinates of the leading and trailing edges, then prints the results. Optional output includes the data for the sections that the surface was divided into. Appendices A and B of reference 1 show the output of WINGGEOM for two example airplanes. WINGGEOM was used to generate output for the following components: wing, aileron (forward and aft of the hinge line), flap, vertical tail, rudder, horizontal tail, elevator (forward and aft of the hinge line), and elevator tab.

### 6.4 GRAPHICS.

The aerodynamic surfaces can be drawn with the GEOMPLOT graphing program. This program is described in the appendix of reference 1, and examples of the figures are shown in appendices A and B of reference 1.

The output files from WINGGEOM are read by the plotting program. The filenames must have the extension *.PLT*.

The results from several surfaces can be plotted together. For example, the wing, aileron, and flap can be plotted together. To do this, plot the wing first and overlay the aileron and flaps. An example of this plot is shown in figure 6.2.



FIGURE 6.2 EXAMPLE OF AERODYNAMIC SURFACES PLOT

## 7. STRUCTURAL DESIGN SPEEDS AND MANEUVERING LOAD FACTORS.

### 7.1 STRSPEED DESCRIPTION.

The structural design speeds and maneuvering load factors are calculated by the module STRSPEED. This module lets you choose the category in which you will certify the airplane: normal, utility, or acrobatic. STRSPEED calculates the minimum structural design speeds and load factors and then verifies that the chosen structural design speeds are greater than the minimum requirements and that the margins between speeds are greater than the requirements. If necessary, the speeds are adjusted to meet the requirements relative to cruise speed.

The structural design speeds and maneuver load factors must be selected so that they are greater than the minimum values specified in FAR 23.335 (design air speeds) and FAR 23.337 (limit maneuvering load factors). Also, the relationships between the structural design speeds must meet the minimum margins between speeds that are specified in FAR 23.335.

The module STRSPEED calculates the minimum structural design speeds and load factors and then verifies that the chosen structural design speeds are greater than the minimum requirements and that the margins between speeds are greater than the requirements. If necessary, the speeds are adjusted to meet the requirements relative to cruise speed.

The maneuvering loads factors are defined in FAR 23.337 and summarized in table 7.1.

CATEGORY	POSITIVE LOAD FACTOR	NEGATIVE LOAD FACTOR
	2.1 + [24000/(W+10000)]	
Normal	but not greater than 3.8	-0.4 x positive load factor
Utility	4.4	-0.4 x positive load factor
Acrobatic	6.0	-0.5 x positive load factor

### TABLE 7.1 MANEUVERING LOAD FACTOR LIMITS

After the design speeds are determined, the Mach limitations at shoulder altitude are calculated for  $V_C$  and  $V_D$ . To calculate the limiting values of  $M_C$  and  $M_D$ , the temperature and speed of sound at altitude are calculated from

T = 59.0 - 0.003566ha = 29.02(T+459.4)<sup>0.5</sup>

where:

T = temperature at altitude (°F) h = altitude (feet)

a = speed of sound (knots)

Then the air speed and Mach number can be calculated:

$$\sigma = (1 - 0.00006879h)^{4.258}$$
$$V_{C-TAS} = \frac{V_{C-EAS}}{\sigma^{0.5}}$$
$$V_{D-TAS} = \frac{V_{D-EAS}}{\sigma^{0.5}}$$
$$M_{C} = \frac{V_{C-TAS}}{a}$$
$$M_{D} = \frac{V_{D-TAS}}{a}$$

where:

σ	=	ratio of density at altitude to density at sea level
$V_C$	=	design cruise air speed (knots)
$V_D$	=	design dive air speed (knots)
$M_C$	=	Mach number at the design cruise speed $V_C$
$M_D$	=	Mach number at the design dive speed $V_D$
EAS	=	equivalent air speed
TAS	=	true air speed

# 7.2 FAR 23 REGULATIONS.

The requirements for the design air speeds are defined in FAR 23.335, and the limit maneuvering load factors must meet the requirements of FAR 23.337.

# 7.2.1 FAR 23.335 Design Air Speeds.

Except as provided in paragraph a.(4) of this section, the selected design air speeds are equivalent air speeds (EAS).

- a. For design cruising speed,  $V_C$ , the following apply:
  - (1)  $V_C$  (in knots) may not be less than
    - (a) 33  $\sqrt{W/S}$  (for normal, utility, and commuter category airplanes) and
    - (b) 36  $\sqrt{W/S}$  (for acrobatic category airplanes).
  - (2) For values of *W/S* more than 20, the multiplying factors may be decreased linearly with *W/S* to a value of 28.6 where W/S = 100.
  - (3)  $V_C$  need not be more than 0.9  $V_H$  at sea level.

- (4) At altitudes where an  $M_D$  is established, a cruising speed  $M_C$  limited by compressibility may be selected.
- b. For design dive speed,  $V_D$ , the following apply:
  - (1)  $V_D/M_D$  may not be less than 1.25  $V_C/M_C$ .
  - (2) With  $V_{Cmin}$  (the required minimum design cruising speed)  $V_D$  (in knots) may not be less than
    - (a) 1.40  $V_{Cmin}$  (for normal and commuter category airplanes);
    - (b) 1.50  $V_{Cmin}$  (for utility category airplanes); and
    - (c)  $1.55 V_{Cmin}$  (for acrobatic category airplanes).
  - (3) For values of *W/S* more than 20, the multiplying factors in paragraph b.(2) of this section may be decreased linearly with *W/S* to a value of 1.35 where *W/S* = 100.
  - (4) Compliance with paragraphs b.(1) and (2) of this section need not be shown if  $V_D/M_D$  is selected so that the minimum speed margin between  $V_C/M_C$  and  $V_D/M_D$  is the greater of the following:
    - (a) the speed increase resulting when, from the initial condition of stabilized flight of  $V_C/M_{C,K}$  the airplane is assumed to be upset, flown for 20 seconds along a flight path 7.5° below the initial path, and then pulled up with a load factor of 1.5 (0.5 g acceleration increment). At least 75 percent maximum continuous power for reciprocating engines, and maximum cruising power for turbines, or, if less, the power required for  $V_C/M_C$  for both kinds of engines must be assumed until the pullup is initiated, at which point power reduction and pilot-controlled drag devices may be used, and
    - (b) mach 0.05 (at altitudes where an  $M_D$  is established).
- c. For design maneuvering speed,  $V_A$ , the following applies:
  - (1)  $V_A$  may not be less than  $V_s \sqrt{n}$  where
    - (a)  $V_S$  is a computed stalling speed with flaps retracted at the design weight, normally based on the maximum airplane normal force coefficients,  $C_{NA}$ ; and
    - (b) n is the limit maneuvering load factor used in design.
  - (2) The value of  $V_A$  need not exceed the value of  $V_C$  used in design.
- d. For design speed for maximum gust intensity,  $V_B$ , the following apply:

- (1)  $V_B$  may not be less than the speed determined by the intersection of the line representing the maximum positive lift  $C_{n max}$  and the line representing the rough air gust velocity in the gust V-n diagram, or  $\sqrt{n_g V_{s1}}$ , whichever is less, where:
  - (a)  $n_g$  is the positive airplane gust load factor due to gust at speed  $V_C$  (in accordance with FAR 23.341) and at the particular weight under consideration, and
  - (b)  $V_{Sl}$  is the stalling speed with the flaps retracted at the particular weight under consideration.
- (2)  $V_B$  need not be greater than  $V_C$ .

# 7.2.2 FAR 23.337 Limit Maneuvering Load Factors.

- a. The positive limit maneuvering load factor *n* may not be less than
  - (1) 2.1+[24,000/(W+10,000)] for normal and commuter category airplanes, except that *n* need not be more than 3.8,
  - (2) 4.4 for utility category airplanes, or
  - (3) 6.0 for acrobatic category airplanes.
- b. The negative limit maneuvering load factor may not be less than
  - (1) 0.4 times the positive load factor for the normal utility and commuter categories or
  - (2) 0.5 times the positive load factor for the acrobatic category.
- c. Maneuvering load factors lower than those specified in this section may be used if the airplane has design features that make it impossible to exceed these values in flight.

# 7.3 RUNNING STRSPEED.

To run STRSPEED, select the STRSPEED button from the main menu window. You will see the main window for the module as shown in figure 7.1.

# 7.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output file to a serial or parallel printer. *Return to Main Menu* exits from STRSPEED and returns to the FAR23 Loads Main Menu.

Enter one category Normal, Utility or Acrobatic (N, U or A):	Are computed stalling speeds known based on max airplane normal force coefficient at	Y
Take-off weight (1b): 3400	max take-off weight (Y/N):	•
Wing area (sq-ft): 184.1	(knots) with flaps retracted at take-off weight:	62.2
Max sea level speed, UH (knots): [177.4	Computed stalling speed (knots) with flaps fully extended at max take-off weight:	58.6
Chosen structural speeds (kno maneuver load factor: UC UD UA UF	ts) and "Shoulder" altit for Mach limitat structural speed N POS N NEG altitude:	ude (ft) ions for ls at

FIGURE 7.1 STRSPEED INPUT WINDOW

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input required for STRSPEED includes the category of airplane (normal, utility, or acrobatic), the takeoff weight, wing area, maximum speed at sea level  $(V_H)$ , and the shoulder altitude.

The stalling speed with flaps extended and with flaps retracted can be entered if known, or they can be calculated by STRSPEED. If you know the stalling speed, answer Y to the question, then enter the speeds. If you want to calculate the stalling speeds, answer N. You will then be asked to enter the maximum lift coefficients,  $C_{L-w}$  and  $C_{L-f}$ , as shown in figure 7.2.

The design speeds ( $V_C$ ,  $V_D$ ,  $V_A$ ,  $V_F$ ) and load factors (+*n*, -*n*) can be entered, or you can allow the program to calculate these. Enter 1 for any value you want calculated. You can enter some of the design speeds and let the program calculate the remaining values.

Note: In this window, it is recommended that you use *Tab* to move from field to field. If you open a previously created file, you must tab through all the fields after they are filled to complete the data entry. Otherwise the program may give a "Divide by zero" error. Also, if you use the mouse to move between fields, you may get the same error message.

Structural Sp	eeds and Load	Factors (C) Hal C McMaster 1988	
Enter one category Normal, Utility or Acrobatic (N, U or A):	H	Are computed stalling speeds known based on max airplane normal force coefficient at N	-
Take-off weight (1b):	3400	max take-off weight (Y/N):	
Wing area (sq-ft):	184.12	Wing CL max:	
Max sea level speed, VH (knots):	177.4	Wing CLF max:	
Chosen structural spee maneuver load factor: UC UD VA	ds (knots) and UF N PO	"Shoulder" altitude ( for Mach limitations l structural speeds at S N NEG altitude:	t) or
170 1 1	1 1	1 12000	

FIGURE 7.2 STRSPEED ALTERNATE INPUT WINDOW

# 7.3.2 Running the Analysis.

After all input are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results. The first option saves the output to a file, and the second option prints the output.

# 7.4 STRSPEED OUTPUT.

STRSPEED calculates the design speeds, load factors, and Mach numbers ( $M_C$ ,  $M_D$ ). The minimum values are calculated for  $V_C$ ,  $V_D$ ,  $V_A$ , and  $V_F$ , and for the positive and negative load factors. If you chose a design speed, then the other speeds are adjusted to meet the requirements. The calculated values are used in MACHLIM, FLTLOADS, AILERON, and FLAPLOAD (sections 8, 11, 13, and 14 respectively).

# 8. MACH LIMITATIONS.

# 8.1 MACHLIM DESCRIPTION.

The MACHLIM module determines the Mach limitations for the flight envelope diagram. For a constant Mach number, the equivalent air speed is calculated at altitudes from the shoulder altitude to the maximum operating altitude. The equations for calculating equivalent air speed are given in section 7.

# 8.2 RUNNING MACHLIM.

To run MACHLIM, select the MACHLIM button from the main menu window. The main input window for MACHLIM is shown in figure 8.1.

- Program to Calculate Mach Limitat File Notepad Color	ion Lines (C) Hal C. McMaster 1988 👘
Enter MC :	_323
Enter MD :	.403
Enter Shoulder Altitude (ft) :	12000
Enter Max Operating Altitude (ft) :	18000
Enter Increment of Altitude (ft) :	1000

FIGURE 8.1 MACHLIM INPUT WINDOW

# 8.2.1 Input Window.

The input window is displayed when the module starts, and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and send the output data to a file or printer. Return to Main Menu exits from MACHLIM and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program, where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input for MACHLIM includes the Mach number at design cruising speed  $(M_C)$ , the Mach number at design dive speed  $(M_D)$ , the shoulder altitude, and the maximum operating altitude. An altitude increment is also required; this is used to determine the altitudes of interest between the shoulder and operating altitudes. The altitudes are entered in feet.

The Mach numbers at design cruise and dive speeds are calculated in STRSPEED (section 7).

#### 8.2.2 Running the Analysis.

After all input are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second selection also includes the option to send the output directly to a printer.

### 8.3 MACHLIM OUTPUT.

The output from MACHLIM includes the air speeds at altitudes between the shoulder altitude and the operating altitude. This data can be plotted on the flight limits diagram using FAR23 Plot.

All speeds are given in knots equivalent air speed (KEAS), and the altitude is in feet.

#### 8.4 GRAPHICS.

The separate graphics program FAR23 Plot can be used to draw the Mach limits lines on the flight limit diagram. The FAR23 Plot program is described in the appendix of reference 1.

To plot the data, the output file from MACHLIM must have a filename with the extension *.SPD*. An example of a flight limit diagram is shown in figure 8.2.



FIGURE 8.2 EXAMPLE OF FLIGHT LIMIT DIAGRAM

#### 9. AERODYNAMIC COEFFICIENTS AND AIRLOADS.

### 9.1 AIRLOADS DESCRIPTION.

The AIRLOADS module is used to calculate the aerodynamic coefficients and wing air loads. AIRLOADS is used twice. First, it is used to calculate the aerodynamic coefficients. Then, after determining the critical wing load conditions (section 12), it is used to calculate the actual air loads for the critical wing load conditions.

The AIRLOADS and AIRLOAD4 (section 10) modules are similar in function. However, AIRLOAD4 should be used to calculate the aerodynamic coefficients and wing air loads if the sweepback of the 25% chord is greater than 15°. If the Mach number is greater than 0.5, then AIRLOAD4 should be used to calculate the air loads. Either AIRLOADS or AIRLOAD4 can be used to calculate the aerodynamic coefficients if the sweepback is less than 15°.

#### 9.1.1 Aerodynamic Coefficients.

AIRLOADS calculates the basic and additive spanwise aerodynamic lift coefficient distributions for the wing. It combines these with the spanwise lift coefficient distribution for any specific total wing lift coefficient and then calculates the associated spanwise drag and moment coefficients for that wing  $C_L$ .

AIRLOADS calculates the stall lift coefficient and angle of attack for the wing. The pitching moment coefficient of the fuselage and nacelle is calculated and added to the total wing moment coefficient to provide lift, drag, and moment coefficients for the airplane-less-tail condition for any  $C_L$ . The drag and moment of the extended landing gear are calculated and added to the airplane-less-tail. The sea level equations for lift, drag, and moment are formulated. These equations are used to make the balancing calculations for the V-n diagrams (see section 11).

The spanwise lift distribution on the wing is determined by Schrenk's method [1]. For additive lift, the Schrenk method averages the chordwise distribution with an elliptical chord distribution of the same wing area as if there was a constant airfoil and no aerodynamic twist. For the basic lift, the Schrenk method averages the zero lift distribution and the elliptical distribution for zero lift. The zero lift distribution is the local chord times slope of the lift times the angle of attack relative to the zero lift line of the wing.

Tau  $(\tau)$  is a correction factor for the slope of the lift curve that accounts for the deviation of the wing plan form from an ellipse [1]. This factor is required input for AIRLOADS and can be calculated during data input.

If the sweepback of the quarter chord is greater than 15°, then the lift distribution is calculated from [3]:

$$\left(\frac{cc_l}{\bar{c}C_L}\right)_{\Lambda} = \left(\frac{cc_l}{\bar{c}C_L}\right)_{\Lambda=0} - \left(1 - \frac{2y}{b}\right) [2(1 - \cos\Lambda)]$$

where:

- $cc_l = local chordwise lift distribution$  $\overline{c} C_L = chordwise lift distribution for the wing$  $\Lambda = angle of sweepback$ y = wing station
  - b = wing span

# 9.1.2 Air Loads.

After determining the critical conditions for the wing (see section 12), the actual air loads can be calculated. The lift coefficient,  $C_L$ , and speed for each critical wing condition is calculated by FLTLOADS (see section 11). Using this data, AIRLOADS calculates the spanwise air load distributions for lift, drag, and pitching moment for each of the critical wing conditions. Then the shear, bending moments, and torsion air loads are calculated along the quarter chord.

# 9.2 FAR 23 REGULATIONS.

The regulations for air loads are defined in FARs 23.301, 23.349, and 23.455 and repeated here for convenience.

# 9.2.1 FAR 23.301 Loads.

- a. Strength requirements are specified in terms of limit loads (the maximum loads to be expected in service) and ultimate loads (limit loads multiplied by prescribed factors of safety). Unless otherwise provided, prescribed loads are limit loads.
- b. Unless otherwise provided, the air, ground, and water loads must be placed in equilibrium with inertia forces, considering each item of mass in the airplane. These loads must be distributed to conservatively approximate or closely represent actual conditions. Methods used to determine load intensities and distribution on canard and tandem wing configurations must be validated by flight test measurement unless the methods used for determining those loading conditions are shown to be reliable or conservative on the configuration under consideration.
- c. If deflections under load would significantly change the distribution of external or internal loads, this redistribution must be taken into account.
- d. Simplified structural design criteria may be used if they result in design loads not less than those prescribed in FARs 23.331 through 23.521. For conventional, single-engine airplanes with design weights of 6,000 pounds or less, the design criteria of Appendix A of Part 23 are an approved equivalent of FARs 23.321 through 23.459. If Appendix A is used, the entire appendix must be substituted for the corresponding sections of Part 23.

### 9.2.2 FAR 23.349 Rolling Conditions.

The wing and wing bracing must be designed for the following conditions:

- a. Unsymmetrical wing loads appropriate to the category. Unless the following values result in unrealistic loads, the rolling accelerations may be obtained by modifying the symmetrical flight conditions in FAR 23.333(d) as follows:
  - (1) For acrobatic category, in conditions A and F, assume that 100 percent of the semispan wing air load acts on one side of the plane of symmetry and 60 percent of this load acts on the other side.
  - (2) For normal, utility, and commuter categories, in Condition A, assume that 100 percent of the semispan wing air load acts on one side of the airplane, and 70 percent of this load acts on the other side. For airplanes of more than 1,000 pounds design weight, the latter percentage may be increased linearly with weight up through 75 percent at 12,500 pounds to the maximum gross weight of the airplane.
- b. The wing and wing bracing must be designed for the loads resulting from the aileron deflections and speeds specified in FAR 23.455, in combination with an airplane load factor of at least two thirds of the positive maneuvering load factor used for design. Unless the following values result in unrealistic loads, the effect of aileron displacement on wing torsion may be accounted for by adding the following increment to the basic airfoil moment coefficient over the aileron portion of the span in the critical condition determined in FAR 23.333(d):

 $\Delta C_{\rm m} = -0.01\delta$ 

where:

 $\Delta C_m$  is the moment coefficient increment, and  $\delta$  is the down aileron deflection in degrees in the critical condition.

### 9.2.3 FAR 23.455 Ailerons.

- a. The ailerons must be designed for the loads to which they are subjected
  - (1) in the neutral position during symmetrical flight conditions and
  - (2) by the following deflections (except as limited by pilot effort) during unsymmetrical flight conditions:
    - (a) Sudden maximum displacement of the aileron control at  $V_A$ . Suitable allowance may be made for control system deflections.

- (b) Sufficient deflection at  $V_C$ , where  $V_C$  is more than  $V_A$ , to produce a rate of roll not less than obtained in paragraph a.(2)(a) of this section.
- (c) Sufficient deflection at  $V_D$  to produce a rate of roll not less than one-third of that obtained in paragraph a.(2)(a) of this section.

# b. [Reserved]

# 9.3 RUNNING AIRLOADS.

To run the module AIRLOADS, select the button from the main menu window. The first input window will be displayed as shown in figure 9.1.

File Notopad Color Pg1 Pg2 Pg3	(C) HAL C MCMASTER 1988, 1990 Pg4 Pg5 Pg6 Pg7 Pg8 Pg9
Enter configuration such as 'FLAPS 35 DEGREES' or 'CRUISE' without quotes:	CRUISE_
How many points define the leading edge ? 3	How many points define the trailing edge ?
Enter coordinates (INCHES) of leading edge XLE, YLE (+XLE is aft and +YLE is outboard) starting at inboard.	Enter coordinates (INCHES) of trailing edge XTE, YTE (+XTE is aft and +YTE is outboard) starting at inboard.
Point No X (INCHES) Y (INCHES) <u>†</u>	Point No X (INCHES) Y (INCHES)
1 45 0	1 146 0
Î The surface is devided into how many i	↓ ncrements of DY: 20

FIGURE 9.1 AIRLOADS FIRST INPUT WINDOW

9.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes twelve menu options: File, Notepad, Color, and Pg1-Pg9.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and send the output data to a printer or file. Return to Main Menu exits from the AIRLOADS program and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files, and the Color option allows you to change the color scheme displayed on your window.

The options Pg1-Pg9 are for the nine input windows used to enter the data required for the air loads analysis. If you are calculating the aerodynamic coefficients, you do not need to enter data on the seventh window. If you are calculating the air loads, you do not need to enter data on the fourth window. The eighth window is used only for landing gear aerodynamic coefficients, and the ninth window is only for calculating tau ( $\tau$ ).

Note: If you open an existing data file in AIRLOADS, you may get an error message about reading past the end of file. This means that the data file does not have enough data for all the input windows and is probably missing data for the seventh and eighth windows. You should check all the windows to verify the data before running the analysis.

On the first window, the geometry data is entered, including the coordinates for the leading and trailing edges.

The parameters required for the additive lift distribution calculations are entered on the second window shown in figure 9.2, and the data for basic lift distribution are entered on the third window as shown in figure 9.3.

How many wing sta	ntion do you selec	t?2
Wing Station No	Wing Station (INCHES)	Slope CL/DEG
1	0	.1075

FIGURE 9.2 AIRLOADS SECOND INPUT WINDOW

le Notepad Color P	g1 Pg2 Pg3 Pg4 Pg5 Pg6 Pg7 Pg8 Pg9
Wing Station No	Wing Station Angle (DEG) 〈INCHES〉 from Water Line ↑
1	0 5
Enter Wing Station	of Discontinuity
between Flap and Ai for No Discontinuity	Jeron (Enter Ø Ø J

FIGURE 9.3 AIRLOADS THIRD INPUT WINDOW

On the fourth window, shown in figure 9.4a, the first question asks if you want to calculate the stall  $C_L$ . If you are calculating the aerodynamic coefficients, then you want to answer Y. If you are calculating the air loads, then answer N. If you answer N, then no additional input is required on this window as shown in figure 9.4b.

If you want to calculate the stall  $C_L$ , then enter the additional data. RN is Reynolds number.

File Notepad Color Pg1 Pg2 Pg3	HAL C MCMASTER 1988, 1990 Pg4 Pg5 Pg6 Pg7 Pg8 Pg9
Do you want to calculate stall CL ?	X
How many wing stations do you select a	? 4
Enter each selected wing station and s CLMAX and RN and its chord strating at	its first CLMAX and RN, Its second t inboard:
WS No WS CILMAX RIN (INCHES)	C2LMAX R2N CHORD (INCHES)
1 0 1.45 300000	1.66 900000 101

FIGURE 9.4a AIRLOADS FOURTH INPUT WINDOW



FIGURE 9.4b AIRLOADS ALTERNATE FOURTH INPUT WINDOW

On the fifth window, shown in figure 9.5, you will enter data for the spanwise drag and moment coefficients,  $C_D$  and  $C_M$ . You need to enter  $\tau$ , which is a correction for the slope of the lift curve. The value for  $\tau$  can be calculated on the ninth window, but then you will need to enter the value here.

FIRMATSE COLOR	Color	Pgl Rg2 Pr	Pg4 Pg5	Polis Pol	Put Put	<u> </u>
What is TAU ?	' (Ref Per	ry P 244)			.05	
For what CL o	lo you wan	t wing coeff:	icient distri	ibuion:	1.41	
How many wing select, not m	r stations wre than	do you 10 for CDO:	How m selec	many wing	station do y pre than 10 f	ou or CM:
	2		2			
Wing Station No	WS (INCHES)	CDØ	Ving Stat: No	ion WS (INCH)	Moment ES) Coefficio	ent 1
1	0	.01	1	0	03	
			Ĩ			Ĩ

FIGURE 9.5 AIRLOADS FIFTH INPUT WINDOW

On the sixth screen, shown in figure 9.6, you will enter additional fuselage data.



FIGURE 9.6 AIRLOADS SIXTH INPUT WINDOW

On the seventh window, shown in figure 9.7a, the first question asks if you want to calculate the air loads. If you are calculating the air loads, then you want to answer Y. If you are not calculating the air loads, then answer N. If you answer N, then no additional input is required on this window.

If you answer Y, then enter the additional data as shown in figure 9.7b.

If you opened an existing input data file, you will need to check the values on the seventh and eighth windows to be sure they are correct.



FIGURE 9.7a AIRLOADS SEVENTH INPUT WINDOW

AIRLOADS FOR SPECIFIED CL AND V (C) HAL C MCMASTER 1988, 1990 File Motepad Color Pg1 Pg2 Pg3 Pg4 Pg5 Pg6 Pg7 Pg8 Pg9
Would you like airloads (not aero coefficient distribution) for this CL=1.519 inputed on the page 5 about aero coefficient distribution ? (Y for Yes / N for No)
What is your airplane speed in KTS(EAS) ? 117.4
Enter description of condition such as - 'CASE 25 COND MAN D': CASE 22 CRITICAL PHAA CONDITION
Enter WL wing ref plane <25% Chord) at plane of symmetry of airplane: 78.5
Enter slope of wing ref plane (DEG): 6

FIGURE 9.7b AIRLOADS ALTERNATE SEVENTH INPUT WINDOW

The data required to calculate the landing gear aerodynamic coefficients is entered on the eighth window shown in figure 9.8.

LAND GEAR AERO COEF'S I	IN AIRPLANE LES	S TAIL (C) HAL C MCMASTER :	1988, 1990
Enter frontal area of nose gear tire (SQ FT):	.935	Enter total frontal area of LH+RH main gear tires (SQ FT):	1.634
Enter fuselage station of nose gear axle <inches>:</inches>	28.573	Enter fuselage station of main gear axles (INCHES):	209.356
Enter water line of nose axle (INCHES):	0	Enter water line of main gear axles (INCHES):	36.137
Landing gear drag coeffic extended or fixed: for si cover is .25; for truss i	ient reference ngle strut is s .54; for tru	d to frontal area of tires .29; for single strut with ss strut with faired wheel	when faired wheel cover is
Enter drag coefficient for nose gear referenced to frontal area of tire:	.54	Enter drag coefficient for main gear referenced to frontal area of tires:	.54
Enter approximate m	edian airplane	CG (INCHES): 98	

FIGURE 9.8 AIRLOADS EIGHTH INPUT WINDOW

The ninth window, shown in figure 9.9a, is used to calculate the correction factor tau ( $\tau$ ). To calculate  $\tau$ , enter the data, then click on the bar at the bottom of the window. The value of  $\tau$  will be displayed on this bar as shown in figure 9.9b.

CORRECTION FACTOR TAU CALCULATION	S (C) HAL C MCMASTER 1988, 1990
TAU is a correction factor which account planform from an ellipse in calculating wing.	ts for the devation of the wing the slope of the lift curve of the
Enter the taper ratio of the wing: (Taper ratio is the wing chord at the tip divided by the chord at the center plane of the airplane assuming the leading and trailing edge are extended to the tip and to the center plane.)	.42
Enter your tip ratio: (Tip ratio is the spanwise width of the rounded tip divided by the semi-span of the wing. A square tip or unrounded tip has a tip ratio of 0.)	0
Click here to update cor	rection factor TAU.
Olick here to update cor	rection factor IAU.

FIGURE 9.9a AIRLOADS NINTH INPUT WINDOW

TAU is a correction factor which accoun planform from an ellipse in calculating wing.	ts for the devation of the wing the slope of the lift curve of the
Enter the taper ratio of the wing: (Taper ratio is the wing chord at the tip divided by the chord at the center plane of the airplane assuming the leading and trailing edge are extended to the tip and to the center plane.)	.42
Enter your tip ratio: (Tip ratio is the spanwise width of the rounded tip divided by the semi-span of the wing. A square tip or unrounded tip has a tin ratio of 0.2	8

# FIGURE 9.9b AIRLOADS NINTH INPUT WINDOW WITH TAU

# 9.3.2 Running the Analysis.

After all input data are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results; the first option saves the output to a file, and the second option prints the output.

# 9.4 AIRLOADS OUTPUT.

# The AIRLOADS module produces the following:

- wing geometry calculations,
- additive lift distribution,
- basic lift distribution,
- stall calculations,
- wing aerodynamic coefficient distributions,
- airplane-less-tail aerodynamic coefficients, and
- equation for aerodynamic coefficients for airplane less tail.

The aerodynamic coefficients for the airplane less tail are used in FLTLOADS (section 11).

When calculating wing spanwise air loads, the output values are used by the program NETLOADS (section 16).

## 9.5 GRAPHICS.

The separate graphics program FAR23 Plot can be used to plot the aerodynamic coefficients. The FAR23 Plot program is described in the appendix of reference 1.

To plot the data, the output file from AIRLOADS or AIRLOAD4 must have a filename with the extension *AIR*. An example of a plot is shown in figure 9.10.



FIGURE 9.10 EXAMPLE OF LIFT DISTRIBUTION PLOT

# 10. ADDITIONAL AERODYNAMIC COEFFICIENTS AND AIRLOADS.

## 10.1 AIRLOAD4 DESCRIPTION.

The AIRLOADS (section 9) and AIRLOAD4 modules are similar in function. However, AIRLOAD4 is used to calculate the aerodynamic coefficients and loads if the sweepback of the 25% chord is greater than  $15^{\circ}$ . If the Mach number is greater than 0.5, then AIRLOAD4 must be used to calculate the air loads. Either AIRLOADS or AIRLOAD4 can be used to calculate the aerodynamic coefficients if the sweepback is less than  $15^{\circ}$ .

## 10.2 FAR 23 REGULATIONS.

The FAR 23 regulations for air loads are given in section 9.

## 10.3 RUNNING AIRLOAD4.

To run the module AIRLOAD4, select the button from the main menu window. The first input window will be displayed as shown in figure 10.1.

WING GEOMETRY CALCULATIONS Rele Notepart Gulor Fol 262 193	(C) HAL C MCMASTER 1988, 1990 Pro Pro Pro Pro
Enter configuration such as 'FLAPS 35 DEGREES' or 'CRUISE' without quotes:	TWIN TURBO ENROUTE CONFIGURATION
How many points define the leading edge ? 2	How many points define the trailing edge ? 3
Enter coordinates (INCHES) of leading edge XLE, YLE (+XLE is aft and +YLE is outboard) starting at inboard.	Enter coordinates (INCHES) of trailing edge XTE, YTE (+XTE is aft and +YTE is outboard) starting at inboard.
Point No X (INCHES) Y (INCHES)	Point No X (INCHES) Y (INCHES)
1 125.745 0	1 211.099 0
The surface is devided into how many :	t Increments of DY: 30

FIGURE 10.1 AIRLOAD4 FIRST INPUT WINDOW

### 10.3.1 Input Windows.

The first input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes ten or eleven menu options: File, Notepad, Color, and Pg1-8 or Pg1-8.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the

calculations and allow the output data to be saved to a file. *Print Output* allows you to perform the calculations and send the output data to a file or printer. *Return to Main Menu* exits from the AIRLOAD4 program and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The options Pg1 through Pg8 are for the eight input windows used to enter the data required for the analysis. Pg8 is appears only if landing gear data is required.

Except for the second and fifth windows, the input windows for AIRLOAD4 are the same as for AIRLOADS. Figures 10.2 and 10.3 show the second and fifth windows for AIRLOAD4. For the other windows see section 9.

Note: AIRLOAD4 does not need the ninth window for calculation of the correction factor  $\tau$ ; instead, the required data is entered on the fifth window (figure 10.3), and  $\tau$  is calculated in the program.

On Pg6, you are asked if the landing gear is extended. If you answer Y, you should enter the data on Pg8. If you answer N, you do not need to enter landing gear data on Pg8 and this page will not appear in the options. Note that this is different from AIRLOADS since AIRLOADS always requires you to enter the data on Pg8.

ADDITIVE 1	LIFT DISTRIBUTION ( Color Ful Fu	CALCULATIONS (C) HAI	L C MCMASTER 1988, 1990	
	Enter Glauert con calculate airload critical conditio	rrection factor to ls for a specific on, else enter 1.0:	1	
	Enter sweepback ar line, DEGREES:	ngle of quarter choi	<sup>-d</sup> 15	
	How many wing stat	ion do you select î	2	
	Wing Station No	Wing Station (INCHES)	Slope CL∕DEG ↑	
	1	0	.1075	

FIGURE 10.2 AIRLOAD4 SECOND INPUT WINDOW



FIGURE 10.3 AIRLOAD4 FIFTH INPUT WINDOW

# 10.3.2 Running the Analysis.

After all inputs are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results; the first option saves the output to a file, and the second option prints the output.

# 10.4 AIRLOAD4 OUTPUT.

The output from AIRLOAD4 is similar to the output from AIRLOADS and is described in section 9.

# 10.5 GRAPHICS.

The separate graphics program FAR23 Plot can be used to plot the aerodynamic coefficients. The FAR23 Plot program is described in the appendix of reference 1.

To plot the data, the output file from AIRLOADS or AIRLOAD4 must have a filename with the extension *AIR*. An example of a plot is shown in section 9.

# <u>11. FLIGHT ENVELOPE</u>.

# 11.1 FLTLOADS DESCRIPTION.

The FLTLOADS module calculates the loads for any combination of airspeed and load factor on and within the boundaries of the flight envelope. The flight envelope is defined in FARs 23.333, 23.345, and 23.373. The data necessary to make these load calculations comes from the results of modules WTENV (section 5), WINGGEOM (section 6), STRSPEED (section 7), and AIRLOADS or AIRLOAD4 (sections 9 and 10).

The flight envelope should be developed for altitudes up to the maximum operating altitude. For airplanes with a maximum operating altitude less than 20,000 feet, three altitudes are usually used: sea level, shoulder altitude, and maximum operating altitude. If the maximum operating altitude is greater than 20,000 feet, then 20,000 feet should be included since this is where the gust formulas begin to taper.

The flight envelope with flaps extended for takeoff, approach, and landing needs to be determined at sea level only.

# 11.2 FAR 23 REGULATIONS.

FAR 23.333 defines the flight envelope for maneuver and gust for normal, utility, and acrobatic category airplanes. The envelope for high lift devices (flaps) is defined in FAR 23.345 and for speed control devices in FAR 23.373.

# 11.2.1 FAR 23.333 Flight Envelope.

# 11.2.1.1 General.

Compliance with the strength requirements of this subpart must be shown at any combination of airspeed and load factor on and within the boundaries of a flight envelope (similar to the one shown in figure 11.1) which represents the envelope of the flight loading conditions specified by the maneuvering and gust criteria of sections 11.2.1.2 and 11.2.1.3.

# 11.2.1.2 Maneuvering Envelope.

Except where limited by maximum (static) lift coefficients, the airplane is assumed to be subjected to symmetrical maneuvers resulting in the following limit load factors:

- a. The positive maneuvering load factor specified in FAR 23.337 at speeds up to  $V_D$ .
- b. The negative maneuvering load factor specified in FAR 23.337 at  $V_c$ .
- c. Factors varying linearly with speed from the specified value at  $V_C$  to 0.0 at  $V_D$  for the normal and commuter category and -1.0 at  $V_D$  for the acrobatic and utility categories.

Flight envelope



### FIGURE 11.1 FLIGHT ENVELOPE FOR FAR 23.333(d)

# 11.2.1.3 Gust Envelope.

The airplane is assumed to be subjected to symmetrical vertical gusts in level flight. The resulting limit load factors must correspond to the conditions determined as follows:

- a. Positive (up) and negative (down) gusts of 50 feet per second (fps) at  $V_C$  must be considered at altitudes between sea level and 20,000 feet. The gust velocity may be reduced linearly from 50 fps at 20,000 feet to 25 fps at 50,000 feet.
- b. Positive and negative gusts of 25 fps at  $V_D$  must be considered at altitudes between sea level and 20,000 feet. The gust velocity may be reduced linearly from 25 fps at 20,000 feet to 12.5 fps at 50,000 feet.
- c. In addition, for commuter category airplanes, positive (up) and negative (down) rough air gusts of 66 fps at  $V_B$  must be considered at altitudes between sea level and 20,000 feet. The gust velocity may be reduced linearly from 66 fps at 20,000 feet to 38 fps at 50,000 feet.

The following assumptions are made:

a. The shape of the gust is

$$U = \frac{U_{de}}{2} \left( 1 - \cos \frac{2\pi s}{25C} \right)$$

where

s = distance penetrated into gust (ft),

C = mean geometric chord of wing (ft), and

 $U_{de}$  = derived gust velocity referred to in subparagraph a. of this section.

b. Gust load factors vary linearly with speed between  $V_C$  and  $V_D$ .

# 11.2.2 FAR 23.345 High Lift Devices.

If flaps or similar high lift devices to be used for takeoff, approach, or landing are installed, the airplane, with the flaps fully deflected at  $V_F$ , is assumed to be subjected to symmetrical maneuvers and gusts resulting in limit load factors within the range determined by

a. maneuvering to a positive limit load factor of 2.0 and

b. positive and negative gust of 25 fps acting normal to the flight path in level flight.

 $V_F$  must be assumed to be not less than 1.4  $V_S$  or 1.8  $V_{SF}$ , whichever is greater, where

a.  $V_S$  is the computed stalling speed with flaps retracted at the design weight, and

b.  $V_{SF}$  is the computed stalling speed with flaps fully extended at the design weight.

However, if an automatic flap load limiting device is used, the airplane may be designed for the critical combinations of airspeed and flap position allowed by that device.

In designing the flaps and supporting structures, the following must be accounted for:

- a. A head-on gust having a velocity of 25 fps (EAS).
- b. The slipstream effects specified in FAR 23.457(b).

In determining external loads on the airplane as a whole, thrust, slipstream, and pitching acceleration may be assumed to be zero.

The requirements of FAR 23.457 and this section may be complied with separately or in combination.

# 11.2.3 FAR 23.373 Speed Control Devices.

If speed control devices (such as spoilers and drag flaps) are incorporated for use in enroute conditions

- a. the airplane must be designed for the symmetrical maneuvers and gusts prescribed in FARs 23.333, 23.337, and 23.341 and the yawing maneuvers and lateral gusts in FARs 23.441 and 23.443 with the device extended at speeds up to the placard device extended speed; and
- b. if the device has automatic operating or load limiting features, the airplane must be designed for the maneuver and gust conditions prescribed in the previous bullet of this section at the speeds and corresponding device positions that the mechanism allows.

# 11.3 RUNNING FLTLOADS.

To run FLTLOADS, select the button from the main menu window. The first input window will be displayed as shown in figure 11.2.

Enter Wing MAC (Inches):	70.336	UPP is speed limit for enroute configuration like partial flaps dive brakes. If you have no enrou configuration please enter UPP sa as VC in the next input data.	
inter XTC (Pus Sta Approx Percent MAC H. Iail):	450.126		
Inter XIF (Fus Sta 25 Percent MAC H. Tail):	460.636	VA: 176	UPF: 210
inter XV (Pus Sta 25 ercent MAC Wing):	188.799	UC: 210	MC: .511
nter ZW (Waterline 25 ercent MAC Wing):	98.692	UD: 284	MD: .69
inter S (Wing Area IQ-FT):	302.99	VF: 139	VT: 12500
Inter Category N for formal, U for Utility	N		

FIGURE 11.2 FLTLOADS FIRST INPUT WINDOW

# 11.3.1 Input Windows.

The first input window is displayed when the module starts. This window also includes eleven menu options: File, Notepad, Color, and Pg1-Pg8.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As Report Format will perform the calculations and save the output file in report format. Save Output As Format SELECT Required will perform the calculations and save the output file in the format required by SELECT (described in section 12). *Print Input* allows you to print only the input data. *Print Output* allows you to perform the calculations and send the output data to a file or printer. *Return to Main Menu* exits from FLTLOADS and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The eight different input windows are accessed with the Pg1, Pg2, etc., menu items. The data required for input windows Pg1 and Pg2 is general data such as airplane category, geometric data, and speeds. These windows are shown in figures 11.2 and 11.3, respectively. The speeds are entered in KEAS, the coordinates are in inches, and the area is in  $ft^2$ .

On the first input window, you enter the category of the airplane, either normal, utility, or acrobatic. This category determines the minimum required load factor on the second window as shown in figure 11.3.

On Pg2, you will be asked if you have an enroute condition. If not, then the question about flaps for enroute will not appear, and you will not see the input windows for enroute (Pg7 and Pg8). Also, on the first window (Pg1) where you enter VPF, use  $V_C$  if you have an enroute condition.



FIGURE 11.3 FLTLOADS SECOND INPUT WINDOW

The input windows, designated Pg3 through Pg8 and shown in figures 11.4 through 11.9, are used to enter data for cruise, landing, and enroute configurations. Each configuration requires two input windows; where the first window asks for the coefficients for the lift ( $C_0$ ,  $C_1$ ,  $C_2$ ,  $C_3$ , and  $C_4$ ), drag ( $D_0$ ,  $D_1$ ,  $D_2$ ,  $D_3$ , and  $D_4$ ), and pitching moment ( $M_0$ ,  $M_1$ ,  $M_2$ ,  $M_3$ , and  $M_4$ ) equations, and the second window asks for the loading c.g. data.
You can enter up to four loading c.g. conditions. The required data includes a description, weight and c.g. coordinates. This information comes from WTONECG (section 4).

File Motes	ight Loads,	Version 2.0	) (C) Hal C Enter Neg	McMaster 198 Stall	8, 1990
Stall CL:	1.41	<u> </u>	CL:	7	
CL=CO+C1*ALE CC=CO+C1*ALE CO	Encer 5 Coer Ma+C2#ALPHA^ C1	ricience re 2+C3×ALPHA C2	3+C4*ALPHA C3	rquacion ^4: C4	
.285416	.089021	0	0	0	2 Contract Contract Contract
For Cruise, CD=D0+D1*CL+ D0	Enter 5 Coef D2*CL^2+D3*C D1	ficients fo L^3+D4*CL^4 D2	r Drag in 1 : D3	Equation D4	
.030563	0	.033274	Ø	0	
For Cruise, CN=N0+M1+ALF M0	Enter 5 Coef MA+M2*ALPHA^ M1	ficients fo 2+M3*ALPHA^ M2	r Pitching 3+M4×ALPHA M3	Moment in Equ ^4: M4	lation
035373	.006578	0	0	0	

FIGURE 11.4 FLTLOADS THIRD INPUT WINDOW

Each of 4 Weight Loading First Veight Loading,	CG	We ight	XCG	ZCG
CG1		12509	194.405	100.6817
econd Weight Loading,	CG	Weight	XCG	ZCG
CG2		12500	185	99.5473
hird Weight Loading.	CG	Veight	XCG	ZCG
CG3		11300	181	99.085
ourth Weight Loading,	CG	Weight	XCG	ZCG
CG4		7324	185.1689	103.1309

FIGURE 11.5 FLTLOADS FOURTH INPUT WINDOW

or Landing, Inter Stall	CL: 1.68		Enter Neg CL:	g Stall	43
or Landing, L=CØ+C1 <b>×</b> ALP CØ	Enter 5 Coe HA+C2×ALPHA^ C1	fficients f 2+C3*ALPHA^ C2	or Lift in 3+C4×ALPH	1 Equation 1^4: C4	
1.22311	.089021	0	0	0	
For Landing, CD=D0+D1*CL+ NØ	Enter 5 Coe D2*CL^2+D3*C D1	fficients f L^3+D4#CL^4 D2	or Drag i : N3	) Equation D4	andar I (an anna an an Stàitean an Anna Anna An Stàitean an Anna
.077187	.000996	.033288	0	0	
or Landing, quation CM= M0	Enter 5 Coe MO+M1*ALPHA+ M1	fficients f M2#ALPHA^2* M2	or Pitchi M3*ALPHA^: M3	ng Moment in )+M4#ALPHA^4: M4	
		r	¬		

FIGURE 11.6 FLTLOADS FIFTH INPUT WINDOW

Each of 4 weight Loadings First Weight Loading,	CG	Veight	XCG	ZCG
CG5		12500	194.405	100.6817
Second Weight Loading,	CG	Weight	XCG	ZCG
CG6		12500	185	99.5473
hird Weight Loading,	CG	Weight	XCG	ZCG
CG7		11300	181	99.085
Fourth Veight Loading.	CG	Weight	XCG	ZCG
CG8		7324	185.1689	103.1309

FIGURE 11.7 FLTLOADS SIXTH INPUT WINDOW

na <b>Fl</b> Jest Activity of the	ight Loads, V	ersion 2.0 (	(C) Hal C Mc	Master 1988	, 1990
Por Enroute. Enter Stall	CL: 1.59		inter Heg St. 11:	all52	
For Enroute, CL=C0+C1*ALP C0	Enter 5 Coef HA+C2*ALPHA^2 C1	ficients for +C3*ALPHA^3+ C2	· Lift in Eq C4*ALPHA^4: C3	uation C4	
.754263	.089021	0	0	0	
For Enroute. CD=D0+D1*CL+ D0	Enter 5 Coef D2*CL^2+D3*CL D1	ficients for ^3+D4*CL^4: D2	Drag in Equ D3	uation D4	
.053739	.00437	.033274	0	0	
For Enroute, Equation CM= M0	Enter 5 Coef MØ*M1×ALPHA+M M1	ficients for 2#ALPHA^2+M3 M2	Pitching Me *ALPHA^3+M4+ M3	oment in «ALPHA^4: M4	
169502	.006578	0	0	0	

FIGURE 11.8 FLTLOADS SEVENTH INPUT WINDOW

irst Weight Loading, CG	Weight	XCG	ZCG
CG5	12500	194.405	100.6817
econd Weight Loading, CG	Weight	XCG	ZCG
CG6	12500	181	99.5473
ird Weight Loading, CG	Weight	XCG	ZCG
G7	11300	181	99.085
urth Weight Loading, CG	Weight	XCG	ZCG
G8	7324	185.1689	103.1309

## FIGURE 11.9 FLTLOADS EIGHTH INPUT WINDOW

The data necessary to make these load calculations comes from the results of the modules WTONECG (section 4), WTENV (section 5), WINGGEOM (section 6), STRSPEED (section 7), and AIRLOADS or AIRLOAD4 (section 9 or section 10).

## 11.3.2 Running the Analysis.

After all inputs are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As Report Format, Save Output As Format SELECT Required*, or *Print Output*. Any of these selections will calculate the results, but you will need to select more than one option to get the output in more than one the format. If you want to use the results in SELECT (section 12), you need to select the option to save results in the correct format. If you want to save the data to a file and print it, you will need to select those options also.

# 11.4 FLTLOADS OUTPUT.

The output from FLTLOADS is used in SELECT (section 12) and WINGINER (section 15). The data for each point on the flight envelope is included in the output file. The following data is included, and if applicable, the variable name used in the output file is given:

- name of the condition and case number,
- altitude (feet) and equivalent air speed (knots),
- normal load factor  $n_z$ ,
- angle of attack  $\alpha$  (degrees),
- compressibility factor (variable G CORR),
- wing lift coefficient  $C_L$ ,
- pitching moment of airplane less tail (variable M(W+F)),
- wing lift normal to the airplane reference line (lbs) (variable LZW),
- tail load (lbs) (variable LT), and
- airplane drag load (lbs) (variable DX).

# 11.5 GRAPHICS.

The separate graphics program FAR23 Plot can be used to draw the flight envelope. The FAR23 Plot program is described in the appendix of reference 1.

To plot the results, the output file from FLTLOADS must have a filename with the extension .*LDS*. An example of a flight envelope is shown in figure 11.10.





## 12. SELECTION OF CRITICAL LOADS.

## 12.1 SELECT DESCRIPTION.

The critical flight loads are determined by SELECT using the results of FLTLOADS. The output file from FLTLOADS contains all the balanced symmetrical flight conditions on the V-n diagram. SELECT searches this file for the critical flight loads on the wing, fuselage, horizontal tail, and vertical tail. Critical loads for the other structures such as ailerons, flaps, engine mounts, landing gear, and tabs are determined in other modules as explained in sections 13, 14, 17, 18, and 21, respectively.

In addition to the flight envelope data, additional geometry and inertia data from WTONECG (section 4) and WINGGEOM (section 6) are required.

## 12.1.1 Wing Loads.

The V-n data is searched for the largest net load on the wing for the following conditions:

- positive maneuver load factor at  $V_A$ ,
- positive maneuver load factor at  $V_C$ ,
- negative maneuver load factor at  $V_C$ ,
- positive maneuver load factor at  $V_D$ ,
- positive gust load at  $V_C$ ,
- negative gust load at  $V_C$ ,
- accelerated roll condition producing the largest resultant air load on the wing at  $V_A$ , and
- steady roll conditions required by FAR 23.349(b) at speeds  $V_A$ ,  $V_C$ , and  $V_D$  for the maximum wing torsion produced by the aileron.

## 12.1.2 Fuselage Loads.

The fuselage loads are not specifically addressed in the FAR 23 regulations, but they are implied in the regulations for the tail and wing. The local loads from the tail are discussed in the following sections on tail loads. The engine mount loads are discussed in section 17, and the landing loads are discussed in section 18.

The V-n data is searched for all the balanced symmetrical conditions, including maneuver and gust conditions, for the critical balanced loads.

The flight loads on the fuselage are critical for vertical shear loading aft of and adjacent to the rear spar attachment resulting from the maximum net upload on the wing. They may also be

critical for fuselage vertical shear forward of the wing forward attachment. The V-n data is searched for the largest wing upload accounting for relieving wing inertia. For aft fuselage mounted engines, this condition could also be critical for aft fuselage bending.

The loading on the aft fuselage is critical for down bending due to unchecked pullup maneuver and due to the combination of down tail load and down fuselage inertia in balanced flight conditions. Also, the largest up bending from the combination of up tail load and up fuselage inertia in balanced flight condition is the critical loading for the aft fuselage.

The loading on the forward fuselage is usually critical for the same condition as the maximum aft fuselage down bending and up bending.

Accelerated pitching due to maneuver or gust may produce the critical loading in the aft fuselage. These conditions are determined in the tail section.

## 12.1.3 Horizontal Tail Loads.

The tail surface loads are reactions to the airplane air and inertia loads and the pitching and yawing motions and are functions of the angle of attack and camber due to control surface deflections. Lift acts at the 0.25 chord due to the change in angle of attack and at about the 50% chord due to the change in camber.

The rational tail loads are calculated per Amendment 42. First, the downwash at the tail is calculated as

$$\varepsilon = \frac{114.6C_{L-w}}{\pi AR_w}$$

where:

 $\varepsilon$  = downwash at the tail  $C_{L-w}$  = lift coefficient of the wing  $AR_w$  = aspect ratio of the wing

Then the angle of attack (figure 12.1) of the stabilizer is calculated

$$\alpha_t = \alpha_{wing} - i_w + i_t - \varepsilon$$

where:

 $\begin{array}{ll} \alpha_t &= \text{absolute angle of attack at the tail} \\ \alpha_{wing} &= \text{angle of attack of wing, relative wind line to zero lift line of wing} \\ i_w &= \text{incidence of wing, angle from waterline to zero lift line of wing} \\ i_t &= \text{incidence of tail, angle from waterline to zero lift line of tail} \\ \varepsilon &= \text{downwash, relative wind line of wing to relative wind line of tail} \end{array}$ 



# FIGURE 12.1 GEOMETRIC RELATION BETWEEN ANGLE OF ATTACK OF WING AND TAIL

The load due to the angle of attack at the 25% chord of the tail is

$$L_t = \left(\frac{\Delta C_{L-t}}{\Delta \alpha x \alpha}\right) q S_t$$

where:

 $L_t = \text{load at the 25\% chord of the tail} \\ \Delta C_{L-t} = \text{change in lift coefficient of the tail} \\ \alpha = \text{angle of attack of the tail} \\ \Delta \alpha = \text{change in angle of attack} \\ q = \text{dynamic pressure} \\ S_t = \text{surface area of the tail} \end{cases}$ 

The airplane is balanced about the c.g. to find the lift due to camber at the 50% chord of the tail and the deflection of the elevator. The chordwise distribution from the angle of attack load is the average pressure at the quarter chord, zero at the trailing edge, and four times the average pressure at the leading edge. The chordwise distribution of the camber load at the 50% chord is trapezoidal, which is symmetrical about the 50% chord with zero load at the trailing edge to w at the hinge line. Then the net chordwise distribution is the algebraic sum of the chordwise distributions.

The largest positive and negative balancing tail loads are determined from the V-n data for both flaps extended and flaps retracted conditions. After selecting the critical balanced conditions, the load due to angle of attack at the 25% chord, the load due to camber at the 50% chord, the deflection of the elevator, and the elevator load are determined.

Maneuvering tail loads are determined for the checked and unchecked pullup maneuvers and checked and unchecked push-down maneuvers. The unchecked pullup and push-down maneuver tail loads are calculated at every 1 g balanced point at  $V_A$  on all the V-n diagrams. The total load, due to angle of attack at the 25% chord, due to camber at the 50% chord, and the deflection of the elevator are calculated.

The up and down gust tail loads are determined for flaps retracted and flaps extended as specified in FAR 23.425. Unsymmetrical tail loads are determined per FAR 23.427.

## 12.1.4 Vertical Tail Loads.

The vertical tail loads required in FARs 23.441(a) and 23.443(b) are calculated using the rational loads method. These loads include

- vertical tail side load for sudden displacement to the maximum rudder deflection at  $V_A$  with the airplane in unaccelerated flight at zero yaw,
- vertical side tail load for rudder deflected to full deflection and airplane yawed to a sideslip angle of 19.5°,
- vertical side tail load for yaw angle of 15° with the rudder control maintained in the neutral position, and
- lateral gust load in unaccelerated flight at  $V_c$ .

# 12.2 FAR 23 REGULATIONS.

The regulations for loads are defined in FARs 23.301, 23.321, 23.331, and 23.349 and repeated here for convenience.

## 12.2.1 FAR 23.301 Loads (General).

- a. Strength requirements are specified in terms of limit loads (the maximum loads to be expected in service) and ultimate loads (limit loads multiplied by prescribed factors of safety). Unless otherwise provided, prescribed loads are limit loads.
- b. Unless otherwise provided, the air, ground, and water loads must be placed in equilibrium with inertia forces, considering each item of mass in the airplane. These loads must be distributed to conservatively approximate or closely represent actual conditions. Methods used to determine load intensities and distribution on canard and tandem wing configurations must be validated by flight test measurement unless the methods used for determining those loading conditions are shown to be reliable or conservative on the configuration under consideration.
- c. If deflections under load would significantly change the distribution of external or internal loads, this redistribution must be taken into account.

d. Simplified structural design criteria may be used if they result in design loads not less than those prescribed in FARs 23.331 through 23.521. For conventional, single-engine airplanes with design weights of 6,000 pounds or less, the design criteria of Appendix A of this part are an approved equivalent of FARs 23.321 through 23.459. If Appendix A is used, the entire appendix must be substituted for the corresponding sections of this part.

#### 12.2.2 FAR 23.321 General (Flight Loads).

- a. Flight load factors represent the ratio of the aerodynamic force component (acting normal to the assumed longitudinal axis of the airplane) to the weight of the airplane. A positive flight load factor is one in which the aerodynamic force acts upward with respect to the airplane.
- b. Compliance with the flight load requirements of this subpart must be shown
  - (1) at each critical altitude within the range in which the airplane may be expected to operate,
  - (2) at each weight from the design minimum weight to the design maximum weight, and
  - (3) for each required altitude and weight and for any practicable distribution of disposable load within the operating limitations specified in FARs 23.1583 through 23.1589.
- c. When significant, the effects of compressibility must be taken into account.

## 12.2.3 FAR 23.331 Symmetrical Flight Conditions.

- a. The appropriate balancing horizontal tail load must be accounted for in a rational or conservative manner when determining the wing loads and linear inertia loads corresponding to any of the symmetrical flight conditions specified in FARs 23.333 through 23.341.
- b. The incremental horizontal tail loads due to maneuvering and gusts must be reacted by the angular inertia of the airplane in a rational or conservative manner.
- c. Mutual influence of the aerodynamic surfaces must be taken into account when determining flight loads.

## 12.2.4 FAR 23.349 Rolling Conditions.

The wing and wing bracing must be designed for the following loading conditions:

a. Unsymmetrical wing loads appropriate to the category. Unless the following values result in unrealistic loads, the rolling accelerations may be obtained by modifying the symmetrical flight conditions in FAR 23.333(d) as follows:

- (1) For the acrobatic category, in conditions A and F, assume that 100 percent of the semispan wing air load acts on one side of the plane of symmetry and 60 percent of this load acts on the other side.
- (2) For normal, utility, and commuter categories, in Condition A, assume that 100 percent of the semispan wing air load acts on one side of the airplane, and 70 percent of this load acts on the other side. For airplanes of more than 1,000 pounds design weight, the latter percentage may be increased linearly with weight up through 75 percent at 12,500 pounds to the maximum gross weight of the airplane.
- b. The wing and wing bracing must be designed for loads resulting from the aileron deflections and speeds specified in FAR 23.455, in combination with an airplane load factor of at least two thirds of the positive maneuvering load factor used for design. Unless the following values result in unrealistic loads, the effect of aileron displacement on wing torsion may be accounted for by adding the following increment to the basic airfoil moment coefficient over the aileron portion of the span in the critical condition determined in FAR 23.333(d):

$$\Delta C_{\rm m} = -0.01\delta$$

where:

 $\Delta C_m$  is the moment coefficient increment, and  $\delta$  is the down aileron deflection in degrees in the critical condition.

# 12.2.5 FAR 23.351 Yawing Conditions.

The airplane must be designed for yawing loads on the vertical surfaces resulting from the loads specified in FARs 23.441 through 23.445.

12.2.6 FAR 23.421 Balancing Loads (Horizontal Tail).

- a. A horizontal surface balancing load is a load necessary to maintain equilibrium in any specified flight condition with no pitching acceleration.
- b. Horizontal balancing surfaces must be designed for the balancing loads occurring at any point on the limit maneuvering envelope and in the flap conditions specified in FAR 23.345.

# 12.2.7 FAR 23.423 Maneuvering Loads (Horizontal Tail).

Each horizontal surface and its supporting structure and the main wing of a canard or tandem wing configuration, if that surface has pitch control, must be designed for the maneuvering loads imposed by the following conditions:

- a. A sudden movement of the pitching control at the speed  $V_A$  to the maximum aft movement and the maximum forward movement as limited by the control stops or pilot effort, whichever is critical.
- b. A sudden aft movement of the pitching control at speeds above  $V_A$  followed by a forward movement of the pitching control resulting in the following combinations of normal and angular acceleration:

· ·	NORMAL	ANGULAR
CONDITION	ACCELERATION (n)	ACCELERATION (radian/sec <sub>2</sub> )
Nose-up pitching	1.0	$+39n_{\rm m} + V^*(n_{\rm m} - 1.5)$
Nose-down pitching	n <sub>m</sub>	$-39n_{\rm m} + V^*(n_{\rm m} - 1.5)$

where:

 $n_m$  = positive limit maneuvering load factor used in the design of the airplane, and V = initial speed in knots.

The conditions in this paragraph involve loads corresponding to the loads that may occur in a checked maneuver (a maneuver in which the pitching control is suddenly displaced in one direction and then suddenly moved in the opposite direction). The deflections and timing of the checked maneuver must avoid exceeding the limit maneuvering load factor. The total horizontal surface load for both nose-up and nose-down pitching conditions is the sum of the balancing loads at V and the specified value of the normal load factor n plus the maneuvering load increment due to the specified value of the angular acceleration.

#### 12.2.8 FAR 23.425 Gust Loads (Horizontal Tail).

- a. Each horizontal surface, other than a main wing, must be designed for loads resulting from
  - (1) gust velocities specified in FAR 23.333(c) with flaps retracted and
  - (2) positive and negative gusts of 25 fps nominal intensity at  $V_F$  corresponding to the flight conditions specified in 23.345(a)(2).
- b. [Reserved]
- c. When determining the total load on the horizontal surfaces for the conditions specified in paragraph a. of this section, the initial balancing loads for steady unaccelerated flight at the pertinent design speeds  $V_F$ ,  $V_C$ , and  $V_D$  must first be determined. The incremental load resulting from the gusts must be added to the initial balancing load to obtain the total load.

d. In the absence of a more rational analysis, the incremental load due to the gust must be computed as follows only on airplane configurations with aft-mounted, horizontal surfaces, unless its use elsewhere is shown to be conservative:

$$\Delta L_{ht} = \frac{K_g U_{de} V a_{ht} S_{ht}}{498} \left( 1 - \frac{d\varepsilon}{d\alpha} \right)$$

where:

 $\Delta L_{ht} = \text{Incremental horizontal tail load (lb),} \\ K_g = \text{Gust alleviation factor defined in FAR 23.341,} \\ U_{de} = \text{Derived gust velocity (fps),} \\ V = \text{Airplane equivalent speed (knots),} \\ a_{ht} = \text{Slope of aft horizontal lift curve (per radian),} \\ S_{ht} = \text{Area of aft horizontal lift surface (ft}^2), \text{ and} \\ \left(1 - \frac{d\varepsilon}{d\alpha}\right) = \text{Downwash factor} \end{cases}$ 

## 12.2.9 FAR 23.427 Unsymmetrical Tail Loads (Horizontal Tail).

- a. Horizontal surfaces other than main wing and their supporting structure must be designed for unsymmetrical loads arising from yawing and slipstream effects in combination with the loads prescribed for the flight conditions set forth in FARs 23.421 through 23.425.
- b. In the absence of more rational data for airplanes that are conventional in regard to location of engines, wings, horizontal surfaces other than main wing, and fuselage shape,
  - (1) 100 percent of the maximum loading from the symmetrical flight conditions may be assumed on the surface on one side of the plane symmetry, and
  - (2) the following percentage of that loading must be applied to the opposite side:

Percent = 100 - 10 (n - 1), where n is the specified positive maneuvering load factor, but this value may not be more than 80 percent.

c. For airplanes that are not conventional (such as airplanes with horizontal surfaces other than main wing having appreciable dihedral or supported by the vertical tail surfaces), the surfaces and supporting structures must be designed for combined vertical and horizontal surface loads resulting from each prescribed flight condition taken separately.

## 12.2.10 FAR 23.441 Maneuvering Loads (Vertical Surfaces).

- a. At speeds up to  $V_{A,K}$  the vertical surfaces must be designed to withstand the following conditions. In computing the loads, the yawing velocity may be assumed to be zero:
  - (1) With the airplane in unaccelerated flight at zero yaw, it is assumed that the rudder control is suddenly displaced to the maximum deflection, as limited by the control stops or by limit pilot forces.
  - (2) With the rudder deflected as specified in paragraph a.(1) of this section, it is assumed that the airplane yaws to the resulting sideslip angle. In lieu of a rational analysis, an overswing angle equal to 1.3 times the static sideslip angle of paragraph a.(3) of this section may be assumed.
  - (3) A yaw angle of 15 degrees with the rudder control maintained in the neutral position (except as limited by pilot strength).
- b. [Reserved]
- c. The yaw angles specified in paragraph a.(3) of this section may be reduced if the yaw angle chosen for a particular speed cannot be exceeded in
  - (1) steady slip conditions,
  - (2) uncoordinated rolls from steep banks, or
  - (3) sudden failure of the critical engine with delayed corrective action.

## 12.2.11 FAR 23.443 Gust Loads (Vertical Surfaces).

- a. Vertical surfaces must be designed to withstand, in unaccelerated flight at speed  $V_{C,K}$ , lateral gusts of the values prescribed for  $V_C$  in FAR 23.333(c).
- b. In addition, for commuter category airplanes, the airplane is assumed to encounter derived gusts normal to the plane of symmetry while in unaccelerated flight at  $V_B$ ,  $V_C$ ,  $V_D$ , and  $V_F$ . The derived gusts and airplane speeds corresponding to these conditions, as determined by FARs 23.341 and 23.345, must be investigated. The shape of the gust must be as specified in FAR 23.333(c)(2)(i).
- c. In the absence of a more rational analysis, the gust load must be computed as follows:

$$L_{vt} = \frac{K_{gt} U_{de} V a_{vt} S_{vt}}{498}$$

where:

 $L_{vt}$  = Vertical surface load (lb),  $K_{gt}$  = 0.88  $\mu_{gt}$ /5.3 +  $\mu_{gt}$  = gust alleviation factor,

- $\mu_{gt} = 2W/PC_t g\alpha_{vt} S_{vt} (K/1_t)^2 = lateral mass ratio,$
- $U_{de}$  = Derived gust velocity (fps),
- P = Air density (slugs/cu ft),
- W =Airplane weight (lb),
- $S_{vt}$  = Area of vertical surface (ft<sup>2</sup>),
- $C_t$  = Mean geometric chord of vertical surface (ft),
- $\alpha_{vt}$  = Lift curve slope of vertical surface (per radian),
- K = Radius of gyration in yaw (ft),
- $1_t$  = Distance from airplane c.g. to lift center of vertical surface (ft),
- g = Acceleration due to gravity (ft/sec<sup>2</sup>), and
- V = Airplane equivalent speed (knots).

# 12.2.12 FAR 23.471 General (Ground Loads).

The limit ground loads specified in this subpart are considered to be external loads and inertia forces that act upon an airplane structure. In each specified ground load condition, the external reactions must be places in equilibrium with the linear and angular inertia forces in a rational or conservative manner.

# 12.3 RUNNING SELECT.

To run SELECT, select the button from the main menu window. The first window will be displayed as shown in figure 12.2.



# FIGURE 12.2 SELECT MAIN WINDOW

## 12.3.1 Main Window.

The first window is used to specify the file containing the V-n data. You must open a data file before you can do any analysis. This window includes three menu options: File, View, and Color.

The File menu contains two options: *Read V-n FLTLOAD Data From Disk* and *Return to Main Menu*. The V-n data file comes from FLTLOADS (section 11). If you try to open a file that is not the correct format, you will get an error message.

The View option opens a Notepad program, allowing you to review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

## 12.3.2 Secondary Window.

After a V-n data file is opened, the window options change to include Select as well as View and Color as shown in figure 12.3.



FIGURE 12.3 SELECT SECONDARY WINDOW

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Save V-n FLTLOADS Data and Inputs will allow the input data to be saved to a file. Print V-n FLTLOADS Data allows you to print the V-n data to a file or printer. Return to Main Menu exits from SELECT and returns to the FAR23 Loads Main Menu.

The Select option allows you to select the type of analysis that you will do. The options are *Critical Wing Loads*, *Critical Fuselage Loads*, *Critical Horizontal Tail Loads*, and *Critical Vertical Tail Loads*.

The View option opens a Notepad program, allowing you to review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

## 12.3.3 Input Windows.

After a selection is made, one of the input windows is displayed. These input windows are shown in figures 12.4 through 12.7. Each input window includes four menu options: File, Select, View, and Color.

The File menu is used to store and retrieve data from the program. Save V-n FLTLOADS Data and Inputs allows the V-n data and input data to be saved to a file. Print V-n FLTLOADS Data allows you to print the V-n data to a file or printer. Save Critical Component Loads allows you to perform the calculations and save the critical loads to a file. Print Critical Component Loads allows you to perform the calculations and send the output to a printer or file. The component is either wing, fuselage, horizontal tail, or vertical tail, depending on which loads you are selecting. Return to Main Menu exits from SELECT and returns to the FAR23 Loads Main Menu.

The Select option allows you to select the type of analysis that you will do. After you select an analysis type and enter the data, you must use the File menu to perform the calculations. You can do the analysis for a component only while you are in the appropriate window.

The View option opens a Notepad program, allowing you to review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

File Select View Color	h
Foter full down aileron deflection (deg): 15	
Enter airfoil section moment coefficient for no aileron deflection:03	

FIGURE 12.4 SELECT "SEARCH CRITICAL WING LOADS" WINDOW

For each analysis type, there is one input window. The input window for the critical wing loads is shown in figure 12.4. For the critical wing loads, you will be asked to enter the full-down aileron deflection and the airfoil section moment coefficient for no aileron deflection.

Figure 12.5 shows the input window for the critical fuselage loads. You will be asked where the engine is mounted and the wing weight. If you leave the wing weight blank, then a weight of 9% of the gross weight will be used.

Before selecting the fuselage loads, you must calculate the horizontal tail loads. You will get a message if you try to select the fuselage loads before calculating the horizontal tail loads.

Search Critical Fuselage	e Loads
Is engine(s) mounted on nose of fuselage, wing or aft fuselage (N, W or A)?	R
What is wing weight or leave input box blank for default of .09 x gross weight?	

FIGURE 12.5 SELECT "SEARCH CRITICAL FUSELAGE LOADS" WINDOW

The data that needs to be entered to calculate the critical horizontal tail loads are shown in figure 12.6. The following data is required:

- slope of the lift curve of the wing,
- incidence of the horizontal tail (degrees),
- horizontal tail area ( $ft^2$ ),
- elevator area forward and aft of hinge line and total area of elevator (ft<sup>2</sup>),
- aspect ratio of horizontal tail,
- full elevator deflection for up and down trailing edge (degrees),
- fuselage station of 25% and 50% MAC of tail,
- angle of WL to zero lift line for cruise, enroute, and landing configurations,
- aspect ratio of the wing, and
- length of airplane (ft).

Searcl	ı Critical H	orizontal Tail Loads	
Enter slope of lift curve of wing, CL/RAD:	4.605	Enter elevator area (Total LH+RH), SQ-FT:	16.403
Enter incidence of horiz tail, WL to chord (deg):	2	Enter aspect ratio of horizontal tail:	4.017
Enter horizontal tail area in SQ-FT:	36.944	Enter angle WL to zero lift line of wing for	3.9881460
Enter aspect ratio of wing:	6.095	enroute, landing	0
Enter full elevator deflections for up	30	Enter length of	13.36388
trailing edge (deg) and lown trailing edge (deg):	20	20 airplane in feet:	
Enter elevator area forward of hinge line	1.639	Enter FS of 25 percent MAC of tail:	261.027
(lotal LH+KH), SY-FI and aft of hinge line (Total LH+RH):	14.792	Enter FS of 50 percent MAC of tail:	270.357

FIGURE 12.6 SELECT "SEARCH CRITICAL HORIZONTAL TAIL LOADS" WINDOW

For the vertical tail critical loads, the data required for analysis is shown in figure 12.7a. This includes

- total area of the vertical tail  $(ft^2)$ ,
- full rudder deflection (degrees),
- area of the rudder forward and aft of hinge line and total  $(ft^2)$ ,
- aspect ratio of vertical tail,
- MAC of vertical tail (ft),
- 25% MAC of vertical tail (ft),
- length of airplane, and
- wing span (ft).

You are also asked if you will use the default moment of inertia to calculate the gust on the vertical tail. If you answer Y, there are no more questions. If you answer N, then you are asked to enter the moment of inertia for the four c.g. locations as shown in figure 12.7b.

The default answer for this question is Y. When you change this to N, the additional questions do not appear until you change to a different window; then come back to the vertical tail loads window.



FIGURE 12.7a SELECT "SEARCH CRITICAL VERTICAL TAIL LOADS" WINDOW

earch Critica Golor	l Vertical Tail Loads	
of 30	Enter FS25% MAC of vertical tail:	266.83
14.84	Enter length of airplane in feet:	26.522
5.236	Enter wing span in feet:	33.5
	Will you use default mom of inertia Izz to calc must on wert tail (YZN):	N
it 4.63	Enter IzzCG1 (SLUG-FT SQ):	
1.520	Enter IzzCG2 (SLUG-FT SQ):	
3.367	Enter IzzCG4 (SLUG-FI SQ): Enter IzzCG4 (SLUG-FI SQ):	
	earch Critica Color 14.84 5.236 Jd .57 Ft 4.63 1.520 3.367	earch Critical Vertical Tail LoadsColorEnter F\$25% MAC of vertical tail:ofInter F\$25% MAC of vertical tail:14.84Enter length of airplane in feet:5.236Enter wing span in feet:5.236Vill you use default mom of inertia Izz to calc gust on vert tail (Y/N):Ft4.631.520Enter IzzCG1 (SLUG-FT SQ): Enter IzzCG3 (SLUG-FT SQ):3.367Enter IzzCG4 (SLUG-FT SQ):

## FIGURE 12.7b SELECT "SEARCH CRITICAL VERTICAL TAIL LOADS" WINDOW

## 12.3.4 Running the Analysis.

For each analysis type, after all inputs are entered in the input window, start the analysis by opening the File menu and selecting *Save Critical Component Loads* or *Print Critical Component Loads Data*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

You must run the analysis for the horizontal tail before you can run the fuselage analysis.

After entering the data for a component, you must save the critical loads for that component before moving to the next component. You can only save the critical loads for a component while you are in the appropriate window.

When you save data to a file, give each component a unique file name. If a file already exists, it will be overwritten.

## 12.4 SELECT OUTPUT.

SELECT determines the critical loads for the wing, fuselage, vertical tail, and horizontal tail. A separate output file is created for each component. The output file lists each critical condition, with appropriate parameters.

The results from SELECT are used in AIRLOADS or AIRLOAD4 (section 9 or 10), WINGINER (section 15), and TAILDIST (section 20) to calculate the loads.

#### 13. AILERON LOADS.

#### 13.1 AILERON DESCRIPTION.

The loads on the aileron are calculated in the module AILERON. The deflected positions during unsymmetrical flight conditions produce the critical loads.

To calculate the aileron loads, the required data include:

- the airspeeds  $V_A$ ,  $V_C$ , and  $V_D$ ,
- area of the aileron forward and aft of the hinge line,
- the maximum up deflection at  $V_A$ , and
- the maximum down deflection at  $V_A$ .

The maximum deflections that are entered for the aileron are specified to occur at the design maneuvering speed,  $V_A$ . The deflections for the design cruise speed,  $V_C$ , and design dive speed,  $V_D$ , are calculated from the ratios of  $V_A/V_C$  and  $V_A/V_D$ :

$$\delta_C = \delta_A \frac{V_A}{V_C}$$
$$\delta_D = 0.5 \frac{V_A}{V_D}$$

where:

 $\begin{array}{ll} \delta_C &= \text{deflection at } V_C \\ \delta_D &= \text{deflection at } V_D \\ \delta_A &= \text{maximum deflection at } V_A \\ V_A &= \text{design maneuvering speed} \\ V_C &= \text{design cruise speed} \\ V_D &= \text{design diving speed} \end{array}$ 

The load on the aileron is calculated for the maximum up and down deflections at  $V_A$ ,  $V_C$ , and  $V_D$  by the equations:

$$L_{ail} = C_{L-ail} q S_{ail}$$
$$C_{L-ail} = 0.04\delta_{ail}$$

where:

 $L_{ail}$  = load on the aileron (lb)  $C_{L-ail}$  = lift coefficient for the aileron q = dynamic pressure (lb/ft<sup>2</sup>)  $S_{ail}$  = surface area of the aileron (ft<sup>2</sup>)  $\delta_{ail}$  = deflection of aileron (degrees) The dynamic pressure q is calculated for sea level:

$$q = \frac{1}{2} \rho_0 V^2$$

where:

 $\rho_0$  = air density at sea level, 2.3769 x 10<sup>-3</sup> slugs/ft<sup>3</sup>

V = equivalent air speed (ft/sec)

The air speed is entered in knots and then converted to ft/sec.

On the aileron, the pressure distribution is constant from the leading edge of the aileron to the hinge line, then tapers to zero at the trailing edge. The pressure forward of the hinge line is calculated for the largest up and down loads:

$$P = \frac{L}{S_{ail-fwd} + 0.5S_{ail-aft}}$$

where:

P = pressure L = load  $S_{ail-fwd} = \text{surface area forward of the hinge line}$   $S_{ail-aft} = \text{surface area aft of the hinge line}$ 

#### 13.2 FAR 23 REGULATIONS.

The FAR requirements for the aileron loads are defined in FAR 23.455 and repeated here for convenience.

#### 13.2.1 FAR 23.455 Ailerons.

a. The ailerons must be designed for the loads to which they are subjected:

- (1) in the neutral position during symmetrical flight conditions and
- (2) by the following deflections (except as limited by pilot effort) during unsymmetrical flight conditions:
  - (a) sudden maximum displacement of the aileron control at  $V_{A_i}$  suitable allowance may be made for control system deflections,
  - (b) sufficient deflection at  $V_C$ , where  $V_C$  is more than  $V_A$ , to produce a rate of roll not less than obtained in paragraph a.(2)(a) of this section, and
  - (c) sufficient deflection at  $V_D$  to produce a rate of roll not less than one-third of that obtained in paragraph a.(2)(a) of this section.

#### 13.3 RUNNING AILERON.

To run AILERON, select the button from the main menu window. The input window for AILERON is shown in figure 13.1.

Program to Caculate Ai. Plue Notional Color	leron Loads	(C) Hal C McMa	ster 1990 .	and an
Enter Structural Speed in Knot:	s Va,	Vc,	Va	
	121	170	213	
Enter Max Down Aile:	ron Deflection	on in Degrees	: 15	
Enter Max Up Aile	ron Deflecti	on in Degrees	: -10	
Enter Aileron Area Fwd o	f Hinge Line	, Square Peet	: 1.3	
Enter Aileron Area Aft of	f Hinge Line	, Square Feet	: 5.188	

FIGURE 13.1 AILERON INPUT WINDOW

## 13.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a file or printer. Return to Main Menu exits from AILERON and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files, and the Color option allows you to change the color scheme displayed on your window.

The input required for AILERON includes the aileron data and the airspeeds  $V_A$ ,  $V_C$ , and  $V_D$ . The airspeeds come from STRSPEED (section 7). Aileron data includes the area of the aileron forward and aft of the hinge line, the maximum up deflection, and the maximum down deflection. The airspeeds are entered in knots, the aileron area is entered as  $ft^2$ , and the deflection is in degrees.

Note: The up deflection must be a negative deflection. If you enter a positive value when you try to do the analysis, you will get an error message.

#### 13.3.2 Running the Analysis.

After all input are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

#### 13.4 AILERON OUTPUT.

The output from AILERON includes the up and down aileron deflections at  $V_A$ ,  $V_C$ , and  $V_D$ . The critical load for the up and down aileron deflection and the pressure forward of the hinge line for up and down aileron is calculated.

The deflection is given in degrees, the critical load is in pounds, and the pressure is given in  $lb/in^2$ .

#### 14. FLAP LOADS.

#### 14.1 FLAPLOAD DESCRIPTION.

FLAPLOAD calculates the critical flap loads per the requirements of FARs 23.345 and 23.457. The critical flap loads are determined by calculating the lift on the flap due to wing angle of attack plus lift on the flap due to the deflection of the flap.

The chordwise distribution of pressure tapers from the leading edge to the trailing edge. The pressure at the trailing edge is half the pressure at the leading edge. The pressure at the leading edge of the flap is calculated as

$$P_{LE} = \frac{L_{flap}}{0.75S_{flap}}$$

where:

 $P_{LE}$  = pressure at the leading edge  $L_{flap}$  = load on flap  $S_{flap}$  = surface area of flap

The calculation of the propeller slipstream at the flap is based on momentum theory. The area of the slipstream is added to the area of the fuselage or nacelle, and a radius is derived. The butt line of the engine plus or minus the radius determines the inboard and outboard edges of the slipstream.

The critical flap loads in the slipstream are determined by combining the slipstream effects with the critical flap loads. The critical flap loads in the slipstream are increased by the ratio of the dynamic pressure of the slipstream to that out of the slipstream.

The requirement for a 25-fps gust is accounted for by increasing the critical flap load by the ratio of the dynamic pressure of the velocity of the airplane plus 25 fps to the dynamic pressure of the airplane before the gust.

#### 14.2 FAR 23 REGULATIONS.

The FAR requirements for critical flap loads are given in FARs 23.345 and 23.457 and repeated here for convenience.

#### 14.2.1 FAR 23.345 High-Lift Devices.

- a. If flaps or similar high-lift devices (used for takeoff, approach, or landing) are installed, the airplane, with the flaps fully deflected at  $V_F$ , is assumed to be subjected to symmetrical maneuvers and gusts resulting in limit load factors within the range determined by
  - (1) maneuvering to a positive limit load factor of 2.0 and
  - (2) positive and negative gust of 25 fps acting normal to the flight path in level flight.

- b.  $V_F$  must be assumed to be not less than 1.4  $V_S$  or 1.8  $V_{SF}$ , whichever is greater, where
  - (1)  $V_S$  is the computed stalling speed with flaps retracted at the design weight, and
  - (2)  $V_{SF}$  is the computed stalling speed with flaps fully extended at the design weight.

However, if an automatic flap load limiting device is used, the airplane may be designed for the critical combinations of airspeed and flap position allowed by that device.

- c. In designing the flaps and supporting structures, the following must be accounted for:
  - (1) A head-on gust having a velocity of 25 fps (EAS).
  - (2) The slipstream effects specified in FAR 23.457(b).
- d. In determining external loads on the airplane as a whole, thrust, slipstream, and pitching acceleration may be assumed to be zero.
- e. The requirements of FAR 23.457 and this section may be complied with separately or in combination.

## 14.2.2 FAR 23.457 Wing Flaps.

- a. The wing flaps, their operating mechanisms, and their supporting structures must be designed for critical loads occurring in the flaps-extended flight conditions with the flaps in any position. However, if an automatic flap load-limiting device is used, these components may be designed for the critical combinations of airspeed and flap position allowed by that device.
- b. The effects of propeller slipstream, corresponding to takeoff power, must be taken into account at not less than 1.4  $V_S$ , where  $V_S$  is the computed stalling speed with flaps fully retracted at the design weight. For the investigation of slipstream effects, the load factor may be assumed to be 1.0.

## 14.3 RUNNING FLAPLOAD.

To run FLAPLOAD, select the button from the main menu window. The input window for FLAPLOAD is shown in figure 14.1.



FIGURE 14.1 FLAPLOAD INPUT WINDOW

# 14.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output file to be saved to a file. Print Output allows you to perform the calculations and send the output data to a file or printer. Return to Main Menu exits from FLAPLOAD and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input required to calculate the flap loads includes

- stalling speed at maximum takeoff weight with flaps retracted (knots),
- stalling speed at maximum takeoff weight with flaps extended (knots),
- design flap speed (knots) from STRSPEED (section 7),
- maximum takeoff weight (lb),
- gust load factor with flaps extended,
- flap area on one side of the airplane  $(ft^2)$ ,
- total area of the wing  $(ft^2)$ ,
- maximum flap deflection (degrees),
- ratio of flap chord to wing chord,

- maximum horsepower of one engine,
- butt line of engine (in),
- frontal area of nacelle  $(ft^2)$ , and
- propeller diameter (in).

Note: The input window asks for "max gust load factor with flaps," this should say "max gust load factor with flaps extended."

## 14.3.2 Running the Analysis.

After all inputs are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

## 14.4 FLAPLOAD OUTPUT.

The output from FLAPLOAD includes the lift coefficients for the wing and flap as well as the flap load for the following conditions: 1 g stall, 2 g stall, 2 g at  $V_F$ , and 1.9 g at  $V_F$ . Additional output includes the critical flap load and the pressure at the leading edge. The butt line for the inboard and outboard edge of the slipstream are given, as well as the slipstream velocity at the flap. For a horizontal gust of 25 fps, the factor to increase the flap load at  $V_F$  and the critical flap load combined with the horizontal gust are given.

#### 15. WING INERTIA.

#### 15.1 WINGINER DESCRIPTION.

WINGINER calculates the spanwise inertia shears and moments in balanced and accelerated flight along the quarter chord of the wing for the critical wing conditions. Concentrated weight such as landing gear, engines, fuel tanks, and external wing stores are accounted for in the calculations.

Using the coordinates of the leading and trailing edges, the wing is divided into incremental chordwise strips. For each strip, the inertia loads, shears, and moments are calculated.

The input required for WINGINER includes wing panel weight, inertia factors obtained for the selected critical wing loads, ratio of densities of the tip area to the root area, wing plan-form geometry, dihedral angle of the wing reference plane and waterline of its intersection with the center plane of symmetry at the quarter chord, weight and coordinates of the concentrated weights, wing station of inboard rib of wing panel, and the load conditions.

For a load condition, the case number,  $n_x$ ,  $n_z$ , and unbalanced moment are required. The case number and  $n_z$  come from the V-n data (section 11). You can calculate the value of  $n_x$  from

$$n_x = \frac{D_x}{W}$$

where:  $n_x = \text{load factor for x-direction}$   $D_x = \text{drag load from V-n data (section 11)}$ W = weight of airplane

If the unbalanced rolling moment is needed, such as for the accelerated roll condition, it can be calculated as described in reference 1.

The inertia loads for the 1 g vertical load, 1 g drag load, and unit rolling moment cases can also be calculated. For the 1 g vertical load, enter  $n_z$  as -1 and  $n_x$  and unbalanced moment as 0. For the 1 g drag load,  $n_x$  is 1 and  $n_z$  and unbalanced moment are 0. For the unit rolling moment, unbalanced moment is -100,000 and the load factors  $n_x$  and  $n_z$  are 0.

#### 15.2 FAR 23 REGULATIONS.

The FAR requirements for loads are given in FAR 23.301 and repeated here for convenience.

15.2.1 FAR 23.301 Loads.

a. Strength requirements are specified in terms of limit loads (the maximum loads to be expected in service) and ultimate loads (limit loads multiplied by prescribed factors of safety). Unless otherwise provided, prescribed loads are limit loads.

- b. Unless otherwise provided, the air, ground, and water loads must be placed in equilibrium with inertia forces, considering each item of mass in the airplane. These loads must be distributed to conservatively approximate or closely represent actual conditions. Methods used to determine load intensities and distribution on canard and tandem wing configurations must be validated by flight test measurements unless the methods used for determining those loading conditions are shown to be reliable or conservative on the configuration under consideration.
- c. If deflections under load would significantly change the distribution of external or internal loads, this redistribution must be taken into account.
- d. Simplified structural design criteria may be used if they result in design loads not less than those prescribed in FARs 23.331 through 23.521. For conventional, single-engine airplanes with design weights of 6,000 pounds or less, the design criteria of Appendix A of this part are an approved equivalent of FARs 23.321 through 23.459. If Appendix A is used, the entire appendix must be substituted for the corresponding sections of this part.

## 15.3 RUNNING WINGINER.

To run WINGINER, select the button from the main menu window. The first input window will be displayed as shown in figure 15.1.

WING	INERTIA PROGRA	1M V 3.0 (C) HAL	C. MCMASTER, 1988, 1990, 1993, 1995
How many the leadi	points define ng edge ?	3	How many points define the trailing edge ?
Enter coo edge XLE, is outboa	rdinates (INC) YLE (+XLE is rd) starting a	IES) of leading aft and +YLE it inboard.	Enter coordinates (INCHES) of trailing edge XTE, YTE (*XTE is aft and *YTE is outboard) starting at inboard.
Point No	X (INCHES)	Y (INCHES)	Point No X (INCHES) Y (INCHES)
1	45		1 146 0
Enter the station ( inboard r panel:	BL or wing IN> of the ib of the wing	r 23	Enter the number of spanwise elements the wing is to be divided into:

FIGURE 15.1 WINGINER FIRST INPUT WINDOW

## 15.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes six menu options: File, Notepad, Color, Page1, Page2, and Page3.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a file or printer. Return to Main Menu exits from WINGINER and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input required for WINGINER is entered on three input windows as shown in figures 15.1, 15.2, and 15.3. The input on the first window includes

- wing plan-form geometry, entered as coordinates on the leading and trailing edges,
- wing station of inboard rib of the wing panel, and
- number of spanwise increments to divide wing into (between 2 and 100).

When entering the coordinates, use the scroll bar to move to the next point.

WING INERTIA PROGRAM U 3.0 (C) Hile Notepad Color Pagel Fac Enter WL (IN) wing reference plane at plane of symmetry of airplane:	HAL C. MCM 2 8./03 78.5	STER, 1988, 19 Enter sl wing ref plane in	990, 1993, 1995 ape of evence degs:	
Enter 1st concentrated weight (LB) on the wing and coordinates (IN) else enter 0:		XCWT Y		
Enter 2nd concentrated weight (LB) on the wing and coordinates (IN) else enter 0:				
Enter 3rd concentrated weight (LB) on the wing and coordinates (IN) else enter 0:				
Enter 4th concentrated weight (LB) on the wing and coordinates (IN) else enter 0:				
What is weight (LB) of wing panel (donot include concentrated weight	>: 165			

## FIGURE 15.2 WINGINER SECOND INPUT WINDOW

The input on the second window includes

- wing panel weight (lb), not including concentrated weight,
- dihedral angle of the wing reference plane and waterline of its intersection with the center plane of symmetry at the quarter chord, and
- weight and coordinates for up to four concentrated weights.

If there are less than four concentrated loads, leave the unneeded fields blank or enter 0.

What is rat relative to .2 LBS/SQ-11	io of density of root area	of tip area <.9 if root is 18 LBS/SQ-IN>:	.95	
how many lo	ad conditions w	vill you enter '	? 6	
Enter each	load combinatio	in of case no.,	Nz. Nx.	
UnbaMomc) desired rem Case No	hosen so that i embering up and Na	inertia will ac l aft are posit Ny	t in direction ive. UnbalMom	Ŧ

FIGURE 15.3 WINGINER THIRD INPUT WINDOW

The input on the third window includes

- ratio of densities of the tip area to the root area and
- load conditions, including case number,  $n_z$ ,  $n_x$ , and unbalanced moment.

When entering the load cases, use the scroll bar to move to the next point.

The load conditions come from FLTLOADS (section 11). The case number and  $n_z$  come directly from the output, but  $n_x$  must be calculated as explained above.

The inertia loads for the 1 g vertical load, 1 g drag load, and unit rolling moment cases can also be calculated. For the case number, enter an unused number such as 1001. Each case should have a unique number. For the 1 g vertical load, enter  $n_z$  as -1 and  $n_x$  and unbalanced moment as 0. For the 1 g drag load,  $n_x$  is 1 and  $n_z$  and unbalanced moment are 0. For the unit rolling moment, unbalanced moment is -100,000 and the load factors  $n_x$  and  $n_z$  are 0.

The positive directions are aft and up. Note that the sign for  $n_z$  in the output of FLTLOADS and the sign of  $n_z$  entered here may not be the same.

## 15.3.2 Running the Analysis.

After all inputs are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

## 15.4 WINGINER OUTPUT.

For each case, the output includes the load, shear, and torsion for each spanwise increment of the wing. This output is used in NETLOADS (section 16) when determining the total loads.

In the output file, the data is labeled by the variable names. These variable names are defined in table 15.1.

VARIABLE NAME	DESCRIPTION	
Case	Input case number	
N <sub>X</sub> , N <sub>Z</sub>	Input load factor for the x and z direction	
THETADOT	Rate of change of the pitch velocity	
UNBAL MOM	Input value of unbalanced moment (in-lbs)	
X, Y, and Z	Coordinates of the quarter chord for the wing increment (in.)	
FX, FZ	Total inertia force in the x and z direction	
DMYY	Incremental torsion (in-lbs)	
SX, SZ	Total drag force in x and z direction (lbs)	
MXX, MYY, MZZ	Bending moment, torsion, and yawing moment (in-lbs)	

TABLE 15.1 DESCRIPTION OF VARIABLES USED IN THE WINGINER OUTPUT FILE

## 16. NET WING LOADS.

## 16.1 NETLOADS DESCRIPTION.

The module NETLOADS calculates the spanwise net wing shears and moments along the quarter chord of the wing. The air loads and inertia loads are algebraically added to determine the net loads.

The input data required for the calculations are the air loads and inertia loads for the selected critical loads for the wing. The air loads come from AIRLOADS or AIRLOAD4 (section 9 or 10) and the inertia loads come from WINGINER (section 15).

## 16.2 FAR 23 REGULATIONS.

The FAR requirements for loads are given in FAR 23.301 and repeated here for convenience.

## 16.2.1 FAR 23.301 Loads.

- a. Strength requirements are specified in terms of limit loads (the maximum loads to be expected in service) and ultimate loads (limit loads multiplied by prescribed factors of safety). Unless otherwise provided, prescribed loads are limit loads.
- b. Unless otherwise provided, the air, ground, and water loads must be placed in equilibrium with inertia forces considering each item of mass in the airplane. These loads must be distributed to conservatively approximate or closely represent actual conditions. Methods used to determine load intensities and distribution on canard and tandem wing configurations must be validated by flight test measurement unless the methods used for determining those loading conditions are shown to be reliable or conservative on the configuration under consideration.
- c. If deflections under load would significantly change the distribution of external or internal loads, this redistribution must be taken into account.
- d. Simplified structural design criteria may be used if they result in design loads not less than those prescribed in FARs 23.331 through 23.521. For conventional, single-engine airplanes with design weights of 6,000 pounds or less, the design criteria of Appendix A of this part are an approved equivalent of FARs 23.321 through 23.459. If Appendix A is used, the entire appendix must be substituted for the corresponding sections of this part.

## 16.3 RUNNING NETLOADS.

To run NETLOADS, select the button from the main menu window. The first window is displayed when the module starts, and it includes three options: File, Notepad, and Color.

When NETLOADS first starts, the File menu has three options: New, Open, and Return to Main Menu. *New* generates a new input file and window. You are asked to name the file and the

number of spanwise load points, and then the input window is displayed. The minimum number of load points is 3, and the maximum is 100. *Open* allows you to retrieve a previously created and saved data file (example files include PHAABB36, ACCELROL, and TORBB36). *Return to Main Menu* exits from NETLOADS and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

## 16.3.1 Input Window.

The input window, shown in figure 16.1, is used to specify the parameters for the analysis. If you specified *New*, the data fields are filled with zeros. If you specified *Open*, the fields will be filled with the data. This window also includes three menu options: File, Notepad, and Color.

-  Program t File Notepad Co	o Calculate Net Wing Loa lor	ds (C) Hal McMaster 1995
X (in) 83	FX AIR (1b) 21	FX INERT (1b) 4
¥ (in) 195,975	FZ AIR (1b) 142	FZ INERT (1b) -25
Z (in) 99.096	SX AIR (1b) 21	SX INERT (1b) 4
	SZ AIR (1b) 142	SZ INERT (1b) -25
	MX AIR (in-1b)	MX INERT 0
Spanwise Load Point 1	MY AIR (in-1b) -198	MY INERT 281
	MZ AIR 0 (in-15)	MZ INERT Ø

FIGURE 16.1 NETLOADS INPUT WINDOW

After a file is open, the File menu is used to store and retrieve data from the program. The *New* command generates a new input window. *Open* allows you to retrieve a previously created and saved input file. *Save Input As* will allow the input data to be saved to a file. *Save Output As* will perform the calculations and allow the output data to be saved to a file. *Print Output* allows you to perform the calculations and print the output data to a file or printer. *Return to Main Menu* exits from NETLOADS and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.
The input required for NETLOADS is

- position of the point (x, y, z coordinates),
- air load information (x, z forces; x, z shears; x, y, z moments), and
- inertia load information (x, z forces; x, z shears; x, y, z moments).

This input data comes from the results of AIRLOADS or AIRLOAD4 and WINGINER (sections 9 or 10, and 15, respectively).

After entering the data for the first point, use the bar on the right side of the window to move to the next point. Continue to enter data until all the points are entered.

If you opened an existing data file, use the scroll bar to review the data and make changes if necessary.

# 16.3.2 Running the Analysis.

After the inputs are entered for all the points, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

When you run the analysis, you will be asked to enter an identification for the net loads condition. This identification is written to the output file.

# 16.4 NETLOADS OUTPUT.

The output includes the spanwise net wing loads, shears, and moments along the quarter chord of the wing. In the output file, the data is labeled by the variable names. These variable names are defined in table 16.1. The positive direction is up and aft.

# TABLE 16.1 DESCRIPTION OF VARIABLES USED IN THE NETLOADS OUTPUT FILE

VARIABLE NAME	DESCRIPTION
X, Y, Z	Coordinates of the quarter chord
FX, FZ	Normal force in the x and z directions (lb)
SX, SZ	Drag and shear loads (lb)
MX, MY, MZ	Moments (in-lb)

# 16.5 GRAPHICS.

The separate graphics program FAR23 Plot can be used to draw the net loads graph. An example of this graph is show in figure 16.2. The FAR23 Plot program is described in the appendix of reference 1.

To plot the data with the FAR23 Plot program, the output file from NETLOADS must be saved with a filename with the extension *.NET*.



FIGURE 16.2 EXAMPLE OF NET LOADS PLOT

## 17. ENGINE MOUNT LOADS.

## 17.1 ENGLOADS DESCRIPTION.

The module ENGLOADS calculates the loads which must be sustained by the engine mount and its supporting structure. These loads include those resulting from engine torque loads, vertical inertia loads, and side inertia loads. For turbine engines, the torque due to sudden stoppage is also included. For turbine-powered airplanes, the gyroscopic and aerodynamic loads resulting from the combination of yaw velocity, pitching velocity, normal inertia loads, and propeller thrust must be considered.

## 17.2 FAR 23 REGULATIONS.

The FAR requirements for engine mount loads are given in FAR 23.361 for engine torque, FAR 23.363 for side loads, and FAR 23.371 for gyroscopic and aerodynamic loads.

## 17.2.1 FAR 23.361 Engine Torque.

- a. Each engine mount and its supporting structure must be designed for the effects of
  - (1) a limit engine torque corresponding to takeoff power and propeller speed acting simultaneously with 75 percent of the limit loads from flight condition A of FAR 23.333(d),
  - (2) a limit engine torque corresponding to maximum continuous power and propeller speed acting simultaneously with the limit loads from flight condition A of FAR 23.333(d), and
  - (3) for turbopropeller installations, in addition to the conditions specified in paragraphs a.(1) and a.(2) of this section, a limit engine torque corresponding to takeoff power and propeller speed multiplied by a factor accounting for propeller control system malfunction, including quick feathering, acting simultaneously with 1 g level flight loads (in the absence of a rational analysis, a factor of 1.6 must be used).
- b. For turbine engine installations, the engine mounts and supporting structure must be designed to withstand each of the following:
  - (1) a limit engine torque load imposed by sudden engine stoppage due to malfunction or structural failure (such as compressor jamming) and
  - (2) a limit engine torque load imposed by the maximum acceleration of the engine.

- c. The limit engine torque to be considered under paragraph a. of this section must be obtained by multiplying the mean torque by a factor of
  - (1) 1.25 for turbopropeller installations;
  - (2) 1.33 for engines with five or more cylinders; and
  - (3) two, three, or four for engines with four, three, or two cylinders, respectively.

# 17.2.2 FAR 23.363 Side Load on Engine Mount.

- a. Each engine mount and its supporting structure must be designed for a limit load factor in a lateral direction, for the side load on the engine mount, of not less than
  - (1) 1.33 or
  - (2) one-third of the limit load factor for flight condition A.
- b. The side load prescribed in paragraph a. of this section may be assumed to be independent of other flight conditions.

# 17.2.3 FAR 23.371 Gyroscopic and Aerodynamic Loads.

For turbine-powered airplanes, each engine mount and its supporting structure must be designed for the combined gyroscopic and aerodynamic loads that result, with the engines at maximum continuous RPM, under either of the following conditions:

- a. the conditions prescribed in FARs 23.351 and 23.423 or
- b. all possible combinations of the following:
  - (1) a yaw velocity of 2.5 radians per second,
  - (2) a pitch velocity of 1 radian per second,
  - (3) a normal load factor of 2.5, and
  - (4) maximum continuous thrust.

# 17.3 RUNNING ENGLOADS.

To run ENGLOADS, select the button from the main menu window. The first input window will be displayed as shown in figure 17.1.

# 17.3.1 Input Window.

The input window is displayed when ENGLOADS starts and is used to specify the parameters for the analysis. This window includes five menu options: File, Notepad, Color, Page1, and Page2.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform

the calculations and print the output data to a file or printer. *Return to Main Menu* exits from ENGLOADS and returns to the FAR23 Loads Main Menu.



FIGURE 17.1 ENGLOADS FIRST INPUT WINDOW

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input is entered on two input windows. The following data are required in the first input window as shown in figure 17.1:

- the type of engine (reciprocating or turboprop),
- limit load factor  $(n_z)$ ,
- engine weight (lb),
- coordinates for the engine center of gravity,
- propeller weight (lb),
- propeller diameter (inches),
- number of propeller blades,
- takeoff and maximum continuous RPM, and
- titles to describe the engine and propeller manufacturer and designations.

The second input window depends on the type of engine; the two possibilities are shown in figures 17.2a and 17.2b. For a reciprocating engine, the input window is shown in figure 17.2a. The following data are required:

- maximum continuous horsepower,
- takeoff horsepower, and
- number of cylinders.

For a turboprop engine, the input window is shown in figure 17.2b. The following data are required:

- propeller hub weight (lb),
- coordinates for the propeller center of gravity,
- number of compressor rotors,
- diameter, weight, and maximum RPM for each rotor, and
- the time to stop due to sudden stoppage.

When entering the rotor data, use the scroll bar to move to the next point.

Program to Calculate Engine Mount Loads (C) Hal C McMaster 1988			
Enter Type of Engine, R for Reciprocating or T for Turboprop: R	Enter Take Off Horsepower:	285	
Enter Maximum Continuous HP: 265	Enter Number of Cylinder:	6	

FIGURE 17.2a ENGLOADS SECOND INPUT WINDOW FOR RECIPROCATING ENGINES

# 17.3.2 Running the Analysis.

After all input are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

Progra	um to Calculate Engi	ne Mount Loads (	C) Hal C McMaster	1988
Enter Type of Reciprocating	Engine, R for or T for Turboprop:	Terre de la companya	Enter Maximum Engine Torque,	285
Enter Cruise Engine Torque, FT-LBS:	265	Enter Propeller	Hub Weight, LBS:	
	Enter Number of Rot	ors: 11		
Rotor Number	Enter Rotor Diameter, IN:	Enter Rotor Weight, LBS:	Enter Rotor Maximum RPM:	
1	Ø	0	Ø	]
Ent due usu	or time in seconds to sudden stoppage ally accepts .3 sec	to stop . PAA onds.		Ŷ

## FIGURE 17.2b ENGLOADS SECOND INPUT WINDOW FOR TURBOPROP ENGINES

## 17.4 ENGLOADS OUTPUT.

For both reciprocating and turboprop engines, the output includes results for the following conditions:

- for limit takeoff torque with 75% limit maneuver vertical load factor,
- a factor times the maximum continuous torque with 100% limit maneuver vertical load factor, and
- side load independent of other flight loads.

The results include the vertical load factor and load, the coordinates where the load acts, and the engine torque. For the side load, the vertical and side load factors are given, as well as the coordinates where the load acts. For each condition, the applicable FAR requirement is specified.

For turboprop engines, additional results are included in the output file. This includes the loads for turboprop propeller malfunction, torque for sudden stoppage due to malfunction, and gyroscopic loads.

# 18. LANDING LOADS.

# 18.1 LANDLOAD DESCRIPTION.

The module LANDLOAD calculates the landing loads for a tricycle landing gear with spring or oleo struts. The main and nose gears do not have to be the same type of gear.

The inputs required for calculation of the landing loads include the landing weight, landing gear load factor, assumed lift factor during landing, the station and waterline of the axles for the static position, rolling radius of the tires, distance between main wheels, tail down bump angle, and the weight and c.g. for the structural limits.

# 18.2 FAR 23 REGULATIONS.

The FAR requirements for landing loads and ground loads are given in FARs 23.471, 23.473, 23.477, 23.479, 23.481, 23.483, 23.485, 23.493, and 23.499 and repeated here for convenience.

# 18.2.1 FAR 23.471 General.

The limit ground loads specified in FAR 23.471 are the external loads and inertia forces that act upon an airplane structure. In each specified ground load condition, the external reactions must be placed in equilibrium with the linear and angular inertia forces in a rational or conservative manner.

# 18.2.2 FAR 23.473 Ground Load Conditions and Assumptions.

- a. The ground load requirements of FAR 23.473 must be complied with at the design maximum weight, except that FARs 23.479, 23.481, and 23.483 may be complied with at a design landing weight (the highest weight for landing conditions at the maximum descent velocity) allowed under paragraphs b. and c. of this section.
- b. The design landing weight may be as low as
  - (1) 95 percent of the maximum weight if the minimum fuel capacity is enough for at least one-half hour of operation at maximum continuous power plus a capacity equal to a fuel weight which is the difference between the design maximum weight and the design landing weight or
  - (2) the design maximum weight less the weight of 25 percent of the total fuel capacity.
- c. The design landing weight of a multiengine airplane may be less than that allowed under paragraph b. of this section if
  - (1) the airplane meets the one-engine-inoperative climb requirements of FAR 23.67a. or b.(1) and

- (2) compliance is shown with the fuel jettisoning system requirements of FAR 23.1001.
- d. The selected limit vertical inertia load factor at the center of gravity of the airplane for the ground load conditions prescribed in this subpart may not be less than that which would be obtained when landing with a descent velocity (V), in feet per second, equal to  $4.4(W/S)^{\frac{1}{4}}$ , except that this velocity need not be more than 10 feet per second and may not be less than seven feet per second.
- e. Wing lift not exceeding two-thirds of the weight of the airplane may be assumed to exist throughout the landing impact and to act through the center of gravity. The ground reaction load factor may be equal to the inertia load factor minus the ratio of the above assumed wing lift to the airplane weight.
- f. Energy absorption tests (to determine the limit load factor corresponding to the required limit descent velocities) must be made under FAR 23.723(a) unless specifically exempted by that section.
- g. No inertia load factor used for design purposes may be less than 2.67 nor may the limit ground reaction load factor be less than the 2.0 at design maximum weight unless these lower values will not be exceeded in taxiing at speeds up to takeoff speed over terrain as rough as that expected in service.

# 18.2.3 FAR 23.477 Landing Gear Arrangement.

Sections 23.479 through 23.483, or the conditions in Appendix C of FAR 23, apply to airplanes with conventional arrangements of main and nose gear or main and tail gear.

## 18.2.4 FAR 23.479 Level Landing Conditions.

- a. For a level landing, the airplane is assumed to be in the following attitudes:
  - (1) For airplanes with tail wheels, a normal level flight attitude.
  - (2) For airplanes with nose wheels, attitudes in which
    - (a) the nose and main wheels contact the ground simultaneously and
    - (b) the main wheels contact the ground and the nose wheel is just clear of the ground.

The attitude used in paragraph  $a_{(2)}(a)$  of this section may be used in the analysis required under paragraph  $a_{(2)}(b)$  of this section.

b. When investigating landing conditions, the drag components simulating the forces required to accelerate the tires and wheels up to the landing speed (spin-up) must be properly combined with the corresponding instantaneous vertical ground reactions, and

the forward-acting horizontal loads resulting from rapid reduction of the spin-up drag loads (spring-back) must be combined with vertical ground reactions at the instant of the peak forward load, assuming wing lift and a tire-sliding coefficient of friction of 0.8. However, the drag loads may not be less than 25 percent of the maximum vertical ground reactions (neglecting wing lift).

- c. In the absence of specific tests or a more rational analysis for determining the wheel spinup and spring-back loads for landing conditions, the method set forth in Appendix D of FAR 23 must be used. If Appendix D of this part is used, the drag components used for design must not be less than those given by Appendix C of FAR 23.
- d. For airplanes with tip tanks or large overhung masses (such as turbo-propeller or jet engines) supported by the wing, the tip tanks and the structure supporting the tanks or overhung masses must be designed for the effects of dynamic responses under the level landing conditions of either paragraph a.(1) or a.(2)(b) of this section. In evaluating the effects of dynamic response, an airplane lift equal to the weight of the airplane may be assumed.

## 18.2.5 FAR 23.481 Tail-Down Landing Conditions.

- a. For a tail-down landing, the airplane is assumed to be in the following attitudes:
  - (1) For airplanes with tail wheels, an attitude in which the main and tail wheels contact the ground simultaneously.
  - (2) For airplanes with nose wheels, a stalling attitude, or the maximum angle allowing ground clearance by each part of the airplane, whichever is less.
- b. For airplanes with either tail or nose wheels, ground reactions are assumed to be vertical with the wheels up to speed before the maximum vertical load is attained.

## 18.2.6 FAR 23.483 One-Wheel Landing Conditions.

For the one-wheel landing condition, the airplane is assumed to be in the level attitude and to contact the ground on one side of the main landing gear. In this attitude, the ground reactions must be the same as those obtained on that side under FAR 23.479.

## 18.2.7 FAR 23.485 Side Load Conditions.

- a. For the side load condition, the airplane is assumed to be in a level attitude with only the main wheels contacting the ground and with the shock absorbers and tires in their static positions.
- b. The limit vertical load factor must be 1.33 with the vertical ground reaction divided equally between the main wheels.

- c. The limit side inertia factor must be 0.83 with the side ground reaction divided between the main wheels so that
  - (1) 0.5 (W) is acting inboard on one side and
  - (2) 0.33 (W) is acting outboard on the other side.
- d. The side loads prescribed in paragraph c. of this section are assumed to be applied at the ground contact point and the drag loads may be assumed to be zero.

# 18.2.8 FAR 23.493 Braked Roll Conditions.

Under braked roll conditions, with the shock absorbers and tires in their static positions, the following apply:

- a. The limit vertical load factor must be 1.33.
- b. The attitudes and ground contacts must be those described in FAR 23.479 for level landings.
- c. A drag reaction equal to the vertical reaction at the wheel multiplied by a coefficient of friction of 0.8 must be applied at the ground contact point of each wheel with brakes, except that the drag reaction need not exceed the maximum value based on limiting brake torque.

# 18.2.9 FAR 23.499 Supplementary Conditions For Nose Wheels.

In determining the ground loads on nose wheels and affected supporting structures, and assuming that the shock absorbers and tires are in their static positions, the following conditions must be met:

- a. For aft loads, the limit force components at the axle must be
  - (1) a vertical component of 2.25 times the static load on the wheel and
  - (2) a drag component of 0.8 times the vertical load.
- b. For forward loads, the limit force components at the axle must be
  - (1) a vertical component of 2.25 times the static load on the wheel and
  - (2) a forward component of 0.4 times the vertical load.
- c. For side loads, the limit force components at ground contact must be
  - (1) a vertical component of 2.25 times the static load on the wheel and
  - (2) a side component of 0.7 times the vertical load.

## 18.3 RUNNING LANDLOAD.

To run LANDLOAD, select the button from the main menu window. The first input window will be displayed as shown in figure 18.1.

Program t	o Calculat	e Landing Loa	ads (C) Hal C McM	aster 1988,	1989
Enter Max Landir (LB):	ıg Weight	3230	Enter Design Ma (Gross Weight)	x Weight (LB):	3400
Enter Gear Load	Factor:	2.5	Enter Wing Lift L=<.667:	Factor.	.667
Is main gear an or spring strut,	oleo strut O or S?	0	Is Nose Gear an or Spring Strut	Oleo Strut , O or S?	0
	X (IN)	Z (IN)		X (IN)	Z (IN)
Enter X,Z of MG Axles for 25% Deflection:	96.3	55.9	Axles for 25% Deflection:	1.9	46.9
Enter X,Z of MG for Static Deflection:	96.7	59.6	Enter X,Z of NG for Static Deflection:	2.4	49.5
Enter X,Z of MG for Pully Extended Deflection:	96.2	54.2	Enter X,Z of NG for Pully Extended Deflection:	1.6	45.1

FIGURE 18.1 LANDLOAD FIRST INPUT WINDOW

# 18.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window includes five menu options: File, Notepad, Color, Page1, and Page2.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a file or printer. Return to Main Menu exits from LANDLOAD and returns to the FAR23 Loads Main Menu.

Notes: If you open a data file, you must enter the stroke of the strut. Your value was not saved to the input data file, so this value always appears as 0. If you select *Save Input As*, the value for the stroke of the strut is not saved.

Currently, the *Print Output* option does not work. Therefore, you must use *Save Output As* to save the results to a file.

The Notepad option opens a Notepad program where you can review your input and output files. If you are running LANDLOAD from the FAR23 Load Main Menu, you may have problems opening your output data file. If this happens, you must exit the FAR23 Loads program before

you can view your files. If you run LANDLOAD as a stand-alone program, you can use Notepad to open and print your output file.

The Color option allows you to change the color scheme displayed on your window.

The input is entered on two input windows as shown in figures 18.1 and 18.2. On the first input window, the following data is required:

- maximum landing weight (lb),
- design maximum (or gross) weight (lb),
- landing gear load factor,
- lift factor during landing,
- type of struts (oleo or spring),
- the wing station and waterline of the gear axles for the static deflection and fully extended deflection (inches),
- for oleo struts, the wing station and waterline of the gear axles for the 25% deflection, and
- for spring struts, the wing station and waterline of the gear axles for the 25% deflection (inches).

Program to Calculate Landing L	oads (C) Hal C McMaster 198	8, 1989
Enter Rolling Radius (INCH) Main Gear: 8	Enter Rolling Radius <inch> Nose Gear:</inch>	5.?
Enter Tread (Distance Between Main Wheels), 114.5 INCH:	Enter Ground Angle (DEG) for Tail Down Allitude Measured from Ground Line to A Waterline:	, <b>15</b>
CG# : 5 WCG 3230	XCG 85.1 ZCG (IN)	93
For FWD MAX Landing Weight, Enter CG# : 6 WCG <lb>: 3230</lb>	xcg         76.12         zcg <in>:</in>	93
For FWD Light Landing Weight, Enter CG# : 7 WCG 2800	XCG 72.64 ZCG	. 92

FIGURE 18.2 LANDLOAD SECOND INPUT WINDOW

The following input is required on the second window:

- rolling radius of the gear tires (inches),
- distance between main wheels (tread) (inches),
- tail-down bump angle (degrees), and
- weight and c.g. for the structural limits.

There are three structural limits: the aft maximum landing weight, the forward maximum landing weight, and the forward light landing weight. The c.g. data comes from WTONECG (section 4).

Note: If test data is not available, the landing gear load factor can be estimated in LGFACTOR (section 19). If test data becomes available, this load factor should be revised.

# 18.3.2 Running the Analysis.

After all inputs are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. Currently, the second option does not work, so use the option *Save Output As* to save the output to a file, and then print the output from DOS using the Print command.

# 18.4 LANDLOAD OUTPUT.

In the LANDLOAD output file, the input data is listed. The type of landing gear is not given explicitly, but for oleo struts the x and z coordinates are given for the 25% deflection, while for the spring struts the coordinates are given for the 100% deflection.

The LANDLOAD module calculates the ground reactions and load factors as well as unbalanced moments. The ground reactions and load factors are given relative to the ground line and with respect to the airplane datum.

# 19. LANDING LOAD FACTOR.

# 19.1 LGFACTOR DESCRIPTION.

When test data is not available, the landing load factor is estimated in LGFACTOR. This load factor is used in the calculation of landing loads (section 18). After test data is available, the load factor should be revised.

## 19.2 FAR 23 REGULATIONS.

The requirements for the landing load factor are defined in FAR 23.473 and repeated here for convenience.

## 19.2.1 FAR 23.473 Ground Load Conditions and Assumptions.

- a. The ground load requirements of FAR 23.473 must be complied with at the design maximum weight except that FARs 23.479, 23.481, and 23.483 may be complied with at a design landing weight (the highest weight for landing conditions at the maximum descent velocity) allowed under paragraphs b. and c. of this section.
- b. The design landing weight may be as low as
  - (1) 95 percent of the maximum weight if the minimum fuel capacity is enough for at least one-half hour of operation at maximum continuous power plus a capacity equal to a fuel weight which is the difference between the design maximum weight and the design landing weight or
  - (2) the design maximum weight less the weight of 25 percent of the total fuel capacity.
- c. The design landing weight of a multiengine airplane may be less than that allowed under paragraph b. of this section if
  - (1) the airplane meets the one-engine-inoperative climb requirements of FAR 23.67a. or b.(1) and
  - (2) compliance is shown with the fuel jettisoning system requirements of FAR 23.1001.
- d. The selected limit vertical inertia load factor at the center of gravity of the airplane for the ground load conditions prescribed in this subpart may not be less than that which would be obtained when landing with a descent velocity (V), in feet per second, equal to  $4.4(W/S)^{\frac{1}{4}}$ , except that this velocity need not be more than 10 fps and may not be less than 7 fps.
- e. Wing lift not exceeding two-thirds of the weight of the airplane may be assumed to exist throughout the landing impact and to act through the center of gravity. The ground

reaction load factor may be equal to the inertia load factor minus the ratio of the above assumed wing lift to the airplane weight.

- f. Energy absorption tests (to determine the limit load factor corresponding to the required limit descent velocities) must be made under FAR 23.723(a) unless specifically exempted by that section.
- g. No inertia load factor used for design purposes may be less than 2.67, nor may the limit ground reaction load factor be less than the 2.0 at design maximum weight, unless these lower values will not be exceeded in taxiing at speeds up to takeoff speed over terrain as rough as that expected in service.

# 19.3 RUNNING LGFACTOR.

To run LGFACTOR, select the button from the main menu window. The input window will be displayed as shown in figure 19.1.

Program to Estima	te Landing Gea:	r Factor (C) Hal C McMaster	1988
Enter Wing Area, SQ FT :	184.125	Enter Landing Weight, LBS:	3230
Enter Outer Diameter of Tire, INCH:	19	Enter Diameter of Hub, INCH:	7
Is Main Gear A Spring (Y/N)?	N	Is Main Gear Strut A OLEO (Y/N)?	¥
What Is Stroke of Strut from fully extended to fully compressed, INCH:	0	Enter Lift Factor (Not Greater Than .667):	.667

FIGURE 19.1 LGFACTOR INPUT WINDOW

# 19.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a file or printer. Return to Main Menu exits from LGFACTOR and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

LGFACTOR requires the following input:

- wing area ( $ft^2$ ),
- landing weight (lb),
- outer diameter of tire (inches),
- diameter of the hub (inches),
- main gear type (either spring or oleo),
- stroke of strut from fully extended to fully retracted (inches), and
- lift factor (must be less than or equal to 0.667).

When entering the type of gear, you must select only one type. Enter Y for either spring or oleo then enter N for the other type.

# 19.3.2 Running the Analysis.

After all input are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

# 19.4 LGFACTOR OUTPUT.

The LGFACTOR module produces the following output:

- sink rate,
- airplane load factor, and
- landing gear load factor.

The landing gear load factor is used in LANDLOAD (section 18) when test data is not available.

# 20. DISTRIBUTION OF TAIL LOADS.

## 20.1 TAILDIST DESCRIPTION.

The TAILDIST module calculates chordwise distributions on the average chord for critical horizontal and vertical tail loads. It also calculates the chordwise distribution for any tail station for any of the critical loads. There are thirteen critical horizontal tail loads and four critical vertical tail loads.

## 20.2 RUNNING TAILDIST.

To run TAILDIST, select the button from the main menu window. The TAILDIST menu window will be displayed, as shown in figure 20.1. This window also include three other menu options: File, Notepad, and Color.



FIGURE 20.1 TAILDIST MENU WINDOW

In the File menu the only option is *Return to Main Menu*, which exits from TAILDIST and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

## 20.2.1 Input Windows.

After an option is selected from the main menu window, an input window is displayed. This input window is used to specify the parameters for the analysis. Each of the four options in the main menu requires multiple windows, accessed through the Page1, Page2, etc., menu choices. The windows also include three other menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The *New* command generates a new input window. *Open* allows you to retrieve a previously created and saved input file. *Save Input As* will allow the input data to be saved to a file. *Save Output As* will perform the calculations and allow the output data to be saved to a file. *Print Output* allows you to perform the calculations and print the output data to a printer or file. *Return to TAILDIST Menu* exits and returns to the TAILDIST Main Menu window (figure 20.1).

Currently, the *Print Output* option does not work correctly. Therefore, it is recommended that you use *Save Output As* to save the results to a file, and then use the Notepad option to print the results.

The Notepad option opens a Notepad program where you can review and print your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input required for each of the options is discussed below. The loads data that is used as input comes from the output files of SELECT (section 12). The geometric data that is required input, such as area, was also input for SELECT. However, in SELECT, the area data is entered as  $ft^2$ , while in TAILDIST, it must be entered as  $in^2$ .

## 20.2.2 Thirteen Critical Horizontal Tail Loads Distributed on Average Chord.

The input windows for this option are shown in figures 20.2, 20.3, and 20.4. The input required on Page1 includes the area of the horizontal tail, area of the elevator, area of the elevator forward and aft of the hinge line, and the semispan of the tail. The areas are in square inches, and the semispan of the tail is in inches.

Note: The areas are for one side of the horizontal tail. The prompts on the window should all say "Enter area of LH" part.

On Page2 and Page3, the loads due to angle of attack at the 25% MAC and loads due to camber at the 50% MAC are entered for thirteen conditions. These conditions are

- up and down balancing tail load with flaps retracted,
- up and down balancing tail load with flaps extended,
- up and down unchecked maneuver tail load,
- up and down checked maneuver tail load,
  - up and down gust tail load with flaps retracted,
  - up and down gust tail load with flaps extended, and
- unsymmetrical tail load.

11

13 Critical Horizontal Loads D	istributed On Average Chord
Enter Area of LH Horizontal Tail (SQR INCHES):	2660
Enter Area of LH Elevator (SQR INCHES):	1181
Enter Area of Elevator Fwd of Hinge Line <sqr inches="">:</sqr>	118
Enter Area of LH Elevator Aft of Hinge Line <sqr inches="">:</sqr>	1065
Enter Semispan of Tail (INCHES):	73.1

FIGURE 20.2 TAILDIST "13 CRITICAL HORIZONTAL LOADS" FIRST INPUT WINDOW



FIGURE 20.3 TAILDIST "13 CRITICAL HORIZONTAL LOADS" SECOND INPUT WINDOW



FIGURE 20.4 TAILDIST "13 CRITICAL HORIZONTAL LOADS" THIRD INPUT WINDOW

The loads data comes from the critical horizontal tail loads output file from SELECT. For the gust tail loads, both the incremental and total loads are given in the SELECT file; be sure to enter the total load here. For the unsymmetrical tail load, the SELECT file does not list the loads, but it does tell you which case has the same distribution. You will have to look through the output file to find that case and its load.

When entering the loads, you can use the *Tab* key to accept the data and move to the next cell. However, using the *Tab* key will move you down the columns on the window, thereby entering all of the angle of attack loads first then all the camber loads.

Note: On the first input window (figure 20.2) the third line should read "Enter Area of LH Elevator Fwd of Hinge Line." Also, Page3 does not have headers for the two load columns; these headers are the same as for Page2.

# 20.2.3 Four Critical Vertical Tail Loads Distributed on Average Chord.

The input windows for this option are shown in figures 20.5 and 20.6. The input required on Page1 includes the area of the vertical tail, area of the rudder, area of the rudder forward and aft of the hinge line, and the span of the tail. The areas are in square inches, and the span of the tail is in inches.

Chordwise Distribution of Critical Loads on Average Chord of Vertical Tail Enter area of vertical tail (SQR INCHES): 2137 Enter area of rudder (SQR INCHES): 754 Enter area of rudder fwd of hinger line (SQR INCHES): 82 Enter area of rudder aft of hinger line (SQR INCHES): 667 57 Enter span of vertical tail (INCHES):

FIGURE 20.5 TAILDIST "FOUR CRITICAL VERTICAL LOADS" FIRST INPUT WINDOW

	Enter load on vertical tail du to angle of atta at 25% MAC (1b):	Enter load on vertical tail due ck to camber at 50% MAC (1b):
. Maneuver load for sudden full rudden deflection.	0	679
. Maneuver load for yaw to sideslip of 19.5 deg with rudder maintained at full deflection.	-1076	679
. Maneuver load for yaw of 15 deg with rudder in neutral.	-827	8
. Side gust load at Vc.	950	8

FIGURE 20.6 TAILDIST "FOUR CRITICAL VERTICAL LOADS" SECOND INPUT WINDOW

On Page2, the loads due to angle of attack at the 25% MAC and load due to camber at the 50% MAC are entered for four conditions. These conditions are

- maneuver load for sudden full rudder deflection,
- maneuver load for yaw to sideslip of 19.5° with rudder maintained at full deflection,
- maneuver load for yaw of 15° with rudder in neutral, and
- side gust load at  $V_C$ .

The loads data comes from the critical vertical tail loads output file from SELECT. Some of the loads may be zero. In this case, do not leave the field blank—be sure to enter a value of 0.0.

When entering the loads, you can use the *Tab* key to accept the data and move to the next cell. However, using the *Tab* key will move you down the columns, thereby entering all of the angle of attack loads first then all the camber loads.

# 20.2.4 One Critical Horizontal Tail Load Distributed on N Station Chords.

The input windows for this option are shown in figures 20.7 and 20.8. The input required on Page1 includes the name of the load condition, the angle-of-attack load at the 25% MAC, the camber load at the 50% MAC, the area of one side of the horizontal tail, area of the LH elevator aft of the hinge line, and the number of butt line stations for chordwise distribution. The loads are the total load for both right and left sides; however, the area is for only one side. The loads are entered in pounds, the areas are in square inches, and the maximum number of butt line stations is ten.

(such as 'UP BALANC	ING TAIL LOAD FLAPS	RETRACIED' >:	
3P BAL TAIL LOAD FI	LAPS RETRACTED		
Enter angle of attack load (LH+RH) (1b) at 25% MAC:	907.62	Enter camber load (LH+RH) (1b) at 50% MAC:	-387.77
inter area of LH perizontal tail (SQR INCHES>:	2660	Enter area of LH elevator aft of hinge line (SQR INCHES):	1065

FIGURE 20.7 TAILDIST "CRITICAL HORIZONTAL LOAD DISTRIBUTED ON STATIONS" FIRST INPUT WINDOW

On Page2 and Page3 (if needed), the data for each butt line station is entered in inches. The data required is

- the butt line of the station,
- chord of horizontal tail at the butt line station,
- chord of elevator at the butt line station, and
- chord of elevator aft of the hinge line at the butt line station.

Only five locations can be entered on Page2. If you have more than five locations, you will need to use Page3 to enter the remaining locations.



# FIGURE 20.8 TAILDIST "CRITICAL HORIZONTAL LOAD DISTRIBUTED ON STATIONS" SECOND INPUT WINDOW

When entering the loads, you can use the *Tab* key to accept the data and move to the next cell. However, using the *Tab* key will move you across the columns, thereby entering all the data for a location before moving to the next location.

# 20.2.5 One Critical Vertical Tail Load Distributed on N Station Chords.

The input windows for this option are shown in figures 20.9 and 20.10. The input required includes the name of the load condition, the angle-of-attack load at the 25% MAC, the camber load at the 50% MAC, the area of the vertical tail, area of the rudder aft of the hinge line, and the number of water line stations for chordwise distribution. The loads are entered in pounds, and the areas are in square inches. The maximum number of water line stations is ten.

On Page2 and Page3 (if needed), the data for each water line station is entered. The data required is

- the water line of a station,
- chord of vertical tail at the water line station,
- chord of rudder at the water line station, and
- chord of rudder aft of the hinge line at the water line station.

Only five locations can be entered on Page2. If you have more than five locations, you will need to use Page3 to enter the remaining locations.

When entering the loads, you can use the *Tab* key to accept the data and move to the next cell. However, using the *Tab* key will move you across the columns, thereby entering all the data for a location before moving to the next location.

Chordwise Distribution of Loads o File Notepad Enfort Facel Facel Enter name of one of 4 critical vertica (such as 'MANEUVER LOAD FOR SUDDEN FULL	n Station Chords of Vertica 1 tail load conditions BUDDER DEFLECTION'):	l Tail
MANEUVER LOAD FOR YAW 15 DEG WITH RUDD	ER IN NEUTRAL	
Enter angle of attack load (LH+RH) (1b) at 25% MAC:	Enter camber load (LH+RH) (1b) at 50% MAC:	679
Enter area of vertical tail (SQR 2137 INCHES):	Enter area of rudder aft of hinge line (SQR INCHES):	667
Enter the number of WL stations for chordwise load distributions (Not more than 10):	3	

FIGURE 20.9 TAILDIST "CRITICAL VERTICAL LOAD DISTRIBUTED ON STATIONS" FIRST INPUT WINDOW

inter the water ine (inches) of a tation for load listribution:	Enter chord of vertical tail (inches) at that WL STA:	Enter chord of rudder (inches) at that WL STA:	Enter chord rudder aft hinge line (inches) at WL STA:
120	51.318	16.724	15.726
140	40.638	13.244	12.454
160	29.956	9.762999	9.18

FIGURE 20.10 TAILDIST "CRITICAL VERTICAL LOAD DISTRIBUTED ON STATIONS" SECOND INPUT WINDOW

## 20.2.6 Running the Analysis.

For all four analysis types, the analysis is run the same way. After all inputs are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. Currently, the second option does not work correctly and will give you error messages. Therefore, you should use the option *Save Output As* to save the output to a file, and then use Notepad (or similar program) to view and print the results. You can also print the output from DOS using the Print command.

# 20.3 TAILDIST OUTPUT.

TAILDIST produces two types of output files. The first type of output file comes from the first two options in the main menu, and the second type of output file comes from the last two options.

From the options for the load distribution on the average chord, the results of the TAILDIST analysis are the chordwise distribution of critical loads for each of the critical load conditions. For the horizontal tail, there are thirteen critical conditions; for the vertical tail, there are four critical conditions. The load distribution is given at five chordwise stations. In the output file, LT25 refers to the load due to angle of attack at the 25% MAC and LT50 refers to the load due to camber at the 50% MAC. This is an echo of your input.

The options for load distribution on N station chords results in the load distribution at the particular butt line or water line. For each station, the chordwise stations and loads are given.

## 20.4 GRAPHICS.

The separate graphics program FAR23 Plot can be used to draw the rational tail loads graphs. An example of one type of graph is shown in figure 20.11. The FAR23 Plot program is described in the appendix of reference 1.

To use the FAR23 Plot program, the output filenames must have the extension .TLD.



## FIGURE 20.11 EXAMPLE OF RATIONAL TAIL LOADS GRAPH

,

## 21. TAB LOADS.

## 21.1 TABLOADS DESCRIPTION.

The tab loads for the wing, horizontal tail, and vertical tail are determined in TABLOADS. The loads are calculated for full deflection at  $V_C$  at the shoulder on the structural limit diagram. This is where  $V_C$  is the highest in equivalent airspeed (KEAS) with the greatest Mach number.

## 21.2 FAR 23 REGULATIONS.

The requirements for the tabs are defined in FAR 23.409 and repeated here for convenience.

#### 21.2.1 FAR 23.409 Tabs.

Control surface tabs must be designed for the most severe combination of airspeed and tab deflection likely to be obtained within the flight envelope for any usable loading condition.

#### 21.3 RUNNING TABLOADS.

To run TABLOADS, select the button from the main menu window. The input window will be displayed as shown in figure 21.1.

Program to Calculate Tab Loads (C) File Notepad Color	Hal C McMaster 1995
Enter Vc (KEAS):	170
Enter the menu number for the surface on which the tab is installed (1 for wing; 2 for horizontal tail; 3 for vertical tail.):	2
Enter MAC of tab (INCHES):	7.478
Enter area of tab (SQR INCHES):	226
Enter butt line of tab MAC:	17.828
Enter chord of horizontal tail at 17.828	42.166
Enter max deflection of tab <deg>:</deg>	15

FIGURE 21.1 TABLOADS INPUT WINDOW

# 21.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window also includes three menu options: File, Notepad, and Color.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a printer or file. Return to Main Menu exits from TABLOADS and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input required for TABLOADS includes

- cruise speed  $V_C$  (KEAS),
- surface of interest (wing, horizontal tail, or vertical tail),
- the mean aerodynamic chord (MAC) for the tab (inches),
- the area of the tab  $(in^2)$ ,
- butt line of the MAC of the tab (inches),
- chord of wing (inches), and
- maximum deflection of the tab (degrees).

Depending on the surface that you select, the prompts on the input window will change to reflect your selections.

# 21.3.2 Running the Analysis.

After all inputs are entered in the input window, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

# 21.4 TABLOADS OUTPUT.

The output from TABLOADS includes the ratio of chord of tab to chord of airfoil, the tab load in pounds, and the tab pressure at the leading edge and trailing edge.

#### 22. ONE ENGINE OUT LOADS.

#### 22.1 ONENGOUT DESCRIPTION.

The loads for one-engine out are calculated with ONENGOUT. When one engine fails, the primary force acting on the airplane is an unbalanced moment about the vertical axis at the center of gravity of the airplane. The acceleration of the rotation of the airplane about the vertical axis at the c.g. is resisted by the mass moment of inertia of the airplane. As the airplane rotates, the vertical tail provides an aerodynamic force which also resists the unbalanced moment.

The net unbalanced moment and the inertia of the airplane determine the angular acceleration about the c.g. from the equation

$$\ddot{\psi} = \frac{torque}{I_{ZZ}}$$

where:

 $\ddot{\psi}$  = angular acceleration about the c.g.

*torque* = net unbalanced moment

 $I_{zz}$  = mass moment of inertia about the vertical axis at c.g.

The angular velocity and the angle are calculated as

$$\dot{\Psi}_{2} = \dot{\Psi}_{1} + \ddot{\Psi} \Delta T_{1-2}$$
  
$$\Psi_{2} = \Psi_{1} + \dot{\Psi}_{2} \Delta T_{1-2} + 0.5 \ddot{\Psi} \left( \Delta T_{1-2} \right)^{2}$$

where:

 $\dot{\psi}$  = angular velocity

 $\psi$  = yaw angle

 $\Delta T$  = increment of time

#### 22.2 FAR 23 REGULATIONS.

The requirements for the unsymmetrical loads due to engine failure are defined in FAR 23.367 and repeated here for convenience.

#### 22.2.1 FAR 23.367 Unsymmetrical Loads Due to Engine Failure.

- a. Turbopropeller airplanes must be designed for the unsymmetrical loads resulting from the failure of the critical engine including the following conditions in combination with a single malfunction of the propeller drag limiting system, considering the probable pilot corrective action on the flight controls:
  - (1) At speeds between  $V_{MC}$  and  $V_D$ , the loads resulting from power failure because of fuel flow interruption are considered to be limit loads.

- (2) At speeds between  $V_{MC}$  and  $V_C$ , the loads resulting from the disconnection of the engine compressor from the turbine or from loss of the turbine blades are considered to be ultimate loads.
- (3) The time history of the thrust decay and drag buildup occurring as a result of the prescribed engine failures must be substantiated by test or other data applicable to the particular engine-propeller combination.
- (4) The timing and magnitude of the probable pilot corrective action must be conservatively estimated, considering the characteristics of the particular engine-propeller-airplane combination.
- b. Pilot corrective action may be assumed to be initiated at the time maximum yawing velocity is reached but not earlier than 2 seconds after the engine failure. The magnitude of the corrective action may be based on the limit pilot forces specified in FAR 23.397 except that lower forces may be assumed where it is shown by analysis or test that these forces can control the yaw and roll resulting from the prescribed engine failure conditions.

#### 22.3 RUNNING ONENGOUT.

To run ONENGOUT, select the button from the main menu window. The first input window will be displayed as shown in figure 22.1.

Program to Calculate C	one Engine Out	: Vert Tail Load (C) Hal C Mc	Master 1995
Enter aspect ratio of vertical tail:	<b>\$.434</b>	Enter fuselage station for 25 percent MAC vert tail (INCHES):	428.861
Enter area of vertical tail (SQR INCHES):	7221	Enter fuselage station for 50 percent MAC vert tail (INCHES):	447.665
Enter area of rudder (SQR INCHES):	2589	Enter speed, V (KEAS):	270
Enter max deflection of rudder (DEG):	30	Enter altitude (FEET):	25000
Enter fuselage station for CG (INCHES):	190	Enter moment of inertia of airplane about vertical axis, 1zz (SLUG FI-SQ):	64209

FIGURE 22.1 ONENGOUT FIRST INPUT WINDOW

## 22.3.1 Input Window.

The input window is displayed when the module starts and is used to specify the parameters for the analysis. This window includes five menu options: File, Notepad, Color, Page1, and Page2.

The File menu is used to store and retrieve data from the program. The New command generates a new input window. Open allows you to retrieve a previously created and saved input file. Save Input As will allow the input data to be saved to a file. Save Output As will perform the calculations and allow the output data to be saved to a file. Print Output allows you to perform the calculations and print the output data to a printer or file. Return to Main Menu exits from ONENGOUT and returns to the FAR23 Loads Main Menu.

The Notepad option opens a Notepad program where you can review your input and output files.

The Color option allows you to change the color scheme displayed on your window.

The input for ONENGOUT is entered on two input windows as shown in figures 22.1 and 22.2. On Page1, the following data is entered:

- aspect ratio of the vertical tail,
- area of the vertical tail  $(in^2)$ ,
- area of the rudder  $(in^2)$ ,
- maximum deflection of the rudder (degrees),
- fuselage station of the c.g. (inches),
- fuselage station for the 25% MAC of the vertical tail (inches),
- fuselage station for the 50% MAC of the vertical tail (inches),
- speed (KEAS),
- altitude (feet), and
- moment of inertia of the airplane about vertical axis,  $I_{zz}$  (slug-ft<sup>2</sup>).

The aspect ratio and area of the vertical tail and rudder come from WINGGEOM (section 6), and the moment of inertia is from WTONECG (section 4).

On the second input page, the following data is entered:

- butt line of the engine (inches),
- maximum horsepower of one engine,
- propeller diameter (feet),
- time at which thrust decays to zero (seconds),
- time at which windmill drag builds to maximum (seconds),
- time to develop full rudder deflection (seconds), and
- incremental time step (seconds) (suggested as 0.05).

You must run a separate analysis for each speed that you are interested in. This might include  $V_C$ ,  $V_D$ , and  $V_S$ .



FIGURE 22.2 ONENGOUT SECOND INPUT WINDOW

## 22.3.2 Running the Analysis.

After all input are entered in the input windows, start the analysis by opening the File menu and selecting *Save Output As* or *Print Output*. Either selection will calculate the results and save the output to a file. The second option also prints the output.

For each speed such as  $V_C$ ,  $V_D$ , and  $V_S$ , that you are interested in, you will need to run a separate analysis.

# 22.4 ONENGOUT OUTPUT.

The output of ONENGOUT includes the engine thrust in pounds, the windmill drag in pounds, maximum yawing velocity, and maximum tail load. The time history provides the data from zero time until recovery is complete in increments as specified. At each time increment, several parameters are printed. These parameters are defined in table 22.1.

In the time history, it is indicated when engine thrust has decayed to zero, when the windmill drag has built up to the maximum, when corrective action is initiated, and when recovery is complete.

# TABLE 22.1 DESCRIPTION OF VARIABLES USED IN THE OUTPUT FILE FROM ONENGOUT

VARIABLE NAME	DESCRIPTION	
TIME	Time	
THETA	Yaw angle	
THETADOT	Angular velocity	
THETA2DOT	Angular acceleration about the c.g.	
LT25	Load at the 25% MAC	
LT50	Load at the 50% MAC	
LT	Total load	
RUD DEFL	Rudder deflection (degrees)	
MOMENT	Moment	

4

Y

# 23. REFERENCES.

\$

- 1. McMaster, Hal C., "FAR 23 Loads," Aero Science Software, Wichita, KS, 1996.
- 2. Code of Federal Regulations, Title 14, Parts 1 to 59, Aeronautics Chapter I—Federal Aviation Administration, Subchapter C—Aircraft, Part 23—Airworthiness Standards: Normal, Utility, Acrobatic and Commuter Category Airplanes, Subpart C—Structures, Revised as of January 1, 1994.
- 3. Pope, Alan, "Basic Wing and Airfoil Theory," McGraw-Hill Book Company, 1951.