

AD-A174 006



Research Product 85-09

# M60A3 Tank Procedure Guides

ARI Field Unit at Fort Knox, Kentucky  
Training Research Laboratory

February 1985

DTIC FILE COPY

DTIC  
SELECTE  
NOV 7 1986  
S  
A  
018

86 11



U. S. Army Research Institute for the Behavioral and Social Sciences

Approved for public release, distribution unlimited.

# U. S. ARMY RESEARCH INSTITUTE FOR THE BEHAVIORAL AND SOCIAL SCIENCES

A Field Operating Agency under the Jurisdiction of the  
Deputy Chief of Staff for Personnel

EDGAR M. JOHNSON  
Technical Director

L. NEALE COSBY  
Colonel, IN  
Commander

---

Technical review by

Ronald E. Kraemer  
Donald M. Kristiansen

Approved for Distribution	<input checked="" type="checkbox"/>
By _____	
Distribution/	
Availability Codes	
Dist _____	Special _____
A-1	

## NOTICES

**FINAL DISPOSITION:** This Research Product may be destroyed when it is no longer needed. Please do not return it to the U.S. Army Research Institute for the Behavioral and Social Sciences.

**NOTE:** This Research Product is not to be construed as an official Department of the Army document in its present form.



UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER ARI Research Product 85-09	2. GOVT ACCESSION NO. AD-A174 006	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) M60A3 TANK PROCEDURE GUIDES	5. TYPE OF REPORT & PERIOD COVERED FINAL	
	6. PERFORMING ORG. REPORT NUMBER --	
7. AUTHOR(s) John E. Morrison	8. CONTRACT OR GRANT NUMBER(s) --	
9. PERFORMING ORGANIZATION NAME AND ADDRESS ARI Field Unit-Fort Knox Steele Hall Fort Knox, KY 40121	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS 2Q263743A794	
11. CONTROLLING OFFICE NAME AND ADDRESS US Army Research Institute for the Behavioral and Social Sciences 5001 Eisenhower Avenue, Alexandria, VA 22333-5600	12. REPORT DATE February 1985	
	13. NUMBER OF PAGES 124	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office) --	15. SECURITY CLASS. (of this report) Unclassified	
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE --	
16. DISTRIBUTION STATEMENT (of this Report)  Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)  --		
18. SUPPLEMENTARY NOTES  Other related report is RP 85-08.		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Retraining                      Retention (Psychology) Army Training                  Performance (Human) Job Training		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This research product presents M60A3 Procedure Guides which are designed to aid experienced tank crewmen and gunners to remember and perform pre- and post-operation procedures for the M60A3 battle tank. One of the notable innovations of the Procedures is the abbreviated algorithmic format for presenting task information. Also, separate booklets were developed for tank commander and gunner tasks. And both booklets were designed to be reduced and inserted into plastic binders. These innovations were intended to make the Procedure Guides easy to use and rugged enough to withstand the rigors of the tank environment.		

DD FORM 1 JAN 73 1473 EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Research Product 85-09

## M60A3 Tank Procedure Guides

**John E. Morrison**

ARI Field Unit at Fort Knox, Kentucky  
Donald F. Haggard, Chief

**Training Research Laboratory**  
**Harold F. O'Neil, Jr., Director**

U.S. ARMY RESEARCH INSTITUTE FOR THE BEHAVIORAL AND SOCIAL SCIENCES  
5001 Eisenhower Avenue, Alexandria, Virginia 22333-5600

Office, Deputy Chief of Staff for Personnel  
Department of the Army

February 1985

---

Army Project Number  
2Q263743A794

Education and Training

Approved for public release; distribution unlimited.

ARI Research Reports and Technical Reports are intended for sponsors of R&D tasks and for other research and military agencies. Any findings ready for implementation at the time of publication are presented in the last part of the Brief. Upon completion of a major phase of the task, formal recommendations for official action normally are conveyed to appropriate military agencies by briefing or Disposition Form.

---

## FOREWORD

---

The Army Research Institute (ARI) Field Unit at Fort Knox, Kentucky, is engaged in research and development on armor training and performance problems related to armor weapon systems. One such problem is that the armor crewman must perform a number of lengthy and complex procedures to prepare the M60A3 battle tank for operation and to power the tank down after operation. Although the M60A3 Operator's Manual (TM 9-2350-253-10) provides complete documentation on these procedural tasks, the TM is a less than ideal job performance aid for the armor crewman who is familiar with the tasks. The Procedure Guides presented herein provide appropriate and convenient aids to help experienced armor crewmen remember and perform procedures for the M60A3 tank.

The M60A3 Procedure Guides were developed along the lines of the M1 Procedure Guides which incorporate a number of innovations. One of the more notable innovations is the abbreviated task information presented in an algorithmic format. Also, the booklets are specific to either tank commander or gunner tasks. And both booklets can be reduced and inserted into plastic ring binders. These innovations were designed to make the Procedure Guides easy to use and rugged enough to withstand the rigors of the tank environment.

The armor community has demonstrated considerable interest in the Procedure Guides. Both the M1 and M60A3 Procedure Guides have been adopted by the Armor School for distribution to armor units worldwide. Furthermore, the development methodology and format of these armor documents were used by the Fort Benning Field Unit to produce Procedure Guides for the Infantry Fighting Vehicle.



EDGAR M. JOHNSON  
Technical Director

**M60A3 TANK PROCEDURE GUIDES**

**CONTENTS**

---

	<u>Page</u>
<b>OVERVIEW . . . . .</b>	<b>1</b>
<b>Background . . . . .</b>	<b>1</b>
<b>Development . . . . .</b>	<b>1</b>
<b>Features . . . . .</b>	<b>1</b>
<b>How to Use . . . . .</b>	<b>2</b>
<b>APPENDIX A. TANK COMMANDER PROCEDURE GUIDES . . . . .</b>	<b>A-1</b>
<b>B. GUNNER PROCEDURE GUIDES . . . . .</b>	<b>B-1</b>

## OVERVIEW

### Background

To prepare the M60A3 battle tank for operation and to power down after operation, armor crewmen have to perform a number of procedural tasks. Although the M60A3 Operator's Manual (TM 9-2350-253-10) presents complete documentation on these tasks, it provides a less than ideal job performance aid for experienced armor crewmen. Some of the problems with the TM include:

- Excessive detail: The procedures are described at an inappropriate level of detail for the experienced performer.
- Large size: The TM is large and cumbersome to use.
- One per tank: Because only one TM is issued per tank, it is unavailable to three of the four crewmen during pre- and post-operations checks.

The M60A3 Procedure Guides were designed to address these problems by providing position-specific job aids that are convenient and complete.

### Development

Eighteen tank commander and 15 gunner procedures were chosen to be included in the Procedure Guides. The format for the M60A3 Guides was taken from Procedure Guides previously developed for the M1 tank.<sup>1,2</sup> All task information was derived from the TM in order to make the Guides compatible with the TM.

### Features

Some of the more notable features of the M60A3 Procedure Guides are listed below:

- "Part . . . action" format: Task information is abridged by casting each step in this format.
- Algorithmic conventions: Flowchart symbols are used to describe branch points in more complex tasks.
- Notes/cautions/warnings: These items which concern task performance, safety, or system integrity are identified at appropriate points in the procedure.

---

<sup>1</sup>Silbernagel, B. L., Vaughan, J. J., Jr., and Schaefer, R. H. Development of M1 Abrams Tank Sustainment Training Material. ARI Research Report 1334, June 1982.

<sup>2</sup>Vaughan, J. J., Silbernagel, B., and Goldberg, S. L. M1-Abrams Tank Procedure Guides. ARI Research Product 82-09, July 1982.



- Identification of common subprocedures: To avoid duplication of information, common subprocedures are identified and presented as separate procedures.
- Convenient, rugged packaging: The guides are designed to be reduced to a smaller (4½" x 7") format and inserted in plastic covered ring binders.
- Separate booklets: Separate Procedure Guides are provided for tank commander and gunner tasks.
- Preventive Maintenance Checks and Services (PMCS): PMCS tasks are presented in the appropriate books, and the tank commander book also has a master checklist.


#### How To Use

The Procedure Guides are designed to complement the TM, not to replace it. The TM is still the most appropriate reference for the details of equipment operation. And the TM should be used for initial training of procedures. The Procedure Guides should be introduced only after soldiers are reasonably familiar with the equipment and task terminology. Additional training on the Procedure Guides themselves is also required to acquaint soldiers with its algorithmic style and abbreviations.

**TANK COMMANDER**

**PROCEDURE GUIDES**

**M60A3 TANK**



July 1982

PREPARED BY THE U.S. ARMY RESEARCH INSTITUTE  
FOR THE  
BEHAVIORAL AND SOCIAL SCIENCES

## GENERAL INFORMATION





This booklet contains M60A3 tank commander procedures guides. Each guide is for a single pre-operation, post-operation, or during operation activity. Each guide is matched to TM 9-2350-253-10 (Operator's Manual for Tank, Combat, Full-Tracked: 105-MM Gun, M60A3).

## PURPOSE OF PROCEDURE GUIDES

The guides in this booklet will not take the place of the M60A3 Operator's Manual or M60A3 training materials. The guides will aid you in remembering long or difficult sets of procedures. In short, the guides will help to "jog your memory."

## USE OF THIS BOOKLET

The Table of Contents (on the next page) lists the procedure guides in this booklet. Each guide gives you a step-by-step outline for completing an activity. The following instructions will help you to better use each guide.

1. Some steps within a procedure are followed by a page number. On that page you will find a detailed breakdown of the step.
2. Some of the procedure guides include a question(s). Each question is stated inside a diamond shape. Your "yes" or "no" to the question will show you which path to follow.
 
3. Some paths lead to an instruction to go to a particular step number within a procedure. The step number is given within a circle.
 
4. Some steps within a procedure guide are followed by a box. In the box you will find more information on the step or a caution/warning.
 
5. Certain steps within a procedure guide require that a knob or switch be turned to a certain position. In some cases, that position might be written like the symbol to the left. The symbol means that a light should also come on.
 
6. Master check-off lists of all before, during, and after operations preventative maintenance checks and services (PMCS) performed by crewmembers are included as an aid in your supervision of these activities.
7. At the beginning of each procedure, the TM page number reference for the procedure is given under the task name. These references will help you if you need more information to complete the task.

## TABLE OF CONTENTS


	<u>Page</u>
<u>COMMANDER'S PERISCOPE M36E1</u>	
INSTALLING COMMANDER'S PERISCOPE M36E1 . . . . .	1
OPERATING COMMANDER'S PERISCOPE M36E1 . . . . .	2
REMOVING COMMANDER'S PERISCOPE M36E1 . . . . .	4
<u>LASER RANGEFINDER (LRF)</u>	
OPERATING LASER RANGEFINDER (LRF) . . . . .	6
LASER RANGEFINDER SELF-TEST . . . . .	8
RANGING AND LOGIC TABLE . . . . .	14
LRF FIRING TEST . . . . .	15
BORESIGHTING LASER RANGEFINDER (LRF) . . . . .	16
<u>COMMANDER'S MACHINE GUN</u>	
CLEARING CALIBER .50 MACHINE GUN . . . . .	19
INSTALLING CALIBER .50 MACHINE GUN . . . . .	21
TESTING CALIBER .50 MACHINE GUN FIRING CIRCUIT . . . . .	23
BORESIGHTING CALIBER .50 MACHINE GUN . . . . .	25
ZEROING CALIBER .50 MACHINE GUN . . . . .	29
REMOVING CALIBER .50 MACHINE GUN . . . . .	32
PREPARING TO FIRE PROCEDURE . . . . .	33
<u>PREVENTATIVE MAINTENANCE CHECKS AND SERVICES (PMCS)</u>	
DURING OPERATIONS PMCS . . . . .	38
MASTER CHECK-OFF LIST -- BEFORE OPERATIONS PMCS . . . . .	40
MASTER CHECK-OFF LIST -- DURING OPERATIONS PMCS . . . . .	42
MASTER CHECK-OFF LIST -- AFTER OPERATIONS PMCS . . . . .	43
<u>PICTURES</u>	
LASER RANGEFINDER RECEIVER-TRANSMITTER . . . . .	45
NETWORKS BOX . . . . .	46
AMMUNITION SELECT UNIT . . . . .	47

INSTALLING COMMANDER'S PERISCOPE M36E1

(TM page 3-122)


LINK ASSEMBLY MUST BE DISCONNECTED FROM PERISCOPE AND ATTACHED TO STOWAGE HANGER BEFORE INSTALLING PERISCOPE DAYLIGHT BODY

1. Daylight body . . . . . Slide into position carefully
2. Daylight body latches . . . . . Engage Support daylight body with one hand
3. Passive elbow . . . . . Slide into position carefully
4. Passive elbow latches . . . . . Engage Support passive elbow with one hand
5. Two electrical connectors . . . . . Connect to rear of daylight body
6. Quick-disconnect clamp . . . . . Disconnect from stowage hanger/  
connect to periscope elevation arm
7. Stowage hanger . . . . . Place in cupola ceiling stowage clip



OPERATING COMMANDER'S PERISCOPE M36E1

(TM page 2-234)




OPERATE PASSIVE ELBOW ONLY UNDER  
LOW LIGHT CONDITIONS OR WITH  
BALLISTIC SHIELD COVER CLOSED

Opens shutter and  
activates power  
switch

Use lowest possible  
intensity

- 10.. Passive elbow shutter lever . Move to the left
- 11. RETICLE control . . . . . Adjust reticle brightness
- 12. TUBE control . . . . . Adjust tube brightness
- 13. Diopter ring . . . . . Focus background
- 14. Focus ring . . . . . Focus target image
- 15. Tube control . . . . . Readjust for clearest image



REMOVING COMMANDER'S PERISCOPE M36E1

(TM page 3-122)

1. Cal .50 machine gun . . . . . Elevate to upper limit
2. Quick-disconnect clamp . . . . . Disconnect from periscope elevation arm
3. Elevation arm . . . . . Move toward rear of cupola
4. Quick-disconnect clamp . . . . . Connect to stowage hanger

LINK ASSEMBLY MUST BE DISCONNECTED FROM PERISCOPE AND ATTACHED TO STOWAGE HANGER BEFORE REMOVING M36 PERISCOPE DAYLIGHT BODY.

5. Two electrical connectors . . . . . Disconnect from rear of daylight body
6. Lamp housing . . . . . Disconnect from daylight body (dovetail slot)
7. Lamp housing . . . . . Connect to light source control (dovetail slot)
8. M30 instrument light . . . . . Disconnect from passive elbow

9. Passive elbow latches . . . . . Release

Support passive elbow with one hand

GO TO 10

GO TO 10




10. Passive elbow . . . . . Lower carefully

11. Daylight body latches . . . . . Release

12. Daylight body . . . . . Lower carefully

Support day-  
light body  
with one hand







OPERATING LASER RANGEFINDER (LRF)

(TM page 2-246)


LIMIT SUSTAINED RANGING RATE TO THREE PER MINUTE OR SIX PER TWO MINUTES WITH THREE-MINUTE INTERVALS BETWEEN EACH TWO MINUTE RANGING PERIOD.

DO NOT LEAN AGAINST RECEIVER-TRANSMITTER WHEN VIEWING THROUGH EYEPiece OR LASING.


MAKE SURE BLISTER COVER IS LOCKED IN THE OPEN POSITION WHEN RANGING.

- 1. MODE . . . . . 
- 2. MASTER BATTERY . . . . .  (driver)
- 3. POWER . . . . .  (gunner)
- 4. Headrest . . . . . Adjust 

Use serrated knob to release and lock









- 5. Blister cover . . . . . Lock in open position
- 6. Eyepiece . . . . . Sight image
- 7. Diopter ring . . . . . Adjust until image is sharp and clear
- 8. RETICLE BRIGHTNESS . . . . . Adjust reticle brightness
- 9. 6X/12X switch . . . . . Select appropriate power
- 10. Rubber eye shield . . . . . Pull off
- 11. Laser filter . . . . . Remove from stowage bracket/  
snap over eyepiece
- 12. Rubber eye shield . . . . . Replace



LASER RANGEFINDER SELF-TEST




(TM page 2-248)

- 1. MODE . . . . . 
- 2. MASTER BATTERY . . . . . 
- 3. POWER . . . . .  (gunner)
- 4. MANUAL/RANGEFINDER . . . . . RANGEFINDER (gunner)
- 5. LIGHT/DIM/TEST . . . . . 
- 6. Control panel indicators . . . All should illuminate
- 7. RANGE (METERS) . . . . . Should display 8888
- 8. RETURNS . . . . . Should display 8
- 9. LIGHT/DIM/TEST . . . . . 
- 10. Control panel indicators . . . The following should illuminate: RANGE, RESET, FEED, BATL RNG, LAST, TEST




- 11. RANGE (METERS) . . . . . Should display 0000
- 12. RETURNS . . . . . Should display 0

DO NOT PRESS RANGE SWITCH OR THUMB SWITCHES ON GUNNER'S CONTROL HANDLES WHILE MODE SWITCH IS IN ON OR AUTO, LASER WILL FIRE.

- 13. MODE . . . . . 
- 14. MODE . . . . . 
- 15. RANGE indicator . . . . . Should flash within 4 seconds
- 16. MANUAL/RANGEFINDER . . . . . MANUAL (gunner)
- 17. RANGE indicator . . . . . Should not flash
- 18. MANUAL/RANGEFINDER . . . . . RANGEFINDER (gunner)
- 19. MODE . . . . . 

- 20. EMER POWER . . . . . ON (gunner)
- 21. Indicators on electronics . . . . . Should remain on unit


GO TO  
22

- 22. EMER POWER . . . . . XMTR TEST (gunner)
- 23. Indicators on electronics . . . . . Should remain on unit
- 24. EMER POWER . . . . . OFF (gunner)
- 25. RANGE pushbutton . . . . .  Depress/Hold
- 26. RANGE (METERS) . . . . . Should display 0002
- 27. MALF . . . . . Should illuminate
- 28. RANGE . . . . . Release
- 29. BATL RNG . . . . . Depress
- 30. LRF panel . . . . . Perform logic test


Indicator should illuminate

Use Ranging and Logic Table (page 14)


DO NOT LOOK INTO LRF EYEPIECE WHEN FIRING LASER INTO THE BLISTER DOOR.


- 31. Blister door . . . . . Assure closed
- 32. Blister door pin . . . . . Assure installed
- 33. EMER POWER . . . . . XMTR TEST (gunner)
- 34. MODE . . . . . 

GO TO 35

- 35. RANGE indicator . . . . . Should flash within 4 seconds
- 36. RANGE pushbutton . . . . .  Press/Release
- 37. Selector lights . . . . . LAST should illuminate
- 38. RETURNS . . . . . Should display 0
- 39. RANGE (METERS) . . . . . Should display 9995 (+15)
- 40. SEL light . . . . . Should be on
- 41. GO light . . . . . Should be off

Report as non-operational






PERFORM FOLLOWING STEPS ONLY IN AN AUTHORIZED LASING AREA. MAKE SURE APPROPRIATE FILTERS HAVE BEEN INSTALLED IN SIGHTS. DO NOT FIRE AT REFLECTIVE SURFACES OR WHEN PERSONNEL WITHIN 20° OF LASER LINE OF SIGHT. BEFORE FIRING, WARN PERSONNEL NOT TO LOOK AT TARGET OR IN THE DIRECTION OF THE BEAM.

- 44. Target . . . . . Clear area/1200 meters
- 45. EMER POWER . . . . . XMTR TEST (gunner)



46. MODE . . . . .

DO NOT LEAN OR PUSH AGAINST RECEIVER-TRANSMITTER WHEN VIEWING THROUGH EYEPIECE OR LASING.






- 47. LRF reticle . . . . . Lay on target
- 48. LRF panel . . . . . Perform firing test.

Use LRF Firing  
Test Table (page 15)

IF TARGET RANGE IS NOT OBTAINED DURING LRF TEST, MAKE SURE THAT LRF AND GUNNER'S RETICLES ARE ON THE SAME POINT. IF NOT REBORESIGHT THE SYSTEM AT EARLIEST OPPORTUNITY.

- 49. EMER POWER . . . . . OFF



- 50. MODE . . . . . 

Ranging and Logic Table

Step	Inputs		Indications					SEL Light	GO Light
	Press and Release	Selector Lights	RETURNS Display	RANGE (METERS) Display (+15)*	RETURNS Display	RANGE (METERS) Display (+15)*			
1	Set MODE switch to TEST								
2	RESET	LAST	0	0000		0000	OFF	OFF	
3	RANGE	LAST	1	850		850	OFF	ON	
4	BATL RNG	LAST	0	0000		0000	OFF	OFF	
5	RANGE	LAST	1	850		850	OFF	ON	
6	1	LAST	1	850		850	OFF	ON	
7	2	LAST	1	850		850	OFF	ON	
8	RANGE	LAST	2	1850		1850	OFF	ON	
9	RANGE	LAST	3	2850		2850	OFF	ON	
10	RANGE	LAST	4	2850		2850	OFF	ON	
11	1	1	4	850		850	OFF	OFF	
12	2	2	4	1850		1850	OFF	OFF	
13	LAST	LAST	4	2850		2850	OFF	OFF	
14	2	2	4	1850		1850	OFF	ON	
15	FEED	2	4	1850		1850	OFF	OFF	
16	RESET	LAST	0	0000		0000	OFF	OFF	
17	2	2	0	0000		0000	OFF	OFF	
18	RANGE	2	1	9995**		9995**	ON	OFF	
19	FEED	2	1	9995		9995	ON	OFF	
20	RANGE	2	2	1850		1850	ON	OFF	
21	FEED	2	2	1850		1850	OFF	ON	
22	Range***	LAST	0	0000		0000	OFF	OFF	
23	RESET	LAST	0	0000		0000	OFF	OFF	

\*Last digit of range display must always be 0 or 5

\*\*If RANGE (METERS) displays 0000, go back to step 15.

\*\*\*Set ELEV/TRAV POWER switch to ON position and range from gunner's handles.  
Set ELEV/TRAV POWER switch to OFF position.

## LRF Firing Test

Step	Inputs	Indications				GO Light
		Selector Lights	RETURNS Display	RANGE (METERS) Display (+ 15)**	SEL Light	
1	RESET	LAST	0	0000	OFF	OFF
2	2	2	0	0000	OFF	OFF
3	RANGE	2	1	9995*	ON	OFF
4	1	1	1	Target Range****	ON	OFF
5	FEED	1	1	Target Range	OFF	ON
6	Range***	LAST	1	Target Range	ON	OFF

\*If RANGE (METERS) displays 0000, press RESET and repeat test sequence.

\*\*Last digit of range display must always be 0 or 5.

\*\*\*Set ELEV/TRAV POWER switch to ON position and range from gunner's station.  
Set ELEV/TRAV POWER switch to OFF position.

\*\*\*\*If RANGE (METERS) displays 9995, set EMER POWER to OFF and repeat steps 1-4.

BORESIGHTING LASER RANGEFINDER (LRF)

(TM page 2-350)

DO NOT VIEW LASER BEAM THROUGH DEVICE NOT FILTERED FOR LASER LIGHT. FIRE LASER IN AUTHORIZED LASING AREA ONLY.

- 1. Laser filter . . . . . Install on eyepiece
- 2. RETICLE BRIGHTNESS . . . . . Rotate until reticle is just visible
- 3. MANUAL/RANGEFINDER . . . . . RANGEFINDER



4. MODE . . . . .




5. BATL RNG . . . . .

DO NOT LEAN OR PUSH AGAINST RECEIVER-TRANSMITTER WHEN VIEWING THROUGH EYEPIECE OR LASING.

6. 6X/12X . . . . . 12X

7. Eyepiece . . . . . Sight target



Lay reticle from left to right and from low to high without overtravel

8. DEFLECTION AND ELEVATION controls . . . . . Lay reticle on aiming point

9. BORESIGHTING WITH MUZZLE BORESIGHT DEVICE ?

9a. Muzzle crossthreads . Assure on target aiming point

GO TO 11

10. Periscope reticle . . . . . Assure on target aiming point

11. Slip scales . . . . . Set on 4 and 4

12. RANGE . . . . . Press

13. 1 or 2 pushbuttons . . . . . Press if necessary

GO TO 7

DOES RANGE (METERS) RANGE INDICATE PROPER RANGE ?

GO TO 15

Lay reticle on aiming point

NO

NO

YES

YES

YES

GO will light


Press



15. FEED . . . . .

16. MODE . . . . .


17. Laser filter . . . . . Remove from eyepiece/  
replace in holder



YES

18a. Periscope reticle. . . Assure on target aiming point

NO



NO

19a. Control handles . . . Relay main gun on target


19b. DEFLECTION and . . . Lay reticle on aiming point ELEVATION


19c. Slip scales . . . . . Set on 4 and 4

YES

CLEARING CALIBER .50 MACHINE GUN

(TM page 2-337)








INSTALLING CALIBER .50 MACHINE GUN

(TM page 3-122)

LINK ASSEMBLY MUST BE CONNECTED TO STORAGE HANGER BEFORE INSTALLING CAL .50 MACHINE GUN.


So that gun can slide under TC's periscope

1. Machine gun . . . . . Clear (page 19)
2. Rear mounting pin . . . . . Remove
3. Machine gun cradle . . . . . Elevate
4. Machine gun . . . . . Slide in cradle
5. Rear mounting pin . . . . . Secure gun in cradle
6. Solenoid lead connector . . . . . Connect to end plate



GO TO 9

- 9. Barrel . . . . . Insert/rotate 1/4 turn
- 10. Cradle access door . . . . . Close
- 11. Quick-disconnect clamp . . . . . Disconnect from stowage/  
hanger/connect to periscope  
elevation arm
- 12. Stowage hanger . . . . . Place in cupola ceiling  
stowage clip
- 13. Cal .50 firing circuit . . . . . Test (page 23)



TESTING CALIBER .50 MACHINE GUN FIRING CIRCUIT

(TM page 3-121)

1. Machine gun . . . . . Clear (page 19)



2. MASTER BATTERY . . . . .



3. CUPOLA POWER . . . . .

4. GUN SAFETY . . . . . ON

5. Dummy ammo . . . . . Load


or


Last round sensing switch . . . . . Depress

6. LAST ROUND OVERRIDE . . . . . OFF



7. . . . . 7a. LAST ROUND OVERRIDE . . . . .






BORESIGHTING CALIBER .50 MACHINE GUN

(TM page 2-366)

1. Tank position . . . . . Level
2. Machine gun . . . . . Elevate to upper limit
3. M36E1 Periscope . . . . . Remove (page 4)
4. Machine gun . . . . . Clear (page 19)
5. Solenoid lead connector . . . . . Disconnect from backplate assembly
6. Backplate . . . . . Lift off
7. Bolt buffer group . . . . . Remove
8. Sear assembly . . . . . Remove
9. Charger handle . . . . . Pull slowly
10. Cover . . . . . Open
11. Bolt assembly . . . . . Pull out
12. Cover . . . . . Close
13. Boresight target . . . . . Right angle/500 meters



GO TO 14


Use manual controls

- 14. Center of barrel . . . . . Aline on target aiming point
- 15. AZIMUTH LOCK . . . . . Push up
- 16. Azimuth adjustment knob . . . . . Adjust azimuth precisely if necessary
- 17. Machine gun/cupola . . . . . Do not move
- 18. M36E1 Periscope . . . . . Install (page 1)
- 19. M36E1 Periscope . . . . . Prepare for operation (page 2)
- 20. Daylight body eyepiece . . . . . Sight target/disengage
- 21. Daylight body elevation . . . . . Aline boresight cross on and deflection knobs
- 22. Slip scales of daylight body . . . . . Set on 4 and 4



A-29

- 24. Searchlight . . . . . Light target momentarily if necessary
- 25. Passive body eyepiece . . . . . Sight target/disengage



- 26. Passive body elevation . . . . . Align reticle on aiming point and deflection knobs
- 27. Slip scales of passive elbow . . . . . Set on 4 and 4
- 28. Daylight body reticle . . . . . Verify still on target aiming point

LINK ASSEMBLY MUST BE DISCONNECTED FROM PERI-SCOPE AND ATTACHED TO STOWAGE HANGER BEFORE ASSEMBLING CAL .50 MACHINE GUN.


- 29. Cal .50 machine gun . . . . . Elevate to upper limit
- 30. Quick-disconnect clamp . . . . . Disconnect from periscope elevation arm
- 31. Elevation arm . . . . . Move toward rear of cupola
- 32. Quick-disconnect clamp . . . . . Connect to stowage hanger
- 33. M36E1 Periscope . . . . . Remove (page 4)
- 34. Cover . . . . . Open
- 35. Bolt locks . . . . . Depress
- 36. Bolt assembly . . . . . Slide into barrel extension assembly
- 37. Hand . . . . . Remove from lever assembly
- 38. Bolt assembly . . . . . Slide forward

Hold lever and ejector assemblies to the left

Force cartridge ejector to the left

GO TO  
39


- 39. Sear assembly guide rails . . . Aline with grooves in receiver
- 40. Sear assembly . . . . . Slide forward
- 41. Bolt buffer group . . . . . Install
- 42. Backplate group . . . . . Aline with grooves in receiver
- 43. Backplate group . . . . . Slide downward
- 44. Machine gun cover . . . . . Close
- 45. Cradle access door . . . . . Close
- 46. Cradle cover . . . . . Close
- 47. Bolt . . . . . Place forward
- 48. Safety . . . . . F
- 49. M36E1 Periscope . . . . . Install (page 1)
- 50. Quick-disconnect clamp . . . . . Disconnect from stowage hanger/  
connect to elevation arm assembly
- 51. Stowage hanger . . . . . Place in cupola ceiling  
stowage clip







ZEROING CALIBER .50 MACHINE GUN

(TM page 2-397)




**SAFETY MUST BE IN F BEFORE CHARGING WEAPON. CHARGING IN S MAY CAUSE THE WEAPON TO FIRE ACCIDENTALLY.**





15. Trigger switch . . . . . Fire 10-20 round burst




REMOVING CALIBER .50 MACHINE GUN

(TM page 3-122)

1. Machine gun . . . . . Clear (page 19)
2. CUPOLA POWER . . . . . OFF
3. Machine gun . . . . . Elevate To disconnect solenoid lead connector
4. Solenoid lead connector . . . . . Disconnect from end plate
5. Cradle access doors . . . . . Open
6. Barrel . . . . . Rotate 1/4 turn/remove Press down on barrel latches
7. Machine gun . . . . . Elevate So that gun can slide under IC's periscope


LINK ASSEMBLY MUST BE CONNECTED TO STOWAGE HANGER BEFORE REMOVAL OF CAL .50 MACHINE GUN.

8. Quick-disconnect clamp . . . . . Disconnect from elevation arm
9. Elevation arm . . . . . Move toward rear of cupola
10. Quick-disconnect clamp . . . . . Connect to stowage hanger
11. Rear mounting pin . . . . . Remove
12. Machine gun . . . . . Slide from cradle





PREPARING TO FIRE PROCEDURE  
(TM page 2-400)

COMMAND: PREPARE TO FIRE


1. Exterior lenses and . . . . . Clean  
vision devices
2. Cupola ballistic . . . . . Check operation  
periscope shield
3. MASTER BATTERY . . . . .  (driver)
4. Instrument lights . . . . . Check
5. LRF . . . . . Check for MALF light

COMMAND: CHECK FIRING SWITCHES

6. MAIN GUN . . . . .  (gunner)
7. Engine . . . . . Start (driver)
8. 105-mm gun safety switch . . . . . In FIRE (loader)
9. Circuit tester . . . . . Insert (loader)
10. TC . . . . . Announces: ON THE WAY


 GO TO  
11

Loader announces  
NO FIRE if circuit  
tester does not light

- 11. TC's control handle . . . . . Check trigger
- 12. Gunner's control handles . . . . . Check triggers (gunner)
- 13. MAIN GUN . . . . . OFF (gunner)
- 14. MACHINE GUN . . . . .  (gunner)
- 15. Coaxial machine gun . . . . . Cock (loader)
- 16. TC . . . . . Announces: ON THE WAY
- 17. TC's control handle . . . . . Check trigger
- 18. Gunner's control handles . . . . . Check triggers (gunner)

Loader announces  
NO FIRE if circuit  
tester does not light

COMMAND: CHECK GUN CONTROLS


- 19. Gunner . . . . . Announces: POWER
- 20. Turret . . . . . Unlock (loader)
- 21. ELEV/TRAV POWER . . . . .  (gunner)
- 22. Gun/turret . . . . . Elevate/traverse using TC power controls

GO TO  
23

23. ELEV/TRAV POWER . . . . . OFF (gunner)

MAKE SURE THAT CREW IS READY AND NO PERSONNEL OR OBSTRUCTIONS ARE IN SURROUNDING AREA

COMMAND: CHECK GUN STABILIZATION



- 29. Gunner . . . . . Announces: TURRET STABILIZED
- 30. TRAV and/or EL BALANCE . . . . . Rotate to null drift (gunner)
- 31. Gunner's control handles . . . . . Check function (gunner)
- 32. TC palm switch . . . . . Activate override


GO TO 33

- 33. TC control handles . . . . . Check function
- 34. STAB SHUT-OFF . . . . . Depress
- 35. POWER on selector assembly . . . . . OFF (gunner)
- 36. Gunner . . . . . Announces: STABILIZATION OFF

COMMAND: CHECK FIRE CONTROL



- 37. CUPOLA POWER . . . . . ON
- 38. GUN SAFETY . . . . . ON
- 39. Cal .50 machine gun . . . . . Check operation
- 40. XM21 computer . . . . . Perform self-test (gunner)
- 41. 105-mm gun . . . . . Prepare for boresighting (loader)
- 42. LRF . . . . . Perform self-test (page 8)
- 43. Gunner's telescope and . . . . . Boresight (gunner) periscope
- 44. LRF . . . . . Boresight (page 14)
- 45. Ammo switch : . . . . . Select appropriate ammo (gunner)






- 46. MOVING/STATIONARY . . . . . Select appropriate setting (gunner)
- 47. Computer . . . . . Enter ballistic data (gunner)
- 48. Cal .50 machine gun . . . . . Boresight (page 18)
- 49. 7.62-mm machine gun . . . . . Load (loader)
- 50. 105-mm gun . . . . . Load (loader)
- 51. Cal .50 machine gun . . . . . Load

COMMAND: REPORT

- 52. Gunner/Driver/Loader . . . . . Announce: READY



DURING OPERATIONS PMCS

(TM page 2-105)

1. Commander's seat . . . . . Check operation/adjustment
2. Amplifier AM-1780/VRC . . . . . Turn on
3. MONITOR . . . . . INT ONLY
4. VOLUME . . . . . Adjust
5. Radio/intercom . . . . . Check operation
6. Azimuth lock . . . . . Check operation
7. Azimuth interlock . . . . . Check operation
8. Azimuth lock . . . . . Unlock
9. Manual traversing handle . . . . . Traverse cupola right/left
10. Azimuth lock . . . . . Lock
11. Elevating handle . . . . . Depress/elevate Cal .50
12. TC control handles . . . . . Check operation

Check that  
cupola traverses  
smoothly

Check that  
machine gun  
elevates smoothly

GO TO  
13

- 13. Gunner control handles . . . . Traverse turret (gunner)  
counterclockwise
  - 14. TC control handles . . . . . Override gunner and traverse  
turret clockwise
  - 15. M36E1 Periscope ballistic . . . . . Assure open  
shield
  - 16. M36E1 Periscope window . . . . . Clean
- 
- Depress palm switch
- Use cleaning compound and lens tissue

TANK COMMANDER MASTER CHECK-OFF LIST

BEFORE OPERATIONS PMCS

(TM page 2-84)

Location	System	Equipment	CHECK														
			Adjustment	Clean/Clear	Damage	In Place	Leaks	Level	Missing Parts	Operation	Position	Pressure	Secure	Status			
Exterior	Torsion Bars	Torsion Bars															
	External Fire Extinguisher Handles	Safety Wire-Lead Seals		X													
	Loader and TC Hatches	Hatches				X											
	Travel Lock	Hold-Open Locking Handles															
Loader's Station	Turret Lock	Travel Lock															
Gunner's Station	Turret Lock	Turret Lock															
	Manual Controls	Elevation Handle															
Driver's Station	Driver's Hatch	Traversing Handle															
	Driver's Seat	Driver's Hatch	X														
	Driver's Seat	Driver's Seat	X														
	Driver's Escape Hatch	Backrest	X														
	Driver's Escape Hatch	Dump Lever	X														
	Driver's Escape Hatch	Escape Hatch				X											
Fire Extinguisher System	Plunger Bolts	Plunger Bolts															
	Manual Control Lever	Manual Control Lever															
	Handle Seal	Handle Seal		X													
	Three Cylinders	Three Cylinders		X													
Hydraulic Brake System	Lead Seal	Lead Seal		X													
	Shrunk Tubing	Shrunk Tubing		X													
	Shifting Lever	Shifting Lever															
	Pressure Gage	Pressure Gage															
Indicator Lamps	Brake Pedal	Brake Pedal															
	Master Cylinder	Master Cylinder															
	MASTER BATTERY	MASTER BATTERY															
	POWER PLANT WARNING	POWER PLANT WARNING															

CHECK

Location	System	Equipment	Adjustment	Clean/Clear	Damage	In Place	Leaks	Level	Missing Parts	Operation	Position	Pressure	Secure	Status	
Hull	Air Cleaner Housings and Doors	Door			X	X									
		Door Fasteners			X	X									
		Housing			X	X									
		Door Hinges			X										
		Drain Plug					X								
		Inspection Plugs					X								
		Top Deck Grille Doors					X		X						
		Engine and Transmission Oil Level		Engine Oil (Stopped)					X						
		Engine and Transmission Oil Coolers		Transmission Oil (Stopped)					X						
		Engine and Transmission Oil Coolers		Engine Oil (Idling)					X						
	Air Cleaner Blower Motors	Air Cleaner Blower Motors	Transmission Oil (Idling)						X						
			Screens												
			Coolers				X								
			Intake Hose				X								
			Outlet Hose					X							
			Intake Hose Elbow					X							
			Outlet Hose Elbow					X							
			Intake Hose Clamps					X							
			Outlet Hose Clamps												
			Air Cleaner Blower Motors									X			
Restriction Indicators	Restriction Indicators	Air Cleaner Blower Motors													
		Restriction Indicators				X									
		Pipe Plug Window				X									

TANK COMMANDER MASTER CHECK-OFF LIST  
 DURING OPERATIONS PMCS  
 (TM page 2-101)

Location	System	Equipment	CHECK														
			Adjustment	Clean/Clear	Damage	In Place	Leaks	Operation	Position	Pressure	Secure	Status					
Driver's Station	Idle Speed/Accelerator Control	Engine Speed at Idle													X		
		Accelerator Control							X							X	
		Engine Speed After Acceleration														X	
		Power Plant Warning Light														X	
	Gages	Battery - Generator	Battery - Generator													X	
			Engine Oil Pressure														X
		Transmission Oil Pressure	Engine Oil Pressure														X
			Transmission Oil Pressure														X
			Transmission Oil Temperature														X
			Transmission Oil Temperature														X
Controls	Steering Control	Steering Control													X		
		Shifting Control														X	
	Brake Pedal	Shifting Control														X	
		Brake Pedal														X	
	Ammunition Stowage Racks/Ammunition Ready Racks	Stowage Rack Tubes and Retainers			X												
		Ready Rack Locks			X	X										X	
Commander's Station	Seat	Cushioning Pads			X												
		Seat				X											
	Intercom/Radio	Intercom/Radio				X											
		Azimuth Lock															
	Cupola Azimuth and Elevation Controls	Azimuth Interlock															
		Manual Traversing Handle															
Turret Power Controls	Manual Elevating Handle																
	Palm Switch																
	Control Handles																
TC's Periscope	TC's Periscope	Control Handles															
		Outside Window		X													

TANK COMMANDER MASTER CHECK-OFF LIST  
 AFTER OPERATIONS PMCS  
 (TM page 2-110)

CHECK

Location	System	Equipment	Chunking/ Separation	Damage	Heat	In Place	Leaks	Missing Parts	Sealed	Secure	Wear	
Exterior/ Track	Rear Grille Doors	Rear Grille Doors		X		X		X		X		
	Final Drive	Final Drive/Sprocket Bottom					X				X	
		Mounting Studs				X						
	Sprockets	Final Drive Hubs		X							X	
		Sprockets		X								
	Roadwheels and Hubs	Roadwheels					X					X
		Mounting Holes				X						
		Hubs					X					
	Roadwheel Arms	Inside Wheel Rims										
		Roadwheel Arms		X			X					
	Shock Absorbers	Shock Absorbers		X				X	X		X	
		Track Support		X			X					
	Rollers and Hubs	Track Support Rollers				X						
		Support Roller Hubs					X				X	
	Track End Connectors and Wedges	End Connectors		X			X				X	
		Bolts					X				X	
	Track Center Guides	Wedges					X			X	X	
		Track Center Guides					X				X	
	Track Pads	Track Pads		X			X				X	X
		Link Assembly			X		X					
Track Adjusting Links	Cotter Pin					X						
	Pins					X						
Track Shoes	Shoes		X								X	
	Compensating Idler											
Wheels and Hubs	Inside Wheel Rims						X					
	Hub				X							

CHECK


Location	System	Equipment	Adjustment	Clean/Clear	Damage	In Place	Leaks	Operation	Position	Pressure	Secure	Status	
Gunner's Station	Seat	Seat	X			X		X					
	Fire Control Quadrant/Light Source Control	Scale		X									
		Index		X					X				
		Level Vial Cover				X			X				
		Level Vial							X				
	Azimuth Indicator	Light Source Control				X			X				
		Glass Cover				X			X				
		Rheostat							X				
		Hydraulic Fluid						X					
		Turret Power Controls/Hydraulic Power							X		X		
	Gunner's Sights	Control Handles							X				
		Periscope Window			X								
		Telescope Lens			X								



**GUNNER**

**PROCEDURE GUIDES**

**M60A3 TANK**



**July 1982**

**PREPARED BY THE U.S. ARMY RESEARCH INSTITUTE  
FOR THE  
BEHAVIORAL AND SOCIAL SCIENCES**

## GENERAL INFORMATION

This booklet contains M60A3 gunner procedures guides. Each guide is for a single pre-operation, post-operation, or during operation activity. Each guide is matched to TM 9-2350-253-10 (Operator's Manual for Tank, Combat, Full-Tracked: 105-MM Gun, M60A3).


## PURPOSE OF PROCEDURE GUIDES

The guides in this booklet will not take the place of the M60A3 Operator's Manual or M60A3 training materials. The guides will aid you in remembering long or difficult sets of procedures. In short, the guides will help to "jog your memory."

## USE OF THIS BOOKLET

The Table of Contents (on the next page) lists the procedure guides in this booklet. Each guide gives you a step-by-step outline for completing an activity. The following instructions will help you to better use each guide.

1. Some steps within a procedure are followed by a page number. On that page you will find a detailed breakdown of the step,
2. Some of the procedure guides include a question(s). Each question is stated inside a diamond shape. Your "yes" or "no" to the question will show you which path to follow.
3. Some paths lead to an instruction to go to a particular step number within a procedure. The step number is given within a circle.
4. Some steps within a procedure guide are followed by a box. In the box you will find more information on the step or a caution/warning.
5. Certain steps within a procedure guide require that a knob or switch be turned to a certain position. In some cases, that position might be written like the symbol to the left. The symbol means that a light should also come on.
6. At the beginning of each procedure, the TM page number reference for the procedure is given under the task name. These references will help you if you need more information to complete the task.
7. Two procedures are listed for boresighting with a boresighting device (taken from TRADOC Training Text 17-12-1) and without such a device (procedure in the Operator's Manual). Note that if a boresighting device is used, the zeroing procedure is not performed.




## TABLE OF CONTENTS


	<u>Page</u>
<u>GUNNER'S OPTICS</u>	
OPERATING TANK THERMAL SIGHT (TTS) . . . . .	1
OPERATING TELESCOPE M105D . . . . .	6
<u>COMPUTER SYSTEM</u>	
COMPUTER SELF-TEST . . . . .	9
OPERATIONAL RESPONSE TEST: . . . . .	14
RATE TACHOMETER AND LEAD CIRCUITRY . . . . .	14
WIND SENSOR TEST . . . . .	21
<u>MAIN GUN</u>	
BORESIGHTING WITH MUZZLE BORESIGHT DEVICE . . . . .	24
BORESIGHTING WITHOUT MUZZLE BORESIGHT DEVICE . . . . .	32
ZEROING 105-MM GUN . . . . .	43
<u>COAXIAL MACHINE GUN</u>	
TESTING 7.62-MM MACHINE GUN FIRING CIRCUIT . . . . .	53
BORESIGHTING 7.62-MM MACHINE GUN . . . . .	55
ZEROING 7.62-MM MACHINE GUN . . . . .	57
<u>PREPARING TO FIRE</u>	
PREPARING TO FIRE PROCEDURE . . . . .	59
<u>PREVENTATIVE MAINTENANCE CHECKS AND SERVICES (PMCS)</u>	
BEFORE OPERATIONS PMCS . . . . .	64
DURING OPERATIONS PMCS . . . . .	65
<u>PICTURES</u>	
GUNNER'S CONTROL UNIT . . . . .	67
GUNNER'S SWITCH BOX/STABILIZATION CONTROL SELECTOR . . . . .	68
AMMUNITION SELECT UNIT . . . . .	69


OPERATING TANK THERMAL SIGHT (TTS)  
(TM PAGE 2-236)


THE INFRARED OPTICS OF THE GUNNER'S PERISCOPE CONTAIN ANTIREFLECTIVE COATING WHICH IS SLIGHTLY RADIOACTIVE. DO NOT SWALLOW OR INHALE.

1. PMCS . . . . . Assure complete (crew)

2. MASTER BATTERY . . . . .  (driver)

3. MODE on LRF . . . . .  (TC)

4. POWER on gunner's control unit . . . . . 

5. MODE on TTS . . . . . 

To prevent accidental firing of LRF

Lift cover switch

ALWAYS LEAVE 4CB1 (CIRCUIT BREAKER) ON TTS POWER CONVERTER SET TO ON.

GO TO 6

6. COOL indicator . . . . . Will light until thermal detector has cooled (< 15 mins)

THERMAL CHANNEL DISPLAY MAY BE USED BEFORE BITE DISPLAY COOL LAMP GOES OUT, BUT SYSTEM OPERATES BEST AFTER COMPLETE COOLDOWN.

Press pushbutton to open/release to lock

Pull down lever to adjust/release to lock

7. Ballistic shield . . . . . Open  
cover

8. Daylight channel . . . . . Adjust  
headrest

9. Unity power window . . . . . Assure view is sharp  
and clear

10. RTCL control . . . . . Adjust until unity power  
reticle is visible

11. Daylight channel . . . . . Obtain image  
eyepiece


12. Diopter ring . . . . . Rotate to sharpen image


13. RTCL control . . . . . Adjust until daylight  
channel reticle is visible

GO TO 14


Push up to selected band color

Lever must point forward to prevent parallax

- 14. Filter selector lever . . . . . Select desired filter color
- 15. Filter selector lever . . . . . Lock in place
- 16. COOL indicator . . . . . Assure off
- 17. MODE on TTS . . . . . ON
- 18. BITE test switch . . . . .  LAMP TEST
- 19. BITE lamps . . . . . All should light
- 20. BITE test switch . . . . . SYS TEST
- 21. BITE lamps . . . . . None should light



23. ARE ANY LAMPS ON? . . . . . NO → 23a. Organizational . . . . . Notify maintenance



YES →

24. THERMAL CHANNEL . . . . . NAR  
FIELD OF VIEW

25. GUNNER/CMDR . . . . . GUNNER (TC)

26. TTS eyepiece . . . . . Select target

27. BRIGHT/CONTRAST . . . . . Adjust for normal viewing  
controls

28. THERMAL CHANNEL . . . . . Adjust until view is sharp  
RANGE FOCUS and clear

29. POLARITY switch . . . . . Move up or down for  
clearest view


30. WHT/BLK HOT . . . . . Should alternate when  
indicators POLARITY switch is moved

31. RTCL control . . . . . Adjust brightness of NAR  
FOV reticle, if necessary



Position depends on scene, temperature, and weather

- 32. THERMAL CHANNEL . . . . . WIDE  
FIELD OF VIEW
- 33. BRIGHT/CONTRAST . . . . . Readjust if necessary  
controls
- 34. WFOV indicator . . . . . Assure on
- 35. RTCL control . . . . . Adjust brightness of WIDE  
FOV reticle, if necessary
- 36. Commander's dis- . . . . . Should have same image (TC)  
play eyepiece as gunner's display
- 37. GUNNER/CMDR . . . . . CMDR (TC)
- 38. BRIGHT . . . . . Should control brightness (TC)
- 39. CONTRAST . . . . . Should control contrast (TC)
- 40. POLARITY . . . . . Should interchange light (TC)  
and dark portions of image
- 41. GUNNER/CMDR . . . . . GUNNER (TC)
- 42. MODE on TTS . . . . . STBY







OPERATING TELESCOPE M105D  
(TM PAGE 2-225)

Loosen retaining knob to adjust/tighten to secure in place


1. Telescope/headrest . . . . . Adjust
2. Eyepiece . . . . . Sight target
3. Diopter ring . . . . . Rotate until view becomes sharp and clear
4.
  - 4a. M50 instrument . . . . . Disconnect from light housing
  - 4b. M50 instrument . . . . . Connect to top of light housing
  - 4c. M50 instrument . . . . . Adjust reticle light rheostat








(driver)

- 5. MASTER BATTERY . . . . .
- 6. Lamp housing on . . . . . Disconnect from storage  
light source control slots
- 7. Lamp housing . . . . . Connect to top of  
telescope
- 8. Light source control . . . . . Adjust reticle  
rheostat brightness





COMPUTER SELF-TEST  
(TM PAGE 2-254)

THE 105-MM GUN MAY MOVE WHEN ELEV/TRAY POWER SWITCH IS ON AND LAMP/NORMAL/SYSTEM SWITCH IS SET IN OR OUT OF SYSTEM OIL LAMP.




DO NOT PERFORM LRF SYSTEM SELF-TESTS WHILE PERFORMING COMPUTER SELF-TEST.

- 1. MODE on LRF . . . . .  
          —TEST— (TC)
- 2. MASTER BATTERY . . . . .  
          —ON— (driver)
- 3. POWER on gunner's . . . . .  
   control unit . . . . .  
          —ON—
- 4. LIGHTS . . . . . Vary brightness
- 5. LIGHTS . . . . . Adjust to normal brightness


Panel lights should vary smoothly from dim to bright

GO TO  
6

Indicators should vary smoothly in brightness


- 6. DIM/BRIGHT controls . . . . . Vary brightness  
on ammo select units
- 7. HEAT ammo switch . . . . . Assure in M456 position
- 8. LAMP/NORMAL/SYSTEM . . . . .  All should illuminate
- 9. SELF TEST and . . . . . All should illuminate  
SENSOR FAIL indicators
- 10. MANUAL/RANGEFINDER . . . . . MANUAL
- 11. LAMP/NORMAL/SYSTEM . . . . .  Should illuminate
- 12. OK indicator . . . . . Should illuminate
- 13. STATIONARY or MOVING . . . . . Assure that one or the other  
indicators on ammo select units indicator is illuminated
- 14. MOVING/STATIONARY . . . . .  switch on either unit


GO TO 15




GO TO 22

WIND SENSOR MUST BE INSTALLED AND OPERABLE FOR A COMPLETE TEST, THE WIND SENSOR FAIL INDICATOR WILL LIGHT IF MANUAL WIND IS SELECTED OR IF WIND SENSOR IS NOT INSTALLED AND PROPERLY CONNECTED.

- 22. Ammo select unit . . . . . Select ammo type
- 23. LAMP/NORMAL/SYSTEM . . . . . 
- 24. OK indicator . . . . . Should illuminate
- 25. RANGE (METERS) . . . . . Should indicate 1850 ± 15
- 26. RETURN . . . . . Should indicate 2





B-15 





OPERATIONAL RESPONSE TEST:  
(TM PAGE 2-258)

RATE TACHOMETER AND LEAD CIRCUITRY

- 1. MODE on LRF . . . . .  TEST (TC)
- 2. MASTER BATTERY . . . . .  ON (driver)
- 3. POWER on gunner's control unit . . . . .  ON
- 4. MANUAL/RANGEFINDER . . . . . MANUAL
- 5. RANGE METERS X100 . . . . . 20
- 6. CROSSWIND AUTO/MANUAL . . . . . MANUAL
- 7. CROSSWIND MPH . . . . . 0 MPH
- 8. MOVING/STATIONARY  STATIONARY
- 9. HEAT switch . . . . . Depress

Heat switch should become brighter than other three

GO TO 10

10. Obstructions . . . . . Clear from tank and surrounding area

MAKE SURE CREW IS IN SAFE POSITION BEFORE OPERATING GUN ELEVATING AND TURRET TRAVERSING CONTROLS.

11. Gun tube . . . . . Release from travel lock

12. Travel lock . . . . . Stow

13. Turret . . . . . Unlock

14. Engine . . . . . Start (driver)

Set speed at 800-900 rpm


MAKE SURE MANUAL TRAVERSING HANDLE LOCKING LEVER IS IN DETENT POSITION.



15. ELEV/TRAV POWER . . . . .

16. Turret hydraulic power pack motor . . . . . Should run until accumulator pressure gage reads 1175-1275 psi


GO TO 17




- 18. RTCL control . . . . . Adjust until reticle is visible
- 19. Turret . . . . . Hold steady
- 20. Palm switch . . . . . Depress/hold
- 21. Thumb switch . . . . . Momentarily depress
- 22. Reticle . . . . . Should not move
- 23. Gunner's palm switch . . . . . Release/depress
- 24. Turret . . . . . Slew turret to the right at medium speed
- 25. Thumb switch . . . . . Momentarily depress
- 26. Reticle . . . . . Should jump to the left

GO TO 27

- 27. Palm switch . . . . . Release
- 28. Reticle . . . . . Should jump to the right
- 29. Palm switch . . . . . Depress/hold
- 30. Turret . . . . . Slew turret to the left at medium speed
- 31. Thumb switch . . . . . Momentarily depress
- 32. Reticle . . . . . Should jump to the right
- 33. Palm switch . . . . . Release
- 34. Reticle . . . . . Should jump to the left
- 35. . . . . 35a. TC's control . . . . . Use to control deflection/elevation handle







WHEN STABILIZATION SYSTEM IF FIRST ENGAGED, TURRET OR GUN MOVEMENT MAY OCCUR. DURING STABILIZED OPERATIONS, MOVEMENT OF THE GUNNER'S CONTROL HANDLES WILL CAUSE TURRET AND GUN MOVEMENT EVEN THOUGH THE PALM SWITCHES ARE NOT DEPRESSED.

- 38. STAB ELECTRONICS . . . . . (TC)
- 39. POWER PACK BLOWER . . . . . (TC)

GO TO 40



41. Gunner . . . . . Announces: STAB




42. STAB . . . . . Should be on indicators at TC and loader's stations

DO NOT OPERATE STABILIZATION SYSTEM UNLESS POWER PACK BLOWER MOTOR COMES ON,


A DRIFT RATE OF 2 MILS/MIN IS ACCEPTABLE AFTER ADJUSTING BOTH TRAV BALANCE AND ELEV BALANCE KNOBS.

44. TRAV BALANCE knob . . . . . Rotate clockwise until drift occurs/note position




- 45. TRAV BALANCE . . . . . Rotate counterclockwise  
knob until drift occurs/  
note position
- 46. TRAV BALANCE . . . . . Set halfway between  
knob first and second position
- 47. ELEV BALANCE . . . . . Rotate clockwise until  
knob drift occurs/note  
position
- 48. ELEV BALANCE . . . . . Rotate counterclockwise  
knob until drift occurs/  
note position
- 49. ELEV BALANCE . . . . . Set halfway between  
knob first and second position

B-23



- 50. POWER on stabiliza- . . . . . OFF  
tion control  
selector



OPERATIONAL RESPONSE TEST:  
(TM PAGE 2-276)


WIND SENSOR TEST

- 1. MODE on LRF . . . . . ~~TEST~~ (TC)
- 2. MASTER BATTERY . . . . . ~~ON~~ (driver)
- 3. POWER on gunner's control unit . . . . . ~~ON~~
- 4. ELEV/TRAV POWER . . . . . ~~ON~~
- 5. MOVING/STATIONARY . . . . . ~~STATIONARY~~
- 6. Ammo select unit . . . . . ~~HBP/WP~~
- 7. MANUAL/RANGEFINDER . . . . . MANUAL
- 8. RANGE METERS X100 . . . . . 30
- 9. CROSSWIND AUTO/MANUAL . . . . . MANUAL

GO TO  
10




- 10. CROSSWIND MPH . . . . . 0 MPH
- 11. Tank . . . . . Position in left-to-right crosswind
- 12. Gunner's control . . . . . Lay vertical bar of 8 X daylight reticle on distant target
- 13. CROSSWIND MPH . . . . . 5 MPH from the left
- 14. Reticle . . . . . Should move to the right
- 15. CROSSWIND MPH . . . . . 0 MPH
- 16. Reticle . . . . . Should return to aiming point
- 17. CROSSWIND AUTO/ . . . . . AUTO  
MANUAL
- 18. Reticle . . . . . Should move to the right
- 19. CROSSWIND AUTO/ . . . . . MANUAL  
MANUAL
- 20. Reticle . . . . . Should return to aiming point



MAKE SURE SURROUNDING AREA IS CLEAR FOR 360° OF TURRET TRAVERSE

- 21. Turret . . . . . Traverse 180°
- 22. Gunner's control . . . . . Lay vertical bar of handles 8X daylight reticle on distant target
- 23. CROSSWIND MPH . . . . . 5 MPH from the right
- 24. Reticle . . . . . Should move to the left
- 25. CROSSWIND MPH . . . . . 0 MPH
- 26. Reticle . . . . . Should return to aiming point
- 27. CROSSWIND AUTO/ MANUAL . . . . . AUTO
- 28. Reticle . . . . . Should move to the left
- 29. CROSSWIND AUTO/ MANUAL . . . . . AUTO
- 30. Reticle . . . . . Should return to aiming point

B-26



BORESIGHTING WITH MUZZLE BORESIGHT DEVICE

(TT 17-12-1)


Prepare




- 1. ELEV/TRAV POWER . . . . .
- 2. Tank position . . . . . Level
- 3. All weapons . . . . . Clear
- 4. Main gun breech . . . . . Open
- 5. Engine . . . . . Assure off
- 6. Target . . . . . 1200 meters
- 7. Ballistic drive . . . . . Down/locked  
coupling lever

Lever must point forward, away from gunner


Locked into position



- 8. Filter select lever . . . . .
- 9. POWER on gunner's . . . . . control unit
- 10. Laser rangefinder . . . . . Self-test (TC)



11. Computer . . . . . Self-test (page 9)



13. MODE on LRF . . . . . ~~ON~~

14. Gunner's control handles . . . Lay reticle on target

15. Thumb switches . . . . . Depress


16. RANGE (METERS) . . . . . Should display known range (TC)

17. GO light . . . . . Should be illuminated (TC)

18. MODE . . . . . ~~TEST~~

19. NORMAL/BORESIGHT . . . . . BORESIGHT

20. Azimuth/elevation zero knobs . Assure on 0



- 21. CROSSWIND AUTO/MANUAL . . . . . MANUAL
- 22. CROSSWIND knob . . . . . Assure on 0
- 23. Boresight device . . . . . Insert

Assure plunger is at 12 o'clock position


Adjust Daylight Channel of TTS

- 24. Gunner's control handles . . . . . Lay reticle aiming dot on target aiming point
- 25. Boresight eyepiece . . . . . Sight target (TC)
- 26. Gunner's control handles . . . . . Traverse and elevate as directed by TC to lay boresight dot on target aiming point
- 27. Boresight knobs . . . . . Adjust so that reticle aiming dot is again on target aiming point
- 28. Gunner's control handles . . . . . Traverse and elevate off the target/re-lay reticle on target aiming point


Last movement of gun must be up

Assure knobs are seated after adjusting

Finish with upward movement




- 30. Boresight scales . . . . . Set on 4 and 4
- 31. Boresight device . . . . . Remove/rotate 180°/reinstall
- 32. Gunner's control handles . . . . . Traverse and elevate off the target/re-lay reticle on target aiming point



- 33. Boresight eyepiece . . . . . Sight target (TC)
- 34. Gunner's control handles . . . . . Traverse and elevate as directed by TC to lay boresight dot on target aiming point
- 35. Boresight knobs . . . . . Adjust so that reticle aiming dot is again on target aiming point
- 36. Gunner . . . . . Announce boresight knob readings

Last movement of gun must be up

GO TO 38



38.

IS ELEVATION READING > 1 MIL FROM 4 OR DEFLECTION READING > .5 MIL FROM 4?

YES

FIRST TIME THROUGH DAYLIGHT CHANNEL ADJUSTMENT?

YES

GO TO 24

NO

38a. Boresight device . . . . . Turn in to maintenance

38b. Another device . . . . . Install

GO TO 24

B-31

- 39. Boresight knobs . . . . . Rotate halfway back to 4
- 40. Manual controls . . . . . Re-lay reticule aiming dot on target aiming point
- 41. Boresight scales . . . . . Set on 4 and 4
- 42. Boresight device . . . . . Remove

Assure aiming dot does not move

GO TO 43

Adjust the M105D Telescope


- 43. M105D Telescope . . . . . Prepare for operation (Page 6)
- 44. Reticle selector . . . . . Move to full-left or full-right position
- 45. Boresight knobs . . . . . Adjust boresight cross on target aiming point
- 46. Boresight scales . . . . . Set on 3 and 3

Adjust the Laser Rangefinder (LRF)


- 47. BATL RNG . . . . . Press
- 48. Gunner's sight . . . . . Assure on target aiming point
- 49. 6X/12X switch . . . . . 12X
- 50. LRF boresight knobs . . . . . Adjust reticle on target aiming point
- 51. Boresight scales . . . . . Set on 4 and 4

Apply Computer Correction Factors

- 52. COMMON ZERO . . . . . 0/0 (azimuth/elevation)







- 61. GUNNER/CDR . . . . . GUNNER (TC)
- 62. COOL indicator . . . . . Assure off
- 63. MODE . . . . . ON
- 64. THERMAL CHANNEL . . . . . NAR  
FIELD OF VIEW
- 65. THERMAL CHANNEL . . . . . Adjust for sharpest view  
RANGE FOCUS
- 66. BRIGHT/CONTRAST controls . . . . . Adjust for normal scene
- 67. POLARITY switch . . . . . Set for best image
- 68. RTCL control . . . . . Adjust until reticle is  
just visible
- 69. Thermal channel eyepiece . . . . . Sight target
- 70. THERMAL CHANNEL . . . . . Lay reticle aiming dot on  
BORESIGHT EL/AZ target aiming point
- 71. Boresight scales . . . . . Set on 4 and 4
- 72. Zeroing procedure . . . . . Do not perform

Assure aiming dot  
does not move



BORESIGHTING WITHOUT MUZZLE BORESIGHT DEVICE

(TM PAGE 2-345)

Preliminary Procedure

1. Tank . . . . . Level ground
2. Cross-threads . . . . . Place on muzzle end of  
gun tube
3. Target . . . . . 1200 meters
4. Breechblock crank stop . . . . . Assure rearward

Threads should be  
directly over  
witness marks


BREECHBLOCK OPERATING HANDLE IS UNDER SPRING  
TENSION UNTIL BREECHBLOCK IS FULLY OPENED  
AND LOCKED BY EXTRACTORS.

5. Breechblock operating . . . . . Pull rearward/down  
handle

Depress plunger

FAILURE TO RETURN OPERATING HANDLE TO  
LATCHED POSITION MAY CAUSE INJURY TO  
PERSONNEL OR DAMAGE TO CLOSING  
MECHANISM WHEN BREECHBLOCK IS CLOSED.

6. Operating handle . . . . . Return to latched position



Trip extractors using empty case or wooden block

Close

7. Breech . . . . .

KEEP HANDS CLEAR OF BREECH.

Depress and move plunger to the right

Release

8. Firing pin spring . . . . .

Turn counter-clockwise until lug aligns with grooves

Remove

9. Spring retainer . . . . .

Pry out with screwdriver blade

Remove

10. Firing pin/retractor . . . . .  
guide/retractor

ON (driver)

11. MASTER BATTERY . . . . .

ON


12. POWER on gunner's control unit

IF THERE IS APPARENT RETICLE MOTION DURING BORESIGHTING, INCREASE ENGINE RPM OR TURN ENGINE OFF.

GO TO 13

13. LRF self-test . . . . . Perform (TC)

14. Computer self-test . . . . . Perform (page 9)

15. MODE on LRF . . . . . 

16. NORMAL/BORESIGHT . . . . . BORESIGHT

17. Right section of ML7A1 binocular . . . . . Place over firing pin hole

Lay gun from left to right and low to high without overtravel

18. Manual traversing and elevating controls . . . . . Lay axis of gun on target aiming point

19. TTS . . . . . Prepare for operation (page 6)

GO TO 30



20.  YES

NO

Manual Range Procedure

21. MANUAL/RANGEFINDER . . . . . MANUAL

GO TO 22






- 22. MODE on LRF . . . . .
  - 23. RANGE (METERS) . . . . . Should display 0000
  - 24. RANGE METERS X100 . . . . . Dial to target distance
  - 25. RETICLE BRIGHTNESS . . . . . Adjust until reticle is just visible
  - 26. 6X/12X . . . . . 12X
  - 27. DEFLECTION and ELEVATION . . . . . Lay reticle on target aiming point
  - 28. Slip scales . . . . . Set on 4 and 4
  - 29. Reticle/crossthreads . . . . . Assure on target aiming point
- M105D Telescope Boresight Procedure
- 30. M105D Telescope . . . . . Prepare for operation (page 6)
  - 31. Eyepiece . . . . . Sight

Lay reticle from low to high and left to right without overtravel

TELESCOPE MUST BE BORESIGHTED AT 1200 METERS ONLY.





- 32. Reticle selector . . . . . Choose appropriate reticle
- 33. Locking levers . . . . . Unlock telescope boresight knobs
- 34. Boresight knobs . . . . . Lay boresight cross on target aiming point
- 35. Slip scales . . . . . Set on 3 and 3
- 36. Locking levers . . . . . Lock telescope boresight knobs
- 37. Boresight cross/ crossthreads . . . . . Assure on target aiming point



38. B-39

Laser Rangefinder (LRF) Procedure

DO NOT VIEW LASER BEAM THROUGH  
DEVICE NOT FILTERED FOR LASER  
LIGHT. FIRE LASER IN AUTHORIZED  
LASING AREA ONLY.

- 39. Laser filter . . . . . Install on receiver-transmitter eyepiece
- 40. RETICLE BRIGHTNESS . . . . . Adjust until reticle is just visible
- 41. MANUAL/RANGEFINDER . . . . . RANGEFINDER
- 42. MODE . . . . . 
- 43. BATL RNG . . . . . 

DO NOT LEAN OR PUSH AGAINST RECEIVER-TRANSMITTER WHEN VIEWING THROUGH EYEPIECE OR LASING.


B-40

- 44. 6X/12X . . . . . 12X
- 45. LRF eyepiece . . . . . Sight target
- 46. DEFLECTION and ELEVATION . . . . . Lay reticle on target aiming point
- 47. Slip scales . . . . . Set on 4 and 4


Lay reticle from left to right and from low to high without overtravel

GO TO  
48





141



TTS Procedure

- 55. MODE . . . . . STBY
- 56. GUNNER/CMDR . . . . . GUNNER
- 57. Ballistic shield cover . . . . . Open

Press push-button actuator and push handle forward

POWER GOES TO TTS RETICLE LAMPS WHEN POWER ON GUNNER'S CONTROL UNIT IS SET TO ON.


GO TO 58

- 58. RTCL control . . . . . Adjust until reticle is just visible
- 59. Eyepiece . . . . . Sight target
- 60. Diopter ring . . . . . Adjust for best reticle focus

Lay reticle from low to high and from left to right without overtravel

61. DAY CHANNEL BORESIGHT . . . . . Lay reticle on target aiming point

62. Slip scales . . . . . Set on EL4 and AZ4





NO

63a. Manual controls . . . . . Relay gun

63b. DAY CHANNEL BORESIGHT . . . . . Readjust reticle EL/AZ knobs


63c. Slip scales . . . . . Set on EL4 and AZ4

63d. Reticle/crossthreads . . . . . Assure on target aiming point



- 64. COOL indicator . . . . . Assure out
- 65. THERMAL CHANNEL FIELD OF VIEW . . . . . NAR
- 66. THERMAL CHANNEL RANGE FOCUS. . . . . Adjust for sharpest view
- 67. BRIGHT/CONTRAST . . . . . Adjust for normal scene
- 68. POLARITY . . . . . Set for best image
- 69. RETICLE . . . . . Adjust until reticle is just visible
- 70. Eyepiece . . . . . Sight target
- 71. THERMAL CHANNEL BORESIGHT EL/AZ knobs . . . . . Lay reticle on target aiming point
- 72. Slip scales . . . . . Set on EL4 and AZ4
- 73. ARE CROSSTHREADS AND RETICLE ON AIMING POINT ?
  - 73a. Manual controls. . . . . Relay gun
  - 73b. THERMAL CHANNEL BORESIGHT EL/AZ knobs . . . . . Readjust reticle
  - 73c. Slip scales . . . . . Set on EL4 and AZ4
  - 73d. Reticle/crossthreads . . . . . Assure on target aiming point

B-44




Should be flush  
with inner surface  
of firing pin well

Depress plunger  
and rotate clock-  
wise to lock position

74. Retractor guide/firing . . . . . Install  
pin retractor

75. Firing pin spring retainer . . . . . Install

76. Zeroing procedure . . . . . Perform (page 43)



ZEROING 105-MM GUN

(TM PAGE 2-373)

DO NOT DISTURB KNOB ADJUSTMENT OF  
TTS 8X DAYLIGHT CHANNEL, TTS THERMAL  
CHANNEL, OR LASER R-T UNIT, EXCEPT  
DURING BORESIGHTING.

1. 105-mm gun . . . . . Bor. ight (page 32)

2. MASTER BATTERY . . . . .  (driver)

3. Target . . . . . Right angle/1200 meters

4. REMAINING TUBE LIFE . . . . . Rotate to computed value

5. AIR TEMP/ALTITUDE . . . . . Rotate to estimated values


6. APDS AMMO knob . . . . . Set on type of ammo to  
be used

7. HEAT AMMO knob . . . . . Assure in M456 position


8. Engine . . . . . Start/maintain speed  
at 800-900 rpm (driver)

GO TO  
9

Use TM 9-1000-202-14



9. POWER on gunner's control unit . . . . .



10. ELEV/TRAV POWER . . . . .

STBY

11. MODE on TTS . . . . .


GUNNER

12. GUNNER/CMDR . . . . .

13. RTCL control . . . . .  
Adjust until daylight channel reticle is just visible

14. BRIGHT/DIM . . . . .  
Adjust for adequate brightness in both channels

15. LIGHTS . . . . .  
Adjust brightness of panel lights




16. MOVING/STATIONARY . . . . .

17. AZ/EL COMMON ZERO . . . . .  
Rotate from 3 to 0 without overtravel


18. AZ/EL ZEROING . . . . .  
Only for types rounds being zeroed, rotate from 3 to 0 without overtravel

19. NORMAL/BORESIGHT . . . . .  
NORMAL



Operating Procedure

DO NOT LEAN OR PUSH AGAINST RECEIVER-TRANSMITTER WHEN VIEWING THROUGH EYEPIECE OR LASING.





Press/release

25. RESET . . . . .

26. Laser safety filters . . . . . Attach to eyepieces of TTS/  
M105D telescope/LRF

AUTO

27. MODE on LRF . . . . .


DO NOT VIEW LASER BEAM THROUGH  
ANY UNFILTERED DEVICE, FIRE LASER  
IN AUTHORIZED LASING AREA ONLY.

Press/release

28. RANGE . . . . .

29. GO light . . . . . Assure on

GO TO 21



NO

YES

GO TO 31



- 31. MODE on LRF . . . . .
- 32. Laser filters . . . . .

Remove from TTS, telescope, and LRF/replace in holders

IF ELECTRICAL POWER IS INTERRUPTED DURING REST OF PROCEDURE, REPEAT STEPS 20-32.

- 33. Ammo select switch . . . . .

Select appropriate ammunition

Make sure all rounds are from same lot

- 34. 105-mm gun . . . . .

Load (loader)

Lay reticle from left to right and from low to high without overtravel

- 35. Turret manual elevation and traversing handles . . . . .

Lay daylight reticle on target aiming point

WAS LASER RANGING USED ?

NO

GO TO 37

YES

IS R-T RETICLE ON TARGET ?

NO

GO TO 35

YES

GO TO 37

37. BLOWER . . . . . ON (TC)



38. MAIN GUN . . . . .

IF RETICLE MOVES MORE THAN 0.1 MIL  
IN TWO SECONDS DUE TO WIND GUSTS,  
DELAY FIRING UNTIL WIND IS STEADY.

Re-lay after  
each shot

39. Trigger on manual . . . . . Fire three-round shot  
elevating handle . . . . . group

40. Rounds . . . . . Must be within 0.5 mil  
from one another

41. BLOWER . . . . . OFF (TC)


42. ELEV/TRAV POWER . . . . . OFF

43. Hydraulic pressure . . . . . Open for 10 seconds/close  
selector valve

44. Manual elevation . . . . . Recharge  
accumulator

45. CROSSWIND AUTO/MANUAL . . . . . MANUAL

46. CROSSWIND MPH . . . . . 0 mph



- 47. Manual elevating . . . . . Re-lay daylight reticle on and traversing handles target aiming point

WHEN ZEROING FSDS AMMO, USE THE 1200 METER AIMING DOT OF THE TELESCOPE APDS-T RETICLE.

- 48. Telescope elevation and . . . . . Unlock deflection locks
- 49. Reticle selector lever . . . . . Choose appropriate telescope reticle
- 50. Telescope eyepiece . . . . . Sight target

Lay from left to right and low to high without overtravel

- 51. Elevation and deflection . . . . . Lay telescope reticle on boresight knobs target aiming point


- 52. Elevation and deflection . . . . . Relock locks


- 53. Boresight scales . . . . . Do not slip

Lay from left to right and low to high without overtravel

- 54. AZ/EL ZEROING CONTROLS . . . . . Lay daylight reticle on center of shot group

GO TO 55






66. ELEVATION and DEFLECTION . . . Lay known target range boresight knobs


67. Elevation and deflection . . . Relock locking levers

68. Telescope boresight . . . . . Record for each type of ammunition scale readings

69. Scales . . . . . Do not slip



70. 70a. Remaining ammo types . . . . . Select one



71. Telescope elevation . . . . . Unlock and deflection locking levers

72. Boresight knobs . . . . . Rotate to 5, then to 3




73. Elevation and deflection . . . . . Relock locking levers

74. Scales . . . . . Do not slip




TESTING 7.62-MM MACHINE GUN FIRING CIRCUIT


(TM PAGE 3-119)

- 1. Machine gun . . . . . Clear (loader)
- 2. MASTER BATTERY . . . . .  (driver)
- 3. ELEV/TRAV POWER . . . . . 
- 4. MAIN GUN . . . . . OFF
- 5. MACHINE GUN . . . . . 
- 6. Machine gun safety . . . . . S
- 7. Gunner's triggers . . . . . Alternately depress left/right

Listen for clicks







BORESIGHTING 7.62-MM MACHINE GUN

(TM PAGE 2-360)

1. Machine gun . . . . . Clear
2. Buffer . . . . . Slide up and off
3. Cover/feed tray . . . . . Raise
4. Charger handle . . . . . Pull back
5. Operating rod and bolt . . . . . Pull out
6. Preliminary boresighting . . . . . Perform (Page 32)
7. Front adjustment nut . . . . . Loosen
8. M17A1 binocular . . . . . Sight through machine gun barrel bore
9. Center of barrel . . . . . Aline of target aiming point
10. Adjustment nut . . . . . Tighten


Depress release catch

Push in on cover latches

Use adjustment knobs on machine-gun mount

Turn additional 1/3 turn after tension is felt

GO TO 11



12. TTS . . . . . Prepare for operation (Page 1)

13. UNITY RETICLE BORESIGHT . . . . . Aline aiming circle center on aiming point EL and AZ

14. 17A1 binocular . . . . . Remove

15. Operating rod and bolt . . . . . Push in

16. Charger handle . . . . . Pull back


17. Feed tray/cover . . . . . Lower

18. Drive spring . . . . . Push in

19. Buffer . . . . . Slide down


20. Charger handle . . . . . Pull back to check operation

Catch will lock




ZEROING 7.62-MM MACHINE GUN

(TM PAGE 2-393)


1. Target . . . . . 800 Meters
2. MODE . . . . . STBY
3. Unity power window . . . . . Sight target
4. RETICLE control . . . . . Adjust until reticle is barely visible
5. MANUAL/RANGEFINDER . . . . . MANUAL
6. RANGE METERS X100 . . . . . Rotate to target distance
7. Ammo select unit . . . . . 
8. Unity power window . . . . . Sight target
9. Manual traversing and elevation handles . . . . . Lay target in center of aiming circle
10. Machine gun . . . . . Load/charge
11. UNITY RETICLE EL and AZ . . . . . Move aiming circle to center of strike area Do not disturb lay of gun
12. Manual traversing and elevation handles . . . . . Relay target in center of aiming circle

GO TO  
13




PREPARING TO FIRE PROCEDURE  
(TM PAGE 2-400)

COMMAND: PREPARE TO FIRE

- 1. Interior periscope and . . . . . Clean telescope sights
- 2. Ballistic shield . . . . . Check operation
- 3. MASTER BATTERY . . . . .  (driver)
- 4. Instrument lights . . . . . Check

COMMAND: CHECK FIRING SWITCHES


- 6. MAIN GUN . . . . . 
- 7. Engine . . . . . Start (driver)
- 8. 105-mm gun safety switch . . . . . In FIRE (loader)
- 9. Circuit tester . . . . . Insert (loader)
- 10. TC's control handles . . . . . Check trigger (TC)
- 11. Gunner . . . . . Announces: ON THE WAY

GO TO  
12

Loader announces  
NO FIRE if circuit  
tester does not light

Loader announces  
NO FIRE if circuit  
tester does not light

Loader announces  
NO FIRE if circuit  
tester does not light


- 12. Gunner's control handle . . . Check trigger
- 13. Gunner . . . . . Announces: ON THE WAY
- 14. Manual elevating control . . . Check trigger
- 15. MAIN GUN . . . . . OFF
- 16. MACHINE GUN . . . . .  ON
- 17. Coaxial machine gun . . . . . Cock
- 18. TC's control handle . . . . . Check trigger (TC)
- 19. Gunner . . . . . Announces: ON THE WAY
- 20. Gunner's control handles . . . Check triggers

COMMAND: CHECK GUN CONTROLS

- 21. Gunner . . . . . Announces: POWER
- 22. Oil in turret control . . . . . Check system

GO TO  
23

23. Turret . . . . . Unlock (loader)



24. ELEV/TRAV POWER . . . . .

25. Gun/turret . . . . . Elevate/traverse using  
gunner power controls

26. Magnetic brake/elevation . . . . . Check  
shutoff valve

27. Azimuth indicator . . . . . Check for accuracy/slippage

28. ELEV/TRAV POWER . . . . . OFF

29. Elevation quadrant . . . . . Check by use of gunner's  
quadrant


MAKE SURE THAT CREW IS READY  
AND NO PERSONNEL OR OBSTRUCTIONS  
ARE IN SURROUNDING AREA.

COMMAND: CHECK GUN STABILIZATION


30. STAB ELECTRONICS . . . . . (TC)



31. POWER PACK BLOWER MOTOR . . . . . (TC)







- 32. ELEV/TRAV POWER . . . . . ON
- 33. POWER on selector assembly . . . . . ON
- 34. STAB . . . . . ON
- 35. Gunner . . . . . Announces: TURRET STABILIZED
- 36. TRAV and/or EL BALANCE . . . . . Rotate to null drift
- 37. Gunner's control handles . . . . . Check function
- 38. TC's control handles . . . . . Activate override/check function (TC)
- 39. STAB SHUT-OFF . . . . . Depress (TC)
- 40. POWER on selector assembly . . . . . OFF
- 41. Gunner . . . . . Announces: STABILIZATION OFF

COMMAND: CHECK FIRE CONTROL

- 42. CUPOLA POWER . . . . . ON (TC)
- 43. GUN SAFETY . . . . . ON (TC)

GO TO 44

- 44. Cal .50 machine gun . . . . . Check operation (TC)
- 45. XM21 computer . . . . . Perform self-test (Page 9)
- 46. 105-mm gun . . . . . Prepare for boresighting (loader)
- 47. LRF . . . . . Perform self-test (TC)
- 48. Gunner's telescope and . . . . . Boresight (Page 24 or 32)  
periscope
- 49. LRF . . . . . Boresight (TC)
- 50. Ammo switch . . . . . Select appropriate ammo
- 51. MOVING/STATIONARY . . . . . Select appropriate setting
- 52. Computer . . . . . Enter ballistic data
- 53. Cal .50 machine gun . . . . . Boresight (TC)
- 54. 7.62-mm machine gun . . . . . Load (loader)
- 55. 105-mm gun . . . . . Load (loader)
- 56. Cal .50 machine gun . . . . . Load (TC)

COMMAND: REPORT

57. Gunner/Driver/Loader . . . . . Announce: READY



BEFORE OPERATIONS PMCS

(TM PAGE 2-87)

1. Travel lock . . . . . Unlock/stow (loader)
2. Turret lock . . . . . Check operation/leave (loader)  
in unlocked position

MAKE SURE CREW IS IN SAFE  
POSITION BEFORE OPERATING MANUAL  
TRAVERSING AND ELEVATING HANDLES


3. Manual elevating handle . . . . Elevate/depress main gun —————  
Check for smooth movement
4. Manual traversing handle . . . . Traverse turret left/right —————  
Check for smooth movement

DURING OPERATIONS PMCS

(TM PAGE 2-105)

- 1. Gunner's seat . . . . . Check if missing
- 2. Gunner's seat . . . . . Check operation/adjustment
- 3. Radio/intercom . . . . . Check operation
- 4. Fire control elevation . . . . . Check if scale and index are readable
- 5. Level vial cover . . . . . Check for free movement
- 6. Level vial . . . . . Check if broken
- 7. Light source control . . . . . Check if light goes from bright to dim
- 8. 8a. Level vial cover. . . . . Close
  - IS FIRE CONTROL QUADRANT TO BE USED ?
  - NO → GO TO 9
  - YES →
- 9. Azimuth indicator . . . . . Check if cover is broken
- 10. Rheostat . . . . . Turn clockwise
  - Light should go from dim to bright
  - GO TO 11

- 11. Turret hydraulic system . . . Check for leaks
- 12. Hydraulic pressure gage . . . Should read between 900 and 1200 psi during hydraulic operations
- 13. Gunner control handles . . . Traverse turret counter-  
clockwise Depress palm switches
- 14. TC control handles . . . Override gunner and traverse turret clockwise (TC)
- 15. TTS ballistic shield . . . Assure open
- 16. TTS window/outside lens . . . Check/clean Use cleaning compound and lens tissue



of M105D