

## 11/81Coastal Engineering Technical Note

CETN-V-2

## EROSION CONTROL AND HABITAT DEVELOPMENT WITH SMOOTH CORDGRASS ON THE GULF AND ATLANTIC COASTS

INTRODUCTION: In recent years there has been increased interest in the establishment or rehabilitation of coastal salt marshes. Plantings are generally made for the purpose of shore protection, dredged material stabilization or habitat development. On the Gulf and Atlantic coasts the dominant, emergent plant of the regularly flooded portion of the intertidal zone is smooth cordgrass (Spartina alterniflora) (Fig. 1). Much attention has been focused upon the planting of this species. In general, this plant can be grown successfully in a wide variety of intertidal

environments. The principle obstacle to the establishment of smooth cordgrass is wave stress. In intertidal environments that are sheltered from waves, invasion and establishment will occur naturally in two to three years without planting if the site is adjacent to existing marshes. In areas subject to wave stress, however, invasion may be slow and protracted or may not occur at all even when natural marshes are nearby.

OBJECTIVE: This technical note provides a method for determining wave climate severity and the probability of planting success at specific sites. In addition, planting specifications for smooth cordgrass are presented.



Figure 1. Smooth Cordgrass

	Form Approved OMB No. 0704-0188								
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.									
1. REPORT DATE NOV 1981		2. REPORT TYPE		3. DATES COVERED 00-00-1981 to 00-00-1981					
4. TITLE AND SUBTITLE	5a. CONTRACT NUMBER								
Erosion Control ar	5b. GRANT NUMBER								
GUIf and Atlantic Coasts					5c. PROGRAM ELEMENT NUMBER				
6. AUTHOR(S)					5d. PROJECT NUMBER				
					5e. TASK NUMBER				
	5f. WORK UNIT NUMBER								
7. PERFORMING ORGANI U.S. Army Corps o Laboratory,3909 H	8. PERFORMING ORGANIZATION REPORT NUMBER								
9. SPONSORING/MONITO	10. SPONSOR/MONITOR'S ACRONYM(S)								
	11. SPONSOR/MONITOR'S REPORT NUMBER(S)								
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited									
13. SUPPLEMENTARY NOTES									
14. ABSTRACT									
15. SUBJECT TERMS									
16. SECURITY CLASSIFIC	17. LIMITATION OF	18. NUMBER	19a. NAME OF						
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	ABSTRACT Same as Report (SAR)	OF PAGES 5	RESPONSIBLE PERSON				

Standard Form 298 (Rev. 8-98) Prescribed by ANSI Std Z39-18 WAVE CLIMATE VS. PROBABILITY OF SUCCESS: No single parameter or list of parameters can accurately predict that a planting will or will not be successful. It is rather, a question of probabilities. Under the best conditions the success of a planting will be influenced by factors such as (1) the care taken by the planter, (2) the occurrence of severe storms or drought, (3) the impact of foot and vehicular traffic, and (4) wildlife predation. However, Knutson, et al. (1981), found that the shore characteristics of FETCH, SHORE GEOMETRY and SEDIMENT GRAIN SIZE were useful indicators of wave climate severity and the likelihood of planting success. Figure 2 is a Vegetative Stabilization Site Evaluation Form based upon the above shore characteristics. This form may be used to evaluate potential marsh planting areas. It allows the user to estimate the success rate of other plantings made under similar conditions. The user (1) measures each Shore characteristic for the area in question, (2) identifies the descriptive categories which best describe the area, (3) notes the weighted score associated with each descriptive category, (4) calculates a cumulative score and (5) compares the cumulative score to the potential success rate.

This type of evaluation is important to the decision process for selecting planting sites. For example, in a mitigation or habitat development project a potential success rate of 50 percent might cause concern and an alternative site may be sought which has more favorable planting conditions. For vegetative stabilization projects, however, 50 percent potential success rate may be very promising considering that structural alternatives may be 10 times more costly.

## PLANTING SPECIFICATIONS - SMOOTH CORDGRASS:

<u>Planting Zone</u>: Mean low water to mean high water where tidal range is less than 6 feet (2 meters); mean tide to mean high water where tidal range is greater than 6 feet.

<u>Planting Width</u>: The entire planting zone should be planted whenever practicable. However, there is typically no advantage in planting to a width of more than 65 feet (20 meters). A practical minimum width is 20 feet (6.0 meters) or 60 percent of the planting zone, whichever is greater, When only a portion of the intertidal zone is to be planted, planting should be from mean high water seaward.

2

1. SHORE CHARACTERISTICS	2. DESCRIPTIVE CATEGORIES (SCORE WEIGHTED BY PERCENT SUCCESSFUL)						<b>3</b> . WEIGHTED SCORE				
d. FETCH-AVERAGE	LESS THAN	.  (0.7 to 3.0	)	3.1 (1.9) to 9.0		GREATER THAN 9.0					
PERPENDICULAR TO THE SHORE AND 45° EITHER SHORE	(0.6)	(1.9		(5.6)		(5.6)					
SIDE OF PERPENDICULAR	(87)	(66	)	(44)		(37)					
b. FETCH-LONGEST	LESS THAN	2,1		6, 1 (3,8) to		REATER THAN					
KILOWETERS (MILES) OF OPEN WATER MEASURED PERPENDICULAR TO THE SHORE OR 45° EITWER	2.0 (1.2)	6.0	to 6.0 (3.7)			18.0					
SITE SITE	(89)	.(67	)	(41)		(17)					
c. SHORELINE GEOMETRY	COVE	COVE		MEANDER OR STRAIGHT							
GENERAL SHAPE OF THE SHORELINE AT THE POINT OF INTEREST PLUS 200 METERS (660 FT)	SHORE SITE		SHORE		SHORL SITE	* ***					
ON EITHER SIDE	(85)		(62)		(50)						
d. SEDIMENT	less than	0.4	0.4 - 0.8		greater than 0.8						
GRAIN SIZE OF SEDIMENTS IN SWASH ZONE (mm)	(84)		(41)		(18)						
4. CUMULATIVE SCORE											
5. SCORE INTERPRETATION											
a. CUMULATIVE SCORE	122 – 200		201 - 300		00	300	- 345				
b. POTENTIAL SUCCESS RATE	0 to 30%		30 to 80%		80 to 100%						

## Figure 2. Vegetative Stabilization Site Evaluation Form

<u>Plant Spacing</u>; Two or three sprigs per hole or one potted seedling, twenty inch (0.5 meter) spacing between holes.

Salinity: 5 to 34 parts per thousand.

Light: Site must be devoid of an overstory of woody vegetation.

<u>Sediment</u>: Sediment grain size is an indicator of wave severity (see Fig. 2); however, in the absence of wave stress, sediments ranging from clay to coarse sand provide no barrier to plant establishment. <u>Plant Materials</u>: Sprigs (stems with attached root material) and potted seedlings are suitable.

<u>Planting Techniques</u>: Hand planting or mechanical planting (tobacco planter or strawberry planter) equally suitable.

<u>Planting Season</u>: Spring (March, April, and May); early spring in southern regions and late spring in northern regions.

<u>Fertilization</u>: Fertilization is recommended for all plantings subject to wave stress except where previous experience has shown it to be unneeded. Two general types of fertilizer can be used, soluble or slow release. Soluble materials should be either broadcast and disked in prior to planting, spread in the planting furrow, placed in a second hole beside the planting hole, or placed in the bottom of the planting hole and covered with soil before the plant is inserted. Slow release materials such as Osmocote or Mag Amp should be applied in the planting hole or furrow.

If soluble materials are used, they should be applied at a rate of 90 pounds per acre (100 kilograms per hectare) of nitrogen at the time of planting. In conventional mixed fertilizers, such as 10-10-10, the number designations represent the percentages (by weight) of nitrogen, phosphorous and potassium, respectively, that are found in the mixture. Therefore, the amount of 10-10-10 fertilizer per acre needed to provide 90 pounds of nitrogen would be 900 pounds per acre (1000 kilograms per hectare). A top-dressing of an additional 90 pounds per acre of soluble nitrogen, 6 to 8 weeks after planting, will be helpful on deficient sites and a third 90-pound application 6 weeks later will be advisable on acutely deficient sites.

Slow release materials, if used in lieu of soluble fertilizer, should be applied at a rate of 90 pounds per acre of nitrogen at time of planting. Slow release materials should always be placed in the planting hole or furrow. For conventional slow release mixtures (14-14-14 or 16-8-12), about  $\frac{1}{2}$  ounce (15 grams) of fertilizer should be placed in each hole. When slow release materials are used, no additional applications are necessary during the first growing season.

If plant cover and development are not adequate by the second growing season, fertilize again with 90 pounds per acre of nitrogen using a soluble source broadcast at low tide in early spring. After establishment, the color of the

4

grass itself can be used as a general indicator of available nitrogen. Dark leaves indicate an adequate supply while lighter shades of green and yellowing lower leaves during active growth results from too little nitrogen.

<u>Planting Maintenance</u>: Debris such as wood, styrofoam, algae, and dislodged submerged plants may accumulate in the planting areas and form a strand line. This material will smother and damage plantings particularly during the first two growing seasons. This debris should be removed in both the fall and spring.

Canada and Snow geese are fond of the tender roots of marsh plants. In areas of high winter wildfowl concentrations they may damage or destroy a planted area before the plants are well established. Open fences erected on the seaward edge of planted areas have been used successfully to exclude waterfowl during the first few growing seasons.

<u>Number of Planting Units</u>: The number of planting units required depends upon the spacing between holes and the number of planting units per hole.

Number of Planting Units = Area of Planting (Spacing)<sup>2</sup> X Number of Planting Units Per Hole (2-3 sprigs or 1 potted seedling)

Labor Estimate: Sprigs require about 1 manhour per 100 holes and potted seedlings about 2 to 3 manhours per 100 holes.

ADDITIONAL INFORMATION: For further information contact the U.S. Coastal Engineering Research Center, Coastal Ecology Branch (202) 325-7393.

**REFERENCES:** 

- KNUTSON, P.L., et al., "National Survey of Planted Salt Marshes (Vegetative Stabilization and Wave Stress) Wetlands," The Journal of the Society of Wetland Scientists, 1981.
- WOODHOUSE, W.W., Jr., "Building Salt Marshes along the Coasts of the Continental United States," SR No. 4, U.S. Army, Corps of Engineers, Coastal Engineering Research Center, Fort Belvoir, VA., 1979.