

UNCLASSIFIED

AD NUMBER

AD867379

NEW LIMITATION CHANGE

TO

**Approved for public release, distribution
unlimited**

FROM

**Distribution authorized to U.S. Gov't.
agencies and their contractors;
Administrative/Operational Use; MAR 1970.
Other requests shall be referred to US Air
Force Rome Air Development Center, Attn:
EMNRR, Griffiss AFB, NY 13440.**

AUTHORITY

RADC, USAF ltr, 27 Aug 1973

THIS PAGE IS UNCLASSIFIED

AD 867389

RADC-TR-70-14
Technical Report
March 1970



COMPUTERIZED RADC RELIABILITY NOTEBOOK
(GE/645/TSS/BASIC)

This document is subject to special
export controls and each transmission
to foreign governments or foreign na-
tionals may be made only with prior
approval of RADC (EMNRR), GAFB,
NY 13440.

D D C
APR 14 1970
B

Rome Air Development Center
Air Force Systems Command
Griffiss Air Force Base, New York

Approved for the
U.S. AIR FORCE USE
Distribution Unlimited
Information Specified in AF 37-1-3

104

When US Government drawings, specifications, or other data are used for any purpose other than a definitely related government procurement operation, the government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded, by implication or otherwise, as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

DISPOSITION FOR	WHITE SECTION <input type="checkbox"/>
OPM	BUFF SECTION <input checked="" type="checkbox"/>
DOC	<input type="checkbox"/>
UNARMED	<input type="checkbox"/>
PUSH POSITION	<input type="checkbox"/>
BY	<input type="checkbox"/>
TRANSMISSION AVAILABILITY CODES	
DATA	AVAIL. AND IN SPECIAL
21	

Do not return this copy. Retain or destroy.

COMPUTERIZED RADC RELIABILITY NOTEBOOK
(GE/645/TSS/BASIC)

George W. Lyne

This document is subject to special
export controls and each transmittal
to foreign governments or foreign na-
tional may be made only with prior
approval of RADC (EMNRR), GAFB,
NY 13440.

FOREWORD

This in-house report was prepared by the Reliability Engineering Section, Reliability Branch, Reliability and Compatibility Division, Rome Air Development Center, Griffiss Air Force Base, New York, under Project 5519. The project engineer and author of this report was Mr. George W. Lyne (EMNRR).

Acknowledgement is given to members of the Reliability and Compatibility Division for assistance in the development of the input and output formats of the computer programs herein.

The distribution of this document is limited under the U.S. Mutual Security Acts of 1949.

This technical report has been reviewed and is approved.

Approved: *G.W.Lyne*
GEORGE W. LYNE
Reliability Engineering Section
Reliability Branch

Approved: *J.J.Narsky*
JOSEPH J. NARSKY
Chief, Reliability & Compatibility Division

FOR THE COMMANDER:

I.J.Gabelman
IRVING J. GABELMAN
Chief, Plans Office

ABSTRACT

Computer programs which enable the reliability engineer to mechanically apply the "RADC Reliability Notebook," Volume II, September 1967, in obtaining the failure rate of piece parts are presented.

TABLE OF CONTENTS

Contents	Page
SECTION I INTRODUCTION	1
OBJECTIVE	1
RESULTS	1
LIBRARY CONTENT	1
COMPUTER OPERATION	2
PROGRAM AVAILABILITY	2
FUTURE STUDIES	2
WARNING	2
SECTION II PROGRAM LISTINGS	3
RESISTORS	3
CARBON COMPOSITION RESISTORS	4
FILM RESISTORS	9
FIXED WIREWOUND RESISTORS	15
POTENTIOMETERS (VARIABLE RESISTORS)	21
CAPACITORS	28
CONNECTORS	34
RELAYS	38
SWITCHES	43
SEMICONDUCTORS	48
MICROCIRCUITS	55
PRINTED WIRING	60
SECTION III PROGRAM INPUT-OUTPUT EXAMPLES	63
INTRODUCTION	63
PROGRAM INSTRUCTIONS	63
DATA INPUT	64
OUTPUT SYMBOLS AND CODES	64
EXAMPLES	64
EXAMPLE I (POTENTIOMETERS)	65
EXAMPLE II (SEMICONDUCTORS)	68
EXAMPLES III (MICROCIRCUITS)	76
EXAMPLE IV (CAPACITORS)	82
APPENDIX PROGRAM INSTRUCTION LISTINGS	85
CARBON COMPOSITION RESISTORS	86
FILM RESISTORS	87
FIXED WIREWOUND RESISTORS	88

TABLE OF CONTENTS CONT'D

Contents	Page
POTENTIOMETERS	89
CAPACITORS	90
CONNECTORS	91
RELAYS	92
SWITCHES	93
SEMICONDUCTORS	94
MICROCIRCUITS	95

SECTION I

INTRODUCTION

1. OBJECTIVE

The purpose of this report is to provide the reliability engineer with a computerized version of the "RADC Reliability Notebook" (Vol.II), September 1967.

Basis of this effort was the number of inquiries to RADC for a computerized version of the Notebook since publication.

2. RESULTS

A library of computer programs, written in basic language for the General Electric 645/Time-Sharing System, which provide the reliability engineer with a mechanical means of applying the "RADC Reliability Notebook" in obtaining catastrophic failure rates for part-types covered by the Notebook. These programs provide the engineer with:

- A. Short analysis response time resulting in cost savings
- B. Capability of obtaining failure rates of a given part for various stress conditions
- C. Repeatability and minimization of error because of computer assessment.

3. LIBRARY CONTENT

A listing of the computer programs contained herein is presented in the table of contents. Computer listings and examples of the implementation of the programs are presented in Sections I and II of this report.

Following is a list of part categories covered in the Notebook which are not covered herein. This is because the failure rate prediction techniques did not lend themselves to computerization or the math models were not available, and the GE/645/TSS basic language does not provide the necessary routines, storage, etc. which are required to perform numerical analysis to approximate the functions.

- A. Magnetic devices
- B. Rotating devices
- C. Electronic tubes

4. COMPUTER OPERATION

Instructions for the GE/645/TSS terminal operation are presented in the "RADC TSS-645 Basic Reference Manual," October 1968.

5. PROGRAM AVAILABILITY

The intent is to make the programs available to the users of the RADC GE/TSS/System through the system library. These users will be notified when the programs are placed in the system. Others may obtain paper tapes of the programs on request of RADC/EMNRR/GAFB/NY/13440.

6. FUTURE STUDIES

It is planned by EMNRR to expand the library to include equipment and system failure rate prediction programs, and convert this library from basic to FORTRAN IV. With the advent of the FORTRAN library it is hoped that the part categories not included herein can be incorporated.

7. WARNING

The computer programs herein do not have checks for values of part parameters and stress conditions which fall outside the part specifications or failure rate prediction model design.

SECTION II

PROGRAM LISTINGS

This section presents a computer listing of the computerized version of the "RADC Reliability Notebook," Volume II, September 1967.

These programs have been developed for piece-part failure rate predictions, i.e. they enable the reliability engineer to obtain the failure rate of a piece part for one or more stress conditions in one computer run (see Section III for examples). These programs have not been developed for obtaining failure rate predictions of equipments or systems. As discussed in Section I the development of such a library of computer programs is planned by EMNRR.

RESISTORS

- A. Carbon composition
- B. Film
- C. Wirewound.

CARBON COMPOSITION RESISTORS

```
00010 DIMA(10),B(10),C(10),D(10),E(10),F(10),G(150),H(60),J(60),W(4,7),B  
00020 DIM V$(10),US(10)  
00030 PRINTTAB(12);"FAILURE RATES FOR CARBON COMPOSITION RESISTORS"  
00040 PRINT  
00050 PRINT " DO YOU WISH INSTRUCTIONS --- YES OR NO"  
00060 INPUT US  
00070 IF US="NO" GO TO 0490  
00080 PRINT  
00090 PRINT "THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE "  
00100 PRINT "CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY"  
00110 PRINT "A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR CARBON COMPO  
00120 PRINT "IN ACCORDANCE "  
00130 PRINT "WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967.  
00140 PRINT  
00150 PRINT TAB(15);"INPUT REQUIREMENTS"  
00160 PRINT  
00170 PRINT "1. RESISTOR STYLE"  
00180 PRINT  
00190 PRINT  
00200 PRINT "2. RESISTANCE VALUE (OHMS)"  
00210 PRINT  
00220 PRINT "3. ENVIRONMENT -- LABORATORY, GROUND, ETC."  
00230 PRINT  
00240 PRINT "4. THE MULTIPLE OF LONGEVITY AND THE VALUE OF PI(L) IF THE"  
00250 PRINT " FAILURE RATE FOR A MULTIPLE OF LONGEVITY IS TO BE CALCULATED"  
00260 PRINT  
00270 PRINT "5. STRESS CONDITIONS"  
00280 PRINT  
00290 PRINT "      A. STRESS RATIO = OPERATING POWER/POWER RATING"  
00300 PRINT "           MAX, MIN AND INCREMENT"  
00310 PRINT  
00320 PRINT "      B. OPERATING TEMPERATURE (DEGREES C)"  
00330 PRINT "           MAX, MIN, AND INCREMENT"  
00340 PRINT  
00350 PRINT "NOTES:  
00355 PRINT  
00360 PRINT "THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE"  
00370 PRINT "NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY"  
00380 PRINT "THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM"  
00390 PRINT  
00401 PRINT "IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS CONDITION"  
00402 PRINT "INPUT THE VALUE FOR MAX, MIN, AND INC --- EXAMPLE:1,1,1"  
00403 PRINT  
00410 PRINT "MANY OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUT CODES"  
00420 PRINT  
00430 PRINT "THE INPUTS ARE ENTERED BY THE KEYBOARD AS THEY ARE QUERIED"  
00440 PRINT  
00450 PRINT "DO YOU WISH TO RUN -- YES OR NO"  
00460 INPUT US  
00470 IF US="YES" GO TO 0490  
00480 GO TO 2380  
00490 PRINT  
00500 PRINT  
00505 LET V$(8)="NO"
```

CARBON COMPOSITION RESISTORS

```
00510 PRINT
00520 PRINT "FOR WHAT ENVIRONMENT IS THIS ANALYSIS TO BE PERFORMED?"
00530 PRINT "(1) LABORATORY (2) SATELLITE ORBIT (3) GROUND, FIXED"
00540 PRINT "(4) GROUND, PORTABLE (5) AIRBORNE, INHABITED (6) GROUND
00550 PRINT "(7) AIRBORNE, UNINHABITED (8) SATELLITE, LAUNCH"
00560 PRINT "(9) MISSILE ----- INPUT 1,2,3,...,OR 9";"
00570 INPUT Y
00580 LET Y8=Y
00581 PRINT
00582 PRINT"GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER - INPUT 1 OR 2
00583 INPUT C7
00590 PRINT
00600 PRINT "WHAT IS THE RESISTOR STYLE: (1) RC-28, (2) RC-07, (3) RC-08
00610 PRINT "(4) RC-20, (5) RC-32, (6) RC-42 OR (7) RC-08";
00620 PRINT " INPUT 1, 2, .... OR 7"
00630 INPUT S
00640 LET S1=S
00650 LET US(1)="RC-28"
00660 LET US(2)="RC-07"
00670 LET US(3)="RC-08"
00680 LET US(4)="RC-20"
00690 LET US(5)="RC-32"
00700 LET US(6)="RC-42"
00710 LET US(7)="RC-08"
00720 LET US=US(S)
00730 IF S<=3GO TO 0780
00740 IF S=7GO TO 0770
00750 LET S=3
00760 GO TO 0780
00770 LET S=4
00780 PRINT
00790 FOR I=1 TO 4
00800 READ A(I),B(I),D(I),E(I),F(I)
00810 NEXT I
00820 FOR I=1 TO 5
00830 READ G(I)
00840 NEXT I
00850 PRINT "RESISTANCE (OHMS)"
00860 INPUT G
00870 LET Y=Y8
00880 PRINT
00890 PRINT "IS THE FAILURE RATE FOR A MULTIPLE OF LONGEVITY TO BE"
00900 PRINT "CALCULATED --- YES OR NO";
00910 INPUT VS
00920 IF VS="NO"GO TO 0980
00930 PRINT
00940 PRINT "MULTIPLE OF LONGEVITY AND PI(L) ="
00960 INPUT C8,C9
00970 PRINT
00980 LET R=G
00990 LET Y=Y*2
01000 IF G>99GO TO 01030
01010 LET Y1=1
01020 GO TO 1130
```

CARBON COMPOSITION RESISTORS

```
01030 IF G>1E5 GO TO 1060
01040 LET Y1=2
01050 GOTO 1130
01060 IF G>1E6 GO TO 1090
01070 LET Y1=3
01080 GO TO 1130
01090 IF G>1E7 GO TO 1120
01100 LET Y1=4
01110 GO TO 1130
01120 LET Y1=5
01130 FOR I=1 TO 18
01140 IF S>280 TO 1170
01150 READ H(I),J(I),T,T
01160 GOTO 1210
01170 IF S>300 TO 1200
01180 READ H(I),T,J(I),T
01190 GOTO 1210
01200 READ H(I),T,T,J(I)
01210 NEXT I
01220 IF USC(8)="YES" THEN 1330
01230 PRINT
01240 PRINT "MAX, MIN AND INCREMENT OF STRESS RATIO ="
01270 INPUT B1,B2,B3
01280 PRINT
01290 PRINT "MAX, MIN AND INCREMENT OF OPER. TEMPERATURE (DEGREES C) ="
01320 INPUT T1,T2,T3
01330 FOR I=1 TO 5
01340 PRINT
01350 NEXT I
01360 PRINT"*****"
01370 PRINT
01380 PRINT
01390 PRINT TAB(1);"CARBON COMPOSITION RESISTORS"
01400 PRINT
01410 PRINT TAB(8);"STYLE",US
01420 PRINT
01430 PRINT TAB(10);"RESISTANCE =">R,
01440 IF Y5<>2GOTO 1470
01450 PRINT "POWER CODE =">Y6
01460 PRINT
01470 PRINT TAB(17);"ENVIRONMENT CODE =">Y8
01480 PRINT
01481 LET USC(1)="UPPER"
01482 LET USC(2)="LOWER"
01485 PRINT TAB(13);"GRADE OF RELIABILITY =">USC(7)
01490 PRINT
01500 IF C9=0GOTO 1530
01510 PRINT TAB(5);"MULTIPLE OF LONGEVITY =">C8, "PI(L)"=>C9
01520 PRINT
01530 FOR I=B2TOB1 STEP B3
01540 PRINT
01550 PRINT "STRESS RATIO =">I
01560 PRINT
01570 PRINT "TEMPERATURE", " FAILURE RATE (%/1000 HRS.)"
```

CAP ON COMPOSITION RESISTORS

```
01620 PRINT TAB(15); "L(B)"; TAB(30); "L(R)"; TAB(50); "L(RL)"  
01630 PRINT  
01631 IF C7=2 THEN 01635  
01632 LET H=H(Y-1)  
01633 LET J=J(Y-1)  
01634 GOTO 01640  
01635 LET H=H(Y)  
01636 LET J=J(Y)  
01640 PRINT  
01650 FOR T=T2TOT1 STEPT3  
01660 LET K=F(S)*EXP(((T+273)/A(S))+D(S))*EXP((I/B(S))+E(S))  
01670 LET A=(K*G(Y1)*H+J)*C9  
01690 IF C9<>0 GOTO 01720  
01700 PRINT T,K,K*G(Y1)*H+J,"NA"  
01710 GOTO 01750  
01720 PRINT T,L,K*G(Y1)*H+J,A  
01750 NEXT T  
01760 PRINT  
01770 NEXT I  
01780 FOR I=1TO3  
01790 PRINT  
01800 NEXT I  
01810 PRINT  
01820 PRINT  
01830 LET T8=0  
01840 PRINT TAB(13); "MATH MODEL"  
01850 PRINT  
01860 PRINT " L(R)=A*EXP(((T+273)/NT)+G*EXP(((P/P0)/NS)+H))  
01870 PRINT "*PI(R)*PI(E)+SIGMA(E)"  
01880 PRINT  
01890 PRINT " WHERE:"  
01900 PRINT "A="; F(S), "NT="; A(S), "NS="; B(S)  
01910 PRINT  
01920 PRINT "J="; C(S), "G="; D(S), "H="; E(S), "PI(R)="; G(Y1)  
01930 PRINT  
01940 PRINT "UPPER PI(E)="; H(Y-1), "UPPER SIGMA(E)="; J(Y-1)  
01950 PRINT  
01960 PRINT "LOWER PI(E)="; H(Y), "LOWER SIGMA(E)="; J(Y)  
01990 PRINT,  
02000 PRINT  
02010 PRINT *****  
02020 PRINT  
02030 FOR I=1TO10  
02040 PRINT  
02050 NEXT I  
02060 RESTORE  
02070 PRINT "DO YOU WISH TO RUN ANOTHER ANALYSIS -- YES OR NO?"  
02080 INPUT US  
02090 IF US="NO" THEN 2380  
02100 LET C9=0  
02110 PRINT  
02120 PRINT "IS THE ANALYSIS FOR THE SAME ENVIRONMENT -- YES OR NO?"  
02130 INPUT US  
02140 IF US="NO" GOTO 0500
```

CARBON COMPOSITION RESISTORS

```
02150 PRINT
02160 PRINT"IS THE ANALYSIS FOR THE SAME STRESS CONDITIONS -- YES OR NO?
02170 INPUT US(S)
02180 PRINT
02190 PRINT"IS THE ANALYSIS FOR THE SAME RESISTOR STYLE --YES OR NO?"
02200 INPUT US
02210 PRINT
02220 IF US=="NO" GOTO 0590
02230 PRINT
02240 LET S=S1
02250 GOTO 0650
02260 DATA 25,.28,1,1,195E-13,25,.31,1,1,399E-13
02270 DATA 25.,.42,1,1,1.2E-10,25,.625,1,1,3.6E-10
02280 DATA 1.1,1,1,1,1.6,2.5
02290 DATA 1,.0001,.0002,.0005, 1.5,.001,.002,.001
02300 DATA 1.04,.0001,.0002,.0005, 1.5,.001,.002,.001
02310 DATA 2,.0004,.0005,.001, 4,.002,.003,.003
02320 DATA 5,.0008,.001,.002, 10,.004,.005,.006
02330 DATA 4,.0006,.001,.001, 8,.003,.005,.003
02340 DATA 7,.001,.002,.002, 14,.005,.008,.006
02350 DATA 8,.001,.002,.002,20,.005,.008,.006
02360 DATA 15,.005,.002,.002, 40,.01,.008,.006
02370 DATA 20,.005,.003,3.003, 80,.01,.01,.01
02380 END
```

FILM RESISTORS

```
00010 DIM A(10),B(10),C(10),D(10),E(10),F(10),G(150),H(60),J(60),W(4,7)
00020 DIM VS(10),Z(4),US(10)
00030 PRINT TAB(15); "FAILURE RATE FOR FILM RESISTORS"
00040 PRINT
00050 PRINT " DO YOU WISH INSTRUCTIONS --- YES OR NO"
00060 INPUT US
00070 IF US="NO" GOTO 00380
00080 PRINT
00090 PRINT "THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE "
00100 PRINT "CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY"
00110 PRINT "A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR FILM RESISTORS"
00120 PRINT "IN ACCORDANCE"
00130 PRINT "WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967."
00140 PRINT
00150 PRINT TAB(15); "INPUT REQUIREMENTS"
00160 PRINT
00170 PRINT "1. RESISTOR TYPE -- POWER, PRECISION, ESTABLISHED RELIABILITY"
00180 PRINT " OR INSULATED"
00190 PRINT "2. RESISTANCE VALUE"
00200 PRINT "3. ENVIRONMENT -- LABORATORY, GROUND, ETC."
00210 PRINT "4. MULTIPLE OF LONGEVITY AND PI(L)"
00220 PRINT "5. RELIABILITY LEVEL"
00230 PRINT "6. RESISTOR CHARACTERISTIC"
00240 PRINT "7. RESISTOR POWER (WATTS)"
00250 PRINT "8. MAX, MIN AND INC OF THE STRESS RATIO AND OPER. TEMPERATURE"
00251 PRINT TAB(13); "STRESS RATIO = OPERATING POWER/RATED POWER"
00260 PRINT
00270 PRINT "NOTES"
00280 PRINT "THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE"
00290 PRINT "NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY"
00300 PRINT "THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM"
00310 PRINT
00320 PRINT "MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUTS"
00330 PRINT
00340 PRINT "IF ONLY ONE ENTRY IS REQUIRED FOR THE STRESS RATIO OR THE"
00350 PRINT "OPER TEMPERATURE INPUT THE SAME VALUE FOR MAX, MIN AND INC"
00360 PRINT
00370 GO TO 0360
00380 PRINT
00390 PRINT
00400 PRINT
00410 PRINT "FOR WHAT ENVIRONMENT IS THIS ANALYSIS TO BE PERFORMED"
00420 PRINT "(1) LABORATORY (2) SATELLITE ORBIT (3) GROUND, FIXED"
00430 PRINT "(4) GROUND, PORTABLE (5) AIRBORNE, INHABITED (6) GROUND, UNINHABITED"
00440 PRINT "(7) AIRBORNE, UNINHABITED (8) SATELLITE, LAUNCH"
00450 PRINT "(9) MISSILE ----- INPUT 1,2,3,...,OR 9"
00460 INPUT Y
00470 LET Y=1
00475 LET US(8)="NO"
00480 PRINT
00490 PRINT
```

FILM RESISTORS

```
00490 PRINT"IS THE ANALYSIS FOR (1) POWER, (2) PRECISION, (3) ESTABLISHED  
00500 PRINT"RELIABILITY OR (4) INSULATED FILM RESISTORS - INPUT 1,2,3 OR  
00501 INPUT Y5  
00502 PRINT  
00503 PRINT"GRADE OF RELIABILITY (1) UPPER OR (2) LOWER - INPUT 1 OR 2"  
00504 INPUT C7  
00514 IF Y5<>3 THEN 00520  
00515 IF C7<>2 GO TO 00520  
00516 PRINT  
00517 PRINT"THE REL MAT MODEL OF THIS RESISTOR IS FOR UPPER GRADE ONLY"  
00518 PRINT"SEE PAGE 45 OF THE NOTEBOOK"  
00519 LET C7=1  
00520 PRINT  
00521 PRINT"RESISTANCE (OHMS)= "  
00522 INPUT R  
00523 PRINT  
00524 PRINT"IS THE F.R. FOR A MULTIPLE OF LONGEVITY TO BE CALCULATED --"  
00525 INPUT VS(9)  
00526 LET Y=VS  
00527 IF VS(9)<>"YES" GO TO 00640  
00528 PRINT  
00529 PRINT"MULTIPLE OF LONGEVITY AND PI(L)= "  
00530 INPUT CS,C9  
00531 PRINT  
00532 LET VS(1)="POWER FILM (MIL-R-11884)"  
00533 LET VS(2)="PRECISION FILM (MIL-R-10509 (RND))"  
00534 LET VS(3)="FIXED ESTABLISHED RELIABILITY FILM (MIL-R-55182 (RNR))"  
00535 LET VS(4)="INSULATED FIXED FILM (MIL-R-22684 (RL))"  
00536 LET VS=VS(Y5)  
00537 IF Y5 <>3 GO TO 00660  
00538 PRINT"RELIABILITY LEVEL. ="  
00539 PRINT" (1) S, (2) R, (3) P OR (4) N ) -- INPUT 1,2,3 OR 4"  
00540 INPUT Y7  
00541 LET S=Y  
00542 PRINT  
00543 IF Y5<>4 GO TO 00760  
00544 LET S=7  
00545 ON Y5 GO TO 00790, 00780, 1020, 1020  
00546 PRINT"RESISTOR CHARACTERISTIC = P OR G"  
00547 INPUT US  
00548 PRINT  
00549 IF US="P" GO TO 00550  
00550 LET S=2  
00551 GO TO 1020  
00552 LET S=1  
00553 GO TO 1020  
00554 REM PRECISION FILM  
00555 PRINT"WHAT IS THE RESISTOR CHARACTERISTIC (1) B,D (2) C,E,F"  
00556 PRINT"OR (3) G ---- INPUT 1,2, OR 3"  
00557 LET US(1)="B,D"  
00558 LET US(2)="C,E, AND F"  
00559 LET US(3)="G"  
00560 INPUT S  
00561 LET US=US(S)
```

FILM RESISTORS

```
00950 PRINT
00960 PRINT"WHAT IS THE RES. POWER (1) 1/20, (2) 1/16, (3) 1/8, (4) 1/4
00970 PRINT"(5) 1/2, (6) 3/4, (7) 1, OR (8) 2 WATTS"
00980 PRINT"INPUT 1,2,3,.....,OR 8"
00990 INPUT Y6
01000 IF S=2THEN01020
01010 LET Y6=Y6-1
01020 FOR I=1 TO 7
01030 READ A(I),B(I),C(I),D(I),E(I),F(I)
01040 NEXT I
01050 FOR I=1TO94
01060 READ G(I)
01070 NEXT I
01080 PRINT
01090 IF US(8)="YES"GO TO 1230
01100 PRINTTAB(17); "STRESS CONDITIONS"
01110 PRINT
01120 PRINT"MAX, MIN AND INC OF STRESS RATIO"
01130 INPUT B1,B2,B3
01140 PRINT
01150 PRINT"MAX, MIN AND INC OF OPER TEMPERATURE (DEGREES C)"
01210 INPUT T1,T2,T3
01220 PRINT
01230 ONY5GOTO1330,1240,1330,1330
01240 LET I=S*28+4
01250 FOR I1=1TO4
01260 FOR I2=7TO1STEP-1
01270 LET W(I1,I2)=G(I)
01280 LET I=I-1
01290 NEXT I2
01300 NEXT I1
01310 LET S=S+2
01320 LET Y=Y*2+9
01330 PRINT
01340 PRINT
01350 IF Y5>2 GO TO 1470
01360 IF R>99 GO TO 1390
01370 LET Y1=1
01380 GOTO1630
01390 IF R>=1000000 GOTO1420
01400 LET Y1=2
01410 GOTO1630
01420 IF R>=1E6 GOTO1450
01430 LET Y1=3
01440 GOTO1630
01450 LET Y1=4
01460 GOTO1630
01470 IF R>99 GO TO 1500
01480 LET Y1=1
01490 GO TO 1570
01500 IF R>1E4 GOTO1530
01510 LET Y1=2
01520 GOTO1570
```

FILM RESISTORS

```
01530 IF R>1E5 GO TO 1560
01540 LET Y1 =3
01550 GOTO 1570
01560 LET Y1=4
01570 LET Y1=Y1+88
01580 LET Y=Y+27
01590 IF Y5<>3GO TO1630
01600 LET Y1=Y1+4
01610 LET Y=Y-27
01620 LET Y=Y*2+36
01630 FOR I=1TO54
01640 READ R(I),J(I)
01650 NEXT I
01660 FOR I=1TO 4
01670 READ Z(I)
01680 NEXT I
01690 IF Y5<>2GO TO1710
01700 LET G(Y1)=W(Y1,Y6)
01710 PRINT
01720 PRINTTAB(17);VS
01730 PRINT
01740 IF Y5>2 GO TO1760
01750 PRINTTAB(17);"CHARACTERISTIC ";US
01760 PRINT
01770 PRINTTAB(10);"RESISTANCE =";R,
01780 IF Y5<>2GO TO1810
01790 PRINT"POWER CODE =";C6
01800 PRINT
01810 PRINTTAB(17);"ENVIRONMENT CODE =";YS
01820 PRINT
01821 LET VS(1)="UPPER"
01822 LET VS(2)="LOWER"
01823 PRINTTAB(13);"GRADE OF RELIABILITY =";VS(C7)
01824 PRINT
01830 IF Y5<>3GO TO1870
01840 PRINTTAB(10);"RELIABILITY LEVEL CODE =";
01850 PRINTY7
01860 PRINT
01870 IF C9=8GO TO1900
01880 PRINTTAB(5);"MULTIPLE OF LONGEVITY =";CS, "PI(L) =";C9
01890 PRINT
01900 FOR I=B2TOB1 STEP B3
01910 PRINT
01920 PRINT"STRESS RATIO =";I
01930 PRINT
01940 PRINT"TEMPERATURE", " FAILURE RATE (%/1000 HRS.)"
01950 PRINTTAB(15);"L(B)";TAB(30);"L(R)";TAB(50);"L(M)"
01955 IF G(Y1)<>0THEN02000
01960 PRINT
01967 PRINT"THE RESISTANCE FACTOR, PI(RW), FOR THIS RESISTANCE AND WATT
01968 PRINT"IS NA -- SEE THE NOTEBOOK PAGE 41"
01969 GOTO02740
02000 PRINT
02001 IF C7=2GO TO02006
```

FILM RESISTORS

```

02002 LET H=H(Y-1)
02003 LET J=J(Y-1)
02004 GOTO 02010
02006 LET H=H(Y)
02007 LET J=J(Y)
02010 ON Y5 GO TO 2020, 2250, 2250, 2020
02020 FOR T=T2 TO T1 STEPT3
02030 LET K=F(S)*EXP(((T+273)/A(S))+D(S))
02040 LET K=K*EXP(((I/B(S))+((T+273)/273)*C(S))+E(S))
02050 LET A=(K*G(Y1)+H+J)*C9
02070 IF Y5<=1 GOTO 2150
02080 IF C9<>0 GO TO 2110
02090 PRINTT,K,K*G(Y1)*H+J,"NA"
02100 GO TO 2140
02110 PRINTT,K,K*G(Y1)*H+J,A
02140 GO TO 2210
02150 IF C9<>0 THEN 02190
02160 PRINTT,K,(K*G(Y1)*H+J)/2.5,"NA"
02170 GO TO 2210
02190 PRINTT,K,(K*G(Y1)*H+J)/2.5,A/2.5
02210 NEXT T
02220 NEXT I
02230 GO TO 02730
02240 PRINT
02250 FOR T=T2 TO T1 STEPT3
02260 LET K=F(S)*EXP(((T+273)/A(S))+D(S))*EXP((I/B(S))+E(S))
02270 LET A=(K*G(Y1)+H+J)*C9
02290 IF Y5<>3 GO TO 2370
02300 IF C9<>0 THEN 02340
02310 PRINTT,K,K*G(Y1)*Z(Y7)+H,"NA"
02320 GOTO 02360
02340 PRINTT,K,K*G(Y1)*Z(Y7)+H,K*G(Y1)*Z(Y7)+H*C9
02360 GO TO 02430
02370 IF C9<>0 THEN 02410
02380 PRINTT,K,K*G(Y1)*H+J,"NA"
02390 GO TO 02430
02410 PRINTT,K,K*G(Y1)*H+J,A
02430 NEXT T
02440 LET T8=1
02450 GOTO 02200
02460 FOR I=1 TO 3
02470 PRINT
02480 NEXT I
02730 PRINT
02740 FOR I=1 TO 10
02750 PRINT
02760 NEXT I
02770 RESTORE
02780 PRINT "DO YOU WISH TO RUN ANOTHER ANALYSIS -- YES OR NO?"
02790 INPUT US
02800 IF US="NO" GO TO 3100
02810 LET C9=0
02820 PRINT
02830 PRINT "IS THE ANALYSIS FOR THE SAME ENVIRONMENT -- YES OR NO?"
```

FILM RESISTORS

```
02640 INPUT US
02650 IF US="NO" GO TO 02390
02660 PRINT
02670 PRINT"IS THE ANALYSIS FOR THE SAME STRESS CONDITIONS -- YES OR NO"
02680 INPUT US(8)
02690 PRINT"IS THE ANALYSIS FOR THE SAME RESISTOR TYPE -- YES OR NO"
02700 INPUT US
02710 IF US="NO" GO TO 02450
02720 GO TO 0520
02730 DATA 551, 1.45, .89, 2.6, 1.3, 11E-3
02740 DATA 551, .72, .89, 2.6, 1.3, 11E-3
02750 DATA 98, 1.89, 0, 1, 1, 1.87E-6, 188, 1.85, 0, 1, 1, 2.5E-5
02760 DATA 98, 1.89, 0, 1, 1, 1.93E-6
02770 DATA 188, 1.85, 0, 1, 1, 2.5E-6, 320, 2, 1, 1, 1.94, 3.26, 1, 305E-6
02780 DATA 1, 2, 1, 1, 3, 3, 5
02790 DATA 0, 0, 0, 3, 4, 5, 3, 6, 4, 2, 0, 3, 75, 2, 5, 2, 5, 3, 75, 3, 3, 5
03000 DATA 2, 1, 5, 1, 1, 1, 5, 1, 2, 1, 4, 3, 2, 25, 1, 5, 1, 5, 2, 25, 1, 8, 2, 1
03010 DATA 0, 0, 0, 0, 4, 5, 3, 6, 0, 0, 3, 75, 2, 5, 2, 5, 3, 75, 3
03020 DATA 3, 2, 1, 5, 1, 1, 1, 5, 1, 8, 4, 5, 3, 2, 25, 1, 5, 1, 5, 2, 25, 1, 8
03030 DATA 0, 0, 3, 3, 4, 5, 3, 6, 4, 2, 5, 3, 75, 2, 5, 2, 5, 3, 75, 3, 3, 5
03040 DATA 2, 1, 5, 1, 1, 1, 5, 1, 2, 1, 4, 3, 2, 25, 1, 5, 1, 5, 2, 25, 1, 8, 2, 1
03050 DATA 1, 4, 1, 1, 2, 5, 1, 5, 1, 2, 2, 4
03060 DATA 1, .001, 1, 5, .0015, 5, .01, 7, 5, .015, 6, 5, .012, 12, .03, 15, .04
03070 DATA 25, .05, 35, .1
03080 DATA 1, 5E-5, 3, .0002, 1, 01, .00005, 3, 2E-4, 2, 5, 1E-4, 8, 4E-4
03090 DATA 6, 2E-4, 20, 1E-3, 5, 2E-4, 15, 1E-3, 18, 5E-4, 20, 2E-3, 12, 6E-4
03100 DATA 50, 25E-5, 18, 1E-3, 75, 4E-3, 25, 2E-3, 100, 1E-2
03110 DATA 1, 0, 1, 01, 0, 2, 5, 0, 6, 0, 0, 5, 0, 10, 0, 0, 18, 0, 0, 25, 0
03120 DATA .2, 0, 1, 0, .3, 0, 0001, 1, 5, .0001, 1, .0005, 5, .001, 1, 5, .0005
03130 DATA 7, 5, .0015, 1, 4, .0006, 6, 5, .0013, 2, 5, .001, 12, .002, 3, .0012
03140 DATA 15, .0025, 10, .002, 25, .004, 15, .003, 35, .006
03150 DATA 1, 3E-1, 1, 0, 6
03160 END
03170 PRINT
```

FIXED WIREWOUND RESISTORS

```
00010 DIMA(10),B(10),C(10),D(10),E(10),F(10),G(150),H(60),J(60),W(4,7)
00020 DIMUS(10),US(10),LS(50)
00030 PRINT TAB(13);"FAILURE RATE FOR FIXED WIREWOUND RESISTORS"
00040 PRINT
00050 PRINT " DO YOU WISH INSTRUCTIONS --- YES OR NO"
00060 INPUT US
00070 IFUS="NO"THEN0430
00080 PRINT
00090 PRINT "THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE "
00100 PRINT "CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY"
00110 PRINT "A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY OF WIREWOUND RE
00120 PRINT "IN ACCORDANCE ";
00130 PRINT "WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967.
00140 PRINT
00150 PRINT TAB(15);"INPUT REQUIREMENTS"
00160 PRINT
00170 PRINT"1. RESISTOR TYPE -- ACCURATE OR POWER
00180 PRINT " OR INSULATED"
00190 PRINT "2. RESISTANCE VALUE
00200 PRINT "3. ENVIRONMENT -- LABORATORY, GROUND, ETC.
00210 PRINT"4. VALUE OF PI(L) FOR MULTIPLE OF LONGEVITY
00220 PRINT"5. RELIABILITY GRADE -- UPPER OR LOWER
00230 PRINT "6. RESISTOR CHARACTERISTIC
00240 PRINT"7. MAX, MIN AND INCREMENT OF THE STRESS RATIO AND OPER TEMP
00250 PRINT TAB(13);"STRESS RATIO = OPERATING POWER/RATED POWER"
00260 PRINT
00270 PRINT "NOTES"
00280 PRINT "THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE"
00290 PRINT "NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY"
00300 PRINT "AND THE RESISTANCE STYLE -- EXAMPLE RW 70"
00310 PRINT
00320 PRINT "THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM"
00330 PRINT
00340 PRINT "MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUT
00350 PRINT
00360 PRINT "IF ONLY ONE ENTRY IS REQUIRED FOR THE STRESS RATIO OR THE"
00370 PRINT "OPER TEMPERATURE INPUT THE SAME VALUE FOR MAX, MIN AND INC
00380 PRINT
00390 PRINT "DO YOU WISH TO RUN -- YES OR NO"
00400 INPUT US
00410 IFUS="YES"THEN0430
00420 GOTO02870
00430 PRINT
00440 PRINT
00450 PRINT
00460 PRINT "FOR WHAT ENVIRONMENT IS THIS ANALYSIS TO BE PERFORMED?"
00470 PRINT "(1) LABORATORY (2) SATELLITE ORBIT (3) GROUND, FIXED"
00480 PRINT "(4) GROUND, PORTABLE (5) AIRBORNE, INHABITED (6) GROUND
00490 PRINT "(7) AIRBORNE, UNINHABITED (8) SATELLITE, LAUNCH"
00500 PRINT "(9) MISSILE ----- INPUT 1,2,3,...,OR 9"
00510 INPUTY
00520 LET Y8=Y
00530 LETUS=""
00540 LET US(8)="NO"
```

FIXED WIREWOUND RESISTORS

```
00550 PRINT
00560 PRINT
00570 PRINT "IS THE ANALYSIS FOR (1) ACCURATE OR (2) POWER WIREWOUND"
00580 PRINT "RESISTORS -- INPUT 1 OR 2"
00590 INPUT Y5
00600 PRINT
00610 LET US(1)="ACCURATE WIREWOUND FIXED RESISTOR (MIL-R-93 (RB))"
00620 LET US(2)="POWER WIREWOUND FIXED RESISTOR (MIL-R-86 (RW))"
00630 IF US(7)="YES" THEN 0670
00640 PRINT "GRADE OF RELIABILITY (1) UPPER OR (2) LOWER -- INPUT 1 OR 2"
00650 INPUT O7
00660 REM
00670 PRINT
00680 LET Y=Y8
00690 PRINT "RESISTANCE (OHMS)="
00700 INPUT R
00710 PRINT
00720 PRINT "IS THE F.R. FOR A MULTIPLE OF LONGEVITY TO BE CALCULATED"
00730 INPUT US(9)
00740 LET Y=Y8
00750 IF US(9)<>"YES" THEN 0790
00760 PRINT
00770 PRINT "MULTIPLE OF LONGEVITY AND PI(L)="
00780 INPUT CS, O9
00790 PRINT
00800 IF US(8)="YES" THEN 0890
00810 PRINT TAB(13); "STRESS CONDITIONS"
00820 PRINT
00830 PRINT "MAX, MIN AND INCREMENT OF STRESS RATIO ="
00840 INPUT D1, M2, S3
00850 PRINT
00860 PRINT "MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)"
00870 INPUT T1, T2, T3
00880 PRINT
00890 FOR I=1 TO 3
00900 READ A(I), B(I), C(I), D(I), E(I), F(I)
00910 NEXT I
00920 FOR I=1 TO 7
00930 READ G(I)
00940 NEXT I
00950 FOR I=1 TO 36
00960 READ H(I), J(I)
00970 NEXT I
00980 LET Y=2*Y
00990 IF Y5=2 THEN 1000
01000 LET S=1
01010 IF R>.1 THEN 1040
01020 LET Y1=1
01030 GOTO 1760
01040 IF R>1 THEN 1070
01050 LET Y1=2
01060 GOTO 1760
01070 IF R>10 GOTO 1100
01080 LET Y1=3
```

FIXED WIREWOUND RESISTORS

```
01090 GOTO 1760
01100 IF R>1E4 THEN 1130
01110 LET Y1=4
01120 GOTO 1760
01130 IF R>1E5 THEN 1160
01140 LET Y1=5
01150 GOTO 1760
01160 IF R>1E6 THEN 1200
01170 LET Y1=6
01180 GOTO 1760
01190 LET Y1=7
01200 LET Y=Y+18
01210 PRINT
01220 PRINT "RESISTANCE CHARACTERISTIC = U OR V"
01230 INPUT US
01240 IF US="V" THEN 1270
01250 LET S=S
01260 GOTO 1280
01270 LET S=3
01280 FOR I=1 TO 35
01290 READ LS(I)
01300 NEXT I
01310 PRINT
01320 PRINT "RESISTOR STYLE = (SEE NOTEBOOK PAGE 63)"
01330 PRINT
01340 INPUT VS
01350 PRINT
01360 FOR I=1 TO 35
01370 IF VS=LS(I) THEN 1430
01380 NEXT I
01390 PRINT "THE STYLE ENTRY IS NOT AS IN THE NOTEBOOK TRY AGAIN"
01400 RESTORES
01410 PRINT
01420 GOTO 1320
01430 FOR J1=1 TO ((I-1)*8)
01440 READ AS
01450 NEXT J1
01460 FOR I=1 TO 8
01470 READ G(I)
01480 PRINT G(I),
01490 NEXT I
01500 IF R>1 THEN 1580
01510 LET Y1=1
01520 IF R>10 THEN 1580
01530 LET Y1=2
01540 GOTO 1760
01550 IF R>100 THEN 1580
01560 LET Y1=3
01570 GOTO 1760
01580 IF R>1000 THEN 1610
01590 LET Y1=4
01600 GOTO 1760
01610 IF R>1E400 TO 1640
01620 LET Y1=5
```

FIXED WIREWOUND RESISTORS

```
01630 GOTO 1760
01640 IF R>1E5 THEN 1660
01650 LET Y1=6
01660 IF R>1.5E5 THEN 1690
01670 LET Y1=7
01680 GOTO 1760
01690 IF R>2E5 THEN 1780
01700 LET Y1=8
01710 GOTO 1760
01720 PRINT "THE VALUE IS TO GREAT FOR THIS ANALYSIS. TRY AGAIN."
01730 RESTORE
01740 RESTORES
01750 GO TO 0690
01760 FOR I=1 TO 6
01770 PRINT
01780 NEXTI
01790 PRINT TAB(13); US(Y5)
01800 PRINT
01810 IF Y5<>2 THEN 1840
01820 PRINT TAB(17); "CHARACTERISTIC " ; US
01830 PRINT
01840 PRINT TAB(10); "RESISTANCE = " ; R
01850 PRINT TAB(17); "ENVIRONMENT CODE = " ; Y8
01860 PRINT
01870 LET US(1)="UPPER"
01880 LET US(2)="LOWER"
01890 PRINT TAB(13); "GRADE OF RELIABILITY = " ; US(C7)
01900 PRINT
01910 IF C9=0 THEN 1940
01920 PRINT TAB(5); "MULTIPLE OF LONGEVITY = " ; C8, "PI(L) = " ; C9
01930 PRINT
01940 FOR I=B2 TO B1 STEP B3
01950 PRINT
01960 PRINT "STRESS RATIO = " ; I
01970 PRINT
01980 PRINT "TEMPERATURE", " FAILURE RATE (1/1000 HRS.)"
01990 PRINT TAB(15); "L(B)" ; TAB(30); "L(R)" ; TAB(50); "L(RL)"
02000 IF C(Y1)<>0 THEN 2050
02010 PRINT
02020 PRINT "THE RESISTANCE FACTOR, PI(RW), FOR THIS RESISTANCE AND WATTE
02030 PRINT "IS NA -- SEE THE NOTEBOOK PAGE 64"
02040 GOTO 2050
02050 PRINT
02060 IF C7=0 THEN N100
02070 LET H=Y-1
02080 LET J=J(Y-1)
02090 GOTO 2100
02100 LET H=Y
02110 LET J=J(Y)
02120 ON Y5 GOTO 2130, 2250
02130 FOR T=T TO T1 STEP T3
02140 LET K=F(S)+EXP(((T+873)/A(S))+D(S))
02150 LET K=K*EXP(((1/B(S))*((T+873)/873)+C(S))+E(S))
02160 LET A=(K*G(Y1)*H+J)*C9
```

FIXED WIREWOUND RESISTORS

```
02170 IF C9<>0 THEN 2200
02180 PRINT T,K,K*G(Y1)*H+J,"NA"
02190 GOTO 2210
02200 PRINT T,K,K*G(Y1)*H+J,A
02210 NEXT T
02220 NEXT I
02230 GOTO 2350
02240 PRINT
02250 FOR T=T2 TO T1 STEPT3
02260 LET K=F(S)*EXP(((T+273)/A(S))+D(S))*EXP((I/B(S))+E(S))
02270 LET A=(K*G(Y1)*H+J)*C9
02280 IF C9<>0 THEN 2310
02290 PRINT T,K,K*G(Y1)*H+J,"NA"
02300 GOTO 2320
02310 PRINT T,K,K*G(Y1)*H+J,A
02320 NEXT T
02330 LET T8=1
02340 GOTO 2220
02350 FOR I=1 TO 3
02360 PRINT
02370 NEXT I
02380 PRINT A(S),B(S),C(S),D(S),E(S),F(S),H,J,G(Y1),C9
02390 FOR I=1 TO 10
02400 PRINT
02410 NEXT I
02420 RESTORE
02430 RESTORE
02440 PRINT "ANOTHER ANALYSIS -- YES OR NO";
02450 INPUT US
02460 IF US<>"NO" THEN 2480
02470 GOTO 2870
02480 LET C9=0
02490 PRINT
02500 PRINT "IS THE ANALYSIS FOR THE SAME ENVIRONMENT -- YES OR NO";
02510 INPUT US
02520 IF US<>"NO" THEN 0430
02530 PRINT
02540 PRINT "IS THE ANALYSIS FOR THE SAME STRESS CONDITIONS -- YES OR NO"
02550 INPUT US(8)
02560 PRINT
02570 PRINT "IS THE ANALYSIS FOR THE SAME RESISTOR TYPE -- YES OR NO"
02580 INPUT US(7)
02590 IF US(7)= "NO" THEN 0550
02600 GOTO 0610
02610 DATA 418,.6,.94,.54,10.7,1.57,653E-6,398,.32,0,2,1,2.75E-4
02620 DATA 310,.32,0,2,1,1.83E-4,4,2,1.1,1,1.7,3,5
02630 DATA 1,0,3,0,1.5,0,4.5,0,6,.002,18,.006,12,.004,36,.012
02640 DATA 15,.005,45,.015,30,.01,90,.03,20,.007,60,.021,60,.02
02650 DATA 180,.06,70,.025,200,.075
02660 DATA 1,0,4,.002,1.2,.0006,5,.0025,3,15E-4,13,65E-4,7,35E-5
02670 DATA 35,175E-4,6,3E-3,30,.015,10,.005,60,.03,12,.006,72,.036
02680 DATA 22,.011,132,.066,30,.015,180,.090
02690 DATARW 10,RW 11,RW 12,RW 13,RW 14,RW 15,RW 16,RW 20,RW 21,RW 22
02700 DATARW 23,RW 24,RW 29,RW 30,RW 31,RW 32,RW 33,RW 34,RW 35,RW 36
```

FIXED WIREWOUND RESISTORS

```
02710 DATARW 37,RW 38,RW 39,RW 47,RW 55,RW 56,RW 67,RW 68,RW 69,RW 70
02720 DATARW 74,RW 78,RW 79,RW 80,RW 81
02730 DATA 1.4,1,1,1,1,1,1,1.2,1.6,1.4,1,1,1,1,1.2,1.6,0
02740 DATA 1.4,1,1,1,1,1.2,1.6,0,0,1.4,1,1,1,1,2,0,0,1.4,1,1,1,1,2,0,0
02750 DATA 1.4,1,1,1,1,1.2,2,0,0,1.8,1.2,1,1.2,1.4,0,0,0,1.6,1.8,1,1,1.6,0
02760 DATA 1.6,1,1,1,1,1.2,2,0,0,1.6,1,1,1,1.2,1.6,0,0,1.6,1,1,1,1.4,0,0
02770 DATA 1.6,1,1,1,1,1.2,0,0,1.6,1.4,1,1,1.4,0,0,0
02780 DATA 1.6,1.2,1,1.2,1.6,0,0,0,1.6,1.2,1,1,1.4,0,0,0,1.6,1,1,1,1.2,0
02790 DATA 1.4,1,1,1,1,1.4,0,0,1.4,1,1,1,1.4,0,0,1.4,1,1,1,1.4,0,0
02800 DATA 1.4,1.2,1,1,1.2,1.5,0,0,1.4,1.4,1,1,1.2,1.6,0,0,1.4,1.2,1,1,1
02810 DATA 1.6,0,1.4,1.4,1,1,1,1.4,1.6,2,1.4,1.4,1,1,1,1.4,1.6,2
02820 DATA 1.6,1.2,1,1,1.4,2,4,0,0,1.6,1.2,1,1,1.2,2,6,0,0
02830 DATA 1.6,1.2,1,1,1,0,0,0,1.6,1.2,1,1,1,0,0,0,1.6,1.2,1,1,0,0
02840 DATA 1.6,1.2,1,1,1.2,1.4,0,0,0,1.6,1.2,1,1,1.2,1.6,0,0
02850 DATA 1.6,1.2,1,1,1,1.6,0,0,1.6,1.2,1,1,1.4,0,0,0,1.6,1.2,1,1.2,1.6
02860 DATA 0,0,0,2,1.6,1,1.2,0,0,0,0
02870 END
```

POTENTIOMETERS (VARIABLE RESISTORS)

```
00010 DIMA(8),B(8),C(8),D(8),E(8),F(8),H(130),G(60),J(10),W(6,6)
00020 DIMV$(10),U$(10),S(20),L(20)
00030 PRINT TAB(12); "FAILURE RATES FOR POTENTIOMETERS"
00040 PRINT
00050 PRINT " DO YOU WISH INSTRUCTIONS --- YES OR NO"
00060 INPUT US
00070 FOR I=1 TO 8
00080 PRINT
00090 NEXT I
00100 IF US="NO" THEN 0480
00110 PRINT "THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE "
00120 PRINT "CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY"
00130 PRINT "A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR POTENTIOMETERS"
00140 PRINT "IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967."
00150 PRINT "WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967."
00160 PRINT
00170 PRINT TAB(12); "INPUT REQUIREMENTS"
00180 PRINT
00190 PRINT
00200 PRINT "ENVIRONMENT - LABORATORY, SATELLITE ORBIT, ETC."
00210 PRINT
00220 PRINT "APPLIED VOLTAGE, RATED VOLTAGE, RESISTANCE (OHMS)"
00230 PRINT
00240 PRINT "NUMBER OF TAPS, NUMBER OF SECTIONS, GANG - FIRST, SECOND, ETC."
00250 PRINT
00260 PRINT "AND THE VALUE OF PI(EFF) F IN ACCORDANCE WITH STEP 3"
00270 PRINT
00280 PRINT "PAGE 78 OF THE NOTEBOOK"
00290 PRINT
00300 PRINT "NOTES:"
00310 PRINT
00320 PRINT "THE USER IS GIVEN THE OPTION OF INPUTING OR HAVING THE"
00330 PRINT "STRESS RATIO CALCULATED BY THE COMPUTER"
00340 PRINT
00350 PRINT "THE NUMBER OF SECTIONS AND"
00360 PRINT "THE VALUE OF PI(EFF) IS NOT REQUIRED IF THE ADJUSTED STRESS"
00370 PRINT "RATIO HAS BEEN PREASSIGNED."
00380 PRINT
00390 PRINT "MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUTS"
00400 PRINT
00410 PRINT "IF ONLY ONE VALUE FOR A GIVEN STRESS CONDITION IS DESIRED"
00420 PRINT "INPUT THAT VALUE FOR MAX, MIN AND INCREMENT"
00430 PRINT
00440 PRINT "DO YOU WISH TO RUN -- YES OR NO"
00450 INPUT US
00460 IF US="NO" THEN 3270
00470 PRINT
00480 PRINT "ENVIRONMENT: (1) LAB, (2) SO, (3) GF, (4) GP,"
00490 PRINT
00500 PRINT "(5) AI, (6) GM, (7) AU, (8) SL, (9) MIL -- INPUT 1,2,...,9"
00510 INPUT Y
00520 LET Y$=Y
00530 PRINT
00540 PRINT "ANALYSIS FOR: (1) PRECISION, (2) SEMI-PRECISION,"
```

POTENTIOMETERS (VARIABLE RESISTORS)

```
00550 PRINT"(3) LOW-PRECISION, (4) NON-WIREWOUND, (5) WIREWOUND,"  
00560 PRINT"(6) ESTABLISHED RELIABILITY OR (7) HIGH POWER"  
00570 INPUT "INPUT 1,2,..., OR 7";  
00580 INPUT Y5  
00590 LET VS(1)="PRECISION POTENTIOMETERS"  
00600 LET VS(2)="SEMI-PRECISION POTENTIOMETERS"  
00610 LET VS(3)="LOW-PRECISION POTENTIOMETERS"  
00620 LET VS(4)="NON-WIREWOUND POTENTIOMETERS"  
00630 LET VS(5)="WIREWOUND POTENTIOMETERS"  
00640 LET VS(6)="ESTABLISHED RELIABILITY POTENTIOMETERS"  
00650 LET VS(6)="HIGH POWER POTENTIOMETERS"  
00660 LET US(8)=VS(Y5)  
00670 PRINT  
00680 PRINT "STRESS RATIO TO BE CALCULATED - YES OR NO";  
00690 INPUT US(7)  
00700 PRINT  
00710 PRINT "GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR  
00720 INPUT C7  
00730 PRINT  
00740 PRINT "IS FAILURE RATE FOR A MULTIPLE OF LONGEVITY TO BE CALCULATED  
00750 PRINT "INPUT YES OR NO"  
00760 INPUT US(5)  
00770 IF US(5)="NO" THEN 00820  
00780 PRINT  
00790 PRINT "MULTIPLE OF LONGEVITY AND PI(L) ="  
00800 INPUT C8,C9  
00810 PRINT  
00820 PRINT "APPLIED VOLTAGE"  
00830 INPUT N5  
00840 LET N6=N5  
00850 PRINT  
00860 PRINT "RATED VOLTAGE"  
00870 INPUT N4  
00880 LET N5=N5/N4  
00890 PRINT  
00900 PRINT "RESISTANCE (OHMS)"  
00910 INPUT R  
00920 PRINT  
00930 PRINT "NUMBER OF TAPS"  
00940 INPUT N1  
00950 PRINT  
00960 IF US(7)="NO" THEN 1090  
00970 PRINT "NUMBER OF SECTIONS"  
00980 INPUT N2  
00990 PRINT  
01000 PRINT "(1) FIRST, (2) SECOND, (3) THIRD, (4) FOURTH, (5) FIFTH"  
01010 PRINT "OR (6) SIXTH IN GANG --- INPUT 1,2, ..., 6"  
01020 INPUT N3  
01030 PRINT  
01040 PRINT "PI(EFF)=? -- SEE STEP 3, PAGE 78")  
01050 INPUT WB  
01060 PRINT  
01070 PRINT "RATED WATTAGE ="  
01080 INPUT WI
```

POTENTIOMETERS (VARIABLE RESISTORS)

```
01090 LETN1=N1+(3/2)/25+.792
01100 IFUS(6)="YES"THEN1180
01110 IFUS(7)="YES"THEN1140
01120 PRINT"MAX, MIN AND INCREMENT OF STRESS RATIO";
01130 INPUT B1,B2,B3
01140 PRINT
01150 PRINT"MAX, MIN AND INCREMENT OF OPER TEMPERATURE - DEG C";
01160 INPUT T1,T2,T3
01170 PRINT
01180 FORI=1TO6
01190 FORJ1=1TO6
01200 READ W(I,J1)
01210 NEXTJ1
01220 NEXTI
01230 FORI=1TO7
01240 READA(I),B(I),C(I),D(I),E(I),F(I)
01250 NEXT I
01260 FOR I=1TO126
01270 READ H(I)
01280 NEXT I
01290 LET Y=(Y5-1)*18+2*Y
01300 IFH(Y)<>0THEN1330
01310 PRINT"THIS POTENTIOMETER IS NOT DESIGNED FOR THIS ENVIRONMENT"
01320 GO TO2740
01330 FORI=1TO52
01340 READG(I)
01350 NEXT I
01360 FORI=1TO7
01370 READ S(I)
01380 NEXTI
01390 FORI=1TO7
01400 IFI=Y5THEN1460
01410 FORJ1=1TOS(I)
01420 READ A8
01430 LETA9=A9+1
01440 NEXTJ1
01450 NEXTI
01460 LETJ1=0
01470 FOR I1=1TOS(I)
01480 LETA9=A9+1
01490 READ A8
01500 IFR<=A8THEN1520
01510 NEXT I1
01520 LETG1=G(A9)
01530 IF A9=52THEN1530
01540 LET A9=A9+1
01550 FORI=A9TO52
01560 READ A8
01570 NEXTI
01580 GOSUB1600
01590 GOTO1650
01600 FOR I=1TO11
01610 READL(I)
01620 NEXTI
```

POTENTIOMETERS (VARIABLE RESISTORS)

```
01630 LET A7=A7+1
01640 RETURN
01650 IF Y5=4 THEN 1680
01660 IF Y5=3 THEN 1680
01670 GOTO 1690
01680 GOSUB 1600
01690 LET J1=0
01700 FOR I=0 TO 1 STEP .1
01710 LET J1=J1+1
01720 IF N5< I+.1 THEN 1770
01730 GOTO 1760
01740 LET J1=J1+1
01750 GOTO 1770
01760 NEXT I
01770 IF A7<>2 THEN 1790
01780 GOTO 1820
01790 LET K1=L(J1)
01800 LET J5=1
01810 GOSUB 1600
01820 IF J5<>1 THEN 1840
01830 GOTO 1850
01840 LET K1=L(J1)
01850 LET A8=A7=A7=J1=J4=J5=0
01860 IF Y5=1 THEN 1910
01870 IF Y5=6 THEN 1970
01880 IF Y5=7 THEN 2060
01890 LET K3=1
01900 GOTO 2080
01910 PRINT "CONSTRUCTION= 1, 2, 3, 4, 5, OR 6"
01920 INPUT K4
01930 FOR I=1 TO K4
01940 READ K3
01950 NEXT I
01960 GOTO 2080
01970 FOR I=1 TO 6
01980 READ K4
01990 NEXT I
02000 PRINT "FAILURE RATE CLASS=(1) S, (2) R, (3) P OR (4) M -- INPUT 1, 2, 3, 4, 5, OR 6"
02010 INPUT K4
02020 FOR I=1 TO K4
02030 READ K3
02040 NEXT I
02050 GOTO 2080
02060 PRINT "CONSTRUCTION CLASS = (1) OPEN OR (2) ENCLOSED - INPUT 1 OR 2"
02070 INPUT K3
02080 PRINT
02090 IF W(N2,N3)<>0 THEN 2130
02100 IF US(7)="NO" THEN 2150
02110 PRINT "PI(GANGED)=NA -- SEE TABLE III-3, PAGE 80 - RADC REL NTB."
02120 GOTO 2740
02130 LET B1=B3=(N6*2/R)/(W1*V(N2,N3)*W2)
02140 PRINT "W(I,J)=", W(N2,N3), "W1=", W1, "W2=", W2
02150 PRINT
02160 PRINT
```

POTENTIOMETERS (VARIABLE RESISTORS)

```

02170 PRINT"-----"
02180 FOR I=1TO6
02190 PRINT
02200 NEXTI
02210 PRINT TAB(13);VS(8)
02220 PRINT
02230 PRINT TAB(10);"RESISTANCE =";R,
02240 PRINT TAB(17);"ENVIRONMENT CODE =";Y8
02250 PRINT
02260 LET VS(1)="UPPER"
02270 LET VS(2)="LOWER"
02280 PRINT TAB(13);"GRADE OF RELIABILITY =";VS(C7)
02290 PRINT
02300 IF C9=0THEN2340
02310 PRINT TAB(5);"MULTIPLE OF LONGEVITY =";C8, "PI(L) =";C9
02320 PRINT
02330 LET N7=24
02340 FOR I=B2TOB1 STEP B3
02350 PRINT
02360 PRINT "STRESS RATIO =";I
02370 PRINT
02380 PRINT "TEMPERATURE, "           FAILURE RATE (%/1000 HRS.)"
02390 PRINT TAB(15);"L(B)";TAB(30);"L(P)";TAB(50);"L(PL)"
02400 PRINT
02410 PRINT
02420 IF C7=2THEN2450
02430 LETH=H(Y-1)
02440 GOTO 02470
02450 LETH=H(Y)
02470 FOR T=T2TOT1STEPT3
02480 LET N7=N7+1
02490 LET K=F(Y5)*EXP(((T+273)/A(Y5))+D(Y5))
02500 LET K=K*EXP(((I/B(Y5))*((T+273)/273)+C(Y5))+E(Y5))
02510 IF C9<>0THEN2540
02520 PRINT T, K, K*G1*K1*K3*H*N1, "NA"
02530 GOTO 2550
02540 PRINT T,K,K*G1*K1*K3*H*N1,K*G1*K1*K3*H*N1*C9
02550 IF N7<60THEN2640
02600 LET N7=10
02610 FOR I=1TO12
02620 PRINT
02630 IF I<>6THEN02632
02631 PRINT"-----"
02632 NEXTI4
02640 NEXT T
02650 NEXT I
02651 IF N7=60THEN02660
02652 FOR I=N7 TO 66
02653 PRINT
02654 NEXTI
02655 PRINT"-----"
02660 GOTO 2660
02670 PRINT
02680 FOR I=1TO3

```

POTENTIOMETERS (VARIABLE RESISTORS)

```

02690 PRINT
02700 NEXT I
02740 FOR I=1TO10
02750 PRINT
02760 NEXT I
02770 RESTORE
02780 RESTORES
02790 PRINT"ANOTHER ANALYSIS -- YES OR NO";
02800 INPUT US
02810 IF US<>"NO"THEN2830
02820 GOTO3270
02830 LET C9=0
02840 PRINT
02850 PRINT"SAME ENVIRONMENTS -- YES OR NO";
02860 INPUT US
02870 IF US="NO"THEN0480
02880 LET Y=1
02890 PRINT
02900 PRINT"SAME STRESS CONDITIONS -- YES OR NO";
02910 INPUT US(8)
02920 PRINT
02930 PRINT"SAME RESISTOR TYPE - YES OR NO";
02940 INPUT US(6)
02950 PRINT
02960 IF US(6)="NO"THEN0530
02970 GOTO0680
02980 DATA1,0,0,0,0,0,0
02990 DATA.75,.6,.6,.6,.6,.6,.75,.5,.6,.6,0,0,.75,.5,.5,.6,0,0
03000 DATA.75,.5,.4,.5,.6,0,.75,.5,.4,.4,.5,.6
03010 DATA356,2.74,3.51,4.45,1,735E-5,355,1.44,4.46,5.28,1,358E-5
03020 DATA373,2.32,3.3,9.3,1,616E-5,460,2.69,8.46,7.3,1,423E-4
03030 DATA371,2.93,6.35,5.47,671,357E-5,371,2.92,6.35,5.47,671,139E-6
03040 DATA377,1.47,2.83,4.66,1,481E-5
03050 DATA1,5,2,4,5,25,8,40,10,50,10,50,15,60,120,600,150,750
03060 DATA1,2,0,0,6,12,8,16,15,30,20,40,0,0,0,0,0,0
03070 DATA1,5,0,0,10,50,40,200,50,250,50,250,60,300,0,0,100,500
03080 DATA1,3,0,0,3,9,6,18,6,18,10,40,15,60,0,0,80,150
03090 DATA1,3,0,0,3,9,6,18,6,18,8,32,12,48,0,0,60,120
03100 DATA1,0,0,0,3,0,6,0,6,0,8,0,12,0,0,0,60,0
03110 DATA1,2,0,0,6,12,8,16,15,30,20,40,0,0,0,0,0,0
03120 DATA 2,1-2,1,1-1,1-4,2,2-5,3-5,2,1-4,1-2,1,1-4,2
03130 DATA1-5,1-1,1-1,1-2,1-4,1-8,2-7,1-4,1-1-1,1-2,1-4,1-3
03140 DATA 4-2,2,1-6,1-1,1-1-1,1-1,1-8,5,10,4-2,2,1-6,1-1-1,1-1,1-8,5,10
03150 DATA2,1-4,1-8,1,1-4,2
03160 DATA8,6,7,7,9,9,6
03170 DATA 19.998,49.998,1E4,2E4,5E4,1E5,2E5,5E5
03180 DATA1.998,4.998,9.998,2E3,5E3,1E4
03190 DATA 19.998,199.999,5E4,1E5,2E5,5E5,1E6
03200 DATA 19.998,49.998,5E4,1E5,2E5,5E5,1E6
03210 DATA 19.998,49.998,99.998,199.99999,1E4,2E4,5E4,1E5,2E5
03220 DATA 19.998,49.998,99.998,199.998,1E4,2E4,5E4,1E5,2E5
03230 DATA1.9989,4.9989,9.9989,2E3,5E3,10E3
03240 DATA1.4,1-1,1-05,1,1,1,1-1,1-82,1-4,2
03250 DATA 1-2,1,1,1,1,1,1,1,1,1-05,1-2

```

POTENTIOMETERS (VARIABLE RESISTORS)

03267 DATA 4, 2, 1, 6, 3, 1+5, 1, 10, 50, 300
03270 BMT

CAPACITORS

```
00010 DIMSS(10),FS(20),B(500),A(500),C(500)
00020 DIMX(15)
00030 PRINTTAB(15);"CAPACITOR FAILURE RATE"
00040 PRINT
00050 PRINT"DO YOU WISH INSTRUCTIONS -- YES OR NO?"
00060 INPUTFS(20)
00070 PRINT
00080 LET FS(1)="PAPER FOIL, PAPER MYLAR, PAPER, MYLAR-METALLIZED"
00090 LETFS(2)="MYLAR OR TELON"
00100 LETFS(3)="PLASTIC FILM (NON-METALLIC CASE)"
00110 LET FS(4)="POLYSTYRENE"
00120 LETFS(5)="TANTALUM FOIL"
00130 LETFS(6)="TANTALUM, WET SLUG"
00140 LETFS(7)="TANTALUM, SOLID, DIELECTRIC"
00150 LET FS(8)="ALUMINUM, WET FOIL"
00160 LET FS(9)="MICA, MOLOUED"
00170 LETFS(10)="MICA, DIPPED"
00180 LETFS(11)="MICA, BUTTON"
00190 LETFS(12)="CERAMIC, LOW K"
00200 LETFS(14)="CERAMIC, HIGH K"
00210 LETFS(15)="VARIABLE, CERAMIC"
00220 LETFS(16)="VARIABLE, GLASS PISTON"
00230 LETFS(12)="GLASS, PORCELAIN"
00240 IF FS(20)<>"YES" THEN 0070
00250 PRINT"THIS PROGRAM CALCULATES THE FAILURE RATE OF CAPACITORS IN"
00260 PRINT"ACCORDANCE WITH THE RADCOM RELIABILITY NOTEBOOK (SEPT 1967)."
00270 PRINT
00280 PRINT
00290 PRINT TAB(13);"INPUT REQUIREMENTS IF APPLICABLE"
00300 PRINT
00310 PRINT"1", TAB(11);"CAPACITOR TYPE AND CODE"
00320 PRINT
00330 PRINT "CODE"; TAB(25);"TYPE"
00340 PRINT
00350 FOR I=1 TO 16
00360 PRINT I,FS(I)
00370 NEXT I
00380 PRINT
00390 PRINT
00400 PRINT"2", TAB(11);"ENVIRONMENT AND CODE"
00410 PRINT
00420 PRINTTAB(15);"(1) LO, (2) SO, (3) GP, (4) GP, (5) AI,"
00430 PRINT
00440 PRINTTAB(15);"(6) GM, (7) AU, (8) SL, AND (9) M"
00450 PRINT
00460 PRINT "3", TAB(11);"RELIABILITY LEVELS AND CODES"
00465 PRINT
00470 PRINTTAB(15);"(1) L, (2) M, (3) N, (4) R, (5) S"
00480 PRINT
00490 PRINT"4", TAB(11);"CASE DIM & LENGTH (IN.)"
00500 PRINT
00510 PRINT"5", TAB(11);"CIRCUIT RESISTANCE (OHMS/VOLT)"
00520 PRINT
00530 PRINT"6", TAB(11);"CIRCUIT STYLE --- CY10, CY20, ETC."
```

CAPACITORS

```
00540 PRINT
00550 PRINT"?" TAB(11); "CAPACITANCE (UUF)"
00560 PRINT
00570 PRINT "S"; TAB(11); "MAX., MIN. AND INCREMENT OF STRESSES ---"
00580 PRINT TAB(11); "(STRESS RATIO AND OPERATING TEMPERATURE - DEG C)"
00590 PRINT
00600 PRINT TAB(11); "NOTE: IF ONLY ONE VALUE IS TO BE ENTERED FOR A STR"
00610 PRINT TAB(11); "(THAT) VALUE FOR MAX, MIN AND INCREMENT"
00620 PRINT
00630 PRINT "DO YOU WISH TO RUN --- YES OR NO"
00640 INPUTFS(19)
00650 PRINT
00660 IF FS(19)<>"YES" THEN 3050
00670 PRINT"INPUT ENVIRONMENT CODE"
00680 INPUTYS
00690 PRINT
00700 PRINT "INPUT CAPACITOR TYPE CODE"
00710 INPUT A1
00720 PRINT
00730 PRINT "ANALYSIS FOR (1) UPPER OR (2) LOWER QUALITY GRADE ?"
00740 PRINT "INPUT 1 OR 2"
00750 INPUT A7
00760 FOR I=1 TO 9
00770 READSS(I)
00780 NEXT I
00790 IF A1<>1 THEN 0820
00800 GOSUB1590
00810 GOTO0910
00820 IF A1<>7THEN 0850
00830 GOSUB1870
00840 GOTO0910
00850 IF A1<>12THEN 0880
00860 GOSUB2140
00870 GOTO0910
00880 FOR I=1 TO 32
00890 READ,L,L
00900 NEXTI
00910 PRINT
00920 PRINT
00930 PRINT "INPUT MAX, MIN AND INCREMENT OF STRESS RATIO"
00940 INPUT B1,B2,B3
00950 PRINT
00960 PRINT "INPUT MAX, MIN AND INCREMENT OF OPER. TEMPERATURE (DEGREES"
00970 INPUT T1,T2,T3
00980 PRINT
00990 GOSUB2390
01000 PRINT TAB(13); FS(A1); " CAPACITOR"
01010 PRINT
01020 PRINT "ENVIRONMENT CODE ="; Y5,
01030 IF A7=2 THEN 1060
01040 PRINT "UPPER GRADE"
01050 GOTO1070
01060 PRINT "LOWER GRADE"
01070 PRINT
```

CAPACITORS

```

01880 IF A1<>100 TO 1110
01890 PRINT "RELIABILITY LEVEL ="; SS; "CASE DIM. AND LENGTH (IN) ="; X4,X
01180 GOTO 1170
01110 IF A1<>7 THEN 1150
01120 PRINT "RELIABILITY LEVEL ="; SS; "CIRCUIT RES. (OHMS/VOLT) ="; X
01130 PRINT
01140 GOTO 1170
01150 IF A1<>1 THEN 1170
01160 PRINT "RESISTOR STYLE ="; SS; "CAPACITANCE (UUF) ="; X3
01170 PRINT
01180 PRINT
01190 IF A1=1 THEN 1230
01200 FOR I=1 TO (41*(A1-1))
01210 READ D
01220 NEXT I
01230 TO 105
01240 REAL A(1)
01250 NEXT I
01260 FOR I=1 TO 5
01270 READ B(I),B(I),C(I),C(I)
01280 NEXT I
01290 FOR B4=B2 TO B1 STEP B3
01300 PRINT "STRESS RATIO ="; B4
01310 PRINT
01320 PRINT "TEMPERATURE", "FAILURE RATE (S/1000HRS.)"
01330 PRINT " B (0)", TAB(15),"L(B)", TAB(30),"L(P)"
01340 PRINT
01350 IF X1<>8 THEN 1370
01360 LET X1=X2=1
01370 FOR T=T2 TO T1 STEP T3
01380 LET A6=A(1)+((B4/A(2))+A(3)+1)*EXP(((T+873)/A(4))+A(5))
01390 PRINT T,A6,A6+B(A7)*X1*X2+C(A7)
01400 NEXT T
01410 PRINT
01420 NEXT B4
01430 GOSUB 390
01440 RESTORE
01450 RESTORE
01460 PRINT "ANOTHER ANALYSIS -- YES OR NO")
01470 INPUT SS
01480 IF SS="NO" THEN 3850
01490 PRINT
01500 PRINT "SAME ENVIRONMENT -- YES OR NO")
01510 INPUT SS
01520 PRINT
01530 IF SS="NO" THEN 8670
01540 PRINT "SAME CAPACITOR TYPE -- YES OR NO")
01550 INPUT SS
01560 IF SS="NO" THEN 8690
01570 GOTO 8720
01580 GOTO 3850
01590 PRINT "RELIABILITY LEVEL = (1) L, (2) M, (3) N, (4) R, OR (5) S"
01600 PRINT "INPUT IS 2, 3, 4, OR 5")
01610 INPUT X1

```

CAPACITORS

```
01620 LETSS=SS(X1)
01630 FOR I=1 TO 5
01640 READ X(I)
01650 NEXT I
01660 LETX1=X(X1)
01670 PRINT
01680 PRINT "INPUT CASE DIM. (IN) AND LENGTH (I)"
01690 INPUT X2,X3
01700 LETX4=X2
01710 FOR I=1 TO 9
01720 READ X(I)
01730 NEXT I
01740 LET X(9)=2
01750 FOR I=1 TO 8
01760 READ D,L
01770 IF X2<=D THEN 1790
01780 GOTO 1800
01790 IF X3<=L THEN 1820
01800 NEXT I
01810 LET I=I+1
01820 LET X9=X(I)
01830 FOR J=I TO 48
01840 READ D,L
01850 NEXT J
01860 RETURN
01870 PRINT
01880 FOR I=1 TO 15
01890 READ X1,X1
01900 NEXT I
01910 READ X(1),X(2),X(3),X(4),X(5)
01920 PRINT "RELIABILITY LEVEL = (1) L, (2) M, (3) H, (4) R OR (5) S"
01930 INPUT K1
01940 LETSS=SS(X1)
01950 LET X1=X(X1)
01960 PRINT
01970 PRINT "CIRCUIT RESISTANCE (OHMS/VOLT) ="
01980 INPUT X2
01990 LET X3=X2
02000 FOR I=1 TO 8
02010 READ D,L
02020 IF X2=D THEN 2040
02030 NEXT I
02040 LET X3=L
02050 IF I=8 THEN 2090
02060 FOR J=I+1 TO 8
02070 READ D,L
02080 NEXT J
02090 FOR I=1 TO 9
02100 READ D,L,L,L,L
02110 NEXT I
02120 PRINT
02130 RETURN
02140 PRINT
02150 FOR I=1 TO 17
```

CAPACITORS

```

02160 READL,L,L
02170 NEXTI
02180 PRINT"RESISTOR STYLE = (1) CY15, (2) CY15, (3) CY28 OR (4) CY30"
02190 INPUTL
02200 LETSS=SS(L+5)
02210 PRINT
02220 PRINT "CAPACITANCE (IN UUF) ="
02230 INPUTX1
02240 LETX2=1
02250 LETX3=X1
02260 FORI=1 TO9
02270 READR(1),X(2),X(3),X(4),D
02280 IFJ7<>0 THEN2300
02290 IFX1>X(L) THEN2300
02300 LETJ7=1
02310 LETX1=D
02320 NEXTI
02330 IFX1<>0 THEN2300
02340 PRINT"THE MULT.FACTOR FOR THIS STYLE AND CAP = NA, TRY AGAIN"
02350 RESTORE
02360 RESTORES
02370 GOTO760
02380 RETURN
02390 FORI=1 TO6
02400 PRINT
02410 NEXTI
02420 PRINT"XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX"
02430 FORI=1 TO6
02440 PRINT
02450 NEXTI
02460 RETURN
02470 DATA1,N,N,R,S,CY15,CY15,CY28,CY30
02480 DATA 3,1,-3,-1,-03,-8,-8,-2,-3,-3,1,1,1,8
02490 DATA .275,.75,.318,.575,-4,.575,-4,1.375,.562,1.625,.67,1.625
02500 DATA .75,2.125,.75,2.375
02510 DATA3,1,-3,-1,-03,-1,-2,-8,-4,-6,-6,-4,-8,-3,1,-2,2,-1,3,-8
02520 DATA10,0,0,0,-2,20,240,650,0,-4,-30,360,1000,0,-6
02530 DATA39,470,1300,4300,0,47,560,1800,5600,1,150,650,3600,10000,2
02540 DATA 150,520,5100,0,3,900,910,0,0,4,300,1200,0,0,5
02550 DATA 1E-5,-4,5,379,20,1,10,0,1E-4,1-1,10,1E-5,1E-4,0,20,2E-5,2E-4
02560 DATA 4,40,1E-4,1E-3,4,40,1E-4,1E-3,4,40,1E-4,1E-3,15,150,5E-4,5E-3
02570 DATA 18,180,5E-4,6E-3,20,200,1E-3,1E-8
02580 DATA20E-5,-75,5,377,20-6,1,6,0,5E-5,11E-1,6,5E-4,5E-3,0,12,-.001,0
02590 DATA4,24,-.002,-.02,4,24,-.002,-.02,4,24,-.002,-.02,15,90,-.05,-.05
02600 DATA16,160,-.006,-.006,20,120,-.01,-.1
02610 DATA 32E-5,-73,5,379,17-4,1,5,0,-.0005,1,-1,5,1E-4,-.001
02620 DATA2,18,2E-4,-.002,4,20,5E-4,-.005,4,20,5E-4,-.005,4,20,5E-4,-.005
02630 DATA15,75,-.002,-.02,15,90,-.003,-.03,20,100,-.003,-.03
02640 DATA438E-9,-.005,5,40,1,-.2,1,0,1E-4,-.002,1,-1,2E-5,2E-4
02650 DATA .4,2,4E-5,4E-4,-.8,4,-.0001,-.001,-.8,4,1E-4,-.001
02660 DATA-.8,-4,1E-4,1E-3,3,15,4E-4,4E-3,3,-6,18,-.0005,-.005,4,10,6E-4,6E-3
02670 DATA13E-4,-.52,3,358,8,-8,1,0,0,-.001,1,-1,5,2E-4,2E-3
02680 DATA2,18,-.0004,-.003,6,30,12E-4,12E-3,-6,30,12E-4,12E-3,6,30,12E-4,0
02690 DATA20,180,4E-3,-.04,25,125,-.005,-.05,30,150,-.006,-.06

```

CAPACITORS

```

0 2700 DATA17E-4, .32, 3, 369, 9.6, .1, 1, 0, 5E-4, .11, 1, 1, .0005, .005, .2, 2, .001, 0
0 2710 DATA, 4, 4, 2E-3, .02, .4, 4, 2E-3, .02, .4, 4, 2E-3, .02, 1.5, 15, 8E-3, .06
0 2720 DATA2, 20, .81, .1, 3, 30, .15E-1, .15
0 2730 DATA574E-6, .4, 3, 381, 14.3, 1, 10, 0, 5E-4, 1, 1, 10, 5E-5, 5E-4
0 2740 DATA2, 20, 1E-4, 1E-3, 4, 40, 2E-4, 2E-3, 4, 40, 2E-4, 2E-3, 4, 40, 2E-4, 2E-3
0 2750 DATA 15, 150, .0008, 8E-3, 18, 180, 9E-4, 9E-3, 20, 200, 1E-3, .01
0 2760 DATA 418E-6, .55, 3, 288, 5.9, 1, 10, 0, 2E-3, 1, 1, 10, 5E-4, 2E-3
0 2770 DATA2, 20, 5E-4, 2E-3, 12, 60, 3E-3, .01, 12, 60, 3E-3, .01, 12, 60, 3E-3, .01
0 2780 DATA38, 160, 8E-3, .03, 35, 180, .01, .04, 40, 200, .012, .05
0 2790 DATA, 526 E-10, .37, 3, 25, 1, 1, 5, 0, 5E-5, 2, 10, 1E-5, 1E-4, 4, 20, 2E-5, 2E-4
0 2800 DATA6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4, 24, 120, 12E-5, 12E4
0 2810 DATA 16, 130, 13E-5, 13E-4, 30, 150, 15E-5, 15E-4
0 2820 DATA831E-13, .37, 3, 15, 1, 1, 5, 0, 5E-5, 2, 10, 1E-5, 1E-4, 4, 20, 2E-5, 2E-4
0 2830 DATA6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4
0 2840 DATA 24, 120, 12E-5, 12E-4, 26, 130, 13E-5, 13E-4, 30, 150, 15E-5, 15E-4
0 2850 DATA 53E-5, .4, 3, 348, 5.3
0 2860 DATA1, 5, 0, .0002, 2, 10, .0003, .0015, 4, 20, .0006, .003, 6, 40, .001, .007
0 2870 DATA6, 40, .001, .007, 6, 40, .001, .007, 24, 160, .004, .03, 86, 170, .004, .03
0 2880 DATA 30, 180, .005, .04
0 2890 DATA 195E-12, .31, 3, 25, 1, 1, 5, 0, 5E-5, 2, 10, 1E-5, 1E-4, 4, 20, 2E-5, 2E-4
0 2900 DATA6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4, 6, 40, 3E-5, 3E-4, 24, 120, 12E-5, 12E4
0 2910 DATA26, 130, 13E-5, 13E-4, 30, 150, 15E-5, 15E-4
0 2920 DATA 361E-12, .3, 3, 25, 1, 1, 10, 0, 5E-5, 2, 20, 1E-5, 1E-4, 4, 4, 2E-5, 2E-4
0 2930 DATA6, 60, 3E-5, 3E-4, 6, 60, 3E-5, 3E-4, 6, 60, 3E-5, 3E-4, 24, 240, 12E-5, 12E4
0 2940 DATA26, 260, 13E-5, 13E-4, 30, 300, 15E-5, 15E-4
0 2950 DATA 54E-6, .3, 3, 348, 5.7, 1, 10, 0, 5E-4, 1, 1, 10, 5E-5, 5E-4
0 2960 DATA 2, 20, 1E-4, 1E-3, 4, 40, 2E-4, 2E-3, 4, 40, 2E-4, 2E-3, 4, 40, 2E-4, 2E-3
0 2970 DATA16, 100, .0006, 5E-3, 12, 120, 6E-4, 6E-3, 15, 150, 6E-4, 6E-3
0 2980 DATA 15E-5, .17, 3, 348, 10, 1, 1, 20, 0, 4E-3, 2, 40, 2E-4, 4E-3
0 2990 DATA4, 60, 4E-4, 5E-3, 5, 160, 1E-3, .02, 6, 160, 1E-3, .02, 6, 160, 1E-3, .02
0 3000 DATA50, 1000, .01, .2, 60, 1200, 15E-3, .3, 70, 1400, .02, .4
0 3010 DATA146E-9, .33, 3, 33, 1, 1E-1, 1, 0, 15E-4, 15E-2, 1, 5, 15E-5, 15E-4
0 3020 DATA .3, 3, 3E-4, 3E-3, 1, 10, 1E-3, .01, 1, 10, .001, .01, 1, 10, .001, .01
0 3030 DATA5, 60, 5E-3, .06, 10, 100, .01, .1, 10, 120, .012, .12
0 3040 RETURN
0 3050 END

```

CONNECTORS

```
00010 DIMA(10),B(10),C(10),D(10),E(10),H(18),US(20)
00020 GOSUB 1530
00030 PRINTTAB(15); "CONNECTOR FAILURE RATE"
00040 PRINT
00050 PRINT"INSTRUCTIONS -- YES OR NO?"
00060 INPUTUS
00070 PRINT
00080 IFUS<>"YES"THEN0540
00090 PRINT"THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE FAILURE
00100 PRINT"OF CONNECTORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTE"
00110 PRINT" SEPT 1967."
00120 PRINT
00130 PRINTTAB(15); "INPUT REQUIREMENTS AND CODES"
00140 PRINT
00150 PRINT"1"; TAB(11); "ENVIRONMENT "
00160 PRINT
00170 PRINTTAB(11); "(1) LABORATORY, (2) GROUND, FIXED, (3) GROUND PORTABLE
00180 PRINTTAB(11); "(4) GROUND, MOBILE, (5) AIRBORNE, INHABITED,"
00190 PRINTTAB(11); "(6) AIRBORNE, UNINHABITED, (7) SATELLITE ORBIT"
00200 PRINTTAB(11); "(8) SATELLITE LAUNCH, (9) MISSILE"
00210 PRINT
00220 PRINT"2"; TAB(11); "CONNECTOR IDENTIFIER"
00230 PRINT
00240 PRINTTAB(11); "ONLY FOR IDENTIFICATION -- NOT USED FOR CALCULATIONS"
00250 PRINT
00260 PRINT"3"; TAB(11); "RELIABILITY GRADE -- UPPER OR LOWER"
00270 PRINT
00280 PRINT"4"; TAB(11); "MATERIAL -- (1) A, (2) B, (3) C, (4) D"
00290 PRINT
00300 PRINT"5"; TAB(11); "EXPECTED CURRENT (AMPS)"
00310 PRINT
00320 PRINT"6"; TAB(11); "NUMBER OF ACTIVE PINS"
00330 PRINT
00340 PRINT"7"; TAB(11); "CYCLES/1000 HRS."
00350 PRINT
00360 PRINT"8"; TAB(11); "MAX, MIN AND INCREMENT OF AMBIENT TEMPERATURE"
00370 PRINTTAB(11); "(DEGREES C)"
00380 PRINT
00390 PRINT"9"; TAB(11); "PIN GAGE -- (1) 22, (2) 20, (3) 16, (4) 12"
00400 PRINT
00410 PRINT"NOTES:"
00411 PRINT
00412 PRINTTAB(11); "CODES = NUMBERS IN BRACKETS ( )"
00420 PRINT
00430 PRINTTAB(11); "IF ONLY ONE VALUE FOR AMBIENT TEMPERATURE IS TO"
00440 PRINTTAB(11); "ENTERED, INPUT THAT VALUE FOR MAX, MIN AND INCREMENT"
00450 PRINT
00460 PRINTTAB(11); "INPUTS TO THIS PROGRAM ARE ENTERED THROUGH THE KEYBOARD"
00470 PRINTTAB(11); "THEY ARE QUERIED."
00480 PRINT
00482 PRINTTAB(11); "MANY OUTPUTS ARE IN ACCORDANCE WITH THE INPUT CODES"
00490 PRINT
00500 PRINT"RUN -- YES OR NO?"
00510 INPUTUS
```

CONNECTORS

```

0 0520 IFUS="NO"THEN1650
0 0530 GO SUB1530
0 0540 PRINT"INPUT:"
0 0550 PRINT
0 0560 PRINT"ENVIRONMENT CODE = ??? (1) LAB, (2) GF, (3) GP, (4) GM, "
0 0570 PRINT"(5) AI, (6) AU, (7) SO, (8) SL OR (9) M -- INPUT 1,2,..., @
0 0580 INPUT Y5
0 0600 PRINT
0 0610 PRINT"CONNECTOR IDENTIFIER =";
0 0620 INPUTUS(4)
0 0630 PRINT
0 0640 PRINT"(1) UPPER OR (2) LOWER GRADE -- INPUT 1 OR 2";
0 0650 INPUT Y3
0 0655 LETY5=Y5*2
0 0660 PRINT
0 0670 FORI=1 TO18
0 0680 READH(I)
0 0690 NEXTI
0 0700 IFY3=2 THEN00725
0 0710 LETH=H(Y5-1)
0 0720 GOT00730
0 0725 LETH=H(Y5)
0 0730 LETY5=Y5/2
0 0740 IFUS(3)="YES"THEN00910
0 0760 PRINT" MATERIAL = ? (1) A, (2) B, (3) C OR (4) D";
0 0770 INPUTJ1
0 0780 PRINT
0 0790 PRINT"EXPECTED CURRENT (AMPS)="
0 0800 INPUTJ3
0 0810 PRINT
0 0820 PRINT"NUMBER OF ACTIVE PINS AND CYCLES/1000HRS.="
0 0830 INPUTJ4,J5
0 0840 PRINT
0 0850 PRINT"PIN GAGE = (1) 22, (2) 20, (3) 16, OR (4) 12";
0 0860 INPUTJ6
0 0870 PRINT
0 0880 IFUS(5)="YES"THEN00910
0 0890 PRINT"MAX, MIN AND INCREMENT OF AMBIENT TEMPERATURE (DEGREES C)="
0 0900 INPUTT2,T1,T3
0 0910 FORI=1 TO4
0 0920 READ A(I),B(I),C(I),D(I),E(I)
0 0930 NEXTI
0 0940 FORI=1 TO4
0 0950 IFI>J6GOTO00980
0 0960 READX1,Y1,X2,Y2
0 0970 GOT00990
0 0980 READ Y,Y,Y,Y
0 0990 NEXTI
0 1000 LETY=(LOG(Y2)-LOG(Y1))*(LOG(J3)-LOG(X2))/(LOG(X2)-LOG(X1))
0 1010 LET Y=Y+LOG(Y2)
0 1020 LETY=EXP(Y)
0 1030 IFJ5<10 THEN1050
0 1040 LET C=J4*.0001*EXP(J5/100)
0 1050 LETP=EXP((J4/10)+.545)

```

CONNECTORS

```
01060 GOSUB1530
01070 PRINT
01080 PRINTTAB(17);US(4);" CONNECTOR"
01090 LETUS(1)="UPPER"
01100 LETUS(2)="LOWER"
01110 PRINT
01120 PRINTTAB(10);"MATERIAL CODE ="$J1;SPC(12);"PIN GAGE CODE ="$J6
01130 PRINT
01140 PRINTTAB(10);US(Y3);" GRADE";SPC(10);"ENVIRONMENT CODE ="$Y5
01150 PRINT
01160 PRINT"NUMBER OF ACTIVE PINS ="$J4;SPC(15);"CYCLES ="$J5
01170 PRINT
01180 PRINTTAB(17);"EXPECTED CURRENT ="$J3;" AMPS"
01190 PRINT
01200 PRINTTAB(7);"TEMPERATURE";SPC(12);"FAILURE (%/1000 HR.)"
01210 PRINT
01220 PRINT"A(I)=""A(J1)", "B(I)=""B(J1)", "C(I)=""C(J1)", "D(I)=""D(J1)"
01230 PRINT"E(I)=""E(J1)", "Y=""Y", "C=""C", "H=""H", "P=""P"
01240 PRINT"AMBIENT", "OPERATING", "L(B)", "L(C0)"
01250 PRINT
01260 FOR T=T1 TO T2 STEP T3
01270 LET Y1=Y
01280 LET Y1=Y1+T+273
01290 LET Y4=(1/(Y1/C(J1)))+(Y1/E(J1))+D(J1)
01300 LET J9=A(J1)+EXP(Y4)
01310 LET Y1=Y1-273
01320 PRINTT,Y1,J9,H*P+C
01330 NEXTT
01340 LET C=0
01350 RESTORE
01360 GOSUB 1530
01370 PRINT"ANOTHER ANALYSIS -- YES OR NO"
01380 INPUTUS(3)
01390 IF US(3)="NO" THEN 1650
01400 PRINT
01410 PRINT"SAME AMBIENT TEMPERATURE -- YES OR NO"
01420 INPUT US(5)
01430 PRINT"SAME ENVIRONMENT -- YES OR NO"
01440 INPUT US(3)
01450 IF US(3)="NO" THEN 0850
01460 PRINT
01470 PRINT"SAME CONNECTOR -- YES OR NO"
01480 INPUTUS(3)
01490 IF US(3)="NO" THEN 0600
01500 PRINT
01510 GOTO 0640
01520 GOTO 1650
01530 FOR I=1 TO 6
01540 PRINT
01550 NEXTI
01560 PRINT"-----"
01570 FOR I=1 TO 6
01580 PRINT
01590 NEXTI
```

CONNECTORS

```
01600 RETURN
01610 DATA 1, 10, 3, 12, 4, 15, 8, 16, 4, 15, 10, 20, 2, 10, 15, 30, 15, 30
01620 DATA 324E-5, -1, -1592, 5, 36, 473, +869, -1, -2073, 4, 66, 423
01630 DATA .018, -1, -1298, 425E-2, 373, +123, -1, -1588, 8, 4, 72, 358
01640 DATA 4, 13, 7, 36, 5, 12, 8, 30, 7, 10, 20, 70, 15, 15, 40, 70
01650 END
```

RELAYS

```
00010 DIM X(10), Y(20), US(10), ZS(10), H(40), J(40), K(10)
00020 DIM A(3), B(3), C(3), L(5), ES(10)
00030 GO SUB2280
00040 PRINT TAB(15); "FAILURE RATES OF RELAYS"
00050 PRINT
00060 PRINT "INSTRUCTION -- YES OR NO";
00070 INPUT US
00080 IF US<>"YES" THEN 0530
00085 PRINT
00090 PRINT "THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE"
00100 PRINT "FAILURE RATE OF RELAYS IN ACCORDANCE WITH THE RADCOM RELIABILITY"
00110 PRINT "NOTEBOOK (SEPT 1967)."
00115 PRINT
00120 PRINT TAB(15); "INPUT REQUIREMENTS AND CODES"
00124 PRINT
00130 PRINT "1) TAB(11); "ENVIRONMENT"
00135 PRINT
00140 PRINT TAB(11); "(1) LABORATORY"; SPC(4); "(2) SATELLITE ORBIT"
00150 PRINT TAB(11); "(3) GROUND FIXES"; SPC(4); "(4) GROUND PORTABLE"
00160 PRINT TAB(11); "(5) AIRBORNE INHABITED"; SPC(4); "(6) GROUND MOBILE"
00170 PRINT TAB(11); "(7) AIRBORNE UNINHABITED"; SPC(4); "(8) SATELLITE LAB"
00180 PRINT TAB(11); "(9) MISSILE"
00190 PRINT
00200 PRINT "2) TAB(11); "CONTACT FORM AND QUANTITY"
00210 PRINT
00220 PRINT TAB(11); "(1) SPST"; SPC(3); "(2) DPST"; SPC(3); "(3) SPDT"
00230 PRINT TAB(11); "(4) 3PST"; SPC(3); "(5) 4PST"; SPC(3); "(6) DPDT"
00240 PRINT TAB(11); "(7) 3PDT"; SPC(3); "(8) 4PDT"; SPC(3); "(9) 6PDT"
00250 PRINT
00260 PRINT "3) TAB(11); "PART IDENTIFIER"
00270 PRINT TAB(11); "ONLY FOR PART IDENTIFICATION - NOT USED IN CALCULATION"
00280 PRINT
00290 PRINT "4) TAB(11); "GRADE OF RELIABILITY -- (1) UPPER, (2) LOWER"
00300 PRINT
00310 PRINT "5) TAB(11); "CYCLES/HR"
00320 PRINT
00330 PRINT "6) TAB(11); "LOAD TYPE - (1) RESISTIVE, (2) INDUCTIVE"
00340 PRINT TAB(11); "(3) LAMP"
00350 PRINT
00360 PRINT "7) TAB(11); "TEMPERATURE RATING - (1) 85 OR (2) 105 DEGREES"
00370 PRINT
00380 PRINT "8) TAB(11); "MAX, MIN AND INCREMENT OF STRESS RATIO -"
00390 PRINT TAB(11); "LOAD/RATED RESISTANCE LOAD"
00400 PRINT
00410 PRINT "9) TAB(11); "MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE"
00420 PRINT
00430 PRINT "NOTES:"
00440 PRINT
00450 PRINT TAB(11); "IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS INPUT"
00460 PRINT TAB(11); "THAT VALUE FOR MAX,MIN AND INCREMENT OF THE STRESS"
00470 PRINT
00480 PRINT TAB(11); "MANY OF THE OUTPUTS ARE IN ACCORDANCE WITH THE INPUT"
00490 PRINT
00500 PRINT "DO YOU WISH TO RUN -- YES OR NO?"
```

RELAYS

```
00510 INPUTUS
00520 IFUS="NO" THEN0520
00530 PRINT
00535 GOSUB00280
00540 PRINT "ENVIRONMENT = ??? (1) LAB, (2) SO, (3) GF, (4) GP, (5) A
00550 PRINT "(6) GM, (7) AU, (8) SL, OR (9) M --- INPUT 1,2,...,9"
00560 INPUT Y5
00570 PRINT
00580 PRINT "CONTACT FORM AND QUALITY = ??? (1) SPST, (2) DPST, (3) S
00590 PRINT "(4) 3PST, (5) 4PST, (6) DPDT, (7) 3PDT, (8) 4PDT OR (9) I
00600 PRINT "INPUT 1,2,...,OR9"
00610 INPUT X1
00620 PRINT
00630 PRINT "PART IDENTIFIER ="
00640 INPUTUS(10)
00650 PRINT
00660 PRINT "GRADE OF RELIABILITY = ??? (1) UPPER OR (2) LOWER -- INP
00670 INPUT X2
00680 PRINT
00690 PRINT "CYCLES/HR="
00700 INPUTC
00710 PRINT
00720 FORI=1TO18
00730 READ Y(I)
00740 NEXT I
00750 IFX2=2THEN0750
00760 LETG=(Y(Y5*2-1))
00770 GOT00790
00780 LETG=Y(Y5*2)
00790 PRINT
00800 PRINT"LOAD TYPE = ? (1) RESISTIVE, (2) INDUCTIVE OR (3) LAMP"
00810 PRINT"INPUT 1,2 OR 3"
00820 INPUTX3
00830 PRINT
00840 PRINT"TEMPERATURE RATING = (1) 85 OR (2) 125 DEGREES - INPUT 1
00850 INPUTT4
00860 PRINT
00870 IFSEC(8)="YES"THEN0950
00880 PRINT"MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE"
00890 PRINT"(DEGREES C)="
00900 INPUT T8, T1, T3
00910 PRINT
00920 PRINT"MAX, MIN AND INCREMENT OF STRESS RATIO (LOAD/RATED RES.
00930 INPUTS8, S1, S3
00940 PRINT
00950 LETL(1)=.8
00960 LETL(2)=.4
00970 LETL(3)=.2
00980 FORI=1TO9
00990 READ X(I)
01000 NEXT I
01010 FOR I=1TO37
01020 READI(I),J(I)
01030 NEXTI
```

RELAYS

```
01040 LET C1=1
01050 IF C<1 THEN 1100
01060 LET C1=C/10
01070 IF X1=1 THEN 1100
01080 IF C<1000 THEN 1100
01090 LET C1=C1*2
01100 LET J=0
01110 PRINT "CONTACT RATING = ?" (1) SIGNAL CURRENT, (2) 0-5 AMPS, (3) 5-
01120 PRINT "OR (4) 25-600 AMPS --- INPUT 1,2,3 OR 4"
01130 LET ESC(7)="SIGNAL CURRENT"
01140 LET ESC(8)="0-5 AMPS"
01150 LET ESC(9)="5-25 AMPS"
01160 LET ESC(10)="25-600 AMPS"
01170 PRINT
01180 INPUT Y6
01190 IF Y6<1 THEN 1040
01200 IF Y6>4 THEN 1040
01210 PRINT
01220 PRINT "APPLICATION TYPE=?????"
01230 PRINT
01240 FOR I=1 TO 4
01250 READ YI
01260 FOR J=1 TO YI
01270 READ UJ
01280 IF I>Y6 THEN 1340
01290 LET ESC(J,I)=UJ
01300 IF J=4 THEN 1340
01310 READ W(I)
01320 PRINT "(J,J)" W(I)
01330 GOTO 1390
01340 READ Y8
01350 IF I>Y6 THEN 1380
01360 LET Y9=Y8+Y8
01370 GO TO 1390
01380 LET Y4=Y4+Y8
01390 NEXT J
01400 NEXT I
01410 LET J=1
01420 IF Y6<1 THEN 1570
01430 IF Y6<>4 THEN 1480
01440 GO TO 1580
01450 PRINT
01460 PRINT "INPUT 1,2,3,4"
01470 INPUT J
01480 IF J<1 THEN 1580
01490 FOR I=1 TO C(J-1)
01500 LET Y9=Y9+K(I)
01510 NEXT I
01520 FOR I=1 TO Y9
01530 READ UJ
01540 NEXT I
01550 PRINT
01560 PRINT "CONSTRUCTION TYPE ="
01570 PRINT
```

RELAYS

```

01600 FORI=1 TO K(J3)
01610 READUS(I)
01620 PRINT "(";I;")", US(I)
01630 NEXTI
01640 IF I=1 THEN 1680
01650 PRINT
01660 PRINT "INPUT 1, 2, . . ."
01670 INPUTJ3
01680 PRINT
01690 IF X2=2 THEN 1720
01700 LETH1=H(Y9+J3)
01710 GOTO 1730
01720 LETH1=J(Y9+J3)
01730 IF Y6=4 THEN 1770
01740 FORI=1 TO Y4
01750 READUS
01760 NEXTI
01770 FORI=1 TO 2
01780 READA(I), B(I), C(I)
01790 NEXTI
01800 GO SUB 2280
01810 PRINT TAB(17); US(10); SPC(4); "RELAY"
01820 PRINT
01830 PRINT "ENVIRONMENT CODE = " ; Y6, "CONTACT RATING = " ; BS(Y6+6)
01840 PRINT
01850 PRINT "CONSTRUCTION TYPE = " ; US(J3); SPC(4);
01860 LETUS(1)="UPPER"
01870 LETUS(2)="LOWER"
01880 PRINT "GRADE OF RELIABILITY = " ; US(K8)
01890 PRINT
01895 LETSS=9
01900 FORS=S1 TO SS STEP S3
01910 PRINT
01920 PRINT "STRESS RATIO = " ; S
01930 PRINT
01935 LETSS=SS+S
01940 PRINT "TEMPERATURE" ; SPC(10); "FAILURE RATE (%/1000HRS)"
01950 PRINT TAB(15); "L(B)", "L(R)"
01960 PRINT
01970 FORT=T1 TO T8 STEP T3
01980 PRINT TA(T4)*EXP((T+B73)/B(T4))+OC(T4));
01990 PRINT AC(T4)*EXP((T+B73)/B(T4))+OC(T4))+EXP((S/L(X3))+B)+N1*X(X1)
01994 LETSS=SS+1
01995 IF SS>60 THEN 00000
01996 GO SUB 00000
02000 NEXTT
02030 NEXTS
02031 IF SS=60 THEN 00041
02032 FORI=SS+1 TO 60
02033 PRINT
02034 NEXTI
02040 PRINT
02041 GO SUB 00000
02042 LETY9=Y4=0

```

RELAYS

```

0 2045 PRINT"A=")A(T4), "B=")B(T4), "C=")C(T4) ) EXP((S/L(X3))+2)
0 2046 PRINT "H1=")H1, "C1=")C1, "G=")G, "X=")X(X1)
0 2050 GO TO 2360
0 2060 DATA1, 2, 1, 5, 3, 2, 4, 8, 20, 8, 16, 10, 30, 12, 30, 55, 150, 100, 300, 1, 1, 5, 1, 75
0 2070 DATA2, 2, 5, 3, 4, 25, 5, 5, 8, 4, 10, 2, 6, 1, 3, 6, 10, 7, 14, 7, 14, 3, 6, 5, 10, 6, 12
0 2080 DATA3, 15, 2, , 6, 8, 20, 100, 100, 10, 30, 100, 100, 8, 6, 1, 3, 85, 0
0 2090 DATA 2, 0, 50, 100, 9, 10, 10, 20, 5, 10, 5, 10, 20, 40, 10, 20, 3, 9, 1, 3, 0, 6, 3, 9
0 2100 DATA4, , 2, 6, 7, 14, 10, 84, 10, 20, 6, 10
0 2110 DATA 1, DRY CIRCUIT, 6, 8, GENERAL PURPOSE, 3, SENSITIVE (O=100MW), 5
0 2120 DATA POLARIZED, 2, VIBRATING REED, 2, HIGH SPEED, 2, THERMAL TIME DELAY
0 2130 DATA1, ELECTRONIC TIME DELAY, 1, LATCHING (MAGNETIC), 3
0 2140 DATA2, HIGH VOLTAGE, 2, MEDIUM POWER, 6, 1, CONTRACTORS (HIGH CURRENT), 4
0 2150 DATA ARMATURE (LONG), DRY REED, MERCURY WETTED, MAGNETIC LATCHING
0 2160 DATA BALANCED ARMATURE, SOLENOID
0 2170 DATA ARMATURE (LONG), BALANCED ARMATURE, SOLENOID
0 2180 DATA ARMATURE (LONG & SHORT), MERCURY WETTED, MAGNETIC LATCHING
0 2190 DATA METER MOVEMENT, BALANCED ARMATURE, ARMATURE (SHORT)
0 2200 DATA METER MOVEMENT, DRY REED, MERCURY WETTED
0 2210 DATA ARMATURE (BALANCED AND SHORT), DRY REED, BIMETAL
0 2220 DATA SOLID STATE, DRY REED, MERCURY WETTED, BALANCED ARMATURE
0 2230 DATA VACUUM (GLASS), VACUUM (CERAMIC), ARMATURE (LONG AND SHORT)
0 2240 DATA MERCURY WETTED, MAGNETIC LATCHING, MECHANICAL LATCHING
0 2250 DATA BALANCED ARMATURE, SOLENOID, ARMATURE (SHORT), MECHANICAL LATCHING
0 2260 DATA BALANCED ARMATURE, SOLENOID
0 2270 DATA 111E-6, 388, 10, 7, 100E-6, 377, 10, 4
0 2280 FOR I=1 TO 6
0 2290 PRINT
0 2300 NEXT I
0 2310 LET SS=0
0 2310 PRINT"*****"
0 2320 FOR I=1 TO 6
0 2330 PRINT
0 2340 NEXT I
0 2350 RETURN
0 2360 PRINT "ANOTHER ANALYSIS -- YES OR NO?"
0 2370 INPUT E
0 2380 IF E="NO" THEN 8000
0 2390 RESTORE
0 2400 RESTORE
0 2410 PRINT
0 2420 PRINT "SAME TEMP AND STRESS RATIO"
0 2430 INPUT E(2)
0 2440 PRINT
0 2450 PRINT "SAME ENVIRONMENT -- YES OR NO?"
0 2460 INPUT E
0 2470 IF E="NO" THEN 8050
0 2480 PRINT "SAME CONTACT FORM AND QUALITY -- YES OR NO?"
0 2490 INPUT E
0 2500 IF E="NO" THEN 8070
0 2510 GO TO 8600
0 2520 END

```

SWITCHES

```
00010 DIM(A(10),B(10),C(10),D(10),X(10),Z(10),US(10))
00020 GO SUB 6110
00030 PRINT TAB(15);"FAILURE RATES FOR SWITCHES"
00040 PRINT
00050 PRINT"INSTRUCTIONS -- YES OR NO"
00060 INPUTUS
00070 PRINT
00080 PRINT
00090 IF US<>"YES" THEN 0680
00100 PRINT"THIS PROGRAM CALCULATES THE FAILURE RATE OF SWITCHES IN ACCORDANCE WITH THE RADCO RELIABILITY NOTEBOOK, SEPT. 1967."
00110 PRINT
00120 PRINT TAB(15);"INPUT REQUIREMENTS AND CODES"
00130 PRINT
00140 PRINT
00150 PRINT"1") TAB(11);"(1) ENVIRONMENT & CODE"
00160 PRINT
00170 PRINTTAB(11);"(1) LABORATORY, (2) SATELLITE ORBIT, (3) GROUND FIXTURE, (4) GROUND PORTABLE, (5) AIRBORNE INHABITERS,"
00180 PRINT
00190 PRINTTAB(11);"(6) GROUND MOBILE, (7) SATELLITE LAUNCH"
00200 PRINT
00210 PRINT TAB(11);"(8) RELIABILITY GRADE -- (1) UPPER, (2) LOWER OR (3) MEAN"
00220 PRINT
00230 PRINT
00240 PRINT "3") TAB(11);"MAX., MIN. AND INCREMENT OF SWITCHING CYCLES/HOUR"
00250 PRINT
00260 PRINT
00270 PRINT
00280 PRINT
00290 PRINT
00300 PRINT
00310 PRINT"4") TAB(11);"SWITCH DESCRIPTION -- (1) TOGGLE OR PUSHBUTTON"
00320 PRINTTAB(11);"(SINGLE BODY), (2) BASIC SENSITIVE SWITCH"
00330 PRINTTAB(11);"(SINGLE BODY OR MULTIPLE GROUPS),"
00340 PRINTTAB(11);"(3) ACTUATION ASSEMBLY (USING BASIC SENSITIVE"
00350 PRINTTAB(11);"(SWITCH OR ROTARY WAFERS), (4) ROTARY SWITCH WAFERS"
00360 PRINT
00370 PRINT
00380 PRINT"5") TAB(11);"SWITCH TYPE - 1 SNAP ACTION, 2 NON-SNAP ACTION"
00390 PRINTTAB(11);"(ACTUATION DIFFERENTIAL <.000 IN., "
00400 PRINTTAB(11);"(4 ACTUATION DIFFERENTIAL <.000 IN.,"
00410 PRINT TAB(11);"(5 CERAMIC RF WAFERS, 6 MEDIUM POWER WAFERS"
00420 PRINT
00430 PRINT
00440 PRINT"6") TAB(11);"NUMBER OF CONTACTS, ACTIVE SWITCHES OR"
00450 PRINT TAB(11);"(BASIC SENSITIVE SWITCHES)"
00460 PRINT
00470 PRINT
00480 PRINT"NOTES:"
00490 PRINT
00500 PRINT"THE NUMBERS IN BRACKETS (X) ARE THE CODES."
00510 PRINT
00520 PRINT "THE CODES FOR THE SWITCH TYPE ARE NOT CONSTANT FOR EVERY RADCO"
00530 PRINT
00540 PRINT"IF ONLY ONE VALUE IS TO BE ENTERED FOR THE CYCLES/HR."
```

SWITCHES

```
00550 PRINT"INPUT THAT VALUE FOR MAX, MIN AND INCREMENT"
00560 PRINT
00570 PRINT "MANY OF THE OUTPUTS ARE IN ACCORDANCE WITH THE INPUT CODES"
00580 PRINT
00590 PRINT"DO YOU WISH TO RUN -- YES OR NO"
00600 INPUTUS
00610 GOSUBB110
00615 IFUS<>"YES"THEN02200
00620 PRINT "ENVIRONMENT = (1) LAB, (2) SO, (3) GF, (4) GP, (5) AI,"
00630 PRINT"(6) GM, OR (7) SL -- INPUT 1,2,...,7"
00640 INPUTYS
00650 IFUS(8)<>"YES"THEN0700
00660 PRINT
00670 PRINT"RELIABILITY GRADE = (1) UPPER, (2) LOWER OR (3) BOTH --"
00680 PRINT"INPUT 1,2 OR 3"
00690 INPUTX9
00700 PRINT
00710 RESTORE
00720 RESTORES
00730 PRINT"MAX, MIN AND INCREMENT OF SWITCHING CYC/HR ="
00740 INPUT S0,S1,S3
00750 PRINT
00760 IFOR<=1THEN0700
00770 LETC1=1
00780 PRINT
00790 PRINT"SWITCH DESCRIPTION ="
00800 FORI=1TO4
00810 READUS(I)
00820 PRINTTABC(1)I;USC(I)
00830 NEXT I
00840 PRINT
00850 PRINT "(INPUT 1,2,3 OR 4)"
00860 INPUTX3
00870 PRINT
00880 FORI=1TO6
00890 READUS(I)
00900 NEXT I
00910 FORI=1TO6
00920 READAC(I),BC(I),DC(I),XC(I)
00930 NEXTI
00940 READKC7
00950 LETK1=.04
00960 FORI=1TO9
00970 READDC(I)
00980 NEXTI
00990 IFX3<>3THEN1110
01000 PRINT
01010 PRINT "USING:"
01020 PRINT
01030 FORI=3TO6
01040 PRINTTABC(4)I;SC(I)
01050 NEXT I
01060 PRINT
01070 PRINT "INPUT 3,4,5, OR 6"
```

SWITCHES

```
01080 INPUTX4
01090 PRINT
01100 GOTO1270
01110 LETX4=2*X3
01120 IFX4<>8THEN1140
01130 LETX4=X4-2
01140 PRINT"SWITCH TYPE = (1)"$SPC(2)$Z$(X4-1)$ SPC(2)$"OR (2)"$SPC(2)$
01150 PRINT"INPUT 1 OR 2"
01160 INPUTX5
01170 IFX4>4THEN1240
01180 PRINT
01190 PRINT"CONTACT FORM AND QUALITY = (1)SPST, (2) DPST, (3) SPDT,"
01200 PRINT"(4) 3PST, (5) 4PST, (6) DPDT, (7) 3PDT, (8) 4PDT,""
01210 PRINT"OR (9) 6PDT --- INPUT 1,2,3,..., 9"
01220 INPUTX1
01230 GOTO1950
01240 LET X1=1
01250 IFX9=8THEN1270
01260 LETX4=X4-1
01270 LETH1=8(X4)
01280 LETH2=0(X4)
01290 IFX3<3THEN1340
01300 PRINT
01310 PRINT"NUMBER OF CONTACTS/ACTIVE POLES/BASIC SEN. SW. = "
01320 INPUTN
01330 PRINT
01340 IFX8=3THEN1390
01350 IFX8=8THEN1380
01360 LETH8=1
01370 GOTO1390
01380 LETH1=1
01390 GOSUB B110
01400 IFX9>8THEN1450
01410 LETN=1
01420 LET A1=A(X4)*X(Y8)*D(X1)*N
01430 LETA2=A1*H1
01440 LETA3=A1*H2
01450 LETSG=18
01460 PRINT TAB(18)$US(X3)$SPC(8) : "SWITCH"
01470 PRINT
01480 PRINT "TYPE = "JS(X4)$SPC(4)$"CONTACT FORM AND QUANTITY CODE = "JDX
01490 PRINT
01500 LETUS(7)="UPPER"
01510 LETUS(8)="LOWER"
01520 LETUS(9)="UPPER AND LOWER"
01530 PRINT"ENVIRONMENT CODE="JYS$SPC(3)$"RELIABILITY GRADE = "JUS(Y2+6)
01540 PRINT
01550 PRINT"NUMBER OF CONTACTS/ACTIVE POLES/BASIC SEN. SW. = "
01560 PRINT
01570 PRINT"CYC/H"$TAB(18)$"FAILURE RATE (%/1000 HRS.)"
01580 PRINT
01590 PRINTTAB(14)$"L(B)"$SPC(5)$"L(SW) UPPER",SPC(5)$"L(SW) LOWER"
01600 PRINT
01610 FORJI=3TOS8STEP50
```

SWITCHES

```
01620 IFJ1>1THEN1650
01630 LETJ=1
01640 GOTO1660
01650 LETJ=J1
01660 IFX3>2THEN1750
01670 IFX2=1THEN1710
01680 IFX2=2THEN1730
01690 PRINTJ,A(X4),A2*J,A3*J
01700 GOTO1820
01710 PRINTJ,A(X4),A2*J,"NA"
01720 GOTO1820
01730 PRINTJ,A(X4),"NA",A3*J
01740 GOTO1820
01750 IFX2=1THEN1790
01760 IFX2=2THEN1810
01770 PRINTJ,"NA",(.04+A(X4)*N)*X(Y5)*J*H1,(.04+A(X4)*N)*X(Y5)*J*H2
01780 GOTO1820
01790 PRINTJ,"NA",(.04+A(X4)*N)*X(Y5)*J*H1,"NA"
01800 GOTO1820
01810 PRINTJ,"NA","NA",(.04+A(X4)*N)*X(Y5)*J*H2
01820 LETS6=S6+1
01830 IF S6<60THEN1850
01840 GOSUB2110
01850 NEXTJ1
01860 FORI=S6TO60
01870 PRINT
01880 NEXT I
01890 GOSUB2110
01900 PRINT"ANOTHER ANLAYAIS -- YES OR NO"
01910 INPUTUS
01920 IF US="NO"THEN2200
01930 PRINT
01940 PRINT"SAME RELIABILITY GRADE -- YES OR NO"
01950 INPUTUS(2)
01960 PRINT
01970 PRINT"SAME ENVIRONMENT -- YES OR NO"
01980 INPUTUS
01990 IF US="NU"THEN0610
02000 PRINT"D(X1)=""D(X1),"A(X4)=""A(X4),"H1=""H1,"H2=""H2,"X(Y5)=""X(Y5)
02010 PRINT"N=""N
02020 GOTO2200
02030 DATATOGGLE OR PUSHBUTTON, BASIC SENSITIVE, ACTUATION ASSEMBLY
02040 DATAROTARY SWITCH WAFERS
02050 DATASNAP ACTION, NON-SNAP ACTION, ACTUATION DIFFERENTIAL >.002 IN.
02060 DATAACTUATION DIFFERENTIAL <.002IN., CERAMIC RF WAFER
02070 DATA MEDIUM POWER WAFERS
02080 DATA-.005,-.8,.15,1,-.01,-.4,.6,.1,.8,-.005,-.07,.36,.2,-.01,-.07,.49,.8
02090 DATA-.001,-.8,.8,-.001,-.8,.84,.10,.55
02100 DATA1,1,.8,1.75,2,0,.5,3,4,.25,5,.5,8
02110 LETS6=6
02120 FORI=1TO6
02130 PRINT
02140 NEXTI
02150 PRINT"*****
```

SWITCHES

```
02160 FOR I=1 TO 6  
02170 PRINT  
02180 NEXT I  
02190 RETURN  
02200 END  
00615 IF U$<>"YES" THEN 02200
```

SIMICONDUCTORS

```
00010 DIM A(10),B(10),C(10),D(10),E(10),F(10)
00020 DIM K(10),L(10),N(10),ZS(10),VS(10)
00030 DIM M(10),VS(10),S(10),G(4)
00040 QOSUB 3200
00050 PRINT TAB(13); "SEMICONDUCTOR FAILURE RATE"
00060 LET N(10)=100
00070 PRINT
00080 PRINT
00090 PRINT "INSTRUCTIONS -- YES OR NO"
00100 INPUT Z$ 
00110 IF Z$<>"YES" THEN 2640
00120 PRINT
00130 PRINT "THIS PROGRAM CALCULATES THE BASE AND CATASTROPHIC FAILURE"
00140 PRINT "RATE OF SEMICONDUCTORS IN ACCORDANCE WITH THE RADAC"
00150 PRINT "RELIABILITY NOTEBOOK, VOL I, SEPT., 1967."
00160 PRINT
00170 PRINT TAB(13); "INPUT REQUIREMENTS AND CODES"
00180 PRINT
00190 PRINT TAB(11); "ENVIRONMENT"
00200 PRINT
00210 PRINT TAB(11); "(1) LABORATORY (2) SATELLITE ORBIT"
00220 PRINT TAB(11); "(3) GROUND FIXED (4) GROUND PORTABLE"
00230 PRINT TAB(11); "(5) AIRBORNE INHABITED (6) GROUND MOBILE"
00240 PRINT TAB(11); "(7) AIRBORNE UNINHABITED (8) SATELLITE LAB"
00250 PRINT TAB(11); "(9) MISSILE"
00260 PRINT
00270 PRINT "2"; TAB(11); " MODEL"
00280 PRINT
00290 PRINT TAB(11); "(1) GENERAL TRANSISTOR (2) FIELD EFFECT, (3) UNIJUNCTION
00300 PRINT TAB(11); "(4) DIODES AND RECTIFIERS, (5) ZENER DIODES, "
00310 PRINT TAB(11); "(6) SILICON CONTROLLED RECTIFIERS (SCR)"
00320 PRINT TAB(11); "(7) MICROWAVE DETECTORS AND MIXERS, AND"
00330 PRINT TAB(11); "(8) VARACTOR AND STEP RECOVERY DIODES"
00340 PRINT
00350 PRINT "3"; TAB(11); "PART TYPE"
00360 PRINT
00370 PRINT "4"; TAB(11); "GRADE OF RELIABILITY -- (1) UPPER OR (2) LOWER"
00380 PRINT
00390 PRINT "5"; TAB(11); "APPLICATION"
00400 PRINT
00410 PRINT "6"; TAB(11); "CURRENT OR POWER RATING (WATTS/AMPS)"
00420 PRINT
00430 PRINT "7"; TAB(11); "VOLTAGE STRESS (PERCENT)"
00440 PRINT
00450 PRINT "8"; TAB(11); "MAX, MIN AND INCREMENT OF STRESS RATIO"
00460 PRINT
00470 PRINT "9"; TAB(11); "MAX, MIN AND INCREMENT OF OPEN TEMPERATURE"
00480 PRINT
00490 PRINT "NOTES"
00500 PRINT
00510 PRINT "PART TYPE, APPLICATION, AND CURRENT OR POWER RATING ARE CODED"
00520 PRINT "HOWEVER, THEY ARE NOT THE SAME FOR EACH MODEL, THUS THEY ARE"
00530 PRINT "INCLUDED HERE-IN. THESE CODES SHOULD NOT GIVE THE USER ANY"
00540 PRINT "DIFFICULTY SINCE THEY ARE STRAIGHT FORWARD"
```

SEMICONDUCTORS

```

00550 PRINT
00560 PRINT"IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS, INPUT THAT"
00570 PRINT"VALUE FOR MAX, MIN AND INCREMENT."
00580 PRINT
00590 PRINT"RUN --- YES OR NO"
00600 INPUTZ$ 
00610 IFZ$<>"N0"GO TO 00630
00620 GO TO 3280
00630 GO SUB 3170
00640 IFZ$(10)="YES"THEN 00690
00650 PRINT
00660 PRINT"ENVIRONMENT = (1) LAB, (2) SO, (3) GF, (4) GP, (5) AI"
00670 PRINT"(6) GM, (7) AU, (8) SL OR (9) H -- INPUT 1,2,... OR 9"
00680 INPUTY$ 
00690 PRINT
00700 IFV$(10)="YES"THEN 00730
00710 PRINT"SEMC. MODEL #"
00720 PRINT
00730 FORI=1 TO 8
00740 READS(I),K(I),L(I),M(I)
00750 IFV$(10)="YES"THEN 00770
00760 PRINTTAB(5),I,Z$(I)
00770 NEXTI
00780 IFV$(10)="YES"THEN 00820
00790 PRINT
00800 PRINT"INPUT 1,2,...,9R8"
00810 INPUT X1
00820 IFK(X1)=1 THEN 00690
00830 PRINT
00840 IFV$(8)="YES"THEN 00860
00850 PRINT"PART TYPE ="
00860 FORI=1 TO 8
00870 IFK(I)=8 THEN 00970
00880 FORJ=1 TO K(I)
00890 IFI<>X1 THEN 00950
00900 READWS(J),A(J),B(J),C(J),D(J),E(J),F(J)
00910 IFK(X1)=1 THEN 00960
00920 IFV$(8)="YES"THEN 00940
00930 PRINTTAB(5)J,V$(J)
00940 GO TO 00960
00950 READWS(10),A1,A1,A1,A1,A1,A1
00960 NEXTJ
00970 NEXTI
00980 IFK(X1)<>1 THEN 01010
00990 LETX8=1
01000 GO TO 0030
01010 PRINT"INPUT 1,2,..."
01020 INPUTX8
01030 IFV$(9)="YES"THEN 00990
01040 PRINT
01050 PRINT"GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2"
01060 INPUT X4
01070 PRINT
01080 FORI=1 TO 8

```

SEMICONDUCTORS

```
01100 IF X1<>1 THEN 1190
01110 FOR J=1 TO 9
01120 LET N(J)=100
01130 IF J<>Y5 THEN 1160
01140 READ G(1), G(2), G(3), G(4)
01150 GO TO 1170
01160 READ G5, G7, G9, G6
01170 NEXT J
01180 GO TO 1280
01190 FOR J=1 TO 9
01200 READ G5, G7, G9, G6
01210 NEXT J
01220 NEXT I
01230 PRINT
01240 IF X4=8 THEN 1280
01250 LET G1=G(1)
01260 LET G3=G(3)
01270 GO TO 1360
01280 LET G5=G(5)
01290 LET G9=G(9)
01300 IF L(X1)=6 THEN 1390
01310 PRINT "APPLICATION :"
01320 FOR I=1 TO 8
01330 IF L(I)=6 THEN 1410
01340 FOR J=1 TO L(I)
01350 IF I<>X1 THEN 1390
01360 READ U(J), N(J)
01370 PRINT U(J), TAB(5), V3(J)
01380 GO TO 1400
01390 READ V3(7), N(7)
01400 NEXT J
01410 NEXT I
01420 LET J1=J1+1
01430 IF J1=1 THEN 1450
01440 RETURN
01450 IF L(X1)=8 THEN 1500
01460 PRINT "INPUT 1, 2, . . . , "
01470 INPUT I
01480 LET Z3(S)=V3(I)
01490 LET W(S)=N(I)
01500 FOR I=1 TO 8
01510 LET L(I)=N(I)
01520 LET S(I)=1
01530 NEXT I
01540 IF L(X1)=8 THEN 1560
01550 PRINT "CURRENT OR POWER RATING ="
01560 GO SUB 1380
01570 IF L(X1)=8 THEN 1650
01580 PRINT "INPUT 1, 2, . . . , "
01590 INPUT I
01600 LET Z3(10)=V3(I)
01610 LET W(10)=N(I)
01620 IF N(S)<>100 THEN 1650
01630 LET N(S)=1
```

SEMICONDUCTORS

```
01640 LET ZS(8)="NA"
01650 IFNC(10)<>100THEN1680
01660 LETN(10)=1
01670 LETZS(10)="NA"
01680 IFX1=1THEN1710
01690 IFX1=3THEN1710
01700 GO TO1730
01710 PRINT"VOLTAGE STRESS (PERCENT)="
01720 INPUTI1
01730 FORI=9TO180STEP10
01740 IFI1>1 THEN1790
01750 IFJ1=0THEN1790
01760 READSC(1),S(4)
01770 LETJ1=0
01780 GO TO1800
01790 READ S8,S9
01800 NEXTI
01810 LETN(9)=1
01820 IFX1>8THEN2000
01830 PRINT
01840 PRINT"COMPLEXITY ="
01850 FORI=1TO7
01860 READ USC(I),NC(I)
01870 IFX1=8THEN1890
01880 PRINTTAB(5)J1JSPC(8)JUSC(I)
01890 NEXTI
01900 IFX1=1THEN1950
01910 FORI=1TO5
01920 READUSC(I),NC(I)
01930 PRINTTAB(5)J1JSPC(8)JUSC(I)
01940 NEXT I
01950 PRINT
01960 PRINT"INPUT 1, 2, 3, . . . "
01970 INPUTF1
01980 LETZS(9)=USC(F1)
01990 LET NC(9)=NC(F1)
02000 PRINT
02010 PRINT"MAX, MIN AND INCREMENT OF STRESS RATIO ="
02020 INPUT 01,02,03
02030 PRINT
02040 PRINT"MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)="
02050 INPUT T1,T2,T3
02060 GO SUB3170
02070 PRINTTAB(13)JZS(X1)JSPC(8)J"SEMICONDUCTOR"
02080 PRINT
02090 PRINT
02100 IFK(X1)=1THEN2120
02110 PRINT"PART TYPE ="JUSC(X2)JSPC(5)J
02120 IFNC(8)=100THEN2140
02130 PRINT"APPLICATION ="JZS(8)
02140 PRINT
02150 IFL(X1)=0THEN2150
02160 PRINT"CURRENT OR POWER RATING (WATTS OR AMPS) ="JZS(10)
02170 PRINT
```

SEMICONDUCTORS

```
02160 IF I1=0 THEN 2210
02190 PRINT
02200 PRINT "VOLTAGE STRESS (X) ="; I1; SPC(4);
02210 IF X>2 THEN 2230
02220 PRINT "COMPLEXITY ="; ZS(9)
02230 PRINT
02240 PRINT "RELIABILITY GRADE CODE="; X4; SPC(4); "ENVIRONMENT CODE="; Y5
02250 PRINT
02260 FOR O=0 TO 01 STEP 0.3
02270 PRINT "STRESS RATIO="; O
02280 PRINT
02290 PRINT TAB(17); "FAILURE RATE (%/1000 HRS)"
02300 PRINT
02310 PRINT "TEMP", "L(B)", "L(SEM.)"
02320 PRINT
02330 PRINT
02340 FOR T=T2 TO T1 STEP T3
02350 LET C9=T+R73
02360 IF B(X2)<0 THEN 2390
02370 LET K4=EXP(((C9+F(X2)*O)/C(X2))+B(X2))
02380 GO TO 2400
02390 LET K4=A(X2)*EXP((1/((C9+F(X2)*O)/C(X2)))+(-B(X2)))
02400 LET K4=K4*EXP(((C9+F(X2)*O)/D(X2))+E(X2))
02410 PRINT T, K4, K4*G1*N(8)*N(9)*N(10)*S(X1)+G2
02420 NEXT T
02430 PRINT
02440 NEXT O
02450 LET I1=0
02460 RESTORE
02470 RESTORE S
02480 GO SUB 3200
02490 PRINT "ANOTHER ANALYSIS -- YES OR NO"
02500 INPUT Z$(10)
02510 IF Z$(10)="NO" THEN 3280
02520 PRINT "SAME ENVIRONMENT -- YES OR NO"
02530 INPUT Z$(10)
02540 PRINT "SAME MODEL";
02550 INPUT U$(10)
02560 PRINT "SAME RELIABILITY GRADE -- YES OR NO"
02570 INPUT U$(9)
02580 GO TO 6630
02590 DATA GENERAL TRANSISTOR, 4, 6, 6, FIELD EFFECT, 1, 6, 0, UNIJUNCTION, 1, 0, 0
02600 DATA DIODES AND RECTIFIERS, 2, 6, 6, ZENER DIODES, 1, 2, 6
02610 DATA SILICON CONTROLLED RECTIFIERS (SCR), 1, 6, 4
02620 DATA MICROWAVE DETECTORS AND MIXERS, 4, 0, 0
02630 DATA VARACTOR AND STEP RECOVERY DIODES, 1, 0, 6
02640 DATA Si-NPN, .027, -1, -1052, 448, 10.5, 150, 31-PNP, .085, -1, -1324, 338, 148
02650 DATA Ge-PNP, 4, 6, -1, -2142, 373, 20.8, 75, Ge-NPN, 8.5, -1, -2221, 373, 19, 75
02660 DATA FET AND IGFET, .075, -1, -1168, 448, 13.8, 150, UNIJ TRAN, 7.81, -1, -1
02670 DATA SILICON, .13, -1, -2138, 448, 17.7, 150, GERMANIUM, 15.7, -1, 3568, 373, 1
02680 DATA VOLT REG, .274, -1, -2242, 448, 10.7, 175, ALL SCR, .286, -1, -2050, 423
02690 DATA DECT 70-MAX, .265, -1, -477, 343, 15.6, 45, DECT 150-MAX, .055, -1, -39
02700 DATA MIXER 70-MAX, .445, -1, 447, 343, 15.6, 45
02710 DATA MIXER 150-MAX, .075, -1, -394, 423, 15.6, 125
```

SEMICONDUCTORS

```

0 2720 DATA VARACTOR AND STEP RECOVERY DIODES, .37, -1, -1162, 448, 13.8, 150
0 2730 DATA1, 10, 0, 0, 5, 50, .0005, .005, 15, 150, .001, .01, 40, 400, .004, .04
0 2740 DATA30, 300, .004, .04, 50, 500, .005, .05, 50, 500, .005, .05, 80, 800, .02, .2
0 2750 DATA140, 1400, .02, .2
0 2760 DATA1, 20, 0, 0, 10, 200, .005, .1, 30, 600, .01, .2, 80, 1600, .02, .4, 60, 1200, 8
0 2770 DATA100, 2000, .02, .4, 100, 2000, .02, .4, 160, 3200, .03, .6, 280, 5600, .05, 1
0 2780 DATA1, 20, 0, 0, 5, 100, .02, .4, 15, 300, .06, 1, 2, 40, 800, .15, 3, 30, 300, .15, 3
0 2790 DATA50, 1000, .2, 4, 50, 1000, .2, 4, 80, 1600, .2, 4, 140, 2800, .3, 6
0 2800 DATA1, 6, 0, 0, 5, 30, .0005, .005, 15, 90, .001, .01, 40, 240, .002, .02
0 2810 DATA30, 180, .002, .02, 50, 300, .003, .03, 50, 300, .003, .03
0 2820 DATA70, 420, .006, .06, 120, 720, .01, .1
0 2830 DATA1, 10, 0, 0, 5, 50, .001, .01, 15, 150, .001, .01, 40, 400, .004, .04
0 2840 DATA30, 300, .004, .04, 50, 500, .006, .06, 50, 500, .006, .06, 70, 700, .01, .1
0 2850 DATA120, 1200, .02, .2
0 2860 DATA1, 10, 0, 0, 5, 50, .001, .02, 20, 200, .001, .02, 40, 400, .005, .1, 30, 300, 8
0 2870 DATA50, 500, .005, .1, 50, 500, .005, .1, 100, 1000, .01, .2, 150, 1500, .02, .4
0 2880 DATA1, 3, 0, 0, 2, 6, .02, .06, 30, 90, .02, .06, 120, 360, .03, 2, 4, 100, 300, .06, 18
0 2890 DATA150, 450, .9, 2, 7, 150, 450, .9, 2, 7, 750, 2250, 4, 5, 15, 150, 4500, 9, 25
0 2900 DATA1, 5, 0, 0, 5, 25, .01, .05, 15, 75, .03, .15, 40, 200, .08, .4, 30, 150, .06, .3
0 2910 DATA50, 250, .1, .5, 50, 250, .1, .5, 80, 400, .16, .8, 120, 600, .25, 1.25
0 2920 DATA LINEAR(AC), 1, LINEAR(DC), 2, LOW NOISE(AUDIO), 1, 3, HIGH FREQUENCY R
0 2930 DATA3, LOW NOISE(RF), 4, LOGIC SWITCHING, .5
0 2940 DATA LINEAR(AC), 1, LINEAR(DC), 2, LOGIC SWITCH, .5, LOW NOISE AUDIO, 1.5
0 2950 DATA HIGH FREQUENCY(RF), 3, LOW NOISE(RF), 4
0 2960 DATA SIGNAL (AUDIO), 1, SIGNAL (IF AND RF), 1, 5, LOGIC SWITCHING, .3
0 2970 DATA POWER RECTIFIER, 1, POWER RECT. (H.V. STACKS) VMAX > 600, 2
0 2980 DATA FORWARD REFERENCE, .3, VOLTAGE REGULATOR, 1
0 2990 DATA VOL TAGE REFERENCE (TEMP. COMPENSATED), 1
0 3000 DATA "0 TO 100 MW", 1, ">100 TO 500 MW", 1, ">.5 TO 1", 1, ">1, TO 5", 1,
0 3010 DATA ">5, TO 20", 2, ">20", 2.
0 3020 DATA "0 TO 100 MA", 1.2, ">100 TO 500 MA", 1, ">.5 TO 1", 1.1
0 3030 DATA ">1 TO 3", 1.5, ">3 TO 10", 2, ">10", 2.5
0 3040 DATA "0 TO 250 MW", 1.2, ">250 TO 500 MW", 1, ">500 TO 1 W", 1.2
0 3050 DATA ">1 TO 5 W", 1.5
0 3060 DATA ">5 TO 20 W", 2, ">20 W", 3.
0 3070 DATA "0 TO 500 MA", 1.2, ".5 TO 1 A", 1, "1 TO 10 A", 1.5, "10 A", 2
0 3080 DATA "0 TO 100 MW", 1.3, ">100 TO 500 MW", 1, ">.5 TO 1 W", 1.5
0 3090 DATA ">1 TO 5W", 2, ">5 TO 20 W", 3, ">20 W", 4
0 3100 DATA .3, .7, .3, .7, .3, .7, .36, .7, .48, .7, .75, .7, 1, .7, 1.2, .75
0 3110 DATA1.65, .8, 2.25, .9, 3, .1
0 3120 DATA "SINGLE TRANSISTOR", 1, DUAL (UNMATCHED), .7, DUAL (MATCHED), 1.2
0 3130 DATA "DARLINGTON", .8, "DUAL Emitter", 1.1, "MULTIPLE Emitter", 1.2
0 3140 DATA "COMPLEMENTARY PAIR", .7
0 3150 DATA "SINGLE DEVICE", 1, "DUAL UNMATCHED", .7, "DUAL MATCHED", 1.2
0 3160 DATA "DUAL COMPLEMENTARY", .7, "TETRODE", 1.1
0 3170 FOR I=1 TO 12
0 3180 PRINT
0 3190 NEXT I
0 3200 FOR I=1 TO 6
0 3210 PRINT
0 3220 NEXT I
0 3230 PRINT
0 3240 FOR I=1 TO 6
0 3250 PRINT

```

S EMICONDUCTORS

**0 3265 NEXT 1
0 3270 RETURN
0 3280 END**

MICROCIRCUITS

```
00010 DIMZ$(10),B(20),A(20)
00020 PRINT TAB(15); "FAILURE RATE OF MICROCIRCUITS"
00030 PRINT
00040 PRINT
00050 PRINT "INSTRUCTIONS--YES OR NO";
00060 INPUTZ$
00070 PRINT
00080 IFZ$=>"YES"THEN0380
00090 PRINT
00100 PRINTTAB(17); "INPUT REQUIREMENTS"
00110 PRINT
00120 PRINT"1";TAB(11); "ENVIRONMENT"
00130 PRINT
00140 PRINTTAB(11); "(1) LABORATORY, (2) SATELLITE ORBIT, (3) GROUND FIXED
00150 PRINT TAB(11); "(4) GROUND PORTABLE, (5) GROUND MOBILE,"
00160 PRINTTAB(11); "(6) AIRBORNE INHABITED, (7) AIRBORNE UNINHABITED,"
00170 PRINTTAB(11); "(8) SATELLITE LAUNCH, (9) MISSILE"
00180 PRINT
00190 PRINT"2";TAB(11); "PART IDENTIFIER"
00200 PRINT
00210 PRINT"3";TAB(11); "NUMBER OF BASIC FUNCTIONS"
00220 PRINT
00230 PRINT"4";TAB(11); "OPEN VOLTAGE GAIN"
00240 PRINT
00250 PRINT"5";TAB(11); "NUMBER OF EXTRA OR SPECIAL INPUTS"
00260 PRINT
00270 PRINT"6";TAB(11); "NUMBER OF EXTRA OR SPECIAL OUTPUTS"
00280 PRINT
00290 PRINT"7";TAB(11); "TYPE OF PACKAGE"
00300 PRINT
00310 PRINT"8";TAB(11); "QUALITY GRADE"
00320 PRINT
00330 PRINT"9";TAB(11); "MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE"
00340 PRINT
00350 PRINT"DO YOU WISH TO RUN -- YES OR NO";
00360 INPUTZ$
00370 IFZ$="NO"THEN2710
00380 PRINT
00390 PRINT "ENVIRONMENT =? (1) LAB, (2) SO, (3) GF, (4) GP, (5) GM,"
00400 PRINT "(6) AI, (7) AU, (8) SL OR (9) MISSILE -- INPUT 1, 2,...,9"
00410 INPUTYS
00420 PRINT
00430 PRINT"ANALYSIS FOR (1) DIGITAL OR (2) LINEAR MICROCIRCUITS = ";
00440 PRINT"INPUT 1 OR 2";
00450 INPUT A4
00460 PRINT
00470 PRINT"INPUT PART IDENTIFIER";
00480 INPUTZ$(9)
00490 LETZ$(1)="DIGITAL MICROCIRCUITS"
00500 LET Z$(2)="LINEAR MICROCIRCUITS"
00510 IF A4=1 THEN0770
00520 PRINT
00530 PRINT "NUMBER OF BASIC FUNCTIONS = ";
00540 INPUT A1
```

MICRO CIRCUITS

```

00550 LET A1=A1*4
00560 PRINT
00570 PRINT"OPEN VOLTAGE GAIN = ";
00580 INPUT A(4)
00590 PRINT
00600 IF A(4)<=60 THEN 0620
00610 LET A1=A1+(A2-60)/10
00620 LET A1=A1+(A(4)-60)/10
00630 PRINT"NUMBER OF EXTRA OR SPECIAL INPUTS (SUCH AS NON-INVERTING)="
00640 INPUT A(1)
00650 LET A1=A1+2*A(1)
00660 PRINT
00670 PRINT"NUMBER OF EXTRA OR SPECIAL OUTPUTS (SUCH AS Emitter FOLLOWER"
00680 INPUT A(2)
00690 LET A1=A1+2*A(2)
00700 PRINT
00710 PRINT "NUMBER OF OTHER SPECIAL FEATURES (SUCH AS THRESHOLD LIMITING"
00720 PRINT "OR EXTREME FREQ RES)=";
00730 INPUT A(3)
00740 PRINT
00750 LET A1=A1+3*A(3)
00760 GOTO 01360
00770 PRINT
00780 PRINT "DO YOU KNOW THE VALUE OF THE COMPLEXITY FACTOR PI(C)?"
00790 PRINT "YES OR NO?";
00800 INPUT Z$(3)
00810 IF Z$(3)="YES" THEN 1330
00820 PRINT
00830 PRINT
00840 PRINT TAB(10); "COMPLEXITY FACTORS FOR DIGITAL MICROCIRCUITS"
00850 PRINT
00860 PRINT "COMPLEXITY"; TAB(17); "LOGIC"; TAB(47); "INPUT DESCRIPTION"
00870 PRINT "*****"
00880 PRINT "1"; TAB(13); "BASIC SINGLE GATE"; TAB(46); "UP TO 4 INPUTS"
00890 PRINT
00900 PRINT TAB(13); "SINGLE GATE"; TAB(46); "4 TO 8 INPUTS"
00910 PRINT TAB(13); "DUAL GATE"; TAB(46); "UP TO 4 INPUTS"
00920 PRINT TAB(13); "EXPANDER"; TAB(46); "UP TO 5 INPUTS"
00930 PRINT TAB(13); "DUAL INVERTER"; TAB(46); "ANY"
00940 PRINT "*****"
00950 PRINT
00960 PRINT "2"; TAB(13); "TRIPLE GATE"; TAB(46); "UP TO 4 INPUTS"
00970 PRINT TAB(13); "EXCLUSIVE OR GATE"; TAB(46); "UP TO 4 INPUTS"
00980 PRINT TAB(13); "TRIPLE NAND GATE"; TAB(46); "UP TO 3 INPUTS"
00990 PRINT TAB(13); "TRIPLE NAND/NOR GATE"; TAB(46); "UP TO 3 INPUTS"
01000 PRINT TAB(13); "NAND/NOR WITH Emitter"
01010 PRINT TAB(13); "FOLLOWER"; TAB(46); "UP TO 6 INPUTS"
01020 PRINT TAB(13); "ADDER"; TAB(46); "ANY"
01030 PRINT
01040 PRINT TAB(13); "QUAD GATE"; TAB(46); "UP TO 4 INPUTS"
01050 PRINT TAB(13); "DUAL EXPANDER"; TAB(46); "UP TO 4 INPUTS"
01060 PRINT TAB(13); "DUAL NAND/NOR GATE"; TAB(46); "UP TO 5 INPUTS"
01070 PRINT TAB(13); "QUAD INVERTER DRIVER"; TAB(46); "ANY"
01080 PRINT TAB(13); "TRIPLE NAND/NOR WITH"

```

MICROCIRCUITS

```
01090 PRINT TAB(13); "EMITTER FOLLOWER"; TAB(46); "UP TO 4 INPUTS"
01100 PRINT TAB(13); "SIMPLE FLIP-FLOP"; TAB(46); "2 INPUTS"
01110 PRINT"*****"
01120 PRINT
01130 PRINT
01140 PRINT "3"; TAB(13); "JK FLIP-FLOP WITH"
01150 PRINT TAB(13); " PRESET AND/OR CLEAR"; TAB(46); "ANY"
01160 PRINT TAB(13); "DUAL EXCLUSIVE-OR GATE"; TAB(46); "UP TO 4 INPUTS"
01170 PRINT TAB(13); "ONE SHOT MULTIVIBRATOR"
01180 PRINT
01190 PRINT TAB(13); "JK/R-S FLIP-FLOP"
01200 PRINT TAB(13); "QUAD NAND/NOR"; TAB(46); "ANY"
01210 PRINT"*****"
01220 PRINT
01230 PRINT
01240 PRINT"4"; TAB(13); "DUAL SIMPLE FLIP-FLOP"; TAB(46); "2 INPUTS"
01250 PRINT TAB(13); "RS FLIP-FLOP/COUNTER"; TAB(46); "ANY"
01260 PRINT TAB(13); "RIPPLE COUNTERS"; TAB(46); "ANY"
01270 PRINT
01280 PRINTTAB(13); "DUAL JK FLIP-FLOP WITH"
01290 PRINT TAB(13); " PRESET AND/OR CLEAR"; TAB(46); "ANY"
01300 PRINT"*****"
01310 PRINT
01320 PRINT
01330 PRINT
01340 PRINT"COMPLEXITY FACTOR ="
01350 INPUT A1
01360 PRINT
01370 PRINT "TYPE OF PACKAGE ="
01380 PRINT
01390 PRINT "FLATPACK -- (1) GLASS, (2) ALUMINUM, (3) METAL"
01400 PRINT
01410 PRINT "OR"
01420 PRINT
01430 PRINT"TO-S -- (4) GLAS FRIT, (5) EUTECTIC SOLDER"
01440 PRINT
01450 PRINT "INPUT 1, 2, 3, 4, OR 5"
01460 INPUTA5
01470 PRINT
01480 FORI=1TO9
01490 READ B(I)
01500 NEXT I
01510 LET B1=B(A5)
01520 LET Z$(3)="OPTIMUM SCREENING"
01530 LET Z$(4)="UPPER GRADE"
01540 LET Z$(5)="AVERAGE GRADE"
01550 LET Z$(6)="LOWER GRADE"
01560 PRINT"QUALITY GRADE = (1) OPTIMUM SCREEN, (2) UPPER GRADE,"
01570 PRINT"(3) AVERAGE GRADE, (4) LOWER GRADE OR (5) EXPLANATION - INP"
01580 INPUTA5
01590 IF A5<>5 THEN 1550
01600 PRINT
01610 PRINTTAB(15); "ADJUSTMENT FACTORS"
01620 PRINT
```

MICROCIRCUITS

```
01630 PRINT"PI(Q)"TAB(17);"QUALITY GRADE"
01640 PRINT"*****"
01650 PRINT
01660 PRINT1;TAB(13);"OPTIMUM SCREEN WHICH INCLUDES:"
01670 PRINT TAB(13);"A. VENDOR LINE AND PRODUCT QUALIFICATION"
01680 PRINT TAB(13);"B. LINE DISCIPLINE ON AN INTERREFERENCE BASIS."
01690 PRINT TAB(13);"C. FAILURE FEEDBACK (TIGHT LOOP) WITH CONTINUOUS"
01700 PRINT TAB(16);"CORRECTIVE ACTION SIMILAR TO MINUTEMAN PROCEDURES"
01710 PRINT TAB(13);"D. SCREENS AND BURN-IN"
01720 PRINT TAB(13);"E. TRACEABILITY OF TEST DATA."
01730 PRINT
01740 PRINT2;TAB(13);"UPPER GRADE WHICH INCLUDES:"
01750 PRINT TAB(13);"A. SCREENS AND BURN-IN COMPARABLE TO RADE SPEC. ■"
01760 PRINT TAB(16);"ON LIMIT TESTING (SAMPLE SUBJECT TO DESTRUCTIVE TEST"
01770 PRINT TAB(16);"TO ESTABLISH ABSOLUTE LIMITS OF STRESSES WHICH DEVS"
01780 PRINT TAB(16);"CAN WITHSTAND) TO IDENTIFY MAJOR FAILURE MODES AND"
01790 PRINT TAB(13);"B. FEEDBACK FROM SCREENING RESULTS ONLY"
01800 PRINT
01810 PRINT 15;TAB(13);"AVERAGE GRADE WHICH INCLUDES:"
01820 PRINT TAB(13);"A. NORMAL PRODUCTION GRADE AND LOT ACCEPTANCE TES■"
01830 PRINT TAB(16);"ON A SAMPLING BASIS."
01840 PRINT TAB(13);"B. NO 100% SCREENING BEYOND PROCEDURES FOR"
01850 PRINT TAB(16);"ELECTRICAL PARAMETERS AND HERMETICITY."
01860 PRINT
01870 PRINT 30, TAB(13);"LOWER GRADE WHICH INCLUDES ROUTINE VENDOR PROG■"
01880 PRINT TAB(13);"WHICH ARE APPLIED TO ALL PRODUCTION DEVICES ON A 10■"
01890 PRINT
01900 PRINT"*****"
01910 PRINT
01920 PRINT
01930 PRINT "QUALITY GRADE CODE = 1, 2, 3, OR 4"
01940 INPUT A$5
01950 PRINT
01960 LET B2=B(A$+5)
01970 FOR I=1 TO 9
01980 READ B(I)
01990 NEXT I
02000 LET B3=B(4)
02010 PRINT
02020 PRINT "WHAT IS THE MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE"
02030 INPUT T1, T2, T3
02040 FOR I=1 TO 5
02050 PRINT
02060 NEXT I
02070 PRINT"-----"
02080 FOR I=1 TO 6
02090 PRINT
02100 NEXT I
02110 PRINT TAB(13)Z$(A4)
02120 PRINT
02130 PRINT
02140 PRINT Z$(9)
02150 PRINT
02160 IF A4=1 THEN 2210
```

MICROCIRCUITS

```
02170 PRINT "NO. OF SPECIAL INPUTS =";A(1), "NO OF SPECIAL OUTPUTS =";A(2)
02180 PRINT
02190 PRINT "NO. OF SPECIAL FEATURES =";A(3), "OPEN VOLTAGE GAIN =";A(4)
02200 PRINT
02210 PRINT TAB(15); "ENVIRONMENT CODE =";Y$ 
02220 PRINT
02230 PRINT "COMPLEXITY FACTOR =";A(1), "QUALITY GRADE =";Z$(A5+2)
02240 PRINT
02250 PRINT
02260 LET N1=20
02270 PRINT "JUNCT TEMP"; TAB(20); "BASE FAIL RATE"; TAB(45); "FAIL RATE (%/H"
02280 PRINT "-----", TAB(20); "-----"; TAB(45); "-----"
02290 PRINT
02300 PRINT
02310 FOR T=T2TOT1STEPT3
02320 LET N1=N1+1
02330 PRINT T, TAB(20)+.98*EXP(-2298/(T+273));
02340 PRINT TAB(47); A1*B1*B2*B3*EXP(-2298/(T+273))+.98
02350 IF N1<60 THEN 2440
02360 FOR I=1 TO 6
02370 LET N1=0
02380 PRINT
02390 NEXT I
02400 PRINT "-----"
02410 FOR I=1 TO 8
02420 PRINT
02430 NEXT I
02440 NEXT T
02450 IF N1=60 GOTO 2530
02460 FOR I=N1 TO 66
02470 PRINT
02480 NEXT I
02490 PRINT "-----"
02510 DATA 2, 5, 2, 2, 2, 1.5, 1, 2, 15, 30
02520 DATA 1, 1.5, 2, 5, 7, 5, 7, 8, 10
02530 FOR I=1 TO 5
02540 PRINT
02550 NEXT I
02560 RESTORE
02570 RESTORE
02580 PRINT "ANOTHER ANALYSIS -- YES OR NO"
02590 INPUT Z$(8)
02600 IF Z$(8)="NO" THEN 2710
02610 PRINT "SAME ENVIRONMENT -- YES OR NO";
02620 INPUT Z$(8)
02630 IF Z$(8)="NO" THEN 0390
02640 PRINT
02650 PRINT "SAME PART TYPE -- YES OR NO";
02660 INPUT Z$(8)
02670 PRINT
02680 IF Z$(8)="NO" THEN 0420
02690 PRINT
02700 GOTO 0470
02710 END
```

PRINTED WIRING

```
00010 DIM US(10)
00020 DIM A(10), B(10), C(10), D(10)
00030 PRINT TAB(13); "FAILURE RATE OF PRINTED WIRING"
00040 PRINT
00050 PRINT
00060 FOR I=1 TO 5
00070 READ A(I), B(I), C(I), D(I)
00080 NEXT I
00090 PRINT "ANALYSIS FOR -- (1) AVERAGE EXPERIENCE, (2) NORMAL UPPER LIMIT"
00100 PRINT "(3) NORMAL LOWER LIMIT, (4) WORST EXPERIENCE OR"
00110 PRINT "(5) BEST EXPERIENCE -- INPUT 1,2,3,4, OR 5"
00120 INPUT N1
00130 LET US(1)="AVERAGE EXPERIENCE"
00140 LET US(2)="NORMAL UPPER LIMIT"
00150 LET US(3)="NORMAL LOWER LIMIT"
00160 LET US(4)="WORST EXPERIENCE"
00170 LET US(5)="BEST EXPERIENCE"
00180 PRINT
00190 PRINT "NUMBER OF CONNECTIONS ="
00200 INPUT N3
00210 LET N2=LOG(N3)
00220 PRINT
00230 LET X1=LOG(A(N1))
00240 LET Y1=LOG(B(N1))
00250 LET X2=LOG(C(N1))
00260 LET Y2=LOG(D(N1))
00270 LET Y=(Y2-Y1)*(N2-X1)/(X2-X1)+Y1
00280 GO SUB 0480
00290 PRINT TAB(17); "PRINTED WIRING FAILURE RATE"
00300 PRINT
00310 PRINT
00320 PRINT TAB(13); US(N1)
00330 PRINT
00340 PRINT "NUMBER OF CONNECTIONS ="; N3
00350 PRINT
00360 PRINT TAB(5); "FAILURE RATE (1/1000 HRS) ="
00370 PRINT EXP(Y)
00380 GO SUB 0480
00390 PRINT "ANOTHER ANALYSIS -- YES OR NO"
00400 INPUT US(8)
00410 IF US(8)="NO" THEN 0560
00420 PRINT
00430 PRINT
00440 GO TO 0090
00450 DATA 15,.011,700,.51,10,.011,100,.125,10,.0045,700,.29
00460 DATA 10,.0497,70,.31,10,.0019,300,.0497
00470 GO TO 0560
00480 FOR I=1 TO 6
00490 PRINT
00500 NEXT I
00510 PRINT "*****"
00520 FOR I=1 TO 6
00530 PRINT
00540 NEXT I
```

PRINTED WIRING

00550 RETURN
00560 END

SECTION III

PROGRAM INPUT - OUTPUT EXAMPLES

1. INTRODUCTION

This section presents a number of computer run-offs of the computerized version, of the "RADC Reliability Notebook," Volume II, September 1967, as developed by RADC/EMNRR/CAF/NY. These runs have been presented to illustrate the input, output and flexibility of the programs.

2. PROGRAM INSTRUCTIONS

Each of the programs contain instructions which the user has option of listing on each computer run. The instructions are listings of the input data required to perform a run and notes which explain peculiarities of the programs. There should not be any difficulty in interpretation of the terms used therein, since the author has kept the terminology in close agreement with the Notebook. However, at this point the phrase, "Max, Min and Increment," should be discussed. This phrase is used in query of stresses. On such a query the user has the option of performing an analysis for one or more stress, in ascending or descending order, during a computer run.

Examples of stress query and inputs:

A. One stress value

Max, Min and increment of operating temperature? 70, 70, 70

B. Ascending values of stress

Max, Min and increment of stress ratio? 1, 0, .2

C. Descending values of stress

Max, Min and increment of operating temperature? 0, 150, - 25

A listing of the instructions is presented in Appendix I. The format of the listings are not the same because of computer storage.

3. DATA INPUTS

The programs are such that the values of the variables which are to be entered as data, are entered through the computer teletypewriter keyboard during the computer run. This is accomplished by typing the value of the variable and depressing the return key after the variable has been queried by the computer.

EXAMPLE

What is the resistance value (OHMS)? 5000 (return)***

If more than one (1) variable is queried at a time, the user types the value of the variables separated by a comma and depresses the return key.

EXAMPLE

What is the multiple of longevity and value of
PI(L)? 10, 3.6 (return)***

*** (return) - depress return key on teletype keyboard

4. OUTPUT SYMBOLS AND CODES

The outputs of the computer programs have been kept as close as possible in agreement with the "RADC Reliability Notebook," Volume II, 1967. However, due to the limitations of the computer (keyboard, software, storage, etc.) many of the symbols and codes used in the notebook had to be coded or changed in the computer. The output codes are in agreement with the instruction codes.

5. EXAMPLES

The examples herein are the same as the ones in the notebook. Example 1 is presented to illustrate analyses of multiple stress conditions during one (1) computer run.

EXAMPLE I
(POTENTIOMETERS)

01/26/70 13:29

FAILURE RATES FOR POTENTIOMETERS

DO YOU WISH INSTRUCTIONS --- YES OR NO?NO

ENVIRONMENT: (1) LAB, (2) SO, (3) GF, (4) GP,
(5) AI, (6) GR, (7) AU, (8) SL, (9) MIL -- INPUT 1,2,...9
?5

ANALYSIS FOR: (1) PRECISION, (2) SEMI-PRECISION,
(3) LOW-PRECISION, (4) NON-WIREWOUND, (5) WIREWOUND,
(6) ESTABLISHED RELIABILITY OR (7) HIGH POWER
INPUT 1,2,..., OR 7?1

STRESS RATIO TO BE CALCULATED - YES OR NO?NO

GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2
?1

IS FAILURE RATE FOR A MULTIPLE OF LONGEVITY TO BE CALCULATED
INPUT YES OR NO
?YES

MULTIPLE OF LONGEVITY AND PI(L)=?3, 1.45

APPLIED VOLTAGE?45

RATED VOLTAGE?250

RESISTANCE (OHMS)?1500

NUMBER OF TAPS?3

MAX, MIN AND INCREMENT OF STRESS RATIO? .71, +71, 1

MAX, MIN AND INCREMENT OF OPER TEMPERATURE - DEG C?50, 50, 30

CONSTRUCTION= 1, 2, 3, 4, 5, OR 6?2

PRECISION POTENTIOMETERS

RESISTANCE = 1500 ENVIRONMENT CODE = 5

GRADE OF RELIABILITY = UPPER

MULTIPLE OF LONGEVITY = 3 PI(L) = 1.45

STRESS RATIO = 0.71

TEMPERATURE	FAILURE RATE (%/1000 HRS.)		
	L(B)	L(P)	L(PL)
50	2.24420E-32	0.493649	0.715791

ANOTHER ANALYSIS -- YES OR NO?YES

SAME ENVIRONMENTS -- YES OR NO? YES

SAME STRESS CONDITIONS -- YES OR NO? YES

SAME RESISTOR TYPE - YES OR NO? YES

STRESS RATIO TO BE CALCULATED = YES OR NO

GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2
12

IS FAILURE RATE FOR A MULTIPLE OF LONGEVITY TO BE CALCULATED
INPUT YES OR NO
?YES

MULTIPLE OF LONGEVITY AND PI(L)=? 6, 2.64

APPLIED VOLTAGE?45

RATED VOLTAGE?250

RESISTANCE (OHMS) ?? 1500

NUMBER OF TAPS??

CONSTRUCTION=1, 2, 3, 4, 5, OR 612

PRECISION POTENTIOMETERS

RESISTANCE = 1500

ENVIRONMENT CODE - 5

GRADE OF RELIABILITY = LOWER

MULTIPLE OF LONGEVITY = 6

PI(L)= -2.64

STRESS RATIO = 0.71

TEMPERATURE

FAILURE RATE (%/1000 HRS.)

2

5

3-244995-02

2-46895

4-81417

EXAMPLE II

(SEMICONDUCTORS)
SEMICONDUCTOR FAILURE RATE

INSTRUCTIONS -- YES OR NO?NO

ENVIRONMENT = (1) LAB, (2) SO, (3) GF, (4) GP, (5) AI,
(6) GM, (7) AU, (8) SL OR (9) M -- INPUT 1,2,... OR 9?3

SEMC. MODEL =:

- 1 GENERAL TRANSISTOR
- 2 FIELD EFFECT
- 3 UNIJUNCTION
- 4 DIODES AND RECTIFIERS
- 5 ZENER DIODES
- 6 SILICON CONTROLLED RECTIFIERS (SCR)
- 7 MICROWAVE DETECTORS AND MIXERS
- 8 VARACTOR AND STEP RECOVERY DIODES

INPUT 1,2,....,OR8?1

PART TYPE =:

- 1 SI-NPN
- 2 SI-PNP
- 3 GE-PNP
- 4 GE-NPN

INPUT 1,2,...,?1

GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2?1

APPLICATION :

- 1 LINEAR(AC)
- 2 LINEAR(DC)
- 3 LOW NOISE(AUDIO)
- 4 HIGH FREQUENCY(RF)
- 5 LOW NOISE(RF)
- 6 LOGIC SWITCHING

INPUT 1,2,....,?1

CURRENT OR POWER RATING =:

- 1 0 TO 100 MW
- 2 100 TO 500 MW
- 3 .5 TO 1.
- 4 1. TO 5
- 5 .5 TO 20
- 6 20

INPUT1,2,3,...,?2

VOLTAGE STRESS (PERCENT)=760

COMPLEXITY =

- 1 SINGLE TRANSISTOR
- 2 DUAL (UNMATCHED)
- 3 DUAL (MATCHED)
- 4 DARLINGTON
- 5 DUAL Emitter
- 6 MULTIPLE Emitter
- 7 COMPLEMENTARY PAIR

INPUT 1,2,3,....,?1

MAX, MIN AND INCREMENT OF STRESS RATIO =7+4,+4,+4

MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)=
730, 30, 30

GENERAL TRANSISTOR SEMICONDUCTOR

PART TYPE =SI-NPN APPLICATION =LINEAR(AC)

CURRENT OR POWER RATING (WATTS OR AMPS)=100 TO500 MW

VOLTAGE STRESS (%) = 60 COMPLEXITY =SINGLE TRANSISTOR

RELIABILITY GRADE CODE= 1 ENVIRONMENT CODE= 3

STRESS RATIO= 0.4

FAILURE RATE (%/1000 HRS)

TEMP	L(B)	L(SEM.)
30	1.66124E-03	2.59186E-02

ANOTHER ANALYSIS -- YES OR NO

?YES

SAME ENVIRONMENT -- YES OR NO?YES

SAME MODEL?YES

SAME RELIABILITY GRADE -- YES OR NO?NO

PART TYPE =:

- 1 SI-NPN
- 2 SI-PNP
- 3 GE-PNP
- 4 GE-NPN

INPUT 1,2,...?1

GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2?2

APPLICATION :

- 1 LINEAR(AC)
- 2 LINEAR(DC)
- 3 LOW NOISE(AUDIO)
- 4 HIGH FREQUENCY(RF)
- 5 LOW NOISE(RF)
- 6 LOGIC SWITCHING

INPUT 1,2,...?1

CURRENT OR POWER RATING =:

- 1 0 TO 100 MW
- 2 100 TO 500 MW
- 3 .5 TO 1.
- 4 1. TO 5
- 5 5. TO 20
- 6 20

INPUT 1,2,3,...?2

VOLTAGE STRESS (PERCENT)=?60

COMPLEXITY =

- 1 SINGLE TRANSISTOR
- 2 DUAL (UNMATCHED)
- 3 DUAL (MATCHED)
- 4 DARLINGTON
- 5 DUAL Emitter
- 6 MULTIPLE Emitter
- 7 COMPLEMENTARY PAIR

INPUT 1,2,3,...?1

MAX, MIN AND INCREMENT OF STRESS RATIO =? .4,.4,.4

MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)=
730,30,30

GENERAL TRANSISTOR SEMICONDUCTOR

PART TYPE =SI-NPN APPLICATION =LINEAR(AC)

CURRENT OR POWER RATING (WATTS OR AMPS)=100 TO500 MW

VOLTAGE STRESS (%) = 60 COMPLEXITY =SINGLE TRANSISTOR

RELIABILITY GRADE CODE= 2 ENVIRONMENT CODE= 3

STRESS RATIO= 0.4

FAILURE RATE (%/1000 HRS)

TEMP	L(B)	L(SEM.)
30	1.66124E-03	0.259186

ANOTHER ANALYSIS -- YES OR NO

?YES

SAME ENVIRONMENT -- YES OR NO?NO

SAME MODEL?NO

SAME RELIABILITY GRADE -- YES OR NO?YES

ENVIRONMENT = (1) LAB, (2) SO, (3) GF, (4) GP, (5) AI,
(6) GM, (7) AU, (8) SL OR (9) M -- INPUT 1,2,... OR 975

SEMC. MODEL =:

- 1 GENERAL TRANSISTOR
- 2 FIELD EFFECT
- 3 UNIJUNCTION
- 4 DIODES AND RECTIFIERS
- 5 ZENER DIODES
- 6 SILICON CONTROLLED RECTIFIERS (SCR)
- 7 MICROWAVE DETECTORS AND MIXERS
- 8 VARACTOR AND STEP RECOVERY DIODES

INPUT 1,2,...,OR872

APPLICATION =

- 1 LINEAR(AC)
- 2 LINEAR(DC)
- 3 LOGIC SWITCH
- 4 LOW NOISE AUDIO
- 5 HIGH FREQUENCY(RF)
- 6 LOW NOISE(RF)

INPUT 1,2,..., 76

COMPLEXITY =

- 1 SINGLE DEVICE
- 2 DUAL UNMATCHED
- 3 DUAL MATCHED
- 4 DUAL COMPLEMENTARY
- 5 TETRODE

INPUT 1,2,3,...,?1

MAX, MIN AND INCREMENT OF STRESS RATIO =?.4,.4,1

MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)=
760,60,60

FIELD EFFECT SEMICONDUCTOR

APPLICATION =LOW NOISE(RF)

COMPLEXITY =SINGLE DEVICE

RELIABILITY GRADE CODE= R ENVIRONMENT CODE= S

STRESS RATIO= 0.4

FAILURE RATE (1/1000 HRS)

TEMP	L(B)	L(SEM.)
60	4.59421E-03	22.3582

ANOTHER ANALYSIS -- YES OR NO

YES

SAME ENVIRONMENT -- YES OR NOTNO

SAME MODEL?NO

SAME RELIABILITY GRADE -- YES OR NOTYES

ENVIRONMENT = (1) LAB, (2) SO, (3) GF, (4) GP, (5) AI,
(6) GM, (7) AU, (8) SL OR (9) M -- INPUT 1,2,... OR 9?6

SEMC. MODEL =:

- 1 GENERAL TRANSISTOR
- 2 FIELD EFFECT
- 3 UNIJUNCTION
- 4 DIODES AND RECTIFIERS
- 5 ZENER DIODES
- 6 SILICON CONTROLLED RECTIFIERS (SCR)
- 7 MICROWAVE DETECTORS AND MIXERS
- 8 VARACTOR AND STEP RECOVERY DIODES

INPUT 1,2,...,9?6?4

PART TYPE =:

- 1 SILICON
- 2 GERMANIUM

INPUT 1,2,...,?1

GRADE OF RELIABILITY = (1) UPPER OR (2) LOWER -- INPUT 1 OR 2?2

APPLICATION :

- 1 SIGNAL (AUDIO)
- 2 SIGNAL (IF AND RF)
- 3 LOGIC SWITCHING
- 4 POWER RECTIFIER
- 5 POWER RECT. (H.V. STACKS) VMAX > 600
- 6 FORWARD REFERENCE

INPUT 1,2,...,?3

CURRENT OR POWER RATING =:

- 1 0 TO 100 MA
- 2 100 TO 800 MA
- 3 .8 TO 1.
- 4 1 TO 3
- 5 3 TO 10
- 6 10

INPUT 1,2,3,...,?1

MAX, MIN AND INCREMENT OF STRESS RATIO =?+4,+4,+4

MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE (DEGREES C)=
730, 30, 30

DIODES AND RECTIFIERS SEMICONDUCTOR

PART TYPE =SILICON APPLICATION =LOGIC SWITCHING

CURRENT OR POWER RATING (WATTS OR AMPS)=0 TO 100 MA

RELIABILITY GRADE CODE= 8 ENVIRONMENT CODE= 6

STRESS RATIO= 0.4

FAILURE RATE (%/1000 HRS)

TEMP	L(B)	L(SEM.)
------	------	---------

30	3.68567E-04	5.78636E-02
----	-------------	-------------

ANOTHER ANALYSIS -- YES OR NO
?NO

EXAMPLE III
(MICROCIRCUITS)

01/28/70 15:04

FAILURE RATE OF MICROCIRCUITS

INSTRUCTIONS--YES OR NOTNO

ENVIRONMENT =? (1) LAB, (2) SO, (3) GF, (4) GP, (5) GM,
(6) AI, (7) AU, (8) SL OR (9) MISSILE -- INPUT 1, 2,...,9
? 6

ANALYSIS FOR (1) DIGITAL OR (2) LINEAR MICROCIRCUITS - INPUT 1 OR 2?2

INPUT PART IDENTIFIEROPERATIONAL AMPLIFIER

NUMBER OF BASIC FUNCTIONS = ?1

OPEN VOLTAGE GAIN = 760

NUMBER OF EXTRA OR SPECIAL INPUTS (SUCH AS NON-INVERTING)=
? 1

NUMBER OF EXTRA OR SPECIAL OUTPUTS (SUCH AS Emitter FOLLOWER)=
? 1

NUMBER OF OTHER SPECIAL FEATURES (SUCH AS THRESHOLD LIMITING
OR EXTREME FREQ RES)=?0

TYPE OF PACKAGE =

FLATPACK -- (1) GLASS, (2) ALUMINUM, (3) METAL

OR

TO-5 -- (4) GLAS FRIT, (5) EUTECTIC SOLDER

INPUT 1, 2, 3, 4 OR 5

? 1

QUALITY GRADE = (1) OPTIMUM SCREEN, (2) UPPER GRADE,

(3) AVERAGE GRADE, (4) LOWER GRADE OR (5) EXPLANATION - INPUT 1 2,3, 4 @
? 1

WHAT IS THE MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE - DEG C
? 75, 75, 75

LINEAR MICROCIRCUITS

OPERATIONAL AMPLIFIER

NO. OF SPECIAL INPUTS = 1 NO OF SPECIAL OUTPUTS = 1

NO. OF SPECIAL FEATURES = 0 OPEN VOLTAGE GAIN = 60

ENVIRONMENT CODE = 6

COMPLEXITY FACTOR = 8 QUALITY GRADE = OPTIMUM SCREENING

JUNCT TEMP -----	BASE FAIL RATE -----	FAIL RATE (%/1000 HRS) -----
75	1.32857E-03	0.132857

ANOTHER ANALYSIS -- YES OR NO

?YES

SAME ENVIRONMENT -- YES OR NOT NO

ENVIRONMENT =? (1) LAB, (2) SO, (3) GF, (4) GP, (5) GM,
(6) AI, (7) AU, (8) SL OR (9) MISSILE -- INPUT 1, 2,...,9
?3

ANALYSIS FOR (1) DIGITAL OR (2) LINEAR MICRO CIRCUITS - INPUT 1 OR 2?1

INPUT PART IDENTIFIER?JK FLIP-FLOP

DO YOU KNOW THE VALUE OF THE COMPLEXITY FACTOR PI(C)
YES OR NOT YES

COMPLEXITY FACTOR =73

TYPE OF PACKAGE =

FLATPACK -- (1) GLASS, (2) ALUMINUM, (3) METAL

OR

TO-5 -- (4) GLAS FRIT, (5) EUTECTIC SOLDER

INPUT 1, 2, 3, 4, OR *
?4

QUALITY GRADE = (1) OPTIMUM SCREEN, (2) UPPER GRADE,

(3) AVERAGE GRADE, (4) LOWER GRADE OR (5) EXPLANATION = INPUT 1 2, 3, 4 &
?3, \

WHAT IS THE MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE - DEG C
?110, 110, 110

DIGITAL MICROCIRCUITS

JK FLIP-FLOP

ENVIRONMENT CODE = 3

COMPLEXITY FACTOR = 3

QUALITY GRADE = AVERAGE GRADE

JUNCT TEMP -----	BASE FAIL RATE -----	FAIL RATE (%/1000 HRS) -----
110	2.42916E-03	0.437262

ANOTHER ANALYSIS -- YES OR NO
?YES

SAME ENVIRONMENT -- YES OR NO?YES

SAME PART TYPE -- YES OR NO?YES

INPUT PART IDENTIFIER?JKK\ FLIP-FLOP

DO YOU KNOW THE VALUE OF THE COMPLEXITY FACTOR PI(C)
YES OR NO?YES

COMPLEXITY FACTOR =73

TYPE OF PACKAGE =

FLATPACK -- (1) GLASS, (2) ALUMINUM, (3) METAL

OR

TO-5 -- (4) GLAS FRIT, (5) EUTECTIC SOLDER

INPUT 1, 2, 3, 4, OR 5
?4

QUALITY GRADE = (1) OPTIMUM SCREEN, (2) UPPER GRADE,

(3) AVERAGE GRADE, (4) LOWER GRADE OR (5) EXPLANATION = INPUT 1 2, 3, 4 &
?3

WHAT IS THE MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE = DEG C
?110, 0, 5

DIGITAL MICROCIRCUITS

JK FLIP-FLOP

ENVIRONMENT CODE = 3

COMPLEXITY FACTOR = 3

QUALITY GRADE = AVERAGE GRADE

JUNCT TEMP	BASE FAIL RATE	FAIL RATE (%/1000 HRS)
0	2.16529E-04	3.89753E-02
5	2.51922E-04	4.53460E-02
10	2.91537E-04	5.24766E-02
15	3.35674E-04	6.04214E-02
20	3.84639E-04	6.92350E-02
25	4.38736E-04	7.89785E-02
30	4.98274E-04	8.96893E-02
35	5.63557E-04	0.101440
40	6.34892E-04	0.114281
45	7.12569E-04	0.128264
50	7.96922E-04	0.143446
55	8.88212E-04	0.159878
60	9.86740E-04	0.177613
65	1.09279E-03	0.196713
70	1.20665E-03	0.217196
75	1.32837E-03	0.239143
80	1.45883E-03	0.262590
85	1.59769E-03	0.287584
90	1.74538E-03	0.314169
95	1.90215E-03	0.342388
100	2.06823E-03	0.372282
105	2.24384E-03	0.403891
110	2.42918E-03	0.437252

EXAMPLE IV
(CAPACITORS)

01/29/70 14:42

CAPACITOR FAILURE RATE

DO YOU WISH INSTRUCTIONS -- YES OR NO?YES

THIS PROGRAM CALCULATES THE FAILURE RATE OF CAPACITORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK (SEPT 1967).

INPUT REQUIREMENTS IF APPLICABLE

1 CAPACITOR TYPE AND CODE

CODE	TYPE
1	PAPER FOIL, PAPER MYLAR, PAPER, MYLAR-METALLIZED
2	MYLAR OR TEFILON
3	PLASTIC FILM (NON-METALLIC CASE)
4	POLYSTYRENE
5	TANTALUM FOIL
6	TANTALUM, WET SLUG
7	TANTALUM, SOLID, DIELECTRIC
8	ALUMINUM, WET FOIL
9	MICA, MOLDED
10	MICA, DIPPED
11	MICA, BUTTON
12	GLASS, PORCELAIN
13	CERAMIC LOW K
14	CERAMIC, HIGH K
15	VARIABLE, CERAMIC
16	VARIABLE, GLASS PISTON

2 ENVIRONMENT AND CODE

- (1) LO, (2) SO, (3) GF, (4) GP, (5) AI,
(6) GM, (7) AU, (8) SL, AND (9) M

3 RELIABILITY LEVELS AND CODES

- (1) L, (2) M, (3) N, (4) R, (5) S

4 CASE DIMA & LENGTH (IN.)

5 CIRCUIT RESISTANCE (OHMS/VOLT)

6 CIRCUIT STYLE --- CY10, CY20, ETC.

7 CAPACITANCE (UUF)

8 MAX., MIN. AND INCREMENT OF STRESSES ---
(STRESS RATIO AND OPERATING TEMPERATURE - DEG C)

NOTE: IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS INPUT
(THAT) VALUE FOR MAX, MIN AND INCREMENT

DO YOU WISH TO RUN --- YES OR NO?YES

INPUT ENVIRONMENT CODE? 5

INPUT CAPACITOR TYPE CODE? 11

ANALYSIS FOR (1) UPPER OR (2) LOWER QUALITY GRADE ?
INPUT 1 OR 272

INPUT MAX, MIN AND INCREMENT OF STRESS RATIO? 7.6, 0., .3

INPUT MAX, MIN AND INCREMENT OF OPER. TEMPERATURE (DEGREES C)? 140, 0, 40

MICA, BUTTON CAPACITOR

ENVIRONMENT CODE = 5 LOWER GRADE

STRESS RATIO = 0

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
0	6.56250E-04	3.33300E-02
40	6.05113E-04	4.84945E-02
80	1.56274E-03	7.03096E-02
120	4.55641E-03	0.109956

STRESS RATIO = 0.3

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
0	9.35950E-04	4.44360E-02
40	1.25852E-03	5.73406E-02
80	8.26646E-03	9.76163E-02
120	6.47664E-03	0.266146

STRESS RATIO = 0.6

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
0	2.87984E-03	0.122194
40	3.67237E-03	0.161895
80	6.92448E-03	0.283979
120	1.99343E-02	0.864973

ANOTHER ANALYSIS -- YES OR NO?YES

SAME ENVIRONMENT -- YES OR NO?NO

INPUT ENVIRONMENT CODE?3

INPUT CAPACITOR TYPE CODE?13

ANALYSIS FOR (1) UPPER OR (2) LOWER QUALITY GRADE ?
INPUT 1 OR 2?1

INPUT MAX, MIN AND INCREMENT OF STRESS RATIO?0.0..1

INPUT MAX, MIN AND INCREMENT OF OPER. TEMPERATURE (DEGREES C)?0..120..40

CERAMIC LOW K CAPACITOR

ENVIRONMENT CODE = 3 UPPER GRADE

STRESS RATIO = 0

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
120	2.48447E-03	9.71767E-03
80	4.69493E-04	1.97797E-03
40	9.88867E-05	4.15367E-04
0	1.99828E-05	9.98116E-05

STRESS RATIO = 0.10

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
120	2.51486E-03	1.00771E-02
80	5.07621E-04	2.05848E-03
40	1.03487E-04	4.09948E-04
0	2.06917E-05	1.02767E-04

STRESS RATIO = 0.2

TEMPERATURE 0 C	FAILURE RATE (%/1000HRS.) L(B)	L(P)
120	3.14983E-03	1.25913E-02
80	6.34626E-04	2.55616E-03
40	1.26100E-04	5.32435E-04
0	2.53647E-05	1.23459E-04

APPENDIX

PROGRAM INSTRUCTION LISTINGS

THIS APPENDIX PRESENTS LISTINGS OF THE PROGRAM INSTRUCTIONS AS DISCUSSED
IN SECTION III, 2, OF THIS REPORT.

FAILURE RATES FOR CARBON COMPOSITION RESISTORS

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY AND A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR CARBON COMP. RES. IN ACCORDANCE WITH THE RADG RELIABILITY NOTEBOOK, SEPT. 1967.

INPUT REQUIREMENTS

1. RESISTOR STYLE
2. RESISTANCE VALUE (OMMS)
3. ENVIRONMENT -- LABORATORY, GROUND, ETC.,
4. THE MULTIPLE OF LONGEVITY AND THE VALUE OF PI(L) IF THE FAILURE RATE FOR A MULTIPLE OF LONGEVITY IS TO BE CALCULATED
5. STRESS CONDITIONS
 - A. STRESS RATIO = OPERATING POWER/POWER RATING
MAX, MIN AND INCREMENT
 - B. OPERATING TEMPERATURE (DEGREES C)
MAX, MIN, AND INCREMENT

NOTES:

THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY
THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM

IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS CONDITION
INPUT THE VALUE FOR MAX, MIN, AND INC -- EXAMPLE 1,1,1

MANY OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUT CODES
THE INPUTS ARE ENTERED BY THE KEYBOARD AS THEY ARE QUERIED

FAILURE RATE FOR FILM RESISTORS

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY AND A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR FILM RESISTORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967.

INPUT REQUIREMENTS

1. RESISTOR TYPE -- POWER, PRECISION, ESTABLISHED RELIABILITY OR INSULATED
2. RESISTANCE VALUE
3. ENVIRONMENT -- LABORATORY, GROUND, ETC.
4. MULTIPLE OF LONGEVITY AND PI(L)
5. RELIABILITY LEVEL
6. RESISTOR CHARACTERISTIC
7. RESISTOR POWER (WATTS)
8. MAX, MIN AND INC OF THE STRESS RATIO AND OPER. TEMPERATURE
STRESS RATIO = OPERATING POWER/RATED POWER

NOTES

THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY
THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM

MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUTS

IF ONLY ONE ENTRY IS REQUIRED FOR THE STRESS RATIO OR THE OPER TEMPERATURE INPUT THE SAME VALUE FOR MAX, MIN AND INC

FAILURE RATE FOR FIXED WIREWOUND RESISTORS

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY AND A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY OF WIREWOUND RESISTORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967.

INPUT REQUIREMENTS

1. RESISTOR TYPE -- ACCURATE OR POWER
OR INSULATED
2. RESISTANCE VALUE
3. ENVIRONMENT -- LABORATORY, GROUND, ETC.
4. VALUE OF PI(L) FOR MULTIPLE OF LONGEVITY
5. RELIABILITY GRADE -- UPPER OR LOWER
6. RESISTOR CHARACTERISTIC
7. MAX, MIN AND INCREMENT OF THE STRESS RATIO AND OPER TEMPERATURE
STRESS RATIO = OPERATING POWER/RATED POWER

NOTES

THE ONLY INPUT TO THE PROGRAM THAT IS REQUIRED FROM THE NOTEBOOK IS THE VALUE OF THE PI(L) FOR LONGEVITY
AND THE RESISTANCE STYLE -- EXAMPLE RW 70

THE REST OF THE ABOVE INPUTS ARE CODED IN THE PROGRAM
MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUTS
IF ONLY ONE ENTRY IS REQUIRED FOR THE STRESS RATIO OR THE
OPER TEMPERATURE INPUT THE SAME VALUE FOR MAX, MIN AND INC

FAILURE RATES FOR POTENTIOMETERS

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE CATASTROPHIC FAILURE RATE FOR THE FIRST PERIOD OF LONGEVITY AND A MULTIPLE OF THE FIRST PERIOD OF LONGEVITY FOR POTENTIOMETERS IN ACCORDANCE WITH THE RAD/C RELIABILITY NOTEBOOK, SEPT. 1967.

INPUT REQUIREMENTS

ENVIRONMENT - LABORATORY, SATELLITE ORBIT, ETC.

APPLIED VOLTAGE, RATED VOLTAGE, RESISTANCE (OHMS)

NUMBER OF TAPS, NUMBER OF SECTIONS, GANG - FIRST, SECOND, ETC-

AND THE VALUE OF PI(EFF) F IN ACCORDANCE WITH STEP 3

PAGE 78 OF THE NOTEBOOK

NOTES:

THE USER IS GIVEN THE OPTION OF INPUTTING OR HAVING THE STRESS RATIO CALCULATED BY THE COMPUTER

THE NUMBER OF SECTIONS AND THE VALUE OF PI(EFF) IS NOT REQUIRED IF THE ADJUSTED STRESS RATIO HAS BEEN PREASSIGNED.

MANY OF THE OUTPUTS ARE CODED IN ACCORDANCE WITH THE INPUT CODES

IF ONLY ONE VALUE FOR A GIVEN STRESS CONDITION IS DESIRED INPUT THAT VALUE FOR MAX, MIN AND INCREMENT

02/03/70 15:54

CAPACITOR FAILURE RATE

DO YOU WISH INSTRUCTIONS -- YES OR NO? YES

THIS PROGRAM CALCULATES THE FAILURE RATE OF CAPACITORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK (SEPT 1967).

INPUT REQUIREMENTS IF APPLICABLE

1 CAPACITOR TYPE AND CODE

CODE TYPE

1	PAPER FOIL, PAPER NYLAR, PAPER, NYLAR-METALLIZED
2	NYLAR OR TEFLON
3	PLASTIC FILM (NON-METALLIC CASE)
4	POLYSTYRENE
5	TANTALUM FOIL
6	TANTALUM, WET SLUG
7	TANTALUM, SOLID, DIELECTRIC
8	ALUMINUM, WET FOIL
9	MICA, MOLDED
10	MICA, DIPPED
11	MICA, BUTTON
12	GLASS, PORCELAIN
13	CERAMIC LOW K
14	CERAMIC, HIGH K
15	VARIABLE, CERAMIC
16	VARIABLE, GLASS PISTON

2 ENVIRONMENT AND CODE

- (1) LO, (2) SO, (3) GF, (4) GP, " AI,
(6) GM, (7) AU, (8) SL, AND (9) N

3 RELIABILITY LEVELS AND CODES

- (1) L, (2) M, (3) N, (4) R, (5) S

4 CASE DIM & LENGTH (IN.)

5 CIRCUIT RESISTANCE (OMMS/VOLT)

6 CIRCUIT STYLE --- CY10, CY20, ETC.

7 CAPACITANCE (UUF)

8 MAX., MIN. AND INCREMENT OF STRESSES ---
(STRESS RATIO AND OPERATING TEMPERATURE - DEG C)

NOTE: IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS INPUT
(THAT) VALUE FOR MAX, MIN AND INCREMENT

DO YOU WISH TO RUN --- YES OR NO?

CONNECTOR FAILURE RATE

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE FAILURE RATE OF CONNECTORS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK,
SEPT 1967.

INPUT REQUIREMENTS AND CODES

1 ENVIRONMENT

- (1) LABORATORY, (2) GROUND, FIXED, (3) GROUND PORTABLE
- (4) GROUND, MOBILE, (5) AIRBORNE, INHABITED,
- (6) AIRBORNE, UNINHABITED, (7) SATELLITE ORBIT
- (8) SATELLITE LAUNCH, (9) MISSILE

2 CONNECTOR IDENTIFIER

(ONLY FOR IDENTIFICATION -- NOT USED FOR CALCULATIONS)

3 RELIABILITY GRADE == UPPER OR LOWER

4 MATERIAL == (1) A, (2) B, (3) C, (4) D

5 EXPECTED CURRENT (AMPS)

6 NUMBER OF ACTIVE PINS

7 CYCLES/1000 HRS.

8 MAX, MIN AND INCREMENT OF AMBIENT TEMPERATURE
(DEGREES C)

9 PIN GAGE == (1) 02, (2) 06, (3) 16, (4) 12

NOTES:

CODES = NUMBERS IN BRACKETS ()

IF ONLY ONE VALUE FOR AMBIENT TEMPERATURE IS TO
ENTERED, INPUT THAT VALUE FOR MAX, MIN AND INCREMENT

INPUTS TO THIS PROGRAM ARE ENTERED THROUGH THE KEYBOARD AS
THEY ARE QUERIED.

MANY OUTPUTS ARE IN ACCORDANCE WITH THE INPUT CODES

FAILURE RATES OF RELAYS

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE FAILURE RATE AND THE FAILURE RATE OF RELAYS IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK (SEPT 1967).

INPUT REQUIREMENTS AND CODES

1 ENVIRONMENT

- (1) LABORATORY (2) SATELLITE ORBIT
- (3) GROUND FIXES (4) GROUND PORTABLE
- (5) AIRBORNE INHABITED (6) GROUND MOBILE
- (7) AIRBORNE UNINHABITED (8) SATELLITE LAUNCH
- (9) MISSILE

2 CONTACT FORM AND QUANTITY

- (1) SPST (2) DPST (3) SPDT
- (4) 3PST (5) 4PST (6) DPDT
- (7) 3PDT (8) 4PDT (9) 6PDT

3 PART IDENTIFIER

ONLY FOR PART IDENTIFICATION - NOT USED IN CALCULATIONS

4 GRADE OF RELIABILITY -- (1) UPPER (2) LOWER

5 CYCLES/HR

6 LOAD TYPE - (1) RESISTIVE (2) INDUCTIVE (3) LAMP

7 TEMPERATURE RATING - (1) 85 OR (2) 125 DEGREES

8 MAX, MIN AND INCREMENT OF STRESS RATIO - (LOAD/RATED RESISTANCE LOAD)

9 MAX, MIN AND INCREMENT OF OPERATING TEMPERATURE

NOTES:

IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS INPUT
THAT VALUE FOR MAX,MIN AND INCREMENT OF THE STRESS

MANY OF THE OUTPUTS ARE IN ACCORDANCE WITH THE INPUT CODES

FAILURE RATES FOR SWITCHES

INSTRUCTIONS

THIS PROGRAM CALCULATES THE FAILURE RATE OF SWITCHES IN ACCORDANCE WITH THE RADC RELIABILITY NOTEBOOK, SEPT. 1967.

INPUT REQUIREMENTS AND CODES

- 1 ENVIRONMENT & CODE
 - (1) LABORATORY, (2) SATELLITE ORBIT, (3) GROUND FIXED
 - (4) GROUND PORTABLE, (5) AIRBORNE INHABITES,
 - (6) GROUND MOBILE, (7) SATELLITE LAUNCH
- 2 RELIABILITY GRADE -- (1) UPPER, (2) LOWER OR (3) BOTH
- 3 MAX., MIN. AND INCREMENT OF SWITCHING CYCLES/HR.
- 4 SWITCH DESCRIPTION -- (1) TOGGLE OR PUSHBUTTON (SINGLE BODY), (2) BASIC SENSITIVE SWITCH (SINGLE BODY OR MULTIPLE GROUPS),
(3) ACTUATION ASSEMBLY (USING BASIC SENSITIVE SWITCH OR ROTARY WAFERS), (4) ROTARY SWITCH WAFERS
- 5 SWITCH TYPE - 1 SNAP ACTION, 2 NON-SNAP ACTION
3 ACTUATION DIFFERENTIAL $> .002$ IN.,
4 ACTUATION DIFFERENTIAL $< .002$ IN.,
5 CERAMIC RF WAFERS, 6 MEDIUM POWER WAFERS
- 6 NUMBER OF CONTACTS, ACTIVE SWITCHES OR BASIC SENSITIVE SWITCHES.

NOTES:

THE NUMBERS IN BRACKETS (X) ARE THE CODES.

THE CODES FOR THE SWITCH TYPE ARE NOT CONSTANT FOR EVERY RUN
IF ONLY ONE VALUE IS TO BE ENTERED FOR THE CYCLES/HR.
INPUT THAT VALUE FOR MAX, MIN AND INCREMENT

MANY OF THE OUTPUTS ARE IN ACCORDANCE WITH THE INPUT CODES.

SEMICONDUCTOR FAILURE RATE

INSTRUCTIONS

THIS PROGRAM CALCULATES THE BASE AND CATASTROPHIC FAILURE RATE OF SEMICONDUCTORS IN ACCORDANCE WITH THE RAD/C
RELIABILITY NOTEBOOK, VOL II, SEPT., 1967.

INPUT REQUIREMENTS AND CODES

1 ENVIRONMENT

- (1) LABORATORY (2) SATELLITE ORBIT
- (3) GROUND FIXED (4) GROUND PORTABLE
- (5) AIRBORNE INHABITED (6) GROUND MOBILE
- (7) AIRBORNE UNINHABITED (8) SATELLITE LAB
- (9) MISSILE

2 MODEL

- (1) GENERAL TRANSISTOR, (2) FIELD EFFECT, (3) UNIJUNCTION
- (4) DIODES AND RECTIFIERS, (5) ZENER DIODES,
- (6) SILICON CONTROLLED RECTIFIERS (SCR)
- (7) MICROWAVE DETECTORS AND MIXERS, AND
- (8) VARACTOR AND STEP RECOVERY DIODES

3 PART TYPE

4 GRADE OF RELIABILITY -- (1) UPPER OR (2) LOWER

5 APPLICATION

6 CURRENT OR POWER RATING (WATTS/AMPS)

7 VOLTAGE STRESS (PERCENT)

8 MAX, MIN AND INCREMENT OF STRESS RATIO

9 MAX, MIN AND INCREMENT OF OPER TEMPERATURE

NOTES

PART TYPE, APPLICATION, AND CURRENT OR POWER RATING ARE CODED
HOWEVER, THEY ARE NOT THE SAME FOR EACH MODEL, THUS THEY ARE NOT
INCLUDED HERE-IN. THESE CODES SHOULD NOT GIVE THE USER ANY
DIFFICULTY SINCE THEY ARE STRAIGHT FORWARD

IF ONLY ONE VALUE IS TO BE ENTERED FOR A STRESS, INPUT THAT
VALUE FOR MAX, MIN AND INCREMENT.

FAILURE RATE OF MICROCIRCUITS

INPUT REQUIREMENTS

1 ENVIRONMENT

- (1) LABORATORY, (2) SATELLITE ORBIT, (3) GROUND FIXED,
- (4) GROUND PORTABLE, (5) GROUND MOBILE,
- (6) AIRBORNE INHABITED, (7) AIRBORNE UNINHABITED,
- (8) SATELLITE LAUNCH, (9) MISSILE

2 PART IDENTIFIER

3 NUMBER OF BASIC FUNCTIONS

4 OPEN VOLTAGE GAIN

5 NUMBER OF EXTRA OR SPECIAL INPUTS

6 NUMBER OF EXTRA OR SPECIAL OUTPUTS

7 TYPE OF PACKAGE

8 QUALITY GRADE

9 MAX, MIN AND INCREMENT OF JUNCTION TEMPERATURE

UNCLASSIFIED

Security Classification

DOCUMENT CONTROL DATA - R & D

(Security classification of title, body of abstract and indexing annotation must be entered when the overall report is classified)

1. ORIGINATING ACTIVITY (Corporate entity)		1a. REPORT SECURITY CLASSIFICATION Unclassified
Rome Air Development Center (EMNRR) Griffiss Air Force Base, New York 13440		1b. GROUP N/A
2. REPORT TITLE COMPUTERIZED RADC RELIABILITY NOTEBOOK (GE/645/TSS/BASIC)		
3. DESCRIPTIVE NOTES (Type of report and inclusive dates) In-house Final Technical Report		
4. AUTHOR(S) (First name, middle initial, last name) George W. Lyne		
5. REPORT DATE March 1970	7a. TOTAL NO. OF PAGES 95	1b. NO. OF REPS
6. CONTRACT OR GRANT NO.	9c. ORIGINATOR'S REPORT NUMBER(S)	
7. PROJECT NO. 5519	9d. OTHER REPORT NO(S) (Any other numbers that may be assigned this report)	
10. DISTRIBUTION STATEMENT This document is subject to special export controls and such transmittal to foreign governments or foreign nationals may be made only with prior approval of RADC (EMNRR), Griffiss Air Force Base, New York 13440.		
11. SUPPLEMENTARY NOTES	12. SPONSORING MILITARY ACTIVITY Rome Air Development Center (EMNRR) Griffiss Air Force Base, New York 13440	
13. ABSTRACT Computer programs which enable the reliability engineer to mechanically apply the "RADC Reliability Notebook," Volume II, September 1967, in obtaining the failure rate of piece parts are presented.		

DD FORM 1 NOV 68 1473

UNCLASSIFIED

Security Classification

UNCLAS IFIND

Security Classification

14 KEY WORDS	LINK A		LINK B		LINK C	
	ROLE	WT	ROLE	WT	ROLE	WT
Computer Reliability						

UNCLASSIFIED
Security Classification