

AD-A050 501 NORTHROP CORP HAWTHORNE CALIF ELECTRONICS DIV F/G 17/7
AN/BRN-7 COMPUTER PROGRAM SPECIFICATION. VOLUME XIII. APPENDIX.(U)
OCT 73
UNCLASSIFIED NORT-73-48 N00039-73-C-0209
NL





VOL XIII

NORTHROP

Electronics Division

- ☐ This submittal applies to AN/BRN-7 (Submarine Ω) only.
- ☐ This submittal applies to AN/SRN-( ) (Hydrofoil Ω) only.
- ☒ This submittal applies to both AN/BRN-7 and AN/SRN-( ).

CONTRACT NO: N00039-73-C-0209

PROGRAM NAME: AN/BRN-7

CDRL No: A01D, A01E, A01F

Title of CDRL: Computer Program Design Specification
Computer Subprogram Design Document
Data Base Design Document

Title of Doc: AN/BRN-7 Computer Program Specification
NORT 73-48
Volume 2 thru 13

Date: 1/16/74

Initial Submittal: [X]

Resubmittal: [ ]

Release	APS 1-16-74
Authentication	

ACCESSION for
RTIS White Section X
DDC Gulf Section ☐
UNANNOUNCED ☐
JUSTIFICATION
Per DDC Form 50
BY on file
DISTRIBUTION/AVAILABILITY CODES
Dist. AVAIL. and/or SPECIAL
A

Prepared by: System Integration Unit
Orgn. Name

A4734 X574
Orgn. No. and Ext.

Approved by:

Norman C. Clark
Supervisor of Preparing Orgn.

Bill Taylor
Program Mgr.

C. M. Oman
Proj. Engr./Proj. Mgr.

FORM 6512 (2-72)

NORTHROP

Electronics Division

AD-A050501

NORT 73-48

AN/BRN-7 COMPUTER PROGRAM SPECIFICATION

Volume XIII

APPENDIX

October 12, 1973

DDC
RECEIVED
FEB 28 1978
D

Approved by

G. W. Hauser
Director, Engineering
Navigation Department

DISTRIBUTION STATEMENT A
Approved for public release;
Distribution Unlimited

Volume XIII

of the

AN/BRN-7 OMEGA COMPUTER
PROGRAM SPECIFICATION

Volume	
I	Performance Specification
II	Design Specification
III	Synchronization Subprogram Design
IV	OMEGA Processing Subprogram Design
V	Tracking Filter Subprogram Design
VI	Kalman Filter Subprogram Design
VII	Propagation Prediction Subprogram Design
VIII	Navigation Subprogram Design
IX	Executive Subprogram Design
X	Control-Indicator Subprogram Design
XI	Built-in Test Subprogram Design
XII	Common Subroutines Subprogram Design
XIII	Appendix

SECTION 1

SCOPE

Volume I, Submarine OMEGA Computer Program Performance Specification, defines the functional requirements for the Submarine OMEGA Computer Program which is used by the AN/BRN-7 OMEGA Navigation Set. The navigation set and the OMEGA program together comprise the Submarine OMEGA Navigation System. The tape which defines the computer program is entitled AN/BRN-7 Navigation Program.

Volume II, Submarine OMEGA Computer Program Design Specification, allocates the functional requirements of Volume I to the computer routine and subprogram level.

This volume is the listing of the Submarine OMEGA Computer Program tape, designated above, whose contents are described by the subprogram design documents, Volumes III through XII of the Submarine OMEGA Computer Program Specification.

SECTION 2

APPLICABLE DOCUMENTS

a) Volume I, Submarine OMEGA Computer Program Performance Specification

b) Volume II, Submarine OMEGA Computer Program Design Specification

c) Volume III, Synchronization Subprogram Design

d) Volume IV, OMEGA Processing Subprogram Design

e) Volume V, Tracking Filter Subprogram Design

f) Volume VI, Kalman Filter Subprogram Design

g) Volume VII, Propagation Prediction Subprogram Design

h) Volume VIII, Navigation Subprogram Design

i) Volume IX, Executive Subprogram Design

j) Volume X, Control Indicator Subprogram Design

k) Volume XI, Built-in-Test Subprogram Design

l) Volume XII, Common Subroutines Subprogram Design

m) NORT 71-41 NDC-1070 MACRO ASSEMBLER, MAY 1971

n) NORT 68-115A, Detailed Description of NDC-1070 Computer Instructions, Revision A, February 1970

o) NORT 69-87A, NDC-1070 Flow Chart Program User's Manual

SECTION 3

DESCRIPTION

This volume contains a listing and label cross-reference list for the Submarine OMEGA Operational Computer Program. This listing defines the exact configuration of the SCDP.

The listing and label cross-reference list is an output of the NAP-70 Assembler program that is produced at the same time that punched tape is generated. The NDC-1070 MACRO ASSEMBLER (NORT 71-41) and the NDC-1070 Flow Chart Program User's Manual (NORT 69-87A) describe the format of the listing and the meaning of special characters and symbols.

The overall organization of the listing is given in the table below.

Pages	
1 - 4	I/O Equivalance Dictionary
5 - 250	Description of memory location 0 to 1737 in sequential order
251 - 258	Description of variable storage memory location 1B39 to 1FFF in inverse sequential order
259 - 264	Description of memory locations 181D to 1990.
265 - 317	Description of memory locations 1991 in sequential order
318 - 319	Literal listing
320 - 322	Assembler Statistics
323 - 344	Cross-Reference List

Note: Equivalences not in the I/O Dictionary are placed in convenient places in the listing, usually near the instructions that use the equivalences.

Users of the listing and the flow charts should rely on the cross-reference list to locate labels in the listing. In particular, main labels that appear on the flow charts can be quickly located in the listing by looking in the cross-reference list to find the memory location associated with the label

and then turning to that location in the listing. Another important use of the cross-reference list is to identify all the users of an operand. The memory location of every instruction that addresses the operand is given in the cross-reference list entry for that operand.

NORTHROP Electronics Division

☐	This submittal applies to AN/BRN-7 (Submarine Ω) only.
☐	This submittal applies to AN/SRN-( ) (Hydrofoil Ω) only.
☒	This submittal applies to both AN/BRN-7 and AN/SRN-( ).

CONTRACT NO: N00039-73-C-0209

PROGRAM NAME: OMEGA NAVIGATIONAL SET
AN/BRN-7 AND AN/SRN-17

CDRL No: A01F

Title of CDRL: DATA BASE DESIGN DOCUMENT

Title of Doc: PROGRAM LISTING
MOD 36 & CORRECTION ON PAGE 83

Date: 19 MAY 1976

Initial Submittal: ☐ Release MZ, 21 May 76

Resubmittal: ☒ Authentication

Prepared by: PROJ. ENGR.
Orgn. Name

4150 545
Orgn. No. and Ext.

NOTE: THIS SUBMISSION IN RESPONSE TO NAVY LETTER 52013B:DC pw DATED 16 JULY 1975.

Approved by:

[signature]	C Jones by WWW	WWWeimer 5/20/76
Supervisor of Preparing Orgn.	Program Mgr.	Proj. Engr./Proj. Mgr.

FORM 6512 (2-72)

```
PROGRAM_ID  VIS          "MOD 35                  AN/BRN-7 "                    10750  NEW            0
PROGRAM_ID  VIS          "MOD 36  02/06/75 AN/BRN-7 "                           10750  REPLACED
```

```
MOD 36  05/18/76  AN/BRN-7                                                    PAGE   1
                **/          LIBRARY       OMEGA_IO_DICTIONARY   04/04/69      000010
                *         IOC,SET, AND SNS LABEL DEFINITIONS                   000020
                *            IOC            CODES                            IC000030
  1                          INHIBIT_BOTH_CSE_INTERRUPTS;                     IC000040
  1     8000                       EQU          X(8000)        1000 .... .... ....  IC000050
  2                          LOAD_PRINTER;                                    IC000060
  2     DF01                       EQU          X(DF01)        1101 1111 .... 0001  IC000070
  3                          LOAD_PUNCH;                                      IC000080
  3     DF02                       EQU          X(DF02)        1101 1111 .... 0010  IC000090
  4                          READ_TAPE;                                       IC000100
  4     CF01                       EQU          X(CF01)        1100 1111 .... 0001  IC000110
  5                          RESET_CMP_INTERRUPT;                             IC000120
  5     9F00                       EQU          X(9F00)        1001 1111 .... ....  IC000130
  6                          INHIBIT_CMP_INTERRUPT;                           IC000140
  6     AF00                       EQU          X(AF00)        1010 1111 .... ....  IC000150
  7                          ENABLE_CMP_INTERRUPT;                            IC000160
  7     BF00                       EQU          X(BF00)        1011 1111 .... ....  IC000170
  8                          READ_START_ADDRESS;                              IC000180
  8     CF02                       EQU          X(CF02)        1100 1111 .... 0010  IC000190
  9                          READ_STOP_ADDRESS;                               IC000200
  9     CF03                       EQU          X(CF03)        1100 1111 .... 0011  IC000210
 10                          LOAD_PMU_REGISTER;                               IC000220
 10     DE00                       EQU          X(DE00)        1101 1110 .... 0000  IC000230
 11                          LOAD_PMU_TIMER;                                  IC000240
 11     DE0A                       EQU          X(DE0A)        1101 1110 .... 1010  IC000250
 12                          READ_PMU_KEYBOARD;                               IC000260
 12     CE08                       EQU          X(CE08)        1100 1110 .... 1011  IC000270
 13                          RESET_PMU_INTERRUPT;                             IC000280
 13     9E00                       EQU          X(9E00)        1001 1110 .... ....  IC000290
 14                          RESET_RECORDER_INTERRUPT;                        IC000300
 14     9B00                       EQU          X(9B00)        1001 1011 .... ....  IC000310
 15                          INHIBIT_RECORDER_INTERRUPT;                      IC000320
 15     AB00                       EQU          X(AB00)        1010 1011 .... ....  IC000330
 16                          ENABLE_RECORDER_INTERRUPT;                       IC000340
 16     BB00                       EQU          X(BB00)        1011 1011 .... ....  IC000350
 17                          LOAD_RECORDER;                                   IC000360
 17     CB00                       EQU          X(CB00)        1100 1011 .... ....  IC000370
 18                          PROGRAMMER_CONTROLLER_GO_LIGHT;                    000380
 18     8CC3                       EQU          X(8CC3)                             000390
```

```
                **          SNS                 CODES
19                      DOPPLER_IN_MEMORY;                                                  SS000400
19                              EQU             X(0000)     0... .... 0000 ....            SS000410
20                      INERTIAL_SYSTEM_NO_GO;                                              SS000420
20      0010                    EQU             X(0010)     0... .... 0001 ....            SS000430
21                      NAV_INERTIAL_DOPPLER_MODE;                                          SS000440
21      0020                    EQU             X(0020)     0... .... 0010 ....            SS000450
22                      HEADING_EXITATION_A;                                                000460
22      0030                    EQU             X(0030)     0... .... 0011 ....            SS000470
23                      SPEED_EXITATION_B;                                                  000480
23      0040                    EQU             X(0040)     0... .... 0100 ....            SS000490
24                      PFG_COUNTDOWN_NO_GOOD;                                              SS000500
24      0050                    EQU             X(0050)     0... .... 0101 ....            SS000510
25                      OMNI_ANTENNA_AVAILABLE;                                             SS000520
25      0060                    EQU             X(0060)     0... .... 0110 ....            SS000530
26                      PUNCH_OR_PRINTER_BUSY;              LOW INDICATOR RESET IF TRUE     SS000540
26      8F10                    EQU             X(8F10)     1... 1111 0001 ....            SS000550
27                      TAPE_READER_DATA_READY;             LOW INDICATOR RESET IF TRUE     SS000560
27      8F20                    EQU             X(8F20)     1... 1111 0010 ....            SS000570
28                      PMU_KEYBOARD_REQUEST;               LOW INDICATOR RESET IF TRUE     SS000580
28      8E10                    EQU             X(8E10)     1... 1110 0001 ....            SS000590
29                      PMU_TIMER_OVERFLOW;                 LOW INDICATOR RESET IF TRUE     SS000600
29      8E20                    EQU             X(8E20)     1... 1110 0010 ....            SS000610
30                      PMU_DISPLAY_BUSY;                   LOW INDICATOR RESET IF TRUE     SS000620
30      8E30                    EQU             X(8E30)     1... 1110 0011 ....            SS000630
31                      HIGH_SPEED_PRINTER_BUSY;            LOW INDICATOR RESET IF TRUE     SS000640
31      8000                    EQU             X(8000)     1... 1101 .... ....            SS000650
32                      TAPE_RECORDER_BUSY;                 LOW INDICATOR RESET IF TRUE     SS000660
32      8801                    EQU             X(8801)     1000 1011 .... ..01            SS000670
33                      TAPE_RECORDER_INTERRUPT;            LOW INDICATOR RESET IF TRUE     SS000680
33      8802                    EQU             X(8802)     1000 1011 .... ..10            SS000690
```

```
                **          SET          CODES                                    ST000710
34                      RESET_PFG_COUNTDOWN;                                     ST000720
34  000A                        EQU      X(000A)      0... .... .... 101.        ST000730
35                      PROGRAM_SEQUENCING;                                      ST000740
35  000C                        EQU      X(000C)      0... .... .... 110.        ST000750
36                      MEMORY_AUGMENTER_GO;                                     ST000760
36  0008                        EQU      X(0008)      0... .... .... 100.        ST000770
37                      HIGH_SPEED_PRINTER_OUTPUT;    BITS 1-8 DEFINE CHARACTER CODE ST000780
37  8D00                        EQU      X(8D00)      1... 1101 XXXX XXXX        ST000790
38                      INTER_RECORD_GAP;                                        ST000800
38  8B01                        EQU      X(8B01)      1000 1011 .... ..01        ST000810
39                      WRITE_FILE_GAP;                                          ST000820
39  8B02                        EQU      X(8B02)      1000 1011 .... ..10        ST000830
40                      DISABLE_MEMORY_PROTECT;                                  ST000840
40  8E20                        EQU      X(8E20)      1... 1110 0010 ...0        ST000850
41                      ENABLE_MEMORY_PROTECT;                                   ST000860
41  8E21                        EQU      X(8E21)      1... 1110 0010 ...1        ST000870
                        *                ADDENDA FOR PMU INDICATORS               ST000880
42                      PMU_INDICATORS;                                          ST000890
42  8E10                        EQU      X(8E10)      1... 1110 0001 0000        ST000900
43  0008    ALPHA       EQU      X(0008)      .... .... .... 1...        ST000910
44  0004    BETA        EQU      X(0004)      .... .... .... .1..        ST000920
45  0002    GAMMA       EQU      X(0002)      .... .... .... ..1.        ST000930
46  0001    ERROR       EQU      X(0001)      .... .... .... ...1        ST000940
                        *                ADDENDA FOR TAPE CONTROL                 ST000950
47                      TAPE_CONTROL;                                            ST000960
47  8F10                        EQU      X(8F10)      1... 1111 0001 0000        ST000970
48  0001    FORWARD     EQU      X(0001)      .... .... .... ...1        ST000980
49  0002    RUN         EQU      X(0002)      .... .... .... ..1.        ST000990
50  0004    VERIFY_ON   EQU      X(0004)      .... .... .... .1..        ST001000
51  0008    SELFTEST_ON EQU      X(0008)      .... .... .... 1...        ST001010
52  0000    REVERSE     EQU      X(0000)      .... .... .... ...0        ST001020
53  0000    STOP        EQU      X(0000)      .... .... .... ..0.        ST001030
                        *                ADDENDA FOR TAPE FILL                    ST001040
54  8F20    TAPE_FILL   EQU      X(8F20)      1... 1111 0010 0000        ST001050
55  0000    ENABLE_READ EQU      X(0000)      .... .... .... ...0        ST001060
56                      INHIBIT_READ;                                            ST001070
56  0001                        EQU      X(0001)      .... .... .... ...1        ST001080
57  0002    FORCE       EQU      X(0002)      .... .... .... ..1.        ST001090
```

```
                                **                                                  001100
                                *                FLAG AND LGC EQUIVALENCE TABLE     001110
                                *                                                  001120
                                *                  1. CONDITION CODES              001130
                                *                                                  001140
58              0000            UC          EQU  X(0000)                          001150
59              0010            NE          EQU  X(0010)                          001160
60              0020            GE          EQU  X(0020)                          001170
61              0030            G           EQU  X(0030)                          001180
62              0040            LE          EQU  X(0040)                          001190
63              0050            L           EQU  X(0050)                          001200
64              0060            E           EQU  X(0060)                          001210
65              0070            NO          EQU  X(0070)                          001220
66              0080            AT          EQU  X(0080)                          001230
67              0090            AF          EQU  X(0090)                          001240
68              00A0            BT          EQU  X(00A0)                          001250
69              00B0            BF          EQU  X(00B0)                          001260
70              00C0            CT          EQU  X(00C0)                          001270
71              00D0            CF          EQU  X(00D0)                          001280
72              00E0            DT          EQU  X(00E0)                          001290
73              00F0            DF          EQU  X(00F0)                          001300
                                *                                                  001310
                                *                  2. FLIP-FLOP CODES              001320
                                *                                                  001330
74              0000            A           EQU  X(0000)                          001340
75              0001            B           EQU  X(0001)                          001350
76              0002            C           EQU  X(0002)                          001360
77              0003            D           EQU  X(0003)                          001370
78                              INTERRUPT_INHIBIT;                                 001380
78              0000                        EQU  X(0000)                          001390
79              0001            DMA_INHIBIT EQU  X(0001)                          001400
80              0002            PIN_MODE    EQU  X(0002)                          001410
                                *                                                  001420
                                *                  3. LOGIC CODES                  001430
                                *                                                  001440
81              0000            UCD         EQU  X(000)                           001450
82              0004            OR          EQU  X(0004)                          001460
83              0008            AND         EQU  X(0008)                          001470
84              000C            EOR         EQU  X(000C)                          001480
                                *//         ENDL                                  001490
                                *                                                  001500
85                              FLOATER_ANTENNA;                                   001510
85              0010                        EQU  INERTIAL_SYSTEM_NO_GO            001520
```

```
**                                                                    001530
*    001 = BLOCK 1                                                    001540
*          MAIN PROGRAM                                               001550
*       002 = BLOCK 2                                                 001560
*          DEBUG ROUTINE                                              001570
*                                                                     001580
*       004 = BLOCK 3                                                 001590
*          TEST ROUTINES - EITHER BLOCK 2 OR 4 MUST BE LOADED AT FILL 001600
*                                                                     001610
*       008 = BLOCK 4                                                 001620
*          MAGNETIC TAPE DATA ROUTINE                                 001630
*                                                                     001640
*       010 = BLOCK 5                                                 001650
*          PLOT - MODIFIES MAIN PROGRAM                               001660
*                                                                     001670
*      020 = BLOCK  6                                                 001680
*          DECIMAL PRINT ROUTINES                                     001690
*   040 = BLOCK 8                                                     001700
*          SIMULATOR, PROGRAMMER CONTROLLER FAILURE DISPLAY           001710
*   080 = BLOCK 9                                                     001720
*          PRODUCTION INSP UNUSED I/O TEST                            001730
*   100 = BLOCK 10                                                    001740
*          NAV PERF TEST                                              001750
*   200 = BLOCK 11                                                    001760
* PCI, DYNAMIC RANGE-RANDOM NOISE TEST DISPLAYS 91 ON CI PANEL        001770
*   400 = BLOCK 12                                                    001780
*        SRN-17   OPERATIONAL OVERLAY                                 001790
*                                                                     001800
*   800 = BLOCK 13                                                    001810
*          LITERALS - DOES NOT MODIFY MAIN PROGRAM                    001820
*          MUST BE LOADED WHENEVER MAIN PROGRAM IS LOADED             001830
```

```
**                          OMEGA_FILL_PUNCH                          001840
*                                                                     001850
*                                                                     001860
* FILL, COMPARE AND PUNCH PROGRAM DISCRIPTION                         001870
*                                                                     001880
*     THIS PROGRAM IS CONTROLLED FROM THE START ADDRESS SWITCHES ON THE 001890
* MAINTENANCE PANEL                                                   001900
*                                                                     001910
*      6XXX = FILL                                                    001920
*      7XXX = COMPARE, PUNCH AND PRINT                                001930
*      8XXX = COMPARE AND PRINT                                       001940
*      YXXX = HALT AND RESTART IF COMPUTE IS PRESSED                  001950
*       XXX = BLOCK SELECTOR BITS                                     001960
*                                                                     001970
* FILL - LOAD THE SELECTED BLOCKS INTO CORE.  IF BLK1 IS SELECTED     001980
*        CLEAR CORE FIRST.  FOR BLK2 AND UP MODIFY CHECKSUM.  CLEAR   001990
*        MOST OF CORE USED BY FILL PROGRAM AFTER COMPLETING FILL.     002000
*        PUT BLK SELECTOR BITS INTO BITS 5-16 OF TAPE ID WORD.        002010
*                                                                     002020
* COMPARE, PUNCH AND PRINT - UPDATE CORR NO BY 1 AND COMPARE THE      002030
*        SELECTED BLOCKS WITH CORE. PUNCH AND PRINT DIFFERENCES.  PUT 002040
*        BLK SELECTOR BITS IN FIRST 3 CHARACTERS OF CORR NUMBER ON    002050
*        VISUALS.  DECREMENT CORR NO AFTER COMPLETION.  IF BLK1 IS    002060
*        SELECTED ALSO PUNCH AND PRINT ALL NON ZERO WORDS WHERE GAPS  002070
*        OCCUR ON THE TAPE BETWEEN START_CKSUM AND END_CKSUM.  ALSO   002080
*        PUNCH OR PRINT ALL NON ZERO WORDS BETWEEN LAST_WORD+1 AND    002090
*        ROLL-1.                                                      002100
*                                                                     002110
* COMPARE AND PRINT - IDENTICAL TO COMPARE, PUNCH AND PRINT EXCEPT NO 002120
*        MODIFICATION OF CORR NO AND NO PUNCHING OF A CORR TAPE.      002130
*                                                                     002140
* BLOCK SELECTOR BITS - THESE BITS TELL THE PROGRAM WHAT BLKS TO      002150
*        PROCESS.  THE SUM OF THE DESIRED BLOCK NUMBERS SHOULD BE     002160
*        SET IN THE MAINTENANCE PANEL START ADDRESS SWITCHES.         002170
*                                                                     002180
*       001 = BLOCK 1                                                 002190
*           MAIN PROGRAM LESS LITERALS - NOTE - ANY CORR TAPES PUNCHED 002200
*           WITH BLK 1 SELECTED WILL ALSO CONTAIN ANY BLKS IN CORE THAT 002210
*           MODIFY MAIN PROGRAM IN ADDITION TO ALL CORRS TO MAIN PROGRAM 002220
*           AND THOSE BLKS      SHOULD NOT BE FILLED WHEN USING THE   002230
*           CORR TAPE.  IF BLKS THAT DO NOT MODIFY MAIN PROGRAM ARE IN 002240
*           CORE WHEN PUNCHING A TAPE BUT THE BLKS HAVE THEMSELVES BEEN 002250
*           MODIFIED THEN THOSE BLKS SHOULD BE SELECTED FOR THE CORR  002260
```

```
                                                *          TAPE AND MUST ALSO BE FILLED EVERY TIME THAT CORR TAPE          002270
                                                *          IS USED.  ANY BLK MAY BE LOADED AFTER THE CORR TAPE AND THE     002280
                                                *          APPROPIATE BLKS ARE LOADED INITIALLY.                           002290
                                                *                                                                         002300
                                                *                                                                         002310
  86                                                                TAPE      4,X(F2)                                     PV002320
  87                                                                TAPE      3,12                                        PV002330
  88                                                                TAPE      4,X(F1)                                     PV002340
  89                                                                TAPE      1                                           PV002350
  90                    0000                                        SCS                                                   PV002360
  91                    2000                          _CORE_SIZE    EQU       X(2000)                                     PV002370
  92                    1D00                                        ORG       _CORE_SIZE-X(300)                           PV002380
  93          4R        1D00  FCE91FFA                 _VERIFY       CLAM      14,,_ROLL_END                               PV002390
  94          12        1D02  F00F8E20                             SET       DISABLE_MEMORY_PROTECT                      PV002400
  95          16        1D04  FCF91FE6                             CLAM      15,,_ROLL_14                                PV002410
  96          20        1D06  FC291F58                             CLAM      2,,_END_CKSUM                               PV002420
  97          24        1D08  FC191D00                             CLAM      1,,_VERIFY                                  PV002430
  98          26        1D0A  8000                                 SUB       0,0                                         PV002440
  99           6R       1D0B  8601                    $4           ADD       I0,1                                        PV002450
 100          14        1D0C  C412    (1D08)                      BXU       1,,$4                                       PV002460
 101           4R       1D0D  D063    (1D11)                      BRE       $5                                          PV002470
 102           8R       1D0E  F00F8F10                            SET       TAPE_CONTROL+STOP                           PV002480
 103          12        1D10  0000                                HLT                                                   PV002490
 104           2R       1D11  9C2F                    $5          CLAM      2,,15                                       PV002500
 105           6        1D12  B800                                SUBD      0,0                                         PV002510
 106          10R       1D13  F1171F5C                $1          STA       X1,,_PPTEMP                                 PV002520
 107          18        1D15  C413    (1D13)                      BXU       1,,$1                                       PV002530
 108           8R       1D16  F4088000                           FETM      0,,X(8000)                                  PV002540
 109          18        1D18  F4071F60                           PTR       0,,_BLOCK_NO+1                              PV002550
 110          26        1D1A  F80F8F00                           IOC       ENABLE_CMP_INTERRUPT                        PV002560
 111          34        1D1C  F00F8F21                           SET       TAPE_FILL+INHIBIT_READ                      PV002570
 112          42        1D1E  F80FCF02                           IOC       READ_START_ADDRESS                          PV002580
 113          52        1D20  F40D1F5C                           PIP       0,,_PPTEMP                                  PV002590
 114          60        1D22  F40A1F5C                           CLA       0,,_PPTEMP                                  PV002600
 115          68        1D24  E4101F5A                           EXT       1,0,_XOFFF                                  PV002610
 116          78        1D26  F0171F5D                           STA       1,,_BLOCKS                                  PV002620
 117          80        1D28  8001                               SUB       0,1                                         PV002630
 118          90        1D29  F0071F62                           STA       0,,_FILL_COMP                               PV002640
 119          94        1D2B  F8098000                           COMM      0,,X(8000)                                  PV002650
 120          98        1D2D  D163    (1D41)                     BRE       _COMPARE                                    PV002660
 121           4R       1D2E  F8097000                           COMM      0,,X(7000)                                  PV002670
 122           8        1D30  D169    (1D4A)                     BRE       _PUNCH_TAPE                                 PV002680
 123           4R       1D31  F8096000                           COMM      0,,X(6000)                                  PV002690
```

```
124        8      1D33  0064   (1D38)            BRE     $3                                          PV002700
125        8R     1D34  F00F8F10                 SET     TAPE_CONTROL+STOP                           PV002710
126       12      1D36  0000                     HLT                                                 PV002720
127       16      1D37  D808   (1D00)            BUC     _VERIFY                                     PV002730
128        4R     1D38  F4148000          $3     LSA     1,,15           CLEAR IF BLOCK 1            PV002740
129        8      1D3A  D320   (1D68)            BGE     _START                                      PV002750
130        4R     1D3B  FC291CFF                CLAM     2,,_VERIFY-1                                PV002760
131        8      1D3D  8800                    SUBD     0,0                                         PV002770
132        8R     1D3E  7110             $2     STA      X1,,0                                       PV002780
133       16      1D3F  C412   (1D3E)            BXU     1,,$2                                       PV002790
134        4R     1D40  D20A   (1D68)            BUC     _START                                      PV002800
```

```
                                **
135      14R        1D41  F80C0151      _COMPARE    FETD    0,,X(151)                                          PV002810
136      22         1D43  F00F8F10                  SET     TAPE_CONTROL+STOP                                  PV002820
137      30         1D45  F48A014C                  CLA     8,,CORR_CKSUM                                      PV002830
138      38         1D47  F49A0152                  CLA     9,,X(152)                                          PV002840
139      42         1D49  D101    (1D5B)            BUC     _START_READ                                        002850
140       8R        1D4A  F46A014C      _PUNCH_TAPE CLA     6,,CORR_CKSUM                                      PV002860
141      16         1D4C  F00F8F10                  SET     TAPE_CONTROL+STOP                                  PV002870
142      22         1D4E  FD69FFFF                  CLAM    X6,,1(-1)                                          PV002880
143      32         1D50  F007014C                  STA     0,,CORR_CKSUM                                      PV002890
144      34         1D52  9C20                      CLAM    2,,0                                               PV002900
145      42   *     1D53  F80D1EA0                  BSV     _PPLEADER                                          PV002910
146      56         1D55  F80C0151                  FETD    0,,X(151)       TAPE AND CORRECTION NUMBER         PH002920
147      58         1D57  A491                      CLA     9,1                                                PH002930
148      60         1D58  9411                      ADDM    1,,1                                               PH002940
149      70         1D59  F0170152                  STA     1,,X(152)                                          PH002950
150       8R   *     1D5B  F80D1E78      _START_READ BSV     _PUNCHBCD                                          PH002960
151      22         1D5D  F80C014F                  FETD    0,,X(14F)       DATE AND MOD                       002970
152      30   *     1D5F  F80D1E78                  BSV     _PUNCHBCD                                          PH002980
153      38         1D61  F4080072                  FETM    0,,X(72)        STOP-CODE CHARACTER                PH002990
154      46   *     1D63  F80D1E29                  BSV     _PUNCH                                             PH003000
155      54   *     1D65  F80D1EA0                  BSV     _PPLEADER                                          PH003010
156      62         1D67  F4080071                  FETM    0,,X(71)        START-FORCE-FILL CHARACTER         PH003020
157      70   *     1D69  F80D1E29                  BSV     _PUNCH                                             PH003030
158       8R        1D6B  F00F8F20      _START      SET     TAPE_FILL+ENABLE_READ                              PH003040
159      18         1D6D  FC8A0144                  CLAD    8,,X(0144)      SAVE OLD CONTENTS                  PV003050
160      22         1D6F  FC191EFD                  CLAM    1,,_TAPE_INPUT                                     PV003060
161      26         1D71  FC09F80D                  CLAM    0,,X(F80D)      BSV                                PV003070
162      38         1D73  F8070144                  STAD    0,,X(0144)      INTERRUPT LOCATION                 PV003080
163      40         1D75  DF60                      LGC     INTERRUPT_INHIBIT+E                                PV003090
164      48         1D76  F00F8F13                  SET     TAPE_CONTROL+FORWARD+RUN                           PV003100
165      52         1D78  FC0900D4                  CLAM    0,,START_CKSUM-1                                   003110
166      54         1D7A  8C31                      CLSM    3,,1                                               PH003120
167       8R   *     1D7B  F80D1ED7      $1          BSV     _READ_DATA                                         PH003130
168      18         1D7D  F00C1F5F                  FET     0,,_BLOCK_NO    IF BLOCK ONE PUNCH GAPS BETWEEN    PH003140
169      20         1D7F  9801                      COMM    0,,1             START AND END CHECKSUM PLUS       PV003150
170      28         1D80  D700                      PRN     0                AREA AFTER LAST WORD TO ROLL-1    PV003160
171      32         1D81  D01C    (1D8E)            BNE     $3                                                 PV003170
172       4R        1D82  F8091946                  COMM    0,,END_CKSUM                                       PV003180
173       8         1D84  D012    (1D87)            BNE     $10                                                PV003190
174       4R        1D85  FC091AE6                  CLAM    0,,LAST_WORD                                       PV003200
175       2R        1D87  9CA0          $10         CLAM    10,,0           ZERO DATA FOR GAP                  PV003210
176       2R        1D88  9401          $2          ADDM    0,,1                                               PV003220
                                                                                                               PH003230
```

```
177        4        1D89  8005                    COM     0,5             TEST FOR GAP                    PH003240
178        8        1D8A  D023   (1D8E)           BGE     $3                                              PH003250
179       8R *      1D8B  F80D1DE2                BSV     $5              COMPARE DATA                    PH003260
180       12        1D8D  D806   (1D88)           BUC     $2                                              PH003270
181       4R        1D8E  F859183C         $3    COMM    5,,ROLL                                         PH003280
182        8        1D90  D025   (1D96)           BGE     $4              SKIP IF END OF TAPE             PH003290
183       2R        1D91  A405                    CLA     0,5                                             PH003300
184        4        1D92  A4A4                    CLA     10,4            DATA FROM TAPE                  PH003310
185       12 *      1D93  F80D1DE2                BSV     $5                                              PV003320
186       16        1D95  D908   (1D78)           BUC     $1                                              PV003330
187       10R       1D96  F00C1F62         $4    FET     0,,_FILL_COMP                                   PV003340
188       14        1D98  F8096000              COMM    0,,X(6000)                                      PV003350
189       18        1D9A  D01B   (1DA6)           BNE     $12                                             PV003360
190        8R       1D9B  F40A1F5F                CLA     0,,_BLOCK_NO                                    PV003370
191       16        1D9D  E4001F5D                EXT     0,0,_BLOCKS                                     PV003380
192       20        1D9F  D066   (1DA6)           BRE     $12                                             PV003390
193        8R       1DA0  F47A1F61                CLA     7,,_CHECK_SUM                                   PV003400
194       16        1DA2  F4781946                ADD     7,,END_CKSUM                                    PV003410
195       26        1DA4  F0771946                STA     7,,END_CKSUM                                    PV003420
196        2R       1DA6  9C00            $12     CLAM    0,,0                                            PV003430
197       12        1DA7  F4071F61                PTR     0,,_CHECK_SUM                                   PV003440
198       22        1DA9  F00C1F5E                FET     0,,_END_TAPE                                    PV003450
199       26        1DAB  D01A   (1D86)           BNE     $20                                             PV003460
200        8R       1DAC  F40A1F5F                CLA     0,,_BLOCK_NO                                    PV003470
201       12        1DAE  4402                    LSA     0,,1                                            PV003480
202       20        1DAF  F0081F5D                COM     0,,_BLOCKS      NO MORE BLOCKS TO PROCESS IF    PV003490
203       24        1DB1  D034   (1D86)           BRG     $20             MORE THAN NEXT BLOCK NUMBER     PV003500
204        8R       1DB2  F00F8F13                SET     TAPE_CONTROL+FORWARD+RUN                        PV003510
205       16        1DB4  D700                    PRN     0                                               PV003520
206       20        1DB5  D808   (1D78)           BUC     $1                                              PV003530
207       12R       1DB6  F8970144          $20   STAD    9,,X(144)       RESTORE INTERRUPT LOCATION      PV003540
208       20        1DB8  F80FAF00                IOC     INHIBIT_CMP_INTERRUPT                           PV003550
209       28        1DBA  F00F8F21                SET     TAPE_FILL+INHIBIT_READ                          PV003560
210       36        1DBC  F00F8F12                SET     TAPE_CONTROL+RUN+REVERSE                        PV003570
211       44        1DBE  F40A1F62                CLA     0,,_FILL_COMP                                   PV003580
212       48        1DC0  F8096000                COMM    0,,X(6000)                                      PV003590
213       52        1DC2  D161   (1DD4)           BRE     $23                                             PH003600
214        8R       1DC3  D700                    PRN     0                                               PH003610
215       18        1DC4  F0770152                STA     7,,X(152)                                       PV003620
216       28        1DC6  F067014C                STA     6,,CORR_CKSUM                                   PV003630
217       36        1DC8  F4080073                FETM    0,,X(73)        INHIBIT FORCE-FILL              PH003640
218       44 *      1DCA  F80D1E29                BSV     _PUNCH                                          PH003650
219       52        1DCC  F4080074                FETM    0,,X(74)        TAPE-REVERSE CHARACTER          PH003660
```

```
220      60  *     1DCE  F80D1E29                BSV     _PUNCH                                          PH003670
221      70        1DD0  F41801F3                FETM    1,,499                                          PH003680
222      78  *     1DD2  F80D1EA2                BSV     _PPLEADER$1                                     PH003690
223      12R       1DD4  F428021F        $23     FETM    2,,_CORE_SIZE-$21                               PH003700
224      10R       1DD6  F1171DE1        $22     STA     X1,,$21                                         PH003710
225      18        1DD8  C413   (1DD6)           BXU     1,,$22                                          PH003720
226       8R       1DD9  F4083FFF                FETM    0,,X(3FFF)                                      PH003730
227      18        1DDB  F0071F68                STA     0,,R12                                          PH003740
228      28        1DDD  F0071F6F                STA     0,,R21                                          PH003750
229      38        1DDF  F0071F79                STA     0,,R33                                          PH003760
230       4R       1DE1  0000            $21     HLT                                                     PH003770
                                       * COMPARE DATA OR FILL DATA                                       PV003780
231      10R       1DE2  F00C1F5F        $5      FET     0,,_BLOCK_NO                                    PV003790
232      18        1DE4  E4001F5D                EXT     0,0,_BLOCKS     0 UNLESS THIS BLOCK TO BE       PV003800
233      22        1DE6  D011   (1DE8)           BNE     $30               PROCESSED                     PV003810
234      12R       1DE7  D500                    BBK     0                                               PV003820
235       8R       1DE8  F40A1F62        $30     CLA     0,,_FILL_COMP                                   PV003830
236      12        1DEA  F8096000                COMM    0,,X(6000)                                      PV003840
237      16        1DEC  D113   (1E00)           BNE     $31             COMPARE ONLY                    PV003850
238      10R       1DED  F00C1F61                FET     0,,_CHECK_SUM                                   PV003860
239       4R       1DEF  F8290144        $34     COMM    2,,X(0144)                                      PV003870
240       8        1DF1  D013   (1DF5)           BNE     $32                                             PV003880
241       2R       1DF2  840A                    ADD     0,10            MODIFY CKSM BY OLD CONTENTS     PV003890
242       4        1DF3  A4AC                    CLA     10,12           FILL NEW WORD                   PV003900
243       8        1DF4  D008   (1DFD)           BUC     $35                                             PV003910
244       4R       1DF5  F8290145        $32     COMM    2,,X(0145)                                      PV003920
245       8        1DF7  D013   (1DF8)           BNE     $33                                             PV003930
246       2R       1DF8  8408                    ADD     0,11            MODIFY CKSUM                    PV003940
247       4        1DF9  A48C                    CLA     11,12           FILL NEW WORD                   PV003950
248       8        1DFA  D002   (1DFD)           BUC     $35                                             PV003960
249       6R       1DFB  8602            $33     ADD     I0,2            SUM OLD                         PV003970
250      14        1DFC  72C2                    STA     I12,2           FILL NEW WORD                   PV003980
251      10R       1DFD  F0071F61        $35     STA     0,,_CHECK_SUM                                   PV003990
252      24        1DFF  D510                    BBK     1                                               PV004000
253       8R       1E00  D700            $31     PRN     0                                               PV004010
254      12        1E01  F8090144                COMM    0,,X(0144)      CHECK FOR LOCATIONS             PV004020
255      16        1E03  D012   (1E06)           BNE     $6              CHANGED BY THIS PROGRAM         PV004030
256       2R       1E04  A418                    CLA     1,8                                             PH004040
257       6        1E05  D006   (1E0C)           BUC     $8                                              PH004050
258       4R       1E06  F8090145        $6      COMM    0,,X(145)                                       PH004060
259       8        1E08  D012   (1E0B)           BNE     $7                                              PH004070
260       2R       1E09  A419                    CLA     1,9                                             PH004080
261       6        1E0A  D001   (1E0C)           BUC     $8                                              PH004090
```

```
262     6R      1E08  A610              $7        CLA     I1,0        PH004100
263     2R      1E0C  801A              $8        COM     1,10        PH004110
264     6       1E0D  D011  (1E0F)               BNE     _PPDATA     PH004120
265     8R      1E0E  D5F0                       BBK     15          PH004130
```

```
                                                **  PRINT AND PUNCH DATA WORD POINTED TO BY R0                          PH004140
                                                *       REGISTERS ON ENTRY:                                             PH004150
                                                *         0       ADDRESS OF WORD TO BE PUNCHED                         PH004160
                                                *         1       DATA TO BE PUNCHED                                    PH004170
                                                *         2       PRINTER CHARACTER POSITION                            PH004180
                                                *         3       ADDRESS OF LAST WORD PUNCHED                          PH004190
 266        2R      1E0F  8003                  _PPDATA   COM     0,3             DO WE NEED TO PUNCH ADDRESS?          PH004200
 267        6       1E10  D013   (1E14)                 BNE     $3                                                    PH004210
 268        4R      1E11  F829002C                      COMM    2,,44           8 WORDS PER LINE                      PH004220
 269        8       1E13  D054   (1E18)                 BRL     $1                                                    PH004230
 270        6R      1E14  C000                $3        FET     0,0             GET ADDRESS                           PH004240
 271       12       1E15  8405                          FETM    0,,5            ADDRESS CODE                          PH004250
 272       20  *    1E16  F80D1E1C                      BSV     $2                                                    PH004260
 273        6R      1E18  C001                $1        FET     0,1                                                   PH004270
 274        8       1E19  A441                          CLA     4,1             REMEMBER FOLLOWING ADDRESS            PH004280
 275       14       1E1A  8404                          FETM    0,,4            DATA CODE                             PH004290
 276       16       1E18  9451                          ADDM    5,,1                                                  004300
 277        8R  *   1E1C  F80D1E4A              $2        BSV     _PRINT_WORD                                           PH004310
 278       14       1E1E  FC040010                      LSAD    0,,4                                                  PH004320
 279       22  *    1E20  F80D1E29                      BSV     _PUNCH                                                PH004330
 280       28       1E22  8400                          FETM    0,,0                                                  PH004340
 281       34       1E23  FC040040                      LSAD    0,,6                                                  PH004350
 282       42  *    1E25  F80D1E29                      BSV     _PUNCH                                                PH004360
 283       48       1E27  F4050040                      LSE     0,,6                                                  PH004370
                                                *   PUNCH CHARACTER IN R0, AFTER ADDING PARITY BIT                   PH004380
 284        6R      1E29  C000                _PUNCH    FET     0,0             COPY CHARACTER                        PH004390
 285       14       1E2A  F4080080                      FETM    0,,X(80)        INITIALIZE PARITY                     PH004400
 286       24       1E2C  F00C1F5C                      FET     0,,_PPTEMP                                            PH004410
 287       28       1E2E  D15A   (1E49)                 BRL     $62                                                   PH004420
 288        4R      1E2F  FC09007F                      CLAM    0,,X(7F)        FIRST PARITY MASK                     PH004430
 289       10R      1E31  F0071F5C              $4        STA     0,,_PPTEMP                                            PH004440
 290       18       1E33  E4221F5C                      EXT     2,2,_PPTEMP                                           PH004450
 291       22       1E35  D065   (1E36)                 18RE    $5                                                    PH004460
 292        4R      1E36  F4190080                      ADDM    1,,X(80)        COUNT BITS IN CHARACTER               PH004470
 293       10       1E38  FD29FFFF                      CLAM    X2,,I(-1)                                             PH004480
 294       14       1E3A  D80A   (1E31)                 BUC     $4                                                    PH004490
 295       10R      1E3B  F0371F5C              $5        STA     3,,_PPTEMP      ORIGINAL CHARACTER                    PH004500
 296       22       1E3D  E0111F5C                      MRG     1,1,_PPTEMP     INSERT PARITY                         PH004510
 297        8R      1E3F  F40F8F10              $6        SNS     PUNCH_OR_PRINTER_BUSY                                 PH004520
 298       12       1E41  D823   (1E3F)                 BGE     $6              WAIT FOR I/O                          PH004530
 299        8R      1E42  F80FDF02                      IOC     LOAD_PUNCH                                            PH004540
 300       18       1E44  FC0D1F5C                      POP     0,,_PPTEMP                                            PH004550
 301       22       1E46  FC1909C4                      CLAM    1,,I((20000)/8) GUARANTEE 20 MSEC DELAY               PH004560
```

```
302      8R        1E48  C411   (1E48)  $61          BXU       1,,$61          (R2 IS ZERO)                    PH004570
303     18R        1E49  D530           $62          BBK       3                                               PH004580
                                        *   PRINT WORD IN R1, TYPE (ADDRESS OR DATA) IN R0                    PH004590
304      8R        1E4A  F4080081       _PRINT_WORD  FETM      0,,X(81)        SPACE                           PH004600
305     10         1E4C  9814                       COMM      1,,4            TEST FOR DATA WORD              PH004610
306     14         1E4D  D067   (1E55)              BRE       $9              BRANCH IF SO                    PH004620
307      4R        1E4E  FC090081                   CLAM      0,,X(81)        SPACE                           PH004630
308      2R        1E50  8C51           $8           CLSM      5,,1            RESET CHARACTER POSITION        PH004640
309     10         1E51  F4080084                   FETM      0,,X(84)        NEW LINE                        PH004650
310     18  *      1E53  F80D1E66                   BSV       _PRINT                                          PH004660
311      4R        1E55  F8590038       $9          COMM      5,,59           END OF LINE 12 WORDS            PH004670
312      8         1E57  D828   (1E50)              BGE       $8                                              PH004680
313      8R *      1E58  F80D1E65                   BSV       $12                                             PH004690
314     16  *      1E5A  F80D1E5C                   BSV       $10                                             PH004700
                                        *       PRINT TWO DIGITS                                              PH004710
315      8R *      1E5C  F80D1E5E       $10         BSV       $11                                             PH004720
                                        *       PRINT ONE DIGIT                                               PH004730
316      6R        1E5E  F4150010       $11         LSE       1,,4                                            PH004740
317     12         1E60  8400                       FETM      0,,0                                            PH004750
318     20         1E61  E4021F56                   EXT       0,2,_X000F                                      PH004760
319     28         1E63  F50A1EC7                   CLA       X0,,_PPTABLE                                    PH004770
                                        *       PRINT ONE CHARACTER                                           PH004780
320      2R        1E65  9451           $12         ADDM      5,,1            ADVANCE CHARACTER POSITION      PH004790
321     10R        1E66  F0071F5C       _PRINT      STA       0,,_PPTEMP                                      PH004800
322      8R        1E68  F40F8F10       $14         SNS       PUNCH_OR_PRINTER_BUSY                           PH004810
323     12         1E6A  D823   (1E68)              BGE       $14                                             PH004820
324      8R        1E6B  F80FDF01                   IOC       LOAD_PRINTER                                    PH004830
325     18         1E6D  FC0D1F5C                   POP       0,,_PPTEMP                                      PH004840
326     22         1E6F  F8090084                   COMM      0,,X(84)        CR                              PH004850
327     26         1E71  D015   (1E77)              BNE       $15                                             PH004860
328      4R        1E72  FC097FFF                   CLAM      0,,X(7FFF)                                      PH004870
329      4R        1E74  FC090001       $20         2SUBM     0,,1                                            PH004880
330      8         1E76  D833   (1E74)              BRG       $20                                             PH004890
331     12R        1E77  D500           $15          BBK       0                                               PH004900
```

```
                                    **  PUNCH VISUAL FROM R0,1 IN FOUR GROUPS OF TWO                    PH004910
332     12R     1E78  8433          _PUNCHBCD   FETM    3,,3                                          PH004920
333     20      1E79  F4080084                  FETM    0,,X(84)        CR                            PH004930
334     28  *   1E7A  F80D1E66                  BSV     _PRINT                                        PH004940
335     36      1E7D  C015                      FET     1,5             PRINT FIRST HALF              PU004950
336     42      1E7E  8400                      FETM    0,,0                                          PH004960
337     50  *   1E7F  F80D1E4A                  BSV     _PRINT_WORD                                   PH004970
338     52      1E81  A418                      CLA     1,8                                           004980
339     54      1E82  9C00                      CLAM    0,,0                                          004990
340     62  *   1E83  F80D1E4A                  BSV     _PRINT_WORD                                   PH005000
341     74      1E85  D720                      PRN     2                                             PU005010
342      8R *   1E86  F80D1E8F          $1      BSV     _PUNCHVIS                                     PH005020
343     16  *   1E88  F80D1E8F                  BSV     _PUNCHVIS                                     PH005030
344     20      1E8A  8800                      SUBD    0,0             BLANK                         PH005040
345     28  *   1E8B  F80D1E96                  BSV     _PUNCHVIS$1                                   PH005050
346     36      1E8D  C428    (1E86)            BXU     2,,$1                                         PH005060
347     22R     1E8E  D550                      BBK     5                                             PH005070
                                    *                                                                 PH005080
348      8R     1E8F  E4031F56      _PUNCHVIS   EXT     0,5,_X000F                                    PH005090
349     18      1E91  F8450800                  RSLD    4,,4                                          PH005100
350     20      1E93  8400                      ADD     0,0                                           PH005110
351     30      1E94  FD0A1EA7                  CLAD    X0,,_VISTABLE                                 PH005120
352      8R     1E96  8415          $1          FETM    1,,5            SIX FRAMES                    PH005130
353      6R     1E97  C003          $2          FET     0,3                                           PH005140
354     14      1E98  E4001F57                  EXT     0,0,_X003F                                    PH005150
355     22  *   1E9A  F80D1E29                  BSV     _PUNCH                                        PH005160
356     32      1E9C  F8250200                  RSLD    2,,6                                          PH005170
357     40      1E9E  C408    (1E97)            BXU     0,,$2                                         PH005180
358     14R     1E9F  D510                      BBK     1                                             PH005190
                                    *   PUNCH BLANK LEADER                                            PH005200
359     10R     1EA0  F4180007      _PPLEADER   FETM    1,,199                                        PH005210
360      6R     1EA2  8400          $1          FETM    0,,0            (BLANK)                       PH005220
361     14  *   1EA3  F80D1E29                  BSV     _PUNCH                                        PH005230
362     22      1EA5  C404    (1EA2)            BXU     0,,$1                                         PH005240
363     14R     1EA6  D510                      BBK     1                                             PH005250
```

```
                        **                                                      PH005260
364   1EA7  1E86185E    _VISTABLE  COND    X(3D0C308C)/2 0                    PH005270
365   1EA9  0C8BF800               COND    X(0117F000)/2 1                    PH005280
366   1EAB  32A69A66               COND    X(654D34CC)/2 2                    PH005290
367   1EAD  2196595A               COND    X(432CB2B4)/2 3                    PH005300
368   1EAF  0830AFC8               COND    X(10615F90)/2 4                    PH005310
369   1EB1  27965959               COND    X(4F2CB2B2)/2 5                    PH005320
370   1EB3  1EA69A50               COND    X(3D4D34A0)/2 6                    PH005330
371   1EB5  31449143               COND    X(62892286)/2 7                    PH005340
372   1EB7  1A96595A               COND    X(352CB2B4)/2 8                    PH005350
373   1EB9  1296595E               COND    X(252CB2BC)/2 9                    PH005360
374   1EBB  3E14517E               COND    X(7C28A2FC)/2 A                    PH005370
375   1EBD  21FE595A               COND    X(43FCB2B4)/2 B                    PH005380
376   1EBF  1E861852               COND    X(3D0C30A4)/2 C                    PH005390
377   1EC1  21FE185E               COND    X(43FC308C)/2 D                    PH005400
378   1EC3  3F965961               COND    X(7F2CB2C2)/2 E                    PH005410
379   1EC5  3F145141               COND    X(7E28A282)/2 F                    PH005420
                        *                                                       PH005430
380   1EC7  0038        _PPTABLE   CON     X(38)         0                    PH005440
381   1EC8  007F                   CON     X(7F)         1                    PH005450
382   1EC9  0076                   CON     X(76)         2                    PH005460
383   1ECA  003E                   CON     X(3E)         3                    PH005470
384   1ECB  0075                   CON     X(75)         4                    PH005480
385   1ECC  0030                   CON     X(30)         5                    PH005490
386   1ECD  0034                   CON     X(34)         6                    PH005500
387   1ECE  007C                   CON     X(7C)         7                    PH005510
388   1ECF  0079                   CON     X(79)         8                    PH005520
389   1ED0  0031                   CON     X(31)         9                    PH005530
390   1ED1  004F                   CON     X(4F)         A                    PH005540
391   1ED2  0046                   CON     X(46)         B                    PH005550
392   1ED3  000E                   CON     X(0E)         C                    PH005560
393   1ED4  0045                   CON     X(45)         D                    PH005570
394   1ED5  000D                   CON     X(0D)         E                    PH005580
395   1ED6  0004                   CON     X(04)         F                    PH005590
```

```
                                    ** READ ADDRESS/DATA PAIR FROM TAPE READER                                    PH005600
                                    *   RETURN ADDR IN  R5, DATA IN R4                                            PV005610
396      14R    1ED7  F4381F63      _READ_DATA  FETM    3,,_TAPE_DATA                                             PV005620
397      18     1ED9  FC991B3C                  CLAM    9,,ROLL          END-OF-TAPE DEFAULT ADDRESS              PV005630
398       6R    1EDB  A535          $1          CLA     X3,,5                                                     005640
399      10     1EDC  D015  (1EE2)              BNE     $2               SKIP IF DATA READY                       PV005650
400       6R    1EDD  A536                      CLA     X3,,6                                                     005660
401      10     1EDE  D824  (1EDB)              BGE     $1               TEST FOR END OF BLOCK                    PV005670
402       2R    1EDF  9C00                      CLAM    0,,0             RESET END OF BLOCK MKR                   PV005680
403      10     1EE0  7136                      STA     X3,6                                                      PV005690
404      14     1EE1  D10A  (1EFC)              BUC     $5                                                        PV005700
405       8R    1EE2  F80FAF00      $2          IOC     INHIBIT_CMP_INTERRUPT                                     PV005710
406      14     1EE4  A535                      CLA     X3,,5                                                     005720
407      18     1EE5  F809005C                  COMM    0,,_BUFFER_LIM                                            PV005730
408      22     1EE7  D025  (1EED)              BGE     $3                                                        005740
409       8R    1EE8  C136                      FET     X3,,6                                                     005750
410      16     1EE9  D700                      PRN     0                                                         005760
411      20     1EEA  D052  (1EED)              BRL     $3                                                        005770
412       8R    1EEB  F00F8F13                  SET     TAPE_CONTROL+RUN+FORWARD                                  PH005780
413       2R    1EED  9002          $3          SUBM    0,,2                                                      PV005790
414      10     1EEE  7135                      STA     X3,,5                                                     005800
415      18     1EEF  F80F8F00                  IOC     ENABLE_CMP_INTERRUPT                                      PV005810
416      24     1EF1  A538                      CLA     X3,,8                                                     005820
417      38     1EF2  F90C1F6C                  FETD    X0,,_BUFFER                                               PV005830
418      42     1EF4  ACA0                      CLAD    10,0                                                      PV005840
419      52     1EF5  D710                      PRN     1                                                         PV005850
420      54     1EF6  9402                      ADDM    0,,2                                                      PV005860
421      58     1EF7  F809005C                  COMM    0,,_BUFFER_LIM                                            PV005870
422      62     1EF9  D051  (1EF8)              BRL     $4                                                        PV005880
423       2R    1EFA  9C00                      CLAM    0,,0                                                      PV005890
424       8R    1EFB  7138          $4          STA     X3,,8                                                     005900
425      18R    1EFC  D530          $5          BBK     3                                                         PV005910
```

```
                                    **  TAPE READER INTERRUPT ROUTINE                                                    PV005920
                                    *   REGISTERS USED:                                                                 PV005930
                                    *       0   TRIPLET ASSEMBLY                                                        PV005940
                                    *       1   CURRENT ADDRESS                                                         PV005950
                                    *       2   TRIPLET COUNTER                                                         PV005960
                                    *       3   CONTROL TYPE                                                           PV005970
                                    *       4   BUFFER INDEX                                                           PV005980
                                    *       5   BUFFER COUNT                                                           PV005990
                                    *       6   ADDRESS VALID                                                         PV006000
                                    *       7   SCRATCH                                                               PV006010
426       8R    1EFD  F80F9F00      _TAPE_INPUT IOC         RESET_CMP_INTERRUPT                                         PV006020
427       16    1EFF  F80FCF01                  IOC         READ_TAPE                                                   PV006030
428       26    1F01  F4001F6A                  PIP         0,,_TAPE_DATA+7                                             PV006040
429       64    1F03  F07C1F63                  FET         7,,_TAPE_DATA                                               PV006050
430       72    1F05  E4771F59                  EXT         7,7,_X007F      REMOVE PARITY                               PV006060
431       76    1F07  F879007F                  COMM        7,,X(7F)                                                    PV006070
432       80    1F09  D068   (1F15)             BRE         $1              SKIP IF DELETE CODE                         PV006080
433       4R    1F0A  F879003F                  COMM        7,,X(3F)                                                    PV006090
434       8     1F0C  D048   (1F18)             BLE         $2              SKIP UNLESS CONTROL CODE                    PV006100
435       4R    1F0D  F8790070                  COMM        7,,X(70)                                                    PV006110
436       8     1F0F  D228   (1F38)             BGE         $7              SKIP IF SUB-CONTROL                         PV006120
437       8R    1F10  E4371F58                  EXT         3,7,_X0070                                                  PV006130
438       10    1F12  B073                      SUB         7,3             FIRST FOUR INFORMATION BITS                 PV006140
439       12    1F13  A407                      CLA         0,7                                                         PV006150
440       14    1F14  9C22                      CLAM        2,,2            COUNT FOR TWO MORE CHARACTERS               PV006160
441       34R   1F15  F4671F63          $1      PTR         6,,_TAPE_DATA                                               PV006170
442       46    1F17  0500                      BBK         0                                                           PV006180
                                    *   PROCESS INFORMATION ONLY                                                        PV006190
443       2R    1F18  9830          $2          COMM        3,,0            IGNORE IF NO PRIOR CONTROL                  PV006200
444       6     1F19  D865   (1F15)             BRE         $1                                                          PV006210
445       4R    1F1A  F4040040                  LSA         0,,6            ASSEMBLE INFORMATION                        PV006220
446       6     1F1C  B407                      ADD         0,7                                                         PV006230
447       8     1F1D  9021                      SUBM        2,,1            TEST FOR END OF TRIPLET                     PV006240
448       12    1F1E  D83A   (1F15)             BRG         $1                                                          PV006250
                                    *   PROCESS COMPLETE TRIPLET                                                        PV006260
449       4R    1F1F  F8390050                  COMM        3,,X(50)                                                    PV006270
450       8     1F21  D232   (1F44)             BRG         $8              SKIP IF END FORCE FILL                      PV006280
451       4R    1F22  D161   (1F34)             BRE         $5              SKIP IF ADDRESS                              006290
452       2R    1F23  9860                      COMM        6,,0                                                        PV006300
453       6     1F24  D960   (1F15)             BRE         $1                                                          PV006310
454       12R   1F25  F9471F6C                  STAD        X4,,_BUFFER                                                 PV006320
455       14    1F27  9442                      ADDM        4,,2                                                        PV006330
456       18    1F28  F849005C                  COMM        4,,_BUFFER_LIM                                              PV006340
```

```
457   22    1F2A  D051  (1F2C)          BRL   $3                                    PV006350
458    2R   1F28  9C40                  CLAM  4,,0                                  PV006360
459    2R   1F2C  9452            $3    ADDM  5,,2                                  PV006370
460    6    1F2D  F859005C              COMM  5,,_BUFFER_LIM                        PV006380
461   10    1F2F  D052  (1F32)          BRL   $4                                    PV006390
462    8R   1F30  F00F8F11              SET   TAPE_CONTROL+STOP+FORWARD             PV006400
463    2R   1F32  9411            $4    ADDM  1,,1          ADVANCE ADDRESS          006410
464    6    1F33  D002  (1F36)          BUC   $6                                     006420
465    2R   1F34  9C61            $5    CLAM  6,,1                                  PV006430
466    4    1F35  A410                  CLA   1,0           REMEMBER NEW ADDRESS     006440
467    2R   1F36  9C30            $6    CLAM  3,,0                                  PV006450
468    6    1F37  DA03  (1F15)          BUC   $1                                    PV006460
                                  *  PROCESS SUB-CONTROL                           PV006470
469    4R   1F38  F8790071        $7    COMM  7,,X(71)      START FORCE FILL         PV006480
470    8    1F3A  D016  (1F41)          BNE   $9                                    PV006490
471   14R   1F3B  F80C1F5F              FETD  0,,_BLOCK_NO  START NEXT BLOCK         PV006500
472   20    1F3D  4C02                  LSAD  0,,1                                  PV006510
473   34    1F3E  FC071F5F              PTRD  0,,_BLOCK_NO                          PV006520
474   38    1F40  D808  (1F36)          BUC   $6                                    PV006530
475    4R   1F41  F8790073        $9    COMM  7,,X(73)                              PV006540
476    8    1F43  D014  (1F48)          BNE   $10                                   PV006550
477    8R   1F44  FC0F8F11        $8    SET   TAPE_CONTROL+STOP+FORWARD             PV006560
478   10    1F46  8C61                  CLSM  6,,1                                  PV006570
479   14    1F47  DB03  (1F15)          BUC   $1                                    PV006580
480    4R   1F48  F8790074        $10   COMM  7,,X(74)                              PV006590
481    8    1F4A  DB16  (1F15)          BNE   $1                                    PV006600
482    6R   1F4B  8401                  FETM  0,,1                                  PV006610
483   16    1F4C  F4071F5E              PTR   0,,_END_TAPE                          PV006620
484   24    1F4E  F80FAF00              IOC   INHIBIT_CMP_INTERRUPT                 PV006630
485   32    1F50  F00F8F21              SET   TAPE_FILL+INHIBIT_READ                 006640
486   40    1F52  F00F8F12              SET   TAPE_CONTROL+RUN+REVERSE              PV006650
487   46    1F54  04001F15              BUC   $1                                    PV006660
```

```
                                **                                                  PH006670
488   1F56  000F          _X000F      CON       X(000F)                           PV006680
489   1F57  003F          _X003F      CON       X(003F)                           PV006690
490   1F58  0070          _X0070      CON       X(0070)                           PV006700
491   1F59  007F          _X007F      CON       X(007F)                           PV006710
492   1F5A  0FFF          _X0FFF      CON       X(0FFF)                           PV006720
493   1F5B  4CF6          _END_CKSUM  ECS                                         PV006730
494   1F5C  0000          _PPTEMP     CON       0                                 PV006740
495   1F5D                _BLOCKS     EQU       _PPTEMP+1                         PV006750
496   1F5E                _END_TAPE   EQU       _BLOCKS+1                         PV006760
497   1F5F                _BLOCK_NO   EQU       _END_TAPE+1                       PV006770
498   1F61                _CHECK_SUM  EQU       _BLOCK_NO+2                       PV006780
499   1F62                _FILL_COMP  EQU       _CHECK_SUM+1                      PV006790
500   1F63                _TAPE_DATA  EQU       _FILL_COMP+1                      PV006800
501   1F6C                _BUFFER     EQU       _TAPE_DATA+9                      PV006810
502   005C                _BUFFER_LIM EQU       92                                006820
503   1FC8                _ROLL       EQU       _BUFFER+_BUFFER_LIM               PV006830
504   1FE6                _ROLL_14    EQU       _ROLL+30                          PV006840
505   1FFA                _ROLL_END   EQU       _ROLL_14+20                       PV006850
506                                   TAPE        2,_VERIFY                       PV006860
507                                   TAPE        3,12                            PV006870
508                                   TAPE        4,X(F1)                         PV006880
                                *                                                 006890
```

```
                        **                                                                  006900
                        *                                                                   006910
509         0008        OS          EQU         8           NUMBER OF STATIONS TRACKED      006920
510         01FE        OSHEX       EQU         X(01FE)     STATION IMAGE FOR DISPLAY       006930
                        *                                                                   006940
                        *                                                                   006950
                        *                                                                   006960
                        *           DIRECT MEMORY ACCESS (DMA)                              006970
                        *                                                                   006980
511                     C_I_INPUT_MISCELLANEOUS_SWITCHES;                                   006990
511         0001                    EQU         X(0001)                                     007000
512                     C_I_INPUT_KEYBOARD_SWITCHES;                                        007010
512         0002                    EQU         X(0002)                                     007020
513                     C_I_LEFT_DISPLAY;                                                   007030
513         0003                    EQU         X(0003)                                     007040
514                     C_I_LEFT_DISPLAY_DIGITS_6_TO_3;                                     007050
514         0003                    EQU         X(0003)                                     007060
515                     C_I_LEFT_DISPLAY_DIGITS_2_TO_1;                                     007070
515         0004                    EQU         X(0004)                                     007080
516                     C_I_RIGHT_DISPLAY;                                                  007090
516         0005                    EQU         X(0005)                                     007100
517                     C_I_RIGHT_DISPLAY_DIGITS_6_TO_3;                                    007110
517         0005                    EQU         X(0005)                                     007120
518                     C_I_RIGHT_DISPLAY_DIGITS_2_TO_1;                                    007130
518         0006                    EQU         X(0006)                                     007140
519                     C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION;                            007150
519         0007                    EQU         X(0007)                                     007160
520                     C_I_RIGHT_DISPLAY_LEGEND_AND_PUNCTUATION;                           007170
520         0008                    EQU         X(0008)                                     007180
521                     C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES;                            007190
521         0009                    EQU         X(0009)                                     007200
522                     C_I_OUTPUT_MALFUNCTION_STATUS_INDICATORS;                           007210
522         0009                    EQU         X(0009)                                     007220
523                     C_I_UPPER_LEFT_KEYBOARD_LAMPS;                                      007230
523         0008                    EQU         X(0008)                                     007240
524                     C_I_UPPER_RIGHT_KEYBOARD_LAMPS;                                     007250
524         000C                    EQU         X(000C)                                     007260
525                     C_I_LOWER_KEYBOARD_LAMPS;                                           007270
525         000D                    EQU         X(000D)                                     007280
                        *                                                                   007290
                        *                                                                   007300
526                     SUM_T_ZERO_DCT;                                                     007310
526         000E                    EQU         X(000E)                                     007320
```

```
                        *                                                                    007330
                        *                                                                    007340
527                     PHASE_COUNTER_TEST_LOCATION;                                         007350
527     0010                    EQU         X(0010)                                          007360
528     0011            COS_10_2    EQU     X(0011)                                          007370
529     0012            SIN_10_2    EQU     X(0012)                                          007380
530     0013            COS_13_6    EQU     X(0013)                                          007390
531     0014            SIN_13_6    EQU     X(0014)                                          007400
532     0015            COS_11_33   EQU     X(0015)                                          007410
533     0016            SIN_11_33   EQU     X(0016)                                          007420
534                     DIRECT_MEMORY_ACCESS_TEST_LOCATION;                                  007430
534     0017                    EQU         X(0017)                                          007440
535                     CH0;                                    NOT USED                 HH007450
535     0018                    EQU         X(0018)                                          007460
536                     CH1;                                    NOT USED                 HH007470
536     0019                    EQU         X(0019)                                          007480
537                     TRUE_HEADING_INPUT;                     CH2                      HH007490
537     001A                    EQU         X(001A)                                          007500
538                     TRUE_AIR_SPEED_INPUT,SHIP_SPEED_INPUT;  CH3                      HH007510
538     001B                    EQU         X(001B)                                          007520
539                     A_TO_D_CONVERTER_TEST_LOCATION;         CH4  4E84 NOMINAL        HH007530
539     001C                    EQU         X(001C)                                          007540
540                     CH5;                                    NOT USED                 HH007550
540     001D                    EQU         X(001D)                                          007560
541                     CH6;                                    NOT USED                 HH007570
541     001E                    EQU         X(001E)                                          007580
542                     CH7;                                    NOT USED                 HH007590
542     001F                    EQU         X(001F)                                          007600
543                     ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2;                                007610
543     0020                    EQU         X(0020)                                          007620
544                     ANTENNA_SWITCHING_MATRIX_OUTPUT_13_6;                                007630
544     0021                    EQU         X(0021)                                          007640
545                     ANTENNA_SWITCHING_MATRIX_OUTPUT_11_33;                               007650
545     0022                    EQU         X(0022)                                          007660
546                     OUTPUT_TEST_AND_MISCELLANEOUS_SIGNALS;                               007670
546     0023                    EQU         X(0023)                                          007680
```

```
                        **                                                                  007690
547                     SIGMA_SQUARED_PHI_SUB_M;                                            007700
547     0024                    EQU     X(0024)                                             007710
548     002A    ACCEPT_OLD      EQU     X(002A)                                             007720
549     0028    AD_DATA         EQU     X(0028)         3 WORDS                             HH007730
550                     TEST_FAIL_TEMP;                                                     HH007740
550     002E                    EQU     X(002E)         2 WORDS                             HH007750
                        * LOCATION 30 RESERVED FOR HARDWARE GARBAGE DUMP                    HH007760
551                     DB_SAVEPATCHSTART;                                                  HH007770
551     0031                    EQU     X(0031)                                             HH007780
552     0032    Q_SUB_T         EQU     X(0032)         3 WORDS                             HH007790
553                     ANTENNA_SELECT_SAVE;                                                HH007800
553     0035                    EQU     X(0035)         3 WORDS                             HH007810
554     0038    Q_M             EQU     X(0038)         6 WORDS  (3 DOUBLE)                 HH007820
555                     PANEL_COUNT;                                                        HH007830
555     003E                    EQU     X(003E)                                             HH007840
                        * LOCATION 3F RESERVED FOR HARDWARE GARBAGE DUMP                    HH007850
556                     MAG_TAPE_DATA;                                                      HH007860
556     0040                    EQU     X(0040)         10 WORDS                            HH007870
557     004A    M_MATRIX        EQU     X(004A)                                             007880
558     004A    R_MATRIX        EQU     M_MATRIX                                            007890
559     005C    PHI_MATRIX      EQU     X(005C)                                             007900
560                     DIVERGENCE_CONTROL;                                                 007910
560     005C                    EQU     PHI_MATRIX                                          007920
561     006F    DF_MKR          EQU     PHI_MATRIX+19                                       007930
562     0070    CONNIE          EQU     PHI_MATRIX+20                                       007940
                        *MEASUREMENT VARIANCE AND MEASUREMENT MUST BE IN ORDER              007950
563                     MEASUREMENT_VARIANCE;                                               007960
563     0072                    EQU     PHI_MATRIX+22                                       007970
564     0074    MEASUREMENT     EQU     PHI_MATRIX+24                                       007980
565                     MEASUREMENT_RESIDUAL;                                               007990
565     0076                    EQU     PHI_MATRIX+26                                       008000
566     0078    DB_MODE         EQU     X(0078)                                             008010
```

```
                                **                                                                                  008020
                                * START EXTENDED ADDRESSING - VARIABLE STORAGE                                     008030
                                *                                                                                  008040
567             0080                        ORG         X(0080)                                                    008050
                                *                                                                                  008060
568             0080  0000      RESET_TF    CON         0                                                          008070
569                             POSITION_NOISE;                                                                    008080
569             0081  00000000              COND        0                                                          008090
570             0083  0000                  CON         0                                                          008100
571             0084  0000      N           CON         0                                                          008110
572             0085  00000000  TF_TEMP     COND        0                                                          008120
573             0087  00000000              COND        0                                                          008130
574             0089  00000000              COND        0                                                          008140
575             0085              SYNC_1OVERN EQU       TF_TEMP                                                    008150
576                             SYNC_DATA_ADDRESS_AND_FREQUENCY;                                                   008160
576             0087              EQU         TF_TEMP+2                                                          008170
577                             SYNC_DATA_ADDRESS;                                                                 008180
577             0087              EQU         TF_TEMP+2                                                          008190
578                             SYNC_FREQUENCY;                                                                    008200
578             0088              EQU         TF_TEMP+3                                                          008210
579                             TEN_SECOND_SYNC_PERIOD_COMPLETE_MARKER;                                            008220
579             0089              EQU         TF_TEMP+4                                                          008230
580                             START_SYNC_TIME;                                                                   008240
580             0088  00000000              COND        0                                                          008250
581                             INTEGRATION_COUNTER;                                                               008260
581             008D  00000000              COND        0                                                          008270
582             008F  0000      PSI_A_SAVE  CON         0                                                          008280
583             008F              SYNC_N      EQU         PSI_A_SAVE    SYNC N +1 = 0 IN SYNC                    008290
584                             KAL_STA_FLG;                        END OF SYNC MARKER FOR KALMAN    11  008300
584             0090  0000                  CON         0           TO LET PROP FINISH OS STATIONS   11  008310
                                *                                     BEFORE MAKING MEAS UPDATE      11  008320
585                             NON_OMEGA_TASK_INDEX;                                                              008330
585             0091  00000000              COND        0                                                          008340
586                             NON_OMEGA_TIME;                                                                    008350
586             0093  00000000              COND        0                                                          008360
587                             OLD_NON_OMEGA_TASK_TIME;                                                           008370
587             0095  00000000              COND        0                                                          008380
588             0097  00000000  OMEGA_TIME  COND        0                                                          008390
589             0099  0000      OMEGA_TASK  CON         0                                                          008400
590                             CALIBRATE_COMPUTED_MARKER;                                                         008410
590             009A  0000                  CON         0                                                          008420
591                             NOISE_COMPUTED_MARKER;                                                             008430
591             0098  0000                  CON         0                                                          008440
```

```
592                                  START_OMEGA_NOW;                                  008450
592   009C  0000                            CON       0                                008460
593                                  PAST_NAV_MODE;                                    008470
593   009D  0000                            CON       0                                008480
594   009E  00000000     IMAGE9      COND      0                                      008490
595                                  C_I_STATUS_IMAGE;                                 008500
595   009F                           EQU       IMAGE9+1                               008510
596   00A0  0000         DB_SAVE     CON       0                                      008520
597                                  PMU_INDICATOR_WORD;                               008530
597   00A1  0000                     CON       0                                      008540
598   00A2  00000000     V2          COND      0                                      008550
599   00A3               V3          EQU       V2+1                                   008560
600   00A4  0000         SLOW_RATE   CON       0                                      008570
601   00A5  0000         WINDOWAD    CON       0                                      008580
602   00A6  0000         PC_INSERT   CON       0                                      008590
603                                  STATION_INDEX;                                    CF008600
603   00A7  0000                     CON       0                                      CF008610
604   00A8  00000000     TIME_INC    COND      0                                      008620
605   00AA  00000000     DB_BUFFER   COND      0                                      008630
606   00AC  00000000                 COND      0                                      008640
607   00AE  00000000                 COND      0                                      008650
608   00B0  00000000                 COND      0                                      008660
609   00B2  0000         START_CNT   CON       0                                      008670
610   00B3  0000         START_MKR   CON       0                                      008680
611   00B4  0000         PP_STATION  CON       0                                      008690
612                                  STATION_COUNTER;                                  008700
612   00B5  0000                     CON       0                                      008710
613                                  STATION_NUMBER;                                   008720
613   00B6  0000                     CON       0                                      008730
614                                  COLD_START_MKR;                                   008740
614   00B7  0000                     CON       0                                      008750
615                                  AUGMENTER_KEY;                                    008760
615   00B8  0000                     CON       0                                      008770
616   00B9  0000         DELTA_V2    CON       0                                      008780
617   00BA  0000         DELTA_V3    CON       0                                      008790
                                     *                                               008800
                                     *     START WORDS PICKED UP BY C I PROG         008810
                                     *                                               008820
618   00BB  0000         V_TAS       CON       0                                      008830
619   00BC  00000000     TIME        COND      0                                      008840
                                     *                                               008850
                                     *     END WORDS CLEARED AT TURN ON              008860
                                     *                                               008870
```

```
                                        *                                                                   008880
620             008E  00000000          VC2             COND    0                                           008890
621             008F                    VC3             EQU     VC2+1                                       008900
622             00C0  00000000          THETA_P         COND    0                                           008910
623             00C2  0000              PSI_A           CON     0                                           008920
624                                     CONNIE_LIMIT;                                                       008930
624             00C3  0000                              CON     0                                           008940
                                        *                                                                   008950
                                        *                   END WORDS PICKED UP BY C I PROG                 008960
                                        *                                                                   008970
625                                     DAY_SINCE_JAN1_1972;                                                008980
625             00C4  00000000                          COND    0                                           008990
626             00C6  00000000          GMT             COND    0                                           009000
627             00C8  00000000          DAY             COND    0                                           009010
628             00CA  0000              MODE            CON     0           REQD =0 FOR PHASE DIFFERENCE    009020
                                        *                           OTHERWISE IT FORCES RHO RHO             009030
629             00CB  00000000          BASE            COND    0                                           009040
630             00CD  0000              NEED_BASE       CON     0                                          SB009050
631             00CE  0000              OFF_COUNT       CON     0                                           009060
632             00CF  0000              PFG_COUNT       CON     0                                           009070
633             00D0  0000              PMU_INPUT       CON     0                                           009080
634             00D1  00000000          TEST_FAIL       COND    0                                          HH009090
```

```
                                **                                                                                  009100
                                *                                                                                   009110
635             00D5                            ORG         X(00D5)                                                 009120
636             00D5            START_CKSUM SCS                                                                     009130
637                                             TAPE        1                                                       009140
                                *                                                                                   009150
638                             POWERS_OF_TWO,;                                                                     009160
638             00D5  0001      HX0001          CON         X(0001)                                                 009170
639             00D6  0002      HX0002          CON         X(0002)                                                 009180
640             00D7  0004      HX0004          CON         X(0004)                                                 009190
641             00D8  0008      HX0008          CON         X(0008)                                                 009200
642             00D9  0010      HX0010          CON         X(0010)                                                 009210
643             00DA  0020      HX0020          CON         X(0020)                                                 009220
644             00DB  0040      HX0040          CON         X(0040)                                                 009230
645             00DC  0080      HX0080          CON         X(0080)                                                 009240
646             00DD  0100      HX0100          CON         X(0100)                                                 009250
647             00DE  0200      HX0200          CON         X(0200)                                                 009260
648             00DF  0400      HX0400          CON         X(0400)                                                 009270
649             00E0  0800      HX0800          CON         X(0800)                                                 009280
650             00E1  1000      HX1000          CON         X(1000)                                                 009290
651             00E2  2000      HX2000          CON         X(2000)                                                 009300
652             00E3  4000      HX4000          CON         X(4000)                                                 009310
653             00E4  8000      HX8000          CON         X(8000)                                                 009320
                                *                                                                                   009330
654                             STATIONS_IN_USE;                                                                    009340
654             00E5  04FF                      CON         X(04FF)     STATIONS - SHIPS LOG/HDG                    009350
655             00E6  FB01                      CON         X(FB01)     COMPLEMENT FOR CHECKSUM                     009360
                                *                                                                                   009370
656             00E7  C7C46925                  LITD        F((5D-3831)/(24*3600*1811))                      11 009380
657             00E9  0AAAAAAB                  LITD        F((1)/12)                                           009390
658             00EB  00000001                  LITD        X(00000001)                                         009400
659             00ED  00000014                  LITD        20                                                  009410
660             00EF  1999999A                  LITD        F(.1E+1)                                            009420
661             00F1  00008000                  LITD        X(00008000)                                         009430
662             00F3  7FFFFFFF                  LITD        X(7FFFFFFF)                                         009440
663             00F5  20000000                  LITD        X(20000000)                                         009450
664             00F7  008C8CCC                  LITD        F((.25)*.25D-128+36)                                009460
                                *                                                                                   009470
665             00F9  00C8      HD200           CON         200                                                     009480
666             00FA  0800      HX0800          CON         X(0800)                                                 009490
667             00FB  1F9A      CAL_R_ADD       CON         CALIBRATE_RESULTS                                HH 009500
668             00FC  0079      DB_M1_ADD       CON         DB_MODE+1                                               009510
669             00FD  1F69      RIJ_ADD         CON         RIJ                                                     009520
```

```
670                00FE  1798          SV_ADD      CON         STATION_VECTOR_TABLE                009530
671                00FF  1C1E          XXX_ADD     CON         XXX                                 009540
                                       *                                                           009550
                                       *                                                           009560
                                       *                                 END  EXTENDED ADDRESSING  009570
                                       *                                                           009580
                                       *                                                           009590
```

```
                                    **                                                                  009600
                                    *                                                                   009610
672                 0100  00ED      HX00ED      CON         X(00ED)                                     009620
673                 0101  1800      HX1800      CON         X(1800)                                     009630
                                    *                                                                   009640
                                    *           PIN ROUTINES - LOCATIONS 102 TO 10F                     009650
                                    *                                                                   009660
674                 0102                        ORG         X(0102)                                     009670
675                                             PIN           OMEGA,2,58                                009680
676                 0102  172E                  CON         OMEGA_TASK_PIN                              009690
677                                             PIN           GEN,3,564                                 DP009700
678                 0103  14FA                  CON         GEN_PIN                                     DP009710
679                                             PIN           SQRT,4,434                                009720
680                 0104  1629                  CON         SQUARE_ROOT                                 009730
681                                             PIN           SINCOS,5,422                              009740
682                 0105  164F                  CON         SC_ENTRY                                    009750
683                                             PIN           ATAN,6,526                                009760
684                 0106  1688                  CON         ATAN_ENTRY                                  009770
685                                             PIN           INPUT,7,58                                CI009780
686                                             PIN           ACCEPT,7,68                               CI009790
687                 0107  1214                  CON         PANEL_PIN                                 CI009800
688                                             PIN           PLINE,8                                   OM009810
689                                             PIN           PSPACE,8                                  OM009820
690                 0108  1897                  CON         HSP_OUT                                   OM009830
691                                             PIN           PDLINE,9                                  OM009840
692                 0109  18AE                  CON         HSP_LINE_D                                OM009850
693                                             PIN           PDEC,10                                   OM009860
694                 010A  1883                  CON         HSP_D                                     OM009870
695                                             PIN           FAIL,11                                     009880
696                 010B  0258                  CON         FAIL_PIN                                    009890
697                                             PIN           SIGNAL,12,34                                009900
698                 010C  19AA                  CON         SIGNAL_PIN                                TS009910
699                                             PIN           MARK,13                                     009920
700                 010D  025B                  CON         MARK_PIN                                    009930
701                                             PIND          FAILD,11                                    009940
702                 010E  FF00      HXFF00      CON         X(FF00)                                     009950
703                 010F  00FF      HX00FF      CON         X(00FF)                                     009960
```

```
                    **                                                                  009970
704      0110                        ORG       X(0110)                                  009980
                    *                                                                   009990
705      0110 0000  DCAY1_TABLE CON   0                                                PP010000
706      0111 68FD                  CON       F(((60.9)*.9974)*217.021860-6)  13.6PP010010
707      0112 3532                  CON       F(((30.0)*.9974)*217.021860-6)  11.3PP010020
708      0113 06BD                  CON       F(((03.8)*.9974)*217.021860-6)  PP010030
709      0114 6187                  CON       F(((55.0)*.9974)*217.021860-6)  PP010040
710      0115 3201                  CON       F(((28.2)*.9974)*217.021860-6)  PP010050
711      0116 0E88                  CON       F(((08.3)*.9974)*217.021860-6)  PP010060
712      0117 4445                  CON       F(((38.5)*.9974)*217.021860-6)  PP010070
713      0118 2598                  CON       F(((21.2)*.9974)*217.021860-6)  PP010080
714      0119 09C1                  CON       F(((05.5)*.9974)*217.021860-6)  PP010090
715      011A 1547                  CON       F(((12.0)*.9974)*217.021860-6)  PP010100
716      011B 09C1                  CON       F(((05.5)*.9974)*217.021860-6)  PP010110
717      011C 2788                  CON       F(((22.3)*.9974)*217.021860-6)  PP010120
718      011D 1AF4                  CON       F(((15.2)*.9974)*217.021860-6)  PP010130
719      011E 2266                  CON       F(((19.4)*.9974)*217.021860-6)  PP010140
720      011F 2EA3                  CON       F(((26.3)*.9974)*217.021860-6)  PP010150
721      0120 220C                  CON       F(((19.2)*.9974)*217.021860-6)  PP010160
722      0121 2951                  CON       F(((23.3)*.9974)*217.021860-6)  PP010170
723      0122 358D                  CON       F(((30.2)*.9974)*217.021860-6)  PP010180
724      0123 2951                  CON       F(((23.3)*.9974)*217.021860-6)  PP010190
725      0124 2FE0                  CON       F(((27.0)*.9974)*217.021860-6)  PP010200
726      0125 3A29                  CON       F(((32.8)*.9974)*217.021860-6)  PP010210
727      0126 2CAF                  CON       F(((25.2)*.9974)*217.021860-6)  PP010220
728      0127 344F                  CON       F(((29.5)*.9974)*217.021860-6)  PP010230
729      0128 3BEF                  CON       F(((33.8)*.9974)*217.021860-6)  PP010240
730      0129 2CAF                  CON       F(((25.2)*.9974)*217.021860-6)  PP010250
731      012A 3532                  CON       F(((30.0)*.9974)*217.021860-6)  PP010260
732      012B 3CA5                  CON       F(((34.2)*.9974)*217.021860-6)  PP010270
733      012C 2CAF                  CON       F(((25.2)*.9974)*217.021860-6)  PP010280
734      012D 358D                  CON       F(((30.2)*.9974)*217.021860-6)  PP010290
735      012E 3B94                  CON       F(((33.6)*.9974)*217.021860-6)  PP010300
736      012F 2CAF                  CON       F(((25.2)*.9974)*217.021860-6)  PP010310
737      0130 3532                  CON       F(((30.0)*.9974)*217.021860-6)  PP010320
738      0131 3ADF                  CON       F(((33.2)*.9974)*217.021860-6)  PP010330
739      0132 2B44                  CON       F(((24.4)*.9974)*217.021860-6)  PP010340
740      0133 3422                  CON       F(((29.4)*.9974)*217.021860-6)  PP010350
741      0134 3A57                  CON       F(((32.9)*.9974)*217.021860-6)  PP010360
742      0135 2A06                  CON       F(((23.7)*.9974)*217.021860-6)  PP010370
743      0136 333F                  CON       F(((28.9)*.9974)*217.021860-6)  PP010380
744      0137 39CF                  CON       F(((32.6)*.9974)*217.021860-6)  PP010390
```

```
745  0138  2A06  CON  F(((23.7)*.9974)*217.021860-6)  PP010400
746  0139  3312  CON  F(((28.8)*.9974)*217.021860-6)  PP010410
747  013A  38EC  CON  F(((32.1)*.9974)*217.021860-6)  PP010420
748  013B  2A06  CON  F(((23.7)*.9974)*217.021860-6)  PP010430
749  013C  3289  CON  F(((28.5)*.9974)*217.021860-6)  PP010440
750  013D  3863  CON  F(((31.8)*.9974)*217.021860-6)  PP010450
751  013E  2A06  CON  F(((23.7)*.9974)*217.021860-6)  PP010460
752  013F  30F1  CON  F(((27.6)*.9974)*217.021860-6)  PP010470
```

```
                                    **                                                                                  010480
753                 0140                        ORG         X(140)                                                      EX010490
                                    *                         INTERRUPTS                                                *H010500
                                    *                                                                                   *H010510
                                    * THE FOLLOWING INSTRUCTIONS ARE LOCATED IN THE WORDS THAT ARE HARDWIRED           *H010520
                                    * IN THE COMPUTER FOR INTERRUPTS AND START SIGNALS.  THE START SIGNALS             *H010530
                                    * CAN BE GIVEN BY POWER ON OR THE PROGRAMMER CONTROLLER. FIRDT                      *H010540
                                    * INSTRUCTION AFTER A START SIGNAL MUST LOAD THE NEXT INSTRUCTION                  *H010550
                                    * REGISTER.  WHEN INTERRUPTS OCCUR THE NEXT INSTRUCTION REGISTER WILL              *H010560
                                    * CONTAIN THE LOCATION OF THE INSTRUCTION THAT WOULD HAVE BEEN EXECUTED            *H010570
                                    * NEXT IF THE INTERRUPT HAD NOT OCCURRED.  THE FIRST INSTRUCTION AFTER             *H010580
                                    * THE INTERRUPT MAY PRESERVE THIS LOCATION IF REQUIRED.                           *H010590
                                    *                                                                                   *H010600
                                    *                                                 "POWER ON START SIGNAL"           *S010610
754         6R      0140  04000166                2BUC        BEGIN                   "BEGIN NORMAL PROGRAM OPERATION   EX010620
                                    *                                                 "POWER OFF INTERRUPT"             *S010630
755         6R      0142  04000161                2BUC        OFF                     "RECOVERY NOT REQUIRED            EX010640
                                    *                                                 "SUPPORT EQUIPMENT INTERRUPT      *I010650
756         8R *    0144  F80D18AE                BSV         MAG_TAPE                "NOT USED BY NAVIGATION PROGRAM   *I010660
                                    *                                                 "OMEGA 5 MILLISEC INTERRUPT       *I010670
757         8R *    0146  F80D0285  PLOT15        2BSV        EXEC                    "CONTROLS ALL PROGRAM TIMING      EX010680
                                    *                                                 "C/I INTERRUPT"                   *I010690
758        16 *     0148  F80D1060                BSV         PANEL_INPUT             "BUTTON HAS BEEN DEPRESSED        EX010700
759                 014A  00000000  PLOT20        COND        0                       SPARE, OVRLYD BY TEST PGM.        EX010710
760                 014C  0000      CORR_CKSUM    CON         0                       CKSUM OF CORR NUMBER              EX010720
761                 014D  1AE7      DB_PCHAD      CON         LAST_WORD+1                                               DB010730
762                 014E  1F69                    CON         RIJ                     PUNCH TAPE LINKAGE                EX010740
763                 014F  05187636  PROGRAM_ID    VIS         "MOD 36  05/18/76  AN/BRN-7 "                              10750
764                 0151  11120000  TAPE_ID       COND        X(11120000)                                               EX010760
765                 0153  00D5      CKSUM_LINK    CON         START_CKSUM                                               EX010770
766                 0154  1B38      ROLLADDRESS   CON         ROLL_15-1               END CHECKSUM ADDRESS              EX010780
767                 0155  0080      TITLE_LINK    CON         TITLE                                                     EX010790
768                 0156  0000      PROG_ID_DB    CON         0                                                          010800
769                 0157  0000      PROG_ID_OVL   CON         0                                                          010810
770                 0158  0000      DB_CKSUM      CON         0                                                          010820
                                    *                                                                                  EX010830
                                    *                                                                                  EX010840
                                    * THE FOLLOWING 8 LOCATIONS ARE USED BY GP_TEST_ENTRY                              EX010850
                                    * FOR A MEMORY TEST.                                                              EX010860
                                    *                                                                                  EX010870
771                                 AUG_MEM_TEST;                                                                      EX010880
771                 0159  FC1A                    CON         X(FC1A)                                                   EX010890
772                 015A  0153                    CON         X(0153)                                                   EX010900
```

```
773  0158  8000        CON     X(8000)     EX010910
774  015C  8601        CON     X(8601)     EX010920
775  015D  C412        CON     X(C412)     EX010930
776  015E  D013        CON     X(D013)     EX010940
777  015F  0308        CON     X(0308)     EX010950
778  0160  0400        CON     X(0400)     EX010960
```

```
                                    **                                                                    EX010970
                                    *                                                                     EX010980
                                    * TITLE CHARACTERS  0-F = 0-F G=10 H=11 I=12 J=13 K=14 L=15 M=16 N=17  EX010990
                                    * O=18 P=19 Q=1A R=1B S=1C T=1D U=1E V=1F W=20 X=21 Y=22 Z=23 -=24     EX011000
                                    * .=25 /=26 #=27 (=28 )=29 +=2A ,=2B *=2C &=2D BLANK=2E               EX011010
                                    *                                                                     EX011020
                                    *                                                                     EX011030
779                 0080            TITLE       EQU         X(0080)                                       011040
                                    *                         'X0A172608  AN/8                            011050
                                    *                           18172407  RN-7                            011060
                                    *                           2E2E170A    NA                            011070
                                    *                           1F2E1C1E  V SU                            011080
                                    *                           08160A18  8MAR                           011090
                                    *                           12170E2E  INE                             011100
                                    *                           2E2E2E2E                                  011110
                                    *                           2E2E                                      011120
                                    *           POWER OFF                                                 *H011130
                                    *                                                                     *H011140
                                    * POWER OFF INTERRUTS FORCE ENTRY TO THIS ROUTINE                    *H011150
                                    *                                                                     *H011160
                                    *                                           "STOP INTERRUPTS SO THAT THIS *I011170
780         2R      0161  DF00      OFF         LGC         INTERRUPT_INHIBIT   "ROUTINE IS NOT INTERRUPTED EX011180
781         8       0162  9E4E  (00CE)          CLA         0,,OFF_COUNT        "INCREMENT COUNT OF NUMBER OF EX011190
782         10      0163  9401                  ADOM        0,,1                "POWER OFF INTERRUPTS         EX011200
783         18      0164  704E  (00CE)          STA         0,,OFF_COUNT                                  EX011210
784         22      0165  0000                  HLT                             "STOP COMPUTER"               $S011220
```

```
                                **                                                                  EX011230
                                *           MAIN PROGRAM                                            *H011240
                                * THIS ROUTINE IS THE LOWEST LEVEL ROUTINE                          *H011250
                                * IN THE SYSTEM.  IT IS ENTERED BY THE POWER                        *H011260
                                * ON INTERRUPT OR WHENEVER A DECISION IS                            *H011270
                                * MADE TO RESTART.  THIS ROUTINE PERFORMS                           *H011280
                                * INITIALIZATION, ENABLES DMA AND INTERRUPTS,                       *H011290
                                * ENTERS THE SYNC COMPUTATIONAL ROUTINE AND                         *H011300
                                * DOES CHECKSUM.  IT ONLY OPERATES WHEN THERE                       *H011310
                                * ARE NO OMEGA OR NON OMEGA TASKS REMAINING.                        *H011320
785      4R      0166 FCF918E8  BEGIN   CLAM    15,,ROLL_14     "INITIALIZE R14 AND R15 TO POINT  EX011330
                                *                               "TO THE TOP OF THE R14 AND R15    EX011340
786      8       0168 FCE91C03          CLAM    14,,ROLL_END    "PUSHDOWN STACKS                  EX011350
                                *                               "TURN ON PROTECT IN CASE PROGRAM  *I011360
787      16      016A F00F8E21          SET     0,,ENABLE_MEMORY_PROTECT "MONITOR IS AVAILABLE    EX011370
788      30      016C F01C014D          FET     1,,DB_PCHAD     "SET UP TO ENTER DEBUG IN SUCH A  EX011380
                                *                               "WAY THAT IT WILL READ THE INPUT  EX011390
                                *                               "WORD ON THE FIRST ENTRY WITHOUT  EX011400
                                *                               "WAITING FOR A BUTTON TO BE       EX011410
                                *                               "DEPRESSED.  THIS WILL ALLOW THE  EX011420
                                *                               "OPERATOR TO 'HOLD' THE PROGRAM   EX011430
789      68      016E FC7C0078          FET     7,,DB_MODE      "FROM THE PMU AT TURN ON.         EX011440
                                *                               "DEBUG - AUTOMATIC RETURN IF NO   *I011450
790      76   *  0170 F80D1948          BSV     OMEGA_DEBUG$2    "PROGRAM MONITOR UNIT AVAILABLE  EX011460
791      84      0172 9EBC   (008C)     CLAD    0,,TIME         "ADD VALUE OF COMPUTER TIME       EX011470
792      102     0173 42E7   (00E7)     MPYD    0,,=DF(50-3831/24/3600/1811)                  11  011480
                                *                                              "TURN OFF TO GMT     011490
793      110     0174 96C4   (00C4)     ADDD    0,,DAY_SINCE_JAN1_1972 "OF PREVIOUS TURN ON TO    011500
794      120     0175 7844   (00C4)     STAD    0,,DAY_SINCE_JAN1_1972 "GET TIME OF THIS TURN ON  011510
                                *                               "(WHICH THE OPERATOR CAN REJECT)  EX011520
                                *                                                                 EX011530
795      124     0176 8811              SUBD    1,1             "CLEAR LOWER MEMORY FROM ZERO UP  EX011540
796      128     0177 FC39008D          CLAM    3,,TIME+1       "TO AND INCLUDING TIME LOCATION   EX011550
797        8R    0179 7212      $1      STA     I1,2                                              % 011560
798      16      017A C422   (0179)     BXU     2,,$1                                             % 011570
                                *                               "                                 EX011580
799      4R      017B FC291841          CLAM    2,,ROLL+5       "CLEAR UPPER MEMORY FROM THE      EX011590
800      8       017D FC391F66          CLAM    3,,PANEL_DATA-1 "BOTTOM OF THE R15 PUSHDOWN STACEX011600
                                *                               "UPTO PANEL DATA LOCATION         EX011610
801        8R    017F 7212      $2      STA     I1,2                                              % 011620
802      16      0180 C422   (017F)     BXU     2,,$2                                             % 011630
                                *                                                                 EX011640
803        4R    0181 FC194A00          CLAM    1,,X(4A00)      "TURN ON THE INSERT, DISPLAY,     %S011650
```

```
                                        *                                                    "NORMAL, ENTER T AND CLEAR LAMPS EX011660
804       6     0183  9C23                        CLAM    2,,X(0003)                       "ON THE C/I PANEL                EX011670
805      10     0184  FC39E000                    CLAM    3,,X(E000)                                                        EX011680
806      20     0186  F0170009                    STA     1,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES                        EX011690
807      32     0188  F8271F48                    STAD    2,,PANELMODE+1   "SET PANEL SWITCH MASK SO THAT                   EX011700
                                        *                                                    "DEPRESSING THE ILLUMINATED      EX011710
                                        *                                                    "BUTTONS IS VALID                EX011720
                                        *                                                                                     EX011730
                                        *   DISPLAY PROGRAM ID ON PANEL                                                       011740
808      46     018A  F80C0156                    FETD    0,,PROG_ID_DB                                                     011750
809      68     018C  F03C014F                    FET     3,,PROGRAM_ID                                              01     011760
810      70     018E  8445                        ADD     4,5                                                               011770
811      72     018F  A424                        CLA     2,4                                                               011780
812      2R     0190  983A              $11       COMM    3,,10                                                             011790
813       6     0191  D054    (0196)              BRL     $21                                                               011800
814      2R     0192  903A                        SUBM    3,,10                                                             011810
815       6     0193  F4290010                    ADDM    2,,16                                                             011820
816      10     0195  D806    (0190)              BUC     $11                                                               011830
817      2R     0196  8423              $21       ADD     2,3                                                               011840
818       4     0197  A431                        CLA     3,1                                                               011850
819       8     0198  F4340100                    LSA     3,,8                                                              011860
820      18     019A  FC440DDC                    CLAD    4,,HX0080                                                         011870
821      48     019C  F4570003                    PTR     5,,C_I_LEFT_DISPLAY                                               011880
822      56     019E  8410                        FETM    1,,0               SET TIME ARGUMENT = 0 FOR OMEGA EX011890
823      60     019F  FC094135                    CLAM    0,,X(4135)           DELAY TO ALLOW                               011900
824      2R     01A1  9001              $3        SUBM    0,1                  OSCILLATOR TO                                011910
825       6     01A2  D812    (01A1)              BNE     $3                   ADJUST.                                      011920
                                        *                                                    "SET 1ST OMEGA TASK = PREFLIGHT  *I011930
826     70R     01A3  0808                        OMEGA   TEST1-OMEGA_TASK_TABLE/2   "TO OCURR IN 50 MSEC EX011940
                                        *                                                                                     EX011950
                                        *                                                    "INITIALIZE PRECISION FREQUENCY  *I011960
827      78     01A4  C30A                        SET     RESET_PFG_COUNTDOWN   "GENERATOR IN RECEIVER    EX011970
828      82     01A5  FC090300                    CLAM    0,,X(0300)                                                        % 011980
                                        *                                                    "ALLOW DIRECT MEMORY ACCESS I/O  *I011990
829      84     01A7  DF61                        LGC     DMA_INHIBIT+E   "TO OCCUR (INHIBIT NOT TRUE)    EX012000
                                        *                                                    "ALLOW INTERRUPTS TO OCCUR IN THE*I012010
830      86     01A8  DF60                        LGC     INTERRUPT_INHIBIT+E   "107C (INHIBIT NOT TRUE)  EX012020
831      96     01A9  F0070023                    STA     0,,OUTPUT_TEST_AND_MISCELLANEOUS_SIGNALS          EX012030
                                        *                                                    "SET COMPUTER AND SYSTEM OK BITS EX012040
                                        *                                                    "IN TEST SIGNAL OUTPUT WORD      EX012050
                                        *                                                      "100 MILLISECOND MONITOR SIGNAL*I012060
832     104     01AB  03CC                        SET     PROGRAM_SEQUENCING   "FOR MALF INDICATOR        EX012070
833     112     01AC  F80F8CC3                    IOC     0,,PROGRAMMER_CONTROLLER_GO_LIGHT                               012080
```

```
834     122     01AE FC0D0150                POP     0,,PROGRAM_IO+1   'GO' & MOD # ON P/C          012090
                                * THE 5 MSEC OMEGA INTERRUPT WILL BE                                 *H012100
                                * ENABLED AFTER ONE PASS THROUGH                                     *H012110
                                * CHECKSUM.  THIS ROUTINE WILL CYCLE                                 *H012120
                                * THROUGH CHECKSUM REPEATEDLY (EXCEPT                                *H012130
                                * WHEN DOING SYNC CALCULATIONS) WHEN                                 *H012140
                                * THERE ARE NO OTHER PROCESSING REQUIREMENTS                         *H012150
                                *                                                                   EX012160
                                *                                "CHECKSUM PROGRAM AREA OF MEMORY   *I012170
835      8R *   0180 F80D0243   TEST_SYNC BSV     MP_CKSUM       "INDICATE MALF IF NOT CORRECT      EX012180
836     14      0182 9E09 (0089)          CLA     0,,TEN_SECOND_SYNC_PERIOD_COMPLETE_MARKER         % 012190
                                *                                "HAS A SYNC IO                     *2012200
837     18      0183 D864 (0180)          BRE     TEST_SYNC      "SEC DATA COLLECTION PERIOD JUST   %R012210
                                *                                "ENDED?                            EX012220
                                * PERFORM SYNC COMPUTATIONS                                         *H012230
                                * RETURN TO TEST SYNC IF NOT COMPLETE                               *H012240
                                * CONTINUE ON IF SYNC IS COMPLETE                                   *H012250
```

```
                        **                                                                          SY012260
                        *                          SYNC CALCULATIONS                                #H012270
                        *                                                                           #H012280
                        *  THIS PROGRAM IS ENTERED AFTER THE SYNC DATA COLLECTION ROUTINE           #H012290
                        *  HAS COLLECTED DATA FOR TEN SECONDS.  IT WILL PROCESS THE DATA AND        #H012300
                        *  DECIDE IF SYNC IS COMPLETE.                                              #H012310
                        *                                                                           #H012320
 838      2R    01B4  9C00          SYNC_CALC  CLAM    0,0            "RESET SYNC TEN SECOND MARKER"  SY012330
 839     10     01B5  7009  (0089)              STA     0,,TEN_SECOND_SYNC_PERIOD_COMPLETE_MARKER      SY012340
 840     14     01B6  FC79000C8                 CLAM    7,,200         "INITIALIZATION"                %S012350
 841     16     01B8  A487                      CLA     8,7            "SET C(100) = -.5               SY012360
 842     18     01B9  A497                      CLA     9,7            "SET POINTERS TO THE 4 LARGEST  SY012370
 843     20     01BA  A4A7                      CLA     10,7           "C(I) = C(100)                  SY012380
 844     30     01BB  FC0A1A7A                  CLAD    0,,=DF(-18-1)      LOCATION                    SY012390
 845     34     01BD  FC891DAE                  CLAM    11,,SYNC_C                                     SY012400
 846     44     01BF  7878                      STAD    IX7,11                                         SY012410
 847     48     01C0  FC49000C6                 CLAM    4,,198         "SET UP INDEX FOR I (0 TO 198)  SY012420
 848     50     01C2  9C30                      CLAM    3,0            "BY 2'S FOR THE 100 C'S (0 TO 99)SY012430
 849     52     01C3  9C50                      CLAM    5,0            "SET UP INDEX FOR K (0 TO 14)   SY012440
 850     54     01C4  9C6E                      CLAM    6,14           "BY 2'S FOR THE 8 STATIONS      SY012450
 851      6R    01C5  8400          $33         FETM    0,,0           "START C(I) COMPUTATION"        SY012460
 852     10     01C6  B822                      SUBD    2,2            "SET SUMMATION = 0"             SY012470
 853      2R    01C7  A406          $3          CLA     0,6            "COMBINE K AND FREQ (MOD 8) TO  SY012480
 854      8     01C8  9208  (0088)              SUB     0,,SYNC_FREQUENCY "FIND OUT WHICH STATION IS NEXSY012490
 855     14     01C9  F0044000                  RSA     0,,1           "(STATION = A FOR K = 0 AND 10.2)SY012500
 856     18     01CB  D021  (01CD)              BGE     $1                                             % 012510
 857      2R    01CC  9408                      ADDM    0,8                                            SY012520
 858      8R    01CD  F50A00D5      $1          CLA     X0,,POWERS_OF_TWO                              % 012530
 859     16     01CF  E40000E5                  EXT     0,0,STATIONS_IN_USE                            SY012540
 860     20     01D1  D06C  (01DE)              BRE     $2             "IS THIS A USABLE STATION?      SY012550
                        *                                             "READ START TIME AND BURST      SY012560
                        *                                             "TIME FOR THIS STATION.  ALL    SY012570
                        *                                             "TIMES ARE RELATIVE TO START OF SY012580
                        *                                             "STATION A 10.2 AND IN UNITS OF SY012590
 861     10R    01D2  FD6A16DE                  CLAD    X6,,SYNC_LIMIT_TABLE ".05 SEC (THEREFORE THE STASY012600
                        *                                             "TIME IS A NUMBER BETWEEN 0 AND SY012610
                        *                                             "198 AND MATCHES THE INDEX I).  SY012620
                        *                                             "BURST TIME IS THE NUMBER OF .1 SY012630
                        *                                             "SEC INTERVALS IN A STATION BURSTSY012640
                        *                                             "COMPUTE SUM OVER BURST FOR THIS #I012650
 862     18  *  01D4  F80D0268                  BSV     SYNC_SUMMATION_SUBROUTINE   "STATION           SY012660
 863     22     01D6  8C40                      ADDD    4,0            "ADD SHORT SUM TO C(I)          SY012670
 864     32     01D7  D710                      PRN     1              "INCREASE NUMBER OF .1 SEC      %S012680
```

```
865     34        01D8  9414                    ADDM    1,4          "INTERVALS BY 4 AND LOWER THE    SY012690
866     36        01D9  9004                    SUBM    0,4          "START TIME BY 2 .1 SEC INTERVALSSY012700
                                        *                            "TO INCLUDE SLOTS BEFORE AND     SY012710
                                        *                            "AFTER BURST IN NEXT SUM.        SY012720
                                        *                            "COMPUTE SUM OVER BURST + SLOTS  *I012730
867     44  *     01DA  F80D0268                BSV     SYNC_SUMMATION_SUBROUTINE   "FOR THIS STATION SY012740
868     48        01DC  8840                    SUBD    4,0          "SUBTRACT LONG SUM FROM C(I)     SY012750
869     58        01DD  D710                    PRN     1                                             SY012760
                                        *                            "INCREMENT K BY 2                *2012770
870      8R       01DE  CD68    (01C7)  $2      BXUD    6,,$3        "ARE THERE MORE STATIONS FOR     SY012780
                                        *                            "THIS C(I)?                      SY012790
871      2R       01DF  A412                    CLA     1,2          "AVERAGE C(I) WITH OLD C(I)"     SY012800
872      4        01E0  A423                    CLA     2,3          "AVERAGE = (C(I) - C(OLD))/N     SY012810
873     12        01E1  D700                    PRN     0            "              + C(OLD)          SY012820
874     20        01E2  8838                    SUBD    IX3,11       "WHERE N = NUMBER OF TEN SECOND  SY012830
875     38        01E3  4285    (0085)          MPYD    0,,SYNC_10VERN "INTERVALS PROCESSED          SY012840
876     46        01E4  8F38                    ADDD    IX3,11                                        SY012850
877     56        01E5  7838                    STAD    IX3,11       C 825                            SY012860
                                        *                                                             SY012870
                                        *                              R0 = KLK, C(I)                 SY012880
                                        *                              R1 = KUK - KLK + 1             SY012890
                                        *                              R2 = TEMP (SUM)                SY012900
                                        *                              R3 = I                         SY012910
                                        *                              R4 = I END                     SY012920
                                        *                              R5 = K                         SY012930
                                        *                              R6 = K END                     SY012940
                                        *                              R7 = I 4TH LARGEST             SY012950
                                        *                              R8 = I 3RD LARGEST             SY012960
                                        *                              R9 = I 2ND LARGEST             SY012970
                                        *                              RA = I 1ST LARGEST             SY012980
                                        *                              RB = SYNC C ADDRESS            SY012990
                                        *                              RC = SPARE                     SY013000
                                        *                              R0 = TEMP(FIRST SUM)           SY013010
                                        *                                                             SY013020
                                        * NOW DETERMINE IF THIS C(I) IS ONE                           *H013030
                                        * OF THE FOUR LARGEST C(I)'S COMPUTED                        *H013040
                                        * SO FAR                                                     *H013050
878     64        01E6  8878                    COMD    IX7,11                                        % 013060
                                        *                            "IS THIS C(I)                    *1013070
879     68        01E7  D05D    (01F5)          BRL     $4           "LARGER THAN THE FOURTH LARGEST? %R013080
880      2R       01E8  A473                    CLA     7,3          "PUT I INTO 4TH LARGEST POINTER  SY013090
881     10        01E9  8888                    COMD    IX8,11                                        SY013100
                                        *                            "IS THIS C(I)                    *1013110
```

```
882     14      01EA  D05A  (01F5)          BRL     $4          "LARGER THAN THE THIRD LARGEST?  %R013120
883      2R     01EB  A478                  CLA     7,8         "MOVE OLD THIRD POINTER TO 4TH   SY013130
884      4      01EC  A483                  CLA     8,3         "AND PUT I INTO 3RD LARGEST      SY013140
885     12      01ED  8898                  COMD    IX9,11      "POINTER                         SY013150
                                *                               "IS THIS C(I)                    *1013160
886     16      01EE  D056  (01F5)          BRL     $4          "LARGER THAN THE SECOND LARGEST? %R013170
887      2R     01EF  A489                  CLA     8,9         "MOVE OLD SECOND POINTER TO 3RD  SY013180
888      4      01F0  A493                  CLA     9,3         "AND PUT I INTO 2ND LARGEST      SY013190
889     12      01F1  88A8                  COMD    IX10,11     "POINTER                         SY013200
890     16      01F2  D052  (01F5)          BRL     $4          "IS THIS C(I) THE LARGEST C(I)?  %R013210
891      2R     01F3  A49A                  CLA     9,10        "MOVE OLD 1ST POINTER TO 2ND AND SY013220
892      4      01F4  A4A3                  CLA     10,3        "PUT I INTO THE LARGEST POINTER  SY013230
                                *                               "I = I+2                         *2013240
893      8R     01F5  CF31  (01C5)  $4      BXUD    3,,$33      "ARE THERE MORE C(I)'S TO        SY013250
                                *                               "COMPUTE?                        SY013260
                                * NOW USE THE FOUR LARGEST C(I)'S TO                             *H013270
                                * DETERMINE IF SYNCHRONIZATION HAS BEEN                         *H013280
                                * OBTAINED AND, IF SO, COMPUTE SYNC TIME                        *H013290
                                *                                                              SY013300
                                *                   DETERMINE IF SYNC IS COMPLETE              SY013310
                                *                                                              SY013320
894      8R     01F6  AFAB                  CLAD    IX10,11     "COMPUTE CONFIDENCE LEVEL"C"     SY013330
895     28      01F7  F8061A7C              MPYD    0,,=DF((.15)*2) "C =(.3*C(1ST) + .036*4*240*240) SY013340
896     38      01F9  FC0B1A7E              ADDD    0,,=DF(.036*16*240*240*28-25/2)              HH013350
897     50      01F8  8685  (0085)          FETD    0,,SYNC_LOVERN                               SY013360
898    496      01FC  1000                  SQRT    0                                            SY013370
899    512      01FD  6820                  MPYD    2,0         CONFIDENCE LEVEL  825            SY013380
900    524      01FE  F8071ED5              STAD    0,,Q_STORAGE+2 "SAVE 1/N**.5 FOR SYNC DISPLAY SO%S013390
                                *                               "THAT DISPLAY IS 0 IF C(1ST) IS  SY013400
                                *                               "LESS THAN ZERO                  SY013410
901    536      0200  F8271ED7              STAD    2,,Q_STORAGE+4 "SAVE C FOR SYNC DISPLAY        SY013420
902    544      0202  AFCD                  CLAD    IX12,13     LARGEST MUST BE +                OM013430
903    554      0203  D710                  PRN     1                                            SY013440
                                *                               "IS C(1ST) MINUS?                *1013450
904    560      0204  04050180              BRL     TEST_SYNC   "(COLLECT MORE DATA IF YES)      SY013460
905      8R     0206  88A8                  SUBD    IX10,11     "FORM (C(1ST) - C(2ND)) - C      SY013470
906     12      0207  A800                  CLSD    0,0         C1ST - CD                        SY013480
907     20      0208  8898                  SUBD    IX9,11      COM WITH SEC                     SY013490
908     32      0209  F8071ED5              STAD    0,,Q_STORAGE+2 "AND SAVE FOR SYNC DISPLAY      SY013500
                                *                               "IS C(1ST)-C(2ND)                *2013510
909     36      020B  D231  (022D)          BRG     $10         "GREATER THAN C?  (SYNC COMPLETE SY013520
                                *                               "IF YES)                         SY013530
                                * THERE IS STILL A POSSIBILITY THAT                             *H013540
```

```
                                    * SYNC IS COMPLETE IF C(1ST) IS IN                                  *H013550
                                    * A TIME SLOT ADJACENT TO C(2ND) OR                                 *H013560
                                    * C(3RD)                                                           *H013570
910          8R   020C  BF9B                    ADDD    IX9,11                                         SY013580
911          10   020D  A42A                    CLA     2,10        "FORM ABSOLUTE I(1ST) - I(2ND)     SY013590
912          12   020E  B029                    SUB     2,9           ADJACENT                         SY013600
913          16   020F  D021   (0211)           BGE     $21                                            % 013610
914          2R   0210  A022                    CLS     2,2                                            SY013620
915          2R   0211  9822              $21   COMM    2,,2                                           % 013630
                                    *                     "ARE C(1ST) AND                            *2013640
916          6    0212  D066   (0219)          BRE     $12         "C(2ND) ADJACENT?   (I(1ST)        SY013650
                                    *                     "- I(2ND) = 2)                             SY013660
917          4R   0213  F829900C6              COMM    2,,198                                         % 013670
                                    *                     "ARE C(1ST) AND                            *2013680
918          10   0215  04010180               BNE     TEST_SYNC   "C(2ND) THE FIRST AND LAST .1 SEC %R013690
                                    *                     "INTERVALS?                                SY013700
919          4R   0217  F49900C8               ADDM    9,,200      "ADD 10 SEC TO I(2ND) SO THAT      SY013710
                                    *                     "I(1ST) + I(2ND) AVERAGE WILL              SY013720
                                    *                     "BE CORRECT IF SYNC IS COMPLETE            SY013730
920          8R   0219  BB8B              $12   SUBD    IX8,11      "SAVE (C(1ST) - C(3RD)) - C        SY013740
921          20   021A  F8071ED5               STAD    0,,Q_STORAGE+2 "FOR SYNC DISPLAY               SY013750
                                    *                     "IS C(1ST)-C(3RD)                          *2013760
922          24   021C  D132   (022F)          BRG     $13         "GREATER THAN C?  (SYNC COMPLETE   SY013770
                                    *                     "IF YES)                                   SY013780
923          8R   021D  BF8B                    ADDD    IX8,11                                         SY013790
924          10   021E  A42A                    CLA     2,10        "FORM ABSOLUTE I(1ST) - I(3RD)     SY013800
925          12   021F  B028                    SUB     2,8           ADJACENT                         SY013810
926          16   0220  D021   (0222)          BGE     $14                                            % 013820
927          2R   0221  A022                    CLS     2,2                                            SY013830
928          2R   0222  9822              $14   COMM    2,,2                                           % 013840
                                    *                     "ARE C(1ST) AND                            *2013850
929          6    0223  D064   (0228)          BRE     $15         "C(3RD) ADJACENT?   (I(1ST)        SY013860
                                    *                     "- I(3RD) = 2)                             SY013870
930          4R   0224  F829900C6              COMM    2,,198                                         % 013880
                                    *                     "ARE C(1ST) AND                            *2013890
931          10   0226  04010180               BNE     TEST_SYNC   "C(3RD) THE FIRST AND LAST .1 SEC %R013900
                                    *                     "INTERVALS?                                SY013910
932          8R   0228  BB7B              $15   SUBD    IX7,11      "SAVE (C(1ST) - C(4TH)) - C        SY013920
933          20   0229  F8071ED5               STAD    0,,Q_STORAGE+2 "FOR SYNC DISPLAY               SY013930
                                    *                     "IS C(1ST)-C(4TH)                          *2013940
934          26   022B  04040180               BLE     TEST_SYNC   "GREATER THAN C?  (SYNC COMPLETE  %R013950
                                    *                     "IF YES)                                   SY013960
935          2R   022D  A41A              $10   CLA     1,10        "SYNC COMPLETE"                    SY013970
```

```
                                        *                                   "I(1ST) DEFINES START OF STATION SY013980
936      6      022E  D004  (0233)              BUC     $16                 "A 10.2 BURST                    SY013990
937      2R     022F  A41A                $13   CLA     1,10                "SYNC COMPLETE"                  SY014000
938      4      0230  B419                      ADD     1,9                 "C(1ST) AND C(2ND) ARE ADJACENT  SY014010
                                        *                                   "USE (I(1ST) + I(2ND))/2 TO      SY014020
                                        *                                   "DEFINE START OF STATION A       SY014030
939      10     0231  F0144000                  RSA     1,,1                "10.2 BURST                      SY014040
940      4R     0233  441A                $16   MPIM    1,,10               "MULTIPLY I BY 10 TO GET STATION SY014050
                                        *                                   "A 10.2 BURST TIME WITH RESOLU-  SY014060
                                        *                                   "TION OF 5 MSEC. THE EFFECTIVE   SY014070
                                        *                                   "RESOLUTION IS THE .1 SEC INTER- SY014080
                                        *                                   "VAL OVER 2 (OR 50 MSEC)         SY014090
941      2R     0234  9C00                $8    CLAM    0,0                                                  % 014100
                                        *                                   "ADD START SYNC TIME TO GET TIME SY014110
                                        *                                   "OF STATION A 10.2 BURST IN      SY014120
942      10     0235  9688  (0088)              ADDD    0,,START_SYNC_TIME                                   SY014130
                                        *                                   "REAL TIME (COMPUTER TIME)  IT ISSY014140
                                        *                                   "THE BURST THAT OCURRED DURING   SY014150
943      20     0236  7808  (0088)              STAD    0,,START_SYNC_TIME                                   SY014160
                                        *                                   "THE FIRST SYNC 10 SEC PERIOD    SY014170
944      24     0237  B800                      SUBD    0,0                  SET OMEGA TIME = 0 TO STOP SYNC  SY014180
945      34     0238  7817  (0097)              STAD    0,,OMEGA_TIME        DATA COLLECTION PROGRAM          SY014190
                                        *                                    SHOULD BE LARGE NUMBER IN OMEGA SY014200
                                        *                                    TIME TO STOP OMEGA PROGRAMS     SY014210
946      4R     0239  FC290205            $11   CLAM    2,,PHI_ZERO-SYNC_DATA COMPUTE NUMBER WORDS           HH014220
                                        *                                   "CLEAR THE SYNC DATA STORAGE AREASY014230
947      14     023B  F1171C1E                  STA     X1,,SYNC_DATA       "FOR USE BY OTHER PROGRAMS       SY014240
948      22     023D  C415  (0239)              BXU     1,,$11                                               % 014250
949      2R     023E  9C01                      CLAM    0,,1                "SET THE 'START OMEGA' MARKER TO %S014260
                                        *                                   "TELL THE START OMEGA PROGRAM    SY014270
950      10     023F  701C  (009C)              STA     0,,START_OMEGA_NOW  "TO BEGIN OMEGA NAVIGATION       SY014280
                                        *                                                                    SY014290
                                        *                                                                    SY014300
                                        *                                                                    EX014310
                                        * SEQUENCE TO THE LAST PART OF MAIN PROGRAM                          #H014320
```

```
                        **                                                                  EX014330
                        *   MAIN PROGRAM - CONTINUOUS CHECKSUM TEST                         EX014340
                        *       PMU DATA-ERROR LIGHT SET ON FAIL, RESET ON PASS             EX014350
                        *                                   "CHECKSUM PROGRAM AREA OF MEMORY *I014360
951                     MAIN_PROGRAM;                                                       EX014370
951       8R *  0240  F80D0243                BSV     MP_CKSUM       "INDICATE MALF IF NOT CORRECT  EX014380
952      12     0242  D803   (0240)            BUC     MAIN_PROGRAM   "LOOP ON CHECKSUM"             EX014390
```

```
                                                **                                                                  EX014400
                                                * MEMORY CHECKSUM - SUM ALL WORDS OF                                *H014410
                                                * MEMORY EXCEPT VARIABLE STORAGE                                    *H014420
                                                * RESULT SHOULD BE ZERO                                             *H014430
953        14R          0243  F80C0153          MP_CKSUM    FETD      0,,CKSUM_LINK                                  EX014440
954        22           0245  8411                          FETM      1,,1                                           EX014450
955         6R          0246  8602              $1          ADD       I0,2                                           EX014460
956        14           0247  C422    (0246)                BXU       2,,$1                                          EX014470
957         4R          0248  D064    (024D)                BRE       $3                                             EX014480
958         8R          0249  F0181C05                      COM       1,,DB_CKSUM_IGNORE MRKR=1 MEANS DB WRITE MADE  TS014490
959        12           024B  D014    (0250)                BNE       $4                                             TS014500
960         2R          024C  9C00                          CLAM      0,,0          PREPARE TO ZERO MRKR             TS014510
961        10R          024D  F0071C05          $3          STA       0,,DB_CKSUM_IGNORE  ALWAYS ZERO DB MRKR        014520
962        14           024F  D003    (0253)                BUC       $2                                             014530
963        18R *        0250  2EDC    (00DC)    $4          FAILD     I0,,HX0080     RESET COMP/REC GO               TS014540
964        30  *        0251  3400                          MARK      0,,0                                           TS014550
965        32           0252  9C01                          CLAM      0,,ERROR                                       EX014560
966        12R          0253  E00100A1          $2          MRG       0,1,PMU_INDICATOR_WORD                         EX014570
967        20           0255  8660    (00E0)                FET       0,,HX0800      ENABLE                          EX014580
968        34  *        0256  2E60    (00E0)                FAIL      I0,,HX0800       INTERRUPTS                    EX014590
969        52           0257  0530                          BBK       3                                              EX014600
```

```
                                                **                                                                  TS014610
                                                *                FAIL                                               *H014620
                                                *                                                                   *H014630
                                                * THIS PIN ROUTINE POSTS BITS IN THE                                *H014640
                                                * TEST SIGNAL OUTPUT WORD. THE BITS ARE                             *H014650
                                                * IN R0 AND THE MASK IS IN R1                                       *H014660
                                                *                                                                   TS014670
970          12R        0258  E0010023          FAIL_PIN    MRG         0,1,OUTPUT_TEST_AND_MISCELLANEOUS_SIGNALS  TS014680
                                                *                                    "MERGE BITS INTO TEST SIGNAL   EX014690
971          26         025A  D510              *           BBK         1            "OUTPUT WORD                  EX014700
                                                *                                                                   TS014710
                                                *                                                                   *H014720
                                                *                                                                   *H014730
                                                *                MARK                                               *H014740
                                                *                                                                   *H014750
                                                * THIS PIN ROUTINE WILL SET BITS IN A TEST                          *H014760
                                                * FAIL WORD GIVEN THE BIT NUMBER IN R0                              *H014770
972           8R        025B  F50A00D5          MARK_PIN    CLA         X0,,POWERS_OF_TWO "READ BIT FROM POWERS OF TWO EX014780
973          20         025D  E00000D1          *           MRG         0,0,TEST_FAIL  "TABLE AND MERGE INTO TEST FAIL EX014790
974          32         025F  E000002E          *           MRG         0,0,TEST_FAIL_TEMP "AND TEST FAIL TEMP WORDS   EX014800
975          44         0261  D500              *           BBK         0                                              TS014810
                                                *                                                                   014820
976                                             FAIL_EXTERNAL;                          PRN'S 1 OFF                 014830
976          18R *      0262  2EDD   (00DD)     *           FAILD       I0,,HX0100       TURN ON SYSTEM FAIL LIGHT  014840
977          12R        0263  E00000D2          $1          MRG         0,0,TEST_FAIL+1          ONLY.              014850
978          24         0265  E000002F          *           MRG         0,0,TEST_FAIL_TEMP+1                        014860
979          36         0267  D500              *           BBK         0                                           014870
```

```
                                **                                                                  SY014880
                                * SYNC SUMMATION ROUTINE                                           #H014890
                                *                                                                  #H014900
                                * THIS ROUTINE IS USED BY THE SYNC COMPUTATIONAL                    #H014910
                                * PROGRAM TO FORM THE SUMMATION OF THE SINE'S                       #H014920
                                * AND COSINE'S OVER THE INTERVAL SPECIFIED BY                       #H014930
                                * THE ARGUMENTS.  THE ARGUMENTS CONSIST OF THE                     #H014940
                                * NUMBER OF TERMS, NUMBER OF THE FIRST TERM                         #H014950
                                * (ASSUMING I=0) AND THE CURRENT VALUE OF I. THE                    #H014960
                                * ARGUMENTS ARE NOT DISTURBED AND THE RESULT IS                     #H014970
                                * LEFT IN REGISTERS ADDED BY THIS ROUTINE.                          #H014980
                                *                                                                  #H014990
980                             SYNC_SUMMATION_SUBROUTINE;                                         SY015000
980     20R  0268  8470                 FETM    7,,0        "CLEAR SUM COS AND SUM SIN             SY015010
981     22   0269  A459                 CLA     5,9         "MOVE NUMBER OF TERMS AND              SY015020
982     24   026A  A408                 CLA     0,8         "START POINT                           SY015030
                                *                           "IS THE START                          #2015040
983     28   026B  D021  (026D)         BGE     $1          "POINT IN PROPER RANGE?                SY015050
                                *                           "(0 TO 198 BY 2)                       SY015060
                                *                           "PUT START POINT INTO RANGE            SY015070
984      6R  026C  9679  (00F9)         ADD     0,,HD200    "BY ADDING 200                         SY015080
985     2R   026D  B40C             $1  ADD     0,12        "FORM START POINT + I                  SY015090
986     10   026E  F41A0087             CLA     1,,SYNC_DATA_ADDRESS "READ BASE ADDRESS OF SYNC    SY015100
                                *                           "DATA FOR THIS 10 SEC PERIOD AND       SY015110
987     12   0270  8401                 ADD     0,1         "ADD TO CURRENT START POINT            SY015120
988     16   0271  F41900C8             ADDM    1,,200      "FORM BASE ADDRESS + 200 = UPPER       SY015130
                                *                           "LIMIT OF DATA STORAGE AREA            SY015140
989     2R   0273  8001             $3  CCM     0,1         "POINTER TO NEXT DATA WORD IS NOW      SY015150
                                *                           "AVAILABLE FOR SUM'S                   SY015160
                                *                           "IS THE DATA                           #2015170
990     6    0274  D051  (0276)         BRL     $2          "POINTER LESS THAN THE DATA UPPER      SY015180
                                *                           "LIMIT?                                SY015190
991     6R   0275  9279  (00F9)         SUB     0,,HD200    "FORM POINTER - 200 TO PUT IT IN       SY015200
                                *                           "THE PROPER RANGE                      SY015210
992     6R   0276  8620             $2  ADD     I2,0        "USE DATA POINTER TO SUM COSINE        SY015220
993     8    0277  9401                 ADDM    0,,1        "INCREMENT POINTER FOR SIN             SY015230
994     14   0278  8660                 ADD     I6,0        "USE DATA POINTER TO SUM SINE          SY015240
995     16   0279  9401                 ADDM    0,1         "INCREMENT POINTER FOR NEXT PAIR       SY015250
                                *                           "ARE THERE MORE                        #1015260
996     24   027A  C448  (0273)         BXU     4,,$3       "TERMS TO ADD TO THE SUM'S?            SY015270
997     2R   027B  9451                 ADDM    5,,1        "FORM FINAL RESULT"                    SY015280
998     6    027C  F4540400             LSA     5,,10       "= ((SUM SIN)**2 + (SUM COS)**2)       SY015290
999     8    027E  A445                 CLA     4,5         "  /(NUMBER OF TERMS)                  SY015300
```

```
1000    10    027F  9C50          CLAM    5,0     "THE SUM'S ARE IN COUNTS AT B15   SY015310
1001    26    0280  6822          MPYD    2,2     "NO OF TERMS IS AN INTEGER AT B5  SY015320
1002    42    0281  6866          MPYD    6,6     "RESULT IS COUNTS SQUARED AT B25  SY015330
1003    46    0282  8C62          ADDD    6,2     SUM SQ B30                        SY015340
1004   172    0283  DC64          DIVD    6,4     C(I) INCREMENT B25                SY015350
1005   194    0284  D550          BBK     5                                         SY015360
                                  *                                                 SY015370
                                  *       R0 = BASE + KLK +I                        SY015380
                                  *       R1 = LAST ADDRESS OF THIS SET OF DATA     SY015390
                                  *       R2 = SUM Y                                SY015400
                                  *       R3 = SUM X                                SY015410
                                  *       R4 = TERM COUNT                           SY015420
                                  *       R5 = NUMBER OF TERMS                      SY015430
                                  *       R6 = KLK                                  SY015440
                                  *       R7 = NUMBER OF TERMS                      SY015450
                                  *       R8 = TEMP                                 SY015460
                                  *       R9 = I                                    SY015470
```

```
                                        **                                                                      EX015480
                                        *                                                                       EX015490
                                        *           EXECUTIVE                                                   *H015500
                                        *                                                                       *H015510
                                        * FIVE MILLISEC OMEGA INTERRUPT PROGRAM                                 *H015520
                                        * ALL TASKS ARE INITIATED FROM THIS ROUTINE                             *H015530
                                        *                                                                       EX015540
1006    12R   0285  868C  (008C)  EXEC      FETD    0,,TIME        "INCREMENT CURRENT COMPUTER TIME EX015550
1007    20    0286  96EB  (00EB)           ADDD    0,,=DX(1)        "BY 5 MILLISEC (LOW ORDER BIT) EX015560
1008    30    0287  783C  (008C)           STAD    0,,TIME                                         EX015570
1009    34    0288  F8097FFF               COMM    0,,X(7FFF)     "DO NOT LET TIME OVERFLOW          015580
1010    38    028A  D013  (028E)           BNE     $2                                                015590
1011    10R   028B  D710                   PRN     1                                                 015600
1012    16    028C  04000306               BUC     SYNC$9                                            015610
                                        *                                            "100 MILLISECOND MONITOR SIGNAL *I015620
1013     8R   028E  030C                 $2        SET     PROGRAM_SEQUENCING    "FOR MALF INDICATOR  EX015630
1014    20    028F  86C6  (00C6)           FETD    0,,GMT         "INCREMENT GMT FOR MAGNETIC TAPE % 015640
1015    28    0290  96EB  (00EB)           ADDD    0,,=DX(1)                                       % 015650
1016    40    0291  7C46  (00C6)           PTRD    0,,GMT                                          % 015660
1017    48    0292  9A97  (0097)           COMD    0,,OMEGA_TIME                                   % 015670
                                        * NOTE - TIME IS IN REGISTERS 0 AND 1                                   *H015680
                                        * WHEN BEGINNING A NEW OMEGA TASK                                       *H015690
                                        *                                            "IS IT TIME                *I015700
1018    58    0293  06020099               BGE     I,,OMEGA_TASK  "TO START A NEW OMEGA TASK?      EX015710
1019     8R   0295  9A93  (0093)           COMD    0,,NON_OMEGA_TIME                               % 015720
                                        *                                            "IS IT TIME TO             *I015730
1020    12    0296  D021  (0298)           BGE     DO_NON_OMEGA_TASK   "START A NEW NON OMEGA TASK?EX015740
                                        * NO NEW TASKS TO BE INITIATED AT THIS TIME                              *H015750
1021    14R   0297  D510               END_EXEC  BBK     1              "RETURN TO INTERRUPTED PROGRAM   EX015760
```

```
                                        **                                                                      EX015770
                                        *           NON OMEGA TASK                                              *H015780
                                        *                                                                       *H015790
                                        * THIS ROUTINE SELECTS THE NEXT NON OMEGA TASK                          *H015800
                                        * FROM A TABLE.  AFTER ALL TASKS HAVE BEEN                              *H015810
                                        * EXECUTED IT UPDATES THE TIME OF NON OMEGA                             *H015820
                                        * TASKS BY .1 SEC.                                                      *H015830
1022                                    DO_NON_OMEGA_TASK;                                                      EX015840
1022     8R     0298  9E91  (0091)              CLAD      0,,NON_OMEGA_TASK_INDEX "READ LAST VALUE OF TABLE     EX015850
1023     10     0299  9C18                      CLAM      1,,END_TASK-NON_OMEGA_TASK_TABLE "POINTER              EX015860
                                        *                                "(POINTER + 1)                         *I015870
1024     20     029A  F40C 02A0                BXU       0,,$1           "HAVE ALL ENTRIES BEEN EXECUTED?       %R015880
1025     12R    029C  8695  (0095)              FETD      0,,OLD_NON_OMEGA_TASK_TIME "COMPUTE THE TIME THAE      EX015890
1026     20     029D  96ED  (00ED)              ADDD      0,,=D20         "THE NON OMEGA TASK SHOULD BE          EX015900
                                        *                                "INITIATED AGAIN BY ADDING .1 SECE     EX015910
                                        *                                "TO THE TIME THAT THEY WERE LAST       EX015920
                                        *                                "INITIATED.                            EX015930
1027     30     029E  7815  (0095)              STAD      0,,OLD_NON_OMEGA_TASK_TIME                            EX015940
1028     42     029F  7C13  (0093)              PTRD      0,,NON_OMEGA_TIME "SAVE NEXT NON OMEGA TASK TIMEE      EX015950
1029     10R    02A0  7811  (0091)  $1          STAD      0,,NON_OMEGA_TASK_INDEX "SAVE NEW POINTER VALUE        EX015960
1030     20     02A1  070002A3                  BUC       IX0,,NON_OMEGA_TASK_TABLE "SELECT TASK FROM TABL       %S015970
                                        * THE TABLE CONSISTS OF 12 ENTRIES      OMEGA DEBUG                     *H015980
                                        *                                       VELOCITY PROCESSING             *H015990
                                        * THE SECOND ENTRY IS THE FIRST         OMEGA DEBUG                     *H016000
                                        * ROUTINE EXECUTED AND THE FIRST        RIJ UPDATE                      *H016010
                                        * ENTRY IS THE LAST ROUTINE             OMEGA DEBUG                     *H016020
                                        * EXECUTED IN A GIVEN .1 SEC            OMEGA DEBUG                     *H016030
                                        * PERIOD.  AFTER THE LAST ROUTINE       PANEL MAIN                      *H016040
                                        * IS EXECUTED THERE IS A WAIT            OMEGA DEBUG                     *H016050
                                        * (USUALLY .04 SEC) BEFORE THE          AD IO TEST                      *H016060
                                        * FIRST ROUTINE IS EXECUTED AGAIN.      OMEGA DEBUG                     *H016070
                                        * ONE ROUTINE IS EXECUTED EACH 5         SLOW                           *H016080
                                        * MILLISECONDS                           START OMEGA                    *H016090
                                        *                                                                       EX016100
1031                                    NON_OMEGA_TASK_TABLE;                                                   EX016110
1031             02A3  1947                     CON       OMEGA_DEBUG                                         EX016120
1032             02A4  0690                     CON       VELOCITY_PROCESSING                                 EX016130
1033             02A5  1947                     CON       OMEGA_DEBUG                                         EX016140
1034             02A6  0701                     CON       RIJ_UPDATE                                          EX016150
1035             02A7  1947                     CON       OMEGA_DEBUG                                         EX016160
1036             02A8  1947                     CON       OMEGA_DEBUG                                         EX016170
1037             02A9  0E82                     CON       PANEL_MAIN                                          EX016180
1038             02AA  1947                     CON       OMEGA_DEBUG                                         EX016190
```

```
1039  02A8  1949          CON     AD_IO_TEST      EX016200
1040  02AC  1947          CON     OMEGA_DEBUG     EX016210
1041  02AD  02AF          CON     SLOW            EX016220
1042  02AE  0334  END_TASK CON     START_OMEGA     EX016230
```

```
                                                **                                                                  EX016240
                                                *           ONE SECOND                                              #H016250
                                                *                                                                   #H016260
                                                * THIS ROUTINE IS A NON OMEGA TASK THAT                              #H016270
                                                * WILL CYCLE THROUGH A TABLE OF TEN ENTRIES                          #H016280
                                                * EXECUTING ONE TASK EACH TIME (THEREBY                              #H016290
                                                * YIELDING ROUTINES EXECUTED ONCE A SECOND)                          #H016300
1043      6R    02AF  9E24  (00A4)  SLOW        CLA         0,,SLOW_RATE  "READ LAST VALUE OF TABLE POINTERE          EX016310
                                                *                         "INCREMENT POINTER AND RESET              EX016320
                                                *                         "TO ZERO IF IT GOES TO 10                 EX016330
1044      8     02B0  9C19                      CLAM        1,,9                                                    EX016340
1045     16     02B1  C400  (02B2)              BXU         0,,$1                                                   % 016350
1046     8R     02B2  7024  (00A4)  $1          STA         0,,SLOW_RATE                                            % 016360
                                                *                         "SAVE NEW VALUE OF POINTER                EX016370
1047     18     02B3  07000285                  BUC         IX0,,ONE_SEC  "SELECT NEXT TASK FROM TABLE              %S016380
                                                * THE TABLE CONSISTS OF 10 ENTRIES     RZ UPDATE          2ND       #H016390
                                                * WHERE THE FIRST, 4TH, AND LAST 5 ENTRIES                          #H016400
                                                * RETURN TO THE INTERRUPTED PROGRAM    RZ TIME UPDATE 3RD          #H016410
                                                * AS THERE ARE ONLY 3 1 SEC ROUTINES   GP TEST 5TH                 #H016420
                                                *                                                                   EX016430
                                                *                                                                   EX016440
1048              02B5  0297                    ONE_SEC     CON         END_EXEC      NO MAG VAR IN SUB             EX016450
1049              02B6  1579                    $101        CON         RZ_UPDATE                                   EX016460
1050              02B7  1598                                CON         RZ_TIME_UPDATE                              EX016470
1051              02B8  0297                    $100        CON         END_EXEC                                     016480
1052              02B9  1948                                CON         GP_TEST                                     EX016490
1053              02BA  194D                                CON         OSC_TEST      OSCILATOR DRIFT TEST          EX016500
1054              02BB  0297                    $102        CON         END_EXEC                                     016510
1055              02BC  0EA2                    $103        CON         OPER_P_C      BECOMES TYPE ROUTINE ENTRY    016520
1056              02BD  0297                    $104        CON         END_EXEC      DATA COLLECT WHEN LOADED      016530
1057              02BE  0297                                CON         END_EXEC                                    EX016540
                                                *                                                                   EX016550
                                                *                                                                   EX016560
1058                                            OMEGA_TASK_TABLE,;                                                  EX016570
1058              02BF  02E7                    SYNC1       CON         SYNC                                        EX016580
1059              02C0  0028                                CON         40                                          EX016590
1060              02C1  02F3                    SYNC2       CON         SYNC$2                                      EX016600
1061              02C2  001E                                CON         30                                          EX016610
1062              02C3  0300                    SYNC3       CON         SYNC$3                                      EX016620
1063              02C4  0014                                CON         20                                          EX016630
1064              02C5  0538                    START_SLOT  CON         START_OF_SLOT                               EX016640
1065              02C6  001E                                CON         30                                          EX016650
1066              02C7  0544                    END_SLOT    CON         END_OF_SLOT                                 EX016660
```

```
1067  02C8  0014          CON     20                                      EX016670
1068  02C9  0635  START_BURST CON  START_OF_BURST                          EX016680
1069  02CA  001E          CON     30                                      EX016690
1070  02CB  0765  K_FILTER CON     KALMAN_FILTER                           EX016700
1071  02CC  0000          CON     0                                       EX016710
1072  02CD  0357  END_BURST CON    END_OF_BURST                            EX016720
1073  02CE  0001          CON     1                                       EX016730
1074  02CF  194F  TEST1    CON     PREFLIGHT_TEST                          EX016740
1075  02D0  000A          CON     10                                      EX016750
1076  02D1  195A  TEST2    CON     PREAMP_TEST$1                           EX016760
1077  02D2  00C8          CON     200          200 X 5 MSEC = 1 SECOND    EX016770
1078  02D3  1965  TEST3    CON     PREAMP_TEST$2                           EX016780
1079  02D4  00C8          CON     200                                     EX016790
1080  02D5  1983  TEST4    CON     RF_TEST$1                               EX016800
1081  02D6  00C8          CON     200                                     EX016810
1082  02D7  1982  TEST5    CON     AD_TEST$1                               EX016820
1083  02D8  0008          CON     8                                       EX016830
1084  02D9  198A  TEST6    CON     RF_TEST$2                               EX016840
1085  02DA  00C8          CON     200                                     EX016850
1086  02DB  19ED  TEST7    CON     PD_TEST$1                               EX016860
1087  02DC  00C8          CON     200                                     EX016870
1088  02DD  1A0A  TEST8    CON     PC_TEST$1                               EX016880
1089  02DE  00C8          CON     200                                     EX016890
1090  02DF  1A15  TEST9    CON     PC_TEST$2                               EX016900
1091  02E0  00C8          CON     200                                     EX016910
1092  02E1  1A27  TEST10   CON     DMA_TEST$1                              EX016920
1093  02E2  0001          CON     1                                       EX016930
1094  02E3  19E9  TEST11   CON     PD_TEST                                 EX016940
1095  02E4  0004          CON     4                                       EX016950
1096  02E5  197A  TEST12   CON     RF_TEST                                 EX016960
1097  02E6  000A          CON     10                                      EX016970
```

```
                                        **                                                                  SY016980
                                        *           SYNCHRONIZATION                                         *H016990
                                        *                                                                   *H017000
                                        * ENTERED .2 SEC AFTER PREFLIGHT TESTS                             *H017010
                                        *                                   "SET UP SECOND SYNC TASK .15 SECS*I017020
1098    70R     02E7  0801    SYNC       OMEGA     0,,SYNC2-OMEGA_TASK_TABLE/2 "AFTER THIS TASK          SY017030
1099    76      02E8  8401               FETM      0,,X(0001)        "SET + A LOOP FOR FLOATER ANTENNA   SY017040
                                        *                           "READ STATE OF THE ANTENNA SELECT*I017050
1100    84      02E9  F0081F8C           COM       0,,FLOATER        "WORD  1=FLOAT  0=LOOP              SY017060
                                        *                           "IS THE SYSTEM                      *2017070
1101    88      02EB  D061   (02ED)      BRE       $1                "OPERATING WITH THE FLOATER         SY017080
                                        *                           "ANTENNA?                           SY017090
1102    2R      02EC  9C06               CLAM      0,,6              "LOOP ANTENNA"                        017100
                                        *                           "SELECT +8 LOOP AND A LOOP +90      SY017110
1103    8R      02ED  C010     $1        FET       1,0               "WRITE LOOP SELECTIONS INTO         SY017120
                                        *                           "ANTENNA SWITCHING MATRIX FOR ALL   SY017130
1104    26      02EE  F4270020           PTR       2,,ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2 "3 FREQ       SY017140
1105    34      02F0  F80F8CC0           IOC       0,,X(8CC0)        PROG CONT - SEND GO LIGHT           SY017150
1106    42      02F2  D5F0               BBK       15                                                    SY017160
                                        *                                                                   SY017170
                                        * SECOND SYNC TASK - CLEAR 10.2 REGISTERS AND START SYNC           SY017180
                                        * SECOND SYNC TASK - CLEAR SIN/COS REGISTERS                      *H017190
                                        * AND START FIRST SYNC 10 SECOND PERIOD                           *H017200
1107    10R     02F3  7808   (0088)    $2        STAD      0,,START_SYNC_TIME "SAVE SYNC START TIME"       SY017210
                                        *                           "THE SYNC PROCESS WILL DETERMINE    SY017220
                                        *                           "WHEN STATION A STARTS ITS 10.2     SY017230
                                        *                           "BURST WITHIN THE FIRST 10 SECOND   SY017240
                                        *                           "PERIOD.  THE SYNC START TIME IS    SY017250
                                        *                           "THE VALUE OF THE COMPUTER REAL     SY017260
                                        *                           "TIME COUNTER AT THE START OF THE   SY017270
                                        *                           "FIRST TEN SECOND BURST.            SY017280
                                        *                                   "SET UP THIRD SYNC TASK .1 SECS *I017290
1108    80      02F4  0802               OMEGA     0,,SYNC3-OMEGA_TASK_TABLE/2 "AFTER THIS TASK          SY017300
1109    100     02F5  8470               FETM      7,,0              "CLEAR ALL SIN/COS INPUT REGIS-     SY017310
                                        *                           "TERS TO START SYNC DATA            SY017320
1110    130     02F6  F4570011           PTR       5,,COS_10_2       "COLLECTION                         SY017330
1111    136     02F8  9E62   (00E2)      CLA       0,,HX2000         "ILLUMINATE SYNC LAMP ON THE        %S017340
1112    148     02F9  E000C09F           MRG       0,0,C_I_STATUS_IMAGE "C/I PANEL                       SY017350
1113    152     02FB  FC091C1E           CLAM      0,,SYNC_DATA      "SET DATA BASE ADDRESS TO THE       %S017360
1114    162     02FD  F0071E7A           STA       0,,SYNC_BASE      "FIRST STORAGE AREA FOR FIRST 10    SY017370
1115    176     02FF  D510               BBK       1                 "SECONDS (200 DATA WORDS)           SY017380
                                        *                                                                   SY017390
                                        * THIRD SYNC TASK - DATA COLLECTION                                *H017400
```

```
                        * ENTERED EVERY .1 SEC UNTIL SYNC                                                *H017410
                        * IS COMPLETE                                                                    *H017420
                        *                                        "SET UP TO REENTER THIS TASK            *I017430
1116    70R  0300 0802  $3          OMEGA    0,,SYNC3-OMEGA_TASK_TABLE/2 "IN .1 SECOND                  SY017440
                        *                                        "READ BITE DISCRETE"                    *I017450
1117    78   0301 0250              SNS      PFG_COUNTDOWN_NO_GOOD   "FROM RECEIVER"                     SY017460
                        *                                        "IS THE PRECISION                       *I017470
1118    82   0302 D066  (0309)      BRE      $8                      "FREQUENCY GENERATOR OK?"           SY017480
1119     6R  0303 9E4F  (00CF)  $19  CLA      0,,PFG_COUNT            "FAILURE"                           SY017490
1120     8   0304 9401              ADDM     0,,1                                                        SY017500
1121    16   0305 704F  (00CF)      STA      0,,PFG_COUNT            "INCREMENT FAIL COUNT"              SY017510
                        *                                        "DO NOT ALLOW INTERRUPTS UNTIL          *I017520
1122     2R  0306 DF00          $9  LGC      INTERRUPT_INHIBIT   "AFTER SYSTEM INITIALIZATION           SY017530
1123     8   0307 04000166          BUC      BEGIN                   "RESTART SYSTEM"                    SY017540
1124    34R  0309 FC6C1E78      $8  FET      6,,SYNC_BASE-2          "READ CURRENT DATA COUNTER (0 TO    SY017550
                        *                                        "198 BY 2'S), FREQ COUNTER (0 TO        SY017560
                        *                                        "4 BY 2'S), AND BASE ADDRESS OF         SY017570
                        *                                        "DATA FOR THIS 10 SEC PERIOD            SY017580
1125    38   0308 FC69000C6         CLAM     6,,198                  MAX DATA COUNTER                    SY017590
1126    40   030D 9C44              CLAM     4,,4                    MAX FREQ COUNTER                    SY017600
1127    50   030E FD3A0011          CLAD     X3,,COS_10_2            "READ SIN/COS DATA PAIR INDEXED     %S017610
                        *                                        "BY FREQ AND SAVE IN DATA STORAGE       SY017620
1128    60   0310 7852              STAD     IX5,2                   "AREA INDEXED BY DATA COUNTER       SY017630
1129    64   0311 B800              SUBD     0,0                     "CLEAR SIN/COS REGISTERS TO BEGIN   %S017640
1130    76   0312 F9370011          STAD     X3,,COS_10_2            "NEXT .1 SEC DATA COLLECTION TIME   SY017650
                        *                                        "DATA COUNTER +2                        *I017660
1131    86   0314 FC5C0331          BXUD     5,,$4                   "IS DATA COLLECTION COMPLETE?       %R017670
                        *                                        10 SEC PERIOD COMPLETE                  SY017680
1132    10R  0316 D710              PRN      1                       "SAVE DATA BASE ADDRESS AND FREQ    SY017690
1133    20   0317 7807  (0087)      STAD     0,,SYNC_DATA_ADDRESS_AND_FREQUENCY                          SY017700
1134    24   0318 F8091C1E          COMM     0,,SYNC_DATA            "NUMBER FOR SYNC COMPUTATIONS       SY017710
                        *                                        "WAS THE DATA                           *2017720
1135    28   031A D012  (031D)      BNE      $5                      "SAVED IN THE SECOND SYNC STORAGE   SY017730
                        *                                        "AREA?                                  SY017740
1136     6R  0318 9679  (00F9)      ADD      0,,HD200                "SET NEW BASE ADDRESS TO THE        SY017750
1137    10   031C D001  (031E)      BUC      $6                      "SECOND STORAGE AREA                SY017760
1138     6R  031D 9279  (00F9)  $5  SUB      0,,HD200                "SET NEW BASE ADDRESS TO THE        SY017770
                        *                                        "FIRST STORAGE AREA                     SY017780
                        *                                        "INCREMENT TO                           *2017790
1139     8R  031E CC10  (031F)  $6  BXUD     1,,$7                   "NEXT FREQ - RESET TO 10.2 IF OLD   SY017800
                        *                                        "FREQ WAS 13.6                          SY017810
1140    16R  031F 8450          $7  FETM     5,,0                                                        % 017820
                        *                                        "CLEAR SIN/COS INPUT REGISTERS TO       %S017830
```

```
1141    46   0320 F4570011                PTR   5,,COS_10_2     "START THE FIRST .1 SEC PERIOD OF SY017840
1142    68   0322 F4371E7A                PTR   3,,SYNC_BASE    "THE NEXT 10 SEC INTERVAL         SY017850
1143    80   0324 868F   (008F)           FETD  0,,SYNC_N       "INCREMENT N = NUMBER OF SYNC     %S017860
1144    86   0325 965E   (000E)           ADD   0,,HX0200       "10 SEC PERIODS COMPLETED         SY017870
                                *                                "HAS THE SYNC                     %2017880
1145    90   0326 D072   (0329)           BND   $11             "PROCESS BEEN GOING ON FOR        %R017890
                                *                                "640 SECONDS?                     SY017900
1146    4R   0327 F4098200              ADDM  0,,X(8200)        "RESET N TO 1"                    SY017910
                                *                                "THIS WILL HAVE THE EFFECT OF     SY017920
                                *                                "THROWING AWAY ALL PREVIOUS DATA  SY017930
                                *                                "AND RESTARTING SYNC              SY017940
1147    8R   0329 700F   (008F)  $11     STA   0,,SYNC_N       "SAVE NEW N                       SY017950
1148    22   032A F80C1A80                FETD  0,,=DX(01FFFFFF) "COMPUTE 1/N SCALED B6 FOR      SY017960
1149   148   032C DC02                    DIVD  0,2             "SYNC COMPUTATIONS                SY017970
1150   158   032D 7805   (0085)           STAD  0,,SYNC_10VERN  "SET 10 SEC PERIOD COMPLETE MKR   %S017980
1151   160   032E 9C01                    CLAM  0,,X(1)         "THIS WILL SIGNAL THE SYNC COMP-  SY017990
                                *                                "UTATION PROGRAM THAT IT CAN      SY018000
                                *                                "START CALCULATIONS ON THE LAST   SY018010
                                *                                "10 SEC INTERVAL                  SY018020
1152   168   032F 7009   (0089)           STA   0,,TEN_SECOND_SYNC_PERIOD_COMPLETE_MARKER         SY018030
1153   188   0330 D540                    BBK   4                                                 SY018040
                                *                                                                SY018050
1154   10R   0331 F0571E7D        $4      STA   5,,SYNC_DATA_COUNTER "SAVE UPDATED DATA COUNTER   SY018060
1155    34   0333 D560                    BBK   6                                                 SY018070
                                *                                                                SY018080
```

```
                                        **                                                                  SY018090
                                        *           START OMEGA NAVIGATION                                  *H018100
                                        *                                                                   *H018110
                                        * THIS ROUTINE TRANSLATES THE TIME DETERMINED                       *H018120
                                        * BY THE SYNC PROCESS INTO THE TIME THAT THE                        *H018130
                                        * OMEGA NAVIGATION TASKS SHOULD BE PERFORMED                         *H018140
                                        *                                                                   SY018150
1156    8R   0334  861C  (009C)  START_OMEGA FET     0,,START_OMEGA_NOW "READ MARKER FROM SYNC              SY018160
                                        *                                "COMPUTATION PROGRAM               SY018170
1157    12   0335  D260  (0356)          BRE         $3                 "HAS SYNC JUST BEEN COMPLETED?     %R018180
1158    12R  0336  8688  (0088)          FETD        0,,START_SYNC_TIME "READ SYNC TIME"                   SY018190
                                        *                                "THIS TIME IS IN COMPUTER REAL     SY018200
                                        *                                "TIME AND REPRESENTS THE START     SY018210
                                        *                                "OF STATION A 10.2 BURST.  THIS    SY018220
                                        *                                "TIME IS LESS THAN THE CURRENT     SY018230
                                        *                                "VALUE OF TIME.                    SY018240
1159    22   0337  FC3A008C            CLAD        3,,TIME                                                %S018250
                                        *                                "COMPUTE DESIRED TIME OF STARTING  SY018260
                                        *                                "THE NON OMEGA TASKS JUST PRIOR    SY018270
                                        *                                "TO THE END OF STATION A 10.2      SY018280
                                        *                                "BURST                             SY018290
                                        *                                "= SYNC TIME + .775 SEC            SY018300
                                        *                                "= SYNC TIME + A BURST TIME (.9)   SY018310
                                        *                                "  - PART OF BURST NOT USED AT     SY018320
1160    32   0339  FC081A82            ADDD        0,,=D(220-65)       "  END (.1) - TIME BETWEEN START   SY018330
                                        *                                "  KALMAL AND END BURST (.005)     SY018340
                                        *                                "  - NUMBER OF NON OMEGA TASKS TO  SY018350
                                        *                                "  BE EXECUTED BEFORE KALMAN TIME  SY018360
                                        *                                "  (4 = .020)                      SY018370
1161    10R  0338  FC081A84  $1          ADDD        0,,=D2000           "NON OMEGA TASK START TIME         SY018380
                                        *                                "+ 10 SECONDS = NEXT POSSIBLE      SY018390
1162    14   033D  8803                 COMD        0,3                 "START TIME                        SY018400
                                        *                                "HAS THE NEXT                      *I018410
1163    18   033E  D844  (0338)          BLE         $1                   "POSSIBLE START TIME PASSED?      SY018420
1164    10R  033F  FC081A86              ADDD        0,,=D4              "NON OMEGA TASK START TIME +       SY018430
                                        *                                ".020 = TIME OF NEXT OMEGA TASK    SY018440
1165    20   0341  7817  (0097)          STAD        0,,OMEGA_TIME       "(KALMAN)                          SY018450
                                        * NOW DETERMINE WHEN TO START THE NEXT .1 SEC INTERVAL           SY018460
1166    30   0342  FC081A88              ADDD        0,,=D16             "FORM OMEGA TASK START TIME        %S018470
                                        *                                "+ .080 = NEXT NON OMEGA TASK      SY018480
                                        *                                "START TIME                        SY018490
1167    8R   0344  92ED  (00ED)  $2      SUBD        0,,=D20             "NEXT NON OMEGA TASK START TIME    SY018500
1168    12   0345  8803                 COMD        0,3                 "- .100  (.1 IS TIME               SY018510
```

```
                                        *                                   "INTERVAL BETWEEN STARTS)          SY018520
                                        *                                   "IS THIS START                     *I018530
1169        16          0346  0833  (0344)                 BRG     $2       "TIME STILL IN THE FUTURE?         SY018540
                                        *                                   "THIS TIME NOW REPRESENTS THE      SY018550
1170        10R         0347  7815  (0095)                 STAD    0,,OLD_NON_OMEGA_TASK_TIME                 SY018560
                                        *                                   "MOST RECENT POSSIBLE NON OMEGA    SY018570
                                        *                                   "START TIME                        SY018580
                                        *                                   "WRITE TIME IN OLD NON OMEGA TASK  SY018590
                                        *                                   "TIME - BECAUSE THE NON OMEGA      SY018600
                                        *                                   "TASKS ARE NOT COMPLETE FOR THIS   SY018610
                                        *                                   "INTERVAL THE NEXT INTERVAL WILL   SY018620
                                        *                                   "BE UPDATED FROM THE 'NEW' OLD     SY018630
                                        *                                   "TIME. THE NEXT INTERVAL MAY NOT   SY018640
                                        *                                   "BE EXACTLY .1 SEC.                SY018650
1171        14          0348  FC090765                    CLAM    0,,KALMAN_FILTER "SET NEXT OMEGA TASK = KALMAN  %S018660
1172        22          034A  7019  (0099)                STA     0,,OMEGA_TASK                              SY018670
1173        32          0348  F4182000                    FETM    1,X(2000)  "TURN SYNC LAMP ON C/I PANEL OFF  %S018680
1174        44          034D  E001009F                    MRG     0,1,C_I_STATUS_IMAGE                       SY018690
1175        52          034F  701C  (009C)                STA     0,,START_OMEGA_NOW "RESET MARKER FROM SYNC  %S018700
                                        *                                   "COMPUTATION PROGRAM               SY018710
                                        *                                   "100 MILLI SEC MONITOR SIGNAL      *I018720
1176        62          0350  F0170090                    STA     1,,KAL_STA_FLG  SET NON ZERO          11   018730
1177        70          0352  030C                        SET     PROGRAM_SEQUENCING  "FOR MALF INDICATOR    SY018740
1178        78  *       0353  F8001613                    BSV     CALC_TIME_CORRECTION                  11   018750
1179       102          0355  D560                        BBK     6           "EXIT"                         SY018760
                                        *                                                                      SY018770
1180        16R         0356  D520                $3      BBK     2           "EXIT"                         SY018780
                                        *                                                                      SY018790
```

```
                                        **                                                                      EB018800
                                        *                       END OF BURST                                    *H018810
                                        *                                                                       *H018820
                                        * THIS IS AN OMEGA TASK THAT IS EXECUTED AT THE CONCLUSION OF           *H018830
                                        * THE STATION BURST DATA COLLECTION PERIOD WHICH ENDS .1 SEC            *H018840
                                        * BEFORE THE ACTUAL STATION BURST ENDS.  THIS ROUTINE SELECTS           *H018850
                                        * THE PROPER ANTENNA / CALIBRATE SIGNALS FOR THE SLOT MEASURE-          *H018860
                                        * MENT AND COMPUTES THE PHASE AND PHASE VARIANCE OF THE STATION         *H018870
                                        * BURST.  IT EXITS DIRECTLY TO THE TRACKING FILTER PROGRAM.             *H018880
                                        *                                                                       *H018890
                                        *                                                                       EB018900
                                        *                                       "SET UP NEXT OMEGA TASK TO OCCUR *I018910
1181                                    END_OF_BURST;                                                           EB018920
1181    70R     0357  0803                        OMEGA     0,,START_SLOT-OMEGA_TASK_TABLE/2 ".15 SEC LATER EB018930
1182    78      0358  F4081F08                    FETM      0,,END_OF_BURST_DATA "READ SIN/COS OF THE 3 FREQEB018940
                                        *                                       "FROM DMA AND SAVE FOR COMPUTA- EB018950
1183    108     035A  F05C0011                    FET       5,,COS_10_2   "TIONS BEFORE ANOTHER DMA INPUT   EB018960
1184    136     035C  7656                        PTR       I5,6          "CAN OCCUR                        EB018970
                                        *                                       "USE STATION COUNTER TO          *S018980
1185    144     035D  8635   (0085)               FET       0,,STATION_COUNTER "SELECT ANTENNA / CALIBRATE  EB018990
                                        *                                       "SIGNALS FOR SLOT DATA AND OUTPUTEB019000
                                        *                                       "TO THE ANTENNA SWITCHING MATRIX EB019010
                                        *                                       "(THE STATION COUNTER IS A NUMBEREB019020
                                        *                                        "FROM 0 TO 7 THAT IDENTIFIES THEEB019030
                                        *                                        "STATION THAT JUST COMPLETED ITSEB019040
                                        *                                        "10.2 BURST)                   EB019050
1186    152     035E  F50A178D                    CLA       X0,,ANTENNA_NOISE_AND_CALIBRATE_CODES                 EB019060
1187    160     0360  C010                        FET       1,0           3 TIMES                           EB019070
1188    178     0361  F4270020                    PTR       2,,ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2               EB019080
                                        * STATION  -  SIGNAL DURING NEXT SLOT                                   *H019090
                                        * A (= 0)      TEST + 90     (CALIBRATE)                               *H019100
                                        * B (= 1)      LOOP A (NOISE / PHANTOM)                                *H019110
                                        * C (= 2)      - TEST        (CALIBRATE)                               *H019120
                                        * D (= 3)      LOOP A (NOISE / PHANTOM)                                *H019130
                                        * E (= 4)      TEST          (CALIBRATE)                               *H019140
                                        * F (= 5)      LOOP B (NOISE / PHANTOM)                                *H019150
                                        * G (= 6)      -(TEST + 90) (CALIBRATE)                                *H019160
                                        * H (= 7)      LOOP B (NOISE / PHANTOM)                                *H019170
1189    186     0363  8618   (0098)               FET       0,,NOISE_COMPUTED_MARKER                              % 019180
                                        *                                       "ARE THE FIRST                   *I019190
1190    190     0364  D011   (0366)               BNE       $30           "NOISE MEASUREMENTS AVAILABLE?    EB019200
                                        *                                       "EXIT"                           EB019210
                                        *                                       "DO NOT TAKE ANY BURST MEASURE-  EB019220
```

```
                                        *                                   "MENTS UNTIL NOISE DATA IS          E8019230
1191      14R     0365  D510                    BBK     1                   "AVAILABLE                          E8019240
1192       6R     0366  9E7B    (00F8)  $30     CLA     0,,CAL_R_ADD        "SET UP A 3 DOUBLE COUNTER TO       E8019250
1193       14     0367  8411                    FETM    1,,1                "CYCLE ON THE 3 FREQUENCIES         E8019260
1194       38     0368  8494                    FETM    9,,4                "SET UP A 2 SINGLE COUNTER TO       E8019270
1195       48     0369  FC6A1F17                CLAD    6,,BURST_TIME       "CYCLE ON THE COS AND SIN TERMS     E8019280
1196       58     0368  FC3A1A8A                CLAD    3,,=DF(1.0D28-13) "READ ACTUAL BURST TIME AND       E8019290
1197      184     036D  DC63                    DIVD    6,3                 "RESCALE TO SEC AT B1               E8019300
                                        *                                                                       E8019310
1198       6R     036E  FC854000        $4      RSL     8,,1                SINGLE INDEX                        E8019320
1199       14     0370  F58A0035                CLA     X8,,ANTENNA_SELECT_SAVE                             E8019330
                                        *                                   "COMPUTE POINTER TO PROPER PHAN-    E8019340
                                        *                                   "TOM CORRECTIONS FOR THIS FREQ      E8019350
                                        *                                   "BASED ON ANTENNA LOOP (A OR B)     E8019360
                                        *                                   "SELECTED FOR THIS STATION          E8019370
1200       16     0372  B400                    ADD     0,0                 8 OR 2                              E8019380
1201       20     0373  FC591FA4                CLAM    5,,Y_P-2                                            E8019390
1202       22     0375  B450                    ADD     5,0                 YP ADDR +6 OR 0                     E8019400
1203       2R     0376  A434            $1      CLA     3,4                 SAVE YB AFTER FIRST PASS            E8019410
1204        8     0377  A64D                    CLA     I4,13               READ BURST DATA AT B15              E8019420
1205       14     0378  A5C0                    CLA     X12,0               BIAS AT B14                         HH019430
1206       20     0379  6C06                    MPY     0,6                 DTB AT B1 = BIAS AT B15             HH019440
1207       22     037A  B040                    SUB     4,0                 SUBTRACT BIAS FROM BURST            HH019450
1208       28     037B  A5C6                    CLA     X12,6               SF  B14                             E8019460
1209       60     037C  D440                    DIV     4,0                 XB AT B1                            E8019470
                                        *                                   "COMPUTE YB OR XB FOR THIS FREQ     E8019480
                                        *                                   "YB = COS/AY - YP * DELTA T BURST   E8019490
                                        *                                   "       SCALED B1                   E8019500
                                        *                                   "XB = SIN/AX - XP * DELTA T BURST   E8019510
                                        *                                   "YB IS COMPUTED ON THE FIRST PASS   E8019520
                                        *                                   "AND XB ON THE SECOND               E8019530
1210       66     037D  A785                    CLA     IX8,5                                                   E8019540
1211       72     037E  6C06                    MPY     0,6                 YN * DTB                            E8019550
1212       74     037F  B400                    ADD     0,0                       B1                            E8019560
1213       2R     0380  B040            $8      SUB     4,0                 PHANTOM CORR. NOP FOR PCI.          E8019570
1214        4     0381  9453                    ADDM    5,,3                INC ADDR                            E8019580
1215        6     0382  9401                    ADDM    13,,1               INCREMENT DATA AND                  E8019590
1216        8     0383  94C1                    ADDM    12,,1               INC CALIB ADDR                      E8019600
1217       16     0384  C4AF    (0376)          BXU     10,,$1              "ARE YB AND XB COMPUTED?            *R019610
                                        *                                                                       E8019620
                                        *                                                                       E8019630
                                        *                 R0 = TEMP D                                           E8019640
                                        *                 R3 = Y(B) S                                           E8019650
```

```
                                                *                R4 = X(B) S                                                E8019660
                                                *                R6 = DELTA T(B) D                                          E8019670
                                                *                R8 = 3 COUNTER SINGLE OR DOUBLE                            E8019680
                                                *                R9 = END 3 COUNTER                                         E8019690
                                                *                RA = 2 COUNTER                                             E8019700
                                                *                RB = END 2 COUNTER                                         E8019710
                                                *                RC = ADDRESS OF CALIBRATE RESULTS                          E8019720
                                                *                RD = ADDRESS OF BURST DATA                                 E8019730
                                                *                                                                           E8019740
1218          10R   0385  D710                        PRN        1                                                          ES019750
1219          12    0386  A401                        CLA        0,1                                                        E8019760
1220          14    0387  9C10                        CLAM       1,,0                                                       E8019770
1221          16    0388  9C30                        CLAM       3,,0                                                       E8019780
1222          38    0389  F03C1787                    FET        3,,BURST_ADDRESSES                                         E8019790
1223          50    038B  C037                        FET        3,7              PLACE SIN INTO 2, COS INTO 0              E8019800
1224         588    038C  1800                        ATAN       0,0              "COMPUTE PHI = ATAN XB/YB                 E8019810
1225         598    038D  F1CC0035                    FET        X12,,ANTENNA_SELECT_SAVE                                   E8019820
1226         606    038F  E40000E4                    EXT        0,0,HX8000       0 OR 180                                  E8019830
1227         608    0391  B410                        ADD        1,0              "ADD 180 DEG TO PHI IF THIS               E8019840
                                                *                                  "STATION IS PICKED UP ON                  E8019850
1228         616    0392  D700                        PRN        0                "MINUS LOOP A OR B. USE BIT 16            E8019860
                                                *                                  "OF ANTENNA SELECT WORD TO DECIDE         E8019870
                                                *                                  "ADD THE 180 IF BIT 16 = 1                E8019880
                                                *                                  "                                         E8019890
1229         622    0393  B3C3                        SUB        IX12,3           "PHI M = PHI - PHI ZERO SCALED PI         E8019900
1230         638    0394  6866                        MPYD       6,6              Y**2   B2                                 E8019910
1231         654    0395  6888                        MPYD       8,8              "Q M = (YB**2 + XB**2)/DELTA TB           ES019920
1232         658    0396  BC86                        ADDD       8,6                                                        E8019930
1233         784    0397  DC8A                        DIVD       8,10             "      SCALED B1                          E8019940
1234         786    0398  A47C                        CLA        7,12                                                       E8019950
1235         788    0399  B4CC                        ADD        12,12            DOUBLE C                                  E8019960
1236         798    039A  78C5                        STAD       IX12,5           PHI_M                                     E8019970
1237         802    039B  AC08                        CLAD       0,8                                                        E8019980
1238          12R   039C  F9C70038          $66       STAD       X12,,Q_M         PROD INSP PUTS NOOP HERE                    019990
1239          14    039E  AC67                        CLS        6,7                                                        DP020000
1240          22    039F  F46B0085                    ADD        6,,STATION_COUNTER                                         DP020010
1241          26    03A1  D021   (03A3)               BGE        $67                                                        S 020020
1242           2R   03A2  9468                        ADDM       6,,8                                                       DP020030
1243           2R   03A3  A417              $67       CLA        1,7                                                        S 020040
1244           6    03A4  4418                        MPIM       1,,8             "SAVE QM FOR THIS STATION AND             E8020050
1245           8    03A5  B461                        ADD        6,1              "FREQUENCY FOR C/I DISPLAY                E8020060
1246          18    03A6  F1671ED3                    STA        X6,,Q_STORAGE    "                                         E8020070
1247          20R   03A8  F9C61F25          $68       MPYD       X12,,RAW_H       "RAW H = (RAW H)*(QM)    (FORM            E8020080
```

```
                                *                                "PRODUCT OF Q'S FOR BASE STATION EB020090
1248      32      03AA  F9C71F25        STAD      X12,,RAW_H     "SELECTION)                      EB020100
                                * START PHASE VARIANCE COMPUTATION                                *H020110
1249      38      03AC  A772            CLA       IX7,2                                           % 020120
1250      40      03AD  9C10            CLAM      1,,0                                            % 020130
1251      44      03AE  AC6A            CLAD      6,10           DTB                              % 020140
1252      48      03AF  8868            SUBD      6,8            DTB - QM B1                      % 020150
1253      52      03B0  D031   (03B2)    BRG       $7             "IS QM GREATER THAN DELTA TB?    EB020160
1254       4R     03B1  8866            SUBD      6,6            "PHASE VARIANCE WILL BE NEGATIVE EB020170
                                *                                "FORCE NUMERATOR TO ZERO         EB020180
1255       4R     03B2  8880      $7    SUBD      8,0            "FORM NUMERATOR OF VARIANCE      EB020190
1256      20      03B3  688A            MPYD      8,10           " = QT(DTB - QM) AT B4PI**2      EB020200
1257      36      03B4  6806            MPYD      0,6            "AND DENOMINATOR                 EB020210
                                *                                " = DTB(QM - QT) AT B2           EB020220
1258      56      03B5  F8061A8C        MPYD      0,,=DF(((1)/3.14159265)/3.1415926582) SCALE AT BEB020230
1259      60      03B7  8808            COMD      0,8            SEE IF DIVIDE WILL OVERFLOW      EB020240
                                *                                "WILL THE DIVIDE                 *2020250
1260      64      03B8  D052   (03B8)    BRL       $6             "OVERFLOW OR THE QUOTIENT BE     %R020260
                                *                                "NEGATIVE?                       EB020270
1261       6R     03B9  9E64   (00E4)    CLA       0,,HX8000      "SET PHASE VARIANCE NEGATIVE AS  EB020280
                                *                                "MARKER TO TRACKING FILTER       EB020290
1262      10      03BA  D002   (03BD)    BUC       $5             "INDICATING NO MEASUREMENT       EB020300
1263     126R     03BB  DC08      $6    DIVD      0,8            "COMPUTE PHASE VARIANCE          EB020310
1264     128      03BC  9401            ADDM      0,,1           "SIGMA SQ M = QT(DTB - QM)/      EB020320
                                *                                "    DTB(QM - QT) + (.005)**2    EB020330
                                *                                "  SCALED (2PI)**2 OR 1 SQ CYCLEEB020340
                                *                                                                 EB020350
                                *                                                                 EB020360
                                *                  R0 = PHI(M)D, SIGMA**2PHI(M)D                  EB020370
                                *                  R2 = ADDRESS OF Q(T)                           EB020380
                                *                  R3 = ADDRESS OF PHI(0)                         EB020390
                                *                  R4 = ADDRESS OF SIGMA**2PHI(M)                 EB020400
                                *                  R5 = ADDRESS OF PHI(M)                         EB020410
                                *                  R6 = Y(B) D                                    EB020420
                                *                  R8 = X(B) D                                    EB020430
                                *                  RA = DELTA T(B) D                              EB020440
                                *                  RC = 3 D COUNTER                               EB020450
                                *                  RD = END 3 COUNTER                             EB020460
                                *                                                                 EB020470
                                *                                                                 EB020480
1265     10R      03BD  78C4      $5    STAD      IX12,4          "SAVE PHASE VARIANCE"          EB020490
1266      24      03BE  D730            PRN       3                                              EB020500
                                *                                "HAVE ALL 3                      *1020510
```

```
1267    34    038F FC8C036E                8XUD      8,,$4      "FREQUENCIES BEEN PROCESSED?  %R020520
                * CONTINUE WITH TRACKING FILTER PROGRAM                                       #H020530
```

```
                                **                                                                  TF020540
                                *                    TRACKING FILTER                               TF020550
                                *                                                                  TF020560
                                *                    R0=ADDR OF SIGMA**2 PHI M                     TF020570
                                *                    R1=ADDR OF PHI M                              TF020580
                                *                    R2=Y(B) D                                     TF020590
                                *                    R4=X(B) D                                     TF020600
                                *                    R6=DELTA T(B) D                               TF020610
                                *                    R8=3D COUNTER                                 TF020620
                                *                    R9=END 3D COUNTER                             TF020630
                                *                    RA=TEMP D                                     TF020640
                                *                    RC=TEMP D                                     TF020650
                                *                                                                  TF020660
                                *                    TRACKING FILTER                               *H020670
                                *                                                                  *H020680
                                * THIS PROGRAM IS EXECUTED AT THE END OF EVERY STATION BURST.       *H020690
                                * IT SMOOTHES THE COMPUTED PHASE AND PROVIDES OUTPUTS TO KALMAN.    *H020700
                                *                                                                  *H020710
                                * FOR NOTATIONAL PURPOSES THE SYMBOLS LISTED BELOW WILL BE USED     *H020720
                                *                                                                  *H020730
                                * PB        = BURST PHASE MEASUREMENT                              *H020740
                                * SB        = BURST PHASE MEASUREMENT VARIANCE                     *H020750
                                *                                                                  TF020760
                                * P         = TRACKING FILTER PHASE ESTIMATE                       *H020770
                                * PR        = TRACKING FILTER PHASE RATE ESTIMATE                  *H020780
                                * PRDR      = PHASE RATE DUE TO CRAFT MOTION TOWARDS THE STATION   *H020790
                                * DTB       = DELTA T BURST                                        *H020800
                                * DT        = TIME BETWEEN TRACKING FILTER TIME UPDATES            *H020810
                                * S         = TRACKING FILTER PHASE ESTIMATE VARIANCE              *H020820
                                * SR        = TRACKING FILTER PHASE RATE ESTIMATE VARIANCE         *H020830
                                * SC        = CROSS CORRELATION OF PHASE AND PHASE RATE VARIANCE   *H020840
                                * C         = CYCLE                                                *H020850
                                *                                                                  TF020860
                                * N         = TRACKING FILTER N COUNTERS                           *H020870
                                * DTM       = TIME BETWEEN TRACKING FILTER MEASUREMENTS (10 SECONDS) *H020880
                                *                                                                  *H020890
1268                            TRACKING_FILTER;                                                   TF020900
1268     8R     03C1  8600 (0080)          FET     0,,RESET_TF   "READ THE 'RESET TF MARKER'      TF020910
1269    16      03C2  D700                 PRN     0                                              TF020920
                                *                                "SHOULD THE                    *1020930
1270    20      03C3  D01F (03D3)          BNE     $10           "TRACKING FILTERS BE RESET?      %R020940
1271    10R     03C4  F418002E             FETM    1,,OS*6-2                                      % 020950
1272    22      03C6  86E9 (00E9)          FETD    0,,=DF((1)/12)                                 % 020960
```

```
1273    12R   03C7  F9271E33          $11     STAD    X2,,SIGMA_SQ_PHI_PHI "OPEN S UP TO 1/12 C**2     TF020970
                                      *                       "                (ALL FILTERS)   TF020980
1274    20    03C9  CC23   (03C7)             BXUD    2,,$11                                    % 020990
1275    14R   03CA  F4380017                  FETM    3,,OS*3-1                                 TF021000
1276    22    03CC  F41A010F                  CLA     1,,HX00FF                                 TF021010
1277    12R   03CE  E1211DB8          $4      MRG     X2,1,SIGMA_SQ_N_COUNTER "SET N = 0  (ALL FILTERSTF021020
1278    20    03D0  C423   (03CE)             BXU     2,,$4                                     % 021030
1279    22R   03D1  D770                      PRN     7               "SET PAST NAV MODE = 16 TO FORCE TF021040
1280    30    03D2  701D   (009D)             STA     0,,PAST_NAV_MODE "AN APPARENT NAV MODE CHANGE    TF021050
1281     8R   03D3  7000   (0080)     $10     STA     0,,RESET_TF     "RESET THE 'RESET TF MARKER'     TF021060
1282    38    03D4  F05C16FB                  FET     5,,TF_SIGMA_SQ_DATA_ADDRESSES-2           TF021070
1283    52    03D6  F438002E                  FETM    3,,OS*6-2       "LOAD REGISTERS WITH ADDRESSES OFTF021080
1284    60    03D8  F4CA1F8E                  CLA     12,,NAV_MODE    "S, SR, SC AND N                 TF021090
1285    68    03DA  F0C8009D                  COM     12,,PAST_NAV_MODE "SET UP COUNTER TO CYCLE ALL   TF021100
                                      *                       "TRACKING FILTERS (3 PER STATION)TF021110
                                      *                       "HAS THE NAV MODE                *1021120
1286    72    03DC  D068   (03E5)             BRE     TF_TIME_UPDATE   "CHANGED SINCE LAST ENTRY?     %R021130
1287    10R   03DD  F0C7009D                  STA     12,,PAST_NAV_MODE "RESET VARIANCES ASSOCIATED WITF021140
                                      *                       "PHASE RATE SINCE VELOCITY CHANGETF021150
                                      *                       "MAY MAKE PREVIOUS ESTIMATES     TF021160
                                      *                       "INVALID                         TF021170
                                      *                       "SAVE NEW NAV MODE               TF021180
1288     4R   03DF  8800                  $1      SUBD    0,0                                       % 021190
1289    14    03E0  7872                      STAD    IX7,2           "OPEN SR UP TO (.003 C/SEC)**2   TF021200
1290    24    03E1  FC0A1A8E                  CLAD    0,,=DF(.17765D-3) "SET SC = 0        (ALL FILTERTF021210
1291    34    03E3  7862                      STAD    IX6,2           SIGMA**2 PHI DOT PHI DOT         TF021220
1292    42    03E4  CC26   (03DF)             BXUD    2,,$1                                     % 021230
                                      *                                                        TF021240
                                      *                                                        TF021250
                                      *       R0=R**2 D                                        TF021260
                                      *       R2=24D COUNTER                                   TF021270
                                      *       R3=END 24D COUNTER                               TF021280
                                      *       R4= -                                            TF021290
                                      *       R5= -                                            TF021300
                                      *       R6=ADDR OF SIGMA**2 PHI DOT PHI DOT              TF021310
                                      *       R7=ADDR OF SIGMA**2 PHI PHI DOT                  TF021320
                                      *       R8=ADDR OF SIGMA**2 PHI PHI                      TF021330
                                      *       R9=ADDR OF SIGMA**2 N COUNTER                    TF021340
                                      *       RA=ADDR OF SIGMA**2 PHI M                        TF021350
                                      *       RB=ADDR OF PHI M                                 TF021360
                                      *       RC=NAV MODE                                      TF021370
                                      *                                                        TF021380
                                      *                                                        TF021390
```

```
                        * TRACKING FILTER TIME UPDATE                                                    #H021400
                        * UPDATE ALL TRACKING FILTERS                                                    #H021410
                        * TO TIME OF END BURST                                                           #H021420
1293                    TF_TIME_UPDATE;                                                                  TF021430
1293    12R  03E5 8430                  FETM    3,,0                                                     TF021440
1294    20   03E6 ADF6                  CLAD    X15,6       "COMPUTE UPDATE DELTA T (DT)                 TF021450
1295    28   03E7 96EF   (00EF)         ADDD    0,,=DF(.2)  "DT = DTB + .4 SEC  SCALED PI                TF021460
1296    48   03E8 F8061A90              MPYD    0,,=DF((2)/3.14159265) DELTA TK SCALED PI                TF021470
1297    52   03EA AC80                  CLAD    8,0         DELTA TK                                     TF021480
1298     8R  03EB AFA6          $1      CLAD    IX10,6      SIGMA**2 PHI DOT PHI DOT                     TF021490
                        *                                  "TIME UPDATE S"                              TF021500
                        *                                  "S(NEW) = S + 2SCDT + SRDT**2                TF021510
                        *                                  "            SCALED 1 C**2                   TF021520
1299    24   03EC 68C8                  MPYD    0,8         DELTA TK                                     TF021530
1300    28   03ED AC20                  CLAD    2,0                                                      TF021540
1301    38   03EE F8044000              RSAD    0,,1        RESCALED PRODUCT TO(8+2)PI                   TF021550
1302    46   03F0 BFB6                  ADDD    IX11,6      SIGMA**2 PHI PHI DOT                         TF021560
1303    62   03F1 68C8                  MPYD    0,8         DELTA TK                                     TF021570
1304    70   03F2 BFC6                  ADDD    IX12,6      SIGMA**2 PHI PHI                             TF021580
1305    74   03F3 0076   (03FA)         BNO     $2          "DOES S(NEW) EXCEED 1 C**2?                  %R021590
1306     8R  03F4 9EF3   (00F3)         CLAD    0,,=DX(7FFFFFFF) "SET S(NEW) = 1 C**2                    TF021600
1307    18   03F5 78C6                  STAD    IX12,6      "SET SC(NEW) = SC/2                          TF021610
1308    26   03F6 AFB6                  CLAD    IX11,6      SIGMA**2 PHI PHI DOT SCALED 2PI              TF021620
1309    36   03F7 F8044000              RSAD    0,,1        ONE HALF OF SIGMA **2 PHI PHI DOTTF021630
1310    40   03F9 0003   (03FD)         BUC     $3                                                       TF021640
1311    10R  03FA 78C6          $2      STAD    IX12,6      "TIME UPDATE SC"                             TF021650
1312    18   03FB AFB6                  CLAD    IX11,6      "SC(NEW) = SC + SRDT                         TF021660
1313    22   03FC BC02                  ADDD    0,2         "         SCALED 1/2PI  C**2/SEC             TF021670
                        *                                                                                TF021680
1314    10R  03FD 78B6          $3      STAD    IX11,6                                                   TF021690
1315    18   03FE AFA6                  CLAD    IX10,6      "TIME UPDATE SR"                             TF021700
1316    28   03FF FC0B1A92              ADDD    0,,=DX(00000006) "SR(NEW) = SR + R**2                    TF021710
                        *                                  "    SCALED 1/2PI**2 C**2/SEC**2             TF021720
                        *                                  "    WHERE R = .000012 (C/SEC)**2TF021730
                        *                                   "DOES SR(NEW)                               #1021740
1317    32   0401 D075   (0407)         BNO     CP          "EXCEED (.225 C/SEC)**2?"                    %R021750
1318     8R  0402 AFB6                  CLAD    IX11,6      "SET SR(NEW) = (.225 C/SEC)**2               TF021760
1319    18   0403 F8044000              RSAD    0,,1        "SET SC(NEW) = SC/2                          TF021770
1320    28   0405 78B6                  STAD    IX11,6      SIGMA**2 PHI PHI DOT                         TF021780
1321    36   0406 9EF3   (00F3)         CLAD    0,,=DX(7FFFFFFF) SIGMA SQ PHI DOT PHI DOT MAX (2TF021790
                        *                                                                                TF021800
1322    10R  0407 78A6          CP      STAD    IX10,6      "SAVE NEW SR"                                TF021810
1323    18   0408 CD6E   (03EB)         BXUD    6,,TF_TIME_UPDATE$1 "ARE ALL FILTERS UPDATED?            %R021820
```

```
1324    22R     0409  D770                    PRN     7                                                 % 021830
                                *                                                                       TF021840
                                *                                                                       TF021850
                                *               R0=DELTA TK D                                           TF021860
                                *               R2=ADDR OF SIGMA**2 PHI DOT PHI DOT                     TF021870
                                *               R3=ADDR OF SIGMA**2 PHI PHI DOT                         TF021880
                                *               R4=ADDR OF SIGMA**2 PHI PHI                             TF021890
                                *               R5=ADDR OF SIGMA**2 N COUNTER                           TF021900
                                *               R6=ADDR OF SIGMA**2 PHI M                               TF021910
                                *               R7=ADDR OF PHI M                                        TF021920
                                *               R8=NAV MODE                                             TF021930
                                *               R9=TEMP                                                 TF021940
                                *               RA=X(B)D                                                TF021950
                                *               RC=DELTA T(B)D                                          TF021960
                                *                                                                       TF021970
                                * START TIME UPDATE OF PHASE ESTIMATE                                   *H021980
                                *                                                                       TF021990
1325    52      040A  F05C1701                  FET     5,,TF_PHI_DATA_ADDRESSES "LOAD REGISTERS WITH   TF022000
                                *                                               "ADDRESSES OF TEMP, STATION TF022010
                                *                                               "VECTOR, RIJ, PRDR, PR AND P TF022020
                                *                                               "SET UP COUNTER TO CYCLE EACH TF022030
1326    60      040C  841E                      FETM    1,,OS*2-2               "STATION                TF022040
1327    80      040D  8474                      FETM    7,,4                    "SET UP COUNTER FOR 3 FREQ TF022050
1328    10R     040E  C02C              $1      FET     2,12                    "START UPDATE FOR EACH STATION TF022060
                                *                                               "                       TF022070
                                *                                               "GET ADDRESSES OF TEMP, STATION TF022080
                                *                                               "VECTOR AND RIJ FOR MATRIX 3D TF022090
                                *                                               "FORM TEMP = S X RIJ TO GET *I022100
1329    18  *   040F  F80D1707                  BSV     MATRIX_3D               "SL2 = S DOT R2, SL3 = S DOT R3 TF022110
1330    20      0411  9486                      ADDM    11,6                    "INCREMENT STATION VECTOR ADDRESSTF022120
1331    28      0412  ADA4                      CLAD    X10,4                   "BY 6 FOR NEXT STATION  TF022130
1332    32      0413  AC40                      CLAD    4,0                     "                       TF022140
1333    40      0414  ADA2                      CLAD    X10,2                   "COMPUTE PRDR FOR THIS STATION TF022150
1334    44      0415  AC20                      CLAD    2,0                     "PRDR = -(V3*SL3 + V2*SL2)/ TF022160
1335    56      0416  C035                      FET     3,5                     "       (SL2**2 + SL3**2)**.5 TF022170
1336    70      0417  FA8400A3                  MPYDM   I8,,V3                  "    SCALED 1/4PI IN 13.6 C/SEC TF022180
1337    84      0419  FA6400A2                  MPYDM   I6,,V2                                          TF022190
1338    88      0418  BC86                      ADDD    8,6                                             TF022200
1339    98      041C  F884A4E0                  MPYDM   8,,F(((-2)*3.14159812)/.723D56-1) 13.6 RADIANS 8TF022210
1340    114     041E  6822                      MPYD    2,2             SL2**2                          TF022220
1341    130     041F  6800                      MPYD    0,0             SL3**2                          TF022230
1342    134     0420  BC02                      ADDD    0,2                                             TF022240
1343    580     0421  1000                      SQRT    0,0                                             TF022250
```

```
1344   706   0422  DC80                    DIVD   8,0                                          TF022260
1345   714   0423  F0C800C8                COM    12,,BASE                                     TF022270
                   *                                "IS THIS PRDR                              *1022280
1346   718   0425  D015   (0428)            BNE    $4              "FOR THE BASE STATION?"    %R022290
1347   42R   0426  F08C1F0D                FET    8,,PHI_DOT_DR_BASE-1 SAVE LAST 9 PHI DOT DR FOR TF022300
                   *                                "ADD THIS PRDR TO THE BOTTOM OF            TF022310
                   *                                "A NINE ELEMENT TABLE THAT KEEPS           TF022320
                   *                                "THE LAST NINE VALUES OF PRDR FORT         TF022330
                   *                                "THE BASE STATION.  THE PREVIOUS           TF022340
                   *                                "ENTRIES ARE MOVED UP IN THE               TF022350
                   *                                "TABLE AND THE OLDEST IS DELETED           TF022360
1348   48    0428  A5F3                    CLA    X15,,3          PHI DOT DR BASE            TF022370
1349   90    0429  F4871F0E                PTR    8,,PHI_DOT_DR_BASE    BASE  8-1 RAD/SEC/10SEC TF022380
1350   22R   042B  D770             $4     PRN    7               "FORM STATION NUMBER - BASE TF022390
1351   24    042C  A414                    CLA    1,4             "STATION NUMBER TO GET THE TIME TTF022400
1352   30    042D  F0154000                RSL    1,,1            "BETWEEN THE BASE STATION BURST TF022410
                   *                                "AND THIS STATION'S BURST                  TF022420
                   *                                "THIS NUMBER WILL BE USED TO FORMTF022430
                   *                                "PRDR OF THIS STATION NOW MINUS            TF022440
                   *                                "PRDR OF BASE AT TIME NOW - T              TF022450
                   *                                "                                          TF022460
                   *                                "IF THE BASE IS A LOWER STATION            TF022470
                   *                                "NUMBER THAN THIS STATION THE              TF022480
                   *                                "DIFFERENCE POINTS TO THE CORRECTTF022490
                   *                                "TERM IN THE PRDR(BASE) TABLE AS           TF022500
1353   38    042F  F01B00CC                SUB    1,,BASE+1       "THE ENTRY FOR TIME (NOW) HAS TF022510
                   *                                "ALREADY BEEN MADE                         TF022520
                   *                                 "IS THE BASE                              *2022530
1354   42    0431  D033   (0435)            BRG    $5              "STATION NUMBER LESS THAN THIS TF022540
                   *                                "STATION NUMBER?                           TF022550
1355   4R    0432  D061   (0434)            BRE    $10             "IS THIS THE BASE STATION?  TF022560
1356   2R    0433  9011                    SUBM   1,,1            "THE BASE STATION PRDR FOR TIME TF022570
                   *                                "(NOW) HAS NOT BEEN COMPUTED YET           TF022580
                   *                                "THE FIRST ENTRY IN THE TABLE IS           TF022590
                   *                                "FOR THE PREVIOUS BURST SO DECRE-          TF022600
                   *                                "MENT STATION - BASE NUMBER BY 1           TF022610
                   *                                "TO CORRECT FOR THIS                       TF022620
1357   2R    0434  9418             $10    ADDM   1,,8            "ADD 8 TO THE STATION - BASE TF022630
                   *                                "NUMBER TO PUT IT IN THE RANGE OFTF022640
                   *                                "1 TO 8 WHERE 8 = 10 SEC AND               TF022650
                   *                                "IMPLIES THIS IS THE BASE STATIONTF022660
                   *                                "IS THIS PHASE                             *1022670
1358   4R    0435  D0D2   (0438)   $5       BCF    $6              "DIFFERENCE NAVIGATION?    %R022680
```

```
1359    8R    0436  F1181F0E          SUB     X1,,PHI_DOT_OR_BASE "SUB ALWAYS PHASE DIFFERENCETF022690
                    *                         "                                             TF022700
                    *                         "FORM PRDR FOR THIS SET OF THREE              TF022710
                    *                         "TRACKING FILTERS (3 FREQ) WHERE              TF022720
                    *                         "PRDR = PRDR (THIS STATION)                   TF022730
                    *                         "       MINUS PRDR (BASE)                     TF022740
1360    8R    0438  7394          $6      STA     IX9,4       "SAVE PRDR FOR THIS SET OF THREE TF022750
                    *                         "TRACKING FILTERS (3 FREQ)                    TF022760
                    *                         "                                             TF022770
                    *                         "NOTE - ALL PRDR'S ARE COMPUTED               TF022780
                    *                         "       FOR THE 13.6 FREQ ONLY                TF022790
                    *                         "       AND CONVERTED TO THE                  TF022800
                    *                         "       OTHER FREQUECIES WHEN                 TF022810
                    *                         "       NEEDED                                TF022820
1361    26    0439  C06D                    FET     6,13                                      TF022830
1362    10R   043A  FD9A1768        $2      CLAD    X9,,TF_LAMBDA_CONSTANT_TABLE              TF022840
1363    26    043C  68C7                    MPYD    0,7         "TIME UPDATE PHI ESTIMATE (P) TF022850
                    *                         "                                             TF022860
                    *                         "P(NEW) = P + (PR + F*PRDR)*DT                TF022870
                    *                         "       SCALED 810 IN CYCLES                  TF022880
                    *                         "F = RATIO OF THIS FREQ TO 13.6               TF022890
1364    34    043D  BF39                    ADDD    IX3,9       PHI DOT ESTIMATE SCALED 8-1   TF022900
1365    50    043E  6805                    MPYD    0,5         DELTA TK SCALED PI            TF022910
1366    60    043F  4808                    RSAD    0,,12       RESCALED TO(8+11)PI           TF022920
1367    68    0440  BF49                    ADDD    IX4,9       PHI ESTIMATE(K-1)SCALED 8+11PITF022930
1368    78    0441  7849                    STAD    IX4,9       PHI ESTIMATE(K)SCALED 8+11PI  TF022940
                    *                         "HAS P FOR ALL                                *1022950
1369    86    0442  CC99    (043A)          BXUD    9,,$2       "THREE FREQUENCIES BEEN UPDATED? %R022960
1370    16R   0443  D740                    PRN     4                                         % 022970
1371    18    0444  94D6                    ADDM    13,,6         PHI EST ADD                 % 022980
1372    20    0445  94C6                    ADDM    12,,6         PHI DOT EST ADD             % 022990
1373    28    0446  8410                    FETM    1,,0                                      % 023000
1374    36    0447  CF8A    (040E)          BXUD    8,,$1       "HAVE ALL STATIONS BEEN UPDATED? %R023010
1375    24R   0448  D780                    PRN     8                                         % 023020
1376    48    0449  D760                    PRN     8                                         % 023030
                    *                                                                       TF023040
                    *                                                                       TF023050
                    *       R0=SIGMA**2 PHI DOT PHI DOT ADDR                                TF023060
                    *       R1=SIGMA**2 PHI PHI DOT ADDR                                    TF023070
                    *       R2=SIGMA**2 PHI PHI ADDR                                        TF023080
                    *       R3=SIGMA**2 N COUNTER ADDR                                      TF023090
                    *       R4=SIGMA**2 PHI M ADDR                                          TF023100
                    *       R5=PHI M ADDR                                                   TF023110
```

```
                                *                       R6=NAV MODE                                                     TF023120
                                *                       R7=TEMP                                                         TF023130
                                *                       R8=X(B)D                                                        TF023140
                                *                       RA=DELTA T(B)D                                                  TF023150
                                *                       RC=3D COUNTER                                                   TF023160
                                *                       RD=END 3D COUNTER                                               TF023170
                                *                                                                                       TF023180
                                * START TRACKING FILTER MEASUREMENT UPDATE                                              *H023190
                                * USE BURST PHASE AND VARIANCE TO UPDATE                                               *H023200
                                * THE TRACKING FILTERS OF THE THREE STATIONS                                           *H023210
                                * THAT JUST TRANSMITTED DURING THE LAST BURST                                         TF023220
                                *                                                                                       TF023230
1377    22R     044A  C08D      $3              FET     8,13                                                            % 023240
1378                            MEASUREMENT_UPDATE;                                                                     TF023250
1378     8R     0448  F44A0085                CLA     4,,STATION_COUNTER                                              TF023260
1379    10      044D  A42D                    CLA     2,13            SIG SQ M ADDRESS                                TF023270
1380    16      044E  A63F                    CLA     13,15           PHI M ADDRESS                                   TF023280
1381    20      044F  4442                    LSA     4,,1            "USE STATION COUNTER (= NUMBER                  TF023290
                                *                                      "OF STATION THAT JUST TRANSMITTED               TF023300
                                *                                      "10.2) AND FREQ NUMBER TO GET THE               TF023310
                                *                                      "NUMBER OF THE STATION THAT JUST                TF023320
1382    22      0450  B047                    SUB     4,7             "TRANSMITTED THIS FREQUENCY                     TF023330
1383    26      0451  D022    (0454)          BGE     $1                                                              % 023340
1384     4R     0452  F4490010                ADDM    4,,16                                                           TF023350
1385     2R     0454  A454            $1      CLA     5,4                                                             % 023360
1386     4      0455  984E                    COMM    4,,OS*2-2       OS = NO OF STATIONS                             TF023370
                                *                                      "IS THIS STATION                                *023380
1387    10      0456  04030512                BRG     $9              "IN THE LIST OF AVAILABLE"                      %R023390
                                *                                      "STATIONS?"                                     TF023400
1388     2R     0458  9874                    COMM    7,,4                                                            % 023410
1389     6      0459  D113    (046D)          BNE     $13             "IS THIS FREQUENCY 11.3?"                       %R023420
1390    10R     045A  FC0A1F29                CLAD    0,,RAW_H+4      "THE RAW H = Q(10.2)*Q(13.6)*                   TF023430
                                *                                      "          Q(11.3) SCALED B3                    TF023440
                                *                                      "FOR THE STATION THAT JUST                      TF023450
                                *                                      "TRANSMITTED 11.3 IS NOW                        TF023460
                                *                                      "AVAILABLE (RAW H IS COMPUTED IN                TF023470
                                *                                      "END BURST WITH Q)                              TF023480
1391    18      045C  F0480008                  COM     4,,BASE                                                         TF023490
                                *                                      "IS THIS RAW H                                  *1023500
1392    22      045E  D016    (0465)          BNE     $84             "FOR THE BASE STATION?"                         %R023510
1393     6R     045F  8400                    FETM    0,,0            "SET UP TO TURN SIGNAL LOSS LAMP                TF023520
1394    10      0460  F8190020                COMM    1,,X(0020)      "ON THE C/I PANEL OFF                           TF023530
1395    14      0462  D031    (0464)          BRG     $83             "IS H RAW GREATER THAN .0078?                   TF023540
```

```
1396    6R   0463  9E8C  (00DC)          CLA     0,,HX0080      "CHANGE SET UP TO TURN LAMP ON   TF023550
                                                                 "BECAUSE THE BASE STATION IS WEAKTF023560
1397    8R   0464  741F  (009F)  $83      PTR     0,,C_I_STATUS_IMAGE "SAVE STATE OF SIGNAL LOSS  TF023570
                                                                 "LAMP FOR C/I PROGRAM            TF023580
1398   10R   0465  F9481F78        $84     SUBD    X4,,H_BURST    "COMPUTE H BURST"                TF023590
1399   20    0467  F8040CCD                MPYDM   0,,F(.1)       "                                TF023600
1400   30    0469  FD481F78                ADDD    X4,,H_BURST    "H BURST(NEW) = H BURST          TF023610
1401   42    0468  F9471F78                STAD    X4,,H_BURST    "      + .1*(H RAW - H BURST)    TF023620
                                                                 "           SCALED B3            TF023630
1402    8R   046D  AF73        $13     CLAD    IX7,3          "READ BURST PHASE PB FOR THIS    TF023640
1403   16    046E  C011                FET     1,1            "STATION AND FREQUENCY           TF023650
                                                                 "IS THIS PHASE                   *1023660
1404   20    046F  D0D2  (0472)         BCF     $10            "DIFFERENCE NAVIGATION?"         %R023670
1405   10R   0470  F9981F1F        $15     SUBD    X9,,PHI_M_BASE "SUB ALWAYS PHASE DIFFERENCE     TF023680
                                                                 "                                TF023690
                                                                 "SUBTRACT LAST BURST PHASE FROM  TF023700
                                                                 "BASE STATION FOR THIS FREQ FROM TF023710
                                                                 "PB                              TF023720
1406   12R   0472  7F95        $10     PTRD    IX9,5          "SAVE NEW PB FOR THIS FILTER     TF023730
                                                                 "                                TF023740
1407   24    0473  CB72                FETD    IX7,2          "READ BURST PHASE VARIANCE SB FORTF023750
1408   32    0474  C011                FET     1,1            "THIS STATION AND FREQUENCY      TF023760
1409   34    0475  9401                ADDM    0,,1           "COMPUTE SB + (.005 C)**2        TF023770
                                                                 "NOTE - SB + (.005 C)**2 WILL BE TF023780
                                                                 "       A NEGATIVE NUMBER IF IT  TF023790
                                                                 "       EXCEEDS 1 C**2 WHICH IS  TF023800
                                                                 "       USED AS A MARKER INDICA- TF023810
                                                                 "       TING AN INVALID MEASURE- TF023820
                                                                 "       MENT                     TF023830
1410   38    0476  D053  (047A)         BRL     $11            "IS THIS A VALID MEASUREMENT?    %R023840
                                                                 "IS THIS PHASE                   *1023850
1411    4R   0477  D0D2  (047A)         BCF     $11            "DIFFERENCE NAVIGATION?"         %R023860
                                                                 "SUB ALWAYS PHASE DIFFERENCE     TF023870
1412   10R   0478  FD881F19                ADDD    X11,,SS_PHI_M_BASE "  TF023880
                                                                 "ADD LAST BURST PHASE VARIANCE   TF023890
                                                                 "FROM BASE STATION FOR THIS FREQ TF023900
                                                                 "TO SB                           TF023910
1413   12R   047A  7F86        $11     PTRD    IX11,6         "SAVE NEW SB FOR THIS FILTER     TF023920
1414   20    047B  F06800C8                COM     6,,BASE                                  TF023930
                                                                 "IS THIS STATION                 *1023940
1415   24    047D  D015  (0483)         BNE     $14            "THE BASE STATION?"              %R023950
1416   14R   047E  FD971F19                PTRD    X9,,SS_PHI_M_BASE                        TF023960
1417   26    0480  F9771F1F                STAD    X7,,PHI_M_BASE "SAVE PB AND SB OF THE BASE TF023970
```

```
                                                *
                                                *                                                "STATION FOR USE DURING THE NEXT TF023980
1418    30      0482  D001   (0484)             *               BUC     $12                      "10 SECONDS                              TF023990
1419    10R     0483  D710                      $14             PRN     1                        "ADJUST REGISTERS                        TF024000
1420    4R      0484  4443                      $12             MPIM    4,,3                     "DEVELOP POINTER TO DATA FOR             TF024010
1421    6       0485  B447                                      ADD     4,7                      "THIS TRACKING FILTER                    TF024020
1422    2R      0486  A464                      $101            CLA     6,4                                                               % 024030
1423    8       0487  9E32   (0082)                             CLA     0,,START_CNT             "INCREMENT TIME COUNTER USED IN          %S024040
1424    10      0488  9401                                      ADDM    0,,1                     "BASE STATION SELECTION                  TF024050
1425    18      0489  7032   (0082)                             STA     0,,START_CNT                                                      TF024060
1426    24      048A  9E33   (0083)                             CLA     0,,START_MKR             "READ THE TRACKING FILTER START          %S024070
                                                *                                                "MARKER WHICH IS SET TRUE BY THE         TF024080
                                                *                                                "BASE STATION SELECTION ROUTINE          TF024090
                                                *                                                "AFTER ENOUGH TIME HAS ELAPSED TOTF024100
                                                *                                                "COLLECT BASE STATION DATA SO            TF024110
                                                *                                                "THAT THE MEASUREMENTS ARE VALID         TF024120
                                                *                                                "IS THE TRACKING                         *1024130
1427    28      048B  D012   (048E)                             BNE     $21                      "FILTER START MARKER TRUE?"              TF024140
                                                *                                                "IS THIS PHASE                           *2024150
1428    6R      048C  040C0512                                  BCT     $9                       "DIFFERENCE TRACKING?"                   TF024160
                                                *                                                "(NO MEASUREMENT)                        TF024170
                                                * SUBMARINE ALWAYS PHASE DIFFERENCE                                                       *H024180
1429    8R      048E  AFD7                      $21             CLAD    IX13,7                   "READ SB FOR THIS FILTER                 TF024190
                                                *                                                "NEGATIVE SB IS A MARKER INDICA-         TF024200
                                                *                                                "TING NO MEASUREMENT                     TF024210
1430    14      048F  04050512                                  BRL     $9                       "IS THIS A VALID MEASUREMENT?            %R024220
                                                * UPDATE PHASE RATE ESTIMATE (PR)                                                         *H024230
1431    4R      0491  AC20                                      CLAD    2,0                      SIGMA SQ PHI M                           TF024240
                                                *                                                "COMPUTE THETA, SCDTM AND SB+S           TF024250
                                                *                                                "SCALED PI, 2C**2 AND 2C**2              TF024260
                                                *                                                "RESPECTIVELY FOR PR AND SAVE            TF024270
                                                *                                                "FOR USE IN UPDATING P                   TF024280
1432    12      0492  AF86                                      CLAD    IX11,6                   SIGMA SQ PHI PHI SCALED (2PI)**2         TF024290
                                                *                                                "WHERE THETA = PB - P +                  TF024300
                                                *                                                "     (PRDR*F + PR)*(0.425)              TF024310
                                                *                                                "THETA IS THE DIFFERENCE BETWEEN         TF024320
                                                *                                                "THE MEASURED AND ESTIMATED PHASE        TF024330
                                                *                                                "F = RATIO OF THIS FREQ TO 13.6          TF024340
1433    22      0493  F8044000                                  RSAD    0,,1                     SIGMA SQ PHI PHI SCALED(B+3)PI**2        TF024350
                                                *                                                "THE 0.425 IS AN AVERAGE VALUE           TF024360
                                                *                                                "EQUIVALENT TO 1/2 THE BURST TIME        TF024370
                                                *                                                "TO CORRECT THE ESTIMATED PHASE          TF024380
                                                *                                                "FROM THE END OF BURST TO THE            TF024390
                                                *                                                "MIDPOINT OF THE BURST                   TF024400
```

```
1434      32          0495  F8244000                    RSAD    2,,1            SIGMA SQ PHI M SCALED (B+3)PI**2 TF024410
1435      36          0497  BC20                        ADDD    2,0                                              TF024420
1436      44          0498  AFA6                        CLAD    IX10,6          SIGMA SQ PHI PHI DOT SCALED 2PI  TF024430
1437      64          0499  F8061A94                    MPYD    0,,=DF((10)/3.14159265B+2) DELTA TM SCALED 4PI   TF024440
1438      94          049B  F05C1701                    FET     5,,TF_PHI_DATA_ADDRESSES                         TF024450
1439     102          049D  AF83                        CLAD    IX11,3          PHI DOT DR SCALED B-1            TF024460
1440     122          049E  F9D61768                    MPYD    X13,,TF_LAMBDA_CONSTANT_TABLE                    TF024470
1441     130          04A0  BFC4                        ADDD    IX12,4          PHI DOT ESTIMATE SCALED B-1      TF024480
1442     150          04A1  F8061A96                    MPYD    0,,=DF((.425)/3.14159265B+1) K/2PI               TF024490
1443     154          04A3  ACA4                        CLAD    10,4            PHI AND PHI DOT ESTIMATE ADDR    TF024500
1444     158          04A4  AC40                        CLAD    4,0             SUM OF(PHI DOT AND PHI DOT DR) K TF024510
1445     166          04A5  AFBC                        CLAD    IX11,12         PHI ESTIMATED SCALED(B+11)PI     TF024520
1446     174          04A6  46E0    (00E0)              MPID    0,,HX0800       RESCALED TO PI                   TF024530
1447     178          04A7  8840                        SUBD    4,0             PHI ESTIMATED                    TF024540
1448     188          04A8  FDDA1EED                    CLAD    X13,,PHI_SUB_M                                   TF024550
1449     192          04AA  BC40                        ADDD    4,0             THETA SCALED PI                  TF024560
1450     208          04AB  C059                        FET     5,9                                              TF024570
1451     238          04AC  F4570085                    PTR     5,,TF_TEMP THETA,SIGMASQ PHI PHI DOT(DELTM),SUM  TF024580
1452     252          04AE  D730                        PRN     3          OF 1/2(SIGMASQ PHI M+PHI PHI)         TF024590
1453     256          04AF  B842                        SUBD    4,2             SIGMA SQ PHI PHI DOT(DELTA TM)   TF024600
                                                *                               "SET UP ARGUMENTS FOR L ALPHA    *S024610
                                                *                               "SUBROUTINE                      TF024620
                                                *                               "THETA              ARGUMENT 1   TF024630
                                                *                               "B = SCDTM          ARGUMENT 2   TF024640
                                                *                               "A = L3 = SB + S - SCDTM  ARG 3  TF024650
                                                *                               "COMPUTE ALPHA 2 SCALED PI       *I024660
1454     264    *     04B0  F80D0518                    BSV     L_ALPHA         "AND L2 SCALED 1                 TF024670
1455     284          04B2  F8261A98                    MPYD    2,,=DF((3.14159265B+1)/10) L2 SCALED PI/B-1      TF024680
1456     304          04B4  F8061A98                    MPYD    0,,=DF((3.14159265B+1)/10) ALPHA 2/DELTA TM SF BTF024690
1457     312          04B6  BF64                        ADDD    IX6,4           "UPDATE PR"                      TF024700
                                                *                               "                                TF024710
                                                *                               "PR(NEW) = PR + ALPHA 2/DTM      TF024720
1458     322          04B7  7864                        STAD    IX6,4           "          SCALED 1/4PI CYCLE/SECTF024730
1459     326          04B8  D021    (04BA)              BGE     $103                                             HH024740
1460      4R          04B9  A800                        CLSD    0,0                                              HH024750
1461      4R          04BA  F8094000            $103    COMM    0,,X(4000)      4 CEC/SEC LIMIT                  HH024760
1462      8           04BC  D052    (04BF)              BRL     $104                                             HH024770
1463      4R          04BD  B800                        SUBD    0,0                                              HH024780
1464     14           04BE  7B64                        STAD    IX6,4                                            HH024790
                                                *                                                                TF024800
                                                *                                                                TF024810
                                                *                 R0=PHI DOT ESTIMATE                            TF024820
                                                *                 R2=L2                                          TF024830
```

```
                                        *  R4=PHI DOT ESTIMATE ADDR                                    TF024840
                                        *  R5=PHI ESTIMATE ADDR                                        TF024850
                                        *  R6=DATA 24D COUNTER                                         TF024860
                                        *  R7=3D COUNTER                                               TF024870
                                        *  R8=END 3D COUNTER                                           TF024880
                                        *  R9=SIGMA SQ PHI DOT PHI DOT ADDR                            TF024890
                                        *  RA=SIGMA SQ PHI PHI DOT ADDR                                TF024900
                                        *  RB=SIGMA SQ PHI PHI ADDR                                    TF024910
                                        *  RC=SIGMA SQ N COUNTER ADDR                                  TF024920
                                        *  RD=SIGMA SQ PHI M ADDR                                      TF024930
                                        *                                                              TF024940
                                        *                                                              TF024950
1465      8R    048F  ABA6              $104    CLSD    IX10,6      -SIGMA SQ PHI DOT SCALED 2PI        HH024960
1466     24     04C0  6802                    MPYD    0,2         L2                                  TF024970
1467     32     04C1  BF96                    ADDD    IX9,6       SIGMA SQ PHI DOT PHI DOT SF B+1     TF024980
1468     62     04C2  F05C0085                FET     5,,TF_TEMP  "UPDATE SR"                         %S024990
1469     78     04C4  6848                    MPYD    4,8         "SR(NEW) = SR +(SB+S)(L2/DTM)**2    TF025000
1470     94     04C5  6848                    MPYD    4,8         "   -2(L2/DTM)SC SCALED 1/2PI**2    TF025010
1471     98     04C6  8C46                    ADDD    4,6         SIGMA SQ PHI DOT PHI DOT(K+1)       TF025020
                                        *                          "IS SR GREATER                      *1025030
1472    102     04C7  D072   (04CA)           BNC     $2          "THAN 1/2PI**2 (C/S)**2?"           %R025040
1473     10R    04C8  FC4A00F3                CLAD    4,,=DX(7FFFFFFF) "SR IS TOO BIG                 TF025050
                                        *                          "SET SR = 1/2PI**2                  TF025060
1474     4R     04CA  AC60              $2      CLAD    6,0         THETA                               TF025070
1475     18     04CB  D730                    PRN     3           RELEASE FOUR REGISTERS              TF025080
1476     28     04CC  7888                    STAD    IX11,8      "SAVE SR(NEW)"                      TF025090
1477     38     04CD  D710                    PRN     1           RELEASE TWO REGISTERS               TF025100
1478     54     04CE  C05D                    FET     5,13                                            TF025110
                                        *                          "SET UP ARGUMENTS FOR L ALPHA       *S025120
                                        *                          "SUBROUTINE                         TF025130
                                        *                          "THETA              ARGUMENT 1      TF025140
                                        *                          "B = S              ARGUMENT 2      TF025150
                                        *                          "A = SB             ARGUMENT 3      TF025160
1479     62     04CF  AFD5                    CLAD    IX13,5      SIGMA SQ PHI M SCALED(2PI)**2       TF025170
1480     66     04D0  AC40                    CLAD    4,0                                             TF025180
1481     74     04D1  AFC3                    CLAD    IX12,3      SIGMA SQ PHI PHI SCALED(2PI)**2     TF025190
1482     78     04D2  AC20                    CLAD    2,0                                             TF025200
1483     90     04D3  C035                    FET     3,5                                             TF025210
1484    120     04D4  F4570085                PTR     5,,TF_TEMP  SIGMA SQ PHI PHI,PHI M,PHI PHI      TF025220
1485    128     04D6  C015                    FET     1,5         THETA                               TF025230
                                        *                          "COMPUTE ALPHA 1 SCALED PI          *I025240
1486    136  *  04D7  F80D0518                BSV     L_ALPHA     "AND L1 SCALED 1                    TF025250
1487    146     04D9  F8040010                RSAD    0,,11       ALPHA 1 SCALED(B+11)PI              TF025260
```

```
1488   154    04DB  BFA9                  ADDD    IX10,9          "UPDATE P"                        TF025270
                                    *                             "                                 TF025280
                                    *                             "P(NEW) = P + ALPHA 1             TF025290
1489   164    04DC  78A9                  STAD    IX10,9          "       SCALED B10 CYCLES         TF025300
1490   168    04DD  AC42                  CLAD    4,2             L1                                TF025310
1491   178    04DE  F8444000              RSAD    4,,1            L1 SCALED B+1                     TF025320
1492   188    04E0  F8481A9A              SUBD    4,,=DF(.5)      (L1-1) SCALED B+1                 TF025330
1493   198    04E2  F9AA1E03              CLSD    X10,,SIGMA_SQ_PHI_PHI_DOT                         TF025340
1494   228    04E4  F05CC085              FET     5,,TF_TEMP      SIGMA SQ PHI PHI,PHI M,PHI PHI    TF025350
1495   244    04E6  6828                  MPYD    2,8             L1 SCALED B+0                     TF025360
1496   260    04E7  684C                  MPYD    4,12            L2 SCALED PI/B-1                  TF025370
1497   276    04E8  68C2                  MPYD    12,2            L1 SIGMA SQ PHI M                 TF025380
1498   292    04E9  6882                  MPYD    8,2                                               TF025390
1499   296    04EA  BC64                  ADDD    6,4             L2 SIGMA SQ PHI PHI               TF025400
1500   312    04EB  686A                  MPYD    6,10            L1-1                              TF025410
                                    *                             "COMPUTE SC"                      *S025420
                                    *                             "                                 TF025430
                                    *                             "SC(NEW) = (1-L1)(SC-(L2/DTM)S)   TF025440
                                    *                             "          + L1L2SB/DTM           TF025450
                                    *                             "     SCALED 1/2PI IN C**2/SEC    TF025460
1501   318    04EC  4C62                  LSAD    6,,1            "                                 TF025470
                                    *                             "COMPUTE FIRST TERM OF S          TF025480
                                    *                             "  = S(1-L1)**2                   TF025490
1502   322    04ED  BCC6                  ADDD    12,6            SIGMA SQ PHI PHI DOT(K+1)         TF025500
1503   338    04EE  680A                  MPYD    0,10            (L1-1) SCALED B+1                 TF025510
1504   354    04EF  68A0                  MPYD    10,0            (L1-1) SIGMA SQ PHI PHI           TF025520
1505   360    04F0  4CA4                  LSAD    10,,2                                             TF025530
                                    *                             "IS THE FIRST                     *1025540
1506   364    04F1  D071   (04F3)        BNC     $3              "TERM OF S GREATER THAN 1 C**2?   %R025550
1507    4R    04F2  D002   (04F5)        BUC     $4              "TOO BIG"                         TF025560
1508    4R    04F3  BCA8                  ADDD    10,8            "COMPUTE S"                       TF025570
                                    *                             "                                 TF025580
                                    *                             "S(NEW) = S(1-L1)**2 + SBL1**2    TF025590
1509    8     04F4  D072   (04F7)        BNC     $5              "IS S GREATER THAN 1 C**2?        %R025600
1510   10R    04F5  FCAA00F3        $4    CLAD    10,,=DX(7FFFFFFF) "SET S = 1 C**2                 TF025610
1511   26R    04F7  D790            $5    PRN     9               "SAVE S(NEW)"                     TF025620
1512   36     04F8  78B6                  STAD    IX11,6          SIGMA SQ PHI PHI SCALED (2PI)**2  TF025630
1513   40     04F9  AC02                  CLAD    0,2                                               TF025640
1514   50     04FA  78A6                  STAD    IX10,6          SIGMA SQ PHI PHI DOT SCALED 2PI   TF025650
1515   52     04FB  A446                  CLA     4,6               SAVE INDEX                      *TF025660
1516    8R    04FC  AFB6            $6    CLAD    IX11,6                                            % 025670
1517   12     04FD  AC10                  CLAD    1,0                                               TF025680
1518   18     04FE  F0644000              RSA     6,,1            DATA 24S COUNTER                  TF025690
```

```
1519   24   0500 A7C6                    CLA     IX12,6          N COUNTER                                  TF025700
1520   34   0501 F8181A9C                COMD    1,,=DF(.0009)   (.06PI)**2                              TF025710
                 * MEASUREMENT UPDATE IS NOW COMPLETE                                                     *H025720
                 * NOW CONSIDER IF VARIANCES ARE                                                          *H025730
                 * SUFFICIENTLY SMALL TO INDICATE                                                         *H025740
                 * GOOD TRACKING TO KALMAN                                                                *H025750
1521   38   0503 D038  (050F)            BRG     $7              "IS S LESS THAN (.003 C)**2?           %R025760
1522   12R  0504 CB94                    FETD    IX9,4           SR                                     % 025770
1523   22   0505 F8081A9E                COMD    0,,=DF(.09*.09D-4*3.1415926*3.1415926*2)               % 025780
1524   32   0507 D710                    PRN     1                                                      % 025790
1525   36   0508 D036  (050F)            BRG     $7              "IS SR LESS THAN (.0009 C/S)**2?       %R025800
1526   2R   0509 9401                    ADDM    0,,1            "TRACKING IS GOOD"                     TF025810
                 *                                               "INCREMENT N COUNTER BY 1              TF025820
                 *                                               "(WHEN N=3 KALMAN CAN TAKE DATA)       TF025830
1527   10   050A E41000D8                EXT     1,0,HX0008      CUT N OFF AT 7                         TF025840
1528   14   050C D064  (0511)            BRE     $8              "IS N LESS THAN 8?"                    TF025850
1529   2R   050D 9001                    SUBM    0,,1            "DECREMENT N BY 1 SO THAT IT WILL      TF025860
                 *                                               "NEVER EXCEED 7  THIS IS FOR THE       TF025870
1530   6    050E D002  (0511)            BUC     $8              "CONVENIENCE OF THE C/I PROGRAM        TF025880
1531   8R   050F E400010E        $7      EXT     0,0,HXFF00      "TRACKING IS POOR"                     TF025890
                 *                                               "SET N COUNTER = 0                     TF025900
1532   8R   0511 73C6            $8      STA     IX12,6          "SAVE THE N COUNTER"                   TF025910
                 *                                               "NOTE - THE 8 HIGH ORDER BITS OF       TF025920
                 *                                               "       THE N COUNTER WORDS ARE        TF025930
                 *                                               "       USED BY KALMAN TO COUNT        TF025940
                 *                                               "       THE NUMBER OF DUMPS            TF025950
                 *                                               "HAVE ALL 3"                           *2025960
1533   10R  0512 FC7C044B        $9      BXUD    7,,MEASUREMENT_UPDATE "MEASUREMENTS BEEN"              %R025970
                 *                                               "PROCESSED?                            TF025980
1534   22R  0514 F03C1F25                FET     3,,RAW_H        "MOVE RAW H(13.6) TO RAW H (11.3)      TF025990
                 *                                               "MOVE RAW H(10.2) TO RAW H (13.6)      TF026000
                 *                                               "SET RAW H(10.2) = 1                   TF026010
                 *                                               "RAW H(11.3) NOW CONTAINS Q(10.2)      TF026020
                 *                                               "*Q(13.6) FOR THE STATION THAT         TF026030
                 *                                               "WILL TRANSMIT 11.3 DURING THE         TF026040
                 *                                               "NEXT BURST.  RAW H(13.6) NOW          TF026050
                 *                                               "CONTAINS Q(10.2) FOR THE STATION      TF026060
                 *                                               "THAT WILL TRANSMIT 13.6 DURING        TF026070
                 *                                               "THE NEXT BURST.  END BURST WILL       TF026080
1535   34   0516 86F3  (00F3)            FETD    0,,=DX(7FFFFFFF) "COMPUTE NEW Q'S FOR EACH FREQ        TF026090
                 *                                               "AND MULTIPLY THEM BY THE              TF026100
                 *                                               "APPROPIATE RAW H.                     TF026110
1536   64   0517 FC471F25                PTRD    4,,RAW_H                                               TF026120
```

```
1537    100     0519  07E0          PRN        14    RELEASE FIFTEEN REGISTERS    TF026130
1538    134     051A  0580          88K        11                                 TF026140
```

```
                                **          TRACKING FILTER L ALPHA SUBR                                    TF026150
                                * CALLING SEQUENCE BSV L_ALPHA                                          TF026160
                                * ENTER WITH THETA SCALED PI IN R0,1                                     TF026170
                                *            B SCALED N IN R2,3                                         TF026180
                                *            A SCALED N IN R4,5                                         TF026190
                                * RETURN WITH ALPHA SCALED PI IN R0,1                                    TF026200
                                *            L SCALED B+0 IN R2,3                                       TF026210
                                * TWO REGISTERS PRUNED                                                   TF026220
                                *                          L ALPHA SUBROUTINE                           *H026230
                                *                                                                       *H026240
                                * THIS ROUTINE WILL ACCEPT 3 ARGUMENTS (THETA, B AND A)                  *H026250
                                * AND RETURN ALPHA AND L                                                *H026260
                                *                                                                       *H026270
                                *                                                                       TF026280
1539    434R    0518  1400      L_ALPHA   SINCOS   0,0      "SIN(ALPHA) = B * SIN(THETA)                TF026290
1540    450     051C  C057                FET     5,7      "COS(ALPHA) = A + B * COS(THETA)            TF026300
                                *                           "NUMERATOR OF L = (A * COS(THETA)           %S026310
                                *                           "   + B) * B                                TF026320
                                *                           "                                           TF026330
                                *                           "DENOMINATOR OF L =                         TF026340
                                *                           "(B * COS(THETA) + A)**2                    TF026350
                                *                           "+ (B * SIN(THETA))**2                      TF026360
1541    466     051D  68A8                MPYD    10,8     SIN THETA                                   TF026370
1542    482     051E  68C6                MPYD    12,6     COS THETA                                   TF026380
1543    492     051F  F8444000            RSAD    4,,1     1/2A                                        TF026390
1544    508     0521  6862                MPYD    6,2      B                                           TF026400
1545    518     0522  F8244000            RSAD    2,,1     1/2B                                        TF026410
1546    522     0524  BC64                ADDD    6,4      1/2A                                        TF026420
1547    526     0525  AC86                CLAD    8,6      1/2A+B COS THETA                            TF026430
1548    530     0526  AC4A                CLAD    4,10     B SIN THETA                                 TF026440
1549    546     0527  6866                MPYD    6,6      (B COS THETA+1/2A)**2                       TF026450
1550    562     0528  6844                MPYD    4,4      (B SIN THETA)**2                            TF026460
1551    566     0529  BC64                ADDD    6,4                                                  TF026470
1552    570     052A  BCC2                ADDD    12,2     1/2 B                                       TF026480
1553    586     052B  68C2                MPYD    12,2                                                 TF026490
                                *                           "COMPUTE ABSOLUTE VALUE OF                  *S026500
                                *                           "NUMERATOR                                  TF026510
1554    590     052C  D022    (052F)      BGE     $1                                                   % 026520
1555     4R     052D  A84C                CLSD    4,12     ABSOLUTE VALUE                              TF026530
1556     8      052E  D001    (0530)      BUC     $2                                                   % 026540
1557     4R     052F  AC4C          $1    CLAD    4,12                                                 % 026550
1558     4R     0530  8846          $2    COMD    4,6                                                  % 026560
1559     8      0531  D042    (0534)      BLE     $3       "WILL THE DIVIDE OVERFLOW?"                 %R026570
```

```
1560    126R    0532  DCC4                    DIVD    12,4    "L = NUMERATOR / ABSOLUTE NUMERA-TF026580
                                *                       "     TOR     (= +1 OR -1)          TF026590
                                                                                            TF026600
1561    130     0533  D001    (0535)          BUC     $4
1562    126R    0534  DCC6            $3      DIVD    12,6    "L = NUMERATOR / DENOMINATOR  TF026610
                                *               "               SCALED 1                    TF026620
1563     22R    0535  D770            $4      PRN     7       RELEASE EIGHT REGISTERS       TF026630
1564    560     0536  1800                    ATAN    0,0     "ALPHA = ATAN SIN/COS SCALED PI TF026640
1565    568     0537  D5F0                    88K     15                                    TF026650
```

```
                                        **                                                                  SS026660
                                        *                          START SLOT                               #H026670
                                        *                                                                   #H026680
                                        * THIS IS AN OMEGA TASK THAT IS EXECUTED AT THE START OF           #H026690
                                        * THE .1 SECOND SLOT DATA COLLECTION PERIOD.  THIS PROGRAM         #H026700
                                        * CLEARS THE 6 SIN/COS REGISTERS AND MONITORS FOR A                #H026710
                                        * PRECISION FREQUENCY GENERATOR FAILURE                            #H026720
                                        *                                                                   #H026730
                                        *                                    "SET UP NEXT OMEGA TASK TO OCCUR #I026740
1566                                    START_OF_SLOT;                                                      SS026750
1566    70R     0538  0804                      OMEGA    0,,END_SLOT-OMEGA_TASK_TABLE/2 ".1 SEC LATER      SS026760
                                        *                "READ THE PRECISION FREQUENCY                      #I026770
1567    78      0539  0250                      SNS      PFG_COUNTDOWN_NO_GOOD  "GENERATOR BITE SIGNAL      SS026780
1568    82      053A  D062  (053D)              BRE      $1           "IS THE PFG GOOD?"                    SS026790
                                        *                "FAILURE"                                          SS026800
                                        *                "GO TO SYNC$19 TO COUNT FAILURES                   SS026810
1569    6R      0538  04000303                  BUC      SYNC$19      "AND RESTART                          SS026820
1570    18R     053D  8460              $1      FETM     6,,0         "CLEAR SIN/COS REGISTERS TO STARTSS026830
1571    48      053E  F4570011                  PTR      5,,COS_10_2  "DATA COLLECTION                      SS026840
1572    58      0540  F4070047                  PTR      0,,MAG_TAPE_DATA+7 START NEW FRAME                 MT026850
                                        *                            START NEW MAGNETIC TAPE FRAME         SS026860
                                        *                            AND ENTER MAG TAPE PROGRAM IF         SS026870
1573    8R      0542  D5F0              PLOT16   28BK     15           RECORDER IS AVAILABLE "EXIT           SS026880
1573    4R      0543  D000                       FILL
```

```
                                        **                                                                  ES026890
                                        *                        END OF SLOT                                *H026900
                                        *                                                                   *H026910
                                        * THIS IS AN OMEGA TASK THAT IS EXECUTED AT THE CONCLUSION OF       *H026920
                                        * THE SLOT .1 SECOND DATA COLLECTION PERIOD WHICH SHOULD BE         *H026930
                                        * THE EXACT CENTER OF THE SLOT.  THIS ROUTINE PERFORMS ANTENNA      *H026940
                                        * SELECT FOR THE STATION BURSTS, COMPUTES SCALE FACTORS AND         *H026950
                                        * MAKES NOISE AND PHANTOM MEASUREMENTS.                             *H026960
                                        *                                                                   *H026970
1574    12R   0544  86A8  (00A8)  END_OF_SLOT FETD    0,,TIME_INC     "CORRECT TIME FOR OSCILLATOR        ES026980
1575    16    0545  BC02              ADDD    0,2                     "DRIFT AS CALIBRATED BY KALMAN      ES026990
1576    28    0546  7C3C  (008C)      PTRD    0,,TIME                 "TIME = TIME + TIME INCREMENT       ES027000
1577    36    0547  8410              FETM    1,,0                    "TIME INCREMENT = 0                 ES027010
                                        *                             "TIME INCREMENT WILL CONTAIN        ES027020
                                        *                             "+ OR - 5 MILLISEC WHENEVER THE     ES027030
                                        *                             "INTEGRAL OF T ZERO DOT SUMS TO 5   ES027040
1578    48    0548  7C28  (00A8)      PTRD    0,,TIME_INC             "MILLISEC (PERFORMED IN KALMAN)     ES027050
                                        *                             "SET UP NEXT OMEGA TASK TO OCCUR    *I027060
1579    118   0549  0805              OMEGA   0,,START_BURST-OMEGA_TASK_TABLE/2 ".15 SEC LATER    ES027070
                                        * NOTE - THE NEXT TASK WILL OCCUR .145                              *H027080
                                        *        OR .155 SEC LATER WHENEVER                                 *H027090
                                        *        THERE IS A TIME CORRECTION                                 *H027100
1580    152   054A  FC6C0011            FET     6,,COS_10_2     READ OMEGA DATA AND GET 1 REGSTER   ES027110
                                        *                             "READ SLOT SIN/COS DATA BEFORE      ES027120
                                        *                             "NEXT DMA UPDATE                    ES027130
1581    160   054C  8412                FETM    1,,2                    "SET UP 3 COUNTER TO CYCLE          ES027140
                                        *                             "ANTENNA SELECT FOR 3 FREQ          ES027150
1582    178   054D  F02C0083            FET     2,,STATION_COUNTER-2 READ K AND GET 2 REGISTERS ES027160
1583    2R    054F  A402        $3      CLA     0,2             STATION NUMBER                      ES027170
1584    4     0550  9401              ADDM    0,,1            INCREMET STATION COUNTER TO         ES027180
1585    6     0551  9808              COMM    0,,8            NEXT STATION                        ES027190
                                        *                             "USE STATION COUNTER AND FREQ TO    ES027200
                                        *                             "DETERMINE NEXT STATION TO          ES027210
                                        *                             "TRANSMIT THIS FREQ                 ES027220
1586    10    0552  D011  (0554)      BNE     $11                                                 % 027230
1587    2R    0553  9C00              CLAM    0,,0                                                ES027240
1588    2R    0554  8003        $11   SUB     0,3              GET K-J MOD 8                      % 027250
1589    6     0555  D021  (0557)      BGE     $1                                                  % 027260
1590    2R    0556  9408              ADDM    0,,8                PER STATION IN TABLE           ES027270
1591    4R    0557  4406        $1    MPIM    0,,6                                                % 027280
1592    10    0558  967E  (00FE)      ADD     0,,SV_ADD                                           ES027290
1593    18    0559  F4081F6F          FETM    0,,R21                                              ES027300
                                        *                             "COMPUTE RELATIVE BEARING FROM      *I027310
```

```
1594    26  *   055B  F80D1605                  BSV     BEARING         "R3 AXIS TO STATION (CW)            ES027320
                                                *                       "BEARING FROM +A LOOP TO STATION    ES027330
1595    32      055D  9240   (00C0)             SUB     0,,THETA_P      "= REL BEARING - THETA P - PSI A    ES027340
1596    38      055E  9242   (00C2)             SUB     0,,PSI_A        "  - 180 DEG                        ES027350
                                                *                       "ADD 45 SO THAT 45 WILL BE MID-     ES027360
                                                *                       "POINT OF QUADRANT IN WHICH THE     ES027370
                                                *                       "+A LOOP IS SELECTED                ES027380
1597    42      055F  F409A000                  ADDM    0,,X(A000)      45 + 180                            ES027390
                                                *                       "READ STATE OF THE ANTENNA"         *I027400
1598    52      0561  F00C1F8C                  FET     0,,FLOATER      "MARKER"                            ES027410
1599    60      0563  D700                      PRN     0                                                   ES027420
1600    64      0564  D014   (0569)             BNE     $52             "IS THE LOOP ANTENNA IN USE NOW?    %R027430
                                                *                       "LOOP"                              ES027440
1601     6R     0565  5002                      RSL     0,,14           "USE THE 180 AND 90 DEG BITS OF     ES027450
                                                *                       "THE BEARING TO DEFINE THE QUAD-    ES027460
                                                *                       "RANT FOR ANTENNA SELECT            ES027470
                                                *                       "  0 -  90 = + A                    ES027480
                                                *                       " 90 - 180 = + B                    ES027490
                                                *                       "180 - 270 = - A                    ES027500
                                                *                       "270 - 360 = - B                    ES027510
1602    14      0566  F50A1762                  CLA     XO,,ANTENNA_SELECT_TABLE                            ES027520
1603    18      0568  D004   (056D)             BUC     $2                                                  ES027530
1604     6R     0569  9662   (00E2)   $52       ADD     0,,HX2000       "FLOATER"                           ES027540
1605    12      056A  5001                      RSL     0,,15           "ADD 45 TO THE BEARING SO THAT      ES027550
                                                *                       "90 WILL BE THE MIDPOINT OF THE     ES027560
                                                *                       "SEMICIRCLE IN WHICH +A IS USED     ES027570
                                                *                       "USE THE 180 DEG BIT TO DEFINE      ES027580
                                                *                       "THE SEMICIRCLE FOR ANTENNA USE     ES027590
                                                *                       "  0 - 180 = +A                     ES027600
                                                *                       "180 - 360 = -A                     ES027610
1606    20      056B  F50A1766                  CLA     XO,,FLOATER_SELECT_TABLE                            ES027620
1607    10R     056D  F1470020           $2     STA     X4,,ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2            ES027630
                                                *                       "OUTPUT ANTENNA CHOICE FOR THIS     ES027640
                                                *                       "FREQ TO ANTENNA SWITCHING MATRIX   ES027650
                                                * NOTE - WHENEVER -A OR -B IS SELECTED                      #H027660
                                                *        THE MATRIX IS SET TO +A OR +B                      #H027670
                                                *        AND A MARKER IS SET FOR THE                        #H027680
                                                *        END BURST ROUTINE TO ADD 180                       #H027690
                                                *        DEG TO THE MEASURED PHASE                          #H027700
1608    20      056F  F5470035                  PTR     X4,,ANTENNA_SELECT_SAVE "SAVE MARKER FOR END BURST  ES027710
                                                *                       "INDICATING + OR - LOOP CHOICE      ES027720
1609    28      0571  C633   (054F)             BXU     3,,$3           "HAVE ALL 3 FREQ BEEN PROCESSED?    %R027730
1610    16R     0572  D740                      PRN     4                                                   % 027740
```

```
                                        *                                                                   ES027750
                                        *                                                                   ES027760
1611        8R      0573  F46A0085      $4        CLA     6,,STATION_COUNTER                              ES027770
                                        *                         "USE LSB OF STATION COUNTER TO            ES027780
                                        *                         "DETERMINE IF THIS IS A CALIBRATEE       ES027790
                                        *                         "OR NOISE MEASUREMENT SLOT                ES027800
1612        16      0575  E46600D5              EXT     6,6,HX0001  "DO CALIBRATE FOLLOWING A,C,E,G          ES027810
1613        22      0577  040105EF              BNE     NOT_CALIB   "IS THIS A NOISE SLOT?"                  ES027820
1614        8R      0579  F46A0085              CLA     6,,STATION_COUNTER "SAVE THE SLOT SIN/COS DATA       ES027830
                                        *                         "USE STATION COUNTER (=0,2,4,6)           ES027840
                                        *                         "TIMES 3 AS A POINTER TO SAVE THEE       ES027850
                                        *                         "6 PIECES OF DATA AT EACH SLOT            ES027860
                                        *                         "THE DATA IS A Y AND X (COS/SIN)          ES027870
                                        *                         "FOR EACH FREQ                            ES027880
                                        *                         "1ST SET = C3 (TEST +90)                  ES027890
                                        *                         "2ND SET = C2 (-TEST)                     ES027900
                                        *                         "3RD SET = C1 (TEST)                      ES027910
1615        12      057B  4463                    MPIM    6,,3        "4TH SET = C4 (-(TEST + 90)           ES027920
                                        *                          ALSO SAVE ALL 4 SETS IN THE C4           ES027930
                                        *                          AREA FOR MAGNETIC TAPE                   ES027940
1616        16      057C  F4691EF6                ADDM    6,,CALIBRATE_DATA                               ES027950
1617        46      057E  F4571F08                PTR     5,,CALIBRATE_DATA+18                            ES027960
1618        76      0580  F05C1F08                FET     5,,CALIBRATE_DATA+18                            ES027970
1619        104     0582  7656                    PTR     I5,6        SAVE CALIBRATE DATA                 ES027980
1620        108     0583  F8091F08                COMM    0,,CALIBRATE_DATA+18                            ES027990
                                        *                         "IS THIS THE 4TH                          *2028000
1621        114     0585  040105E4              BNE     NOT_FOURTH_ITERATION  "SET OF DATA IN A 10 SEC      *R028010
                                        *                         "PERIOD?"                                 ES028020
1622        6R      0587  9E7B    (00F8)        CLA     0,,CAL_R_ADD                                        ES028030
1623        18      0588  86EF    (00EF)        FETD    0,,=DF(.18+1)  DELTA T CALIBRATE 8-1                ES028040
1624        26      0589  8415                  FETM    1,,5        "SET UP 6 COUNTER TO PROCESS THE        ES028050
                                        *                         "6 PIECES OF DATA                         ES028060
1625        64      058A  F07C177D              FET     7,,CALIBRATE_DATA_ADDRESSES-4 AND GET 4 REGISTEREES028070
1626        2R      058C  9C10        $7        CLAM    1,,0        "COMPUTE BIAS"                          ES028080
1627        8       058D  A786                  CLA     IX8,6       "BIAS = (C1 + C2 + C3 + C4)/.1          ES028090
1628        14      058E  B785                  ADD     IX8,5       X OR Y C2                               ES028100
1629        20      058F  B784                  ADD     IX8,4       X OR Y C3                               ES028110
1630        26      0590  B787                  ADD     IX8,7       X OR Y C4                               ES028120
1631        152     0591  DC0A                  DIVD    0,10        8 AT B14                                ES028130
1632        158     0592  B1C0                  SUB     X12,0       NEW-OLD                                 HH028140
1633        164     0593  F0040666              MPYM    0,,F(.05)   200 SECOND TIME CONSTANT FILT           HH028150
1634        170     0595  B5C0                  ADD     X12,0       OLD+(NEW-OLD)*.05                       HH028160
1635        178     0596  71C0                  STA     X12,0                                               HH028170
```

```
1636   182        0597 D021  (0599)          BGE    $12                                    % 028180
1637    2R        0598 A000                  CLS    0,0        "GET ABSOLUTE VALUE OF BIAS ES028190
1638    4R        0599 F80901F4      $12     COMM   0,,F(2508-14) SLOW CORRELATOR         HH028200
1639    8         059B D053  (059F)          BRL    $10        "IS BIAS LESS THAN 250 COUNTS/SECES028210
1640    2R        059C 9C01                  CLAM   0,,1                                   % 028220
                                    *                          "INDICATE RECEIVER MALF FOR THIS *I028230
1641   10  *      059D F80D05E5              BSV    REC_ERROR  "FREQ AND TURN ON MALF LAMP ES028240
                                    * NOTE - BIAS NOT USED IN SYSTEM EQUATIONS             *H028250
1642    2R        059F 9C10          $10     CLAM   1,,0       "COMPUTE SCALE FACTOR       ES028260
1643    8         05A0 A786                  CLA    IX8,6      "SF = .5(C1 - C2)**2        ES028270
1644   14         05A1 B385                  SUB    IX8,5      "     + (C3 - C4)**2)**.5/.1ES028280
1645   30         05A2 6800                  MPYD   0,0        "SAVE SF FOR NOISE, BURST AND ES028290
1646   34         05A3 AC20                  CLAD   2,0        "PHANTOM                    ES028300
1647   36         05A4 9C10                  CLAM   1,,0       CLEAR                       ES028310
1648   42         05A5 A784                  CLA    IX8,4      X OR Y C3                   ES028320
1649   48         05A6 B387                  SUB    IX8,7      X OR Y C4                   ES028330
1650   64         05A7 6800                  MPYD   0,0        SQUARE                      ES028340
1651   68         05A8 BC02                  ADDD   0,2        SUM                         ES028350
1652  514         05A9 1000                  SQRT   0,0        A*DT AT B14                 ES028360
1653  640         05AA DC0A                  DIVD   0,10                                   ES028370
1654  644         05AB BC00                  ADDD   0,0        SF AT B14                   ES028380
1655  652         05AC 71C6                  STA    X12,6                                  ES028390
1656  656         05AD F0090C80              SUBM   0,,F(1600B-14) "FORM ABSOLUTE(SF-NOMINAL SF) HH028400
1657  660         05AF D021  (05B1)          BGE    $20                                    % 028410
1658   2R         05B0 A000                  CLS    0,0        " NOMINAL SF = 1600 COUNTS/SEC ES028420
1659   4R         05B1 F80903E8      $20     COMM   0,,F(500B-14)                          HH028430
                                    *                          "IS THE SF"                 *2028440
1660   8          05B3 D057  (05B8)          BRL    $80        "DEVIATION LESS THAN        HH028450
1661   8R         05B4 F58A1C18              CLA    X8,,CALIBRATE_FAIL_COUNT               HH028460
1662  10          05B6 9805                  COMM   0,,5                                   HH028470
1663  14          05B7 D055  (05BD)          BRL    $81                                    HH028480
                                    *                          "500 COUNTS/SEC?            ES028490
1664   6R         05B8 9E5D  (000D)          CLA    0,,HX0100                              % 028500
                                    *                          "INDICATE RECEIVER MALF FOR THIS *I028510
1665  14  *      05B9 F80D05E5              BSV    REC_ERROR  "FREQ AND TURN ON MALF LAMP ES028520
1666   2R         05B8 8000          $80     SUB    0,0                                    HH028530
1667   6          05BC D001  (05BE)          BUC    $82                                    HH028540
1668   2R         05BD 9401          $81     ADDM   0,,1                                   HH028550
1669  10R         05BE F1871C18      $82     STA    X8,,CALIBRATE_FAIL_COUNT               HH028560
1670   2R         05C0 94C1          $21     ADDM   12,,1      "INCREMENT POINTER"         ES028570
                                    *                          "HAVE ALL 6 SETS            *I028580
1671  10          05C1 C786  (05BC)          BXU    8,,$7      "OF DATA BEEN PROCESSED?"   %R028590
1672   2R         05C2 9C92                  CLAM   9,,2       "SET UP 3 COUNTER TO COMPUTE ES028600
```


```
1673      4   05C3  9CA0                    CLAM    10,,0          "PHI ZERO FOR EACH FREQ          ES028610
1674      6   05C4  9C10                    CLAM    1,,0                                            ES028620
1675     6R   05C5  A7A7              $8    CLA     IX10,7         "COMPUTE PHI ZERO                ES028630
1676     12   05C6  B3A4                    SUB     IX10,4         "= ATAN (YC4-YC3+XC1-XC2) /      ES028640
1677     14   05C7  94A1                    ADDM    10,,1          "       (XC3-XC4+YC1-YC2)        ES028650
1678     20   05C8  B7A6                    ADD     IX10,6         "+ PHI ZERO C (= SUBMARINE       ES028660
                                            *                      "              COUPLER SHIFT)    ES028670
1679     26   05C9  B3A5                    SUB     IX10,5         "  + PHI ZERO LOOP OR FLOATER    ES028680
1680     30   05CA  AC20                    CLAD    2,0            "                                ES028690
1681     36   05CB  A7A4                    CLA     IX10,4         "NOTE - PHI ZERO NOT REQUIRED FORES028700
1682     42   05CC  B3A7                    SUB     IX10,7         "       PHASE DIFFERENCE TRACKINGES028710
1683     44   05CD  90A1                    SUBM    10,,1          DECREMENT INDEX                  ES028720
1684     50   05CE  B7A6                    ADD     IX10,6         YC1                              ES028730
1685     56   05CF  B3A5                    SUB     IX10,5         YC2                              ES028740
1686     58   05D0  94A2                    ADDM    10,,2          INCREMENT ADDRESS                ES028750
1687    596   05D1  1800                    ATAN    0,0                                             ES028760
1688    604   05D2  F56817C8                ADD     X6,,PHI_ZERO_0                                  ES028770
                                            *                      "READ STATE OF THE ANTENNA       *I028780
1689    614   05D4  F00C1F8C                FET     0,,FLOATER     "MARKER"                         ES028790
1690    622   05D6  D700                    PRN     0                                               ES028800
1691    626   05D7  D063    (05DB)          BRE     $37            "IS THE LOOP ANTENNA IN USE?     ES028810
1692     8R   05D8  F56817CE                ADD     X6,,PHI_ZERO_FLOATER "USE PHI ZERO FLOATER      ES028820
1693     12   05DA  D002    (05DD)          BUC     $38                                             ES028830
1694     8R   05DB  F56817D1        $37     ADD     X6,,PHI_ZERO_LOOP "USE PHI ZERO LOOP (AND ACU144ES028840
                                            *                      "              COUPLER SHIFT)ES028850
1695    10R   05DD  F1671EF3        $38     STA     X6,,PHI_ZERO   "SAVE PHI ZERO (IN CASE USING    ES028860
                                            *                      "              RHO-RHO NAV)      ES028870
1696     18   05DF  8410                    FETM    1,,0           RESTORE PRN 2 IN ARC TAN         ES028880
1697     26   05E0  C58C    (05C5)          BXU     8,,$8          "HAVE ALL 3 FREQ BEEN PROCESSED? $RO28890
1698     2R   05E1  9C01                    CLAM    0,,1           "SET CALIBRATE COMPUTED MARKER SOES028900
                                            *                      "THAT NOISE MEASUREMENTS CAN     ES028910
1699     10   05E2  701A    (009A)          STA     0,,CALIBRATE_COMPUTED_MARKER "START             ES028920
1700     46   05E3  D5C0                    BBK     12                                              ES028930
                                            *                                                       ES028940
                                            *                                                       ES028950
1701                                        NOT_FOURTH_ITERATION;                                   ES028960
1701    12R   05E4  D5C0                    BBK     0              "EXIT - NO PROCESSING NOW        ES028970
                                            *                                                       TS028980
                                            *                                                       TS028990
                                            *          RECEIVER ERROR                               *H029000
                                            *                                                       *H029010
                                            * THIS ROUTINE IS ENTERED WHENEVER                      *H029020
                                            * THE BIAS OR SCALE FACTOR ARE OUT                      *H029030
```

```
                                        * OF LIMITS.                                                                    *H029040
1702      2R        05E5  A418           REC_ERROR   CLA      1,8            CONVERT 6 COUNTER TO A 3 COUNTER      TS029050
1703      8         05E6  F0144000                   RSA      1,,1           "COUNT NUMBER OF FAILURES             ES029060
1704      16        05E8  F5181F8F                   ADD      X1,,CHANNEL_FAIL                                     TS029070
1705      26        05EA  F1171F8F                   STA      X1,,CHANNEL_FAIL                                     TS029080
                                        *                                    "POST ERROR TYPE IN FAILURE WORD      *I029090
1706      44  *     05EC  351C                      MARK     X1,,12         "10.2 = BIT 13, 13.6=14, 11.3=15      ES029100
1707      62  *     05ED  2EDD    (00DD)            FAILD    I0,,HX0100     "TURN ON MALFUNCTION LAMP             ES029110
1708      70        05EE  D5F0                      BBK      15             "EXIT                                 ES029120
                                        *                                                                           ES029130
                                        *                                                                           ES029140
                                        *                      R0 = TEMP                                            ES029150
                                        *                      R2 = TEMP                                            ES029160
                                        *                      R4 = ADDRESS OF CALIB DATA YC3                       ES029170
                                        *                      R5 = ADDRESS OF CALIB DATA YC2                       ES029180
                                        *                      R6 = ADDRESS OF CALIB DATA YC1                       ES029190
                                        *                      R7 = ADDRESS OF CALIB DATA YC4                       ES029200
                                        *                      R8 = 6 COUNTER, 3 (D) COUNTER                        ES029210
                                        *                      RA = DELTA T CALIBRATE (D)                           ES029220
                                        *                      RC = ADDRESS OF CALIB RESULTS (BY10-2)               ES029230
                                        *                                                                           ES029240
                                        *                                                                           ES029250
                                        *                                                                           ES029260
                                        *                                                                           ES029270
1709      8R        05EF  F46A009A       NOT_CALIB   CLA      6,,CALIBRATE_COMPUTED_MARKER                         ES029280
                                        *                                    "THE NOISE COMPUTATIONS REQUIRE       ES029290
                                        *                                    "THAT THE SCALE FACTOR HAS BEEN       ES029300
                                        *                                    "COMPUTED                             ES029310
                                        *                                    "HAS CALIBRATION                      *I029320
1710      12        05F1  D011    (05F3)            BNE      $9             "BEEN PERFORMED YET?"                 ES029330
                                        *                                                                           ES029340
1711      24R       05F2  D560                      BBK      6              "EXIT - NO PROCESSING NOW             ES029350
                                        *                                                                           ES029360
                                        *                                                                           ES029370
1712      4R        05F3  FC691F08       $9          CLAM     6,,NOISE_DATA  "SAVE SLOT DATA FOR NOISE/PHANTOME   ES029380
1713      32        05F5  7656                      PTR      I5,6                                                 ES029390
1714      46        05F6  F80C1AA0                   FETO     0,,=DF(.1B-1)  DELTA T  NOISE   8+1                 ES029400
1715      54        05F8  8678    (00F8)            FET      0,,CAL_R_ADD   "SET UP 3 COUNTER FOR 3 FREQ         ES029410
1716      62        05F9  8412                      FETM     1,,2           "SET UP 2 COUNTER FOR Y AND X         ES029420
1717      82        05FA  8471                      FETM     7,,1           2 COUNTER + 6 REGISTERS               ES029430
1718      2R        05FB  A442           $10         CLA      4,2            SAVE Y**2 ON 2ND PASS                 ES029440
1719      8         05FC  A62D                      CLA      I2,13          "COMPUTE Y/SF = YN AT B1              ES029450
1720      14        05FD  A5A0                      CLA      X10,0          BIAS AT B14                           HH029460
```

```
1721    20    05FE  F0040666          MPYM  0,,F(.05)          COUNTS PER .1 SECONDS                HH029470
1722    22    0600  B020               SUB   2,0               SUB BIAS FROM PHANTOM                HH029480
1723    28    0601  A5A6               CLA   X10,6             "COMPUTE POINTER TO PHANTOM DATA ES029490
1724    60    0602  D420               DIV   2,0               "= 0 IF Y AND 3 IF X + FREQ 0,1,2ES029500
1725    62    0603  A406               CLA   0,6               CONVERT 2 COUNTER TO 0 IF            ES029510
1726    66    0604  4403               MPIM  0,,3              "  ADD 6 IF STATION COUNTER = 5      ES029520
1727    72    0605  F5891FA6           ADDM  X8,,Y_P           "  OR 7 INDICATING 8 LOOP DATA       ES029530
1728    80    0607  8635   (0085)      FET   0,,STATION_COUNTER "THE DATA IS STORED                 ES029540
1729    86    0608  F0052000           RSL   0,,2              "YPA10, YPA13, YPA11, XPA10,         ES029550
1730    90    060A  4406               MPIM  0,,6              "XPA13, XPA11, YPB10, YPB13,         ES029560
1731    92    060B  B410               ADD   1,0               "YPB11, XPB10, XPB13, XPB11          ES029570
1732    94    060C  A403               CLA   0,3               "                                    ES029580
1733    98    060D  440A               MPIM  0,,10                 "YP(NEW) =  YP(OLD) +            ES029590
1734   104    060E  B110               SUB   X1,0              "       .001(YN/.1 - YP(CLD))        ES029600
1735   110    060F  F0040021           MPYM  0,,F(.001)        "                                    ES029610
1736   116    0611  B510               ADD   X1,0              "FORM YN**2                          ES029620
1737   124    0612  7510               PTR   X1,0              "                                    ES029630
1738   130    0613  6022               MPY   2,2               "THE ABOVE EQUATIONS REPEAT FOR XES029640
1739   132    0614  94D1               ADDM  13,,1             INCREMENT ADDRESS OF NOISE DATA      ES029650
1740   134    0615  94A1               ADDM  10,,1             INC CALIB ADDR                       ES029660
1741   142    0616  C56C   (05FB)      BXU   6,,$10            "HAVE BOTH X AND Y BEEN PROCESSED%R029670
                                *                                                                   ES029680
                                *                                                                   ES029690
1742    2R    0617  8442               ADD   4,2               "Q(T)' = (XN**2 + YN**2)/.1 AT 81ES029700
1743    34    0618  D448               DIV   4,11              Q T PRIME 81                         ES029710
1744    42    0619  F41A009B           CLA   1,,NOISE_COMPUTED_MARKER                             ES029720
1745    46    061B  D06D   (0629)      BRE   $48              "IS THIS THE 1ST TIME THROUGH?       ES029730
1746    8R    061C  F58A0032       $47 CLA   X8,,Q_SUB_T                                          % 029740
1747    12    061E  F8490333           COMM  4,,F(.058-1)                                         % 029750
                                *                             "IS QT' GREATER                      *2029760
1748    16    0620  D045   (0626)      BLE   $50               "THAN .05? (WAS THERE A LOT OF       %R029770
                                *                             "NOISE THIS TIME)                    ES029780
1749    4R    0621  4449               MPIM  4,,9              "MAGNIFY QT' BY FORMING              ES029790
1750    8     0622  F049199A           SUBM  4,,F(.48-1)       "QT = 9QT' - .4                      ES029800
                                *                             "TO MINIMIZE WEIGHT OF STATION       ES029810
1751    10    0624  A404               CLA   0,4                                                  ES029820
1752    14    0625  D009   (062F)      BUC   $46               "BURSTS NOW                          ES029830
1753    4R    0626  F8090333       $50 COMM  0,,F(.058-1)      "LOOK FOR PREVIOUS QT LARGE          ES029840
                                *                             "INDICATING THAT THERE WAS A LOT ES029850
                                *                             "OF NOISE BEFORE                     ES029860
1754    8     0628  D042   (062B)      BLE   $49              "IS QT GREATER THAN .05?             %R029870
1755    4R    0629  FC09019A       $48 CLAM  0,,F(.0258-1)     "SET OLD QT = .025 SO THAT NEW QT%R029880
                                *                             "CAN DROP SHARPLY SINCE QT' IS       %R029890
```

AD-A050 501 NORTHROP CORP HAWTHORNE CALIF ELECTRONICS DIV F/G 17/7
AN/BRN-7 COMPUTER PROGRAM SPECIFICATION. VOLUME XIII. APPENDIX.(U)
OCT 73 N00039-73-C-0209
UNCLASSIFIED NORT-73-48 NL

2 OF 4
AD A050501



```
                                    *                                   "NOW SMALL                                  %R029900
1756        2R      0628  B040      $49       SUB       4,0             "FORM SMOOTHED QT WHERE                     %R029910
1757        8       062C  F0440666            MPYM      4,,F(.05)       "QT(NEW) = QT(OLD) + .05(QT'                %R029920
1758        10      062E  B404                ADD       0,4             "          - QT(OLD))                       %R029930
1759        10R     062F  F1870032    $46     STA       X8,,Q_SUB_T     "SAVE NEW QT FOR BURST                      %R029940
1760        8R      0631  C787  (05FB) $30     BXU       8,,$10          "HAVE ALL 3 FREQ BEEN PROCESSED?            %R029950
1761        10R     0632  F0970098            STA       9,,NOISE_COMPUTED_MARKER NON ZERO                           ES029960
                                    *                                   "SET MARKER INDICATING THAT THE             ES029970
                                    *                                   "NOISE COMPUTATIONS ARE COMPLETE            ES029980
                                    *                                   "AND BURST PROCESSING CAN START             ES029990
1762        48      0634  D500                BBK       13                                                          ES030000
                                    *                                                                               ES030010
                                    *                                                                               ES030020
                                    *                     R0 = TEMP                                                 ES030030
                                    *                     R2 = TEMP                                                 ES030040
                                    *                     R4 = TEMP                                                 ES030050
                                    *                     R6 = 2 COUNTER                                            ES030060
                                    *                     R8 = 3 D COUNTER                                          ES030070
                                    *                     RA = ADDRESS OF CALIBRATE RESULTS (BY)                    ES030080
                                    *                     RB = DELTA T  D                                           ES030090
                                    *                     RD = ADDRESS OF NOISE DATA                                ES030100
```

```
                                        **                                                                      SB030110
                                        *                       START OF BURST                                  *H030120
                                        *                                                                       *H030130
                                        * THIS ROUTINE IS AN OMEGA TASK THAT IS EXECUTED AT THE START          *H030140
                                        * OF EACH STATION BURST DATA COLLECTION PERIOD.  THE PROGRAM           *H030150
                                        * INCREMENTS THE STATION COUNTER, SETS THE TIME OF BURST AND           *H030160
                                        * PERFORMS BASE STATION SELECTION                                      *H030170
                                        *                                                                       *H030180
 1763                                   START_OF_BURST;                                                        SB030190
 1763    22R   0635  F03C00B3          FET     3,,STATION_COUNTER-2 AND CREATE 2 REGISTERS                    SB030200
 1764    24    0637  9C37              CLAM    3,,7            "INCREMENT STATION COUNTER BY 1                SB030210
                                        *                       "RESET TO ZERO IF IT GOES TO 8                 SB030220
                                        *                       "THE STATION COUNTER ALWAYS                    SB030230
                                        *                       "DEFINES THE STATION THAT IS JUSTSB030240
                                        *                       "STARTING IT'S 10.2 FREQ BURST                 SB030250
                                        *                       "0 = STA A  7 = STA H                          SB030260
 1765    32    0638  C420  (0639)      BXU     2,,$1                                                          % 030270
 1766     8R   0639  F52A175A      $1  CLA     X2,,STATION_BURST_TIMES "READ STATION BURST TIMESB030280
 1767    18    063B  F0071F17          STA     0,,BURST_TIME   "FROM A TABLE AND ADD TO TIME                  SB030290
 1768    20    063D  A410              CLA     1,0             "FOR DETERMINATION OF NEXT OMEGA               SB030300
 1769    22    063E  9C00              CLAM    0,,0            "TASK TIME                                     SB030310
 1770    26    063F  8C40              ADDD    4,0             "A = .7  B = .8  C = .9  D = 1.0               SB030320
                                        *                       "E = .9  F = .7  G = 1.0  H = .8               SB030330
                                        *                                                                      SB030340
                                        *                       "NOTE - DATA COLLECTION IS .2 SECSB030350
                                        *                       "       LESS THAN THE TOTAL                    SB030360
                                        *                       "       STATION BURST TIME                     SB030370
 1771    36    0640  F0270085          STA     2,,STATION_COUNTER                                             SB030380
 1772    52    0642  8450              FETM    5,,0            "CLEAR THE 6 SIN/COS REGISTERS TO%SB030390
 1773    82    0643  F4570011          PTR     5,,COS_10_2     "START THE DATA COLLECTION                     SB030400
 1774    96    0645  D730              PRN     3                                                              SB030410
 1775   104    0646  92EB  (00EB)      SUBD    0,,=D1          NEXT TASK .005S BEFORE END BURST               SB030420
                                        *                       "SET NEXT OMEGA TASK 5 MSEC PRIOR*I030430
 1776   174    0647  0806              OMEGA   0,,K_FILTER-OMEGA_TASK_TABLE/2 "TO END OF BURST               SB030440
 1777   182    0648  8632  (0082)      FET     0,,START_CNT                                                   % 030450
 1778   190    0649  864D  (00CD)      FET     0,,NEED_BASE                                                   % 030460
                                        *                       "HAS A BASE                                    *I030470
 1779   194    064A  D015  (0650)      BNE     $2              "STATION BEEN SELECTED YET?                    SB030480
 1780     4R   0648  F8190048          COMM    1,,I((12)*6)    "ALLOW THE SYSTEM TO OPERATE FOR               SB030490
                                        *                       "1 MINUTE AFTER SYNC BEFORE                    SB030500
                                        *                       "ATTEMPTING BASE STATION SELECT                SB030510
                                        *                       "                                              *2030520
 1781    10    064D  0405068F          BRL     $10             "HAS 1 MINUTE ELAPSED?"                        %R030530
```

```
                                        *                                       "(EXIT IF NO)                                   SB030540
1782    4R      064F  D004  (0654)                BUC     $3                    "DO BASE STATION SELECTION                      SB030550
1783    2R      0650  981C                $2      COMM    1,,12                 "REVIEW BASE STATION EVERY 10 SEC               SB030560
                                        *                                       "                                               *2030570
1784    8       0651  0405068F                    BRL     $10                   "HAVE 10 SECONDS ELAPSED?                       %R030580
                                        *                                       "(EXIT IF NO)                                   SB030590
1785    8R      0653  7033  (0083)                STA     0,,START_MKR          "SET START MARKER TRUE TO ALLOW                 SB030600
                                        *                                       "THE TRACKING FILTERS TO OPERATE                SB030610
                                        *                                       "(THE MARKER WAS ALREADY TRUE                   SB030620
                                        *                                       "UNLESS THERE WAS A BASE STATION                SB030630
                                        *                                       "CHANGE 10 SECONDS AGO)                         SB030640
1786    2R      0654  8C01                $3      CLSM    0,,1                  "SET LARGEST H BURST NEGATIVE                   SB030650
1787    14      0655  8437                        FETM    3,,OS-1               "SET UP A COUNTER TO CYCLE THE                  SB030660
1788    22      0656  7032  (0082)                STA     0,,START_CNT          "OS STATIONS                                    SB030670
1789    26      0657  FC191F7B                    CLAM    1,,H_BURST            "SET A AS BASE IN CASE ALL                      SB030680
1790    28      0659  9C50                        CLAM    5,,0                  "STATIONS ARE OFF OR TOO CLOSE                  SB030690
                                        *                                       "                                               SB030700
1791    8R      065A  F52A00D5          $4      CLA     X2,,POWERS_OF_TWO     "READ STATIONS SELECTED BY                      SB030710
1792    16      065C  E40000E5                    EXT     0,0,STATIONS_IN_USE   "THE OPERATOR                                   SB030720
                                        *                                       "HAS THE OPERATOR                               *1030730
1793    20      065E  D015  (0664)                BNE     $40                   "TURNED THIS STATION OFF?"                      %R030740
1794    8R      065F  F02800CC          $42     COM     2,,BASE+1             "AT THIS POINT THE STATION IS                   SB030750
                                        *                                       "EITHER OFF OR TOO CLOSE                        SB030760
                                        *                                       "IS THIS STATION                                *1030770
1795    12      0661  D110  (0672)                BNE     $5                    "THE PRESENT BASE STATION?                      %R030780
1796    8R      0662  704D  (00CD)                STA     0,,NEED_BASE          "SET THE NEED BASE MARKER TO                    SB030790
1797    12      0663  D00E  (0672)                BUC     $5                    "FORCE A NEW BASE SELECTION NOW                 SB030800
1798    8R      0664  867D  (00FD)    $40         FET     0,,RIJ_ADD            "SET UP ARGUMENTS FOR THETA 1                   SB030810
1799    14      0665  C003                        FET     STA NO                0,3                                             SB030820
                                        *                                       "COMPUTE THE DISTANCE BETWEEN THE               *1030830
1800    22  *   0666  F80D0862                    BSV     COMPUTE_THETA1        "STATION AND THE CRAFT                          SB030840
1801    26      0668  F8090488                    COMM    0,,F((((400)*6076)/2.0950)/3.14159)                                   % 030850
1802    36      066A  D710                        PRN     1                                                                     % 030860
                                        *                                       "IS THE STATION                                 *1030870
1803    40      066B  D032  (066E)                BRG     $41                   "MORE THAN 400 N MILES AWAY?                    SB030880
1804    2R      066C  8000                        SUB     0,0                   "THIS STATION IS TOO CLOSE                      SB030890
1805    6       066D  D80F  (065F)                BUC     $42                                                                   SB030900
1806    6R      066E  8241          $41         COM     I4,1                  "COMPARE THE H BURST FOR THIS                   SB030910
                                        *                                       "STATION AGAINST THE LARGEST OF                 SB030920
                                        *                                       "THE H BURSTS FROM THE STATIONS                 SB030930
                                        *                                       "ALREADY EXAMINED                               SB030940
                                        *                                       "IS H BURST MORE                                *1030950
1807    10      066F  D032  (0672)                BRG     $5                    "THAN THE LARGEST H BURST?                      %R030960
```

```
1808    2R    0670 A452                    CLA     5,2      "THIS STATION IS STRONGER"          SB030970
                                  *                          "SAVE STATION NUMBER                SB030980
                                  *                          "REPLACE LARGEST H BURST WITH THESB030990
1809    8     0671 A641                    CLA     I4,1     "H BURST FROM THIS STATION          SB031000
1810    2R    0672 9412              $5    ADDM    1,,2     "INCREMENT H BURST POINTER          SB031010
                                  *                          "HAVE ALL                           *1031020
1811    10    0673 C52A    (065A)        BXU     2,,$4    "STATIONS BEEN EXAMINED?            %R031030
1812    6R    0674 9E4D    (00CD)        CLA     0,,NEED_BASE                                 % 031040
1813    10    0675 D06F    (0685)        BRE     $6       "IS A BASE STATION NEEDED NOW?      SB031050
1814    4R    0676 F0190010              SUBM    1,,OS*2  "NOW DETERMINE IF THE STRONGEST      031060
1815    16    0678 F71A00C8              CLA     IX1,,BASE "STATION IS SUFFICIENTLY STRONGERSB031070
1816    22    067A F0040CCD              MPYM    0,,F(.1) "THAN THE PRESENT BASE STATION     SB031080
1817    34    067C F7180CC8              ADD     IX1,,BASE "                                 SB031090
1818    38    067E F4090000             2ADDM    0,,0     "H  = 1.1*(H BURST(BASE)) + H(0)   SB031100
1819    40    0680 8415                  ADD     1,5                                          SB031110
1820    42    0681 8415                  ADD     1,5                                          SB031120
1821    48    0682 8201                  COM     I0,1                                         SB031130
                                  *                          "IS THE LARGEST                     *1031140
1822    52    0683 D041    (0685)        BLE     $6       "H BURST GREATER THAN H?            SB031150
1823    22R   0684 D550                  BBK     5        "EXIT - NO CHANGE IN BASE STATIONSB031160
1824    14R   0685 D730              $6    PRN     3        "BASE STATION CHANGE"               SB031170
1825    2R    0686 A401              $77   CLA     0,1      "SAVE NEW BASE STATION NO.          SB031180
1826    4     0687 8400                  ADD     0,0                                          SB031190
1827    16    0688 7C48    (00C8)        PTRD    0,,BASE                                      SB031200
1828    24    0689 8411                  FETM    1,,1                                         SB031210
1829    28    068A D0D2    (068D)        BCF     $7       "PHASE DIFFERENCE TRACKING?         %R031220
1830    8R    068B 7000    (0080)        STA     0,,RESET_TF "SUBMARINE ALWAYS PHASE DIFF     SB031230
                                  *                          "                                   SB031240
                                  *                          "SET MARKER TO RESET TRACKING       SB031250
                                  *                          "FILTERS BECAUSE OF BASE CHANGE     SB031260
                                  *                          "RESET TRACKING FILTER START        SB031270
                                  *                          "MARKER BECAUSE NEW BASE STATION    SB031280
                                  *                          "PHASE'S ARE NOT AVAILABLE YET      SB031290
1831    16    068C 7033    (0083)        STA     0,,START_MKR "THEY WILL BE AVAILABLE IN 10 SECSB031300
1832    10R   068D F0170CCD        $7    STA     1,,NEED_BASE "RESET NEED BASE MARKER         SB031310
1833    14R   068F D510            $10   BBK     1        "EXIT                               SB031320
```

```
                                                                                                                    VP031330
                                                                                                                    *H031340
                                                                                                                    *H031350
                                                                                                                    *H031360
                                                                                                                    *H031370
                                                                                                                    *H031380
                                                                                                                    *H031390
                                                                                                                    *H031400
                                                                                                                    *H031410
                                                                                                                    *I031420
1834                                                                                                                VP031430
1834      8R        0690  F408001A                  FETM    0,,TRUE_HEADING_INPUT "SET UP INDEX TO READ 3          VP031440
1835      24        0692  8451                      FETM    5,,1          "SYNCHRO INPUTS FROM DMA                 HH031450
1836      26        0693  90F7                      SUBM    15,,7                                                  HH031460
1837      6R        0694  A746                $1    CLA     IX4,6         "READ SYNCHRO INPUT"                     VP031470
1838      12        0695  9661   (00E1)             ADD     0,,HX1000     "INCREMENT OCTANT AND EXTRACT            HH031480
1839      20        0696  E420177E                  EXT     2,0,HX6000    "QUAD FROM BITS 14 AND 15                VP031490
1840      24        0698  4422                      LSA     2,,1          "SCALE QUADRANT AT PI                    HH031500
1841      26        0699  A430                      CLA     3,0           "EXTRACT TAN/COT FROM 1 TO 12            VP031510
1842      34        069A  E403177F                  EXT     0,3,HX0FFF    "RESCALE TO 80  USE AS SINE              HH031520
1843      40        069C  4658   (0008)             MPI     0,,HX0008     "SET COSINE = 1                          HH031530
1844      42        069D  9C10                      CLAM    1,,0          "USE ARCTAN TO GET ANGLE AT PI           VP031540
1845      54        069E  86F3   (00F3)             FETD    0,,=DX(7FFFFFFF) "BASE ANGLE NOW BETWEEN 0 AND 4         VP031550
1846      592       069F  1800                      ATAN    0,0           GET BASE ANGLE                           VP031560
1847      600       06A0  E43300E1                  EXT     3,3,HX1000                                             HH031570
                                                    *                     "IS IT A COTAN?                          *I031580
1848      604       06A2  D011   (06A4)             BNE     $2            "(ORIGINAL OCTANT = 1, 3, 5 OR 7)        %R031590
1849      4R        06A3  A800                      CLSD    0,0           "COMPLIMENT ANGLE"                       VP031600
                                                    *                     "NEW BASE BETWEEN 315 AND 360 DEG        VP031610
1850      2R        06A4  8402                $2    ADD     0,2           "ADD QUADRANT TO GET FINAL RESULT        VP031620
1851      10        06A5  734F                      STA     IX4,15        "SAVE IN R15 STACK                       VP031630
                                                    *                     "SMOOTH INPUT WITH OLD DATA TO           *I031640
1852      18  *     06A6  F80D06EE                  BSV     SMOOTH        "ELIMINATE BIG JUMPS DUE TO NOISE        VP031650
                                                    *                     "HAVE ALL THREE                          *I031660
1853      26        06A8  C545   (0694)             BXU     4,,$1         "SYNCHRO'S BEEN PROCESSED?"              %R031670
                                                    * THE R15 STACK NOW CONTAINS IN R15 AND R15+1,                  HH031680
                                                    * TRUE HEADING AND SHIPS SPEED RESPECTIVELY.                    HH031690
                                                    *                                                              VP031700
                                                    *                                                              VP031710
                                                    *                                                              *H031720
                                                    * THE OPERATOR HAS SELECTED A NAV - HDG                         *H031730
                                                    * MODE THROUGH A C-I PANEL PROCEDURE.                           *H031740
                                                    * THE PROCEDURE DICTATES THAT ONE AND                           *H031750
```

```
                        * ONLY ONE MODE WILL BE SELECTED.                                                *H031760
1854      6R    06A9 9E65   (00E5)          CLA      0,,STATIONS_IN_USE "EXAMINE VEL/HDG MODE SELECTEVP031770
1855      10    06AA F4040020               LSA      0,,5               "BY THE OPERATOR AND SET PROGRAM   031780
1856      12    06AC DE50                   FLG      L+A                "FLAGS ACCORDINGLY FOR LATER USE.VP031790
1857      16    06AD 4402                   LSA      0,,1               "A TRUE = SHIPS LOG/TRUE HDG       031800
1858      18    06AE DE52                   FLG      L+C                "C TRUE = MANUAL VEL/HDG           031810
                        *                                               "A,C ALL FALSE = NO RATE AIDING    031820
                        *                                                                                *S031830
1859      24    06AF A5F1                   CLA      X15,1              "READ SHIP LOG,SUBT 120 DEG        VP031840
1860      28    0680 F0090000               2SUBM    0,,0               "(ELECT 0=0 DEG) WAS 120/180       031850
1861      36    0682 5263   (00E3)          MPLM     10,,HX4000         "RESCALE TO FEET/SECOND AT B11     VP031860
1862       6R   0683 F0040438        $81    MPYM     0,,F(6076*40/3600811) "40 KNOTS PER 360 DEG         031870
1863      10    0685 F8090381               COMM     0,,F(((35)*6076)/3600811)                          VP031880
1864      14    0687 D051   (0689)          BRL      $20                "IS LOG LESS THAN 35 KNOTS?        VP031890
1865       2R   0688 8000          $3        SUB      0,0                BECOMES NOOP FOR PI TEST           031900
                        *                                               "SO THAT A SMALL AMOUNT OF NOISE VP031910
                        *                                               "WILL NOT MAKE 0 KTS READ 40 KTS VP031920
1866       8R   0689 7038   (00B8)  $20     STA      0,,V_TAS           "SAVE LOG IN VTAS AND R15 STACK  VP031930
1867      16    068A 71F1                   STA      X15,1                                               HH031940
1868      22    068B A64F                   CLA      I4,15              "PSI A = TRUE HEADING"           *S031950
1869      24    068C 9C52                   CLAM     5,,2               "SET HDG MODE = 2 = TRUE HDG     VP031960
1870      28    068D 8800                   SUBD     0,0                "SET VEL = 0                     VP031970
1871      30    068E 9C60                   CLAM     6,,0               "SET NAV MODE = 0 = NO RATE AID  VP031980
                        *                                               "                                *2031990
1872      34    068F D093   (06C3)          BAF      $30                "MODE = SHIPS LOG/TRUE HDG?      *R032000
                        *                                               "(FLAG A TRUE)                   VP032010
1873       6R   06C0 A5F1                   CLA      X15,1              "VEL=SHIPS LOG                     HH032020
1874       8    06C1 9C62                   CLAM     6,,2               "SET NAV MODE = 2 = SHIPS LOG/   VP032030
1875      12    06C2 D007   (06CA)          BUC      $33                "TRUE HEADING                    VP032040
                        *                                               "                                *2032050
1876       4R   06C3 D0D6   (06CA)  $30     BCF      $33                "MODE = NO RATE AIDING?"           032060
                        *                                               "(FLAG C FALSE)                  VP032070
                        *                                               "MODE = MANUAL VEL / MANUAL HDG  VP032080
1877       2R   06C4 9C51                   CLAM     5,,1               "SET HDG MODE = 1 = MANUAL       VP032090
1878      10    06C5 F44A1F8B               CLA      4,,PSI_INSERT      "PSI A = INSERTED HDG (PSI WIND) VP032100
1879       8R   06C7 F40A1FF4        $31    CLA      0,,V_INSERT        "VEL = INSERTED VEL (V INSERT)   VP032110
1880      10    06C9 9C64                   CLAM     6,,4               "NAV MODE = 4 = MANUAL           VP032120
1881       8R   06CA C015          $33     FET      1,5                "GET HDG ARGUMENT (PSI A)        VP032130
                        *                                               "COMPUTE V2 AND V3 FROM VEL, HDG *I032140
1882      16 *  06CB F80D06E3               BSV      RESOLVE            "AND THETA P                     VP032150
1883      22    06CD 9E50   (00D0)          CLA      0,,PMU_INPUT       "LAB USE ONLY"                   % 032160
1884      28    06CE 465C   (00DC)          MPI      0,,HX0080          TEST BIT 9 OF MONITOR SWITCHES   % 032170
                        *       LAB USE ONLY                                                             *H032180
```

```
                                        * ALLOW LAB OPERATOR TO OVERRIDE                                    *H032190
                                        * VEL/HDG INPUTS FROM THE PROGRAM                                   *H032200
                                        * MONITOR UNIT                                                      *H032210
                                        *                                   "IS MONITOR UNIT                *2032220
1885    32      06CF  D023  (06D3)              BGE     $12                 "OVERRIDE BUTTON TRUE INDICATING %R032230
                                        *                                   "LAB USE?                       VP032240
1886     4R     06D0  B822                      SUBD    2,2                 "SET V2=V3=0 IN LAB"            VP032250
1887     8      06D1  FC492000                  CLAM    4,,F((45)/180)      "SET PSI A = 45 DEG IN LAB"     VP032260
1888    10R     06D3  FC0A1F8D          $12     CLAD    0,,HEADING_MODE     "READ PREVIOUS NAV MODE"        VP032270
                                        *                                    HEADING MODE NOT USED IN SUB   VP032280
1889    12      06D5  8016                      COM     1,6                  COMPARE OLD AND NEW NAV MODES  VP032290
                                        *                                   "IS THE NEW NAV                 *2032300
1890    16      06D6  D062  (06D9)              BRE     $14                 "MODE DIFFERENT THAN THE PREVIOUS%R032310
                                        *                                   "NAV MODE?                      VP032320
1891     4R     06D7  B800                      SUBD    0,0                 "SET KALMAN VEL CORRECTIONS     VP032330
1892    14      06D8  7839  (0089)              STAD    0,,DELTA_V2         "DELTA V2,3 = 0 BECAUSE THE     VP032340
                                        *                                   "PREVIOUS CORRECTIONS ARE       VP032350
                                        *                                   "PROBABLY NO LONGER VALID       VP032360
1893     8R     06D9  9E89  (0089)    $14     CLAD    0,,DELTA_V2          READ DELTA V2,3                VP032370
1894    10      06DA  B402                      ADD     0,2                 "VC2 = V2 + DELTA V2            VP032380
1895    12      06DB  B413                      ADD     1,3                 "VC3 = V3 + DELTA V3            VP032390
1896    14      06DC  94F7                      ADDM    15,,7                                               VP032400
1897    26      06DD  7C3E  (008E)              PTRD    0,,VC2              "SAVE VC2,3 AT B12 FT/SEC       VP032410
1898    38      06DE  7C22  (00A2)              PTRD    0,,V2               "SAVE V2,3  AT B12 FT/SEC       VP032420
1899    46      06DF  7442  (00C2)              PTR     0,,PSI_A            "SAVE PSI A = HEADING           VP032430
1900    60      06E0  FC071F8D                  PTRD    0,,HEADING_MODE     "SAVE HDG/NAV MODES             VP032440
1901    74      06E2  D510                      BBK     1                    PRUNE 2 EXEC REGISTERS         VP032450
                                        *                                                                   VP032460
                                        * IN GENERAL THE REGISTERS CONTAIN THE FOLLOWING                    VP032470
                                        *                       R6          NAV MODE                        VP032480
                                        *                       R5          HDG MODE                        VP032490
                                        *                       R4          PSI A                           VP032500
                                        *                       R3          V3                              VP032510
                                        *                       R2          V2                              VP032520
                                        *                       R1          SPARE                           VP032530
                                        *                       R0          SPARE                           VP032540
```

```
                                                                                                                    VP032550
                                                                                                                    *H032560
                                                                                                                    *H032570
                                                                                                                    *H032580
                                                                                                                    *H032590
                                                                                                                    *H032600
                                                                                                                    *H032610
                                                                                                                    *H032620
                                                                                                                    *H032630
                                                                                                                    VP032640
                                                                                                                    VP032650
                                                                                                                    VP032660
                                                                                                                    VP032670
                                                                                                                    VP032680
1902        6R      06E3  9640  (00C0)  RESOLVE  ADD      0,,THETA_P   "RESOLVE ALONG TRACK VEL (REG 2)            VP032690
1903      440       06E4  1400            SINCOS   0                    "AND CROSS TRACK VEL (REG 3)               VP032700
1904      444       06E5  AC64            CLAD     6,4                  "THROUGH ANGLE IN REG 0,1+THETA            PVP032710
1905      450       06E6  6062            MPY      6,2                  "TO FORM V2,V3 (RESCALED BY B1)            VP032720
1906      456       06E7  6040            MPY      4,0                  "LEAVE RESULT IN REG 2,3 AFTER             VP032730
1907      462       06E8  6072            MPY      7,2                  "PRUNING 2 REGISTERS                       VP032740
1908      468       06E9  6050            MPY      5,0                  "V2 = VAT*SIN + VCT*COS                    VP032750
1909      470       06EA  8465            ADD      6,5                  "V3 = VAT*COS - VCT*SIN                    VP032760
1910      472       06EB  8047            SUB      4,7                                                             VP032770
1911      474       06EC  A474            CLA      7,4                                                             VP032780
1912      492       06ED  D530            BBK      3                                                               VP032790
                                                                                                                    VP032800
```

```
                                        **                                                                  VP032810
                                        *                                                                   VP032820
                                        * SYNCHRO SMOOTHING ROUTINE                                        #H032830
                                        *                                                                   #H032840
                                        * THIS PROGRAM WILL SMOOTH THE NEW                                  #H032850
                                        * SYNCHRO INPUT IF IT IS SUBSTANTIALLY                              #H032860
                                        * DIFFERENT THEN THE OLD VALUE                                      #H032870
1913      8R   06EE F1481F67            SMOOTH  SUB     X4,,SMOOTH_DATA "FORM .02(NEW - OLD) WHICH WILL     VP032880
1914     14    06F0 F004028F                    MPYM    0,,F(.02)       "BE THE INCREMENT OF CHANGE IF      VP032890
1915     16    06F2 A410                        CLA     1,0             "NEW - OLD IS LARGE                 VP032900
1916     20    06F3 D031   (06F5)              BRG     $1                                                  % 032910
1917      2R   06F4 A000                        CLS     0,0             "FORM ABSOLUTE .02(NEW - OLD)       %S032920
1918      4R   06F5 F8090010          $1       COMM    0,,F(((4.4)/180)*.02) "COMPARE DIFF AGAINST 4.4     % 032930
                                        *                               "DOES NEW - OLD                     #1032940
1919      8    06F7 D032   (06FA)              BRG     $2              "EXCEED 4.4 DEGREES?                VP032950
1920      6R   06F8 A7F4                        CLA     IX15,4          "SMALL CHANGE SO USE NEW VALUE      VP032960
1921     10    06F9 D004   (06FE)              BUC     $3              "WITHOUT ANY SMOOTHING              VP032970
1922      2R   06FA A401              $2       CLA     0,1             "LARGE CHANGE - SMOOTH NEW VALUE    VP032980
                                        *                               "SMOOTHED V = .02(NEW-OLD) + OLD    VP032990
1923     10    06FB F5481F67                    ADD     X4,,SMOOTH_DATA "SAVE IN R15 STACK FOR USE NOW      VP033000
1924     18    06FD 73F4                        STA     IX15,4                                              VP033010
1925     10R   06FE F1471F67          $3       STA     X4,,SMOOTH_DATA "SAVE IN SMOOTH DATA FOR NEXT       VP033020
1926     18    0700 D5F0                        BBK     15              "TIME                               VP033030
                                        *                                                                   VP033040
```

```
                                **                                                                      VP033050
                                *           RIJ UPDATE                                                  *H033060
                                *                                                                       *H033070
                                * THIS IS A NON OMEGA TASK THAT UPDATES                                  *H033080
                                * CRAFT POSITION 10 TIMES A SECOND                                       *H033090
                                *                                                                       RU033100
1927    28R     0701  8480      RIJ_UPDATE  FETM    11,,0           "INTEGRATE COMPUTED VELOCITY        RU033110
                                *                                   "VC2,3 * DELTA T / RHO = ANG2,3     RU033120
1928    36      0702  F48A08BF              CLA     8,,VC3          "RHO = EARTH EQUATORIAL RADIUS      RU033130
                                *                                   "TO GET ANGULAR CHANGE ALONG        RU033140
1929    44      0704  F4AA08BE              CLA     10,,VC2         "R2, R3                             RU033150
1930    64      0706  F8861AA2              MPYD    8,,=DF((.1)/2.0926D+7B-14) DT/R0 AT 8-14            RU033160
1931    84      0708  F8A61AA2              MPYD    10,,=DF((.1)/2.0926D+7B-14) DT/R0 AT 8-14           RU033170
1932    94      070A  FC6A1F69              CLAD    6,,R11          "COMPUTE DELTA THETA 2              *S033180
1933    110     070C  6866                  MPYD    6,6             "= -(1 + E(1-2R11**2 + R31**2       RU033190
1934    114     070D  BC66                  ADDD    6,6             "  - R21**2))*(ANG 3) - 2ER21R31    RU033200
1935    124     070E  F86B00F5              SUBD    6,,=DF(1.08-2)  " *(ANG 2) + KALMAN CORRECTION 2    RU033210
1936    134     0710  FC4A1F6F              CLAD    4,,R21          "                                   RU033220
1937    138     0712  AC24                  CLAD    2,4             "COMPUTE DELTA THETA 3              RU033230
1938    154     0713  6822                  MPYD    2,2             "= (1 + E(1-2R11**2 - R31**2        RU033240
1939    164     0714  FC0A1F75              CLAD    0,,R31          "  + R21**2))*(ANG 2) + 2ER21R31    RU033250
1940    180     0716  6840                  MPYD    4,0             "  (ANG 3) + KALMAN CORRECTION 3    RU033260
1941    196     0717  6800                  MPYD    0,0             R31**2                              RU033270
1942    200     0718  B802                  SUBD    0,2             R31SQ - R21SQ                       RU033280
1943    204     0719  A820                  CLSD    2,0             R21SQ - R31SQ                       RU033290
1944    208     071A  B826                  SUBD    2,6             1-2R11SQ - R31SQ + R21SQ            RU033300
1945    212     0718  B806                  SUBD    0,6             1-2R11SQ - R21SQ + R31SQ            RU033310
1946    232     071C  F8061AA4              MPYD    0,,=DF(1/298.25)  E @ B0                      11  033320
1947    252     071E  F8261AA4              MPYD    2,,=DF(1/298.25)                              11  033330
1948    260     0720  96F5   (00F5)         ADDD    0,,=DF(1.08-2)                                  RU033340
1949    270     0721  FC2B00F5              ADDD    2,,=DF(1.08-2)                                  RU033350
1950    286     0723  6808                  MPYD    0,8             VC3 TERM OF DTHETA2                 RU033360
1951    302     0724  682A                  MPYD    2,10            VC2 TERM OF DTHETA3                 RU033370
1952    306     0725  BC44                  ADDD    4,4             2*R31*R21                           RU033380
1953    326     0726  F8461AA4              MPYD    4,,=DF(1/298.25)  E*2*R31*R21                 11  033390
1954    342     0728  68A4                  MPYD    10,4            VC2 TERM OF DTHETA2                 RU033400
1955    358     0729  6884                  MPYD    8,4             VC3 TERM OF DTHETA3                 RU033410
1956    362     072A  8CA0                  ADDD    10,0            -DTHETA 2                           RU033420
1957    366     072B  A8AA                  CLSD    10,10           DTHETA2                             RU033430
1958    370     072C  BC82                  ADDD    8,2             DTHETA 3                            RU033440
1959    380     072D  FC881F2D              ADDD    8,,DELTA_THETA_3 KALMAN CORRECTIONS                 RU033450
1960    390     072F  FCAB1F28              ADDD    10,,DELTA_THETA_2                                   RU033460
1961    402     0731  8430                  FETM    3,,0            "CLEAR KALMAN CORRECTIONS 2,3       *S033470
```

```
1962    424       0732  F4371F28              PTR     3,,DELTA_THETA_2 "(THEY WILL BE NON ZERO AT MOSTRU033480
1963    442       0734  D750                  PRN     5                "ONCE PER 10 SECONDS)          RU033490
1964    448       0735  9E7D    (00FD)        CLA     0,,RIJ_ADD       UPDATE THIS SET OF RIJ'S       RU033500
1965    450       0736  A410                  CLA     1,0              STORE THEM IN THE SAME PLACE   RU033510
                                  *                                    "UPDATE RIJ MATRIX WITH DELTA  *I033520
1966    458   *   0737  F80D0743              BSV     ROTATE_RIJS      "THETA 2, DELTA THETA 3        RU033530
1967    472       0739  F80C1F6F              FETD    0,,R21           "COMPUTE THETA P = ATAN R21/R31 RU033540
1968    486       0738  F80C1F75              FETD    0,,R31           "SAVE THETA P, SIN (THETA P)   RU033550
1969   1024       073D  1800                  ATAN    0,0              "AND COS (THETA P) FOR OTHER   RU033560
1970   1034       073E  7840    (00C0)        STAD    0,,THETA_P       "PROGRAMS                      RU033570
1971   1468       073F  1400                  SINCOS  0,0                AND                          RU033580
1972   1490       0740  F4371F92              PTR     3,,COS_THETA_P       FOR OTHER ROUTINES       RU033590
1973   1504       0742  D510                  BBK     1                                              RU033600
```

```
                                                                                                                    RU033610
                        **                                                                                          RU033620
                        * THIS PROGRAM WILL ROTATE A SPECIFIED SET OF RIJS.  THE CALLING                            RU033630
                        *       SEQUENCE IS AS FOLLOWS.                                                             RU033640
                        *             R0 = ADDRESS OF ROTATED RIJ MATRIX                                            RU033650
                        *             R1 = ADDRESS OF RIJ MATRIX TO BE ROTATED                                      RU033660
                        *             R2,3 = DELTA THETA 3                                                          RU033670
                        *             R4,5 = DELTA THETA 2                                                          RU033680
                        *                    (ALL REGISTERS PRUNED ON RETURN)                                       RU033690
                        *                                                                                          #H033700
                        * RIJ ROTATE                                                                               #H033710
                        *                                                                                          #H033720
                        * THIS PROGRAM WILL ROTATE A 3X3 MATRIX (R)                                                #H033730
                        * THROUGH THE 2 ANGLES SPECIFIED                                                          RU033740
                        *                                                                                          RU033750
1974      8R  0743 8412 ROTATE_RIJS FETM    1,,2                                                                    % 033760
1975     12R  0744 C930 $1          FETD    X3,0        "                                                           RU033770
1976     24   0745 C956              FETD    X5,6        R2I                                                         RU033780
1977     36   0746 C97C              FETD    X7,12       R3I                                                         RU033790
1978     52   0747 680C              MPYD    0,12        R3I(D2)                                                     RU033800
1979     68   0748 682A              MPYD    2,10        R2I(D3)                                                     RU033810
1980     72   0749 B820              SUBD    2,0         R2I(D3)-R3I(D2)                                             RU033820
1981     76   074A AC02              CLAD    0,2         R2I(D3)-R3I(D2)                                             RU033830
1982     86   0748 F8244000          RSAD    2,,1        "GIVEN THE 2 ANGLES T2 AND T3                               RU033840
                        *                                  "THEN                                                   RU033850
                        *                                  "          SQ    T3        -T2                          RU033860
                        *                                  "THETA = -T3   -T3*T2/2    T2*T3/2                      RU033870
                        *                                  "          T2    T2*T3/2   -T2*T2/2                     RU033880
                        *                                  "                                                       RU033890
                        *                                  " WHERE SQ = (T2*T2 + T3*T3) / 2                        033900
1983     90  074D BC42              ADDD    4,2         "                                                           033910
                        *                                  "AND                                                    033920
1984     94  074E A824              CLSD    2,4         "                                                           033930
                        *                                  "R(NEW) = R(OLD) + R(OLD)*THETA                         RU033940
1985    110  074F 682A              MPYD    2,10        -D3(R1I+R2I(D3)/2 -R3I(D2)/2) =X                            RU033950
1986    126  0750 684C              MPYD    4,12        +D2(R1I+R2I(D3)/2 -R3I(D2)/2) =Y                            RU033960
1987    138  0751 C82D              FETD    2,13                                                                    RU033970
1988    154  0752 680C              MPYD    0,0         (D3)(D3)                                                    RU033980
1989    170  0753 6822              MPYD    2,2         (D2)(D2)                                                    RU033990
1990    174  0754 BC20              ADDD    2,0                                                                     RU034000
1991    184  0755 F8244000          RSAD    2,,1        ((D3)(D3)+(D2)(D2))/2 = Z                                   RU034010
1992    192  0757 ADD0              CLAD    X13,0       R1I                                                         RU034020
1993    208  0758 6820              MPYD    2,0                                                                     RU034030
1994    212  0759 B802              SUBD    0,2
```

```
1995   216   075A  BC04                ADDD    0,4                                    RU034040
1996   228   075B  7DC0                PTRD    X12,0   R1I=R1I-R1I(Z)+R2ID3-R3ID2     RU034050
1997   242   075C  D730                PRN     3                                      RU034060
1998   250   075D  BD76                ADDD    X7,6                                   RU034070
1999   262   075E  7D66                PTRD    X6,6    R2I= R2I+X                     RU034080
2000   270   075F  BD5C                ADDD    X5,12                                  RU034090
2001   282   0760  7D4C                PTRD    X4,12   R3I= R3I+Y                     RU034100
2002   284   0761  9422                ADDM    2,,2                                   RU034110
2003   286   0762  9432                ADDM    3,,2                                   RU034120
2004   294   0763  C600  (0744)        BXU     0,,$1   "                              RU034130
2005    26R  0764  D570                BBK     7                                      RU034140
```

```
                                **                                                                  CF034150
                                *                          KALMAN FILTER                            *H034160
                                *                                                                   *H034170
                                * THIS PROGRAM PROCESSES TRACKING FILTER MEASUREMENTS AND POSITION FIXES*H034180
                                * TO GENERATE ESTIMATES OF SYSTEM ERRORS.  IT IS AN OMEGA TASK THAT IS  *H034190
                                * ENTERED 5 MILLISECONDS BEFORE END BURST.  THIS PROGRAM ONLY CYCLES    *H034200
                                * WHEN THE STATION COUNTER IS 0 (STATION A).  IT HAS BEEN SYNCHRONIZED  *H034210
                                * WITH THE NON OMEGA TASK ROUTINES IN SUCH A WAY THAT RIJ UPDATE OCCURS *H034220
                                * 5 MILLISECONDS BEFORE KALMAN.  FIVE MILLISECONDS AFTER KALMAN IS INI- *H034230
                                * TIATED THE END BURST/TRACKING FILTER ROUTINES WILL INTERRUPT KALMAN SO*H034240
                                * THAT ALL TRACKING FILTERS WILL BE TIME UPDATED TO THE END BURST TIME. *H034250
                                * THIS RESULTS IN THE RIJ, KALMAN AND TRACKING FILTER UPDATES OCCURING  *H034260
                                * WITHIN A 10 MILLISECOND PERIOD.  FOR THIS TIMING TO BE CORRECT KALMAN *H034270
                                * MUST NOT READ ANY TRACKING FILTER DATA IN THE 5 MILLISECONDS AVAILABLE*H034280
                                * BEFORE THE END BURST INTERRUPT.                                    *H034290
                                *                                                                   *H034300
                                *                                                                   *H034310
                                *                                        "SET NEXT OMEGA TASK TO OCCUR IN *I034320
2006                            KALMAN_FILTER;                                                      CF034330
2006    70R   0765  0807                 OMEGA    0,,END_BURST-OMEGA_TASK_TABLE/2 "5 MILLISECONDS"CF034340
2007    78    0766  8635  (0085)         FET      0,,STATION_COUNTER                                % 034350
                                *                                        "IS IT"                    *I034360
2008    82    0767  D061  (0769)         BRE      COVARIANCE_INITIALIZATION   "STATION A TIME?"     CF034370
2009    12R   0768  D500                 BBK      0                       "EXIT"                     CF034380
                                *                                                                   CF034390
2010                            COVARIANCE_INITIALIZATION;                                          CF034400
2010     8R   0769  D7C0                 PRN      0                                                  HH034410
2011    42    076A  F4081D17             FETM     13,,P_MATRIX                                       CF034420
2012    44    076C  8C02                 CLSM     0,,2          START PANEL UPDATE AT EVEN SEC   11  034430
2013    54    076D  FC07003E             STA      0,,PANEL_COUNT                                   11  034440
2014    60    076F  9E10  (0090)         CLA      0,,KAL_STA_FLG  HAS PP FINISHED OS STATIONS      11  034450
2015    64    0770  D062  (0773)         BRE      $21                                              11  034460
2016     6R   0771  04000A15             BUC      K_EXIT                                           11  034470
2017     8R   0773  F4AAC084     $21     CLA      10,,N                                            11  034480
2018    16    0775  F42A0087             CLA      2,,COLD_START_MKR                                CF034490
2019    20    0777  D11E  (0796)         BNE      SAVE_RIJ          "IS IT TIME TO INITIALIZE KALMAN?%R034500
2020    22R   0778  8480                 FETM     8,,0              "SET NUMBER OF STATE VECTORS (N) CF034510
                                *                                    "TO 0 (FOR 1 STATE VECTOR)       CF034520
                                *                                    "RESET NO KICK AND STATION CHECK CF034530
                                *                                    "ZERO THE FIRST STATE VECTOR     CF034540
                                *                                    "ZERO THE COVARIANCE MATRIX (P)  CF034550
                                *                                    "                                CF034560
                                *                                    "P44 = .25 MICROSEC/SEC          CF034570
```

```
                                                *                                "P33 = (441.176)**2 / 3 MICROSEC CF034580
                                                *                                "P22 = INITIAL P22               CF034590
                                                *                                "P11 = INITIAL P11               CF034600
 2021    30    0779  7004   (0084)              STA      0,,N                   "THE INITIAL P11 AND P22 ARE THE CF034610
                                                *                                "VALUES FROM KALMAN AT TURN OFF  CF034620
                                                *                                "IF POSITION AND TIME HAVE NOT   CF034630
                                                *                                "YET BEEN INSERTED.  THEY ARE    CF034640
                                                *                                "0.5 N MILE IF TIME HAS BEEN     CF034650
                                                *                                "INSERTED (NOT OLD TIME ACCEPTED)CF034660
                                                *                                "AND THERE IS NO POSITION INSERT CF034670
                                                *                                "YET.  THEY ARE THE INSERTED     CF034680
                                                *                                "QUALITY IF POSITION HAS BEEN    CF034690
                                                *                                "INSERTED                        CF034700
 2022    52    077A  F4371C27                    PTR      3,,X                   ZERO X1,X2,X3,X4                 CF034710
 2023    78    077C  F4471CE8                    PTR      4,,XXXX                ZERO X5,X6,X7,X8,X9              CF034720
 2024    82    077E  FCC900A0                    CLAM     12,,160                                                 CF034730
 2025    86    0780  8800                        SUBD     0,0                                                     CF034740
 2026   10R    0781  7880                  $3    STAD     IX11,13                                                 % 034750
 2027    18    0782  CCB2   (0781)              BXUD     11,,$3                                                  % 034760
 2028    8R    0783  9EF7   (00F7)              CLAD     0,,=DF((.25)*.25D-128+36)                               CF034770
 2029    20    0784  F8071D53                    STAD     0,,P44                                                  CF034780
 2030    30    0786  FC0A0C38                    CLAD     0,,NOISE+2                                              CF034790
 2031    42    0788  F8071D3F                    STAD     0,,P33                                                  CF034800
 2032   22R    078A  F82C1F96              $10   FETD     2,,SAVE_POSITION_VARIANCES                              % 034810
 2033    36    078C  F80C1AA6                    FETD       0,,=DF(5*6076*5*6076/2.0D5D7/2.0D5D78-8)              CF034820
 2034   14R    078E  FC071D00              $11   PTRD     0,,SIGMA_SQ_KICK                                        CF034830
 2035    28    0790  FC071D17                    PTRD     0,,P11           "SET KALMAN STARTED MARKER WHICH CF034840
 2036    42    0792  FC071D2B                    PTRD     0,,P22           "   RESETS THE INITIALIZE MARKER CF034850
 2037    52    0794  F0D70087                    STA      13,,COLD_START_MKR       NOT ZERO                    CF034860
 2038   54R    0796  F8AC1F69              SAVE_RIJ FETD    10,,RIJ          "SAVE THE RIJ POSITION MATRIX NOWCF034870
 2039   108    0798  FCA71CD5                    PTRD     10,,BI           "TO ESTABLISH THE CURRENT OMEGA  CF034880
 2040   138    079A  F84C1F75                    FETD     4,,RIJ+12        "POSITION FOR KALMAN COMPUTATIONSCF034890
 2041   168    079C  FC471CE1                    PTRD     4,,BI+12                                                CF034900
                                                *                                                                 034910
                                                * COMPUTE THE OFF DIAGONAL AND                                   *H034920
                                                * NON-UNITY DIAGONAL ELEMENTS                                    *H034930
                                                * OF THE PHI MATRIX AND COMPUTE                                  *H034940
                                                * THE R MATRIX                                                   *H034950
                                                * NOTE - THERE IS SPACE FOR 14                                   *H034960
                                                *        ITEMS IN PHI MATRIX                                    *H034970
 2042    4R    079E  FCD90060              COMPUTE_PHI CLAM  13,,PHI_MATRIX+4                                     CF034980
 2043    8     07A0  FCB90052                    CLAM     11,,R_MATRIX+8                                          CF034990
 2044    16    07A2  F4AA1F8E                    CLA      10,,NAV_MODE                                            CF035000
```

```
2045      48          07A4  84D0                FETM    13,,0           "SET FIRST 7 ITEMS IN PHI TO ZEROCF035010
2046     110          07A5  FCC7005C              PTRD    12,,PHI_MATRIX                               CF035020
2047     120          07A7  FC0A1AA8              CLAD    0,,=DF((((108-18)*.408D+6)*2)/360)           CF035030
2048     130          07A9  790C                  STAD    X13,,12         "9TH ITEM = PHI 3,4          CF035040
2049     140          07AA  FC0A1AAA              CLAD    0,,=DF((10)/2.0950+78-16)                    CF035050
2050     150          07AC  7900                  STAD    X13,,0          "3RD ITEM = PHI 1,8          CF035060
2051     160          07AD  79DA                  STAD    X13,,10         "8TH ITEM = PHI 2,9          CF035070
2052     170          07AE  FC0A1AAC              CLAD    0,,=DF(108-7)   DELTA T                      CF035080
2053     174          07B0  AC60                  CLAD    6,0                                          CF035090
2054     176          07B1  94DE                  ADDM    13,,14                                       CF035100
2055     196          07B2  F9A60C24              MPYD    X10,,BETA_NRA                                CF035110
2056     206          07B4  79D6                  STAD    X13,,6          "13TH ITEM = PHI 8,8         CF035120
2057     216          07B5  79D8                  STAD    X13,,8          "14TH ITEM = PHI 9,9         CF035130
2058     226          07B6  F9AA0C2A              CLSD    X10,,SIGMA_NRA          SIGMA V              CF035140
2059     236          07B8  F8047FFF              MPYDM   0,,X(7FFF)                                   CF035150
2060     254          07BA  69D6                  MPYD    X13,,6          BETA                         CF035160
2061     266          07BB  C031                  FET     3,1                                          HH035170
2062     288          07BC  FC270058              PTRD    2,,R_MATRIX+14  R8,R9                        HH035180
2063     320          07BE  84D0                  FETM    13,0                                         HH035190
2064     382          07BF  F4D7004A              PTR     13,,R_MATRIX    0 R1-R7                      HH035200
2065                                  TIME_UPDATE_P;                            55700                  CF035210
2065      8R          07C1  F4080012              FETM    0,,18           "SET UP POINTERS FOR P MATRIX CF035220
2066      14          07C3  8402                  FETM    0,,2                                         CF035230
                                    *                                     "START P UPDATE"             *I035240
2067      22  *       07C4  F80D08A6              BSV     PHI_P_PHIT      "COMPUTE (K) = (P)*(PHI)TRANSPOSECF035250
2068      28          07C6  8402                  FETM    0,,2            "SET UP POINTERS FOR K TRANSPOSE CF035260
2069      36          07C7  F4080012              FETM    0,,18                                        CF035270
                                    *                                     "FINISH P UPDATE"            *I035280
2070      44  *       07C9  F80D08A6              BSV     PHI_P_PHIT      "P = (K)TRANSPOSE *(PHI)TRANSPOSECF035290
2071      52  *       07CB  F80D08D6              BSV     P_SYM           "MAKE P SYMETRIC             CF035300
2072      66          07CD  F4380010              FETM    3,,16           "UPDATE P WITH NOISE MATRIX R CF035310
2073      70          07CF  FC491D17              CLAM    4,,P_MATRIX     "P(I,I) = P(I,I) + R(I), I = 1, 9CF035320
2074     10R          07D1  FD2A004A          $1  CLAD    X2,,R_MATRIX                                 % 035330
2075      18          07D3  8E04                  ADDD    I0,4                                         CF035340
2076      28          07D4  7A04                  STAD    I0,4                                         CF035350
2077      32          07D5  F4490014              ADDM    4,,20                                        CF035360
2078      40          07D7  CC27   (07D1)         BXUD    2,,$1                                        % 035370
2079     10R          07D8  FC0A1D17              CLAD    0,,P_MATRIX     "SAVE UPDATED P11, P22 FOR USE BY%S035380
2080      20          07DA  FC2A1D28              CLAD    2,,P_MATRIX+20 "SYSTEM FOR KALMAN INITIALIZATIONCF035390
                                    *                                     "IF THERE IS A POWER DROPOUT NOW CF035400
                                    *                                     "AND FOR DISPLAY             CF035410
2081      42          07DC  FC271F96              PTRD    2,,SAVE_POSITION_VARIANCES                   CF035420
                                  * TIME UPDATE STATE VECTORS (X)                                      *H035430
```

```
2082                    TIME_UPDATE_X;                                                                  CF035440
2082    20R     07DE  8471                    FETM    7,,1                                             CF035450
2083    28      07DF  F45A0084                CLA     5,,N      "SET UP TO CYCLE N STATE VECTORS       CF035460
2084    50      07E1  8480                    FETM    8,,0                                             CF035470
2085    92      07E2  F4871C1E                PTR     8,,XXX    "SET AVERAGE VECTOR (XXX) TO 0         CF035480
2086    96      07E4  FC891CED                CLAM    8,,XX                                            CF035490
2087   100      07E6  FC391C27                CLAM    3,,X                                             CF035500
2088    6R      07E8  8409            $6      FETM    0,,9      NOT USED                               CF035510
2089    12      07E9  8401                    FETM    0,,1                                             CF035520
2090    18      07EA  C005                    FET     0,5       "SET ARGUMENTS FOR ASSEMBLE XX         CF035530
2091    26  *   07EB  F80D08A0                BSV     ASSEMBLE_XX "PUT NEXT STATE VECTOR TOGETHER     CF035540.
2092    34      07ED  F4081CED                FETM    0,,XX                                            % 035550
2093    62      07EF  8480                    FETM    11,,0                                            % 035560
                      *                                           "UPDATE STATE VECTOR X"              *I035570
2094    70  *   07F0  F80D08A9                BSV     PHI_P_PHIT$6 "X = PHI * X                       CF035580
2095    78      07F2  8541                    FETM    X4,,1                                            CF035590
2096    86      07F3  867F    (00FF)          FET     0,,XXX_ADD                                       CF035600
2097    92      07F4  C00A                    FET     0,10        XX                                   CF035610
2098   112      07F5  C230                    FET     I3,0                                             CF035620
2099   132      07F6  763A                    PTR     I3,10     "SAVE UPDATED X                        CF035630
                      *                                           "UPDATE AVERAGE VECTOR XXX           *I035640
2100   140  *   07F7  F80D0B30                BSV     AVERAGE_X "AND SCATTER X2XX                     CF035650
2101   142      07F9  9434                    ADDM    3,,4                                             % 035660
                      *                                           "ARE THERE MORE                      *I035670
2102   150      07FA  C543    (07E8)          BXU     4,,$6     "STATE VECTORS TO UPDATE?"             CF035680
2103    4R      07FB  AC80            $3      CLAD    8,0                                              % 035690
2104    12      07FC  F56A1C1E                CLA     X6,,XXX   "RESCALE XXX(1) AND XXX(2)            CF035700
2105    14      07FE  9C10                    CLAM    1,,0      "TO RAD 80 FOR DELTA THETA 2, 3        CF035710
2106    24      07FF  F8040800                RSAD    0,,4        2**0 RAD                             CF035720
2107    8R      0801  C467    (07FB)          BXU     6,,$3     "                                      % 035730
2108    14R     0802  F80C1CF6                FETD    0,,X2XX   "SUM 1ST 2 TERMS OF SCATTER          CF035740
2109    16      0804  B401                    ADD     0,1       "VECTOR X2XX TO GET ESTIMATE OF        CF035750
                      *                                           "POSITION VARIATIONS BETWEEN         CF035760
                      *                                           "STATE VECTORS                       CF035770
2110    22      0805  9A59    (0009)          COM     0,,HX0010 (4.76 MI)**2                           CF035780
2111    32      0806  D710                    PRN     1                                                CF035790
                      *                                           "DOES THE"                           *2035800
2112    36      0807  D137    (081F)          BRG     $9        "POSITION SCATTER EXCEED"              CF035810
                      *                                           "4.76 N MILES?                       CF035820
2113    4R      0808  A828                    CLSD    2,8       "CORRECT POSITION"                     CF035830
2114    16      0809  C823                    FETD    2,3       "DELTA THETA 3 = - XXX(1)              CF035840
2115    20      080A  AC60                    CLAD    6,0       "DELTA THETA 2 =   XXX(2)              CF035850
2116    24      080B  AC42                    CLAD    4,2       "                                      CF035860
```

```
                                        *                                   "STORE DELTA THETA'S FOR RIJ UP- CF035870
                                        *                                   "DATE TO CORRECT PRESENT POSITIONCF035880
2117      46          080C  FC271F28            PTRD    2,,DELTA_THETA_2                                CF035890
2118      56          080E  F4181CD5            FETM    1,,BI                                           CF035900
2119      58          0810  A401               CLA     0,1                                             CF035910
                                        *                                   "APPLY CORRECTIONS TO POSITION  *I035920
2120      66  *       0811  F80D0743           BSV     ROTATE_RIJS         "KALMAN SAVED AT START OF CYCLE CF035930
2121      80          0813  F4381C27           FETM    3,,X                                            % 035940
2122       6R         0815  A603       $7      CLA     I0,3                "DELETE CORRECTION JUST APPLIED CF035950
2123      14          0816  F00B1C1E           SUB     0,,XXX              "TO POSITION FROM ALL STATE     CF035960
2124      22          0818  7203               STA     I0,3                "VECTORS                        CF035970
2125      28          081S  A531               CLA     X3,1                "X(N)1 = X(N)1 - XXX1           CF035980
2126      36          081A  F0081C1F           SUB     0,,XXX+1            "X(N)2 = X(N)2 - XXX2           CF035990
2127      44          081C  7131               STA     X3,1                                            CF036000
2128      46          081D  9434               ADDM    3,,4                                            CF036010
                                        *                                   "ARE THERE MORE                 *I036020
2129      54          081E  C44A    (0815)     BXU     4,,$7               "VECTORS TO CORRECT?"           CF036030
2130       8R         081F  F44A1F8E     $9    CLA     4,,NAV_MODE                                         CF036040
2131      16          0821  F45AC0C2           CLA     5,,PSI_A                                        CF036050
2132      24          0823  F47A008F           CLA     7,,PSI_A_SAVE                                   CF036060
2133      34          0825  F057C08F           STA     5,,PSI_A_SAVE                                   CF036070
2134      36          0827  B075               SUB     7,5                 OLD - NEW                   CF036080
2135      42          0828  9E39    (0089)     CLA     0,,DELTA_V2                                     CF036090
2136      46          0829  B811               SUBD    1,1                                             CF036100
2137      66          082A  F8060074           MPYD    0,,PHI_MATRIX+24        DECAY DELTA V2          CF036110
2138      76          082C  FC0B1D04           ADDD    0,,RES2             "DECAY DELTA V2, DELTA V3   CF036120
2139      86          082E  F0171D05           STA     1,,RES2+1                                       CF036130
2140      94          0830  F41A00BA           CLA     1,,DELTA_V3                                     CF036140
2141     114          0832  F8160C74           MPYD    1,,PHI_MATRIX+24        DECAY DELTA V3          CF036150
2142     124          0834  FC1B1D02           ADDD    1,,RES3                                         CF036160
2143     134          0836  F0271D03           STA     2,,RES3+1                                       CF036170
2144     140          0838  9639    (0089)     ADD     0,,DELTA_V2                                     CF036180
2145     148          0839  F41B00BA           ADD     1,,DELTA_V3                                     CF036190
2146     156          083B  F0081C25           SUB     0,,XXX+7                                        CF036200
2147     164          083D  F01B1C26           SUB     1,,XXX+8                                        CF036210
2148     166          083F  9840               COMM    4,,0                                            CF036220
2149     170          0840  D016    (0847)     BNE     $10                 "IS THE NAV MODE NO RATE AIDING? %R036230
2150       8R         0841  C808               FETD    0,8                                             % 036240
                                        *                                   "ROTATE DELTA V2,3 THROUGH HEAD-*I036250
2151      16  *       0842  F80D06E4           BSV     RESOLVE+1           "ING CHANGE IN LAST 10 SECONDS  CF036260
2152      20          0844  9F33               CLAM    IX3,3               V2 AT 2**12 FPS                 % 036270
2153      22          0845  A412               CLA     1,2                                             % 036280
2154      24          0846  B412               ADD     1,2                 V3 AT 2**12 FPS                 % 036290
```

```
                                *                                "DO NOT PERMIT VEL PROC TO CHANGE*I036300
2155      2R    0847  DF00      $10       LGC     INTERRUPT_INHIBIT   "MODE BEFORE DELTA V UPDATE CF036310
2156      10    0848  F0481F8E            COM     4,,NAV_MODE                                % 036320
                                *                                "HAS THE NAV MODE          *2036330
2157      14    084A  D011  (084C)        BNE     $11               "CHANGED SINCE THE DECAY OF DELTACF036340
                                *                                "V STARTED?                CF036350
2158      10R   084B  7839  (0089)        STAD    0,,DELTA_V2       "SAVE NEW DELTA V'S        CF036360
2159      4R    084C  B800      $11       SUBD    0,0               "SET DELTA V ELEMENTS (8,9) = 0 CF036370
2160      6     084D  DF10              LGC     INTERRUPT_INHIBIT+NE   "ALLOW INTERRUPTS"     CF036380
2161      24    084E  F02C1C22            FET     2,,XXX+4          "SAVE ELEMENTS 5, 6 AND 7 FROM CF036390
2162      50    0850  F4471CE8            PTR     4,,XXXX           "THE AVERAGE STATE VECTOR  CF036400
2163      8R    0852  F40A1D06  $52       CLA     0,,P44_INC_RATE                            CF036410
2164      12    0854  F409199A            ADDM    0,,F(-2)          "INCREMENT P44 NOISE TERM WITH CF036420
                                *                                "P44 NOISE RATE WHICH IS TOO CF036430
                                *                                "SMALL TO CAUSE A CHANGE TO P44 CF036440
                                *                                "EVERY 10 SECONDS          CF036450
2165      22    0856  F0071D06            STA     0,,P44_INC_RATE     NOISE FOR T ZERO DOT VAR CF036460
2166      26    0858  D075  (085E)        BNO     $53               "DID NOISE TERM OVERFLOW?" %R036470
2167      8R    0859  8411              FETM    1,1               "INCREMENT P44 BY 1*2**-31 (1BIT)CF036480
2168      18    085A  FC0B1D53            ADDD    0,,P44                                     CF036490
2169      32    085C  FC071D53            PTRD    0,,P44                                     CF036500
2170      4R    085E  FC591D17  $53       CLAM    5,,P11            "THE POSITION AND T ZERO VARIAN- CF036510
2171      6     0860  A445                CLA     4,5               "CES COULD OVERFLOW DUE TO VERY  CF036520
2172      8     0861  9C34                CLAM    3,4               "LONG PERIODS WITH NO MEASUREMENTCF036530
2173      10    0862  9C20                CLAM    2,0               "                          CF036540
                                *                                "DECAY APPROPIATE ROWS AND COL- CF036550
                                *                                "UMNS IF P11, P22 OR P33 ARE    CF036560
                                *                                "OVER THEIR RESPECTIVE LIMITS   CF036570
2174      8R    0863  AF25      $56       CLAD    IX2,5                                      % 036580
2175      18    0864  F928CC3D            COMD    X2,,DATA_TABLE                             CF036590
2176      22    0866  D04F  (0876)        BLE     $54                                        % 036600
2177      8R    0867  8724              FETM    IX2,4                                      CF036610
2178      22    0868  F4380010            FETM    3,,16                                      CF036620
2179      8R    086A  AF2A      $55       CLAD    IX2,10                                     % 036630
2180      18    086B  F8047800            MPYDM   0,,X(7800)                                 CF036640
2181      28    086D  782A                STAD    IX2,10                                     CF036650
2182      36    086E  AE04                CLAD    I0,4                                       CF036660
2183      46    086F  F8047800            MPYDM   0,,X(7800)                                 CF036670
2184      56    0871  7A04                STAD    I0,4                                       CF036680
2185      60    0872  F4490012            ADDM    4,,18                                      CF036690
2186      68    0874  CC2B  (086A)        BXUD    2,,$55                                     % 036700
2187      16R   0875  D740                PRN     4                                          CF036710
2188      4R    0876  F4590012  $54       ADDM    5,,18                                      % 036720
```

```
2189    12      0878  CD26  (0863)          BXUD    2,,$56                                  % 036730
2190    32R     0879  D7C0                  PRN     12              "CORRECT SYNC TIME"     %S036740
2191    44      087A  8431                  FETM    3,,1            "                       CF036750
2192    52      0878  F40A1C21              CLA     0,,XXX+3        "FORM INTEGRAL OF T ZERO DOT WITHCF036760
                                    *                               "RESPECT TO TIME SCALED AT 2.5  CF036770
                                    *                               "MILLISECONDS SO THAT AN OVERFLOWCF036780
                                    *                               "WILL OCCUR AT 2.5 MSEC AND EVERYCF036790
                                    *                               "5 MSEC THEREAFTER.             CF036800
                                    *                               "SET CLOCK CHANGE TO + 5 MSEC FORCF036810
                                    *                               "A SLOW CLOCK                   CF036820
2193    72      087D  F8061AAE              MPYD    0,,=DF((10)/2.58+18D-3)                 CF036830
2194    82      087F  FC08000E              ADDD    0,,SUM_T_ZERO_DOT                       CF036840
2195    96      0881  FC07000E              PTRD    0,,SUM_T_ZERO_DOT                       CF036850
                                    *                               "IS IT TIME TO          *2036860
2196    100     0883  D073  (0887)          BNO     $20             "MAKE A CORRECTION TO THE"  %R036870
                                    *                               "COMPUTER CLOCK?        CF036880
2197    4R      0884  D051  (0886)          BRL     $21             "IS THE COMPUTER CLOCK TO SLOW? CF036890
2198    4R      0885  A800                  CLSD    0,0             "CHANGE CORRECTION TO MINUS     CF036900
                                    *                               "5 MILLISECONDS"        CF036910
2199    10R     0886  7828  (00A8)  $21     STAD    0,,TIME_INC     "SAVE CLOCK CHANGE FOR APPLICA- CF036920
                                    *                               "TION TO TIME IN END SLOT ROUTINECF036930
2200    22R     0887  D770            $20     PRN     7               "ADJUST R15 STACK"      CF036940
```

```
                                **                                                                  CF036950
                                * SELECT MEASUREMENT TYPE - TAKE                                    *H036960
                                * POSITION FIX IF AVAILABLE                                        *H036970
                                * OTHERWISE TRY FOR A TRACKING                                     *H036980
                                * FILTER MEASUREMENT                                               *H036990
2201                            SELECT_MEASUREMENT;                                                 CF037000
2201     2R     0888  DEAD                  FLG      BT+B+EOR      "SET PROGRAM FLAG B FALSE TO NOTECF037010
                                *                                    "THAT SYSTEM HAS NOT JUST KICKED CF037020
                                *                                    "OPEN ON A POSITION FIXPOINT     CF037030
2202     32R    0889  84D0            $1        FETM     13,,0                                       % 037040
                                *                                    "SET M3,4,5,6,7,8,9 = 0          CF037050
                                *                                    "   (M MATRIX)                   CF037060
                                *                                    "SET E3,4,5,6,7,8,9 = 0          CF037070
                                *                                    "   (DIVERGENCE CONTROL)         CF037080
2203     94     088A  FCC7004E                PTRD     12,,M_MATRIX+4   ZERO M3,4,5,6,7,8,9          CF037090
2204     126    088C  84D0                    FETM     13,,0                                         CF037100
2205     188    088D  FCC70060                PTRD     12,,DIVERGENCE_CONTROL+4 ZERO E3,4,5,6,7,8,9  CF037110
2206     194    088F  9E26   (00A6)          CLA      0,,PC_INSERT                                  CF037120
2207     196    0890  DE10                    FLG      NE+A+UCD      "SET PROGRAM FLAG A TRUE FOR A  %S037130
                                *                                    "POSITION FIX AND FALSE FOR A    CF037140
                                *                                    "TRACKING FILTER MEASUREMENT     CF037150
                                *                                    "IS THIS A                       *1037160
2208     200    0891  D263   (0885)          BRE      TRACKING_FILTER_MEASUREMENT   "POSITION FIX?"  %R037170
2209                            POSITION_MEASUREMENT;                    36600                      CF037180
2209     2R     0892  DECE                    FLG      CT+C+EOR      "RESET PROGRAM FLAG C WHICH IS   CF037190
                                *                                    "USED TO COUNT THE 2 MEASUREMENTSCF037200
                                *                                    "(NORTH AND EAST ERRORS)         CF037210
2210     32     0893  F84C1CD1                FETD     4,,ERROR_NORTH "SET UP SETS OF ARGUMENTS FOR TWOCF037220
2211     54     0895  F82C1F92                FETD     2,,COS_THETA_P "MEASUREMENTS                  CF037230
2212     62     0897  C807                    FETD     0,7           "FIRST = ERROR EAST, COS THETA P,CF037240
2213     66     0898  AC84                    CLAD     8,4           "        -SIN THETA P            CF037250
2214     70     0899  ACA2                    CLAD     10,2          "SECOND = ERROR NORTH, SIN THETA CF037260
2215     74     089A  A844                    CLSD     4,4           "         P, COS THETA P         CF037270
2216     14R    0898  FC070074          $1    PTRD     0%,,MEASUREMENT "SET MEASUREMENT = ERROR      CF037280
2217     36     089D  FC27004A                PTRD     2,,M_MATRIX   "SET M1 = 2ND ARGUMENT          CF037290
                                *                                    "    M2 = 3RD ARGUMENT           CF037300
2218     48     089F  8681   (0081)          FETD     0,,POSITION_NOISE     2**-6                   CF037310
2219     56     08A0  C801                    FETD     0,1           "SET MEASUREMENT VARIANCE       CF037320
                                *                                    "    = INSERTED POSITION QUALITY CF037330
                                *                                    "SET E1 = E2 =  POSITION QUALITY CF037340
2220     68     08A1  F8070072                STAD     0,,MEASUREMENT_VARIANCE                       CF037350
2221     90     08A3  FC27005C                PTRD     2,,DIVERGENCE_CONTROL     E 1,2   2**-8       CF037360
2222     92     08A5  DED2                    FLG      CF+C+UCD      "CHANGE STATE OF FLAG C - GOES  CF037370
```

```
                                                *                                                "TRUE IF 1ST MEAS OTHERWISE FALSECF037380
2223      100  *      08A6  F80D0A1E                        BSV       COMPUTE_BI_AND_C          "START MEASUREMENT PROCESSINGCF037390
2224      108  *      08A8  F80D0A64                        BSV       MEASUREMENT_UPDATE_X      "COMPLETE MEASUREMENT      CF037400
                                                * MEASUREMENT UPDATE X ROUTINE                                              *H037410
                                                * RETURNS HERE ONLY IF A STATE                                             *H037420
                                                * VECTOR WAS UPDATED.                                                      *H037430
                                                * IF THE MEASUREMENT RESULTED                                              *H037440
                                                * IN NO STATE VECTORS THEN THE                                             *H037450
                                                * RETURN SKIPS ONE BOX IN THE                                              *H037460
                                                * PROGRAM FLOW.                                                            *H037470
                                                *                                                "MEASUREMENT PROCESSED"    CF037480
2225      114          08AA  0400C8B0                      2BUC      $2                        "SUCCESSFULLY"             CF037490
2226       2R          08AC  DE01                           FLG       UC+B+UCD                  "MEASUREMENT UNSUCCESSFUL" CF037500
                                                *                                                "THE POSITION VARIANCES HAVE BEENCF037510
                                                *                                                "KICKED OPEN.              CF037520
                                                *                                                "SET FLAG 8 TRUE TO BYPASS THE 36CF037530
                                                *                                                "MILE LIMIT ON STATE VECTOR POSI-CF037540
                                                *                                                "TION ERRORS.              CF037550
                                                *                                                "IS THIS THE               *1037560
2227       6           08AD  D9DC   (0892)                  BCF       POSITION_MEASUREMENT      "SECOND MEASUREMENT?"      CF037570
2228      18R          08AE  D750                           PRN       5                         "DELETE THE ARGUMENTS FOR THE CF037580
                                                *                                                "2ND MEASUREMENT AND TRY THE CF037590
                                                *                                                "1ST MEASUREMENT AGAIN     CF037600
2229      22           08AF  D90E   (0892)                  BUC       POSITION_MEASUREMENT      "                          CF037610
                                                *                                                "IS THERE ONE              *1037620
2230       4R          08B0  D9C6   (089B)     $2           BCT       $1                        "MORE MEASUREMENT TO PROCESS? CF037630
2231      30R          08B1  84C0                           FETM      12,,0                     "RESET THE POSITION FIX MARKER CF037640
                                                *                                                "                          CF037650
2232      38           08B2  7026   (00A6)                 STA       0,,PC_INSERT                                          037660
2233      44           08B3  04000A15                       BUC       K_EXIT                                               CF037670
```

```
                                    **                                                                  037680
                                    * LOOK FOR MEASUREMENT FROM 1 OR                                    *H037690
                                    * MORE FILTERS FOR ANY STATION                                      *H037700
2234                                TRACKING_FILTER_MEASUREMENT;            23300                       CF037710
2234      8R    08B5  8417                      FETM      1,,OS-1     "SET UP COUNTER TO CONTROL SEARCHCF037720
                                    *                                   "FOR MEASUREMENTS STARTING WITH  CF037730
                                    *                                   "STATION USED LAST               CF037740
2235      6R    08B6  9E36  (00B6)  $100        CLA       0,,STATION_NUMBER                             % 037750
2236     24     08B7  8462                      FETM      6,,2                                          CF037760
2237     34     08B8  F067006F                  STA       6,,DF_MKR   "SET DIFFERENCY FREQUENCY MARKER CF037770
                                    *                                   "                                *2037780
2238      8R    08BA  C470  (08BB)  $13         BXU       7,,$5       "INCREMENT STATION COUNTER       %R037790
                                    *                                   "RESET TO A IF E                 CF037800
2239     10R    08BB  FC0A1D3F      $5          CLAD      0,,P33      "COMPUTE X = (T ZERO)*(N MILE/CY)CF037810
                                    *                                   "          * (CY/MSEC)           CF037820
2240     30     08BD  F8061AB0                  MPYD        0,,=DF(72*72*6076*6076/2.095/2.095D14B-8)   CF037830
2241     34     08BF  D0D1  (08C1)              BCF       $85         "PHASE DIFFERENCE?"              %R037840
2242      4R    08C0  8800                      SUBD      0,0         "SET X = 0                       CF037850
2243     10R    08C1  FC081D17      $85         ADDD      0,,P11      "COMPUTE Y = P11 + X             CF037860
2244     14     08C3  D071  (08C5)              BNO       $63         "DID Y OVERFLOW?"                %R037870
2245      4R    08C4  D00A  (08CF)              BUC       $1          "DIFFERENCE FREQ REQUIRED        CF037880
2246     10R    08C5  FC081D2B      $63         ADDD      0,,P22      "COMPUTE Z = P22 + Y             CF037890
2247     14     08C7  D071  (08C9)              BNO       $12         "DID Z OVERFLOW?"                %R037900
2248      4R    08C8  D006  (08CF)              BUC       $1          "DIFFERENCE FREQ REQUIRED        CF037910
2249     10R    08C9  F8081AB2      $12         COMD        0,,=DF(4*6076*4*6076/2.095D+7/2.095D+7B-8)  CF037920
                                    *                                   "CHECK SIZE OF Z                 CF037930
2250     14     08CB  D023  (08CF)              BGE       $1          "IS Z GREATER THAN 4 N MILE?     CF037940
2251     10R    08CC  F057006F                  STA       5,,DF_MKR   "ERROR'S ARE SMALL"               CF037950
2252     12     08CE  9041                      SUBM      4,,1        "RESET DIFF FREQ MARKER"         CF037960
2253      2R    08CF  9442          $1          ADDM      4,,2        "NUMBER OF FREQ NEEDED FOR MEAS  CF037970
2254      4     08D0  9C33                      CLAM      3,,3        "= 2 IF DIFF FREQ OTHERWISE = 1  CF037980
2255      8     08D1  6437                      MPI       3,7                                          CF037990
2256     10     08D2  A423                      CLA       2,3                                          CF038000
2257     14     08D3  F4391D88                  ADDM      3,,SIGMA_SQ_N_COUNTER                        CF038010
2258      6R    08D5  9E65  (00E5)  $3          CLA       0,,STATIONS_IN_USE                           CF038020
                                    *                                   "EXAMINE STATIONS ENABLED BY     CF038030
                                    *                                   "THE OPERATOR                    CF038040
2259     14     08D6  E57000D5                  EXT       X7,0,POWERS_OF_TWO 1=A 2=B 4=C 8=D           CF038050
2260     18     08D8  D066  (08DF)              BRE       $2          "IS THIS STATION DISABLED?       CF038060
2261      6R    08D9  A753                      CLA       IX5,3       "EXAMINE TRACKING FILTER N       CF038070
2262     14     08DA  E400010F                  EXT       0,0,HX00FF  "COUNTER FOR THIS STATION / FREQ CF038080
2263     16     08DC  98C3                      COMM      0,,3                                         CF038090
                                    *                                   "IS THERE A                      *2038100
```

```
2264    20    08DD  D051  (08DF)          BRL   $2          "MEASUREMENT AVAILABLE FROM THIS %R038110
                          *                                 "FILTER? (N = 3)                 CF038120
2265     2R   08DE  9041                  SUBM  4,,1        "DECREMENT NO. OF FREQ STILL     CF038130
                          *                                 "NEEDED FOR A MEAS BY 1          CF038140
2266     8R   08DF  C458  (08D5)  $2      BXU   5,,$3       "ARE THERE MORE FREQUENCIES?     CF038150
2267     2R   08E0  9840                  COMM  4,,0                                         % 038160
                          *                                 "ARE THERE ENOUGH                *2038170
2268     6    08E1  D033  (08E5)          BRG   $28         "FREQ'S AVAILABLE FROM THIS      %R038180
                          *                                 "STATION?                        CF038190
2269     8R   08E2  861F  (009F)          FET   0,,C_I_STATUS_IMAGE                          038200
2270    16    08E3  D700                  PRN   0           "SIGNAL LOSS OFF                 *1038210
2271    20    08E4  D067  (08EC)          BRE   $4          "ACCEPT MEASUREMENT IF YES         038220
2272     2R   08E5  9C40                  CLAM  4,,0        "NO MEASUREMENT FROM THIS STATIONCF038230
2273    10    08E6  FC7800B6              COM   7,,STATION_NUMBER                            CF038240
2274    14    08E8  DA1F  (08BA)          BNE   $13         "HAVE ALL STATIONS BEEN EXAMINED?%R038250
2275    12R   08E9  8430                  FETM  3,,0                                         % 038260
2276    18    08EA  04000A15              BUC   K_EXIT      "NO MEASUREMENTS THIS TIME       CF038270
                          * THERE IS A MEASUREMENT AVAILABLE                                 *H038280
2277    12R   08EC  C828                  $4    FETD  2,8   MAKE REG AVAIL REP. STAT NO      CF038290
2278    22    08ED  FC2700B6              STA   2,,STATION_NUMBER                            CF038300
                          *                                 "SAVE NUMBER OF THIS STATION     CF038310
2279    32    08EF  FF89006F              CLAM  IX8,,DF_MKR ADDRESS-DR MKR + NO OF FREQ      CF038320
2280    34    08F1  9801                  COMM  0,,1                                         CF038330
                          *                                 "ARE THERE 3 FREQ                *2038340
2281    38    08F2  D01F  (0902)          BNE   $71         "AVAILABLE AND IS DIFF FREQ      %R038350
                          *                                 "MARKER TRUE?                    CF038360
                          *                                 "THERE IS AN EXTRA FREQ AVAILABLECF038370
                          *                                 "READ COUNTER FOR THIS STATION   CF038380
                          *                                 "THAT DEFINES OPTIMUM FREQ PAIR  CF038390
                          *                                 "THE COUNTER CYCLES BETWEEN 11-10CF038400
                          *                                 "11-13 AND 13-10.  IT IS RESET TOCF038410
2282     8R   08F3  F52A1D07              CLA   X2,,DF_COUNTER "11-10 WHEN NOT IN DIFF FREQ    CF038420
                          *                                 "                                CF038430
                          *                                 "SET THE N COUNTER OF THE FREQ   CF038440
                          *                                 "THAT IS NOT TO BE USED TO ZERO  CF038450
2283    10    08F5  9001                  SUBM  0,,1        DF CNT = 0 GOES TO -1  ZERO 13   CF038460
2284    14    08F6  F809FFFD              COMM  0,,I(-3)    DF CNT =-1 GOES TO -2  ZERO 10   CF038470
2285    18    08F8  D011  (08FA)          BNE   $70         DF CNT =-2 GOES TO  0  ZERO 11     038480
2286     2R   08F9  9C00                  CLAM  0,,0                                         CF038490
2287    10R   08FA  F1271D07      $70     STA   X2,,DF_COUNTER                               % 038500
2288    12    08FC  9402                  ADDM  0,,2        R0 = 1, 0, 2 FOR 13, 10, 11      CF038510
2289    14    08FD  B407                  ADD   0,7                                          CF038520
2290    20    08FE  A610                  CLA   I1,0                                         CF038530
```

```
2291   28   08FF  E411010E          EXT   1,1,HXFF00                                    CF038540
2292   36   0901  7210              STA   I1,0                                          CF038550
2293    2R  0902  B466        $71   ADD   6,6          "CREATE POINTER TO TRACKING     CF038560
                               *                       "FILTER DATA FOR THIS STA/FREQ  CF038570
                               *                       "CREATE SCRATCH STORAGE IN R15  CF038580
2294    6   0903  F0F90022          SUBM  15,,34        "STACK FOR TF DATA FOR 3 FREQ ANDCF038590
                               *                       "SPARE                          CF038600
2295    8   0905  9C80              CLAM  8,,0          RESET INDEX                     CF038610
2296   10R  0906  FD6A1EA3    $7    CLAD  X6,,PHI_ESTIMATE "READ AND SAVE DATA FOR THIS FRCF038620
2297   20   0908  788F              STAD  IX8,15        "PHI ESTIMATE  CYCLES B10       CF038630
2298    2R  0909  9482        $20   ADDM  8,,2                                         % 038640
2299   12   090A  FD6A1E33          CLAD  X6,,SIGMA_SQ_PHI_PHI                          CF038650
2300   22   090C  F8040020          RSAD  0,,10         "SIGMA SQ PHI PHI  CYCLES**2 B10 CF038660
2301   32   090E  788F              STAD  IX8,15        "N COUNT                        CF038670
2302   34   090F  9482              ADDM  8,,2          INC INDEX                       CF038680
2303   40   0910  A607              CLA   I0,7          N COUNT                         CF038690
2304   48   0911  E400010F          EXT   0,0,HX00FF    "TF POINTER                     CF038700
2305   50   0913  A416              CLA   1,6           T.F. OFFSET                     CF038710
2306   60   0914  788F              STAD  IX8,15        "GOOD MEASUREMENT MKR FALSE     CF038720
2307   70   0915  FD6A10D3          CLAD  X6,,SIGMA_SQ_PHI_DOT_PHI_DOT                  CF038730
2308   80   0917  F8081AB4          COMD    0,,=DF(.031*.031D-4*2*3.1415926*3.1415926)  CF038740
                               *                       "IS THE PHASE                   *2038750
2309   84   0919  D033  (091D)      BRG   $41           "RATE VARIANCE LESS THAN .031   %R038760
                               *                       "CEC/SEC?                       CF038770
2310    6R  091A  A78F              CLA   IX8,15                                        CF038780
2311   12   0918  9664  (00E4)      ADD   0,,HX8000     "SET GOOD MEASUREMENT MKR TRUE  CF038790
2312   20   091C  738F              STA   IX8,15                                        CF038800
2313    2R  091D  9482        $41   ADDM  8,,2          INC INDEX                       CF038810
2314    4   091E  9471              ADDM  7,,1          INC N COUNTER ADDRESS           CF038820
2315    6   091F  9462              ADDM  6,,2          "INCREMENT POINTER              CF038830
2316   14   0920  C59B  (0906)      BXU   9,,$7         "ARE THERE MORE FREQ'S TO READ? CF038840
2317    2R  0921  A47F              CLA   7,15                                          CF038850
2318    6   0922  8C99              ADDD  9,9                                           CF038860
2319    8   0923  B48F              ADD   8,15          "SET UP POINTER FOR STATION DATA CF038870
2320   10   0924  8CD1              CLSM  13,,1         MARKER                          CF038880
2321   12   0925  A448              CLA   4,11          "READ STATION NUMBER            CF038890
2322   16   0926  D003  (092A)      BUC   $42                                           CF038900
2323    2R  0927  9488        $43   ADDM  8,,8          "SET UP POINTER FOR BASE DATA   CF038910
2324   10   0928  F44A00CC          CLA   4,,BASE+1     "READ BASE STATION NUMBER       CF038920
2325    4R  092A  FC591CD5    $42   CLAM  5,,BI          "GET POINTER TO SAVED POSITION  CF038930
2326   12   092C  C015              FET   1,5           "MATRIX                         CF038940
2327   16   092D  44C6              MPIM  0,,6          STA POINTER                     CF038950
2328   22   092E  967E  (00FE)      ADD   0,,SV_ADD                                     CF038960
```

```
2329  28        092F  C00A                    FET       0,10                                        CF038970
                                        *                                   "COMPUTE AND SAVE R . S1, R . S2 *I038980
2330  36  *     0930  F80D1707                BSV       MATRIX_3D         "AND R . S3 FOR M MATRIX  CF038990
2331  44        0932  C015                    FET       1,5                                         % 039000
                                        *                                   "COMPUTE"                 *I039010
2332  52  *     0933  F80D0B62                BSV       COMPUTE_THETA1      "PREDICTED CENTRAL ANGLE" CF039020
2333  62        0935  79A0                    STAD      X10,,0                                      % 039030
2334  70  *     0936  F80D1656                BSV       SIN               "SIN THETA 1"             CF039040
2335  82        0938  7DA6                    PTRD      X10,,6                                      % 039050
2336  84        0939  94D1                    ADDM      13,,1                                       % 039060
                                        *                                   "HAS THE BASE             *1039070
2337  88        093A  D964   (0927)           BRE       $43               "DATA BEEN COMPUTED YET?" %R039080
2338   2R       093B  9088                    SUBM      8,,8                                        % 039090
2339  10        093C  AD80                    CLAD      X8,,0             GET ANGLE BACK              039100
2340  14        093D  F8090444                COMM      0,,F(6/180)        NEAR LIMIT               039110
                                        *                                   "                         *2039120
2341  18        093F  D029   (0949)           BGE       $9                "IS THE STATION TOO CLOSE? %R039130
                                        *                                   "(360 N MILE)             CF039140
                                        * UPPER LIMIT OF RANGE TEST IS NEW IN BRN-7                  HH039150
2342   4R       0940  F4F90022          $99   ADDM      15,,34            STATION TOO CLOSE OR TOO FAR CF039160
2343   8        0942  4483                    MPIM      11,,3                                       CF039170
2344  14        0943  FD891D88                CLAM      X11,,SIGMA_SQ_N_COUNTER                     CF039180
2345  24        0945  8420                    FETM      2,,0              "SET N COUNTER AND NUMBER OF CF039190
2346  40        0946  7623                    PTR       I2,3              "KALMAN DUMPS = 0 FOR ALL 3 FREQ CF039200
2347  46        0947  C4000A15                BUC       K_EXIT                                      CF039210
2348   4R       0949  F8095555          $9    COMM      0,,F(120/180)     MAX RANGE = 120 DEGRESS     039220
2349   8        0948  D82C   (0940)           BGE       $99                                         039230
2350   2R       094C  A458                    CLA       5,11              STA NUMBER BASE IN R1     CF039240
                                        *                                   "COMPUTE POINTERS FOR STATION ANDCF039250
2351   8        094D  4C43                    MPIDM     4,,3              "BASE PROPAGATION DATA    CF039260
                                        *                                                           CF039270
                                        *                                                           CF039280
                                        *         REG D = 0001                                      CF039290
                                        *         REG 9 = FREQ  COUNTER (D)                         CF039300
                                        *         REG 8 = POINTER TO R15 STACK  THETA1, R.S2, R.S3, SIN THETA1CF039310
                                        *         REG 7 = POINTER TO R15 STACK  PHI EST, SS, N CNT, TF POINTERCF039320
                                        *         REG 5 = STA  * 3 + FREQ(S) FOR PROP               CF039330
                                        *         REG 4 = BASE * 3 + FREQ(S) FOR PROP               CF039340
                                        *                                                           CF039350
                                        *                                                           CF039360
                                        * START MEASUREMENT LOOP                                    *H039370
2352   4R       094E  FC69004A          $11   CLAM      6,,M_MATRIX       "SET PROGRAM FLAG D TRUE IF THIS CF039380
                                        *                                   "FREQ QUALIFIES AS A GOOD MEAS CF039390
```

```
2353   12   0950 F40A006F          CLA   0,,DF_MKR                                  11 039400
2354   16   0952 D024  (0957)      BGE   $102        IF NOT 2ND FREQ IN DF           11 039410
2355   4R   0953 D0E3  (0957)      BOT   $102        IF 1ST FREQ OK                  11 039420
2356   2R   0954 DEEF              FLG   DT+EOR+D    RESET FLG D                     11 039430
2357   8    0955 A574              CLA   X7,,4                                       11 039440
2358   12   0956 D002  (0959)      BUC   $103                                        11 039450
2359   6R   0957 A574        $102  CLA   X7,,4        READ N COUNTER (THIS FREQ)      11 039460
2360   8    0958 DE53              FLG   L+D          TRUE IF GOOD MEASUREMENT          CF039470
2361   2R   0959 8400        $103  ADD   0,0          DESTROY SIGN                    11 039480
2362   4    095A 9806              COMM  0,,6                                          CF039490
                                 *                   "IS THERE A                       *2039500
2363   10   095B 040509F8          BRL   $10          "MEASUREMENT FROM THIS FREQ?      %R039510
                                 *                   "(N = 3)                          CF039520
                                 * COMPUTE M MATRIX                                  *H039530
2364   2R   095D 9488              ADDM  8,,8         "SET POINTER FOR BASE DATA        CF039540
2365   12R  095E 8430        $46   FETM  3,,0         "SET M1 = M2 = 0                  CF039550
2366   32   095F 763A              PTR   I3,10        ZERO M1, M2                       CF039560
2367   10R  0960 FD9A1682    $45   CLAD  X9,,LAMBDA_TABLE "COMPUTE M1, M2"             CF039570
2368   14   0962 ACB0              CLAD  11,0         "                                 CF039580
2369   22   0963 AD86              CLAD  X8,,6        SIN THETA 1                       CF039590
2370   30   0964 C01C              FET   1,12         LAMBDA                            CF039600
2371   48   0965 69A2              MPYD  X10,,2       S DOT R2                          CF039610
2372   174  0966 DC02              DIVD  0,2          "M1 = (S.R2)*LAMBDA/SIN(THETA 1)  CF039620
2373   182  0967 B980              SUBD  X8,,0        "          - M1                   CF039630
2374   194  0968 7D80              PTRD  X8,,0        M 1                               CF039640
2375   202  0969 C01C              FET   1,12         LAMBDA                            CF039650
2376   220  096A 69A4              MPYD  X10,,4       S DOT R3                          CF039660
2377   346  0968 DC02              DIVD  0,2          "                                 CF039670
2378   354  096C B982              SUBD  X8,,2        "M2 = (S.R3)*LAMBDA/SIN(THETA 1)  CF039680
2379   366  096D 7D82              PTRD  X8,,2        "          - M2                   CF039690
2380   368  096E 9088              SUBM  8,,8         "SET POINTER FOR STATION DATA     %S039700
2381   370  096F 90D1              SUBM  13,,1                                         CF039710
2382   374  0970 D012  (0973)      BNE   $44          "ARE THE M'S COMPLETE?            CF039720
                                 *                   "                                 *2039730
2383   4R   0971 D9C2  (0960)      BCT   $45          "PHASE DIFFERENCE?"               CF039740
                                 *                   "M(STA)- M(BASE)                  CF039750
2384   4R   0972 D905  (095E)      BUC   $46          "RHO-RHO  DON'T NEED BASE M'S     CF039760
2385   2R   0973 9488        $44   ADDM  8,,8                                          CF039770
2386   12   0974 FD9A1722          CLAD  X9,,V_LAMBDA "SET KICK LIMIT = V LAMBDA        CF039780
2387   20   0976 7043  (00C3)      STA   0,,CONNIE_LIMIT                               CF039790
2388   24   0977 D0C1  (0979)      BCT   $47          "PHASE DIFFERENCE?"               CF039800
2389   10R  0978 7964              STAD  X6,,4        "RHO-RHO"                         CF039810
                                 *                   "SET M3 = V LAMBDA                CF039820
```

```
2390      8R    0979  F55A1CA1        $47     CLA     X5,,PROP_C     "READ PROPAGATION VARIANCE        CF039830
                                      *                              "FOR STATION                      CF039840
2391      12    097B  D0D2  (097E)            BCF     $49            "PHASE DIFFERENCE?"               %R039850
2392      8R    097C  F5481CA1                ADD     X4,,PROP_C     "ADD PROPAGATION VARIANCE FOR     CF039860
                                      *                              "BASE STATION                     CF039870
2393      10R   097E  F8040040        $49     RSAD    0,,9           "MEASUREMENT VARIANCE  = PROPAGA-CF039880
                                      *                              "  TION VARIANCE + SIGMA SQ PHI   CF039890
2394      8R    0980  BD72            $48     ADDD    X7,,2                                            % 039900
                                      *                              "          PHI                    CF039910
2395      20    0981  F8070072                STAD    0,,MEASUREMENT_VARIANCE                          CF039920
2396      24    0983  D0DC  (0990)            BCF     $50            "PHASE DIFFERENCE?"               %R039930
2397      2R    0984  8045                    CCM     4,5                                              % 039940
                                      *                              "IS THIS A                        *1039950
2398      6     0985  D01A  (0990)            BNE     $50            "BASE STATION MEASUREMENT?        %R039960
2399      14R   0986  F99C0C43                FETD    X9,,M_4_TABLE  "READ M4 FROM A TABLE            CF039970
2400      26    0988  7D86                    PTRD    X8,,6          "NOTE - M1, M2 WILL BE ZERO       CF039980
                                      *                              "                                 CF039990
                                      *                              "USE PHI DOT DR FROM THE TRACKINGCF040000
                                      *                              "FILTER AS THE 'PREDICTED'        CF040010
                                      *                              "MEASUREMENT REFERENCE            CF040020
2401      34    0989  F40A1F0E                CLA     0,,PHI_DOT_DR_BASE                               CF040030
2402      44    098B  F8040019                MPYDM   0,,F(((10)/4)/3.14159B10) SCALE CYC/SEC B10      CF040040
2403      64    098D  F9961768                MPYD    X9,,TF_LAMBDA_CONSTANT_TABLE CONVERT FROM        CF040050
                                      *                              13.6 TO APPROPIATE FREQ           CF040060
2404      68    098F  D00D  (099D)            BUC     $51                                              CF040070
2405      8R    0990  AD80            $50     CLAD    X8,,0          "GET STATION NO., FREQ AND        CF040080
2406      14    0991  C009                    FET     0,9            "THETA 1 ARGUMENTS FOR THETA C    CF040090
2407      22    0992  8636  (0086)            FET     0,,STATION_NUMBER                                CF040100
                                      *                              "COMPUTE PREDICTED TOTAL PHASE    *I040110
2408      30  * 0993  F80D0847                BSV     THETA_C          "FOR THE STATION                CF040120
2409      34    0995  D0D7  (099D)            BCF     $51            "PHASE DIFFERENCE?                %R040130
2410      12R   0996  C988                    FETD    X8,,8          "GET BASE STATION NO., FREQ AND   CF040140
2411      18    0997  C008                    FET     0,11           "THETA 1 ARGUMENTS FOR THETA C    CF040150
2412      26    0998  864C  (00CC)            FET     0,,BASE+1                                        CF040160
                                      *                              "COMPUTE PREDICTED TOTAL PHASE    *I040170
2413      34  * 0999  F80D0847                BSV     THETA_C          "FOR THE BASE STATION           CF040180
2414      38    099B  B820                    SUBD    2,0            "FORM PREDICTED PHASE DIFFERENCE  CF040190
2415      48    099C  D710                    PRN     1                                                CF040200
2416      12R   099D  C970            $51     FETD    X7,,0          "COMPUTE KALMAN MEASUREMENT       CF040210
2417      16    099E  B802                    SUBD    0,2            "= TRACKING FILTER PHI -          CF040220
2418      24    099F  46DA  (00DA)            MPID    0,,HX0020      "     PREDICTED                   CF040230
2419      38    09A0  FC070074                PTRD    0,,MEASUREMENT 86 PI                            CF040240
2420      54    09A2  6888                    MPYD    11,11          "COMPUTE DIVERGENCE CONTROL E1,2  CF040250
```

```
2421    64          09A3  FC0A0072          CLAD    0,,MEASUREMENT_VARIANCE                                  CF040260
2422   190          09A5  DC08              DIVD    0,11            "= K * MEAS VAR / (LAMBDA)**2            CF040270
2423   210          09A6  F8061AB6          MPYD    0,,=DF(.0625)                                            CF040280
2424   222          09A8  C821              FETD    2,1                                                      CF040290
2425   244          09A9  FC27005C          PTRD    2,,DIVERGENCE_CONTROL E1,2  2**-8                        CF040300
2426   254          09AB  F8040080          RSAD    0,,8                                                     CF040310
2427   270          09AD  C841              FETD    4,1                                                      CF040320
2428   300          09AE  FC470064          PTRD    4,,DIVERGENCE_CONTROL+8  E 5,6,7 2**0                    CF040330
2429   310          09B0  FCBA0072          CLAD    11,,MEASUREMENT_VARIANCE                                 CF040340
2430   320          09B2  FD9A1722          CLAD    X9,,V_LAMBDA                                             CF040350
2431   336          09B4  6800              MPYD    0,0             "                                        CF040360
2432   462          09B5  DCB0              DIVD    11,0            "E3 = K * MEASVAR/(V LAMBDA)**2          CF040370
2433   482          09B6  F8B61AB6          MPYD    11,,=DF(.0625)                                           CF040380
2434   494          09B8  F8870080          STAD    11,,DIVERGENCE_CONTROL+4   E3 2**-18                    CF040390
2435   502          09BA  F40A006F          CLA     0,,DF_MKR                                                CF040400
2436   506          09BC  D163   (09D0)     BRE     $90             "IS KALMAN IN DIFFERENCE FREQ?           %R040410
2437    6R          09BD  04030A08          BRG     $91             "IS THIS THE 1ST FREQ?"                  CF040420
2438    2R          09BF  9CC6              CLAM    12,,6           "SECOND FREQ"                            CF040430
                                      *                             "FORM DIFFERENCES"                       CF040440
2439    4           09C0  9CB0              CLAM    11,,0                                                    CF040450
2440   10R          09C1  FD8A1C06    $94   CLAD    X11,,KAL_TEMP                                            % 040460
2441   18           09C3  B8B6              SUBD    IX11,6          " M = M(2ND) - M(1ST), M1,2,3,4          CF040470
2442   28           09C4  78B6              STAD    IX11,6          " KICK LIMIT = (2ND) - (1ST)             CF040480
                                      *                             " MEAS VAR   = (2ND) + (1ST)             CF040490
                                      *                             " MEASUREMENT = (2ND) - (1ST)            CF040500
2443   36           09C5  CC85   (09C1)     BXUD    11,,$94                                                  % 040510
2444   26R          09C6  F83C1C13          FETD    3,,KAL_TEMP+13                                           CF040520
2445   32           09C8  9243   (00C3)     SUB     0,,CONNIE_LIMIT                                          CF040530
2446   40           09C9  7443   (00C3)     PTR     0,,CONNIE_LIMIT                                          CF040540
2447   50           09CA  FC0B0072          ADDD    0,,MEASUREMENT_VARIANCE                                  CF040550
2448   60           09CC  F82B0074          SUBD    2,,MEASUREMENT                                           CF040560
2449   82           09CE  FC270072          PTRD    2,,MEASUREMENT_VARIANCE                                  CF040570
2450    8R *        09D0  F80D0A1E    $90   BSV     COMPUTE_BI_AND_C  "START MEASUREMENT PROCESSING        CF040580
2451   16 *         09D2  F80D0A64          BSV     MEASUREMENT_UPDATE_X  "COMPLETE MEASUREMENT"            CF040590
                                      * MEASUREMENT UPDATE X ROUTINE                                        *H040600
                                      * RETURNS HERE ONLY IF A STATE                                        *H040610
                                      * VECTOR WAS UPDATED.                                                 *H040620
                                      * IF NO STATE VECTORS WERE GEN-                                       *H040630
                                      * ERATED THEN IT RETURNS TO $10                                       *H040640
                                      * IF 'GOOD MEASUREMENT' IS FALSE                                      *H040650
                                      * TO TRY ANOTHER FREQ. OTHERWISE                                      *H040660
2452    6R          09D4  A575    $77   CLA     X7,5            "READ POINTER TO TRACKING FILTER         CF040670
2453    8           09D5  A460          CLA     6,0             "DATA FOR THIS FREQ TO PREPARE           CF040680
```

```
                                        *                                   "FOR THE RESET OT FILTERS.          CF040690
2454      12        09D6  D0D2  (09D9)          BCF       $64             "PHASE DIFFERENCE?"                 %R040700
2455       2R       09D7  8045                 COM       4,5                                                 % 040710
                                        *                                   "IS THIS THE BASE                   *2040720
2456       6        09D8  D06A  (09E3)          BRE       $65             "STATION?  (NEVER RESET BASE        CF040730
                                        *                                   "FILTER)"                           CF040740
2457       4R       09D9  8800                 $64       SUBD      0,0     "RESET TRACKING FILTER"             CF040750
                                        *                                   "                                   CF040760
                                        *                                   "OPEN ALL TRACKING FILTER           CF040770
                                        *                                   "VARIANCES                          CF040780
2458      16        09DA  F9671E03               STAD      X6,,SIGMA_SQ_PHI_PHI_DOT                          CF040790
2459      24        09DC  9EE9  (00E9)           CLAD      0,,=DF((1)/12)                                    CF040800
2460      36        09DD  F9671E33               STAD      X6,,SIGMA_SQ_PHI_PHI                              CF040810
2461      46        09DF  FC0A1A8E               CLAD      0,,=DF(.17765D-3) .006 PI **2                     CF040820
2462      58        09E1  F9671DD3               STAD      X6,,SIGMA_SQ_PHI_DOT_PHI_DOT                      CF040830
2463       8R       09E3  F00A006F       $65     CLS       0,,DF_MKR       "COMPLIMENT DIFFERENCE FREQ MKR     CF040840
                                        *                                   "(= 0 IF NOT DIFF FREQ)             CF040850
2464      12        09E5  D064  (09EA)           BRE       $97             "IS KALMAN IN DIFFERENCE FREQ?      %R040860
2465       4R       09E6  D051  (09E8)           BRL       $96             "IS THIS THE FIRST FREQ?"           CF040870
2466       2R       09E7  9C00                 CLAM      0,,0            "RESET DIFF FREQ MKR                CF040880
2467      10R       09E8  F007006F       $96     STA       0,,DF_MKR       "SAVE NEW DIFF FREQ MKR             CF040890
2468       6R       09EA  F0654000       $97     RSL       6,,1            "UPDATE KALMAN DUMP COUNTS FOR      CF040900
                                        *                                   "THIS STATION FREQUENCY             CF040910
                                        *                                   "RESET COUNT TO 0 AT 100 FOR THE    CF040920
                                        *                                   "CONVENIENCE OF THE C/I PROGRAM     CF040930
2469      14        09EC  F56A1D88               CLA       X6,,SIGMA_SQ_N_COUNTER                            CF040940
2470      24        09EE  F0071D89               STA       0,,N_CTR_SAVE   SAVE INCASE OF MISFIRE IN DF   11 040950
2471      34        09F0  F0671D8A               STA       6,,N_CTR_SAVE+1 R6 IS NCTR INDEX               11 040960
2472      42        09F2  E400010E               EXT       0,0,HXFF00                                        CF040970
2473      48        09F4  965D  (00DD)           ADD       0,,HX0100                                         CF040980
2474      52        09F5  F8096400               COMM      0,,X(6400)      99 DEC                            CF040990
2475      56        09F7  D051  (09F9)           BRL       $37                                               % 041000
2476       2R       09F8  9C00                 CLAM      0,0                                               CF041010
2477      10R       09F9  F1671D88       $37     STA       X6,,SIGMA_SQ_N_COUNTER                            % 041020
                                        * RETURN HERE FROM MEASUREMENT                                      *H041030
                                        * UPDATE IF NO STATE VECTORS WERE                                   *H041040
                                        * GENERATED AND THE SYSTEM WAS                                      *H041050
                                        * NOT KICKED BECAUSE THE 'GOOD                                      *H041060
                                        * MEASUREMENT' MARKER WAS FALSE                                      *H041070
2478       2R       09FB  9CD1           $10     CLAM      13,,1           "INCREMENT POINTERS TO PREPARE      CF041080
                                        *                                   "FOR THE NEXT FREQ                  CF041090
2479       4        09FC  9476                   ADDM      7,,6            INC T.F. ADDR                       CF041100
2480       6        09FD  9451                   ADDM      5,,1            STA                                 CF041110
```

```
2481      8          09FE  9441                        ADDM    4,,1          BASE                                    CF041120
                                                       *                     "ARE THERE MORE                         *1041130
2482      18         09FF  FC9C094E                    BXUD    9,,$11        "FREQUENCIES TO TRY?"                   CF041140
                                                       * RETURN HERE FROM MEASUREMENT                                *H041150
                                                       * UPDATE IF NO STATE VECTORS WERE                             *H041160
                                                       * GENERATED AND THE SYSTEM WAS                                *H041170
                                                       * KICKED OPEN.  THIS WILL PREVENT                             *H041180
                                                       * ANOTHER FREQ MEASUREMENT FROM                               *H041190
                                                       * THIS STATION NOW.                                           *H041200
2483      8R         0A01  F40A006F                    $92     CLA     0,,DF_MKR     RESTORE LOW FREQ NCTR IF      11  041210
2484      12         0A03  D024    (0A08)               BGE     $101          KICKED IN DIFF FREQ, I.E. DF    11  041220
2485      10R        0A04  FC0A1D89                    CLAD    0,,N_CTR_SAVE IS NEGATIVE                     11  041230
2486      20         0A06  F1171D88                    STA     X1,,SIGMA_SQ_N_COUNTER                        11  041240
2487      4R         0A08  F4F90022                    $101    ADDM    15,,34        "RELEASE SCRATCH STORAGE        11  041250
2488      8          0A0A  D00A    (0A15)               BUC     K_EXIT                                        CF041260
2489      36R        0A0B  CA66                        $91     FETD    I6,6          M MATRIX                        CF041270
2490      74         0A0C  FC671C06                    PTRD    6,,KAL_TEMP   "SAVE M1,2,3,4, MEAS, MEAS VAR     CF041280
                                                       *                     "AND KICK LIMIT FOR THE 1ST FREQ CF041290
2491      96         0A0E  F82C0072                    FETD    2,,MEASUREMENT_VARIANCE     C AND Y             CF041300
2492      104        0A10  8643    (00C3)               FET     0,,CONNIE_LIMIT                                   CF041310
2493      130        0A11  FC371C13                    PTRD    3,,KAL_TEMP+13                                    CF041320
2494      136        0A13  040009D4                    BUC     $77                                               CF041330
                                                       *          KALMAN COMPLETE                                   *H041340
                                                       * LOOK FOR CONFIRM AND EXECUTE                                *H041350
                                                       * PROPAGATION PREDICTION                                      *H041360
2495      6R         0A15  9E34    (0084)               K_EXIT  CLA     0,,PP_STATION "INCREMENT A COUNTER TO CYCLE ALL%S041370
                                                       *                     "STATIONS THROUGH PROP PREDICTIONCF041380
2496      8          0A16  9C17                        CLAM    1,,OS-1       "(ONE EVERY 10 SECONDS)         CF041390
2497      18         0A17  F40C0A1A                    BXU     0,,$30                                        % 041400
2498      8R         0A19  7010    (0090)               STA     0,,KAL_STA_FLG                            11  041410
2499      8R         0A1A  7034    (0084)               $30     STA     0,,PP_STATION                         % 041420
                                                       *                     "COMPUTE THETA1, THETA2 AND     *I041430
2500      16  *      0A1B  F80D0C49                    BSV     PROPAGATION_PREDICTION   "PROP C FOR 1 STATION" CF041440
2501      54         0A1D  D500                        BBK     13                                            CF041450
```

```
                                **                    3586          TOTAL   5602                    CF041460
                                *                     COMPUTE BI AND C                            *H041470
                                *                                                                 *H041480
                                * THIS ROUTINE COMPUTES THE MEASUREMENT WEIGHTING VECTOR B         *H041490
                                *                                                                 *H041500
2502                            COMPUTE_BI_AND_C:                                                 CF041510
2502      8R *    0A1E F80D08FB         BSV     REG_SETUP     "INITIALIZE 1070 REGISTERS          CF041520
                                *                             "COMPUTE AND SAVE (P)(M)TRANSPOSECF041530
                                *                             "                                   CF041540
                                *                             "COMPUTE (M)(P)(M)TRANSPOSE         CF041550
                                *                             "                                   CF041560
                                *                                       "Q = MPMT + MEAS VAR      CF041570
2503      2R      0A20 A468     $5      CLA     6,11                                              % 041580
2504      4R      0A21 B822     $3      SUBD    2,2                                               % 041590
2505      8R      0A22 AF7C     $2      CLAD    IX7,12                                            % 041600
2506      26      0A23 6876             MPYD    IX7,6           P MATRIX                          CF041610
2507      30      0A24 BC20             ADDD    2,0                                               CF041620
2508      8R      0A25 CC74 (0A22) $1   BXUD    7,,$2                                             % 041630
2509      4R      0A26 AC02             CLAD    0,2             KAL TEMP     PMT                  CF041640
2510      14      0A27 7B9D             STAD    IX9,13                                            CF041650
2511      32      0A28 689C             MPYD    IX9,12                                            CF041660
2512      36      0A29 BC40             ADDD    4,0               MPMT                            CF041670
2513      40      0A2A F4690012         ADDM    6,,18             INC P ADDR                      CF041680
2514      48      0A2C CC9C (0A21)      BXUD    9,,$3                                             % 041690
2515      10R     0A2D FC460072         ADDD    4,,MEASUREMENT_VARIANCE    Q = MPMT+C           CF041700
                                *                     2016                                        CF041710
2516      8R      0A2F AF7C     COMPUTE_BI CLAD IX7,12                                            CF041720
2517      28      0A30 F576C05C         MPYD    X7,,DIVERGENCE_CONTROL                            CF041730
                                *                             "COMPUTE B"                         CF041740
                                *                             "                                   CF041750
                                *                             "B =(PMT + MT*E) / Q  (CODE 0)      CF041760
                                *                             "                                   CF041770
                                *                             "OR"                                CF041780
2518      36      0A32 BF7D             ADDD    IX7,13        "                                   CF041790
                                *                             "B = Q / (PMT + MT*E)  (CODE 1)     CF041800
                                *                             "                                   CF041810
                                *                             "SET B CODE TO DEFINE WHICH B WASCF041820
                                *                             "COMPUTED B(1) CODE IS IN BIT 16    CF041830
                                *                             "AND B(9) CODE IS IN BIT 8          CF041840
2519      40      0A33 AC20             CLAD    2,0                                               CF041850
2520      44      0A34 D163 (0A48)      BRE     $1                                                % 041860
2521      4R      0A35 D031 (0A37)      BRG     $2                                                % 041870
2522      4R      0A36 A820             CLSD    2,0                                               CF041880
```

```
2523    4R    0A37  8824          $2        COMD    2,4                                          % 041890
2524    8     0A38  D05E  (0A47)           BRL     $3                                           % 041900
2525    4R    0A39  D037  (0A41)           BRG     $4                                           % 041910
2526    2R    0A3A  9800                   COMM    0,,0                                         CF041920
2527    6     0A3B  D052  (0A3E)           BRL     $5                                           % 041930
2528    8R    0A3C  9EF3  (00F3)           CLAD    0,,=DX(7FFFFFFF)                             CF041940
2529    12    0A3D  D00A  (0A48)           BUC     $1                                           % 041950
2530    10R   0A3E  FC0A1AB8        $5      CLAD    0,,=DX(80000001)                             % 041960
2531    14    0A40  D007  (0A48)           BUC     $1                                           % 041970
2532    4R    0A41  AC24                $4      CLAD    2,4                                          % 041980
2533    130   0A42  DC20                        DIVD    2,0             Q/PM(T)                      CF041990
2534    134   0A43  F4990040                    ADDM    9,,X(40)                                     CF042000
2535    138   0A45  AC02                        CLAD    0,2                                          CF042010
2536    142   0A46  D001  (0A48)           BUC     $1                                           % 042020
2537    126R  0A47  DC04                $3      DIVD    0,4                                          % 042030
2538    12R   0A48  F9771CD5            $1      STAD    X7,,BI                                       % 042040
2539    14    0A4A  B499                        ADD     9,9             SHIFT B CODE                 CF042050
2540    22    0A4B  CD7D  (0A2F)           BXUD    7,,COMPUTE_BI                                % 042060
2541    10R   0A4C  F0971CE7                    STA     9,,BI+18        B CODE                       CF042070
2542    20    0A4E  F8481ABA                    COMD    4,,=DF((1)/10)                               CF042080
                                * DETERMINE KICK CRITERIA                                          *H042090
2543    24    0A50  D052  (0A53)           BRL     $6              "IS Q LESS THAN 1/10?        CF042100
2544    10R   0A51  FC4A1ABA                    CLAD    4,,=DF((1)/10) "SET Q = 1/10                CF042110
2545    6R    0A53  4C49                $6      MPIDM   4,,9            "MULTIPLY Q BY 9"            CF042120
2546    10    0A54  D08C  (0A61)           BAT     $7              "IS THIS A POSITION MEASUREMENT? CF042130
2547    6R    0A55  9E43  (00C3)           CLA     0,,CONNIE_LIMIT "COMPUTE UPPER KICK LIMIT =  CF042140
2548    22    0A56  6800                        MPYD    0,0             " (KICK LIMIT)**2 + .75 CY**2    CF042150
2549    26    0A57  F4090018                    ADDM    0,,F(.758-10)   INCREASE MAXIMUM              CF042160
2550    30    0A59  8840                        COMD    4,0                                          CF042170
2551    34    0A5A  D041  (0A5C)           BLE     $10             "IS Q LESS THAN UPPER KICK LIMIT?CF042180
2552    4R    0A5B  AC40                        CLAD    4,0             "SET Q = UPPER KICK LIMIT    CF042190
2553    10R   0A5C  FC4B1ABC        $10     ADDD    4,,=DF((.04)*.048-10)                        CF042200
                                *                                                                  CF042210
                                *                               "ADD .04 CYCLE TO Q          CF042220
2554    12R   0A5E  F8470070        $8      STAD    4,,CONNIE       "SAVE KICK VALUE             CF042230
2555    50    0A60  D5D0                        BBK     13                                           CF042240
2556    10R   0A61  FC4B1ABE        $7      ADDD      4,,=DF(2*2*6076*6076/2.095D+7/2.095D+78-6)   CF042250
2557    14    0A63  D806  (0A5E)           BUC     $8              "ADD 2 N MILE TO Q           CF042260
```

```
                                                                                                                                CF042270
                                **                                                                                              CF042270
                                *                                MEASUREMENT UPDATE X                                           *H042280
                                *                                                                                               *H042290
                                * UPDATE STATE VECTORS WITH THIS MEASUREMENT                                                    *H042300
                                *                                                                                               *H042310
2558                            MEASUREMENT_UPDATE_X;                                                                          CF042320
                                *  FLAG A SET FOR FIXPOINT MEASUREMENT                                                         CF042330
2558      34R     0A64  F4D81C27        FETM    13,,X       "GENERATE POINTERS TO THE FIRST                                   CF042340
2559      42      0A66  F42A0084        CLA     2,,N        "STATE VECTOR AND THE FIRST SPARE                                 CF042350
2560      46      0A68  4424            MPIM    2,,4        "STORAGE FOR NEW STATE VECTORS                                    CF042360
2561      48      0A69  842D            ADD     2,13        "                                                                 CF042370
                  *                                         "SET AVERAGE STATE VECTOR (XXX)                                   CF042380
                  *                                         "    TO ZERO                                                      CF042390
2562      50      0A6A  9424            ADDM    2,,4        X(NN) BASE ADDR                                                   CF042400
2563      52      0A6B  A430            CLA     3,13        X (I)                                                             CF042410
2564      74      0A6C  8480            FETM    8,,0                                                                          CF042420
2565      116     0A6D  F4871C1E        PTR     8,,XXX      ZERO AVERAGE VECTOR                                               CF042430
2566      118     0A6F  A442            CLA     4,2         X(NN)                                                             CF042440
2567      10R     0A70  FC8A1AC0  $17   CLAD    11,,=DF(18-5) 2PI AT 2**6 PI   1 LANE                                       CF042450
                  *                                         "SET RESIDUAL INCREMENT = +1 LANE                                 CF042460
2568      16      0A72  C003            FET     0,3         X(I)                                                              CF042470
                  *                                         "GET STATE VECTOR - 4 ELEMENTS                                    *I042480
2569      24  *   0A73  F80D08A0        BSV     ASSEMBLE_XX "FROM MULTIPLE + 5 COMMON                                         CF042490
2570      32      0A75  F4081CED        FETM    0,,XX                                                                         % 042500
2571      40  *   0A77  F80D08ED        BSV     Y_MINUS_MX  "COMPUTE MEASUREMENT RESIDUAL                                     CF042510
2572      10R     0A79  FC5A0076  $98   CLAD    5,,MEASUREMENT_RESIDUAL                                                  135CF042520
                  *                                         "READ THE MEASUREMENT RESIDUAL                                    CF042530
2573      4R      0A7B  AC75        $4    CLAD    7,5         "FORM (RES +/- INC)**2 FOR                                        CF042540
                  *                                         "TESTING AGAINST KICK LIMIT                                       CF042550
2574      20      0A7C  6877            MPYD    7,7         (Y-MX)**2                                                         CF042560
2575      30      0A7D  F8780070        COMD    7,,CONNIE     K(MPM(T)+C)                                                     CF042570
                  *                                         "IS THIS RESIDUAL                                                 *I042580
2576      34      0A7F  D140    (0A90)  BLE     $1          "INSIDE THE ACCEPTABLE LIMIT?                                     CF042590
                  *                                         "IS THIS A                                                        *2042600
2577      4R      0A80  D0AF    (0A90)  BBT     $1          "POSITION FIX THAT HAS ALREADY                                    CF042610
                  *                                         "CAUSED A KICK?                                                   *H042620
                  * THE RESIDUAL INCREMENT WILL BE USED                                                                          *H042630
                  * TO TRY TO DRIVE THE RESIDUAL INSIDE                                                                         *H042640
                  * THE LIMITS.  THE INCREMENT MUST BE                                                                          *H042650
                  * THE OPPOSITE SIGN OF THE RESIDUAL.                                                                          *H042660
                  * THE INCREMENT IS + FIRST AND THEN                                                                           *H042670
                  * MINUS WHICH IS USED AS A MARKER TO                                                                          *H042680
                  * DEFINE PROCESS IS COMPLETE                                                                                  *H042690
```

```
2578    4R      0A81  AC05                      CLAD    0,5                                    % 042700
2579    20      0A82  6808                      MPYD    0,11                                   % 042710
                      *                         BRL     $6      "ARE THE RESIDUAL              *1042720
2580    24      0A83  D055   (0A89)             BRL     $6      "AND INCREMENT OPPOSITE IN SIGN? CF042730
2581    4R      0A84  A88B                      CLSD    11,11   "CHANGE SIGN OF INCREMENT SO THATCF042740
                      *                                         "ALL VALUES OF RESIDUAL + OR -   CF042750
                      *                                         "N LANES INSIDE LIMIT ARE USED   CF042760
                      *                                         "IS THE INCREMENT              *2042770
2582    10      0A85  04030ADE                  BRG     $2      "BACK TO + AGAIN?"             CF042780
                      *                                         "(PROCESS DONE)                CF042790
2583    10R     0A87  FC5A0076                  CLAD    5,,MEASUREMENT_RESIDUAL                CF042800
                      *                                         "READ ORIGINAL RESIDUAL AGAIN TO CF042810
                      *                                         "TRY RESIDUE MINUS N LANES       CF042820
                      * ENTER HERE IF IT IS DECIDED TO                                         *H042830
                      * ELIMINTE THIS VECTOR AFTER UPDATE                                      *H042840
                      *                                                                        *H042850
                      * ONLY INCREMENT TRACKING FILTER                                         *H042860
                      * MEASUREMENTS BY LANES                                                  *H042870
2584    6R      0A89  04080ADE          $6      BAT     $2      "IS THIS A POSITION FIX?"      CF042880
2585    6R      0A8B  C003                      FET     0,3                                    % 042890
                      *                                         "CREATE VECTOR AGAIN AS IT MAY BE*I042900
2586    14  *   0A8C  F80D0BA0                  BSV     ASSEMBLE_XX "CHANGED IN EARLIER PROCESSING CF042910
2587    18      0A8E  BC5B                      ADDD    5,11    "INCREMENT RESIDUAL            CF042920
2588    22      0A8F  D905   (0A7B)             BUC     $4                                     CF042930
                      * THIS RESIDUAL + OR - N LANES IS                                      *H042940
                      * NOW WITHIN ACCEPTABLE LIMITS                                          *H042950
                      * COMPUTE STATE VECTOR NOW AS THIS                                      *H042960
                      * MEASUREMENT FITS THIS VECTOR.                                         *H042970
2589    18R     0A90  F4580010          $1      FETM    5,,16   "SET UP TO GENERATE VECTOR (XX) CF042980
2590    20      0A92  9C38                      CLAM    3,,8    "READ B CODE                   CF042990
2591    28      0A93  F4DA1CE7                  CLA     13,,BI+18   B CODE                     CF043000
2592    4R      0A95  AC68              $5      CLAD    6,11        RESIDUAL                   CF043010
2593    14      0A96  F04A1CD5                  CLAD    X4,,BI                                 CF043020
2594    16      0A98  A4DD                      CLA     13,13   "COMPUTE XX(I)(NEW) = XX(I)     CF043030
                      *                                         "     + RES * B (OR RES/1/B)     CF043040
                      *                                         "     AS INDICATED BY B CODE FOR CF043050
                      *                                         "     THIS TERM                  CF043060
2595    20      0A99  D023   (0A9D)             BGE     $8                                     % 043070
2596    126R    0A9A  DC60                      DIVD    6,0         Y(RES)/1/B                 CF043080
2597    130     0A9B  AC06                      CLAD    0,6                                    CF043090
2598    134     0A9C  D001   (0A9E)             BUC     $9                                     % 043100
2599    16R     0A9D  6806              $8      MPYD    0,6                                    % 043110
2600    8R      0A9E  96F1   (00F1)     $9      ADDD    0,,=DX(00008000)                       % 043120
```

```
2601   16   0A9F F5281CED          ADD    X2,,XX                                  CF043130
2602   26   0AA1 F1271CED          STA    X2,,XX       R9= X(I)  RA = X(NN)       CF043140
2603   28   0AA3 B4DD              ADD    13,13        INC CODE                   CF043150
2604   36   0AA4 C420   (0AA5)     BXU    2,,$7                                   % 043160
2605    8R  0AA5 CD41   (0A95)$7    BXUD   4,,$5        "HAVE ALL TERMS BEEN COMPUTED?  %R043170
2606   18R  0AA6 D750              PRN    5                                       % 043180
                                   *                   "DO 36 MILE TEST           *2043190
2607   22   0AA7 D0A8   (0AB0)     BBT    $22          "UNLESS POSITION FIX HAS"  %R043200
                                   *                   "KICKED SYSTEM?            CF043210
2608   10R  0AA8 FC0A1CED          CLAD   0,,XX        "EXAMINE POSITION ERROR IN THIS CF043220
2609   16   0AAA 6000              MPY    0,0          "VECTOR (XX(1))**2 + (XX(2))**2 CF043230
2610   22   0AAB 6011              MPY    1,1                                     CF043240
2611   24   0AAC B401              ADD    0,1          THETA2**2 + THETA3**2      CF043250
2612   28   0AAD F8090392          COMM   0,,F(36*36/2.095/2.095D14*6076*6076B8)  CF043260
                                   *                   "IS THE POSITION           *2043270
2613   32   0AAF DA27   (0A89)     BGE    $6           "ERROR MORE THAN 36 N MILE?  CF043280
                                   *                   "(REJECT VECTOR)           CF043290
2614    2R  0AB0 A4AA              CLA    10,10        "EXAMINE NUMBER OF VECTORS  CF043300
                                   *                   "COMPUTED SO FAR           CF043310
                                   *                   "WAS THE VECTOR            *1043320
2615    6   0AB1 D260   (0AD2)     BRE    $10          "JUST GENERATED THE VERY FIRST?  CF043330
2616    2R  0AB2 9C83              CLAM   8,,3         "SET UP TO TEST VECTOR      CF043340
2617    4   0AB3 A412              CLA    1,2          "FOR UNIQUENESS             CF043350
2618    2R  0AB4 9C70              CLAM   7,,0         "SET TERM COUNT TO ZERO     CF043360
2619    8R  0AB5 F57A1CED          CLA    $15          "FORM DIFFERENCE OF ONE TERM OF  CF043370
2620   14   0AB7 B371              SUB    IX7,1        "THE NEW VECTOR WITH CORRESPOND-  CF043380
                                   *                   "ING TERM OF A VECTOR GENERATED  CF043390
                                   *                   "PREVIOUSLY WITH THIS MEASUREMENT CF043400
2621   18   0AB8 D071   (0ABA)     BNO    $14          "DID THE DIFFERENCE OVERFLOW?  %R043410
2622    4R  0AB9 D004   (0ABE)     BUC    $13          "THE VECTOR IS UNIQUE       CF043420
2623    6R  0ABA 6000              MPY    0,0          "EXAMINE THE SIZE OF THE    CF043430
                                   *                   "DIFFERENCE                CF043440
2624   10   0ABB D032   (0ABE)     BRG    $13          "IS THE DIFFERENCE SIGNIFICANT?  CF043450
2625    8R  0ABC C478   (0AB5)     BXU    7,,$15       "ARE THERE MORE TERMS TO TEST?  CF043460
                                   *                   "DUPLICATE"                CF043470
                                   *                   "DO NOT KEEP THIS VECTOR AND TRY CF043480
2626    4R  0ABD 0805   (0A89)     BUC    $6           "FOR ANOTHER               CF043490
2627    2R  0ABE 9414              ADDM   1,,4         "INCREMENT VECTOR COUNT     CF043500
2628    4   0ABF 8014              COM    1,4                                     CF043510
                                   *                   "ARE THERE MORE            *1043520
2629    8   0AC0 D81D   (0AB4)     BNE    $11          "VECTORS TO COMPARE AGAINST?  CF043530
2630    2R  0AC1 98AF              COMM   10,,15                                  % 043540
                                   *                   "IS THE VECTOR             *1043550
```

```
2631    6        0AC2  D05F  (0AD2)          BRL     $10          "STORAGE AREA FULL? (15 LIMIT)   %R043560
                       * TOO MANY STATE VECTORS - MISFIRE                                        *H043570
2632    10R      0AC3  8420                   FETM    2,,0         TOO MANY ESTIMATE VECTORS        CF043580
2633    18       0AC4  7004  (0084)           STA     0,,N                                          CF043590
2634    36       0AC5  F4271C27               PTR     2,,X         "REDUCE TO 1 VECTOR WITH 1ST 3   CF043600
2635    44       0AC7  F40A1CF9               CLA     0,,X2XX+3    "TERMS SET TO ZERO               CF043610
                       *                                            "IS THE 4TH TERM                 *1043620
2636    50       0AC9  04060807               BRE     $25          "OF THE VECTOR (T ZERO DOT) OK?  CF043630
2637    2R       0ACB  9C00                   CLAM    0,,0         X2XX GREATER THAN .08625 MSEC/SECCF043640
2638    12       0ACC  F0071C2A               STA     0,,X+3       "SET 4TH TERM TO ZERO AND OPEN   CF043650
                       *                                            "UP P44 BECAUSE MISFIRE ROUTINE  CF043660
                       *                                            "DOES NOT OPEN UP T ZERO DOT     CF043670
                       *                                            "                                CF043680
                       *                                            "GO TO MISFIRE                   CF043690
2639    20       0ACE  9EF7  (00F7)           CLAD    0,,=DF((.25)*.250-128+36)                     CF043700
2640    32       0ACF  F8071D53               STAD    0,,P44                                        CF043710
2641    36       0AD1  D305  (0807)           BUC     $25                                           CF043720
                       * THE NEW STATE VECTOR IS GOOD                                            *H043730
2642    2R       0AD2  94A1                   $10     ADDM    10,,1        "INCREMENT STATE VECTOR COUNT    CF043740
2643    8        0AD3  C00A                           FET     0,10         "MOVE VECTOR FROM TEMPORAY (XX)  CF043750
2644    16       0AD4  867F  (00FF)                   FET     0,,XXX_ADD   "TO 'PERMANENT' SCRATCH          CF043760
2645    24       0AD5  F4081CED                       FETM    0,,XX                                         CF043770
2646    44       0AD7  C230                           FET     I3,0                                          CF043780
2647    64       0AD8  7638                           PTR     I3,11        X(NN)                            CF043790
                       *                                            "INCORPORATE THIS VECTOR INTO    *I043800
2648    72  *    0AD9  F80D0830               BSV     AVERAGE_X    "AVGERAGE AND AVERAGE VARIANCE   CF043810
2649    74       0ADB  9444                   ADDM    4,,4         INC X(NN)                        CF043820
                       *                                            "RETURN TO CONSIDER ANOTHER NEW  CF043830
2650    80       0ADC  04000A89               BUC     $6           "VECTOR FROM THE SAME OLD VECTOR CF043840
                       * ALL POSSIBLE MEASUREMENTS FROM                                           *H043850
                       * THIS OLD STATE VECTOR HAVE NOW                                           *H043860
                       * BEEN MADE                                                               *H043870
2651    2R       0ADE  9434                   $2      ADDM    3,,4         "INCREMENT POINTER TO OLD STATE  CF043880
2652    4        0ADF  8032                           COM     3,2          "VECTORS                         CF043890
2653    10       0AE0  04010A70               BNE     $17          "ARE THERE ANYMORE OLD VECTORS?  CF043900
2654    2R       0AE2  9C90                   CLAM    9,,0                                          % 043910
2655    4        0AE3  90A1                   SUBM    10,,1                                         % 043920
2656    8        0AE4  D150  (0AF5)           BRL     $19          "ARE THERE ANY NEW STATE VECTORS?%R043930
                       *                                            "UPDATE THE P MATRIX"            *I043940
2657    8R  *    0AE5  F80D0879               BSV     MEASUREMENT_UPDATE_P                          CF043950
2658    10       0AE7  A40A                   CLA     0,10                                          % 043960
2659    16       0AE8  9AC4  (0084)           COM     0,,N                                          % 043970
                       *                                            "ARE THERE MORE                  *2043980
```

```
2660   20    0AE9  D034   (0AEE)          BRG    $52          "VECTORS THIS TIME THAN THERE    HH043990
                                *                             "WERE BEFORE?                    CF044000
2661   26R   0AEA  F04C1C22               FET    4,,XXX+4     "SAVE THE NEW COMMON ELEMENTS    CF044010
2662   52    0AEC  F4471CE8               PTR    4,,XXXX      "FROM THE AVERAGE STATE VECTOR   CF044020
2663    8R   0AEE  7004   (0084)  $52     STA    0,,N                                          % 044030
2664   12    0AEF  44A4                    MPIM   10,,4                                         CF044040
2665   14    0AF0  94A3                    ADDM   10,,3                                         CF044050
2666    6R   0AF1  A792              $18     CLA    IX9,2                                       % 044060
2667   14    0AF2  739D                    STA    IX9,13       "TRANSFER ALL THE NEW VECTORS    CF044070
                                *                             "INTO THE STORAGE AREA FOR OLD   CF044080
                                *                             "VECTORS                         CF044090
2668   22    0AF3  C493   (0AF1)           BXU    9,,$18                                       % 044100
                                *                             "EXIT"                           CF044110
2669   38R   0AF4  D5D0              $30     BBK    13           "MEASUREMENT COMPLETE"           CF044120
                                * NO NEW STATE VECTORS                                         *H044130
2670    4R   0AF5  D186   (0B0C)  $19     BAT    $83          "IS THIS A POSITION FIX?"        CF044140
2671   10R   0AF6  FC0A1AC2               CLAD   0,,=DF((.15)*.158-10)                        % 044150
2672   20    0AF8  F8080070               COMD   0,,CONNIE                                     % 044160
                                *                             "IS THE ACCEPT                   *1044170
2673   24    0AFA  D057   (0B02)           BRL    $24          "LIMIT LESS THAN (.15 CYCLE)**2? %R044180
2674   10R   0AFB  FC0B0070               ADDD   0,,CONNIE    "INCREMENT ACCEPTABLE LIMIT BY   CF044190
2675   22    0AFD  F8070070               STAD   0,,CONNIE    "(.15 CYCLE)**2 AND TRY AGAIN TO CF044200
                                *                             "GENERATE STATE VECTORS          CF044210
2676   34R   0AFF  D7D0              $23     PRN    13                                          % 044220
2677   40    0B00  04000A64                BUC    MEASUREMENT_UPDATE_X                         CF044230
                                *                             "IS THIS A GOOD                  *1044240
2678    4R   0B02  D0E4   (0B07)  $24     BDT    $25          "TRACKING FILTER MEASUREMENT?    CF044250
                                * DO NOT MISFIRE                                              *H044260
2679    4R   0B03  FC0909F8              $28     CLAM   0,,TRACKING_FILTER_MEASUREMENT$10     CF044270
                                *                             "MODIFY RETURN TO TRACKING FILTERCF044280
                                *                             "MEASUREMENT TO BYPASS ANYMORE   CF044290
                                *                             "PROCESSING OF THIS FREQ         CF044300
2680    8R   0B05  71E1              $27     STA    X14,,1       "PUT NEW RETURN ADDRESS IN R14   CF044310
                                *                             "SUBROUTINE STACK                CF044320
2681   46    0B06  D5D0                    BBK    13           "RETURN"                         CF044330
2682    4R   0B07  D084   (0B0C)  $25     BAT    $83          "IS THIS A POSITION FIX?"        CF044340
2683    4R   0B08  D0D3   (0B0C)           BCF    $83          "IS THIS PHASE DIFFERENCE?       %R044350
2684    6R   0B09  9E36   (0086)           CLA    0,,STATION_NUMBER                            % 044360
2685   12    0B0A  9A4C   (00CC)           COM    0,,BASE+1                                    % 044370
                                *                             "                                *2044380
2686   16    0B0B  D869   (0B03)           BRE    $28          "IS THIS THE BASE STATION?       CF044390
                                *                             "(NO MISFIRE)                    CF044400
2687    2R   0B0C  9C01              $83     CLAM   0,,1         "INCREMENT MISFIRE COUNT         CF044410
```

```
2688    10      0B0D  F4081CFF              ADD     0,,MISFIRE_CNT                          CF044420
2689    20      0B0F  F0071CFF              STA     0,,MISFIRE_CNT                          CF044430
2690    42      0B11  F82C0C39              FETD    2,,NOISE        "READ P33 KICK VALUE    %S044440
2691    46      0B13  D082   (0B16)         BAT     $32             "IS THIS A POSITION FIX?"CF044450
                      *  NO KICK OF 833 AFTER MOD 8                                         044460
2692    10R     0B14  FC0A1D00      $35     CLAD    0,,SIGMA_SQ_KICK "READ SIGMA KICK FOR USE AS A CF044470
                      *                                              "LOWER LIMIT ON P11 AND P22 CF044480
2693    10R     0B16  F8081D17      $32     COMD    0,,P11          "EXAMINE P11"           CF044490
2694    14      0B18  D052   (0B1B)         BRL     $33             "IS SIGMA KICK LESS THAN P11? CF044500
2695    12R     0B19  F8071D17              STAD    0,,P11          "SET P11 = SIGMA KICK   CF044510
2696    10R     0B1B  F8081D28      $33     COMD    0,,P22          "EXAMINE P22            CF044520
2697    14      0B1D  D052   (0B20)         BRL     $34             "IS SIGMA KICK LESS THAN P22? CF044530
2698    12R     0B1E  F8071D28              STAD    0,,P22          "SET P22 = SIGMA KICK   CF044540
2699    10R     0B20  D710          $34     PRN     1               "SAVE NEW P33"          CF044550
2700    24      0B21  FC071D3F              PTRD    0,,P33                                  CF044560
2701    28      0B23  D089   (0B2D)         BAT     $26             "IS THIS A POSITION FIX?"  044570
2702     8R     0B24  F40A006F              CLA     0,,DF_MKR                               % 044580
                      *                                              "IS KALMAN IN           %1044590
2703    12      0B26  D013   (0B2A)         BNE     $20             "DIFFERENCE FREQUENCY NOW? CF044600
2704    12R     0B27  8430                  FETM    3,,0            "RESET FREQUENCY PAIR SELECT CF044610
2705    34      0B28  F4371D07              PTR     3,,DF_COUNTER   "COUNTERS FOR ALL STATIONS TO CF044620
                      *                                              "ALWAYS START DIFF FREQ WITH CF044630
                      *                                              "11-10 DIFF IF 3 FREQ AVAILABLE CF044640
2706    4R      0B2A  FC090A01      $20     CLAM    0,,TRACKING_FILTER_MEASUREMENT$92       CF044650
                      *                                              "MODIFY RETURN TO TRACKING FILTERCF044660
                      *                                              "MEASUREMENT TO BYPASS ANYMORE CF044670
                      *                                              "MEASUREMENTS FROM THIS STATION CF044680
2707    8       0B2C  DA08   (0B05)         BUC     $27             NO MEASUREMENT          CF044690
2708    2R      0B2D  9C02          $26     CLAM    0,,2                                    % 044700
                      *                                              "MODIFY THE RETURN TO POSITION CF044710
                      *                                              "MEASUREMENT TO INDICATE A CF044720
                      *                                              "MISFIRE                CF044730
2709    8       0B2E  B5E1                  ADD     X14,,1                                  CF044740
2710    12      0B2F  DA0B   (0B05)         BUC     $27                                     CF044750
```

```
                                **                      446                                                     CF044760
                                *                       AVERAGE X                                               *H044770
                                *                                                                               *H044780
                                * THIS ROUTINE WILL COMPUTE AN AVERAGE STATE VECTOR.  EACH TIME THIS            *H044790
                                * ROUTINE IS CALLED IT WILL UPDATE THE AVERAGE WITH ONE STATE VECTOR.           *H044800
                                * IT ALSO GENERATES THE VARIANCE OF EACH ELEMENT OVER THE SET OF STATE          *H044810
                                * VECTORS.  THE ARGUMENTS CONSIST OF POINTERS TO THE NEW VECTOR (XB) AND       *H044820
                                * THE AVERAGE VECTOR (XC)  AND THE NUMBER OF THE NEW VECTOR (N).  THE          *H044830
                                * RESULTS ARE LEFT IN XXX (AVERAGE) AND X2XX (VARIANCE)                        *H044840
                                *                                                                               *H044850
                                *X X(A) +(X(B)-X(C))/N  = X(A)NEW                                               CF044860
                                *  R2 = N                                                                       CF044870
                                *  R1 = X(C) ADDR                                                               CF044880
                                *  R0 = X(B) ADDR                                                               CF044890
2711      8R    0830  867F  (00FF)  AVERAGE_X  FET     0,,XXX_ADD                                              CF044900
2712      32    0831  8498          FETM      9,,8      I LIM                                                   CF044910
2713      34    0832  8C71          CLSM      7,,1      I =R6,7                                                 CF044920
2714      36    0833  A44D          CLA       4,13      N =R4,5                                                 CF044930
2715     162    0834  DC64          DIVD      6,4       "COMPUTE I/N                                            CF044940
2716     166    0835  FCD91CF6      CLAM      13,,X2XX                                                          CF044950
2717      6R    0837  A788    $1    CLA       IX8,11    "PROCESS THE ITH TERM"                                  CF044960
2718      12    0838  B38C          SUB       IX8,12    "                                                       CF044970
2719      16    0839  AC40          CLAD      4,0       "XXX = XXX + (XB - XC)/N                                CF044980
2720      32    083A  6844          MPYD      4,4       "                                                       CF044990
2721      48    083B  6846          MPYD      4,6       DX*DX/N                                                 CF045000
2722      54    083C  B64D          ADD       I4,13     X2XX                                                    CF045010
2723      56    083D  AC24          CLAD      2,4       "X2XX = X2XX + ((XB - XC)**2)/N                         CF045020
2724      74    083E  6826          MPYD      2,6       "   + (X2XX + ((XB - XC)**2)/N)/N                       CF045030
2725      78    083F  B842          SUBD      4,2       (1-1/N)                                                 CF045040
2726      86    0840  7240          STA       I4,13     X2XX                                                    CF045050
2727      92    0841  6006          MPY       0,6       DX/N                                                    CF045060
2728      98    0842  878A          ADD       IX8,10                                                            CF045070
2729     106    0843  738A          STA       IX8,10    XXX (I)                                                 CF045080
2730     108    0844  94D1          ADDM      13,,1     INC X2XX ADDR                                           CF045090
2731     116    0845  C48F  (0837)  BXU       8,,$1     "ARE THERE MORE TERMS TO PROCESS?                       CF045100
2732      38R   0846  D5D0          BBK       13        "EXIT"                                                  CF045110
```

```
                                **                                                                  CF045120
                                *  THETA C RETURNED IN R0,1  2 REGS PRUNED                          CF045130
                                *    R0 = STA  R1 = FREQ R2,3 = THETA 1                             CF045140
                                *    ANSWER CORRECTED FOR DELTA T K I * PHI BASE                    CF045150
                                *                        THETA C                                    *H045160
                                *                                                                   *H045170
                                * THIS ROUTINE WILL COMPUTE THE PEDICTED PHASE FROM A STATION TO THE *H045180
                                * CRAFT FOR ANY FREQUENCY.  IN PHASE DIFFERENCE NAVIGATION A CORRECTION *H045190
                                * TERM IS ADDED.  THIS TERM IS THE TIME BETWEEN BASE STATION BURSTS AND *H045200
                                * THIS STATION'S BURSTS TIMES THE PHASE ESTIMATE IN THE BASE STATION *H045210
                                * TRACKING FILTER FOR THIS FREQUENCY.  THE ARGUMENTS CONSIST OF THETA1, *H045220
                                * FREQUENCY AND STATION NUMBER.                                      *H045230
                                *                                                                   *H045240
                                *                                                                   CF045250
2733      16R     0847  C053    THETA_C   FET     5,3             REPEAT THETA 1                    CF045260
2734      36      0848  F93616B2          MPYD    X3,,LAMBDA_TABLE "CONVERT THETA1 TO CYCLES FOR    CF045270
2735      56      084A  F8061AC4          MPYD    0,,=DF(3.141592658-2)                             CF045280
2736      60      084C  BC00              ADDD    0,0             "THIS FREQUENCY SCALED B10        CF045290
2737      64      084D  4423              MPIM    2,,3                                              CF045300
2738      70      084E  F0354000          RSL     3,,1                                              CF045310
2739      72      0850  B423              ADD     2,3                                               CF045320
2740      86      0851  F96C1D0F          FETD    X6,,PP_THETA2   "FORM THETA1 + THETA2 + THETA3    %S045330
2741      96      0853  F1961768          MPY     X9,,TF_LAMBDA_CONSTANT_TABLE                       045340
2742     106      0855  FD481CB9          ADDD    X4,,PP_THETA3   "           SCALED B10            CF045350
2743     116      0857  F8040400          RSAD    0,,5                                              CF045360
2744     120      0859  BC20              ADDD    2,0                                               CF045370
2745     124      085A  ACA2              CLAD    10,2                                              CF045380
                                *                                 "IS THIS"                         *1045390
2746     128      085B  D005   (0861)     BCF     $1              "PHASE DIFFERENCE NAVIGATION?     %R045400
                                *                                 "SUB ALWAYS PHASE DIFFERENCE      CF045410
2747      2R      085C  A418              CLA     1,8             STA                               CF045420
                                *                                 "SET UP STATION NO AND FREQ       CF045430
                                *                                 "ARGUMENT FOR D PHI KI ROUTINE    CF045440
2748       4      085D  A409              CLA     0,9             FREQ                              CF045450
2749      12  *   085E  F80D0C05          BSV     D_PHI_KI        "COMPUTE DELTA PHI CORRECTION     CF045460
2750      16      0860  BCA0              ADDD    10,0            "THETA C = SUM THETA(I) + D PHI   CF045470
                                *                                 "              SCALED B10 CYCLES  CF045480
2751      30R     0861  D590    $1        BBK     9               "EXIT"                            CF045490
```

```
                                ** ENTER WITH R0 = STA NUMBER                                          CF045500
                                *              R1  CONTAINS ADDRESS OF RIJ TO BE USED                  CF045510
                                *    RETURN  THETA 1  IN R0,1                                          CF045520
                                *                        COMPUTE THETA1                                *H045530
                                *                                                                      *H045540
                                * THIS ROUTINE COMPUTES THE CENTRAL ANGLE BETWEEN ANY STATION AND THE   *H045550
                                * CRAFT.  THE ARGUMENTS CONSIST OF THE STATION NUMBER AND A POINTER TO  *H045560
                                * THE POSITION VECTOR OF THE CRAFT.                                     *H045570
                                *                                                                      *H045580
2752                            COMPUTE_THETA1;                                                        CF045590
2752      4R        0B62  4406          MPIM    0,,6                                                   CF045600
2753      8         0B63  F4091798      ADDM    0,,STATION_VECTOR_TABLE                                CF045610
2754      16        0B65  C011          FET     1,1             "READ R1 VECTOR AND CONVERT TO         CF045620
2755      44        0B66  CA41          FETD    I4,1            "GEOCENTRIC COORDINATES                CF045630
                                * 1960 FISHER EQ RADIUS =  6378166.0 METERS  = A = 20925741.47 FEET      045640
                                *          POLAR RADIUS=  6356784.283 = B = 20855591.48 FEET            045650
                                *   B**2/A**2 = 0.9933065781                                           045660
2756      64        0B67  F8061AC6        MPYD    0,,=DF(0.9933065781)                                   045670
2757      80        0B69  C845          FETD    4,5             REPEAT R1                              CF045680
2758      116       0B6A  CA6C          FETD    I6,12                                                  CF045690
2759      124   *   0B6B  F80D1714      BSV     REGISTER_CROSS                                         % 045700
2760      140       0B6D  C845          FETD    4,5                                                    CF045710
2761      148   *   0B6E  F80D1728      BSV     REGISTER_DOT                                           % 045720
2762      594       0B70  1000          SQRT    0,0             "SIN(THETA) = MAG (S X R1)             %S045730
2763      598       0B71  ACA0          CLAD    10,0            "                                      CF045740
2764      612       0B72  D730          PRN     3               "COS(THETA) = R1 . S                   CF045750
2765      640       0B73  CA48          FETD    I4,8                                                   CF045760
2766      648   *   0B74  F80D1728      BSV     REGISTER_DOT                                           % 045770
2767      1186      0B76  1800          ATAN    0,,0                                                   CF045780
2768      1190      0B77  AC20          CLAD    2,0             "THETA1 = ARCTAN SIN/COS AT PI         %S045790
2769      1204      0B78  D510          BBK     1                                                      CF045800
                                *                                                                      CF045810
```

```
                                                **                                                          CF045820
                                                *                                                           CF045830
                                                *                    MEASUREMENT UPDATE P                   *H045840
                                                *                                                           *H045850
                                                * UPDATE THE COVARIANCE MATRIX IF NEW STATE VECTORS WERE GENERATED.  *H045860
                                                *                                                           *H045870
 2770                                           MEASUREMENT_UPDATE_P;                                       CF045880
 2770      8R *    0B79  F80D08F8                      BSV     REG_SETUP     "SET UP POINTERS AND COUNTERS   CF045890
                                                *                           "UPDATE P"                      CF045900
                                                *                           "COMPUTE (B)(M)(P)              CF045910
                                                *                           "(M)(P) IS AVAILABLE FROM THE   CF045920
                                                *                           "       Q COMPUTATION           CF045930
                                                *                           "                               CF045940
                                                *                           " USE B CODE TO CONTROL THE     CF045950
                                                *                           " MULTIPLY BY (B)               CF045960
 2771      12      0B7B  FC691CD5                      CLAM    6,,BI                                       CF045970
 2772      20      0B7D  F45A1CE7                      CLA     5,,BI+18      CODE                          CF045980
 2773       2R     0B7F  A445              $3          CLA     4,5                                         % 045990
 2774       4      0B80  A497                          CLA     9,7                                         CF046000
 2775       8R     0B81  AF9D              $2          CLAD    IX9,13                                      % 046010
 2776      12      0B82  AC20                          CLAD    2,0                                         CF046020
 2777      20      0B83  AF76                          CLAD    IX7,6         BI                            CF046030
 2778      22      0B84  9850                          COMM    5,,0                                        CF046040
 2779      26      0B85  D052    (0B88)                BRL     $4                                          % 046050
 2780      16R     0B86  6820                          MPYD    2,0                                         CF046060
 2781      20      0B87  D001    (0B89)                BUC     $5                                          % 046070
 2782     126R     0B88  DC20              $4          DIVD    2,0                                         % 046080
 2783       8R     0B89  AF7C              $5          CLAD    IX7,12                                      % 046090
                                                *                           "COMPUTE (E)(M)TRANSPOSE"       *S046100
 2784      28      0B8A  F976005C                      MPYD    X7,,DIVERGENCE_CONTROL                      CF046110
 2785      32      0B8C  D067    (0B94)                BRE     $1            "IS (E)(M)T ZERO?"            CF046120
 2786      12R     0B8D  CB96                          FETD    IX9,6         BI                            CF046130
 2787      14      0B8E  9860                          COMM    6,,0          "COMPUTE  (E)(M)T(B)          CF046140
                                                *                           "                               CF046150
                                                *                           "USE B CODE TO CONTROL THE      CF046160
                                                *                           "MULTIPLY BY (B)                CF046170
 2788      18      0B8F  D052    (0B92)                BRL     $6                                          % 046180
 2789      16R     0B90  6820                          MPYD    2,0                                         CF046190
 2790      20      0B91  D001    (0B93)                BUC     $7                                          % 046200
 2791     126R     0B92  DC20              $6          DIVD    2,0                                         % 046210
 2792      10R     0B93  D710              $7          PRN     1                                           % 046220
 2793       4R     0B94  B802              $1          SUBD    0,2                                         CF046230
 2794      12      0B95  8F9B                          ADDD    IX9,11        "COMPUTE P(NEW)"              CF046240
```

```
2795      22        0B96  7B98                STAD    IX9,11      "                                  CF046250
2796      24        0B97  B444                ADD     4,4         "= P - (B)(M)(P) + (E)(M)T(B)      CF046260
2797      32        0B98  CD98   (0B81)       BXUD    9,,$2                                          % 046270
2798       4R       0B99  F4B90012           ADDM    11,,18                                         CF046280
2799       6        0B9B  B455                ADD     5,5                                            CF046290
2800      14        0B9C  CD7E   (0B7F)       BXUD    7,,$3                                          % 046300
2801       8R *     0B9D  F80D0BD6            BSV     P_SYM       "FORCE P TO BE SYMETRICAL"         CF046310
2802      46        0B9F  D5D0                BBK     13          "EXIT"                             CF046320
```

```
                                **                                                                  CF046330
                                *                    ASSEMBLE STATE VECTOR                          #H046340
                                *                                                                   #H046350
                                * THIS ROUTINE WILL BUILD A SINGLE 9 ELEMENT STATE VECTOR (XX) FROM ONE #H046360
                                * OF THE 4 ELEMENT MULTIPLE VECTORS AND THE 5 ELEMENT COMMON VECTOR  #H046370
                                * (XXXX).  THE ARGUMENT IS A POINTER TO THE MULTIPLE VECTOR.         #H046380
                                *                                                                   #H046390
2803    26R   08A0 F04C1CE8     ASSEMBLE_XX FET     4,,XXXX      "READ 5 COMMON ELEMENTS            CF046400
2804    46    08A2 C235                     FET     I3,5         "READ 4 UNIQUE ELEMENTS            CF046410
2805    88    08A3 F4871CED                 PTR     8,,XX        "SAVE NEW 9 ELEMENT VECTOR         CF046420
2806    100   08A5 0500                     BBK     0                                               CF046430
```

```
                                                                                                                    CF046440
                                **                                                                                  CF046440
                                *                          PHI (P) PHI TRANSPOSE                                    *H046450
                                *                                                                                   *H046460
                                * THIS ROUTINE MULTIPLIES PHI BY (X), (P), OR (P)TRANSPOSE.  THE RESULT             *H046470
                                * REPLACES THE ORIGINAL MULTIPLIER.  THE 14 PHI ELEMENTS CONSIST OF                 *H046480
                                * 0, 0, PHI(1,8), 0, 0, 0, 0, PHI(2,9), PHI(3,4), PHI(5,5), PHI(6,6),              *H046490
                                * PHI(7,7), PHI(8,8) AND PHI(9,9).  THEY ARE ORDERED BY THE SEQUENCE OF             *H046500
                                * USEAGE WHEN ACCESSING PHI COLUMN BY COLUMN.  THE UNITY TERM OF THE               *H046510
                                * DIAGONAL ELEMENTS DOES NOT APPEAR AS IT IS HANDLED SEPARATELY.                   *H046520
                                *                                                                                 *H046530
                                *                                                                                 *H046540
                                * ENTER HERE WITH J = 18 AND I = 2                                                 *H046550
                                * TO MULTIPLY BY P.  ENTER HERE                                                    *H046560
                                * WITH J = 2 AND I = 18 TO MULTIPLY                                                *H046570
                                * BY P TRANSPOSE                                                                   *H046580
2807      32R   08A6  F4C81D17  PHI_P_PHIT  FETM    12,,P_MATRIX   "READ POINTER TO P AND CREATE                   CF046590
2808      34    08A8  9CB8                  CLAM    11,8           "13 REGISTERS                                  CF046600
                                *                                  "SET UP COUNTER K=9 TO PROCESS P               CF046610
                                * ENTER HERE WITH I = 1, POINTER TO                                                *H046620
                                * X, 13 REGISTERS AND COUNTER K=1                                                  *H046630
                                * TO PROCESS X (J IS NOT USED)                                                     *H046640
2809      4R    08A9  FC990010  $6          CLAM    9,,16          "SET UP TWO 9 COUNTERS M AND N                 CF046650
2810      6     08AB  A479                  CLA     7,9            "READ POINTER FOR TEMP VECTOR                  CF046660
2811      10    08AC  FC391C06              CLAM    3,,KAL_TEMP    "TO SAVE INTERMIDIATE RESULTS                  CF046670
2812      4R    08AE  FC59005C  $5          CLAM    5,,PHI_MATRIX  "READ POINTER TO START OF PHI                  CF046680
                                *                                  "MATRIX ELEMENTS                               CF046690
2813      6     08B0  A44C                  CLA     4,12           "COPY POINTER TO MULTIPLIER (P,X)              CF046700
2814      2R    08B1  A406      $3          CLA     0,6            "READ PHI CODE (N) FOR THIS                    CF046710
2815      8     08B2  FC0440C0              RSA     0,,1           "COLUMN                                        CF046720
2816      16    08B4  F50A0C30              CLA     X0,,PHI_CODE                                                  CF046730
2817      18    08B6  A420                  CLA     2,0                                                           CF046740
2818      22    08B7  B800                  SUBO    0,0                                                           CF046750
2819      32    08B8  7863                  STAD    IX6,3          "SET NTH ELEMENT OF TEMP = 0                   CF046760
2820      2R    08B9  9820      $2          COMM    2,,0           "EXAMINE MSB OF PHI CODE TO DE-                CF046770
                                *                                  "TERMINE IF THIS ELEMENT OF PHI                CF046780
                                *                                  "IS ONE OF THE 14 PROVIDED FOR                 CF046790
                                *                                  "IN PHI MATRIX                                 CF046800
                                *                                  "DOES THE (N,M)                                *1046810
2821      6     08BA  D058  (08C3)          BRL     $1             "ELEMENT OF PHI EXIST?"                        %R046820
2822      8R    08BB  AE04                  CLAD    10,4           "READ THE MTH ELEMENT OF THE                   CF046830
2823      10    08BC  9880                  COMM    11,,0          "KTH ROW OR COLUMN OF P OR X                   CF046840
2824      14    08BD  D011  (08BF)          BNE     $7             "IS THIS A P MATRIX TERM?"                     CF046850
2825      2R    08BE  9C10                  CLAM    1,,0           "X VECTOR TERM"                                CF046860
```

```
                                        *                                                                  "CLEAR LOWER HALF OF DOUBLE       CF046870
                                        *                                                                  "REGISTER AS X IS ONLY 16 BITS    CF046880
2826    18R     08BF  6AC5              $7          MPYD        I0,5                                       "FORM PRODUCT OF MULTIPLIER       CF046890
2827    26      08C0  BF63                          ADDD        IX6,3                                      "ELEMENT AND PHI(N,M)             CF046900
2828    36      08C1  7B63                          STAD        IX6,3                                      "ADD RESULT TO THE MTH TERM OF    CF046910
                                        *                                                                  "TEMP                             CF046920
2829    38      08C2  9452                          ADDM        5,2                                        "INCREMENT PHI MATRIX POINTER TO  CF046930
                                        *                                                                  "THE NEXT ELEMENT OF PHI          CF046940
2830    2R      08C3  B422              $1          ADD         2,2                                        "SHIFT PHI CODE 1 TO GET READY    CF046950
                                        *                                                                  "FOR THE M+1 ELEMENT              CF046960
2831    4       08C4  B44D                          ADD         4,13                                       "ADD I TO MULTIPLIER POINTER TO   CF046970
                                        *                                                                  "SEQUENCE TO THE M+1 ELEMENT OF   CF046980
                                        *                                                                  "ROW OR COLUMN K. I=2 FOR P ROWS, CF046990
                                        *                                                                  "I=18 FOR P COLUMNS AND I=1 FOR X CF047000
                                        *                                                                  "INCREMENT M                      *1047010
2832    12      08C5  CC8D  (08B9)                  BXUD        8,,$2                                      "ARE THERE MORE ELEMENTS?"        CF047020
2833    2R      08C6  A44C                          CLA         4,12                                       "COPY POINTER TO MULTIPLIER (P,X) CF047030
                                        *                                                                  "TO START THE PROCESS OVER FOR    CF047040
                                        *                                                                  "THE N+1 COLUMN OF PHI            CF047050
                                        *                                                                  "INCREMENT N                      *2047060
2834    10      08C7  CD67  (08B1)                  BXUD        6,,$3                                      "ARE THERE MORE COLUMNS OF PHI    CF047070
                                        *                                                                  "TO PROCESS?                      CF047080
                                        * THE MULTIPLICATION IS COMPLETE                                                                  *H047090
                                        * EXCEPT FOR THE UNITY TERM IN                                                                    *H047100
                                        * THE PHI DIAGONAL ELEMENTS.                                                                      *H047110
                                        * NOTE - M, N ARE RESET NOW                                                                       *H047120
2835    8R      08C8  AF63              $4          CLAD        IX6,3                                      "READ MTH ELEMENT OF THE NEW      CF047130
2836    10      08C9  9880                          COMM        11,,0                                      "VECTOR IN TEMP                   CF047140
2837    14      08CA  D014  (08CF)                  BNE         $8                                         "IS THIS A P MATRIX MULTIPLY?     CF047150
2838    6R      08CB  B6C4                          ADD         I0,4                                       "X"                               CF047160
                                        *                                                                  "ADD X(M) TO TEMP TO GET THE      CF047170
                                        *                                                                  "FINAL RESULT                     CF047180
2839    14      08CC  96F1  (00F1)                  ADDD        0,,=DX(00008000)                           "ROUND THE RESULT                 CF047190
2840    22      08CD  7204                          STA         I0,4                                       "SAVE IN X(M)                     CF047200
2841    26      08CE  D002  (08D1)                  BUC         $9                                                                           CF047210
2842    8R      08CF  BE04              $8          ADDD        I0,4                                       "P"                               CF047220
                                        *                                                                  "ADD P(M,K) (OR P(K,M)) TO TEMP   CF047230
                                        *                                                                  "TO GET THE FINAL RESULT          CF047240
2843    18      08D0  7AC4                          STAD        I0,4                                       "SAVE IN P(M,K) (OR P(K,M))       CF047250
2844    2R      08D1  B44D              $9          ADD         4,13                                       "ADD I TO MULTIPLIER POINTER TO   CF047260
                                        *                                                                  "SEQUENCE TO THE M+1 ELEMENT OF   CF047270
                                        *                                                                  "ROW OR COLUMN K. I=2 FOR P ROWS, CF047280
                                        *                                                                  "I=18 FOR P COLUMNS AND I=1 FOR X CF047290
```

```
                                *                                                    "INCREMENT M                          *1047300
2845      10      08D2  CC6B  (08C8)          BXUD      6,,$4                      "ARE THERE MORE ELEMENTS?"            CF047310
                                * PROCESSING IS COMPLETE IF X                                                          *H047320
                                * AS K ONLY COUNTS TO L                                                               *H047330
2846      6R      08D3  B6CF                 ADD       I12,15                     "ADD J TO P MATRIX POINTER TO         CF047340
                                *                                                  "SEQUENCE TO THE K+1 ROW OR           CF047350
                                *                                                  "COLUMN OF P (J=18 FOR COLUMNS        CF047360
                                *                                                  "AND J=2 FOR ROWS)                    CF047370
                                *                                                  "INCREMENT K                          *2047380
2847      14      08D4  C6A7  (08AE)          BXU       10,,$5                     "ARE THERE MORE ROWS OR COLUMNS       CF047390
                                *                                                  "OF P TO PROCESS?                     CF047400
2848      40R     08D5  D5E0                 BBK       14                         "EXIT"                                CF047410
```

```
                                **                                                                                  CF047420
                                *                              P SYM                                               *H047430
                                *                                                                                  *H047440
                                * THIS ROUTINE WILL FORCE THE P MATRIX TO BE SYMETRIC AND THE DIAGONAL              *H047450
                                * ELEMENTS TO BE POSITIVE                                                          *H047460
                                *                                                                                  *H047470
2849    22R   08D6  F4781D17    P_SYM     FETM   7,,P_MATRIX    "SET P(M,N) = P(N,M) FOR                          CF047480
2850    26    08D8  FC690010              CLAM   6,,16          "                    M UNEQUAL N                  CF047490
2851    28    08DA  A446                  CLA    4,6           "SET P(M,N) = 0 IF N = M                          CF047500
                                *                               "                AND P(M,N) MINUS                 CF047510
2852     2R   08D8  A427          $3      CLA    2,7                                                             * 047520
2853     6    08DC  F4290012              ADDM   2,,18                                                           CF047530
2854    14    08DE  AE07                  CLAD   IO,7                                                            CF047540
2855    18    08DF  D027   (08E7)        BGE    $1                                                              * 047550
2856     4R   08E0  8800                  SUBD   0,0                                                            CF047560
2857    14    08E1  7A07                  STAD   IO,7                                                            CF047570
2858    18    08E2  D004   (08E7)        BUC    $1                                                              * 047580
2859     8R   08E3  AF37          $2      CLAD   IX3,7                                                           * 047590
2860    18    08E4  7A02                  STAD   IO,2                                                            CF047600
2861    22    08E5  F4290012              ADDM   2,,18                                                           CF047610
2862     8R   08E7  CC35   (08E3)  $1      BXUD   3,,$2                                                           * 047620
2863     4R   08E8  F4790014              ADDM   7,,20                                                           CF047630
2864     6    08EA  9042                  SUBM   4,,2                                                            CF047640
2865    14    08E8  C051   (08D8)        BXUD   5,,$3                                                           * 047650
2866    26R   08EC  D570                  BBK    7                                                               CF047660
```

```
                                                **                                                              CF047670
                                                *                    MEASUREMENT RESIDUE                        *H047680
                                                *                                                               *H047690
                                                * THIS ROUTINE COMPUTES THE RESIDUE Y - (M)(X).  THE ARGUMENT CONSISTS  *H047700
                                                * OF A POINTER TO X.                                             *H047710
                                                *                                                               *H047720
                                                *  X ADDRESS IN R0 UPON ENTRY R0 PRUNED   444                    CF047730
 2867    18R   08ED  F4580010   Y_MINUS_MX  FETM    5,,16                                                       CF047740
 2868     2R   08EF  9C10       $1          CLAM    1,,0                                                        % 047750
 2869     8    08F0  A206                   CLS     I0,6          "COMPUTE  -(M)(X)                             CF047760
 2870    28    08F1  F946004A               MPYD    X4,,M_MATRIX  "ADD MEASUREMENT (Y)                          CF047770
 2871    32    08F3  BC20                   ADDD    2,0           "SAVE RESIDUE                                 CF047780
 2872    34    08F4  9461                   ADDM    6,,1                                                        CF047790
 2873    42    08F5  CC47   (08EF)          BXUD    4,,$1                                                       % 047800
 2874   10R    08F6  FC280074               ADDD    2,,MEASUREMENT                                              CF047810
 2875    22    08F8  F8270076               STAD    2,,MEASUREMENT_RESIDUAL                                     CF047820
 2876    46    08FA  D560                   BBK     6                                                           CF047830
                                                *                                                               CF047840
                                                *                    REGISTER SET UP                            *H047850
                                                *                                                               *H047860
                                                * THIS ROUTINE WILL CREATE 14 REGISTERS AND SET UP COMMON POINTERS *H047870
                                                *                                                               *H047880
                                                * D = KAL TEMP                                                   CF047890
                                                * C = M MATRIX                                                   CF047900
                                                * B = P.MATRIX                                                   CF047910
                                                * A = 16                                                         CF047920
                                                * 9 = 0                                                          CF047930
                                                * 8 = 16                                                         CF047940
                                                * 7,6,5,4,3,2,1 = 0                                              CF047950
 2877    34R   08FB  F4D81C06       REG_SETUP   FETM    13,,KAL_TEMP  "CREATE REGISTERS                          CF047960
 2878    38    08FD  FCC9004A                   CLAM    12,,M_MATRIX  "SET POINTER TO TEMP VECTOR                CF047970
 2879    42    08FF  FCB91D17                   CLAM    11,,P_MATRIX  "SET POINTER TO M MATRIX                   CF047980
 2880    46    0C01  FCA90010                   CLAM    10,,16        "SET POINTER TO P MATRIX .                 CF047990
 2881    48    0C03  A48A                       CLA     8,10          "SET UP TWO 9 COUNTERS                     CF048000
 2882    56    0C04  D5F0                       BBK     15                                                       CF048010
```

```
                                **                                                                  CF048020
                                *  STA NUMBER (S) IN R1                                             CF048030
                                *  FREQ (D) IN R0                                                   CF048040
                                *  DELTA T (KI) * PHI (BASE) (I) AT 810 CYCLES IN R0,1              CF048050
                                *                        D PHI KI                                   #H048060
                                *                                                                  #H048070
                                * THIS ROUTINE COMPUTES A CORRECTION TERM THAT REPRESENTS WHAT IS    #H048080
                                * EXPECTED TO HAPPEN TO THE BASE STATION PHASE BETWEEN THE BASE STATION #H048090
                                * BURST TIME AND THE TIME OF A NON BASE STATION BURST FOR ANY FREQUENCY. #H048100
                                * THIS ROUTINE COMPUTES THE TIME DIFFERENCE AND USES THE PHASE ESTIMATE #H048110
                                * IN THE BASE STATION TRACKING FILTER AS THE EXPECTED CHANGE IN PHASE OF #H048120
                                * THE BASE STATION DURING A TEN SECOND PERIOD.  THE ARGUMENTS CONSIST OF #H048130
                                * THE STATION NUMBER AND THE FREQUENCY.                             #H048140
                                *                                                                  #H048150
2883        8R    0C05  8648  (00C8)  D_PHI_KI   FET     0,,BASE                                  CF048160
                                *                                    "SET DELTA T = 0              CF048170
                                *                                    "                             CF048180
2884        20    0C06  C032          FET     3,2      "USE THE BASE STATION NUMBER AND          CF048190
2885        22    0C07  8000          SUB     0,0      "FREQ TO DETERMINE WHAT STATION           CF048200
2886        24    0C08  B412          ADD     1,2      "IS SENDING 10.2 WHEN THE BASE IS         CF048210
2887        34    0C09  F8154000      RSLD    1,,1     "SENDING THIS FREQ. (BASE REF)            CF048220
2888        36    0C0B  9818          COMM    1,,8                                               CF048230
2889        40    0C0C  D051  (0C0E)  BRL     $1       "IS BASE REF IN RANGE OF 0 TO 7?          CF048240
2890        2R    0C0D  9018          SUBM    1,,8     "PUT BASE REF IN RANGE OF 0 TO 7          CF048250
2891        2R    0C0E  B432          $1      ADD     3,2      "USE THE STATION NUMBER AND FREQ  CF048260
                                *                              "TO DETERMINE WHAT STATION IS       CF048270
                                *                              "SENDING 10.2 WHEN THIS STATION     CF048280
2892        4     0C0F  9038          SUBM    3,,8     "IS SENDING THIS FREQ (STA REF)             048290
2893        8     0C10  D021  (0C12)  BGE     $3       "IS STA REF IN RANGE OF 0 TO 7?           CF048300
2894        2R    0C11  9438          $2      ADDM    3,,8     "PUT STA REF IN RANGE OF 0 TO 7   CF048310
                                * IF THE STATION NUMBER IS THE                                     #H048320
                                * BASE STATION NUMBER THE TEST                                     #H048330
                                * BELOW WILL CAUSE THE CORR-                                       #H048340
                                * ECTION TO BE ZERO                                                #H048350
2895        2R    0C12  8013          $3      COM     1,3      "COMPARE STA REF AND BASE REF     CF048360
                                *                              "IS THE STA REF                     #1048370
2896        6     0C13  D067  (0C18)  BRE     $4       "NOW EQUAL TO THE BASE REF?               CF048380
2897        8R    0C14  F538175A      ADD     X3,,STATION_BURST_TIMES                            CF048390
2898        12    0C16  F4090050      ADDM    0,,80    "ADD THE BURST COLLECTION TIME            CF048400
                                *                              "FOR THIS STATION TO DELTA T        CF048410
                                *                                    "                             CF048420
                                *                              "ADD .4 SECONDS TO DELTA T FOR      CF048430
                                *                              "THE SLOT TIME AND TRUNCATED        CF048440
```

```
                                    *                                   "BURST TIME                                  CF048450
2899        14      0C18  9031                    SUBM    3,,1          "DECREMENT STA REF BY 1 TO PRE-              %S048460
                                    *                                   "PARE TO ADD IN THE NEXT TIME IF             CF048470
                                    *                                   "LOOP IS NOT COMPLETE                        CF048480
                                    *                                   "IS STA REF - 1                              *1048490
2900        18      0C19  D828  (0C12)              BGE     $3          "OUTSIDE OF THE RANGE 0 TO 7?                %R048500
2901         4R     0C1A  D80A  (0C11)              BUC     $2          "STA REF MUST BE IN RANGE 0 TO 7             CF048510
2902         4R     0C1B  FC1907D0          $4      CLAM    1,,2000     "COMPUTE D PHI"                              CF048520
                                    *                                   "= (DELTA T / 10 SEC) * PHI                  CF048530
2903        36      0C1D  D401                      DIV     0,1         "          ESTIMATE(BASE)                    CF048540
2904        40      0C1E  4443                      MPIM    4,,3        BASE                                         CF048550
2905        42      0C1F  B445                      ADD     4,5         FREQ                                         CF048560
2906        62      0C20  F9461EA3                  MPYD    X4,,PHI_ESTIMATE                                         CF048570
2907        66      0C22  AC50                      CLAD    5,0                                                      CF048580
2908        86      0C23  D540                      BBK     4                                                        CF048590
```

```
                                **                                                                  CF048600
2909    0C24  A4FA4FA5  BETA_NRA      COND    F(((-1)/.05)/36008-7)                               CF048610
2910    0C26  A4FA4FA5  BETA_LOG      COND    F(((-1)/.05)/36008-7)                               CF048620
2911    0C28  A4FA4FA5  BETA_PSEUDO   COND    F(((-1)/.05)/36008-7)                               CF048630
2912    0C2A  00024200  SIGMA_NRA     COND    F((((20)*20)*1.7)*1.78-24)                          CF048640
2913    0C2C  00000D01  SIGMA_LOG     COND    F((((03)*03)*1.7)*1.78-24)                          CF048650
2914    0C2E  00009080  SIGMA_PSUDO   COND    F((((10)*10)*1.7)*1.78-24)                          CF048660
2915    0C30  3E7F      PHI_CODE      CON     X(3E7F)                                             CF048670
2916    0C31  3E7F                    CON     X(3E7F)                                             CF048680
2917    0C32  EFFF                    CON     X(EFFF)                                             CF048690
2918    0C33  FFFF                    CON     X(FFFF)                                             CF048700
2919    0C34  F7FF                    CON     X(F7FF)                                             CF048710
2920    0C35  FBFF                    CON     X(FBFF)                                             CF048720
2921    0C36  FDFF                    CON     X(FDFF)                                             CF048730
2922    0C37  FEFF                    CON     X(FEFF)                                             CF048740
2923    0C38  FF7F                    CON     X(FF7F)                                             CF048750
2924    0C39  011A3D3E  NOISE         COND      F(20*6076*20*6076/2.095D+7/2.095D+7B-8)           CF048760
2925    0C3B  2AAAAAAB                COND    F((1)/3)        MAX = 441.176 MICRO SEC             CF048770
2926    0C3D  04690000  DATA_TABLE    COND    X(04690000)                                         CF048780
2927    0C3F  04690000                COND    X(04690000)                                         CF048790
2928    0C41  40000000                COND    X(40000000)                                         CF048800
                                *                                                                   CF048810
2929    0C43  018E7000  M_4_TABLE     COND    F((10)*10.20D38-23)                                 CF048820
2930    0C45  02134000                COND    F((10)*13.60D38-23)                                 CF048830
2931    0C47  018A9400                COND    F((10)*11.33D38-23)                                 CF048840
```

```
                                **                                                                  PP048850
                                *                    PROPAGATION PREDICTION                         *H048860
                                *                                                                   *H048870
                                * THIS PROGRAM WILL COMPUTE THE PREDICTED SPHEROIDAL AND PROPAGATION *H048880
                                * CORRECTIONS TO THE NOMINAL PREDICTED PHASE MEASUREMENTS FROM A GIVEN *H048890
                                * STATION.  IT ALSO COMPUTES AN ASSOCIATED VARIANCE.  THE THREE PARA- *H048900
                                * METERS ARE COMPUTED FOR ALL 3 FREQUENCIES AND SAVED IN MEMORY FOR EACH*H048910
                                * STATION.  THE TOTAL LANE COUNT FROM THE CORRECTED PREDICTED PHASE  *H048920
                                * REPLACES ANY LANE COUNTS CONTAINED IN THE MEASURED PHASE IN THE    *H048930
                                * TRACKING FILTER.  THE STATION NUMBER IS THE ONLY ARGUMENT.         *H048940
                                *                                                                   *H048950
                                *                        ENTER WITH STATION NUMBER IN R0            PP048960
                                *                                                                   PP048970
2932                            PROPAGATION_PREDICTION;                                              048980
2932    14R          0C49 F4381C63          FETM    3,,PROP_PRED_RESULTS                             048990
2933    18           0C4B FC29001A          CLAM    2,,26                                            049000
2934     8R          0C4D 7313      $10     STA     IX1,3          CLEAR RESULTS                     049010
2935    16           0C4E C412 (0C4D)       BXU     1,,$10                                           049020
2936     2R          0C4F 9C26              CLAM    2,,6                                             049030
2937     6           0C50 6424              MPI     2,4                                              049040
2938    16           0C51 D710              PRN     1                                                049050
2939    22           0C52 967E (00FE)       ADD     0,,SV_ADD                                        049060
2940    30           0C53 867D (00FD)       FET     0,,RIJ_ADD                                       049070
2941    36           0C54 C003              FET     0,3                                    34080     049080
2942    44 *         0C55 F80D0862          BSV     COMPUTE_THETA1                           81      049090
2943    54           0C57 780D (008D)       STAD    0,,INTEGRATION_COUNTER                   82      049100
2944    82           0C58 C252              FET     I5,2           GET STATION VECTOR AGAIN            PP049110
2945   120           0C59 F07C1F69          FET     7,,R11         GET 2 WORDS THEN R1 VECTOR          PP049120
2946   128 *         0C5B F80D1714          BSV     REGISTER_CROSS   STA CROSS R1                      PP049130
2947   144           0C5D C055              FET     5,5            DUP STA CROSS R1                    PP049140
2948   160           0C5E 6800              MPYD    0,0                                                PP049150
2949   176           0C5F 6822              MPYD    2,2                                                PP049160
2950   192           0C60 6844              MPYD    4,4                                                PP049170
2951   196           0C61 BC02              ADDD    0,2                                                PP049180
2952   200           0C62 BC04              ADDD    0,4            (STAXR1 DOT STAXR1)                 PP049190
2953   646           0C63 1000              SQRT    0,0                                                PP049200
2954   652           0C64 4C02              LSAD    0,,1                                               PP049210
2955   778           0C65 DC60              DIVD    6,0            -AX1                                PP049220
2956   904           0C66 DC80              DIVD    8,0            -AX2 AT B1                          PP049230
2957  1030           0C67 DCA0              DIVD    10,0           -AX3                                PP049240
2958  1032           0C68 A4DA              CLA     13,10          SINGLE PRECISION AX                 PP049250
2959  1034           0C69 A4C8              CLA     12,8                                               PP049260
2960  1036           0C6A A4B6              CLA     11,6                                               PP049270
```

```
2961  1064  0C6B  D7A0                    PRN   10                                          PP049280
2962  1092  0C6C  C255                    FET   I5,5          INITIAL P = STATION VECTOR     PP049290
2963  1094  0C6D  A454                    CLA   5,4           SINGLE PRECISION               PP049300
2964  1100  0C6E  F0544000                RSA   5,,1          P3 AT B1                       PP049310
2965  1102  0C70  A442                    CLA   4,2                                          PP049320
2966  1108  0C71  F0444000                RSA   4,,1          P2 AT B1                       PP049330
2967  1110  0C73  A430                    CLA   3,0                                          PP049340
2968  1116  0C74  F0344000                RSA   3,,1          P1 AT B1                       PP049350
2969  1128  0C76  D720                    PRN   2                                            PP049360
2970  1146  0C77  F02C16AC                FET   2,,NORTH_MAGNETIC_POLE_VECTOR AT B0        PP049370
2971  1152  0C79  6006                    MPY   0,6                                          PP049380
2972  1158  0C7A  6017                    MPY   1,7                                          PP049390
2973  1164  0C7B  6028                    MPY   2,8                                          PP049400
2974  1166  0C7C  B421                    ADD   2,1                                          PP049410
2975  1168  0C7D  B420                    ADD   2,0           A2 AT B1                       PP049420
                                *                                                          PP049430
                                *           GET SEASON INDEX                               PP049440
                                *                                                          PP049450
                                *           AND DATE FOR SUN POSITION VECTOR               049460
2976  1180  0C7E  869C  (009C)            FETD  0,,TIME                                    049470
2977  1198  0C7F  42E7  (00E7)            MPYD  0,,=DF((((5D-3B31)/24)/3600)/1811)         049480
2978  1206  0C80  96C4  (00C4)            ADDD  0,,DAY_SINCE_JAN1_1972    811        01  049490
2979  1208  0C81  A420                    CLA   2,0                                        049500
2980  1214  0C82  F0240800                RSA   2,,4          SCALE DAYS AT B15            049510
2981  1216  0C84  DE01                    FLG   8                                          049520
2982    4R  0C85  FC39016D          $B1   CLAM  3,,365                                     049530
2983    2R  0C87  8023              $I    COM   2,3           GET DAYS MOD 365             049540
2984     6  0C88  D052  (0C8B)            BRL   $2                                         049550
2985    2R  0C89  B023                    SUB   2,3                                        049560
2986     6  0C8A  D804  (0C87)            BUC   $1                                         049570
2987    2R  0C8B  9C3C              $2    CLAM  3,,12          DEC 16 TO DEC 31            049580
2988     6  0C8C  F829015D                COMM  2,,349                                     049590
2989    10  0C8E  D03C  (0C9B)            BRG   $3                                         049600
2990    2R  0C8F  9C39                    CLAM  3,,9                                       049610
2991     6  0C90  F8290086                COMM  2,,182                                     049620
2992    10  0C92  D038  (0C9B)            BRG   $3                                         049630
2993    2R  0C93  9C36                    CLAM  3,,6                                       049640
2994     6  0C94  F829001F                COMM  2,,31                                      049650
2995    10  0C96  D034  (0C9B)            BRG   $3                                         049660
2996    2R  0C97  9C33                    CLAM  3,,3                                       049670
2997     4  0C98  982F                    COMM  2,,15                                      049680
2998     8  0C99  D031  (0C9B)            BRG   $3                                         049690
2999    2R  0C9A  9C30                    CLAM  3,,0                                       049700
```

```
3000      4R        0C9B  D086  (0CA2)  $3        BBF   $82                                                    049710
3001      10R       0C9C  F0371C9F                 STA   3,,SEASON_INDEX_NORTH     SAVE NORTH VALUE      049720
3002      14        0C9E  F4290087                 ADDM  2,,183                   SET UP FOR            049730
3003      16        0CA0  DEA0                     FLG   BT+EOR+B                   SOUTHERN HEMI         049740
3004      20        0CA1  D9CD  (0C85)             BUC   $81                                                  049750
3005      10R       0CA2  F0371CA0        $82      STA   3,,SEASON_INDEX_SOUTH                               049760
3006      52        0CA4  F08C1748                 FET   8,,SUN_CONS      K2,K1D,K3D,K5,K4,K6,-K7          PP049770
3007      68        0CA6  6819                     MPYD  1,9               K1*DAYS @  PI84                  049780
3008      74        0CA7  FC140010                 LSAD  1,,4                                               049790
3009      76        0CA9  B401                     ADD   0,1               *K2 = LS AT PI                   PP049800
3010      92        0CAA  6839                     MPYD  3,9               K3*DAYS @  PI84                  049810
3011      98        0CAB  FC340010                 LSAD  3,,4              RESCALE TO PI                    049820
3012      100       0CAD  B436                     ADD   3,6               K3*D+K4 = MS @ PI                049830
3013      110       0CAE  F8940800                 RSAD  9,,4              RESCALE DAYS TO B15              049840
3014      114       0CB0  F4A97FFF                 ADDM  10,,X(7FFF)       ADD 1/2 DAY TO FORM MEAN         049850
                                                  *                       LONGITUDE OF THE SUN @ PI        049860
3015      122       0CB2  C804                     FETD  0,4               GET MS                           049870
3016      130   *   0CB3  F80D1656                 BSV   SIN                                                049880
3017      136       0CB5  6C90                     MPY   9,0               K6*SIN(MS) @ PI IN R9            049890
3018      138       0CB6  A402                     CLA   0,2               LS @ PI                          049900
3019      140       0CB7  B409                     ADD   0,9                                                049910
3020      148   *   0CB8  F80D1656                 BSV   SIN               SIN(LS + K6*SIN(MS)) @ B1        049920
3021      154       0CBA  6070                     MPY   7,0               K5*SIN(LS +K6*SIN(MS))= S1@B1    049930
3022      156       0CBB  A487                     CLA   11,7                                               049940
3023      158       0CBC  9C80                     CLAM  8,,0                                               PP049950
3024      174       0CBD  6877                     MPYD  7,7               S1**2                            PP049960
3025      182       0CBE  9EF5  (00F5)             CLAD  0,,=DF(1B-2)                                       PP049970
3026      186       0CBF  B807                     SUBD  0,7                                                PP049980
3027      632       0CC0  1000                     SQRT  0,0               (1-S1**2)**.5 AT B1              PP049990
3028      640       0CC1  8410                     FETM  1,,0              MAKE ROOM                        050000
3029      644       0CC2  9F44                     CLAM  IX4,4             2LS                              050010
3030      652   *   0CC3  F80D1656                 BSV   SIN                                                PP050020
3031      658       0CC5  600C                     MPY   0,12               -K7*SIN(2LS)                    PP050030
3032      660       0CC6  B408                     ADD   0,11              K6*SIN(MS)                       PP050040
3033      666       0CC7  B1F0                     SUB   X15,0             L AT PI                          PP050050
3034      1100      0CC8  1400                     SINCOS 0,0                                               PP050060
3035      1106      0CC9  6004                     MPY   0,4                                                PP050070
3036      1108      0CCA  B400                     ADD   0,0               S2 B1                            050080
3037      1114      0CCB  6024                     MPY   2,4                                                PP050090
3038      1116      0CCC  A412                     CLA   1,2                                                PP050100
3039      1118      0CCD  B411                     ADD   1,1               S3 B1                            050110
3040      1130      0CCE  7DF2                     PTRD  X15,2             SAVE ADJACENT TO S1              PP050120
3041      1162      0CCF  D7C0                     PRN   12                                                 PP050130
```

```
                                *
                                *                    START INTEGRATION
                                *
3042   12R    0CD0  F4284000    $55    FETM  2,,F(18-1)          FM1,2,3 FOR COSX LESS THEN A
3043   22     0CD2  C02A               FET   2,10                GET P
3044   28     0CD3  6006               MPY   0,6                 P1 * S1
3045   34     0CD4  6017               MPY   1,7                 P2 * S2
3046   40     0CD5  6028               MPY   2,8                 P3 * S3
3047   42     0CD6  B421               ADD   2,1
3048   44     0CD7  B420               ADD   2,0                 P DOT S = COS (X) B2
3049   48     0CD8  F829F833           COMM  2,,F(-.158-2)       A
3050   52     0CDA  D155   (0CF0)      BRL   $20                 COS(X) LESS THAN -.15
3051    4R    0CDB  F829FE88           COMM  2,,F(-.048-2)       B
3052    8     0CDD  D048   (0CE6)      BLE   $15                 COS(X) LESS OR EQUAL THAN -.04
3053    2R    0CDE  9C50               CLAM  5,,0                FM1
3054    6     0CDF  FC492000           CLAM  4,,F(18-2)
3055    8     0CE1  B042               SUB   4,2                 1 - COS X
3056   12     0CE2  FC29428F           CLAM  2,,F(18-1+.048-1)   1 - B
3057   44     0CE4  D442               DIV   4,2                 FM2=(1-COSX)/(1-B) B1
3058   48     0CE5  D00A   (0CF0)      BUC   $20
3059    2R    0CE6  A452               CLA   5,2
3060    6     0CE7  F059FE88           SUBM  5,,F(-.048-2)       COSX - B  B2
3061   10     0CE9  FC49F833           CLAM  4,,F(-.158-2)
3062   12     0CEB  B042               SUB   4,2                 A - COSX  B2
3063   16     0CEC  FC29F8F6           CLAM  2,,F(-.158-1+.048-1) A-B B1
3064   48     0CEE  D442               DIV   4,2                 FM2 = (A - COSX)/(A-B)
3065   80     0CEF  D452               DIV   5,2                 FM1 = (COSX - B)/(A-B)
3066   12R    0CF0  D720               PRN   2                   $20
3067   30     0CF1  F02C16AC           FET   2,,NORTH_MAGNETIC_POLE_VECTOR
3068   36     0CF3  6008               MPY   0,11
3069   42     0CF4  601C               MPY   1,12
3070   48     0CF5  602D               MPY   2,13
3071   50     0CF6  B421               ADD   2,1
3072   52     0CF7  B420               ADD   2,0                 NP DOT P AT B1 = A5
3073   56     0CF8  D021   (0CFA)      BGE   $21
3074    2R    0CF9  A022               CLS   2,2                 A5 = ABSOLUTE(NP DOT P) B1
3075   14R    0CFA  C046               FET   4,6                 A5 IN R0
3076   22  *  0CFB  F80D16B8           BSV   ARCSIN
3077   24     0CFD  B400               ADD   0,0                 AA6 AT P1B-1 = MAGNETIC LATITUDE
3078   28     0CFE  B811               SUBD  1,1                 AAUR, BAUR
3079   38     0CFF  F4180E90           FETM  1,,AUR_DATA
3080   44     0D01  C002               FET   0,2                 AA6
3081    8R    0D02  F1180E78   $72     SUB   X1,,AUR_LIMITS
```

```
3082    12    0D04  D044  (0D09)          BLE   $70                                    PP050570
3083    2R    0D05  9411                  ADDM  1,,1                                   PP050580
3084    4     0D06  9814                  COMM  1,,4     AA6 TOO LARGE THEREFORE       PP050590
3085    8     0D07  D164  (0D1C)          BRE   $71       AAUR = BAUR = 0 (IF E)      PP050600
3086    4R    0D08  D8C7  (0D02)          BUC   $72                                    PP050610
3087    2R    0D09  9810          $70     COMM  1,,0     AA6 TOO SMALL THEREFORE       PP050620
3088    6     0D0A  D161  (0D1C)          BRE   $71       AAUR = BAUR = 0 (IF E)      PP050630
3089    2R    0D0B  9011                  SUBM  1,,1     AA6 OK R1 = 0, 1, OR 2        PP050640
3090    6     0D0C  4416                  MPIM  1,,6     6 CONS FOR EACH LAT           PP050650
3091    8     0D0D  B421                  ADD   2,1      DATA ADDRESS FOR THIS LAT     PP050660
3092    14    0D0E  A202                  CLS   I0,2     A1  PI-285                    PP050670
3093    20    0D0F  6003                  MPY   0,3      *AA6 PIB-1                    PP050680
3094    26    0D10  B121                  SUB   X2,,1    B   PI-1B4                   PP050690
3095    32    0D11  6003                  MPY   0,3      *AA6                          PP050700
3096    38    0D12  B122                  SUB   X2,,2    C   B3                        PP050710
3097    44    0D13  465D  (0DDD)          MPI   0,,HX0100 SHIFT LEFT 8  AAUR AT B-5    PP050720
3098    46    0D14  A440                  CLA   4,0                                    PP050730
3099    52    0D15  A123                  CLS   X2,,3    DA                            PP050740
3100    58    0D16  6003                  MPY   0,3      *AA6                          PP050750
3101    64    0D17  B124                  SUB   X2,,4    DB                            PP050760
3102    70    0D18  6C03                  MPY   0,3      *AA6                          PP050770
3103    76    0D19  B125                  SUB   X2,,5    DC                            PP050780
3104    82    0D1A  465E  (0DDE)          MPI   0,,HX0200 SHIFT LEFT 9  BAUR AT B-6    PP050790
3105    84    0D1B  A450                  CLA   5,0                                    PP050800
3106    6R    0D1C  60AA          $71     MPY   10,10    A5**2                         PP050810
3107    12    0D1D  9E62  (0DE2)          CLA   0,,HX2000 1 B2                         PP050820
3108    14    0D1E  B00A                  SUB   0,10                                   PP050830
3109    460   0D1F  1000                  SQRT  0                                      PP050840
3110    468   0D20  C1F4                  FET   X15,,4   A2                            PP050850
3111    470   0D21  A000                  CLS   0,0                                    PP050860
3112    478   0D22  4263  (0DE3)          MPY   0,,HX4000 SHIFT RIGHT 1                PP050870
3113    510   0D23  D4C1                  DIV   0,1      B1 AT B1                      PP050880
3114    514   0D24  FC194000              CLAM  1,,F(1B-1)                             PP050890
3115    516   0D26  A420                  CLA   2,0                                    PP050900
3116    522   0D27  6022                  MPY   2,2                                    PP050910
3117    526   0D28  4424                  LSA   2,,2     281**2 B1                     PP050920
3118    528   0D29  B012                  SUB   1,2                                    PP050930
3119    532   0D2A  FC297FFF              CLAM  2,,X(7FFF) PI/2  AT PIB-1              PP050940
3120    534   0D2C  B024                  SUB   2,4      -AA6 = B4 PIB-1               PP050950
3121    536   0D2D  A432                  CLA   3,2                                    PP050960
3122    542   0D2E  6033                  MPY   3,3      B4**2                         PP050970
3123    548   0D2F  6032                  MPY   3,2      B4**3 = AA6 AT PI+3B-3        PP050980
3124    554   0D30  6003                  MPY   0,3      AA2 AT PI+3B-2                PP050990
```

```
3125  560        0031  6021                MPY   2,1          AA4 AT PI                          PP051000
3126  566        0032  6013                MPY   1,3          AA3 AT PI+38-2                     PP051010
3127  570        0033  FC891C80            CLAM  11,,AUR_SAVE                                    PP051020
3128  602        0035  7668                PTR   I6,11        SAVE AA2 - AA6, AAUR, BAUR         PP051030
                                     *                                                           PP051040
                                     *        DETERMINE CONDUCTIVITY LEVEL                       PP051050
                                     *                                                           PP051060
3129  604        0036  A40D                CLA   0,13         P1                                 PP051070
3130  608        0037  D053   (0038)       BRL   $83          SOUTHERN HEMISPHERE                 051080
3131    8R       0038  F48A1C9F            CLA   11,,SEASON_INDEX_NORTH                          051090
3132   12        003A  D002   (003D)       BUC   $84                                             051100
3133    8R       0038  F48A1CA0      $83   CLA   11,,SEASON_INDEX_SOUTH                        051110
3134    2R       003D  9C10          $84   CLAM  1,,0                                           051120
3135   10  *     003E  F80D1688            BSV   ARCSIN       LATITUDE                           PP051130
3136   18        0040  8410                FETM  1,,0                                           PP051140
3137   30        0041  C9F2                FETD  X15,2        P2 IN R0 AND P3 IN R1              PP051150
3138   32        0042  A421                CLA   2,1          P3                                 PP051160
3139  570        0043  1800                ATAN  0,0          LONGITUDE                          PP051170
3140  574        0044  F4294000            ADDM  2,,F(18-1)   = 90 DEGREES  0 = SOUTH POLE       PP051180
3141  580        0046  F0240024            MPYM  2,,F((180)/5B15) LAT WITH B1=5DEG               PP051190
3142  584        0048  FC090E39            SUBM  0,,F((20)/180) START AT 20 DEG EAST             PP051200
3143  592        004A  5263   (00E3)       MPLM  I0,,HX4000   SCALE AT 2PI AND POSITIVE         PP051210
3144    6R       004B  FC040048      $30   MPYM  0,,F((360)/5B15) LONG WITH B1 = 5 DEG           PP051220
3145    8        004D  9827                COMM  2,,7         TEST FOR 55 DEGREE LAT             PP051230
3146   12        004E  D022   (0051)       BGE   $31                                            PP051240
3147    6R       004F  FC044000            RSA   0,,1         LONG WITH B1 = 10 DEC              PP051250
3148   10R       0051  F12C1922      $31   FET   X2,,COND_TABLE GET ADDRESS FOR THIS LAT         PP051260
3149   12        0053  A420                CLA   2,0                                            PP051270
3150   20        0054  D700                PRN   0                                              PP051280
3151   22        0055  9C33                CLAM  3,,3          SET UP 4 COUNTER TO              PP051290
3152   24        0056  A423                CLA   2,3           TRIGGER FIRST TIME               PP051300
                                     *                                                           PP051310
3153    2R       0057  9C40          $32   CLAM  4,,0          CLEAR WORD FOR DOUBLE SHIFT      PP051320
3154   12        0058  F42C005C            BXU   2,,$35       TEST - TIME FOR NEXT WORD        PP051330
3155    6R       005A  A651                CLA   I5,1          YES-READ NEXT DATA WORD          PP051340
3156    8        005B  9411                ADDM  1,,1          AND INCREMENT ADDRESS            PP051350
3157    6R       005C  FC440010      $35   MPIDM 4,,16        PLACE NEXT 4 BITS IN UPPER WORD 5PP051360
3158    8        005E  984F                COMM  4,,15         IS IT WATER (F)                  PP051370
3159   12        005F  D019   (0069)       BNE   $36          IF YES FIGURE OUT HOW MANY       PP051380
3160    2R       0060  9C40                CLAM  4,,0          GET                              PP051390
3161   12        0061  F42C0065            BXU   2,,$37       NEXT                             PP051400
3162    6R       0063  A651                CLA   I5,1            4 BITS                        PP051410
3163    8        0064  9411                ADDM  1,,1            AND                           PP051420
```

```
3164        6R    0D65  FC440010          $37       MPIDM   4,,16          DECREMENT LONGITUDE                    PP051430
3165         8    0D67  B004                        SUB     0,4              COUNT WITH REPEAT CODE                 PP051440
3166        10    0D68  9C4F                        CLAM    4,,15          CONDUCTIVITY LEVEL FOR WATER             PP051450
3167        2R    0D69  9001              $36       SUBM    0,,1         DECREMENT LONG COUNT                       PP051460
3168         6    0D6A  D924   (0D57)               BGE     $32          DONE WHEN LONG COUNT NEGATIVE              PP051470
3169        4R    0D6B  4443                        MPIM    4,,3          SET LEVEL UP FOR THREE FREQ               PP051480
3170         6    0D6C  A454                        CLA     5,4                                                     PP051490
3171        22    0D6D  D740                        PRN     4                                                       PP051500
                                          *                                                                         PP051510
                                          *                                                                         PP051520
                                          * INTEGRATION OF TERMS THAT ARE A FUNCTION OF FREQUENCY                   PP051530
                                          *                                                                         PP051540
3172        32    0D6E  8422                        FETM    2,,2           FREQUENCY COUNTER JF                     PP051550
3173        6R    0D6F  A5F8              $50       CLA     X15,8          GET ADDRESS OF RESULTS                   PP051560
3174        12    0D70  C001                        FET     0,1            JF                                       PP051570
3175        16    0D71  4409                        MPIM    0,,9           GET ADDRESS FOR THIS FREQUENCY           PP051580
3176        18    0D72  B410                        ADD     1,0                                                     PP051590
3177        20    0D73  A40C                        CLA     0,12           SEASON INDEX                             PP051600
3178        22    0D74  B402                        ADD     0,2            FOR THIS FREQ                            PP051610
3179        30    0D75  F50A16EE                    CLA     X0,,DIURNAL_CONSTANT_TABLE K                            PP051620
3180        36    0D77  6007                        MPY     0,7            K*FM2                                    PP051630
3181        38    0D78  B408                        ADD     0,8            F = FM1 + K*FM2  B1                      PP051640
3182        46    0D79  C1F8                        FET     X15,8           INTEGRATION MARKER NONE ZERO            PP051650
3183        50    0D7A  D114   (0D8F)               BNE     $41             FIRST TIME THRU                         PP051660
3184        6R    0D7B  A522                        CLA     X2,2            F(OLD)                                  PP051670
3185         8    0D7C  B001                        SUB     0,1            F(OLD) - F  B1                           PP051680
3186        12    0D7D  4408                        LSA     0,,3           B-2                                      PP051690
3187        18    0D7E  6000                        MPY     0,0                                                     PP051700
3188        24    0D7F  C000                        FET     0,0                                                     PP051710
3189        30    0D80  F0040888                    MPYM    0,,F(((6.70)/2)/3.1415984) K11                          PP051720
3190        38    0D82  6131                        MPY     X3,1           TIMES C21                                PP051730
3191        44    0D83  B530                        ADD     X3,0           + C11                                    PP051740
3192        52    0D84  7530                        PTR     X3,0           C11  2PI B1                              PP051750
3193        58    0D85  F0040FEA                    MPYM    0,,F(((25.0)/2)/3.1415985) K21                           051760
3194        64    0D87  C001                        FET     0,1            F                                        PP051770
3195        74    0D88  F14616AF                    MPY     X4,,ALPHA_0                                             PP051780
3196        76    0D8A  B400                        ADD     0,0            ALPHA * F B0                              051790
3197        84    0D8B  6131                        MPY     X3,1           C21*ALPHA*F  2PI B1                      PP051800
3198        86    0D8C  B410                        ADD     1,0            C21                                      PP051810
3199        94    0D8D  D700                        PRN     0                                                       PP051820
3200        98    0D8E  D005   (0D94)               BUC     $42                                                     PP051830
3201        2R    0D8F  A401              $41       CLA     0,1            F AT B1                                  PP051840
3202        12    0D90  F13616AF                    MPY     X3,,ALPHA_0                                             PP051850
```

```
3203        18      0D92  F004145F          MPYM  0,,F(((1)/2)/3.14159) C21(I) 2PI B1          PP051860
3204         8R     0D94  7521        $42   PTR   X2,1              C21 2PI B1                 PP051870
3205        16      0D95  7112              STA   X1,2              SAVE F FOR F(OLD)          PP051880
3206        24      0D96  C010              FET   1,0               F                          PP051890
3207        34      0D97  F8040040         RSAD  0,,9              DOUBLE F AT B10            PP051900
3208        42      0D99  8D33              ADDD  X3,3              GG B10                     PP051910
3209        54      0D9A  7D33              PTRD  X3,3                                         PP051920
3210        60      0D9B  C002              FET   0,2               JF                         PP051930
3211        72      0D9C  C965              FETD  X6,,5             BAUR, AAUR                 PP051940
3212        76      0D9D  4425              MPIM  2,,5                                         PP051950
3213        86      0D9E  8424              FETM  2,,4                                         PP051960
3214         8R     0D9F  F51A0E7C    $74   CLA   X1,,CAY_TABLE                               PP051970
3215        16      0DA1  6318              MPY   IX1,11            *AA(I)                     PP051980
3216        18      0DA2  8430              ADD   3,0               AAUR + SUM CAY(I)*AA(I) B-5 PP051990
3217        26      0DA3  F55A0E81          CLA   X5,,DCAY_TABLE                               PP052000
3218        34      0DA5  6318              MPY   IX1,11            *AA(I)                     PP052010
3219        36      0DA6  8440              ADD   4,0               BAUR + SUM DCAY(IC,I)*AA(I) B-6 PP052020
3220        38      0DA7  9451              ADDM  5,,1                                         PP052030
3221        46      0DA8  C41A    (0D9F)    BXU   1,,$74                                       PP052040
3222         2R     0DA9  A458              CLA   5,8               JF                         PP052050
3223         4      0DAA  845A              ADD   5,10              +IC                        PP052060
3224        12      0DAB  F55A0E47          CLA   X5,,CAY1_TABLE B-5                           PP052070
3225        14      0DAD  8403              ADD   0,3                                          PP052080
3226        24      0DAE  F186171F          MPY   X8,,RAT_TABLE   FREQ CON B1                  PP052090
3227        26      0DB0  A430              CLA   3,0               A(JF) B-4                  PP052100
3228        34      0DB1  F55A0110          CLA   X5,,DCAY1_TABLE B-6                          PP052110
3229        36      0DB3  8404              ADD   0,4                                          PP052120
3230        46      0DB4  F186171F          MPY   X8,,RAT_TABLE                                PP052130
3231        48      0DB6  A440              CLA   4,0               B(JF) B-5                  PP052140
3232        60      0DB7  D720              PRN   2                                            PP052150
3233        62      0DB8  A421              CLA   2,1                B AT B-5                  PP052160
3234        68      0DB9  6013              MPY   1,3                B*F                       PP052170
3235        70      0DBA  8401              ADD   0,1               DELTA THETA 3 AT B-4       PP052180
3236        80      0DBB  4802              RSAD  0,,14             B10                        PP052190
3237        88      0DBC  8D47              ADDD  X4,7              THETA 3 B10                PP052200
3238       100      0DBD  7D47              PTRD  X4,7                                         PP052210
3239       106      0DBE  A5F1              CLA   X15,1              P1                        PP052220
3240       112      0DBF  6000              MPY   0,0               P1**2 B2                   PP052230
3241       122      0DC0  FC060E77          MPY   0,,CI_TABLE       DELTA THETA 2 B-4          052240
3242       132      0DC2  F8040040         RSAD  0,,9              B5                         PP052250
3243       140      0DC4  8D25              ADDD  X2,5                                         PP052260
3244       152      0DC5  7D25              PTRD  X2,5               THETA 2 AT B10            PP052270
3245       162      0DC6  F41C0D6F          BXU   1,,$50            FREQUENCY INDEX           PP052280
```

```
3246    22R   0DC8  D770                    PRN     7                                          PP052290
                                *                                                            PP052300
3247    24    0DC9  B0DD                    SUB     13,13          INTEGRATION MARKER EQUAL ZERO PP052310
                                *             TEST FOR END OF INTEGRATION                    PP052320
                                *                                                            PP052330
3248    36    0DCA  868D  (008D)             FETD    0,,INTEGRATION_COUNTER                     PP052340
3249    46    0DCB  F8CB1AC8                SUBD    0,,=DF((.01)/3.14159265)                   PP052350
3250    58    0DCD  7C0D  (008D)            PTRD    0,,INTEGRATION_COUNTER                     PP052360
3251    62    0DCE  D14C  (0DE8)            BLE     $60            DONE                        PP052370
3252    18R   0DCF  C068                    FET     6,11           GET AX AND P + 1 REGISTER   PP052380
3253    20    0DD0  A465                    CLA     6,5            AX CROSS P                  PP052390
3254    26    0DD1  6061                    MPY     6,1                                        PP052400
3255    32    0DD2  6013                    MPY     1,3                                        PP052410
3256    38    0DD3  6032                    MPY     3,2                                        PP052420
3257    44    0DD4  6024                    MPY     2,4                                        PP052430
3258    50    0DD5  6040                    MPY     4,0                                        PP052440
3259    56    0DD6  6005                    MPY     0,5                                        PP052450
3260    58    0DD7  B062                    SUB     6,2            1                           PP052460
3261    60    0DD8  B030                    SUB     3,0            2                           PP052470
3262    62    0DD9  B041                    SUB     4,1            3                           PP052480
3263    66    0DDA  FC29028F                CLAM    2,,F(.0181)    SIN(DTHETA) B-1             PP052490
3264    72    0DDC  6032                    MPY     3,2                                        PP052500
3265    78    0DDD  6042                    MPY     4,2                                        PP052510
3266    84    0DDE  6062                    MPY     6,2                                        PP052520
3267    96    0DDF  D720                    PRN     2                                          PP052530
3268    100   0DE0  FC297FFE                CLAM    2,,F(.99995)   COS DTHETA B0               PP052540
3269    106   0DE2  6092                    MPY     9,2                                        PP052550
3270    112   0DE3  60A2                    MPY     10,2                                       PP052560
3271    118   0DE4  60B2                    MPY     11,2                                       PP052570
3272    120   0DE5  B493                    ADD     9,3            NEW P1 B1                   PP052580
3273    122   0DE6  B4A0                    ADD     10,0           NEW P2                      PP052590
3274    124   0DE7  B481                    ADD     11,1           NEW P3                      PP052600
3275    138   0DE8  D730                    PRN     3                                          PP052610
3276    144   0DE9  04000CD0                BUC     $55                                        PP052620
                                *                                                            PP052630
                                *               INTEGRATION COMPLETE                         PP052640
                                *                                                            PP052650
3277    28R   0DEB  D7A0            $60     PRN     10                                         PP052660
3278    30    0DEC  A424                    CLA     2,4            STA N0                      PP052670
3279    34    0DED  4423                    MPIM    2,,3                                       PP052680
3280    48    0DEE  C041                    FET     4,1            THETA 1                     PP052690
3281    58    0DEF  F83B008D                SUBD    3,,INTEGRATION_COUNTER                     PP052700
3282    184   0DF1  DC13                    DIVD    1,3            AVERAGING CONSTANT AT B+0   PP052710
```

```
3283   192        0DF2  867D   (00FD)          FET    0,,RTJ_ADD                                    052720
3284   200        0DF3  864C   (00CC)          FET    0,,BASE+1          "COMPUTE THETA1 FOR THE    *1052730
3285   208  *     0DF4  F80D0862                BSV    COMPUTE_THETA1        "BASE STATION           052740
3286   212        0DF6  AC50                    CLAD   5,0                                           052750
3287   222        0DF7  D710                    PRN    1                                             052760
3288   230        0DF8  8414                    FETM   1,,4               FREQUENCY INDEX            PP052770
3289    6R        0DF9  C00A            $61     FET    0,10               DATA ADDRESS               PP052780
3290   12         0DFA  C001                    FET    0,1                JF                         PP052790
3291   16         0DFB  4409                    MPIM   0,,9                                           052800
3292   22         0DFC  FC044000                RSA    0,,1                                          PP052810
3293   24         0DFE  B410                    ADD    1,0                FREQ DATA ADDRESS          PP052820
3294   26         0DFF  A401                    CLA    0,1                DATA ADDRESS               PP052830
3295   28         0E00  9405                    ADDM   0,,5               INCREMENT DATA ADDRESS BY 5 PP052840
3296   36         0E01  8412                    FETM   1,,2               20 COUNTER                 052850
3297   12R        0E02  CB02            $80     FETD   IX0,2              AVERAGING                  PP052860
3298   28         0E03  6809                    MPYD   0,9                    OF                    PP052870
3299   40         0E04  7F24                    PTRD   IX2,4                    THETA'S               PP052880
3300   48         0E05  CC04   (0E02)          BXUD   0,,$80                                         052890
3301   12R        0E06  D720                    PRN    2                                             PP052900
3302   26         0E07  F91C176F                FETD   X1,,DCAY_ONE        DTHETA*DCAY AT PI          PP052910
3303   44         0E09  6923                    MPYD   X2,3                GG B10                     PP052920
3304   170        0E0A  DC0A                    DIVD   0,10               A=THETA 1 AT PI            PP052930
3305   180        0E0B  FD3B1795                ADDD   X3,,CAY_ONE        B10                        PP052940
3306   188        0E0D  BD27                    ADDD   X2,7               + THETA 3                  PP052950
3307    6R        0E0E  FC040020        PLOT17  LSAD   0,,5               SCALE CYCLES B5. SUBD Q SMLTR PP052960
3308   16         0E10  F1C71CB9                STA    X12,,PP_THETA3                                PP052970
3309   24         0E12  AD20                    CLAD   X2,,0              C11 IN R1, C21 IN R0, AT 2PIB1 PP052980
3310   26         0E13  B401                    ADD    0,1                C = C21 + C11  B1 CYCLES    PP052990
3311   30         0E14  F409028F                ADDM   0,,F(.04B-1)       ADD 4 CEC'S                PP053000
3312   36         0E16  6000                    MPY    0,0                C**2                       PP053010
3313   46         0E17  F1C71CA1                STA    X12,,PROP_C                                   PP053020
3314   50         0E19  AC0A                    CLAD   0,10               THETA 1                    PP053030
3315   52         0E1A  94C1                    ADDM   12,,1              INCREMENT STATION FREQ POINTER PP053040
3316   60         0E1B  C013                    FET    1,3                FREQ                       PP053050
3317   66         0E1C  A5F2                    CLA    X15,,2             STA                        PP053060
3318   76         0E1D  FC0C1C68                FET    0,,PROP_PRED_RESULTS+5                        053070
3319   86         0E1F  F51710DF                PTR    X1,,PP_THETA2      CYCLES B5                  053080
                                        *                                "COMPUTE THETA C = PREDICTED *1053090
3320   94  *     0E21  F80D0847                BSV    THETA_C            "PHASE FOR THIS STATION / FREQ PP053100
                                        *                                "IS THIS PHASE               *1053110
3321   98        0E23  DCD7   (0E28)          BCF    $44                "     DIFFERENCE NAVIGATION? %R053120
                                        *                                "SUB ALWAYS PHASE DIFFERENCE PP053130
                                        *                                "                            PP053140
```

```
                                        *                                   "SET UP ARGUMENTS FOR THETAC BASEPP053150
                                        *                                   "(THETA 1), FREQ, BASE STA NO)  PP053160
3322     8R      0E24  C019             *       FET     1,9                 THETA 1 BASE                    PP053170
3323     14      0E25  C005             *       FET     0,5                 FREQ                            PP053180
3324     22      0E26  864C   (00CC)    *       FET     0,,BASE+1                                           PP053190
                                        *                                   "COMPUTE THETA C FOR THE        *1053200
3325     30  *   0E27  F80D0847         *       BSV     THETA_C             "     BASE STATION              PP053210
3326     34      0E29  8820             *       SUBD    2,0                 "THETA P = THETA C - THETA C BASEPP053220
                                        *                                   "                               PP053230
                                        *                                   "THETA P = PREDICTED TRACKING   PP053240
                                        *                                   "          FILTER MEASUREMENT   PP053250
                                        *                                   "          (FRACTIONS OF A CYCLE PP053260
                                        *                                   "          + THE TOTAL INTEGER  PP053270
                                        *                                   "          LANE COUNT)          PP053280
3327     38      0E2A  0005   (0E30)    *       BUC     $45                                                 PP053290
3328     14R     0E2B  F80C1C20         $44     FETD    0,,XXX+2            T ZERO                          PP053300
3329     34      0E2D  F9560E41         *       MPYD    X5,,FREQ_TABLE      CYCLES B10                      PP053310
3330     38      0E2F  8C20             *       ADDD    2,0                 "RHO - RHO NAVIGATION"          PP053320
                                        *                                   "                               PP053330
                                        *                                   "CORRECT PREDICTED PHASE FOR    PP053340
                                        *                                   "T ZERO TERM                    PP053350
                                        *                                   "THETA P = THETA C + T(0)       PP053360
3331     6R      0E30  A5F2             $45     CLA     X15,,2              STA NO                          PP053370
3332     10      0E31  4406             *       MPIM    0,,6                "COMPUTE POINTER TO THE TRACKING PP053380
                                        *                                   "FILTER PHASE ESTIMATE P        PP053390
3333     12      0E32  8405             *       ADD     0,5                 FREQ                            PP053400
3334     26      0E33  F90C1EA3         *       FETD    X0,,PHI_ESTIMATE    "UPDATE LANE COUNT"             %S053410
3335     30      0E35  8804             *       SUBD    0,4                                                 PP053420
                                        *                                   "                               PP053430
3336     36      0E36  FC040800         *       LSAD    0,,11               "REPLACE THE INTEGER PART OF P  PP053440
3337     46      0E38  F8040010         *       RSAD    0,,11               "(IN CYCLES) WITH THE INTEGER   PP053450
3338     50      0E3A  BC04             *       ADDD    0,4                 "PART OF THETA P.  ADJUST THE   PP053460
3339     64      0E3B  FD271EA3         *       PTRD    X2,,PHI_ESTIMATE    "LANE COUNT IN P BY 1 IF NECES-PP053470
3340     80      0E3D  D740             *       PRN     4                   "SARY SO THAT THETA P AND P ARE PP053480
                                        *                                   "WITHIN 1/2 CYCLE OF EACH OTHER PP053490
                                        *                                   "ARE THERE MORE                 *1053500
3341     90      0E3E  FC0C00F9         *       BXUD    0,,PROPAGATION_PREDICTION$61 "FREQ TO PROC?"        PP053510
                                        *                                   "EXIT"                          PP053520
                                        *                                   "                               PP053530
                                        *                                   "THE ARGUMENT IS UNDISTURBED    PP053540
                                        *                                   "45 WORDS HAVE BEEN ADDED TO THE PP053550
3342     32R     0E40  D5A0             *       BBK     10                  "R15 PUSH DOWNSTACK             PP053560
                                        *                                                                   PP053570
```

```
                                        *                                                                                    PP053580
                                        *                                                                                    PP053590
3343    0E41  008FFFF6  FREQ_TABLE  COND  F((441.176D-6)*10.2000D38-10)                                                     PP053600
3344    0E43  008FFFF3              COND  F((441.176D-6)*13.6000D38-10)                                                     PP053610
3345    0E45  009FFFD6              COND  F((441.176D-6)*11.3333D38-10)                                                     PP053620
                                        *                                                                                    PP053630
                                        *                                                                                    PP053640
3346    0E47  E810      CAY1_TABLE  CON   F(((-27.0D-6)*.9974)*217.021B5)                                          10.2PP053650
3347    0E48  DC89                  CON   F(((-40.0D-6)*.9974)*217.021B5)                                          13.6PP053660
3348    0E49  E3A1                  CON   F(((-32.0D-6)*.9974)*217.021B5)                                          11.3PP053670
3349    0E4A  EE45                  CON   F(((-20.0D-6)*.9974)*217.021B5)                                              PP053680
3350    0E4B  E0F8                  CON   F(((-35.0D-6)*.9974)*217.021B5)                                              PP053690
3351    0E4C  E810                  CON   F(((-27.0D-6)*.9974)*217.021B5)                                              PP053700
3352    0E4D  07FB                  CON   F(((+09.0D-6)*.9974)*217.021B5)                                              PP053710
3353    0E4E  EB9C                  CON   F(((-23.0D-6)*.9974)*217.021B5)                                              PP053720
3354    0E4F  F8E8                  CON   F(((-08.0D-6)*.9974)*217.021B5)                                              PP053730
3355    0E50  1D42                  CON   F(((+33.0D-6)*.9974)*217.021B5)                                              PP053740
3356    0E51  1862                  CON   F(((+27.5D-6)*.9974)*217.021B5)                                              PP053750
3357    0E52  202F                  CON   F(((+36.3D-6)*.9974)*217.021B5)                                              PP053760
3358    0E53  15CF                  CON   F(((+24.6D-6)*.9974)*217.021B5)                                              PP053770
3359    0E54  2703                  CON   F(((+44.0D-6)*.9974)*217.021B5)                                              PP053780
3360    0E55  1CFE                  CON   F(((+32.7D-6)*.9974)*217.021B5)                                              PP053790
3361    0E56  0E74                  CON   F(((+16.3D-6)*.9974)*217.021B5)                                              PP053800
3362    0E57  2222                  CON   F(((+38.5D-6)*.9974)*217.021B5)                                              PP053810
3363    0E58  166E                  CON   F(((+25.3D-6)*.9974)*217.021B5)                                              PP053820
3364    0E59  0701                  CON   F(((+07.9D-6)*.9974)*217.021B5)                                              PP053830
3365    0E5A  1D6F                  CON   F(((+33.2D-6)*.9974)*217.021B5)                                              PP053840
3366    0E5B  10EF                  CON   F(((+19.1D-6)*.9974)*217.021B5)                                              PP053850
3367    0E5C  02D6                  CON   F(((+03.2D-6)*.9974)*217.021B5)                                              PP053860
3368    0E5D  1A99                  CON   F(((+30.0D-6)*.9974)*217.021B5)                                              PP053870
3369    0E5E  0D1F                  CON   F(((+14.8D-6)*.9974)*217.021B5)                                              PP053880
3370    0E5F  FFD3                  CON   F(((-00.2D-6)*.9974)*217.021B5)                                              PP053890
3371    0E60  1878                  CON   F(((+27.6D-6)*.9974)*217.021B5)                                              PP053900
3372    0E61  0AA4                  CON   F(((+12.0D-6)*.9974)*217.021B5)                                              PP053910
3373    0E62  FD57                  CON   F(((-03.0D-6)*.9974)*217.021B5)                                              PP053920
3374    0E63  1682                  CON   F(((+25.6D-6)*.9974)*217.021B5)                                              PP053930
3375    0E64  0828                  CON   F(((+09.2D-6)*.9974)*217.021B5)                                              PP053940
3376    0E65  FB7A                  CON   F(((-05.1D-6)*.9974)*217.021B5)                                              PP053950
3377    0E66  151A                  CON   F(((+23.8D-6)*.9974)*217.021B5)                                              PP053960
3378    0E67  06A6                  CON   F(((+07.5D-6)*.9974)*217.021B5)                                              PP053970
3379    0E68  FA53                  CON   F(((-06.4D-6)*.9974)*217.021B5)                                              PP053980
3380    0E69  144E                  CON   F(((+22.9D-6)*.9974)*217.021B5)                                              PP053990
3381    0E6A  057F                  CON   F(((+06.2D-6)*.9974)*217.021B5)                                              PP054000
```

```
3382  0E6B  F99E            CON   F(((-07.2D-6)*.9974)*217.021B5)                                PP054010
3383  0E6C  13AF            CON   F(((+22.2D-6)*.9974)*217.021B5)                                PP054020
3384  0E6D  049C            CON   F(((+05.2D-6)*.9974)*217.021B5)                                PP054030
3385  0E6E  F8E8            CON   F(((-08.0D-6)*.9974)*217.021B5)                                PP054040
3386  0E6F  1310            CON   F(((+21.5D-6)*.9974)*217.021B5)                                PP054050
3387  0E70  03FD            CON   F(((+04.5D-6)*.9974)*217.021B5)                                PP054060
3388  0E71  F833            CON   F(((-08.8D-6)*.9974)*217.021B5)                                PP054070
3389  0E72  129E            CON   F(((+21.0D-6)*.9974)*217.021B5)                                PP054080
3390  0E73  035E            CON   F(((+03.8D-6)*.9974)*217.021B5)                                PP054090
3391  0E74  F805            CON   F(((-09.0D-6)*.9974)*217.021B5)                                PP054100
3392  0E75  1271            CON   F(((+20.8D-6)*.9974)*217.021B5)                                PP054110
3393  0E76  0375            CON   F(((+03.9D-6)*.9974)*217.021B5)                                PP054120
                     *                                                                          PP054130
                     *                                                                          PP054140
3394  0E77  B08F     CI_TABLE CON   F((((((-.336D-4)*.9974)*217.021B+6)*4)/3)  13.6              054150
                     *                                                                          PP054160
                     *                                                                          PP054170
3395  0E78  53E9     AUR_LIMITS CON F((1.02974)/3.141592658-1)  PI8-1                           PP054180
3396  0E79  0889             CON   F((0.10472)/3.141592658-1)  PI8-1                           PP054190
3397  0E7A  0222             CON   F((0.02618)/3.141592658-1)  PI8-1                           PP054200
3398  0E7B  149F             CON   F((0.25307)/3.141592658-1)  PI8-1                           PP054210
                     *                                                                          PP054220
                     *                                                                          PP054230
3399  0E7C  FD40     CAY_TABLE CON  F((((-0.4D-6)*217.021)*.9974)*31.00628+3)  PI-3B-          PP054240
3400  0E7D  0000             CON   0                                                            PP054250
3401  0E7E  FE31             CON   F((((-.65D-6)*217.021)*.9974)*3.14159B+5)  PI-1B-          PP054260
3402  0E7F  0000             CON   0                                                            PP054270
3403  0E80  0107             CON   F((((1.32D-6)*217.021)*.9974)*3.14159B+4)  PI-1B-          PP054280
                     *                                                                          PP054290
                     *                                                                          PP054300
                     *                                                                          PP054310
                     *                                                                          PP054320
3404  0E81  267D     DCAY_TABLE CON F((((+2.80)*217.021)*.9974)*31.00628+4D-6)   10.2          PP054330
3405  0E82  EB62             CON   F((((-1.50)*217.021)*.9974)*31.00628+4D-6)   10.2          PP054340
3406  0E83  039F             CON   F((((+0.65)*217.021)*.9974)*3.14159B+6D-6)   10.2          PP054350
3407  0E84  204D             CON   F((((+4.70)*217.021)*.9974)*31.00628+3D-6)   10.2          PP054360
3408  0E85  FC53             CON   F((((-1.32)*217.021)*.9974)*3.14159B+5D-6)   10.2          PP054370
3409  0E86  1904             CON   F((((+1.82)*217.021)*.9974)*31.00628+4D-6)   13.6          PP054380
3410  0E87  EC58             CON   F((((-1.43)*217.021)*.9974)*31.00628+4D-6)   13.6          PP054390
3411  0E88  039F             CON   F((((+0.65)*217.021)*.9974)*3.14159B+6D-6)   13.6          PP054400
3412  0E89  1AAA             CON   F((((+3.88)*217.021)*.9974)*31.00628+3D-6)   13.6          PP054410
3413  0E8A  FC53             CON   F((((-1.32)*217.021)*.9974)*3.14159B+5D-6)   13.6          PP054420
3414  0E8B  2070             CON   F((((+2.36)*217.021)*.9974)*31.00628+4D-6)   11.3          PP054430
```

```
3415                    0E8C  EC35                    CON     F((((-1.44)*217.021)*.9974)*31.0062B+4D-6)  11.3PP054440
3416                    0E8D  039F                    CON     F((((+0.65)*217.021)*.9974)*3.141598+6D-6)  11.3PP054450
3417                    0E8E  1001                    CON     F((((+4.22)*217.021)*.9974)*31.0062B+3D-6)  11.3PP054460
3418                    0E8F  FC53                    CON     F((((-1.32)*217.021)*.9974)*3.141598+5D-6)  11.3PP054470
                                              *                                                           PP054480
                                              *                                                           PP054490
3419                    0E90  02A6            AUR_DATA  CON     F((((00310.04)*9.869598-5)*.9974)*217.021D-6)  PP054500
3420                    0E91  FC83                    CON     F((((-0641.39)*3.141598-4)*.9974)*217.021D-6)  PP054510
3421                    0E92  0126                    CON     F(((00331.718-3)*.9974)*217.021D-6)            PP054520
3422                    0E93  07F3                    CON     F((((00930.13)*9.869598-5)*.9974)*217.021D-6)  PP054530
3423                    0E94  F5A3                    CON     F((((-1905.09)*3.141598-4)*.9974)*217.021D-6)  PP054540
3424                    0E95  0361                    CON     F(((00975.478-3)*.9974)*217.021D-6)            PP054550
3425                    0E96  F092                    CON     F((((-1805.55)*9.869598-5)*.9974)*217.021D-6)  PP054560
3426                    0E97  168D                    CON     F((((04179.73)*3.141598-4)*.9974)*217.021D-6)  PP054570
3427                    0E98  F7A3                    CON     F(((-2414.908-3)*.9974)*217.021D-6)            PP054580
3428                    0E99  0395                    CON     F((((-5197.77)*9.869598-5)*.9974)*217.021D-6)  PP054590
3429                    0E9A  406A                    CON     F((((11840.17)*3.141598-4)*.9974)*217.021D-6)  PP054600
3430                    0E9B  E880                    CON     F(((-6731.368-3)*.9974)*217.021D-6)            PP054610
3431                    0E9C  0084                    CON     F((((00060.30)*9.869598-5)*.9974)*217.021D-6)  PP054620
3432                    0E9D  FF11                    CON     F((((-0171.32)*3.141598-4)*.9974)*217.021D-6)  PP054630
3433                    0E9E  006C                    CON     F(((00121.658-3)*.9974)*217.021D-6)            PP054640
3434                    0E9F  FF33                    CON     F((((-0093.80)*9.869598-5)*.9974)*217.021D-6)  PP054650
3435                    0EA0  011F                    CON     F((((00206.28)*3.141598-4)*.9974)*217.021D-6)  PP054660
3436                    0EA1  FFA4                    CON     F(((-0104.138-3)*.9974)*217.021D-6)            PP054670
                                              * PROGRAMMER CONTROLLER ROUTINE DISPLAYS 2 HEX DIGITS FOR TEST RESULTS  054680
                                              * IN ITS LED AND OPERATES GO - NOGO - LIGHTS.                           054690
                                              * ALSO SEE THE IOC X(8CC0) IN THE SYNC ROUTINE.                         054700
3437                 8R 0EA2  F80F8C80        OPER_P_C  IOC     0,,X(8C80)      TURN OFF NOGO TIMER         054710
3438                 22 0EA4  F80C002E                  FETD    0,,TEST_FAIL_TEMP  GET FAIL WORDS           054720
3439                 28 0EA6  C001                      FET     0,1             SWAP WORDS                  054730
3440                 36 0EA7  F42A00D0                  CLA     2,,HX0100       GIVES ZERO IF NO ERRER      054740
3441                168 0EA9  0D02                      NMLD    0,2             REG 2 GETS -(SHIFT COUNT)   054750
3442                178 0EAA  F0271EE8                  STA     2,,AVIONICS     SAVE SHIFT COUNT FOR PC OUTP 054760
3443                182 0EAC  0062    (0EAF)           BRE     $1                                          054770
3444                 8R 0EAD  F80F8C00                  IOC     0,,X(8C00)      TURN ON NOGO                054780
3445                10R 0EAF  FC0D1EE8        $1        PCP     0,,AVIONICS     OUTPUT 2 HEX DIGITS TO PC   054790
3446                 30 0EB1  D540                      BBK     4               RETURN                      054800
```

```
                                **                                                                    DP054810
                                *                        PANEL MAIN                                   *H054820
                                *                                                                     *H054830
                                * THIS ROUTINE PROCESSES ALL DATA INSERTED THROUGH THE CONTROL INDICATOR*H054840
                                * PANEL AND GENERATES ALL DATA DISPLAYED ON THE PANEL.  IT IS A NON    *H054850
                                * OMEGA TASK THAT IS EXECUTED 10 TIMES A SECOND.                       *H054860
                                *                                                                     *H054870
3447    8R      0E82 D700       PANEL_MAIN PRN     0              PRUNE ONE EXEC REGISTER             DP054880
3448    16      0E83 F40A1F47              CLA     0,,PANELMODE   "READ PANEL MODE                    DP054890
                *                                                 "                                   *2054900
3449    22      0E85 04051027              BRL     PANEL_TEST     "IS THE PANEL IN THE TEST MODE?     DP054910
                *                                                 "(MODE NEGATIVE)                    DP054920
                *                                                 "                                   *2054930
3450    4R      0E87 D162  (0ECA)          BRE     $11            "IS THE PANEL QUIESCENT?"           DP054940
                *                                                 "(MODE ZERO)                        DP054950
                *                                                                                     DP054960
3451    18R     0E88 F02C1F40              FET     2,,CALLWORD    "READ PANEL PARAMETERS              DP054970
                *                                                 "CALL = NUMBER DEFINING MAJOR       DP054980
                *                                                 "       PANEL SUBROUTINE BASED ONDP054990
                *                                                 "       LOWER KEYBOARD BUTTONS      DP055000
                *                                                 "ARG1, ARG2 = TEMPORARY STORAGE     DP055010
                *                                                 "             USED BY VARIOUS       DP055020
                *                                                 "             ROUTINES TO SAVE      DP055030
                *                                                 "             INFORMATION DURING    DP055040
                *                                                 "             BUTTON PUSHING        DP055050
                *                                                 "             PROCEDURES            DP055060
3452    20      0E8A 9831                  COMM    3,,1           TEST MODE AGAIN                     DP055070
                *                                                 "                                   *2055080
3453    26      0E8B 04061248              BRE     PANELOUTPUT    "IS THE PANEL IN THE DISPLAY MODEDP055090
                *                                                 "(MODE = 1)                         DP055100
                * THE MODE IS INSERT (2) INDICATING                                                   *H055110
                * THAT THE ACCEPT BUTTON HAS JUST                                                     *H055120
                * BEEN DEPRESSED TO COMPLETE A PRO-                                                   *H055130
                * CEDURE AND THE DATA DISPLAYED ON                                                    *H055140
                * THE PANEL NOW SHOULD BE PROCESSED                                                   *H055150
3454    22R     0E8D F03C0005              FET     3,,C_I_RIGHT_DISPLAY AND BOTH LEGENDS               DP055160
                *                                                 "READ THE LEFT LEGEND, RIGHT        DP055170
                *                                                 "LEGEND AND THE LEFT DISPLAY        DP055180
                *                                                 "REGISTER (DISPLAY IS A 6 DIGIT     DP055190
                *                                                 "BCD WORD)                          DP055200
                *                                                 "CONVERT DISPLAY TO INTEGER IN      *I055210
3455    30  *   0E8F F80D1564              BSV     BCDTOBIN       "UNITS OF LSB OF THE DISPLAY        DP055220
3456    44      0EC1 F01C0003              FET     1,,C_I_LEFT_DISPLAY "READ RIGHT DISPLAY REGISTERDP055230
```

```
                                                
```

```
3479    12      0EE2  F00C1F8C              FET   0,,FLOATER      "USE MARKER                    DP055670
3480    20      0EE4  D700                   PRN   0               "IS THE LOOP                   DP055680
3481    24      0EE5  0012   (0EE8)          BNE   $35             "ANTENNA IN USE?               %R055690
3482     4R     0EE6  F4090018               ADDM  0,,X(0018)      "TURN OFF THE FLOATER LAMP AND DP055700
                                    *                              "TURN ON THE LOOP ANTENNA IN USE DP055710
                                    *                              "LAMP                          DP055720
3483     4R     0EE8  FC1920F8       $35       CLAM  1,,X(20F8)    "MASK FOR STATUS LAMP           055730
3484    16      0EEA  E0010009                 MRG   0,1,C_I_OUTPUT_MALFUNCTION_STATUS_INDICATORS 055740
                                    *                              "OUTPUT THE STATE OF THE STATUS DP055750
                                    *                              "LAMPS TO THE C/I              DP055760
3485    30      0EEC  D510                     BBK   1             "EXIT PANEL ROUTINE"           %S055770
                                    *                                                             CI055780
3486            0EED  0EFA           $1        CON   $5            INPUTS                         DP055790
3487            0EEE  0F09                     CON   $12           1 SPARE                        DP055800
3488            0EEF  0F09                     CON   $12           SPARE                           055810
3489            0EF0  0000                     CON   0             SIGMA - SPARE                  DP055820
3490            0EF1  0F09                     CON   $12           4 SPARE                        DP055830
3491            0EF2  0F0A                     CON   $3            D-GMT                           055840
3492            0EF3  0F09                     CON   $12           6 SPARE                        DP055850
3493            0EF4  0F09                     CON   $12                                          DP055860
3494            0EF5  0F64                     CON   $4            MAN H/S                         055870
3495            0EF6  0F09                     CON   $12           SPARE                           055880
3496            0EF7  0F09                     CON   $12           SPARE                           055890
3497            0EF8  0F7A                     CON   $7            POS                             055900
3498            0EF9  0F09                     CON   $12           SPARE                           055910
```

```
                                                **                                                                  DP055920
                                                * OMEGA DR INSERT                                                   #H055930
                                                *                                                                   #H055940
                                                * NOTE - A SINGLE 16 BIT WORD                                       #H055950
                                                *        DEFINES THE CURRENT                                        #H055960
                                                *        LIST OF STATIONS AVAIL-                                    #H055970
                                                *        ABLE AND NAV MODE THAT                                     #H055980
                                                *        HAVE BEEN SELECTED BY                                      #H055990
                                                *        THE OPERATOR                                               #H056000
3499    10R   0EFA  FC1A1F3D    $5              CLAD    1,,IMAGE11          -,UL,UR                                 056010
3500    18    0EFC  E40200DE                    EXT     0,2,HX0200          MAN BIT FROM UR                         056020
3501    20    0EFE  B020                        SUB     2,0                                                         056030
3502    22    0EFF  B401                        ADD     0,1                 ADD AUTO BIT FROM UL                    056040
3503    28    0F00  F0254000                    RSL     2,,1                                                        056050
3504    30    0F02  B402                        ADD     0,2                 FORM STATIONS IN USE WORD               056060
3505     2R   0F03  A010    $97                 CLS     1,0                                                       $ 056070
                                                *                                   "FORM COMPLIMENT TO MAINTAIN    DP056080
                                                *                                   "A GOOD CHECKSUM                DP056090
                                                *                                   "PROGRAM MONITOR UNIT COULD STOP #I056100
3506    10    0F04  F00F8E20                    SET     0,,DISABLE_MEMORY_PROTECT "IF NOT DISABLED              DP056110
3507    20    0F06  7865   (00E5)                STAD    0,,STATIONS_IN_USE "SAVE UPDATED STATIONS AND           DP056120
                                                *                                   "NAV MODE"                      DP056130
3508    28    0F07  F00F8E21                    SET     0,,ENABLE_MEMORY_PROTECT "ENABLE PMU"                   DP056140
3509    28R   0F09  0580      $12               BBK     8                   "EXIT"                                  DP056150
```

```
                                        **                                                                  DP056160
                                        * DATE TIME INSERT                                                  *H056170
3510        8R      0F0A  F42A002A        $3          CLA     2,,ACCEPT_OLD  "READ ACCEPT OLD MARKER       DP056180
                                        *                                    "DID THE OPERATOR              *2056190
3511        14      0F0C  04010F58                    BNE     $33            "TAKE THE OPTION OF ACCEPTING THEDP056200
                                        *                                    "DISPLAYED TIME?               DP056210
                                        * A NEW TIME WAS INSERTED                                          *H056220
3512        8R      0F0E  F42A0009                    CLA     2,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES  DP056230
3513        12      0F10  4422                        LSA     2,,1           "EXAMINE THE ENTER TIME LAMP    056240
                                        *                                    "IS THIS TIME                  *2056250
3514        16      0F11  D028   (0F1A)               BGE     $61            "INSERT THE FIRST TIME INSERT  *R056260
                                        *                                    "SINCE TURN ON?                DP056270
3515        10R     0F12  8420                        FETM    2,,0           "SET DELTAV2, 3 = 0            DP056280
3516        22      0F13  7C39   (0089)               PTRD    0,,DELTA_V2    "RESTART KALMAN IF IT HAS      DP056290
                                        *                                    "    ALREADY STARTED           DP056300
                                        *                                    "SET POSITION VARIANCES TO AN 'A'DP056310
                                        *                                    "    FIX FOR KALMAN RESTART    DP056320
3517        30      0F14  7437   (0087)               PTR     0,,COLD_START_MKR RESTART KALMAN               DP056330
3518        44      0F15  F80C1776                    FETD    0,,POS_NOISE_TABLE SET A FIX                   DP056340
3519        52      0F17  C011                        FET     1,1                                            DP056350
3520        74      0F18  FC271F96                    PTRD    2,,SAVE_POSITION_VARIANCES                     DP056360
3521        10R     0F1A  FC2A0003        $61         CLAD    2,,C_I_LEFT_DISPLAY BCD DATE                   DP056370
3522        18  *   0F1C  F80D100F                    BSV     MAKE_TWO_BINARY   YEAR                         DP056380
3523        22      0F1E  F0590048                    SUBM    5,,72          YEARS  SINCE  1972              056390
3524        24      0F20  A405                        CLA     0,5                                            DP056400
3525        28      0F21  F404016D                    MPIM    0,,365                                         DP056410
3526        30      0F23  B066                        SUB     6,6            ZERO R6                         056420
3527        40      0F24  F8542000                    RSAD    5,,2           II IN R5   FF IN R6             056430
3528        42      0F26  B405                        ADD     0,5             D + II =  D                    056440
3529        50  *   0F27  F80D100F                    BSV     MAKE_TWO_BINARY    MONTH OF YEAR               DP056450
3530        60      0F29  F05700C9                    STA     5,,DAY+1                                       DP056460
3531        62      0F2B  9860                        COMM    6,,0           TEST FOR LEAP YEAR              056470
3532        66      0F2C  D013   (0F30)               BNE     $31            NOT LEAP YR                     DP056480
3533        2R      0F2D  9852                        COMM    5,,2           LEAP YR  BUT IS IT FEB          056490
3534        6       0F2E  D031   (0F30)               BRG     $31                      OR EARLIER             DP056500
3535        2R      0F2F  9001                        SUBM    0,,1           YES IT IS   D - 1 =  D          056510
3536        8R      0F30  F55B16C0        $31         ADD     X5,,DAYS_BY_MONTH-1                            DP056520
3537        16  *   0F32  F80D100F                    BSV     MAKE_TWO_BINARY   DAY OF MONTH                 DP056530
3538        26      0F34  F05700C8                    STA     5,,DAY                                         DP056540
3539        28      0F36  B405                        ADD     0,5                                            DP056550
                                        *                                    DAYS  AT  B15                  056560
3540        30      0F37  A480                        CLA     8,0            SAVE IN R8                      DP056570
                                        *   TIME PROCESSING                                                 DP056580
```

```
3541    40       0F38  FC2A0005            CLAD   2,,C_I_RIGHT_DISPLAY BCD TIME                    DP056590
3542    48  *    0F3A  F80D100F            BSV    MAKE_TWO_BINARY    HOURS (0 TO 23)               DP056600
3543    52       0F3C  AC64                CLAD   6,4                                              DP056610
3544    56       0F3D  F474C03C            MPIM   7,,60              CONVERT TO MINUTES            DP056620
3545    64  *    0F3F  F80D100F            BSV    MAKE_TWO_BINARY    MINUTES (0 TO 59)             DP056630
3546    66       0F41  8475                ADD    7,5                                              DP056640
3547    72       0F42  FC64003C            MPIDM  6,,60              CONVERT TO SECONDS            DP056650
3548    80  *    0F44  F80D100F            BSV    MAKE_TWO_BINARY    SECONDS (0 TO 59)             DP056660
3549    84       0F46  8C64                ADDD   6,4                                              DP056670
3550    90       0F47  FC6400C8            MPIDM  6,,200             CONVERT TO UNITS OF 5 MILLISECS DP056680
3551   102       0F49  F86700C6            STAD   6,,GMT             SAVE NEW GMT                  DP056690
3552   112       0F4B  F86B00BC            SUBD   6,,TIME                                           DP056700
3553   132       0F4D  F866C0E7            MPYD   6,,=0F((((50-3831)/24)/3600)/1811)               056710
3554   136       0F4F  F4840010            LSA    8,,4                                              056720
3555   138       0F51  8468                ADD    6,8                                              DP056730
3556   150       0F52  F86700C4            STAD   6,,DAY_SINCE_JAN1_1972                           056740
3557   158       0F54  F41AC0E2            CLA    1,,HX2000                                         056750
3558   166       0F56  E4110009            EXT    1,1,C_I_OUTPUT_MALFUNCTION_STATUS_INDICATORS      056760
3559   170       0F58  D012   (0F5B)       BNE    $33                                          11   056770
3560    8R  *    0F59  F80D1613            BSV    CALC_TIME_CORRECTION     CORRECT TIME             056780
3561    8R       0F5B  F41A00E3      $33   CLA    1,,HX4000          "READ CURRENT STATE OF ENTER TIME 056790
3562    16       0F5D  E4010009            EXT    0,1,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES     DP056800
3563    20       0F5F  4402                LSA    0,,1               "LAMP.  IF IT IS ON TURN IT OFF  056810
3564    22       0F60  8410                ADD    1,0                "AND TURN THE ENTER POSITION     DP056820
                                     *                               "LAMP ON                         DP056830
3565   12R       0F61  E0010009      $43   MRG    0,1,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES     DP056840
                                     *                               "OUTPUT NEW STATE OF ENTER TIME  DP056850
3566    40       0F63  D580                BBK    8                  "AND / OR ENTER POSITION LAMP    DP056860
```

```
                                                                                                                    DP056870
                                **                                                                                  DP056870
                                * MANUAL VELOCITY INSERT                                                           *H056880
3567          8R    0F64  C011  $4          FET     1,1          SWAP  HEADING                                    056890
3568          12    0F65  AC24              CLAD    2,4           AND SPEED                                       056900
3569          16    0F66  AC40              CLAD    4,0                                                           056910
3570          26    0F67  D710              PRN     1                                                             056920
3571          28    0F68  987C              COMM    7,,12        IS THIS RZ VELOCITY                              056930
3572          34    0F69  C4C60FE6          BRE     $9           YES                                              056940
3573          4R    0F6B  FC092F66          CLAM    0,,F(.3703)  "CONVERT SPEED FROM INTEGER                     056950
3574          36    0F6D  D410              DIV     1,0          "NUMBER OF KNOTS TO FEET/SECOND                  DP056960
                                *                                 "SCALED B11                                      DP056970
                                *                                 "SUBTRACT 1/16 FT/SEC SO THAT AN                 DP056980
                                *                                 "INSERTED ZERO WILL GIVE A ZERO                  DP056990
                                *                                 "VELOCITY (DIVIDE FORCES THE LSB                 DP057000
                                *                                 "TO A 1)                                         DP057010
                                *                                 "SAVE IN V INSERT                                DP057020
3575          38    0F6E  9011              SUBM    1,,1         GET ZERO IF ZERO ENTERED                         DP057030
3576          48    0F6F  F0171FF4          STA     1,,V_INSERT                                                   DP057040
3577          58    0F71  FC4A1ACA          CLAD    4,,=DI(180000)                                                %5057050
3578          62    0F73  8824              SUBD    2,4                                                           057060
3579          188   0F74  DC24              DIVD    2,4                                                           057070
3580          192   0F75  F4298000          ADDM    2,,X(8000)                                                    057080
3581          202   0F77  F0271F88          STA     2,,PSI_INSERT                                                 057090
3582          230   0F79  D580              BBK     8                                                             DP057100
```

```
                                **                                                                  DP057110
                                * POSITION INSERT                                                   *H057120
                                *                                                                  DP057130
                                *                                   "SCALE LATITUDE AND LONGITUDE PI *I057140
3583     8R *   0F7A  F80D101A  $7          BSV   LAT_LONG_SCALING   "AND ADJUST FOR N/S AND E/W     DP057150
3584     10     0F7C  987B                 COMM  7,,11               "ARG1 DEFINES POSITION TYPE      DP057160
                                *                                   "BUTTON (0-9 = DESTINATION,      DP057170
                                *                                   "        11 = SUB)               DP057180
                                *                                   "IS THIS POSITION                *1057190
3585     16     0F7D  04030FD8             BRG   $71                "RZ (12) OR SUB (11)"            DP057200
3586     4R     0F7F  D066   (0F86)        BRE   $72                                                  057210
                                *   POS 0 TO 9                                                     DP057220
3587     2R     0F80  B477                 ADD   7,7                DOUBLE DESTINATION INDEX         DP057230
                                *                                   "SAVE LATITUDE AND LONGITUDE IN  DP057240
                                *                                   "TABLE OF DESTINATIONS INDEXED   DP057250
                                *                                   "BY DESTINATION NUMBER IN ARG1   DP057260
3588     14R    0F81  FD771FDE  $112        2PTRD X7,,DESTINATION_LATITUDE                         % 057270
3589     12R    0F83  F9571FC4  $113        2STAD X5,,DESTINATION_LONGITUDE                        % 057280
3590     36     0F85  D560                 BBK   6                                                  DP057290
                                *   POS A/C                                                        DP057300
3591     2R     0F86  B488       $72        ADD   8,8                "ARG2 DEFINES QUALITY (A, B OR C)DP057310
                                *                                   "OF POSITION INSERT              DP057320
                                *                                   "READ VARIANCE ASSOCIATED WITH   DP057330
                                *                                   "QUALITY A = .5, B = 5, C = 20 MIDP057340
                                *                                   "EXAMINE THE ENTER POSITION LAMP %S057350
3592     16     0F87  F98C1776             FETD  X8,,POS_NOISE_TABLE                              DP057360
3593     24     0F89  F46A0009             CLA   6,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES       DP057370
                                *                                   "IS THIS THE"                    *1057380
3594     28     0F8B  D054   (0F90)        BRL   $17                "FIRST POSITION INSERT?"         DP057390
3595     8R     0F8C  F46A0B87             CLA   6,,COLD_START_MKR                                 % 057400
3596     12     0F8E  D21A   (0FB9)        BNE   $73                "HAS KALMAN BEEN INITIATED YET?  DP057410
                                *                                   "TREAT THIS POSITION LIKE A      DP057420
3597     4R     0F8F  D005   (0F95)        BUC   $16                "FIRST POSITION INSERT           DP057430
3598     8R     0F90  F46A002A   $17       CLA   6,,ACCEPT_OLD      "FIRST INSERT"                   DP057440
                                *                                   "DID THE OPERATOR                *2057450
3599     12     0F92  D062   (0F95)        BRE   $16                "TAKE THE OPTION OF ACCEPTING THE%R057460
                                *                                   "DISPLAYED POS?                  DP057470
3600     14R    0F93  D730                 PRN   3                  "DO NOT CHANGE POSITION"         DP057480
3601     18     0F94  D00E   (0FA3)        BUC   $19                                                  DP057490
3602     6R     0F95  4C04       $16       LSAD  0,,2               "RESCALE POSITION VARIANCE FOR   DP057500
3603     14     0F96  C011                 FET   1,1                "KALMAN TO USE AS INITIAL VALUE  DP057510
3604     36     0F97  FC271F96             PTRD  2,,SAVE_POSITION_VARIANCES                       DP057520
3605     44 *   0F99  F80D0FA6             BSV   PANEL_MAIN$8       "COMPUTE NEW POSITION MATRIX RIJ DP057530
```

```
3606    54    0F98  F0670087                    STA     6,,COLD_START_MKR "SET MARKER TO FORCE KALMAN TODP057540
                                                *                       "RESTART IF IT HAS STARTED      DP057550
3607   124    0F9D  F4F71F69                    PTR     15,,RIJ         "SAVE RIJ MATRIX                DP057560
3608   136    0F9F  F8071F79                    STAD    0,,R33          "SET MARKER TO RESET THE        DP057570
3609   142    0FA1  8400                        FETM    0,,0            "TRACKING FILTERS               DP057580
3610   150    0FA2  7400    (0080)              PTR     0,,RESET_TF                                     DP057590
3611   12R    0FA3  86E3    (00E3)    $19       FETD    0,,HX4000       "TURN OFF ENTER POSITION LAMP    057600
3612    18    0FA4  04000F61                    BUC     $43                                             DP057610
```

```
                                **                                                                  DP057620
                                *                    POSITION MATRIX COMPUTATION                    *H057630
                                *                                                                   *H057640
                                * THIS ROUTINES COMPUTES A NINE ELEMENT POSITION MATRIX WITH THE NUMBER *H057650
                                * 3 AXIS POINTING NORTH.  THE ARGUMENTS CONSIST OF THE LATITUDE AND  *H057660
                                * LONGITUDE                                                          *H057670
                                *                                                                   *H057680
                                *                    A=LAT, B=LONG                                  DP057690
 3613     434R      0FA6 1400  $8          SINCOS    0              CA,SA,B                         DP057700
                                *                                   "R11 = SIN (LAT)                DP057710
                                *                                   "R12 = COS (LAT) * COS (LONG)   DP057720
                                *                                   "R13 = COS (LAT) * SIN (LONG)   DP057730
                                *                                   "R21 = 0                        DP057740
                                *                                   "R22 = - SIN (LONG)             DP057750
                                *                                   "R23 =   COS (LONG)             DP057760
                                *                                   "R31 =   COS (LAT)              DP057770
                                *                                   "R32 = - SIN (LAT) * COS (LONG) DP057780
                                *                                   "R33 = - SIN (LAT) * SIN (LONG) DP057790
 3614     442       0FA7 C015                     FET       1,5    "       (SCALED B1)             DP057800
 3615     448       0FA8 9663 (00E3)              ADD       0,,HX4000 B+PI/2                        DP057810
 3616     882       0FA9 1400                     SINCOS    0      -SB,CB,CA,SA,A                   DP057820
 3617     886       0FAA AC86                     CLAD      8,6          ...     ,SA                DP057830
 3618     902       0FAB 6880                     MPYD      8,0          ...     ,-SA SB            DP057840
 3619     906       0FAC BC88                     ADDD      8,8                                     DP057850
 3620     922       0FAD C057                     FET       5,7    CB,CA,SA,-SB,CB,CA,SA,-SASB      DP057860
 3621     938       0FAE 68C8                     MPYD      12,8         ...     ...    ,SACB,-SASB DP057870
 3622     942       0FAF BCCC                     ADDD      12,12                                   DP057880
 3623     946       0FB0 A8CC                     CLSD      12,12        ...     ...    ,-SACB,SASB DP057890
 3624     962       0FB1 6826                     MPYD      2,6      ,-CASB,     ...                DP057900
 3625     966       0FB2 BC22                     ADDD      2,2                                     DP057910
 3626     970       0FB3 A822                     CLSD      2,2      ,CASB,      ...                DP057920
 3627     986       0FB4 680A                     MPYD      0,10   CACB,     ...                   DP057930
 3628     990       0FB5 BC00                     ADDD      0,0                                     DP057940
 3629     998       0FB6 C015                     FET       1,5    SA,       ...                   DP057950
 3630    1002       0FB7 B866                     SUBD      6,6                                     DP057960
 3631    1010       0FB8 D5F0                     BBK       15                                      DP057970
                                * POSITION UPDATE                                                   *H057980
 3632      12R      0FB9 C035  $73                FET       3,5                                     DP057990
 3633      20       0FBA 867D (00FD)              FET       0,,RIJ_ADD "READ POINTER TO R1 VECTOR   DP058000
 3634      28  *    0FBB F80D14A7                 BSV       MAKE_LAT_LONG  "COMPUTE CRAFT PRESENT POSITION DP058010
 3635      32       0FBD 8840                     SUBD      4,0    "COMPUTE POSITION ERROR          DP058020
 3636      36       0FBE 8862                     SUBD      6,2    "ERROR NORTH = LAT(NEW) - LAT    DP058030
                                *                                   "ERROR EAST = COS (LAT)         DP058040
```

```
3637    44  *       0F8F  F80D1655                  BSV     COS                                     % 058050
                                                *                       "COMPUTE RADIAL ERROR SQUARED   DP058060
3638    60          0FC1  6860                      MPYD    6,0         " = (ERR N)**2 + (ERR E)**2     DP058070
3639    64          0FC2  BC66                      ADDD    6,6                                         058080
3640    68          0FC3  AC04                      CLAD    0,4                                         DP058090
3641    72          0FC4  AC26                      CLAD    2,6                                         DP058100
3642    88          0FC5  6800                      MPYD    0,0                                         DP058110
3643   104          0FC6  6822                      MPYD    2,2                                         DP058120
3644   108          0FC7  BC02                      ADDD    0,2                                         DP058130
3645   118          0FC8  F8081ACC                  COMD    0,,=DF((((1.2)*1.2)/180)/180) 72 MILES      DP058140
                                                *                       "DOES THE RADIAL                *I058150
3646   122          0FCA  D052    (0FCD)            BRL     $74         "ERROR EXCEED 72 N MILE?"       %R058160
3647    22R         0FCB  D770                      PRN     7           "ERROR TOO LARGE"               DP058170
                                                *                       "PROCESS THIS INSERT LIKE A FIRSTDP058180
3648    26          0FCC  D808    (0F95)            BUC     $16         "POSITION INSERT                DP058190
3649    10R         0FCD  F80A1ACE          $74     CLSD    0,,=DF((1)/3.141592658+3)                   DP058200
3650   136          0FCF  DC40                      DIVD    4,0         "SCALE ERRORS IN RADIANS AT B-3 DP058210
3651   262          0FD0  DC60                      DIVD    6,0         "SAVE FOR KALMAN                DP058220
3652   276          0FD1  D730                      PRN     3           "SET POSITION FIX MARKER TO     DP058230
3653   298          0FD2  F4371CD1                  PTR     3,,ERROR_NORTH "NOTIFY KALMAN               DP058240
3654   308          0FD4  F0170DA6                  STA     1,,PC_INSERT "SAVE ASSOCIATED VARIANCE      DP058250
3655   320          0FD6  7C01    (0081)            PTRD    0,,POSITION_NOISE                           DP058260
3656   348          0FD7  D580                      BBK     8                                           DP058270
                                                * ENTER HERE FOR A MOVING DESTINATION                   *H058280
                                                * POSITION INSERT                                       *H058290
                                                *                       "CONVERT LAT AND LONG FROM .1 MIN*I058300
3657     8R         0FD8  C013          $71         FET     1,3         LONG                            058310
3658   442          0FD9  1400                      SINCOS  0                                           DP058320
3659   450          0FDA  C015                      FET     1,5         LAT                             DP058330
3660   884          0FDB  1400                      SINCOS  0                                           DP058340
3661   888          0FDC  BC00                      ADDD    0,0         "COMPUTE MOVING DESTINATION     DP058350
3662   904          0FDD  6860                      MPYD    6,0         "POSITION VECTOR RZ SCALED BI   DP058360
3663   920          0FDE  6840                      MPYD    4,0         "RZ1 = SIN (LAT)                DP058370
3664   930          0FDF  D710                      PRN     1           "RZ2 = COS (LAT) * COS (LONG)   DP058380
3665   960          0FE0  F4571FB8                  PTR     5,,RZ_POS   "RZ3 = COS (LAT) * SIN (LONG)   DP058390
3666   972          0FE2  D720                      PRN     2                                           DP058400
3667   980          0FE3  F40A1FDA                  CLA     0,,RZ_ALPHA                                 DP058410
3668   984          0FE5  D100    (0FF6)            BUC     $91         COMPUTE BETA                    DP058420
                                                * ENTER HERE FOR A MOVING DESTINATION                   *H058430
                                                * VELOCITY - HEADING INSERT                             *H058440
3669     4R         0FE6  FC095ECC          $9          CLAM    0,,F(.7406) "RESCALE VEL FROM INTEGER KNOTS DP058450
3670    36          0FE8  D410                      DIV     1,0         "TO FT/SEC AT 812 SAVE IN RZ VEL DP058460
3671    38          0FE9  9011                      SUBM    1,,1        GET ZERO IF ZERO ENTERED        DP058470
```

```
3672    48    0FEA  FC4A1ACA          CLAD    4,,=DI(180000)                                  058480
3673    52    0FEC  B824              SUBD    2,4                                             058490
3674   178    0FED  DC24              DIVD    2,4                                             058500
3675   182    0FEE  F4298000          ADDM    2,,X(8000)                                      058510
3676   184    0FF0  A432              CLA     3,2                                             058520
3677   194    0FF1  F0171FD8          STA     1,,RZ_VEL                                      DP058530
3678   206    0FF3  D720              PRN     2                                              DP058540
3679   216    0FF4  F0071FDA          STA     0,,RZ_ALPHA                                    DP058550
3680  434R    0FF6  1400      $91     SINCOS  0               "COMPUTE THE VECTOR BETA THAT IS DP058560
3681   464    0FF7  F05C1FB8          FET     5,,RZ_POS       "PERPENDICULAR TO THE PLANE OF  DP058570
3682   476    0FF9  C035              FET     3,5             "MOTION OF THE MOVING DESTINATIONDP058580
3683   492    0FFA  6800              MPYD    0,0             "                               DP058590
3684   508    0FF8  6822              MPYD    2,2             "BETA = (RZ POS) X (VEL VECTOR) DP058600
3685   512    0FFC  8C02              ADDD    0,2             "                               DP058610
3686   958    0FFD  1000              SQRT    0               "K = (RZ2**2 + RZ3**2)**.5      DP058620
3687   974    0FFE  684C              MPYD    4,12            "USE SIN/COS ALPHA FOR VEL VECTORDP058630
3688   978    0FFF  BC44              ADDD    4,4             "                               DP058640
3689   982    1000  A824              CLSD    2,4             " BETA1 = SIN(ALPHA)*K          DP058650
3690   998    1001  6848              MPYD    4,8             " BETA3 = (-RZ3*RZ1*SIN         DP058660
3691  1014    1002  6826              MPYD    2,6             "           -RZ2*COS)/K         DP058670
3692  1030    1003  688A              MPYD    8,10            " BETA2 = (-RZ2*RZ1*SIN         DP058680
3693  1046    1004  686A              MPYD    6,10            "           +RZ3*COS)/K         DP058690
3694  1050    1005  BC28              ADDD    2,8             "                               DP058700
3695  1054    1006  BC46              ADDD    4,6             "SAVE BETA SCALED B1            DP058710
3696  1058    1007  A844              CLSD    4,4                                             DP058720
3697  1184    1008  DC20              DIVD    2,0             BETA 2  B1                      DP058730
3698  1310    1009  DC40              DIVD    4,0             BETA 3  B1                      DP058740
3699  1326    100A  680C              MPYD    0,12            BETA 1  B2                      DP058750
3700  1330    100B  BC00              ADDD    0,0             BETA 1  B1                      DP058760
3701  1360    100C  F4571FBE          PTR     5,,RZ_BETA                                     DP058770
                            *                                                                *S058780
3702  1394    100E  D5B0              BBK     11              "RETURN TO PANEL MAIN           DP058790
                            *                                                                DP058800
3703          0F81          PLOT3     EQU     PANEL_MAIN$112                                 DP058810
3704          0F83          PLOT4     EQU     PANEL_MAIN$113                                 DP058820
```

```
                **                                                                  DP058830
                *                          BCD TO BINARY                           *H058840
                *                                                                  *H058850
                * THIS ROUTINE WILL CONVERT 2 BCD CHARACTERS TO BINARY.  THE ARGUMENT *H058860
                * IS A 32 BIT WORD WITH THE 2 DIGITS IN THE MOST SIGNIFICANT BITS.  THE *H058870
                * ARGUMENT IS SHIFTED LEFT END AROUND ON RETURN                      *H058880
                *                                                                  *H058890
                *      TWO M. S. DIGITS IN R2,3 WHICH ARE LEFT CYCLED 8 BITS       DP058900
                *       ANSWER IN R5    R1 IS USED                                 DP058910
                MAKE_TWO_BINARY;                                                   DP058920
3705
3705      8R    100F  FC250010          LSED    2,,4        "SHIFT FIRST CHARACTER FROM MSB'SDP058930
3706      16    1011  E4131770          EXT     1,3,HX000F  "TO LSB'S AND EXTRACT 4 BITS    DP058940
3707      24    1013  FC250010          LSED    2,,4        "SHIFT SECOND CHARACTER FROM    DP058950
3708      32    1015  E4531770          EXT     5,3,HX000F  "MSB'S TO LSB'S AND EXTRACT 4   DP058960
3709      36    1017  4414              MPIM    1,,10       "BITS                           DP058970
3710      38    1018  8451              ADD     5,1         "                               DP058980
3711      46    1019  D5F0              BBK     15          "RESULT = 2ND CHAR + 10 * 1ST CHRDP058990
```

```
                                    **                                                                  DP059000
                                    *                LATITUDE / LONGITUDE SCALING                       *H059010
                                    *                                                                   *H059020
                                    * THIS ROUTINE TAKES LAT AND LONG THAT HAS BEEN CONVERTED TO BINARY AND *H059030
                                    * CHANGES IT TO RADIANS SCALED PI AFTER CORRECTING FOR S LAT AND W LONG *H059040
                                    *                                                                   *H059050
                                    *   CONVERT R2,3 AND R4,5 TO LATITUDE AND LONGITUDE                 DP059060
3712                                LAT_LONG_SCALING:                                                   DP059070
3712    14R     101A  F80C1AD0              FETO    0,,=D108000   "DIVIDE LAT / LONG BY THE NUMBER    DP059080
3713    140     101C  DC20                  DIVD    2,0           "OF .1 MINUTES IN PI RADIANS        DP059090
3714    266     101D  DC40                  DIVD    4,0           "TO SCALE PI RADIANS                DP059100
3715    270     101E  F869A02E              COMM    6,,X(A02E)    "EXAMINE LEFT DISPLAY LEGEND        %S059110
3716    274     1020  D061   (1022)        BRE     $1            "IS THIS A SOUTH LATITUDE?"         %R059120
3717     4R     1021  A822                  CLSD    2,2           "COMPLIMENT THE LATITUDE            DP059130
3718     4R     1022  F879A025        $1    COMM    7,,X(A025)    "EXAMINE RIGHT DISPLAY LEGEND       DP059140
3719     8      1024  D061   (1026)        BRE     $2            "IS THIS A WEST LONGITUDE?"         %R059150
3720     4R     1025  A844                  CLSD    4,4           "COMPLIMENT THE LONGITUDE           DP059160
3721    14R     1026  D510            $2    BBK     1             "RETURN"                            DP059170
```

```
                                **                                                                  CI059180
                                *                        PANEL TEST                                 *H059190
                                *                                                                   *H059200
                                * THIS PART OF THE C/I PROGRAM IS EXECUTED AFTER THE OPERATOR DEPRESSES *H059210
                                * THE PANEL TEST BUTTON.  IT CYCLES ALL OF THE LAMPS AND DISPLAYS ON THE *H059220
                                * PANEL IN 10 SECONDS.  IT ALSO TURNS OFF THE MALFUNCTION LAMP.      *H059230
                                *                                                                   *H059240
3722      4R    1027 F809FFFC   PANEL_TEST  COMM    0,,I(-4)      "EXAMINE PANEL MODE             DP059250
                                *                                 "                               *2059260
3723      8     1029 0112 (103C)            BNE     $3            "IS THIS THE FIRST ENTRY TO TEST?%R059270
                                *                                 "(MODE = -4)                    DP059280
                                *                                 "RESET THE SYSTEM OK BIT TO TURN *I059290
3724     18R *  102A 2EDD (000D)            FAILD   IO,,HX0100    "ON THE MALF LAMP               DP059300
3725      32    102B F01C0009               FET     1,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES      CI059310
3726      40    102D 701E (009E)            STA     0,,IMAGE9     "SAVE CURRENT STATE OF ALL STATUSDP059320
                                *                                 "AND MISCELLANEOUS LAMPS FOR    DP059330
                                *                                 "RESTORATION AFTER TEST FINISH  DP059340
                                *                                 "                               DP059350
                                *                                 "SET UP BIT PATTERN TO TURN ON  DP059360
                                *                                 "ALL LAMPS ON THE PANEL         DP059370
                                *   SET UP DMA BIT PATTERN IN REGS 0 - 10                         CI059380
3727      48    102E 8EE8 (00E8)            CLSD    0,,=D1        FFFF  12, 13                    DP059390
3728      58    102F C020                   FET     2,0           FFFF  11, 10, 9                 DP059400
3729      66    1030 8410                   FETM    1,,0          8, 7                              059410
3730      74    1031 F408FFFF               FETM    0,,X(FFFF)    6                                 059420
3731     10R    1033 C020       $1          FET     2,0           "OUTPUT STATE OF ALL LAMPS TO C/IDP059430
3732      60    1034 F4A70003               PTR     10,,C_I_LEFT_DISPLAY                          CI059440
3733      70    1036 F4180013               FETM    1,,19         "SET UP A TIMER TO DELAY TWO    %S059450
                                *                                 "SECONDS BEFORE PROCEDING TO THE DP059460
3734      72    1038 9421                   ADDM    2,,1          "NEXT PART OF THE TEST          DP059470
3735     18R    1039 F4271F45   $2          PTR     2,,PANELTIME  "SAVE PANEL MODE AND PRESENT    DP059480
                                *                                 "VALUE OF THE TIMER             DP059490
3736      26    1038 D5F0                   BBK     15            "EXIT PANEL PROGRAM"            %S059500
                                *   TEST FOR END OF 5 SECOND DECAY                                CI059510
3737     14R    103C F80C1F45   $3          FETD    0,,PANELTIME  "READ PRESENT VALUE OF TIMER    DP059520
                                *                                 "INCREMENT TIMER                *1059530
3738      22    103E C406 (1039)            BXU     0,,$2         "IS THE TIME UP?"               %R059540
3739      4R    103F FC09E03F               CLAM    0,,X(E03F)    "SET UP LEGEND                    059550
3740      8     1041 F829FFFE               COMM    2,,I(-2)      "DISPLAYS IN CASE THE MODE IS -2 DP059560
                                *                                 "IS THIS THE                    *2059570
3741      12    1043 D059 (104D)            BRL     $4            "START OF THE SECOND PART OF THE DP059580
                                *                                 "TEST? (MODE=-3)                DP059590
                                *                                 "IS THIS THE                    *2059600
```

```
3742        4R          1044  D061   (1046)          BRE       $6          "START OF THE THIRD PART OF THE  DP059610
                                                    *                       "TEST? (MODE=-2)                 DP059620
3743        4R          1045  D00E   (1054)          BUC       $5          "TEST COMPLETE"                   059630
3744        2R          1046  A410                 $6 CLA       1,0         "SET SAME BIT PATTERN IN RIGHT   DP059640
3745        4           1047  8C21                    CLSM      2,,1        "LEGEND AS LEFT LEGEND           DP059650
                                                    *                       "OUTPUT LEGEND DISPLAYS TO C/I   DP059660
                                                    *                       "SET MODE = -1                   DP059670
3746        18          1048  FC070007                PTRD      0,,C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION DP059680
3747        28          104A  F4180013                FETM      1,,19       "SET TIMER TO DELAY 2 SECONDS     059690
3748        32          104C  D904   (1039)          BUC       $2                                           DP059700
                                                    *  CHANGE DMA BIT PATTERN                               CI059710
3749         4R         104D  B800                 $4 SUBD      0,0         "SET BIT PATTERN TO TURN OFF ALL DP059720
3750        20          104E  8450                    FETM      5,,0        "LAMPS ON THE C/I                DP059730
3751        28          104F  867A   (00FA)          FET       0,,HX0B00                                    DP059740
                                                    *                       "SET THE SYSTEM OK AND COMPUTER  *I059750
3752        42 *        1050  2E7A   (00FA)          FAIL      I0,,HX0B00  "OK BITS TO TURN MALF LAMP OFF   DP059760
                                                    * NOTE - THIS HAS THE EFFECT OF                        *H059770
                                                    *        'RESETTING' THE MALF                          *H059780
                                                    *        LAMP IF A SYSTEM FAILURE                      *H059790
                                                    *        HAD TURNED IT ON PRIOR                        *H059800
                                                    *        TO INITIATING PANEL TEST                      *H059810
3753        46          1051  FC098888                CLAM      0,,X(8888)                                   059820
3754        50          1053  DA01   (1033)          BUC       $1          FFFF 5,4,3 AND START DELAY       I 059830
                                                    *  RESTORE QUIESCENT MODE                               CI059840
3755         4R         1054  B8C0                 $5 SUBD      0,0         "TEST COMPLETE"                   059850
3756        16          1055  F807002E                STAD      0,,TEST_FAIL_TEMP                            059860
3757        24          1057  9E9E   (009E)          CLAD      0,,IMAGE9                                    059870
                                                    *                       "RESTORE STATUS AND MISCELLANEOUSDP059880
                                                    *                       "LAMPS TO THEIR STATE AT THE     DP059890
                                                    *                       "START OF TEST                   DP059900
3758        38          1058  FC070009                PTRD      0,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES   DP059910
3759        46          105A  867A   (00FA)          FET       0,,HX0B00   "PUT BITS INTO C/I INPUT WORD TO DP059920
                                                    *                       "SIMULATE THE DEPRESSING OF MORE DP059930
                                                    *                       "THAN ONE BUTTON.  THIS WILL     DP059940
                                                    *                       "CAUSE THE PANEL INPUT ROUTINE TODP059950
                                                    *                       "CLEAR THE PANEL                 DP059960
3760        56          105B  F4070001                PTR       0,,C_I_INPUT_MISCELLANEOUS_SWITCHES (CLEAR)  DP059970
3761        58          105D  9C00                    CLAM      0,,0        "SET MODE = 0 = QUIESENT         DP059980
3762        68          105E  F4071F47                PTR       0,,PANELMODE                                 CI059990
                                                    * SEQUENCE TO PANEL INPUT ROUTINE                      *H060000
                                                    * TO FORCE A PANEL CLEAR OPERATION                      *H060010
```

```
                                **                                                                  DP060020
                                *                        PANEL INPUT                                *H060030
                                *                                                                   *H060040
                                * THIS PROGRAM PROCESSES ALL C/I PANEL INPUTS.  IT IS AN INTERRUPT  *H060050
                                * ROUTINE ENTERED WHENEVER A BUTTON IS DEPRESSED ON THE PANEL.  IT IS *H060060
                                * ALSO ENTERED AFTER PANEL TEST.  THE PANEL INPUT WORDS WILL CONTAIN A *H060070
                                * BIT THAT IDENTIFIES WHICH BUTTON WAS DEPRESSED.  THIS ROUTINE CONTROLS*H060080
                                * ALL INSERT AND DISPLAY PROCEDURES.                                 *H060090
                                *                                                                   *H060100
                                *                                                                   CI060110
                                * CONTROL AND INDICATOR PANEL INPUT INTERRUPT ROUTINE                CI060120
                                *       REGISTER ALLOCATION                                         CI060130
                                *         0        7 LEFT LEG                                       CI060140
                                *         1        8 RIGHT LEG                                      CI060150
                                *         2  DMA   9 SWITCH LAMPS                                   CI060160
                                *         3       10 MALF LAMPS                                     CI060170
                                *         4  WORD 11 TOP LEFT  ) KEY-                               CI060180
                                *         5       12 TOP RIGHT ) BOARD                              CI060190
                                *         6       13 LOWER     ) LAMPS                              CI060200
                                *                                                                   CI060210
                                *         7       PANEL MODE                                        CI060220
                                *         8       SWITCH MASK                                       CI060230
                                *         9       KEYBRD MASK, AND INPUT                            CI060240
                                *         A       DIGIT COUNT                                       CI060250
                                *                                                                   CI060260
                                *         B       THREE                                             CI060270
                                *         C       WORKING                                           CI060280
                                *         D       REGISTERS                                         CI060290
                                *                                                                   CI060300
3763  10R  1060  842E           PANEL_INPUT FETM    2,,14          "SET UP NORMALIZE COUNTER TO     DP060310
3764  32   1061  F03C1F47                FET     3,,PANELMODE   "DETERMINE WHICH BUTTON             DP060320
                                *                                  "READ PANEL MODE, SWITCH MASK,   DP060330
                                *                                  "KEYBOARD MASK AND DIGIT COUNT   DP060340
                                *                                  "                                *2060350
3765  38   1063  040510A5                BRL     PANOUT$3       "IS THE PANEL IN THE TEST MODE?  DP060360
                                *                                  "(MODE NEGATIVE)                 DP060370
                                * NOTE - ALL BUTTONS ARE IGNORED                                     *H060380
                                *        DURING PANEL TEST                                          *H060390
3766  34R  1065  F06C0007           FET     6,,C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION              CI060400
                                *                                  "READ CURRENT STATE OF ALL PANEL DP060410
                                *                                  "LAMPS AND LEGENDS FOR USE BY THEDP060420
                                *                                  "VARIOUS PROCEDURES              DP060430
3767  44   1067  EC880001           EXTD    11,8,C_I_INPUT_MISCELLANEOUS_SWITCHES                   CI060440
```

```
                                        *                                                "LOGICALLY 'AND' THE C/I INPUT    DP060450
                                        *                                                "WORDS WITH THE SWITCH AND KEY-   DP060460
                                        *                                                "BOARD MASKS.  THE MASKS DEFINE   DP060470
                                        *                                                "THE VALID BUTTON INPUTS.         DP060480
3768      54        1069  F8B80001                  COMD      11,,C_I_INPUT_MISCELLANEOUS_SWITCHES                  CI060490
                                        *                                                "WERE ANY INVALID                 *1060500
3769      60        1068  040110AA                  BNE       INPUTERROR      "BUTTONS DEPRESSED?"                  DP060510
3770      10R       106D  F8B800EB                  SUBD      11,,=D1                                               % 060520
3771      20        106F  EC8B0001                  EXTD      11,11,C_I_INPUT_MISCELLANEOUS_SWITCHES                % 060530
                                        *                                                "WAS MORE THAN                    *1060540
3772      24        1071  D318   (10AA)             BNE       INPUTERROR      "ONE BUTTON DEPRESSED?"               DP060550
                                        * ONE VALID BUTTON HAS BEEN DEPRESSED                                       *H060560
3773      8R        1072  F4CA0001                  CLA       12,,C_I_INPUT_MISCELLANEOUS_SWITCHES                    060570
3774      12        1074  D116   (1088)             BNE       $3                                                      060580
3775      8R        1075  F4CA0002                  CLA       12,,C_I_INPUT_KEYBOARD_SWITCHES                       % 060590
3776      16        1077  E48C112D                  EXT       11,12,HXE000                                            060600
3777      20        1079  D018   (1082)             BNE       $1              HOLD,DISPLAY,CLEAR OR                   060610
                                        *                                       INSERT ACCEPT IN R11                    060620
                                        * KEYBOARD BUTTON ONLY OCCURS                                               *H060630
                                        * AFTER A PROCEDURE HAS BEEN                                                *H060640
                                        * INITIATED                                                                 *H060650
3778      2R        107A  A49C                      CLA       9,12            "SAVE KEYBOARD INPUT WORD WHICH       DP060660
                                        *                                       "IDENTIFIES THE BUTTON                DP060670
                                        *                                       "NORMALIZE INPUT WORD TO GET THE      DP060680
                                        *                                       "NUMBER OF THE KEYBOARD BUTTON        DP060690
                                        *                                       "O/A/POS BUTTON = 0                   DP060700
3779      38        1078  D6CD                      NML       12,13           "S/W/SUB V/H BUTTON = 14              DP060710
3780      48        107C  F00C1F44                  FET       0,,PROCWORD     TEST FOR LOOP/FLOAT FIX-                060720
3781      56        107E  D700                      PRN       0               PREVENTS PROGRAM HALT WHEN              060730
3782      60        107F  D26A   (10AA)             BRE       INPUTERROR      SWITCH NOT SENDING CODE.                060740
                                        *                                       "RESUME PROCEDURE"                    *S060750
                                        *                                       "PROCWORD POINTS TO THE NEXT          DP060760
3783      10R       1080  06001F44                  BUC       I,,PROCWORD     "INSTRUCTION IN THE PROCEDURE         DP060770
                                        * SWITCH INPUT - THESE BUTTONS                                              *H060780
                                        * EITHER START OR END PROCEDURES                                            *H060790
3784      4R        1082  D25C   (10AF)  $1          BRL       HCONTROL        HOLD/NORMAL                             060800
3785      36R       1083  D68D                      NML       11,13                                                   060810
3786      38        1084  90DD                      SUBM      13,,13                                                  060820
3787      48        1085  07D01087                  BUC       IX13,,$2                                                060830
3788                1087  112F            $2        CON       INSACC          ACCEPT/INSERT                           060840
3789                1088  10C5                      CON       DISTART         CLEAR/DISPLAY                           060850
3790                1089  10AD                      CON       PANTEST         PANEL TEST                              060860
3791                108A  108D                      CON       FLOAT_LOOP      TOGGLE ANTENNA                          060870
```

```
3792    36R    1088  06C0        $3        NML     12,13          060880
3793    38     108C  9402                  ADDM    13,,2          060890
3794    48     108D  07001087              BUC     IX13,,$2       060900
```

```
                                                                                                                    DP060910
                **                                                                                                  DP060910
                *                                WITH ACCEPT LAMP                                                   *H060920
                *                                                                                                   *H060930
                * THIS ROUTINE WILL TURN ON THE ACCEPT LAMP IN ADDITION TO ANY OTHER                                *H060940
                * LAMPS ALREADY ENABLED AND REQUEST ONE BUTTON INPUT.  IF THE NEXT                                  *H060950
                * BUTTON IS NOT ACCEPT IT WILL TURN OFF THE ACCEPT LAMP AND RETURN TO                               *H060960
                * THE INPUT PROCEDURE                                                                              *H060970
                *                                                                                                   *H060980
3795      4R    108F  F4290400  OUTWAL  ADDM    2,,X(0400)    "TURN ON ACCEPT LAMP AND ENABLE                      060990
3796      8     1091  F4892000          ADDM    8,,X(2000)    "ACCEPT IN KEYBOARD/SWITCH MASK                      061000
                *                                             "WAIT FOR ONE BUTTON - DO NOT                       *I061010
3797      78    1093  1C01              INPUT   UPPER_LEFT_KEY  "RETURN IF ACCEPT IS DEPRESSED                    DP061020
3798      82    1094  F0290400          SUBM    2,,X(0400)    "TURN OFF ACCEPT LAMP AND DELETE                     061030
3799      86    1096  F0892000          SUBM    8,,X(2000)    "ACCEPT FROM SWITCH MASK                             061040
                *                                             "DISPLAYED DATA WAS NOT ACCEPTED                    *I061050
3800      94 *  1098  F800122D          BSV     DISCLEAR$1    "CLEAR DISPLAY BEFORE CONTINUING                    DP061060
                *                                             "RETURN TO PROCEDURE IN PROCESS                     DP061070
3801      104   109A  06001F43          BUC     I,,LINKWORD   "THROUGH LINKWORD POINTER                           DP061080
```

```
                                **                                                                  DP061090
                                *                    INPUT KEYBOARD BUTTON                          *H061100
                                *                                                                   *H061110
                                * THIS ROUTINE IS USED TO EXIT THE PANEL INTERRUPT ROUTINE WHILE A  *H061120
                                * PROCEDURE IS IN PROCESS.  FIRST IT BUILDS THE KEYBOARD MASK FROM THE *H061130
                                * LAMPS TURNED ON BY THE PROCEDURE AND THEN IT OUTPUTS THE STATE OF ALL *H061140
                                * LAMPS AND LEGENDS TO THE C/I PANEL.                               *H061150
                                *                                                                   *H061160
3802      2R      109C  9C60    PANOUT    CLAM    6,,0          "INPUT UPPER LEFT KEY ENTRY        DP061170
                                *                               "                                  DP061180
                                *                               "TURN OFF LOWER KEYBOARD LAMPS     DP061190
3803      2R      109D  A494    $1        CLA     9,4           "INPUT LOWER KEY ENTRY"            DP061200
3804      4       109E  B495              ADD     9,5           "                                  DP061210
3805      6       109F  B496              ADD     9,6           "FORM KEYBOARD SWITCH MASK         DP061220
3806      14      10A0  E4D81788          EXT     13,8,HXF000                                      061230
3807      16      10A2  B49D              ADD     9,13                                             061240
                                *                               "= UPPER LEFT LAMPS + UPPER RIGHT  DP061250
                                *                               "  LAMPS + LOWER LAMPS             DP061260
3808      34R     10A3  F4670007  $2        PTR     6,,C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION     CI061270
                                *                               "OUTPUT ALL LAMPS AND LEGENDS      DP061280
                                *                               "TO C/I                            DP061290
3809      22R     10A5  F4371F47  $3        PTR     3,,PANELMODE  "SAVE MODE, MASKS, DIGIT COUNT     DP061300
3810      38      10A7  D520              BBK     2             "EXIT PANEL INTERRUPT"             %S061310
3811      2R      10A8  9C40    $4        CLAM    4,,0          "INPUT UPPER RIGHT KEY ENTRY       DP061320
                                *                               "                                  DP061330
3812      6       10A9  D80E  (109C)      BUC     PANOUT        "TURN OFF UPPER LEFT LAMPS         DP061340
```

```
                                        **                                                                      CI061350
                                        * CLEAR CR ERROR ENTRY                                                  *H061360
                                        *   INPUT ERROR                                                         CI061370
                                        *                                   "PLACE PANEL IN QUIESCENT STATE     *I061380
3813    70R     10AA  1C00            INPUTERROR  INPUT     CLEAR_PANEL   "MODE=0,INSERT,ACCEPT,DISPLAY OFF  DP061390
                                        *                                   "TURN ON INSERT, DISPLAY - EXIT     DP061400
3814    76      10AB  04001110                    BUC       DISFINAL$2    "INTERRUPT ROUTINE AT DISFINAL$2    DP061410
                                        * PANEL TEST ENTRY                                                      *H061420
3815     2R     10AD  8C74            PANTEST     CLSM      7,,4          "SET PANEL MODE = TEST (-4)         DP061430
3816     6      10AE  D80C   (10A3)               BUC       PANOUT$2                                          CI061440
                                        * HOLD / NORMAL ENTRY                                                   *H061450
3817     6R     10AF  5428            HCONTROL    LSE       2,,3          "EXAMINE HOLD LAMP                    061460
3818    10      10B0  D057   (10B8)               BRL       $1            "HOLD ON                              061470
                                        *                                   "START HOLD MODE"                   *I061480
3819     8R *   10B1  F80D14EE                    BSV       VARSAVE       "TRANSFER VARIABLES FOR DISPLAY     DP061490
3820    14      10B3  F4252000                    LSE       2,,13                                             061500
3821    18      10B5  F4291000                    ADDM      2,,X(1000)    "TURN HOLD ON                         061510
3822    22      10B7  D905   (10A3)               BUC       PANOUT$2                                          061520
3823     6R     10B8  F4252000            $1      LSE       2,,13                                             061530
3824    10      10BA  F0291000                    SUBM      2,,X(1000)    "TURN HOLD OFF                        061540
3825    14      10BC  D90A   (10A3)               BUC       PANOUT$2                                          CI061550
                                        *                                                                       DP061560
3826    10R     10BD  F00C1F8C            FLOAT_LOOP  FET       0,,FLOATER    TOGGLE FLOATER MARKER           061570
3827    12      10BF  9001                        SUBM      0,,1                                              061580
3828    16      10C0  D061   (10C2)               BRE       $1                                                061590
3829     2R     10C1  9402                        ADDM      0,,2                                              061600
3830    10R     10C2  F4071F8C            $1      PTR       0,,FLOATER                                        061610
3831    14      10C4  DA02   (10A3)               BUC       PANOUT$2                                          061620
```

```
                                **                                                                  DP061630
                                *                    DISPLAY PROCEDURES                             *H061640
                                *                                                                   *H061650
                                * ENTER HERE WHEN THE DISPLAY BUTTON IS DEPRESSED.  ALL DISPLAY PRO- *H061660
                                * CEDURES ARE INITIATED AND CONTROLED FROM HERE                      *H061670
                                *                                                                   *H061680
                                *                                    "PLACE PANEL IN QUIESCENT STATE *I061690
3832    70R   10C5 1C00       DISTART  INPUT    CLEAR_PANEL       "MODE=0,INSERT,ACCEPT,DISPLAY OFFDP061700
3833    74    10C6 FC691FFF              CLAM     6,,X(1FFF)        "TURN ON ALL LOWER LAMPS AS EACH DP061710
                                *                                    "ONE IS A VALID DISPLAY         DP061720
                                *                                    "WAIT FOR OPERATOR TO SELECT A  *I061730
3834    144   10C8 1C03                 INPUT    LOWER_KEY         "DISPLAY WITH A LOWER BUTTON    DP061740
3835    154   10C9 F0D71F40             STA      13,,CALLWORD      "SAVE SELECTED PROCEDURE IN CALL DP061750
                                *                                    "FOR USE BY THE DISPLAY ROUTINE DP061760
                                *                                    "AFTER THE PROCEDURE IS COMPLETE DP061770
3836    164   10CB F0971F3F             STA      9,,IMAGE13        "                               DP061780
                                *                                    "SAVE BIT THAT TURNS ON THE LAMP DP061790
                                *                                    "FOR THIS PROCEDURE IN IMAGE13  DP061800
                                *                                    "FOR USE WHEN THE PROCEDURE IS  DP061810
                                *                                    "COMPLETE                       DP061820
                                *                                    "GO TO SELECTED PROCEDURE"      %S061830
                                *                                    "USE PROCEDURE NUMBER (BASED ON DP061840
                                *                                    "THE NUMBER OF THE SELECTED LOWERDP061850
                                *                                    "KEY) TO INDEX A TABLE OF POINT- DP061860
                                *                                    "ERS TO THE CORRECT PROCEDURE   DP061870
3837    174   10CD 07D010CF             BUC      IX13,,$10                                          CI061880
                                * EACH PROCEDURE   0 = DISFINAL                                     *H061890
                                * WILL CONTROL     1 = $55           SYNC                            *H061900
                                * ALL OPERATOR     2 = DISFINAL                                      *H061910
                                * STEPS NECESSARY  3 = NCT_DISPLAY                                   *H061920
                                * TO DEFINE THE    4 = $3            CSE-ETE                         *H061930
                                * DESIRED DISPLAY  5 = DISFINAL      D_GMT                           *H061940
                                * DISFINAL INDI-   6 = $5            LOP                             *H061950
                                * CATES THAT NO    7 = DISFINAL      CAL H/S                         *H061960
                                * FURTHER STEPS    8 = $21           MAN H/S                         *H061970
                                * ARE REQUIRED     9 = DISFINAL      AUTO H/S                        *H061980
                                *                10 = $4            BRG/RNG                         *H061990
                                *                11 = $1            POSITION                        *H062000
                                *                12 = NCT_DISPLAY   COH                             *H062010
3838                    10CF 1108 $10      CON      DISFINAL          INPUTS                            062020
3839                    10D0 10F6          CON      $55               SYNC                            CI062030
3840                    10D1 1108          CON      DISFINAL                                          DP062040
3841                    10D2 1121          CON      NCT_DISPLAY                                         062050
```

```
                                                                                                    062060
3842            10D3  10E1                    CON     $3              CSE - ETE                   062070
3843            10D4  1108                    CON     DISFINAL        D-GMT                       062080
3844            10D5  10F1                    CON     $5              LOP                         062090
3845            10D6  1108                    CON     DISFINAL        CAL H/S                     062100
3846            10D7  10DC                    CON     $21             MAN H/S                     062110
3847            10D8  1108                    CON     DISFINAL        AUTO H/S                    062120
3848            10D9  10E5                    CON     $4              BRG/RNG                     062130
3849            10DA  10DF                    CON     $1              POSITION                    062140
3850            10DB  1121                    CON     NCT_DISPLAY     COH                         062150
                                * ENTER HERE FOR MAN H/S                                            062160
3851      4R    10DC  F4491800  $21           ADDM    4,,X(1800)      "TURN ON SUB - RZ"          062170
3852      8     10DE  D004   (10E3)           BUC     $33
```

```
                                **                                                                      DP062180
                                * ENTER HERE FOR POSITION                                              *H062190
3853        4R      10DF  F4490800  $1          ADDM        4,,X(0800)    "TURN ON SUB                  062200
                                * ENTER HERE FOR ETE - CSE                                             *H062210
3854        4R      10E1  F44913FF  $3          ADDM        4,,X(13FF)    "TURN ON 0-9,RZ UPPER LEFT LAMPS 062220
                                *                                         "TO SELECT POSITION TO BE DIS- DP062230
                                *                                         "PLAYED OR DESTINATION FOR ETE DP062240
                                *                                         "WAIT FOR NEXT BUTTON - SAVE NO. *I062250
3855       80R      10E3  1C0C  $33          ACCEPT      ARGUMENT      "IN ARG1 AND LAMP BIT IN IMAGE11 DP062260
3856        84      10E4  D206  (110B)       BUC         DISFINAL      "PROCEDURE COMPLETE"          DP062270
                                * ENTER HERE FOR R-BRG                                                 *H062280
3857        4R      10E5  F44918FF  $4          ADDM        4,,X(18FF)    "TURN ON SUB, 0-9, RZ LAMPS TO   062290
                                *                                         "SELECT START POINT FOR RANGE DP062300
                                *                                         "WAIT FOR NEXT BUTTON - SAVE NO. *I062310
3858        84      10E7  1C0C                  ACCEPT      ARGUMENT      "IN ARG1 AND LAMP BIT IN IMAGE11 DP062320
3859        86      10E8  8049                  SUB         4,9           "TURN OFF THE SELECTED START  DP062330
                                *                                         "POINT TO FORCE OPERATOR TO   DP062340
                                *                                         "SELECT AN END POINT DIFFERENT DP062350
                                *                                         "THAN THE START POINT         DP062360
                                *                                         "TURN OFF THE 'SUB' LAMP AS   DP062370
                                *                                         "DISPLAY ROUTINE CANNOT PROCESS DP062380
3860        94      10E9  E444112C              EXT         4,4,HX17FF    "SUB AS THE END POINT            062390
3861       164      10EB  1C01                  INPUT       UPPER_LEFT_KEY  "WAIT FOR NEXT BUTTON"      DP062400
3862       174      10EC  F0D71F42              STA         13,,ARGWORD2  "SAVE BUTTON NO. OF END POINT IN DP062410
                                *                                         "ARG2 FOR DISPLAY ROUTINE     DP062420
                                *                                         "SAVE LAMP BIT IN IMAGE11 WITH DP062430
3863       186      10EE  E0991F3D              MRG         9,9,IMAGE11   "BIT OF START POINT LAMP      DP062440
                                *                                         "                             DP062450
3864       190      10F0  D10A  (110B)          BUC         DISFINAL      "PROCEDURE COMPLETE"          DP062460
                                * ENTER HERE FOR LOP                                                    *H062470
                                *                                         "WAIT FOR 2 BUTTONS - SELECTED *I062480
3865       80R      10F1  1C0A  $5          ACCEPT      LEFT_STATION_PAIR   "PAIR IN LEFT LEGEND DISPLAYDP062490
                                *                                         "WAIT FOR 2 BUTTONS - CHOSEN PAIR*I062500
3866       160      10F2  1C0B                  ACCEPT      RIGHT_STATION_PAIR  "IN RIGHT LEGEND DISPLAY DP062510
3867       162      10F3  9C4E                  CLAM        4,14          "TURN ON 1, 2 AND 3              062520
3868       232      10F4  1C01                  INPUT       UPPER_LEFT_KEY                                 062530
3869       236      10F5  D006  (10FC)          BUC         $6                                             062540
                                * ENTER HERE FOR STATUS DISPLAY                                        *H062550
3870        2R      10F6  9C4E  $55         CLAM        4,14          "TURN ON 1, 2, 3 AND             062560
3871        6       10F7  FC691001              CLAM        6,X(1001)     "COH AND INPUTS                  062570
3872        76      10F9  1C03                  INPUT       LOWER_KEY     "WAIT FOR 1 BUTTON               062580
3873        86      10FA  F0D71F42              STA         13,ARGWORD2   "SAVE FOR STATUS DECODE          062590
3874        2R      10FC  90D1  $6          SUBM        13,1          "CHECK IF INPUTS                 062600
```

```
3875    6    10FD  D057  (1105)          BRL    STATUS_INPUTS  "YES                          062610
3876    2R   10FE  9807                  COMM   13,7           "CHECK IF COH                 062620
3877    6    10FF  D035  (1105)          BRG    STATUS_INPUTS  "YES                          062630
3878    10R  1100  F0D71F41              STA    13,ARGWORD1    "SAVE SELECTED FREQUENCY      062640
3879    20   1102  F0971F3D              STA    9,IMAGE11      "AND LAMP BIT                 062650
3880    24   1104  D006  (1108)          BUC    DISFINAL                                     062660
3881                            STATUS_INPUTS;                                               062670
3881    2R   1105  DE50                  FLG    A+L            "FLAG A TRUE IF INPUTS        062680
3882    4    1106  9492                  ADDM   9,2            "KEEP STATUS LIT              062690
3883    14   1107  F0971F3F              STA    9,IMAGE13                                    062700
3884    16   1109  9C40                  CLAM   4,0                                          062710
3885    20   110A  D196  (1121)          BAF    NCT_DISPLAY                                  062720
                            * FALL INTO DISFINAL IF INPUTS                                   062730
```

```
                                        **                                                                  DP062740
                                        * DISPLAY PROCEDURE COMPLETE                                        *H062750
                                        * THIS ROUTINE IS USED TO EXIT                                      *H062760
                                        * THE PANEL INTERRUPT ROUTINE                                       *H062770
                                        * AT THE END OF A PROCEDURE                                         *H062780
3886    2R      1108  9C71              DISFINAL  CLAM      7,,1      "SET DISPLAY MODE (= 1) THIS WILLDP062790
                                        *                             "CAUSE THE C/I PANEL NON OMEGA    DP062800
                                        *                             "TASK ROUTINE TO GENERATE THE     DP062810
                                        *                             "REQUESTED DISPLAY                DP062820
3887    10R     110C  FC4A1F3D          $1        CLAD      4,,IMAGE11 "TURN ON KEYBOARD LAMPS FROM      DP062830
                                        *                             "IMAGE11,12,13 TO REFLECT THE     DP062840
                                        *                             "PROCEDURE SELECTED BY THE        DP062850
3888    18      110E  F46A1F3F                    CLA       6,,IMAGE13 "OPERATOR                         DP062860
3889    4R      1110  F4290A00          $2        ADDM      2,,X(0A00) "TURN ON INSERT AND DISPLAY LAMPS  062870
                                        *                             "WHICH WERE TURNED OFF BY THE     DP062880
                                        *                             "CLEAR ROUTINE AFTER THE DISPLAY  DP062890
3890    8       1112  F4896000                    ADDM      8,,X(6000) "BUTTON WAS SELECTED              062900
3891    16      1114  E422112A                    EXT       2,2,HXFEFF "TURN OFF CLEAR                   062910
                                        *                             "EXIT PANEL PROCEDURE WITH DUMMY  *I062920
3892    70R     1116  1C03              $3        INPUT     LOWER_KEY  "REQUEST FOR ANOTHER BUTTON       DP062930
                                        *                             "IF THE OPERATOR SELECTS ONE OF   DP062940
                                        *                             "THE ILLUMINATED LAMPS NOW IT IS  DP062950
3893    76      1117  040010AA                    BUC       INPUTERROR "AN ILLEGAL PROCEDURE             DP062960
                                        * ENTER HERE TO END AN INSERT                                       *H062970
                                        * PROCEDURE AFTER THE ACCEPT                                        *H062980
                                        * BUTTON IS SELECTED                                                *H062990
3894    4R      1119  F0290400          $4        SUBM      2,,X(0400) "TURN OFF THE ACCEPT LAMP AND     063000
3895    8       1118  F0892000                    SUBM      8,,X(2000) "DELETE IT FROM THE MASK          063010
3896    18      111D  FC77002A                    STA       7,,ACCEPT_OLD "                              DP063020
                                        *                             "SAVE MODE IN ACCEPT OLD MARKER   DP063030
                                        *                             "THE MODE WILL BE ZERO UNLESS THEDP063040
                                        *                             "OPERATOR WAS IN A PROCEDURE      DP063050
                                        *                             "WHERE THE OLD DATA WAS DISPLAYEDDP063060
                                        *                             "ON THE PANEL (MODE = 1) AND IT   DP063070
                                        *                             "WAS ACCEPTED WITHOUT CHANGE      DP063080
3897    20      111F  9C72                    CLAM      7,,2       "SET INSERT MODE (2)  THIS WILL   *S063090
                                        *                             "CAUSE THE C/I PANEL NON OMEGA    DP063100
                                        *                             "TASK ROUTINE TO PROCESS THE      DP063110
                                        *                             "INSERTED DATA                    DP063120
3898    24      1120  D905  (110C)                BUC       $1                                           CI063130
                                        * ENTER HERE FOR NCTR OR COH                                        *H063140
3899    4R      1121  FC5901FE          NCT_DISPLAY CLAM    5,,OSHEX   "TURN ON STATION LAMPS            063150
                                        *                             "WAIT FOR ONE BUTTON - OPERATOR   *I063160
```

```
3900        70R     1123  1C01          $1          INPUT   UPPER_LEFT_KEY   "WILL SELECT A STATION          DP063170
3901        80      1124  F0971F3E                  STA     9,,IMAGE12      "SAVE LAMP BIT IN IMAGE12 FOR  DP063180
3902        82      1126  9001                      SUBM    13,,1                                          HH063190
                                          *                                 "UPPER RIGHT KEY DISPLAY AT END DP063200
                                          *                                 "OF PROCEDURE                  DP063210
3903        92      1127  F0D71F41                  STA     13,,ARGWORD1    "SAVE BUTTON NO. IN ARG1 FOR USE DP063220
                                          *                                 "BY DISPLAY ROUTINE            DP063230
                                          *                                 "                              DP063240
                                          *                                 "PROCEDURE COMPLETE"           DP063250
3904        96      1129  D90F    (1106)            BUC     DISFINAL                                       DP063260
3905                112A  FEFF              HXFEFF  CON     X(FEFF)                                          063270
3906                112B  FFF0              HXFFF0  CON     X(FFF0)                                          063280
3907                112C  17FF              HX17FF  CON     X(17FF)                                          063290
3908                112D  E000              HXE000  CON     X(E000)                                          063300
3909                112E  F0FF              HXF0FF  CON     X(F0FF)                                          063310
```

```
                                        **                                                                  CI063320
                                        *                    INSERT PROCEDURES                              *H063330
                                        *                                                                   *H063340
                                        * ENTER HERE WHEN THE ACCEPT/INSERT BUTTON IS DEPPRESSED.  ALL INSERT *H063350
                                        * PROCEDURES ARE INITIATED AND CONTROLLED HERE.  IF THE ACCEPT LAMP IS *H063360
                                        * ON THEN AN INSERT PROCEDURE IS COMPLETE OTHERWISE THE INSERT LAMP IS *H063370
                                        * ON AND A PROCEDURE IS TO BE INITIATED.                            *H063380
                                        *                                                                   *H063390
3910      8R    112F  E49200DF          INSACC    EXT       9,2,HX0400    "EXAMINE THE ACCEPT LAMP          063400
3911      12    1131  0919   (1119)               BNE       DISFINAL$4    "WAS THE ACCEPT BUTTON DEPRESSED?DP063410
                                        * THE INSERT BUTTON WAS DEPRESSED                                   *H063420
                                        *                                   "PLACE PANEL IN QUIESCENT STATE *I063430
3912      70R   1132  1C00                     INPUT     CLEAR_PANEL   "MODE=0,ACCEPT,INSERT,DISPLAY OFFDP063440
3913      74    1133  FC690921                 CLAM      6,,X(0921)    "TURN ON VALID LAMPS                063450
                                        *                                   "VALID INSERTS  POS, RZ-POS,    DP063460
                                        *                                   "O-GMT, MAN-V/H, OMEGA-DR, RZ-V/HDP063470
                                        *                                   "WAIT FOR OPERATOR TO SELECT AN *I063480
3914      144   1135  1C03                     INPUT     LOWER_KEY     "INSERT WITH A LOWER BUTTON       DP063490
3915      154   1136  F0D71F40                 STA       13,,CALLWORD  "SAVE BUTTON NUMBER IN CALL FOR   DP063500
                                        *                                   "USE BY THE INSERT ROUTINE AFTER DP063510
                                        *                                   "THE PROCEDURE IS COMPLETE. IT  DP063520
                                        *                                   "WILL ALSO BE USED BY THE DISPLAYDP063530
                                        *                                   "ROUTINE IF THE INSERT PROCEDURE DP063540
                                        *                                   "REQUIRES THE DISPLAY OF OLD DATADP063550
                                        *                                   "                               DP063560
3916      164   1138  F0D71F42                 STA       13,,ARGWORD2  "MAKE ARG2 POSITIVE AS A MARKER   DP063570
                                        *                                   "INDICATING A GENERAL INSERT    DP063580
                                        *                                   "                               DP063590
3917      174   113A  F0971F3F                 STA       9,,IMAGE13    "SAVE LAMP BIT IN IMAGE13 TO TURNDP063600
                                        *                                   "ON THE SELECTED LOWER LAMP AT  DP063610
                                        *                                   "THE END OF THE PROCEDURE       DP063620
3918      176   113C  9808                     COMM      13,,11        POSITION                            063630
                                        * THE BUTTON NO.    2 = $21 RZ POS                                  *H063640
                                        * IS USED TO SE-     8 = $9  O-GMT                                   *H063650
                                        * LECT THE INSERT    9 = $10 MAN-V/H                                 *H063660
                                        * PROCEDURE FROM    10 = $11 OMEGA-DR                                *H063670
                                        * A TABLE OF        12 = $10 RZ-V/H                                  *H063680
                                        * POINTERS UNLESS                                                    *H063690
                                        * THE BUTTON IS                                                      *H063700
                                        * POS (=0)                                                          *H063710
                                        *                                                                   *H063720
                                        * $7 IS THE ADDRESS OF THE INSERT TABLE                              *H063730
                                        *                                   "WAS THE POSITION               *I063740
```

AD-A050 501 NORTHROP CORP HAWTHORNE CALIF ELECTRONICS DIV F/G 17/7
AN/BRN-7 COMPUTER PROGRAM SPECIFICATION. VOLUME XIII. APPENDIX.(U)
OCT 73 N00039-73-C-0209
UNCLASSIFIED NORT-73-48 NL

3 OF 4
AD A050501



```
3919   186   113D 07051161                BRL      IX13,,$7      "INSERT PROCEDURE SELECTED      %R063750
                                  * POSITION INSERT                                            *H063760
3920    4R   113F FC4913FF          $1     CLAM     4,,X(13FF)    "TURN ON RZ,DIGITS 0-9 TO       063770
                                  *                              "SELECT A DESTINATION POSITION  DP063780
3921    12   1141 E4D200E3                EXT      13,2,HX4000                                   063790
3922    16   1143 D012   (1146)           BNE      $19           "IS THE ENTER TIME LAMP OFF?    %R063800
3923    4R   1144 F4490800                ADDM     4,,X(0800)    "ALLOW SHIP POSITION INSERTS    063810
                                  *                              "TURN ON SUB LAMP               DP063820
                                  *                              "WAIT FOR NEXT BUTTON - SAVE NO. *I063830
3924    8OR  1146 1C0C          $19    ACCEPT   ARGUMENT      "IN ARG1 AND LAMP BIT IN IMAGE11 DP063840
                                  * ENTER HERE FOR RZ POS                                       *H063850
3925    4R   1147 FC590801      $21    CLAM     5,,X(0801)    "TURN ON N AND S LAMPS FOR      063860
3926    6    1149 9C40                  CLAM     4,,0                                          063870
3927    8    114A 98D8                  COMM     13,,11        "THE LATITUDE                   DP063880
                                  *                              "IS THIS A DEST-                *I063890
3928    12   1148 D019   (1155)          BNE      $2                                            063900
                                  * CRAFT POSITION INSERT                                       *H063910
3929    2R   114C 8CD1                  CLSM     13,,1         "CHANGE ARG2 TO NEGATIVE TO MARK DP063920
                                  *                              "A SPECIAL INSERT               DP063930
                                  *                              "NOTE - THIS MARKER IS USED BY  DP063940
                                  *                              "       THE ROUTINE ACCEPTING   DP063950
                                  *                              "       DIGITS TO SELECT THE    DP063960
3930    12   114D F0071F42                STA      13,,ARGWORD2  "       POSITION QUALITY BEFORE DP063970
3931    20   114F E4D200E4                EXT      13,2,HX8000                                   063980
                                  *                              "IS THIS THE"                   *2063990
3932    24   1151 D063   (1155)          BRE      $2            "FIRST POSITION INSERT?"        %R064000
                                  *                              "(ENTER P ON)                   DP064010
3933    2R   1152 9C71                  CLAM     7,,1          "ALLOW OPERATOR TO SELECT CURRENTDP064020
                                  *                              "CRAFT POSITION WITHOUT CHANGE  DP064030
                                  *                              "                               DP064040
                                  *                              "SET MODE = 1 TO DISPLAY POSITIONDP064050
                                  *                              "WAIT FOR 1 BUTTON (N OR S) END *I064060
3934    72   1153 1C04                  INPUT    WITH_ACCEPT_LIGHT   "PROCEDURE IF ACCEPT PUSHED DP064070
                                  *                              "N OR S IS NOW IN - THE REST OF DP064080
                                  *                              "THE PROCEDURE IS COMMON TO     DP064090
3935    76   1154 D001   (1156)          BUC      $3            "DESTINATION PROCEDURE          DP064100
                                  * DEST 0-9 RZ                                                 DP064110
                                  *                              "WAIT FOR OPERATOR TO SELECT    *I064120
3936    7OR  1155 1C02          $2     INPUT    UPPER_RIGHT_KEY  "NORTH OR SOUTH                064130
3937    4R   1156 FC09A02E      $3     CLAM     0,,X(A02E)    "SET UP TO DISPLAY N IN THE LEFT  064140
                                  *                              "LEGEND AND PUNCTUATION IN LEFT DP064150
3938    6    1158 98D8                  COMM     13,,11        "DISPLAY REGISTER"              064160
                                  *                              "WAS NORTH"                     *1064170
```

```
3939      10    1159  D062  (115C)          BRE     $4              "SELECTED BY THE OPERATOR?"          DP064180
3940       4R   115A  FC09A033              CLAM    0,,X(A033)      "CHANGE LEGEND TO S                  064190
3941      80R   115C  1C07            $4    ACCEPT  FIVE_DIGITS     "WAIT FOR 5 DIGIT LATITUDE INSERTD   P064200
                                      *                             "WAIT FOR OPERATOR TO SELECT E/W     *I064210
3942     160    115D  1C09                  ACCEPT  EAST_OR_WEST    "SET UP RIGHT LEGEND WITH E OR W     DP064220
3943     164    115E  F419A000              ADDM    1,,X(A000)      "DISPLAY PUNCTUATION IN THE RIGHTD   P064230
                                      *                             "DISPLAY REGISTER                    DP064240
                                      *                             "FINISH PROCEDURE"                   *I064250
3944     244    1160  1C08                  ACCEPT  SIX_DIGITS      "6 DIGIT LONG/A,B,C IF SUB/ACCEPTD   P064260
                                      *                                                                  CI064270
3945            1161  1189            $7    CON     $11             INPUTS                               064280
3946            1162  0000                  CON     0                                                    DP064290
3947            1163  0000                  CON     0                                                    DP064300
3948            1164  0000                  CON     0                                                    DP064310
3949            1165  0000                  CON     0                                                    DP064320
3950            1166  116A                  CON     $9              D-GMT                                064330
3951            1167  0000                  CON     0                                                    064340
3952            1168  0000                  CON     0                                                    064350
3953            1169  1179                  CON     $10             MAN H/S                              064360
                                      * ENTER HERE FOR D-GMT                                             *H064370
3954       8R   116A  E4D200E3        $9    EXT     13,2,HX4000     "EXAMINE THE ENTER TIME LAMP         064380
                                      *                             "IS THIS THE"                        *2064390
3955      12    116C  D06A  (1177)          BRE     $91             "FIRST TIME INSERT?"                 ΣR064400
                                      *                             "(ENTER T ON)                        DP064410
                                      *                             "ALLOW OPERATOR TO SELECT CURRENTD   P064420
                                      *                             "DATE - TIME WITHOUT CHANGE          DP064430
                                      *                             "                                    DP064440
                                      *                             "SET MODE = 1 TO DISPLAY DATE        DP064450
3956       2R   116D  9C71                  CLAM    7,,1            "AND TIME                            DP064460
3957       6    116E  FC4903FF              CLAM    4,,X(03FF)      "TURN ON DIGITS 0 - 9                DP064470
                                      *                             "WAIT FOR 1ST DIGIT OF DATE  END     *I064480
3958      76    1170  1C04                  INPUT   WITH_ACCEPT_LIGHT  "PROCEDURE IF ACCEPT PUSHED     DP064490
3959      80    1171  FCB91178              CLAM    11,,$92         "THE OPERATOR IS INSERTING A NEW     DP064500
3960      90    1173  F0B71F43              STA     11,,LINKWORD    "TIME - SET UP TO ENTER DIGIT        DP064510
3961      92    1175  8CAA                  CLSM    10,,10          "ACCEPT ROUTINE FOR 6 DIGITS AND     DP064520
                                      *                             "RETURN TO $92.  THIS WILL MAKE      DP064530
                                      *                             "THE PROGRAM APPEAR TO FOLLOW THED   P064540
                                      *                             "SEQUENCE FOR D-GMT INSERTS THAT     DP064550
3962      96    1176  D302  (11A9)          BUC     INSSIX$4        "ARE NOT THE FIRST                   DP064560
                                      *                             "WAIT FOR 6 DIGIT DATE TO BE         *I064570
3963      80R   1177  1C08            $91   ACCEPT  SIX_DIGITS      "INSERTED BY THE OPERATOR            DP064580
                                      *                             "FINISH PROCEDURE"                   *I064590
3964      80R   1178  1C08            $92   ACCEPT  SIX_DIGITS      "GET 6 DIGIT TIME AND ACCEPT         DP064600
```

```
                        * ENTER HERE FOR MAN-V/H                                                    *H064610
                        * ENTER HERE FOR RZ-V/H                                                     *H064620
3965      4R    1179  FC491800        $10       CLAM      4,,X(1800)      "TURN ON SHIP AND RZ        064630
3966      84    1178  1C0C                      ACCEPT    ARGUMENT                                    064640
3967      88    117C  FC098024                  CLAM      0,,X(8024)      "DISPLAY D IN LEFT DISPLAY  064650
3968      98    117E  F0071C03                  STA       0,,HEADING_GROUP  "FLAG HEADING AS SPECIAL  064660
                        *                                                 "TURN ON PUNCTUATION IN LEFT DP064670
                        *                                                 "DISPLAY REGISTER           DP064680
3969     178    1180  1C08                      ACCEPT    SIX_DIGITS      "WAIT FOR 3 DIGIT HDG INSERT 064690
3970     182    1181  FC19202B                  CLAM      1,,X(202B)      "TURN ON PUNCTUATION IN RIGHT 064700
                        *                                                 "DISPLAY REGISTER           DP064710
                        *                                                 "FINISH PROCEDURE"          *I064720
3971     192    1183  F00C1F41                  FET       0,,ARGWORD1                                 064730
3972     194    1185  980C                      COMM      0,,12           TEST FOR RZ V/H             064740
3973     202    1186  D700                      PRN       0                                           064750
3974     206    1187  D163   (1198)             BRE       PLOT11$1                                    064760
3975     80R    1188  1C06                      ACCEPT    THREE_DIGITS    "GET 3 DIGIT VELOCITY / ACCEPT 064770
                        * ENTER HERE FOR INPUTS                                                     064780
3976      4R    1189  FC490400        $11       CLAM      4,,X(0400)      "TURN ON ALL STATION LAMPS  064790
3977      8     118B  FC5903FE                  CLAM      5,,X(03FE)      "AND AUTO AND MAN           064800
3978      12    118D  F4290400                  ADDM      2,,X(0400)      "TURN ON ACCEPT LAMP AND ENABLE 064810
3979      16    118F  F4892000                  ADDM      8,,X(2000)      "ACCEPT IN THE SWITCH MASK - THIS 064820
                        *                                                 "WILL ALLOW THE OPERATOR TO DP064830
                        *                                                 "ACCEPT WHEN THE OMEGA STATION DP064840
                        *                                                 "LAMPS ON ARE THE CORRECT SET DP064850
3980     12R    1191  F8471F3D        $12       STAD      4,,IMAGE11      "SAVE LAMPS NOW ON IN       064860
                        *                                                 "IMAGE11/12 FOR DISPLAY AT END OF 064870
                        *                                                 "PROCEDURE AND INSERT ROUTINE DP064880
                        *                                                 "WAIT FOR 1 STATION TO BE TURNED *I064890
3981      82    1193  1C01                      INPUT     UPPER_LEFT_KEY  "OFF - END PROCEDURE IF ACCEPT 064900
3982      92    1194  F84A00EB                  CLSD      4,,=D1          "TURN OFF SELECTED LAMPS    064910
3983      94    1196  B049                      SUB       4,9             "                           064920
3984      96    1197  B059                      SUB       5,9             "ALLOW OPERATOR TO TURN OFF 064930
3985     106    1198  EC441F3D                  EXTD      4,4,IMAGE11     "ANOTHER                    064940
3986     110    119A  D80A   (1191)             BUC       $12             "LAMP                       064950
3987            113F                  PLOT11    EQU       INSACC$1                                    PT064960
3988     80R    1198  1C0D            $1        ACCEPT    FOUR_DIGITS     4 DIGIT VELOXITY FOR RZ     064970
```

```
                                                                                                                    CI064980
                                **                                                                                  CI064980
                                *                          DIGIT INPUT                                              *H064990
                                *                                                                                   *H065000
                                * THIS ROUTINE PROCESSES STRINGS OF DIGITS AS REQUESTED BY THE CALLING              *H065010
                                * PROGRAM.  IT HAS ENTRIES FOR STRINGS OF 2, 3, 5 AND 6 DIGITS.  ALL               *H065020
                                * DIGITS ARE DISPLAYED IN THE APPROPIATE REGISTER AS INDICATED BY                  *H065030
                                * WINDOWAD.  IT IS ASSUMMED THAT THE LAST DIGIT IN GOES INTO THE RIGHT            *H065040
                                * MOST DIGIT OF THE DISPLAY AND ALL OTHERS ARE PLACED ACCORDINGLY.  IT            *H065050
                                * HAS SPECIAL PROVISIONS TO INCREMENT THE WINDOWAD BY 2 AT THE END OF             *H065060
                                * EACH SEQUENCE.  IT WILL LOOK FOR A SPECIAL INSERT AND REQUEST POSITION         *H065070
                                * QUALITY DATA IF REQUIRED.  IF THE DISPLAY REGISTER IS THE RIGHT DIS-            *H065080
                                * PLAY IT WILL TURN ON THE ACCEPT LAMP AT THE END OF THE SEQUENCE                  *H065090
                                *                                                                                 *H065100
3989        2R    119C  8CA2        INSTWO    CLSM    10,,2          "INITIALIZE COUNTER FOR 2 DIGITS           DP065110
3990        6     119D  D007  (11A5)          BUC     INSSIX$1                                                  DP065120
3991        2R    119E  8CA4        INSTHREE  CLSM    10,,4          "INITIALIZE COUNTER FOR 3 DIGITS           DP065130
3992        6     119F  D005  (11A5)          BUC     INSSIX$1                                                  CI065140
3993        2R    11A0  8CA6        INSFOUR   CLSM    10,,6          "INITIALIZE COUNTER FOR 4 DIGITS            065150
3994        6     11A1  D003  (11A5)          BUC     INSSIX$1                                                   065160
3995        2R    11A2  8CA8        INSFIVE   CLSM    10,,8          "INITIALIZE COUNTER FOR 5 DIGITS           DP065170
3996        6     11A3  D001  (11A5)          BUC     INSSIX$1                                                  CI065180
3997        2R    11A4  8CAA        INSSIX    CLSM    10,,10         "INITIALIZE COUNTER FOR 6 DIGITS           DP065190
3998        4R    11A5  FC4903FF    $1        CLAM    4,,X(03FF)     "TURN ON DIGIT LAMPS 0 - 9                 DP065200
3999        6     11A7  9C50                  CLAM    5,,0           "CLEAR UPPER RIGHT KEYS                     065210
                                *                                    "WAIT FOR THE OPERATOR TO SELECT           *I065220
4000        70R   11A8  1C01        $3        INPUT   UPPER_LEFT_KEY   "ONE DIGIT                               DP065230
4001        14R   11A9  FEBA00A5    $4        CLAD    I11,,WINDOWAD  "READ LEFT OR RIGHT DISPLAY USING         DP065240
                                *                                    "WINDOWAD AS A POINTER                     DP065250
                                *                                    "EACH DIGIT IN THE DISPLAY NOT             DP065260
                                *                                    "YET INSERTED IS A BLANK WHICH IS          DP065270
                                *                                    "A BCD 15                                  DP065280
                                *                                    "FORM INSERTED DIGIT NUMBER - 15           DP065290
                                *                                    "SO THAT IT WILL BE CORRECT AFTER          DP065300
4002        16    11AB  90DF                  SUBM    13,,15         "IT IS ADDED TO THE DISPLAY                DP065310
                                *                                    "USE DIGIT COUNT TO DETERMINE              *S065320
                                *                                    "THE NUMBER OF SHIFTS NECESSARY            DP065330
                                *                                    "TO PLACE THE DIGIT IN THE COR-            DP065340
                                *                                    "RECT DISPLAY CHARACTER                    DP065350
                                *                                    "                                          DP065360
                                *                                    "BRANCH INDEXED BY DIGIT COUNT             DP065370
                                *                                    "TO A TABLE OF SHIFT INSTRUCTIONS          DP065380
                                *                                    "$6 IS JUST A REFERENCE POINT              DP065390
4003        22    11AC  05A01188              BUC     X10,,$6        "IN THE TABLE FOR INDEXING                 DP065400
```

```
                                    * ENTER HERE FOR SIXTH POSITION                                                  *H065410
4004      4R      11AE  F4D4001C             LSA       13,,4          "SHIFT DIGIT OVER 1 CHARACTER                 DP065420
                                    * ENTER HERE FOR FIFTH POSITION                                                  *H065430
4005      8       11B0  F4D40010             LSA       13,,4          "SHIFT DIGIT OVER 1 CHARACTER                 DP065440
                                    * ENTER HERE FOR FOURTH POSITION                                                 *H065450
4006      12      11B2  F4D40010             LSA       13,,4          "SHIFT DIGIT OVER 1 CHARACTER                 DP065460
                                    * ENTER HERE FOR THIRD POSITION                                                  *H065470
4007      14      11B4  B48D                 ADD       11,13          "ADD DIGIT TO THE DISPLAY WORD                DP065480
4008      18      11B5  D005   (11BB)        18UC      $7             "FOR THE 4 HIGH ORDER DIGITS                  DP065490
                                    * ENTER HERE FOR SECOND POSITION                                                 *H065500
4009      4R      11B6  F4D40010             LSA       13,,4          "SHIFT DIGIT OVER 1 CHARACTER                 DP065510
                                    * ENTER HERE FOR FIRST POSITION                                                  *H065520
4010      4R      11B8  F4D40100   $6        LSA       13,,8                                                        % 065530
                                    *                                  "SHIFT DIGIT OVER 2 CHARACTERS                DP065540
                                    *                                  "BECAUSE 2 LOW ORDER DIGITS OCCURD            P065550
                                    *                                  "IN THE MOST SIGNIFICANT BITS OF              DP065560
                                    *                                  "THE WORD                                     DP065570
4011      6       11BA  B4CD                 ADD       12,13          "ADD DIGIT TO THE DISPLAY WORD                DP065580
4012      16R     11BB  FA8700A5   $7        STAD      I11,,WINDOWAD  "RESTORE UPDATED DISPLAY FOR                 DP065590
                                    *                                  "OUTPUT TO THE C/I PANEL                      DP065600
4013      24      11BD  F48A1C03             CLA       11,,HEADING_GROUP  "TEST FOR HEADING                        065610
4014      28      11BF  D066   (11C6)        BRE       $9                 "AND                                      065620
4015      4R      11C0  F8A9FFFA             COMM      10,,-6             "EXIT AFTER                               065630
4016      8       11C2  D013   (11C6)        BNE       $9                 "INSERT OF THREE                          065640
4017      2R      11C3  B0AA                 SUB       10,10              "DIGITS                                   065650
4018      12      11C4  F0A71C03             STA       10,,HEADING_GROUP                                            065660
4019      2R      11C6  9CB0         $9      CLAM      11,,0                                                        065670
                                    *                                  "INCREMENT DIGIT                              *2065680
4020      10      11C7  CEA3   (11A5)        BXUD      10,,$1         "COUNT - IS THE DIGIT SEQUENCE                %R065690
                                    *                                  "COMPLETE?                                    DP065700
4021      2R      11C8  9C40               CLAM      4,,0           "TURN OFF DIGIT LAMPS 0 - 9                   DP065710
4022      10      11C9  F4DA00A5             CLA       13,,WINDOWAD   "INCREMENT WINDOWAD WHICH WILL                DP065720
                                    *                                  "CHANGE IT TO RIGHT IF IT WAS                 DP065730
                                    *                                  "LEFT (CLEAR SETS IT TO LEFT)                 DP065740
                                    *                                  "NOTE - ALL PROCEDURES REQUIRE                DP065750
                                    *                                  "       THAT THE LEFT DIGITS BE               DP065760
4023      12      11CB  94D2                 ADDM      13,,2          "       ENTERED FIRST.  MOST                  DP065770
                                    *                                  "       PROCEDURES END WITH THE               DP065780
4024      22      11CC  F0D700A5             STA       13,,WINDOWAD   "       RIGHT DIGITS                          DP065790
4025      24      11CE  98D5                 COMM      13,,C_I_RIGHT_DISPLAY                                        CI065800
                                    * IF THIS IS THE END OF THE LEFT                                                 *H065810
                                    * DISPLAY SEQUENCE THE ROUTINE                                                   *H065820
                                    * WILL RETURN TO THE NEXT STEP                                                  *H065830
```

```
                        * IN THE PROCEDURE WHICH IS                                                    *H065840
                        * CONTAINED IN LINK                                                            *H065850
                        *                                          "WAS A LEFT                         *I065860
4026  34  11CF 06061F43          BRE       I,,LINKWORD           "DISPLAY REGISTER JUST COMPLETED?DP065870
4027   8R 11D1 F40A1F42          CLA       13,,ARGWORD2                                               % 065880
                        * RIGHT DISPLAY - PREPARE TO                                                   *H065890
                        * END INSERT PROCEDURE                                                         *H065900
                        *                                          "IS THIS A                          *I065910
4028  12  11D3 D026  (11DA)      BGE       $8                    "GENERAL INSERT PROCEDURE?          DP065920
4029   2R 11D4 9C5E              CLAM      5,,14                 "SPECIAL"                            065930
                        *                                          "TURN ON A, B AND C FOR POSITION DP065940
                        *                                          "QUALITY                         DP065950
                        *                                          "WAIT FOR OPERATOR"              *I065960
4030  72  11D5 1C02              INPUT     UPPER_RIGHT_KEY       "TO SELECT QUALITY"                 DP065970
4031  74  11D6 90D1              SUBM      13,,1                                                      065980
4032  84  11D7 F0D71F42          STA       13,,ARGWORD2          "SAVE QUALITY BUTTON NO. IN ARG2    DP065990
                        *                                          "FOR INSERT ROUTINE              DP066000
                        *                                          "KEEP THE QUALITY LAMP ON        DP066010
4033  86  11D9 A459              CLA       5,9                   "FOR ACCEPT                         DP066020
                        *   INSERT FINAL                                                               CI066030
                        *                                          "ALLOW OPERATOR TO ACCEPT THE       *I066040
4034  70R 11DA 1C04          $8  INPUT     WITH_ACCEPT_LIGHT     "INSERTED DATA                      DP066050
                        *                                          "ERROR IF OPERATOR PUSHES ANY       DP066060
4035  76  11DB 040010AA          BUC       INPUTERROR            "OTHER BUTTON                       DP066070
```

```
                                                **                                                                  DP066080
                                                *                    STATION PAIR                                   *H066090
                                                *                                                                   *H066100
                                                * THIS ROUTINE IS USED BY THE LOP DISPLAY PROCEDURE TO ALLOW THE    *H066110
                                                * OPERATOR TO SELECT A PAIR OF STATIONS AND DISPLAY THE SELECTED PAIR *H066120
                                                * IN THE LEGENDS                                                    *H066130
                                                *                                                                   *H066140
                                                * ENTER HERE FOR LEFT STATION PAIR                                  *H066150
4036      2R        11DD  9CA0                  STAPAIR   CLAM      10,,0          "SET MARKER = 0 FOR LEFT       DP066160
4037      6         11DE  D001   (11E0)                   BUC       $2                                            CI066170
                                                * ENTER HERE FOR RIGHT STATION PAIR                                *H066180
4038      2R        11DF  9CA1                  $1        CLAM      10,,1          "SET MARKER = 1 FOR RIGHT      DP066190
4039      4R        11E0  FC5901FE              $2        CLAM      5,,OSHEX       "TURN ON STATION LAMPS         DP066200
4040      8         11E2  FC3917D4                       CLAM      3,,ASCII-1     "WAIT FOR OPERATOR TO SELECT THE *I066210
4041      78        11E4  1C02                           INPUT     UPPER_RIGHT_KEY   "FIRST STATION OF THE PAIR   DP066220
4042      80        11E5  B059                           SUB       5,9                                           066230
4043      82        11E6  B4D3                           ADD       13,3                                          066240
4044      88  *     11E7  F1AD11F4                       XEQ       X10,,$3        "USE MARKER TO DISPLAY STATION INDP066250
                                                *                                 "RIGHT OR LEFT DISPLAY LEGEND  DP066260
                                                *                                 "TURN OFF SELECTED STATION LAMP  066270
                                                *                                 "SO THAT THE SECOND STATION WILL DP066280
                                                *                                 "BE DIFFERENT THAN THE FIRST   DP066290
                                                *                                 "WAIT FOR OPERATOR TO SELECT THE *I066300
4045      158       11E9  1C02                           INPUT     UPPER_RIGHT_KEY   "SECOND STATION OF THE PAIR  DP066310
4046      164 *     11EA  F1AD11F6                       XEQ       X10,,$4                                       066320
4047      166       11EC  B4D3                           ADD       13,3                                          066330
4048      172 *     11EE  F1AD11F9                       XEQ       X10,,$5                                       066340
4049      178 *     11EF  F1AD11F8                       XEQ       X10,,$6                                       066350
4050      180       11F1  9C50                           CLAM      5,,0           "TURN OFF ALL STATION LAMPS    DP066360
                                                *                                 "RETURN TO THE DISPLAY PROCEDURE DP066370
4051      190       11F2  06001F43                       BUC       I,,LINKWORD    "WHICH IS DEFINED IN LINK      DP066380
4052      6R        11F4  A60D                $3         CLA       I0,13                                         % 066390
4053      12        11F5  A61D                           CLA       I1,13                                         % 066400
4054      6R        11F6  4658   (00D8)       $4        1MPI      0,,HX0040                                     % 066410
4055      10        11F7  F4140040                       LSA       1,,6                                          % 066420
4056      6R        11F9  B60D                $5         ADD       I0,13                                         % 066430
4057      12        11FA  B61D                           ADD       I1,13                                         % 066440
4058      6R        11FB  9663   (00E3)       $6         ADD       0,,HX4000                                     % 066450
4059      14        11FC  F41800E3                       ADD       1,,HX4000                                     % 066460
```

```
                                **                                                                  DP066470
                                *                    INPUT EAST OR WEST                             *H066480
                                *                                                                   *H066490
                                * THIS ROUTINE WILL ALLOW THE OPERATOR TO SELECT EAST OR WEST LONGITUDE *H066500
                                * AND DISPLAY THE E OR W IN THE RIGHT DISPLAY LEGEND                 *H066510
                                *                                                                   *H066520
4060      4R    11FE  FC591400  ENTEREW   CLAM     5,,X(1400)     "TURN ON E AND W LAMPS          DP066530
                                *                                  "WAIT FOR OPERATOR TO SELECT    *I066540
4061      74    1200  1C02              INPUT    UPPER_RIGHT_KEY   "EAST OR WEST"                  DP066550
4062      78    1201  FC190025          CLAM     1,,X(0025)     "SET UP TO DISPLAY E IN THE RIGHTDP066560
4063      80    1203  98DC              COMM     13,,12         "LEGEND                         DP066570
4064      84    1204  D062   (1207)     BRE      $1             "DID THE OPERATOR SELECT EAST?  DP066580
4065      4R    1205  FC190037          CLAM     1,,X(0037)     "CHANGE LEGEND DISPLAY TO WEST  DP066590
4066      2R    1207  9CD5    $1        CLAM     13,,C_I_RIGHT_DISPLAY GUARANTEE                 CI066600
                                *                                  "SET WINDOWAD TO RIGHT SO THAT  DP066610
                                *                                  "NEXT DIGIT SEQUENCE WILL       DP066620
4067      12    1209  F0D700A5          STA      13,,WINDOWAD   "TERMINATE WITH ACCEPT          DP066630
4068      14    120A  9C50              CLAM     5,,0           "TURN OFF E AND W LAMPS         DP066640
                                *                                  "CONTINUE PROCEDURE BY RETURNING DP066650
4069      24    120B  06001F43          BUC      I,,LINKWORD    "TO LINK POINTER                DP066660
                                *                    ARGUMENT INPUT                                 *H066670
                                *                                                                   *H066680
                                * THIS ROUTINE WILL EXECUTE AN 'INPUT UPPER LEFT KEY' AND SAVE THE   *H066690
                                * BUTTON NUMBER IN ARG1 AND THE LAMP BIT IN IMAGE11.  IT IS USED BY  *H066700
                                * PROCEDURES THAT WANT TO PASS THE BUTTON NUMBER (UPPER LEFT) TO THE *H066710
                                * DISPLAY OR INSERT ROUTINES.                                        *H066720
                                *                                                                   *H066730
4070      70R   120D  1C01    ARGINPUT  INPUT    UPPER_LEFT_KEY   "WAIT FOR 1 BUTTON"            DP066740
4071      80    120E  F0971F3D          STA      9,,IMAGE11     "SAVE NUMBER IN ARG1            DP066750
4072      90    1210  F0D71F41          STA      13,,ARGWORD1   "SAVE LAMP BIT IN IMAGE11       DP066760
                                *                                  "USE LINK POINTER TO RETURN     DP066770
4073     100    1212  06001F43          BUC      I,,LINKWORD    "TO PROCESS                     DP066780
```

```
                                                **                                                              DP066790
                                                *                    PANEL PIN SUBROUTINE                       *H066800
                                                *                                                               *H066810
                                                * THIS SUBROUTINE IS AN ENTRY POINT FOR ALL PANEL PROCEDURE SUBROUTINES. *H066820
                                                * THESE ROUTINES ALL HAVE THE FEATURE OF NOT RETURNING TO THE CALLING    *H066830
                                                * PROCEDURE UNTIL THE OPERATOR DEPRESSES A BUTTON.  THE PANEL INPUT     *H066840
                                                * PROGRAM IS AN INTERRUPT PROGRAM THAT REQUIRES AN ORDERLY RETURN TO    *H066850
                                                * THE INTERRUPTED PROGRAM AND THEREFORE NORMAL SUBROUTINE ENTRIES CAN    *H066860
                                                * NOT BE USED IN THE PANEL INTERRUPT PROGRAM.  THIS SPECIAL ROUTINE      *H066870
                                                * REMOVES THE RETURN ADDRESS FROM THE R14 PUSHDOWN STACK AND SAVES IT    *H066880
                                                * IN SPECIAL LINKAGES FOR USE AFTER A BUTTON HAS BEEN DEPRESSED.  THIS  *H066890
                                                * ROUTINE THEN ENTERS THE SELECTED SUBROUTINE WHICH WILL TURN ON THE     *H066900
                                                * APPROPIATE LAMPS AND EXIT FROM THE PANEL INTERRUPT PROGRAM.  THE       *H066910
                                                * RETURN FROM THE SELECTED SUBROUTINE ACTUALLY OCCURS AFTER THE NEXT     *H066920
                                                * BUTTON HAS BEEN READ AND INTERPRETED AT WHICH TIME THE PANEL INTERRUPT*H066930
                                                * PROGRAM WILL CONTINUE THE PROCEDURE BY USING THE LINKAGE FOR A RETURN.*H066940
                                                * THE ARGUMENT CONSISTS OF A POINTER TO SELECT A SUBROUTINE FROM A TABLE*H066950
                                                *                                                               *H066960
                                                *                                        "WAS THE CLEAR         *2066970
4074  4R  1214  D068  (1220)  PANEL_PIN  BRE     $2                                      "ROUTINE SELECTED?"    DP066980
                                                *                                        "(POINTER = 0)         DP066990
4075  8R  1215  C1E1                     FET     X14,,1                                  "READ RETURN ADDRESS FROM R14  DP067000
                                                *                                        "PUSH DOWN STACK       DP067010
4076  10  1216  9814                     COMM    1,,ACCEPT_GROUP                                                CI067020
                                                * ALLOW 2 LEVELS OF NESTING                                     *H067030
                                                * THE ACCEPT GROUP MAY ALSO                                     *H067040
                                                * REQUEST BUTTON INPUTS                                         *H067050
                                                *                                        "IS THIS ROUTINE       *1067060
4077  14  1217  D052  (121A)                   BRL     $1                              "IN THE ACCEPT GROUP?  %R067070
4078  10R 1218  F0071F43                       STA     0,,LINKWORD     "SAVE RETURN IN LINK LINKAGE   DP067080
                                                * ACCEPT ROUTINES WILL CALL                                     *H067090
                                                * FOR AN INPUT ROUTINE AS                                       *H067100
                                                * THE INPUT ROUTINES ARE THE                                    *H067110
                                                * ONLY ONES THAT EXIT THE                                       *H067120
                                                * PANEL INTERRUPT PROGRAM                                       *H067130
4079  10R 121A  F4071F44                $1    PTR     0,,PROCWORD     "SAVE RETURN IN PROC LINKAGE   DP067140
                                                * PANEL INTERRUPT WILL ALWAYS                                   *H067150
                                                * RETURN TO PROC LINKAGE WHEN                                   *H067160
                                                * EVER A KEYBOARD IS DEPRESSED                                  *H067170
                                                * THE ACCEPT GROUP WILL ALWAYS                                  *H067180
                                                * RETURN TO THE LINK LINKAGE WHICH                              *H067190
                                                * WILL ALWAYS POINT TO A BASIC                                  *H067200
                                                * PROCEDURE                                                     *H067210
```

```
4080   18   121C  F50A123A          CLA     X0,,PPT      "READ START ADDRESS OF SELECTED  DP067220
                                    *                    "SUBROUTINE FROM TABLE AND WRITE DP067230
                                    *                    "INTO R14 PUSH DOWN STACK WHERE  DP067240
4081   26   121E  71E1              STA     X14,,1       "CALLING PROGRAM RETURN WAS.     DP067250
                                    *                    "ENTER SUBROUTINE BY EXECUTING A *S067260
                                    *                    "BBK (SUBROUTINE RETURN) WHICH   DP067270
                                    *                    "WILL RESTORE THE R14 POINTER TO DP067280
4082   38   121F  D500              BBK     0            "ITS PROPER VALUE                DP067290
                                    *  PIN ENTRY TO DISCLEAR                              CI067300
4083   8R   1220  D700              $2      PRN     0    "ADJUST R15 AND SEQUENCE TO CLEARDP067310
                                    *                                                     *H067320
                                    * CLEAR PANEL - PUT PROGRAM AND PANEL IN QUIESCENT STATE *H067330
                                    *                                                     *H067340
4084   8R   1221  E422112E          DISCLEAR EXT    2,2,HXFOFF   "TURN OFF ACCEPT, INSERT AND DP067350
4085   12   1223  F4290100                 ADDM    2,,X(0100)   "TURN ON CLEAR               067360
4086   16   1225  FC898003                 CLAM    8,,X(8003)   "DISPLAY LAMPS              067370
4087   20   1227  8844                     SUBD    4,4          "SWITCH MASK             DP067380
4088   22   1228  9C60                     CLAM    6,,0         "TURN OFF ALL KEYBOARD LAMPS DP067390
4089   34   1229  F8471F3D                 STAD    4,,IMAGE11   "AND CLEAR KEYBOARD IMAGE  DP067400
4090   44   122B  F0671F3F                 STA     6,,IMAGE13                            CI067410
                                    * ENTER HERE TO BLANK DISPLAYS                        *H067420
                                    * AND LEGENDS AND SET MODE = 0                        *H067430
4091   2R   122D  9C03              $1      CLAM    0,,C_I_LEFT_DISPLAY INITIALIZE        CI067440
4092   10   122E  7025   (00A5)            STA     0,,WINDOWAD  "INITIALIZE WINDOWAD TO POINT TO DP067450
4093   12   122F  8C01                     CLSM    0,,1         "LEFT DISPLAY AND GUARANTEE THAT DP067460
4094   16   1230  FC19FF00                 CLAM    1,,X(FF00)   "NEXT DIGIT SEQUENCE WILL BE LEFTDP067470
4095   28   1232  F8070003                 STAD    0,,C_I_LEFT_DISPLAY BLANK             CI067480
4096   40   1234  F8070005                 STAD    0,,C_I_RIGHT_DISPLAY WINDOWS          CI067490
4097   44   1236  8800                     SUBD    0,0          "BLANK LEFT, RIGHT DISPLAYS AND DP067500
4098   46   1237  9C70                     CLAM    7,,0         "LEGENDS                 DP067510
4099   56   1238  F0071C03                 STA     0,,HEADING_GROUP                      DP067520
4100   64   123A  D5F0                     BBK     15           "SET MODE = 0 = QUIESCENT DP067530
```

```
                                **                                                                  CI067540
                                *   TABLE OF ENTRY POINTS TO PANEL PINS                             CI067550
                                PANEL_PIN_TABLE,;                                                   CI067560
4101                                                                                                CI067570
4101    1238  109C              PT1         CON         PANOUT          INPUT                     CI067580
4102    123C  10A8              PT2         CON         PANOUT$4        INPUT                     CI067590
4103    123D  109D              PT3         CON         PANOUT$1        INPUT                     CI067600
4104                            START_ACCEPT_GROUP,;                                                CI067610
4104    123E  108F              PT4         CON         OUTWAL          INPUT (SPECIAL)           DP067620
4105    123F  119C              PT5         CON         INSTWO                                    DP067630
4106    1240  119E              PT6         CON         INSTHREE        ACCEPT                    CI067640
4107    1241  11A2              PT7         CON         INSFIVE         ACCEPT                    CI067650
4108    1242  11A4              PT8         CON         INSSIX          ACCEPT                    CI067660
4109    1243  11FE              PT9         CON         ENTEREW         ACCEPT                    CI067670
4110    1244  11DD              PT10        CON         STAPAIR         ACCEPT                    CI067680
4111    1245  11DF              PT11        CON         STAPAIR$1       ACCEPT                    CI067690
4112    1246  120D              PT12        CON         ARGINPUT        ACCEPT                     067700
4113    1247  11A0              PT13        CON         INSFOUR         ACCEPT                    CI067710
4114    123A                    PPT         EQU         PANEL_PIN_TABLE-1                         CI067720
4115                            ACCEPT_GROUP;                                                       CI067730
4115    0004                                EQU         START_ACCEPT_GROUP-PPT
```

```
                                **                                                  CI067740
                                *   LABELS FOR PANEL PINS                           CI067750
                                *       INPUT GROUP                                 CI067760
4116            0000            CLEAR_PANEL EQU         0           DUMMY           CI067770
4117                            UPPER_LEFT_KEY;                                     CI067780
4117            0001                    EQU         PT1-PPT                         CI067790
4118                            UPPER_RIGHT_KEY;                                    CI067800
4118            0002                    EQU         PT2-PPT                         CI067810
4119            0003            LOWER_KEY   EQU         PT3-PPT                     CI067820
4120                            WITH_ACCEPT_LIGHT;                                  CI067830
4120            0004                    EQU         PT4-PPT     (SPECIAL)           CI067840
                                *       ACCEPT GROUP                                CI067850
4121            0005            TWO_DIGITS  EQU         PT5-PPT                     DP067860
4122                            THREE_DIGITS;                                       DP067870
4122            0006                    EQU         PT6-PPT                         DP067880
4123            0007            FIVE_DIGITS EQU         PT7-PPT                     CI067890
4124            0008            SIX_DIGITS  EQU         PT8-PPT                     CI067900
4125                            EAST_OR_WEST;                                       CI067910
4125            0009                    EQU         PT9-PPT                         CI067920
4126                            LEFT_STATION_PAIR;                                  CI067930
4126            000A                    EQU         PT10-PPT                        CI067940
4127                            RIGHT_STATION_PAIR;                                 CI067950
4127            000B                    EQU         PT11-PPT                        CI067960
4128            000C            ARGUMENT    EQU         PT12-PPT                    CI067970
4129            000D            FOUR_DIGITS EQU         PT13-PPT                    067980
```

```
                                                **                                                                  DP067990
                                                *                        DISPLAY PROGRAM                            *H068000
                                                *                                                                   *H068010
                                                * THIS ROUTINE IS ENTERED FROM THE MAIN PANEL PROGRAM 10 TIMES A SECOND *H068020
                                                * WHENEVER THE PANEL IS IN THE DISPLAY MODE (1).  IT GENERATES A NEW    *H068030
                                                * DISPLAY EVERY SECOND BASED ON THE PROCEDURE IDENTIFIED IN CALL.       *H068040
                                                *                                                                   *H068050
4130        8R      1248  F43A003E      PANELOUTPUT CLA       3,,PANEL_COUNT "READ DISPLAY PANEL 10 COUNTER        DP068060
4131        12      124A  D066   (1251)             BRE       $2             "IS IT TIME FOR A DISPLAY UPDATE?     DP068070
4132        2R      124B  9431                      ADDM      3,,1           "INCREMENT 10 COUNTER                 DP068080
4133        10R     124C  F037003E      $1          STA       3,,PANEL_COUNT "SAVE 10 COUNTER                      DP068090
                                                *                            "                                     DP068100
                                                *                            "DISPLAY PROGRAM COMPLETE"            DP068110
                                                *                            "RETURN TO MAIN PANEL PROGRAM TO      DP068120
                                                *                            "GENERATE STATUS DISPLAYS             DP068130
4134        22      124E  D720                      PRN       2                                                    DP068140
4135        28      124F  04000ECA                  BUC       PANEL_MAIN$11                                        DP068150
4136        8R      1251  F43A0009      $2          CLA       3,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES           DP068160
                                                *                            "EXAMINE THE HOLD LAMP                DP068170
4137        12      1253  4438                      LSA       3,,3           "                                      068180
4138        16      1254  D052   (1257)             BRL       $3             "DOES THE OPERATOR HAVE THE HOLD      DP068190
                                                *                            "MODE ON?"                            DP068200
4139        8R *    1255  F80D14EE                  BSV       VARSAVE        "TRANSFER VARIABLES FOR DISPLAY       DP068210
4140        8R      1257  F43A00CA      $3          CLA       3,,MODE        "SET PROGRAM FLAG C TO DEFINE         DP068220
                                                *                            "NAVIGATION MODE                      DP068230
                                                *                            "  TRUE = PHASE DIFFERENCE            DP068240
                                                *                            " FALSE = RHO - RHO                   DP068250
                                                *                            "                                     DP068260
4141        10      1259  DE62                      FLG       C+E            "SUB ALWAYS PHASE DIFFERENCE          DP068270
                                                * USE PARAMETER              0 = POP11                             *H068280
                                                * IN CALL TO                 1 = POP2                              *H068290
                                                * DEFINE DISPLAY             2 = POP4                              *H068300
                                                * SUBROUTINE                 3 = POP12                             *H068310
                                                *                            4 = POP7                              *H068320
                                                *                            5 = POP9                              *H068330
                                                *                            6 = POP5                              *H068340
                                                *                            7 = POP14                             *H068350
                                                *                            8 = POP10                             *H068360
                                                *                            9 = POP15                             *H068370
                                                *                           10 = POP6                              *H068380
                                                *                           11 = POP1                              *H068390
                                                *                           12 = POP8                              *H068400
                                                *                            "SELECT DISPLAY SUBROUTINE"           *I068410
```

```
4142    22 *    125A  F80D1263                BSV     IX0,,$4      "FROM DISPLAY TABLE"          DP068420
                                      * THE GENERATION OF THE DISPLAY                            *H068430
                                      * IS NOW COMPLETE AND THE DATA                             *H068440
                                      * IS READY FOR OUTPUT                                      *H068450
4143    24      125C  9C63                      CLAM    6,,C_I_LEFT_DISPLAY                     DP068460
4144    36      125D  7D60                      PTRD    X6,,0        "OUTPUT LEFT DISLAY        DP068470
4145    44      125E  7544                      PTR     X4,,4        "      LEFT LEGEND         DP068480
4146    56      125F  7D32                      PTRD    X3,,2        "      RIGHT DISPLAY       DP068490
4147    64      1260  7515                      PTR     X1,,5        "      RIGHT LEGEND        DP068500
                                      * RETURN HERE (WITH PROPER                                 *H068510
                                      * HANDLING OF R14) IF THE                                  *H068520
                                      * DISPLAY SUBROUTINE SET UP                                *H068530
                                      * ITS OWN DISPLAYS                                         *H068540
4148    2R      1261  8C39            $5        CLSM    3,,9         "RESET PANEL COUNT TO 10 TO DP068550
4149    6       1262  D907    (124C)            BUC     $1           "DELAY ANOTHER SECOND       DP068560
                                      *   JUMP TABLE FOR DISPLAY ROUTINES                        DP068570
4150            1263  146A            $4        CON     POP11        INPUTS                        068580
4151            1264  1293                      CON     POP2         SYNC                        DP068590
4152            1265  12C2                      CON     POP4         POS VAR                       068600
4153            1266  142D                      CON     POP12        N COUNTER                     068610
4154            1267  12CE                      CON     POP7         CSE-ETE                       068620
4155            1268  1386                      CON     POP9         D-GMT                         068630
4156            1269  13D9                      CON     POP5         LOP                           068640
4157            126A  148B                      CON     POP14        CAL H/S   (GS-TK)             068650
4158            126B  145F                      CON     POP10        MAN-H/S                       068660
4159            126C  1498                      CON     POP15        AUTO H/S                      068670
4160            126D  12C9                      CON     POP6         BGR/RWG                       068680
4161            126E  1270                      CON     POP1         POSITION  SHIP  0-9 RZ        068690
4162            126F  12E2                      CON     POP8         COH                           068700
```

```
                                **                                                                  DP068710
                                * ENTER HERE FOR POSITION DISPLAY                                  *H068720
4163        2R      1270  9818  POP1        COMM        1,,11          "EXAMINE ARG1              DP068730
4164        6       1271  D068  (127A)      BRE         $2             "SHIP                        068740
                                * DISPLAY DESTINATION POSITION                                     *H068750
                                * OR INTERCEPT POSITION                                            *H068760
4165        2R      1272  8411              ADD         1,1            DOUBLE DESTINATION INDEX   DP068770
                                *                                      "READ LONGITUDE            DP068780
4166        14R     1273  F91C1FC4  $118    2FETD       X1,,DESTINATION_LONGITUDE                 % 068790
                                *                                      "CONVERT LONGITUDE FOR DISPLAY *I068800
4167        590     1275  0C02              GEN         LONGITUDE_DISPLAY  "AND SET UP LEGEND"    DP068810
                                *                                      "READ LATITUDE             DP068820
4168        14R     1276  F94C1FDE  $119    2FETD       X4,,DESTINATION_LATITUDE                  % 068830
                                *                                      "CONVERT LATITUDE FOR DISPLAY *I068840
4169        590     1278  0C01              GEN         LATITUDE_DISPLAY  "AND SET UP LEGEND"     DP068850
4170        598     1279  D5F0              BBK         15             "RETURN TO MAIN DISPLAY ROUTINE DP068860
                                * ENTER HERE FOR CRAFT POSITION                                    *H068870
4171        8R      127A  F4081F55  $2       FETM        0,,RIJ_STAR    "READ POINTER TO R1 VECTOR DP068880
                                *                                      "CONVERT POSITION VECTOR TO *I068890
4172        8R *    127C  F80D14A7  $21       BSV         MAKE_LAT_LONG   "LATITUDE AND LONGITUDE  DP068900
4173        12      127E  AC60              CLAD        6,0                                       % 068910
4174        22      127F  D710              PRN         1                                         % 068920
                                *                                      "CONVERT LONGITUDE FOR DISPLAY *I068930
4175        598     1280  0C02              GEN         LONGITUDE_DISPLAY  "AND SET UP LEGEND     DP068940
4176        606     1281  C016              FET         1,6                                       % 068950
                                *                                      "CONVERT LATITUDE FOR DISPLAY *I068960
4177        1182    1282  0C01              GEN         LATITUDE_DISPLAY  "AND SET UP LEGEND      DP068970
4178        1190    1283  D5F0              BBK         15             "RETURN TO MAIN DISPLAY ROUTINE DP068980
4179                1273              PLOT2       EQU         POP1$118                          PT068990
4180                1276              PLOT5       EQU         POP1$119                          PT069000
                                *                                                                   069010
4181        14R     1284  F80C002E  STATUS_FAIL FETD        0,,TEST_FAIL_TEMP                      069020
4182        16      1286  A421              CLA         2,1                                       069030
4183        26      1287  F8050080          RSLD        0,,8                                      069040
4184        32      1289  F0150080          RSL         1,,8                                      069050
4185        36      128B  F4240100          LSA         2,,8                                      069060
4186        38      128D  8402              ADD         0,2                                       069070
4187        52      128E  FC070008          PTRD        0,,C_I_UPPER_LEFT_KEYBOARD_LAMPS          069080
4188        62      1290  8420              FETM        2,,0                                      069090
4189        70      1291  92EB  (00EB)      SUBD        0,,=DX(1)                                 069100
4190        74      1292  D20C  (129F)      BUC         BLANKS_GEN                                069110
```

```
                                **                                                                  DP069120
                                * ENTER HERE FOR STATUS DISPLAY                                     *H069130
4191      2R    1293  9021      POP2        SUBM    2,1       "TEST ARGWORD2                       069140
4192       6    1294  D951 (1284)           BRL     STATUS_FAIL                                    069150
4193      2R    1295  9823                   COMM    2,3                                            069160
4194       8    1296  040312E0               BRG     STATUS_CCOH                                    069170
4195     30R    1298  F05C1ED3               FET     5,,Q_STORAGE  "READ DATA FOR SYNC PERCENT       069180
                                *                                  "COMPLETION DISPLAY              DP069190
4196      36    129A  9E1A (009A)            CLA     0,,CALIBRATE_COMPUTED_MARKER                   DP069200
                                *                                  "IS THE SYNC                     *1069210
4197      40    129B  D164 (12B0)           BRE     $4            "PROCESS GOING ON NOW?           DP069220
                                * BURST DISPLAY                                                     *H069230
4198      2R    129C  A447                   CLA     4,7           "CONVERT FREQ NUMBER IN ARG1 TO  DP069240
4199       6    129D  4448                   MPIM    4,,8          "INDEX FOR READING THE 8 Q BURSTSDP069250
4200       8    129E  A454                   CLA     5,4           "FOR 1 FREQUENCY                 DP069260
4201      10    129F  9457                   ADDM    5,,7          "CLEAR DOUBLE REGISTER FOR DIGITSDP069270
4202      14    12A0  B822                   SUBD    2,2                                            DP069280
4203      8R    12A1  F54A1ED3      $3       CLA     X4,,Q_STORAGE "READ 1 Q BURST SCALED BI        DP069290
4204      12    12A3  4402                   LSA     0,,1                                           DP069300
4205      16    12A4  D022 (12A7)            BGE     $1            "IS THIS Q GREATER THAN 1?       %R069310
4206      2R    12A5  9C09                   CLAM    0,,9          "SET DISPLAY DIGIT TO A 9 WHICH  DP069320
4207       6    12A6  D002 (12A9)            BUC     $2            "IS THE MAXIMUM DISPLAY          DP069330
4208    446R    12A7  1000       $1        SQRT    0             "FORM 9 * Q**.5 AT B15           DP069340
                                *                                  "   THIS WILL GIVE A NUMBER FROM DP069350
                                *                                  "   0 TO 8 IN THE LSB'S OF THE   DP069360
                                *                                  "   WORD WHICH IS ALMOST          DP069370
                                *                                  "   EQUAL TO THE TENTH'S PLACE   DP069380
4209     452    12A8  5009                   MPLM    0,,9          "   OF Q**.5                     DP069390
4210      6R    12A9  FC240010     $2        LSAD    2,,4          "SHIFT DISPLAY OVER 1 DIGIT      DP069400
4211       8    12AB  B430                   ADD     3,0           "ADD IN THE NEXT DIGIT           DP069410
                                *                                  "ARE THERE MORE                  *1069420
4212      16    12AC  C44C (12A1)            BXU     4,,$3         "Q'S FOR THIS FREQUENCY?"        DP069430
4213      2R    12AD  A402                   CLA     0,2           "SET UP THE 8 DIGITS TO DISPLAY  DP069440
                                *                                  "IN THE 4 LEFT DIGITS OF EACH    DP069450
                                *                                  "REGISTER                        DP069460
4214       4    12AE  8C11                   CLSM    1,,1          "BLANK THE REMAINING DIGITS OF   DP069470
4215       8    12AF  D008 (12B8)            BUC     $10           "THE LEFT DISPLAY REGISTER       DP069480
4216      4R    12B0  AC04       $4        CLAD    0,4           "DURING SYNC Q STORAGE + 2       DP069490
                                *                                  "CONTAINS DELTA C - CD WHERE     DP069500
                                *                                  "DELTA C = C(LARGEST) - C(2ND    DP069510
                                *                                  "LARGEST) WITH THE 2 C'S NOT     DP069520
                                *                                  "ADJACENT.  Q STORAGE + 4 CON-   DP069530
                                *                                  "TAINS CD                        DP069540
```

```
                                                                                                                    "                                                                   DP069550
4217        8       12B1  8C02                                    ADDD        0,2                                   "FORM DELTA C                                                       DP069560
                                                                                                                    "IS THE 1ST SYNC                                                    *2069570
4218        12      12B2  D061    (12B4)                          BRE         $20                                   "10 SEC PERIOD COMPETE YET?                                         %R069580
                                                                                                                    "(DELTA C NOT 0)                                                    DP069590
4219        126R    12B3  DC04                                    DIVD        0,4                                   "COMPUTE DELTA C / CD                                               DP069600
                                                                                                                    "WHICH EQUALS PERCENTAGE / 100                                      DP069610
4220        10R     12B4  480A                    $20             MPYDM       0,,10                                 "FORM PERCENTAGE * 10/2**15 TO                                      DP069620
                                                                                                                    "GIVE THE TENS DIGIT IN THE LOW                                     DP069630
                                                                                                                    "BITS OF THE LEFT HALF OF A 32                                      DP069640
                                                                                                                    "BIT REGISTER                                                       DP069650
                                                                                                                    "                                                                   DP069660
4221        16      12B5  F0155000                                MPLM        1,,X(5000)                            "FORM REMAINDER * 10/2**4 (IGNOREDP069670
                                                                                                                    "THE SIGN BIT IN THIS OPERATION)                                    DP069680
                                                                                                                    "TO GIVE THE ONES DIGIT IN THE                                      DP069690
                                                                                                                    "MSB'S OF THE RIGHT HALF OF THE                                     DP069700
                                                                                                                    "32 BIT REGISTER                                                    DP069710
                                                                                                                    "                                                                   DP069720
4222        26      12B7  F8040800                                RSAD        0,,4                                  "SHIFT THE DOUBLE REGISTER RIGHT                                    DP069730
                                                                                                                    "ONE CHARACTER TO ALIGN THE                                         DP069740
                                                                                                                    "DIGITS WITH THE 2 LOW DIGITS OF                                    DP069750
                                                                                                                    "THE LEFT DISPLAY REGISTER                                          DP069760
                                                                                                                    "                                                                   DP069770
4223        28      12B9  8C01                                    CLSM        0,,1                                  "BLANK THE 4 HIGH CHARACTERS OF                                     DP069780
4224        30      12BA  8C31                                    CLSM        3,,1                                  "THE LEFT AND RIGHT DISPLAYS                                        DP069790
4225        2R      12B8  8C41                    $10             CLSM        4,,1                                  "BLANK THE 2 LOW DIGITS IN THE                                      DP069800
4226        4       12BC  B055                                    SUB         5,5                                   "RIGHT DISPLAY                                                      DP069810
4227        6       12BD  B022                                    SUB         2,2                                   "CLEAR BOTH LEGENDS                                                 DP069820
                                                                                                                    "                                                                   DP069830
4228        14      12BE  D5F0                                    BBK         15                                    "RETURN TO MAIN DISPLAY ROUTINE                                     DP069840
                                                                                                                                BLANKS                                                  *H069850
                                                                                                                                                                                        *H069860
                                                                                                                                                                                        *H069870
                                                                                                                                                                                        *H069880
4229        10R     12BF  8420                    BLANKS_GEN      FETM        2,,0                                  "CREATE 3 REGISTERS FOR THE                                         DP069890
                                                                                                                    "DISPLAY                                                            DP069900
4230        18      12C0  92E8    (00E8)                          SUBD        0,,=01                                "ZERO THE LEGEND                                                    DP069910
4231        26      12C1  D5F0                                    BBK         15                                    "BLANK THE DISPLAY REGISTER                                         DP069920
                                                                                                                                                                                        *H069930
4232        14R     12C2  F80C1F96                POP4            FETD        0,,SAVE_POSITION_VARIANCES                                                                            DP069940
4233        24      12C4  FC081F98                                ADDD        0,,SAVE_POSITION_VARIANCES+2                                                                          DP069950
4234        470     12C6  1000                                    SQRT        0                                     "COMPUTE (P11 + P22)**.5                                            DP069960
                                                                                                                    "CONVERT POS VAR FOR DISPLAY                                        *I069970
```

```
4235    1046        12C7  0C07                    GEN       SIG_DISPLAY   "IN NAUTICAL MILES                DP069980
                                                  *                       "BLANK THE LEFT DISPLAY           DP069990
4236    1050        12C8  D80A   (128F)           BUC       BLANKS_GEN    "RETURN TO MAIN DISPLAY ROUTINE   DP070000
                                                  * ENTER HERE FOR RANGE AND BEARING                      *H070010
                                                  * RANGE START POINT IS IN ARG1                          *H070020
                                                  * RANGE END POINT IS IN ARG2                            *H070030
                                                  *                       "COMPUTE AND CONVERT BEARING      *I070040
4237     8R *       12C9  F80D1483                POP6      BSV       MAKE_RANGE_AND_BEARING  "COMPUTE RANGE" DP070050
4238    584         12CB  0C04                    GEN       RANGE_DISPLAY  "CONVERT RANGE FOR DISPLAY        DP070060
4239    590         12CC  040014A1                BUC       SWAP          "INTERCHANGE LEFT & RIGHT           070070
                                                  * ENTER HERE FOR ETE - CSE                              *H070080
4240     2R         12CE  A421                    POP7      CLA       2,1           "MOVE ARG1 TO ARG2 AND SET CRAFT DP070090
                                                  *                       "IN ARG1 TO GET RANGE AND BEARINGDP070100
                                                  *                       "FROM CRAFT TO SELECTED           DP070110
4241     4          12CF  9C18                    CLAM      1,,11         "DESTINATION                        070120
                                                  *                       "COMPUTE AND CONVERT BEARING      *I070130
4242    12 *        12D0  F80D1483                BSV       MAKE_RANGE_AND_BEARING  "COMPUTE RANGE"       DP070140
4243    26          12D2  F80C1F4E                FETD      0,,VC2_STAR                                   $ 070150
                                                  *                       "COMPUTE CRAFT SPEED FROM         *I070160
4244    34 *        12D4  F80D1751                BSV       MAKE_VELOCITY  "VC2 AND VC3"                  DP070170
4245    54          12D6  F8261AD2                MPYD      2,,=DF(.004459345) "DIVIDE RANGE BY 100 HOURS (MDP070180
                                                  *                       "IMUM DISPLAY) TO GET MINIMUM     DP070190
4246    58          12D8  8820                    COMD      2,0           "ACCEPTABLE VELOCITY              DP070200
4247    62          12D9  D051   (1208)           BRL       $1            "IS THE VELOCITY HIGH ENOUGH?     DP070210
4248     4R         12DA  AC20                    CLAD      2,0           "TOO SLOW"                        DP070220
                                                  *                       "SET RANGE = VEL TO GET 100 HR    DP070230
4249    126R        12DB  0C20                    $1        DIVD      2,0           "COMPUTE TIME TO GO       DP070240
4250    136         12DC  D710                    PRN       1             "= RANGE / VELOCITY               DP070250
4251    576R        12DD  0C06                    $3        GEN       ETE_DISPLAY   "CONVERT ETE FOR DISPLAY   DP070260
4252    582         12DE  040014A1                BUC       SWAP          "EXCHANGE                           070270
```

```
                                **                                                                  DP070280
                                * ENTER HERE FOR COHERENCY                                         *H070290
4253      2R    12E0 DE01       STATUS_COOH FLG     B              SET FLAG B                       070300
4254      6     12E1 D001 (12E3)            BUC     POP8$53                                         070310
4255      2R    12E2 DEAD       POP8        FLG     BT+EOR+8       RESET FLAG B                     070320
4256      6R    12E3 9E4C (00CC) $53        CLA     0,,BASE+1      "READ BASE STATION NUMBER        070330
                                *                                  "IS THIS PHASE                   *1070340
4257      10    12E4 D0D3 (12E8)            BCF     $10            "DIFFERENCE NAVIGATION?"         $R070350
4258      2R    12E5 8001                   COM     0,1            "SUB ALWAYS PHASE DIFFERENCE     DP070360
                                *                                  "IS THE SELECTED                 *1070370
4259      8     12E6 04061369               BRE     $20            "STATION (ARG1) THE BASE STATION?DP070380
4260      6R    12E8 4C03       $10         MPIDM   0,,3           "COMPUTE POINTERS TO PHI ESTIMATEDP070390
4261      10    12E9 AC20                   CLAD    2,0            "AND THETA 3 (STA AND BASE)      DP070400
4262      12    12EA B411                   ADD     1,1                                             DP070410
4263      16    12EB F4191EA3               ADDM    1,,PHI_ESTIMATE                                 DP070420
4264      20    12ED F4291CB9               ADDM    2,,PP_THETA3   "                                DP070430
4265      24    12EF F4391CB9               ADDM    3,,PP_THETA3   "SET UP COUNTER TO CYCLE THE 3   DP070440
4266      40    12F1 8454                   FETM    5,,4           "FREQ AND CREATE 14 SCRATCH      DP070450
4267      42    12F2 90FE                   SUBM    15,,14         "WORDS IN R15 STACK              DP070460
4268      50    12F3 F43A1C2A               CLA     3,,X+3                   CALCULATE UPDATED       070470
4269      56    12F5 F0340118               MPYM    3,,F(3.814/441.17643)    OSCILLATOR START        070480
4270      64    12F7 F4361C85               MPI     3,,STATION_COUNTER       TIME FOR USE IF NOT     070490
4271      72    12F9 F43B1C29               ADD     3,,X+2                   PHASE DIFF NAVIGATION   070500
4272      6R    12FB A209       $1          CLS     I0,9           -THETA 3 (STATION)               070510
                                *                                  "IS THIS PHASE                   *1070520
4273      10    12FC D0DA (1307)            BCF     $5             "DIFFERENCE NAVIGATION?"         $R070530
4274      10R   12FD F00C1F41               FET     0,,ARGWORD1    "SUB ALWAYS PHASE DIFFERENCE     DP070540
4275      16    12FF C005                   FET     0,5            FREQ                             DP070550
                                *                                  "COMPUTE PHASE CORRECTION FOR    *I070560
4276      24  * 1300 F80D0C05               BSV     D_PHI_KI       "TIME DIFFERENCE BETWEEN BASE/STADP070570
4277      30    1302 FC040020               LSAD    0,,5           "RESCALE TO 85                   070580
4278      32    1304 B020                   SUB     2,0            "APPLY CORR TO -THETA 3          070590
4279      42    1305 D710                   PRN     1                                               DP070600
4280      48    1306 B608                   ADD     I0,8           "ADD THETA 3 BASE                070610
4281      4R    1307 D086 (130E) $5         BBF     $52                                             070620
4282      4R    1308 D0C5 (130E)            BCT     $52                                             070630
4283      2R    1309 A420                   CLA     2,0            "CORRECT FOR TO IF NOT           070640
4284      10    130A F14A1722               CLS     X4,,V_LAMBDA   "PHASE DIFF                      070650
4285      16    130C 6003                   MPY     0,3                                             070660
4286      18    130D B402                   ADD     0,2                                             070670
4287      10R   130E F8040400       $52       RSAD    0,5                                             070680
4288      18    1310 8F47                   ADDD    IX4,7          "ADD PHI ESTIMATE FROM           070690
                                *                                  "THE TRACKING FILTER             070700
```

```
4289   24        1311  FC040800                LSAD   0,,11          "DISCARD LANE COUNT                 070710
4290   32        1313  734F                    STA    IX4,15         "SAVE IN SCRATCH STORAGE            DP070720
4291   34        1314  9481                    ADDM   8,,1                                               DP070730
4292   36        1315  9491                    ADDM   9,,1                                               DP070740
                       *                                             "ARE THERE MORE                     *1070750
4293   44        1316  CD4C   (12F8)           BXUD   4,,$1          "FREQUENCIES TO PROCESS?            DP070760
4294    8R       1317  ADF0                    CLAD   X15,,0         "SET UP ANGLES IN STORAGE IN        DP070770
4295   18        1318  79F6                    STAD   X15,,6         "ORDER OF DISPLAY  EACH WILL BE     DP070780
4296   20        1319  94F2                    ADDM   15,,2          "DISPLAYED IN 2 DIGITS ON PANEL     DP070790
4297   24        131A  D381   (134C)           BBF    $6                                                 070800
4298    8R       1318  F49A1F41                CLA    9,,ARGWORD1    STATION NUMBER                      070810
4299   16        131D  F48A00CC                CLA    8,,BASE+1                                         070820
4300   18        131F  A409                    CLA    0,9                                               070830
4301   22        1320  FC191F55                CLAM   1,,RIJ_STAR                                       070840
4302   30   *    1322  F80D0862                BSV    COMPUTE_THETA1                                    070850
4303   34        1324  AC20                    CLAD   2,0            SAVE THETA1 STATION                 070860
4304   38        1325  D0D6   (132C)           BCF    $7             "SUB ALWAYS PHASE DIFF              070870
4305    2R       1326  A408                    CLA    0,8            BASE                                070880
4306    6        1327  FC191F55                CLAM   1,,RIJ_STAR                                       070890
4307   14   *    1329  F80D0862                BSV    COMPUTE_THETA1                                    070900
4308   18        1328  8820                    SUBD   2,0            THETA1  STATION - BASE              070910
4309    4R       132C  AC02          $7        CLAD   0,2            GET THETA                           070920
4310   24        132D  F9461682                MPYD   X4,,LAMBDA_TABLE                                  070930
4311   44        132F  F8061AC4                MPYD   0,,=DF(3.14159265B-2)                            070940
4312   48        1331  BC00                    ADDD   0,0                                               070950
4313   62        1332  F99C1D0F                FETD   X9,,PP_THETA2                                     070960
4314   66        1334  D0D2   (1337)           BCF    $71                                               070970
4315    8R       1335  F1A81D0F                SUB    X10,,PP_THETA2                                    070980
4316   10R       1337  F1661768        $71     MPY    X6,,TF_LAMBDA_CONSTANT_TABLE                      070990
4317   20        1339  F8040400                RSAD   0,,5                                              071000
4318   24        133B  BC02                    ADDD   0,2            R0 = CHART VALUE                    071010
4319   30        133C  FC040800                LSAD   0,,11          REMOVE LANE COUNT                   071020
4320   32        133E  9468                    ADDM   6,,8           INCREASE STACK POINTER              071030
4321   42        133F  786F                    STAD   IX6,15                                             071040
4322   44        1340  9068                    SUBM   6,,8                                               071050
4323   54        1341  D710                    PRN    1                                                  071060
4324   62        1342  CD47   (132C)           BXUD   4,,$7                                              071070
4325    8R       1343  ADF6                    CLAD   X15,,6         10.2                                071080
4326   12        1344  AC60                    CLAD   6,0            SAVE 10.2                           071090
4327   20        1345  ADF8                    CLAD   X15,,8         13.6                                071100
4328   30        1346  79F6                    STAD   X15,,6         13 IN FIRST SLOT FROM RIGHT         071110
4329   38        1347  ADFA                    CLAD   X15,,10              ON DISPLAY                    071120
4330   48        1348  79F8                    STAD   X15,,8         11 IN SECOND                        071130
```

```
4331      52        1349  AC06                    CLAD    0,6                                    071140
4332      62        134A  79FA                    STAD    X15,,10     10 IN THIRD                071150
4333      66        134B  D009   (1355)           BUC     $2-1                                   071160
4334       8R       134C  ADF0             $6     CLAD    X15,,0                                 071170
4335      16        134D  B9F4                    SUBD    X15,,4      "REGISTERS                 DP071180
4336      26        134E  79F6                    STAD    X15,,6      "ORDER =  13.6, 11.3, 10.2,DP071190
4337      34        134F  ADF0                    CLAD    X15,,0      "13.6 - 10.2, 13.6 - 11.3, DP071200
4338      42        1350  B9F2                    SUBD    X15,,2      "11.3 - 10.2               DP071210
4339      52        1351  79F8                    STAD    X15,,8      "                          DP071220
4340      60        1352  ADF2                    CLAD    X15,,2      "SET UP COUNTER TO CYCLE THE DP071230
4341      68        1353  B9F4                    SUBD    X15,,4      "6 DISPLAYS                DP071240
4342      78        1354  79FA                    STAD    X15,,10     "RELEASE 2 OF THE SCRATCH WORDS DP071250
4343      80        1355  9C5A                    CLAM    5,,10                                  DP071260
4344       6R       1356  A74F             $2     CLA     IX4,15      "READ WORD INTO UPPER HALF OF A DP071270
4345       8        1357  9C10                    CLAM    1,,0        "32 BIT REGISTER           DP071280
4346      16        1358  5C0A                    MIEDM   0,,10       "MULTIPLY END AROUND BY 10 TO GETDP071290
4347      22        1359  5005                    MPLM    0,,5        "TENTHS OF CYCLE IN LSB'S OF DP071300
4348      28        135A  FC041000                LSAD    0,,12       "SECOND HALF OF WORD       DP071310
                                                *                     "MULTIPLY FIRST HALF BY 10/2**16 DP071320
                                                *                     "TO GET THE HUNDREDTHS DIGIT IN DP071330
                                                *                     "THE LSB'S OF THE FIRST HALF DP071340
                                                *                     "SHIFT BOTH DIGITS LEFT TO THE DP071350
                                                *                     "MSB'S                     DP071360
4349      38        135C  784F                    STAD    IX4,15      "SAVE IN SCRATCH WORD      DP071370
                                                *                     "ARE THERE MORE            *1071380
4350      46        135D  CC48   (1356)           BXUD    4,,$2       "WORDS TO CONVERT?"        DP071390
4351       2R       135E  9C65                    CLAM    6,,5        "SET UP 6 COUNTER TO PACK THE 6 DP071400
4352       4        135F  9C50                    CLAM    5,,0        "DIGITS OF ONE DISPLAY REGISTER DP071410
                                                *                     "PACK DIGITS OF 1ST 3 WORDS FOR *I071420
4353      12  *     1360  F80D1364                BSV     $3          "THE LEFT DISPLAY REGISTER DP071430
4354      16        1362  AC30                    CLAD    3,0         "MOVE DATA FROM LEFT DISPLAY TO DP071440
4355      18        1363  9C20                    CLAM    2,,0        "THE RIGHT DISPLAY         DP071450
4356      10R       1364  F8050800         $3     RSLD    0,,4        "SHIFT DOUBLE WORD RIGHT 1 DIGIT DP071460
4357      16        1366  875F                    ADD     IX5,15      "ADD 1 DIGIT TO THE DISPLAY FROM DP071470
                                                *                     "SCRATCH STORAGE           DP071480
                                                *                     "ARE THERE MORE            *1071490
4358      24        1367  C454   (1364)           BXU     5,,$3       "DIGITS TO ADD TO THE DISPLAY DP071500
                                                *                     "RETURN AND RELEASE 6 SCRATCH DP071510
                                                *                     "AFTER SECOND ENTRY ALL DATA IS DP071520
                                                *                     "SET UP FOR DISPLAY AND THE DP071530
                                                *                     "RETURN GOES TO MAIN DISPLAY DP071540
4359       8R       1368  D5F6                    88K     15,6        "ROUTINE                   DP071550
                                                * BASE STATION TRACKING FILTER DISPLAY          *H071560
```

```
4360        4R      1369  4406          $20       MPIM    0,,6                "COMPUTE POINTER TO PHI ESTIMATE DP071570
4361        8       136A  F4091EA3                ADDM    0,,PHI_ESTIMATE "CREATE REGISTERS FOR LEFT/RIGHTDP071580
4362       24       136C  8450                     FETM    5,,0                "DISPLAY AND LEGENDS             DP071590
4363       32       136D  8414                     FETM    1,,4                "SET UP A 3 COUNTER FOR 3 FREQ   DP071600
4364       12R      136E  CB08          $22       FETD    IX0,8               "READ PHI ESTIMATE               DP071610
                                        *                                     "CONVERT AND POSITION 4 DIGITS   *I071620
4365       20  *    136F  F80D1373                BSV     $21                 "FOR DISPLAY AS FUNCTION OF FREQ DP071630
                                        *                                     "ARE THERE MORE                  *I071640
4366       28       1371  CC04   (136E)           BXUO    0,,$22              "FREQUENCIES TO PROCESS?"        DP071650
4367       14R      1372  D510                     BBK     1                   "RETURN TO MAIN DISPLAY ROUTINE  DP071660
                                        * SCALE PHI IN CYCLES/10 SEC AND                                      *H071670
                                        * DISPLAY 4 DIGITS TO RIGHT OF                                        *H071680
                                        * DECIMAL.  THE 12 DIGITS ON THE                                      *H071690
                                        * DISPLAY WILL READ 10.2, 13.6                                        *H071700
                                        * AND 11.3 FROM LEFT TO RIGHT                                        *H071710
4368        6R      1373  FC040400      $21       LSAD    0,,10               "DELETE LANE COUNT               DP071720
                                        *                                     "SCALE CYCLES / 10 SECONDS       DP071730
4369       10       1375  D021   (1377)           BGE     $23                 "IS THE RESULT NEGATIVE          %R071740
4370        6R      1376  9664   (00E4)           ADD     0,,HX8000           "ADD 1 CYCLE TO FORCE POSITIVE   DP071750
4371      576R      1377  0C08          $23       GEN     BASE_DISPLAY        "CONVERT FOR DISPLAY (4 DIGITS)  DP071760
4372      578       1378  9832                     COMM    3,,2                                                 % 071770
4373      582       1379  D024   (137E)           BGE     $24                 "IS THIS 10.2?"                  %R071780
4374        6R      137A  FC040100                 LSAD    0,,8                "SHIFT DISPLAY OVER 2 DIGITS AND DP071790
4375        8       137C  A450                     CLA     5,0                 "PLACE IN LEFT 4 DIGITS OF LEFT  DP071800
4376       24       137D  D520                     BBK     2                   "DISPLAY                         DP071810
4377        4R      137E  D035   (1384)  $24       BRG     $25                 "IS THIS 13.6?"                  %R071820
4378        4R      137F  F4040100                 LSA     0,,8                "MOVE 2 HIGH ORDER DIGITS TO LOW DP071830
4379        6       1381  8481                     ADD     8,1                 "DIGITS OF LEFT DISPLAY AND 2 LOWDP071840
4380        8       1382  8460                     ADD     6,0                 "ORDER DIGITS TO THE 2 HIGH ORDERDP071850
4381       24       1383  D520                     BBK     2                   "DIGITS OF THE RIGHT DISPLAY     DP071860
4382        4R      1384  BC80          $25       ADDD    8,0                 "11.3"                           DP071870
                                        *                                     "PLACE THE 4 DIGITS INTO THE 4   DP071880
4383       20       1385  D520                     BBK     2                   "LOW DIGITS OF THE RIGHT DISPLAY DP071890
```

```
                                **                                                                  DP071900
                                * ENTER HERE FOR D-GMT DISPLAY                                      #H071910
4384   16R   1386  8450          POP9      FETM    5,,0                                           DP071920
4385   26    1387  FC6A00E7                CLAD    6,,=DF((((5D-3831)/24)/3600)/1811)               071930
4386   36    1389  FC8A00C4                CLAD    8,,DAY_SINCE_JAN1_1972                           071940
4387   10R   138B  FC1A1F4C    $9           CLAD    1,,TIME_STAR                                   DP071950
4388   26    138D  6816                    MPYD    1,6             CONVERT TO DAYS                DP071960
4389   30    138E  BC18                    ADDD    1,8                                            DP071970
4390   40    138F  FC1B1A92                ADDD    1,,=DF((.5)/86400811) ROUND DISPLAY TO NEAREST S  071980
4391   42    1391  A461                    CLA     6,1             SAVE FOR DATE DISPLAY          DP071990
4392   48    1392  F0650800                RSL     6,,4            RESCALE DAYS TO B15            HH072000
4393   56    1394  E411177D                EXT     1,1,HX000F      REMOVE INTEGER PART              072010
4394   62    1396  4C13                    MPIDM   1,,3            CONVERT TO HOURS AT B15          072020
4395   72    1397  F8154000                RSLD    1,,1                                             072030
4396   80 *  1399  F80D13D2                BSV     $7              MAKE TWO BCD                   DP072040
4397    6R   1398  FC14003C    $8          MPIDM   1,,60                                          DP072050
4398   14 *  139D  F80D13D2                BSV     $7              MINUTES                        DP072060
4399   20    139F  FC14003C                MPIDM   1,,60                                          DP072070
4400   28 *  13A1  F80D13D2                BSV     $7              SECONDS                        DP072080
                                *    PROCESS DATE                                                  DP072090
4401   30    13A3  DEEF                    FLG     DT+EOR+D        RESET FLG D                      072100
4402   46    13A4  F448016D                FETM    4,,365                                           072110
4403   48    13A6  9C13                    CLAM    1,,3                                             072120
4404   50    13A7  A428                    CLA     2,11            DAYS SINCE TO R2                 072130
4405   52    13A8  8024                    COM     2,4                                              072140
4406   56    13A9  D048   (13B2)          BLE     $2              LESS THAN 365                    072150
4407    4R   13AA  D004   (13AF)          BUC     $11                                              072160
4408    2R   13AB  8024              $10   SUB     2,4                                              072170
4409    4    13AC  9431                    ADDM    3,,1                                             072180
4410    6    13AD  8024                    COM     2,4                                              072190
4411   10    13AE  D043   (13B2)          BLE     $2                                               072200
4412   8R    13AF  C405   (13AB)    $11   BXU     0,,$10                                           072210
4413   2R    13B0  9021                    SUBM    2,,1            SUB 1 IF LEAP YEAR PASSED OVER   072220
4414   6     13B1  D807   (13AB)          BUC     $10                                              072230
4415   2R    13B2  9800                $2  COMM    0,,0                                             072240
4416   6     13B3  D016   (13BA)          BNE     $3                                               072250
4417   4R    13B4  F8290038              COMM    2,,59                                            072260
4418   8     13B6  D033   (13BA)          BRG     $3                                               072270
4419   2R    13B7  DE63                    FLG     E+D                                              072280
4420   6     13B8  D061   (13BA)          BRE     $3                                               072290
4421   2R    13B9  9421                    ADDM    2,,1                                             072300
4422   10R   13BA  D710                $3  PRN     1                                                072310
4423   14    13BB  F4190048              ADDM    1,,72                                            072320
```

```
4424    22  *   13BD  F80D13D2              BSV     $7              YEAR                        DP072330
4425    24      13BF  9C11                  CLAM    1,,1            INDEX FOR MONTH SEARCH      DP072340
4426     8R     13C0  F11816C1        $4    COM     X1,,DAYS_BY_MONTH                           DP072350
4427    12      13C2  D041   (13C4)        BLE     $5                                          DP072360
4428     8R     13C3  C414   (13C0)        BXU     1,,$4           COUNT THE MONTHS            DP072370
4429     8R     13C4  F11B16C0        $5    SUB     X1,,DAYS_BY_MONTH-1                         DP072380
4430    16  *   13C6  F80D13D2              BSV     $7              MONTH                       DP072390
4431    18      13C8  A410                  CLA     1,0             DAY OF MONTH                DP072400
4432    22      13C9  D0F1   (13CB)        BDF     $1              SKIP UNLESS D               DP072410
4433     2R     13CA  9411                  ADDM    1,,1            MAKE FEB 29 IF LEAP YEAR     072420
4434     8R  *   13CB  F80D13D2        $1    BSV     $7              DAY                         DP072430
4435    10      13CD  9C50                  CLAM    5,,0            CLEAR RIGHT LEGEND          DP072440
4436    26      13CE  D520                  BBK     2                                           DP072450
                                      *  MAKE R1 INTO 2 BCD CHARACTERS, SHIFTED INTO R3,4, LEAVING R1=0  DP072460
4437     2R     13CF  901A            $6    SUBM    1,,10           DIVIDE BY 10 LOOP           DP072470
4438     6      13D0  F4490010              ADDM    4,,16                                       DP072480
4439     2R     13D2  981A            $7    COMM    1,,10           (ENTRY POINT)               DP072490
4440     6      13D3  D825   (13CF)        BGE     $6                                          DP072500
4441     2R     13D4  8441                  ADD     4,1             REMAINDER                   DP072510
4442     4      13D5  9C10                  CLAM    1,,0            CLEAN UP                    DP072520
4443    10      13D6  FC340100              LSAD    3,,8                                        DP072530
4444    18      13D8  D5F0                  BBK     15                                          DP072540
```

```
                                **                                                                          DP072550
                                * ENTER HERE FOR LOP                                                       #H072560
4445        2R      13D9 B411   POP5        ADD         1,1          "SAVE FREQUENCY IDENTIFIER          DP072570
4446        12      13DA F0171F3C           STA         1,,PHI_OFFSET "  FROM ARG1                       DP072580
                                *                                    "COMPUTE LOP FOR RIGHT STATION      #I072590
4447        20  *   13DC F80D13E9           BSV         PROCESS_RIGHT_PAIR  "PAIR"                      DP072600
                                *                                    "ADD 900 LANE OFFSET AND CONVERT    #I072610
4448        28  *   13DE F80D13E2           BSV         $1           "FOR DISPLAY                        DP072620
                                *                                    "COMPUTE LOP FOR LEFT STATION       #I072630
4449        36  *   13E0 F80D13EC           BSV         PROCESS_LEFT_PAIR  "PAIR"                       DP072640
                                * ENTER HERE AS SUBROUTINE TO                                            #H072650
                                * CONVERT RIGHT DISPLAY.                                                 #H072660
                                * FALL INTO ROUTINE TO CONVERT                                           #H072670
                                * LEFT DISPLAY AND EXIT                                                  #H072680
4450       10R      13E2 F8044000 $1        RSAD        0,,1         "RESCALE LOP TO CYCLES B11 AND      DP072690
4451        14      13E4 F4093840           ADDM        0,,F(9008-11) "ADD 900 CYCLE OFFSET             DP072700
4452       590      13E6 0C03               GEN         LOP_DISPLAY  "CONVERT LOP FOR DISPLAY           DP072710
                                *                                    "MOVE DATA INTO PROPER REGISTERS     072720
                                *                                    "FOR DISPLAY                        DP072730
                                *                                    "ADD DOT TO LEGEND                  DP072740
                                *                                    "EXIT"                              DP072750
4453       594      13E7 AC40               CLAD        4,0          "1ST TIME RETURNS TO LOP DISPLAY    DP072760
4454       612      13E8 D530               BBK         3            "2ND TIME RETURNS TO MAIN DISPLAY   DP072770
                                *                          COMPUTE LOP                                   #H072780
                                *                                                                        #H072790
                                * THIS ROUTINE WILL COMPUTE THE LOP FOR THE STATION PAIR DISPLAYED IN     #H072800
                                * THE LEFT OR RIGHT LEGEND                                               #H072810
                                *                                                                        #H072820
                                * ENTER HERE FOR RIGHT DISPLAY                                           #H072830
4455                            PROCESS_RIGHT_PAIR;                                                      DP072840
4455       10R      13E9 F00C0008           FET         0,,C_I_RIGHT_DISPLAY_LEGEND_AND_PUNCTUATION     DP072850
4456        14      13EB D002   (13EE)      BUC         ALLSTATIONS  "READ RIGHT LEGEND                  DP072860
                                * ENTER HERE FOR LEFT DISPLAY                                           #H072870
4457                            PROCESS_LEFT_PAIR;                                                       DP072880
4457       10R      13EC F00C0007           FET         0,,C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION      DP072890
                                *                                    "READ LEFT LEGEND                   DP072900
4458        4R      13EE F0090041 ALLSTATIONS SUBM      0,,X(0041)   ADJUST ASCII FOR INDEXING            072910
4459        12      13F0 C010               FET         1,0          P,P,P                               072920
4460        22      13F1 EC00177C           EXTD        0,0,HD03C0   N1,N2,P   N1=0-7X2**6  N2=0-7       072930
4461        28      13F3 F0050200           RSL         0,,6                      MOVE N1 INTO          072940
4462        30      13F5 A420               CLA         2,0          N1,N2,P  DISPLAY POSITION           072950
4463        40      13F6 C021               FET         2,1          N2,N1,N2,N1,N2,P                    072960
4464        42      13F7 8001               COM         0,1          FIND LARGEST STATION NUMBER         072970
```

```
4465   46        13F8  D032   (13F8)          BRG    $4          ORDER IS OK                              072980
4466    4R       13F9  AC30                   CLAD   3,0         N2,N1,N2,N2,N1,P                         072990
4467    8        13FA  AC13                   CLAD   1,3         N2,N2,N1,N2,N1,P                         073000
4468    4R       13FB  F4040040        $4      LSA    0,,6                                                 073010
4469    6        13FD  8450                   ADD    5,0         TOGGLE DISPLAY                           073020
4470   10        13FE  F4594861               ADDM   5,,X(4861)  ADD LEGEND AND FORCE TO ASCII            073030
4471   14        1400  BC11                   ADDD   1,1                                                  DP073040
4472   20        1401  4C13                   MPIDM  1,,3        -,6N1,6N2,N1,N2,P                        DP073050
4473   28        1402  F40A1F3C               CLA    0,,PHI_OFFSET "                                     DP073060
4474   30        1404  8410                   ADD    1,0         "USE STATION NUMBERS AND FREQ TO         DP073070
4475   32        1405  8420                   ADD    2,0         "COMPUTE POINTERS TO PHI ESTIMATED       DP073080
                                        *                        "IS THIS PHASE                           *1073090
4476   36        1406  D1D4   (1418)          BCF    $10         "DIFFERENCE NAVIGATION?"                 %R073100
4477    2R       1407  DEAD                   FLG    8T+EOR+B    "SUB ALWAYS PHASE DIFFERENCE             DP073110
                                        *                        "                                        DP073120
4478   10        1408  F03800CC               COM    3,,BASE+1   "RESET PROGRAM FLAG 8                    DP073130
                                        *                        "IS THE FIRST                            *1073140
4479   14        140A  D013   (140E)          BNE    $1          "STATION THE BASE STATION?               %R073150
4480    2R       140B  A414                   CLA    1,4         STA 2 INDEX (TF POINTER IN R2)           DP073160
                                        *                        "PHI ESTIMATE ALREADY CONTAINS           DP073170
                                        *                        "THE LOP EXCEPT THAT THE SIGN            DP073180
                                        *                        "IS WRONG                                DP073190
                                        *                        "SET UP SECOND STATION NUMBER AS         DP073200
4481    4        140C  DE01                   FLG    8           "ARGUMENT FOR D PHI KI ROUTINE           DP073210
4482    8        140D  D005   (1413)          BUC    $2          "SET PROGRAM FLAG 8 TRUE                 DP073220
4483    8R       140E  F04800CC       $1      COM    4,,BASE+1   "EXAMINE THE SECOND STATION             DP073230
                                        *                        "IS THE SECOND                           *1073240
4484   12        1410  DC1A   (1418)          BNE    $10         "STATION THE BASE STATION?               %R073250
4485    2R       1411  A421                   CLA    2,1         STA 1 TF POINTER                         DP073260
                                        *                        "PHI ESTIMATE ALREADY CONTAINS           DP073270
                                        *                        "THE LOP                                 DP073280
                                        *                        "SET UP FIRST STATION NUMBER AS          DP073290
                                        *                        "ARGUMENT FOR D PHI KI ROUTINE           DP073300
4486    4        1412  A413                   CLA    1,3         STA 1 INDEX                              DP073310
                                        *                        "COMPUTE CORRECTION FOR TIME DIF-        *1073320
4487    8R *     1413  F80D0C05       $2      BSV    D_PHI_KI    "FERENCE BETWEEN STATION AND BASE        DP073330
4488   12        1415  A800                   CLSD   0,0         "FORM PHI ESTIMATE - CORRECTION          DP073340
4489   22        1416  FD281EA3               ADDD   X2,,PHI_ESTIMATE "    = + OR - LOP                DP073350
                                        *                        "                                        *2073360
4490   26        1418  D081   (141A)          BBF    $3          "IS THIS THE CORRECT LOP?                DP073370
                                        *                        "(FLAG 8 FALSE)                          DP073380
4491    4R       1419  A800                   CLSD   0,0         "COMPLIMENT TO GET + LOP                 DP073390
4492    8R       141A  D5F0           $3      BBK    15          "EXIT"                                   DP073400
```

```
4493    10R          1418  FD1A1EA3        $10     CLAD    X1,,PHI_ESTIMATE "FORM LOP = PHI EST (1)        DP073410
4494    20           141D  F92B1EA3                SUBD    X2,,PHI_ESTIMATE "          - PHI EST (2)       DP073420
4495    24           141F  D0C1   (1421)           BCT     $11             CORRECT IF PHASE DIFF       11  073430
4496     8R          1420  D5F0                    BBK     15                                          DP073440
4497    14R          1421  F01C1F3C        $11     FET     1,,PHI_OFFSET   GET FREQ                     11  073450
4498    16           1423  A440                    CLA     4,0             SAVE FOR N1                 11  073460
4499    18           1424  A416                    CLA     1,6             N2                          11  073470
4500    26  *        1425  F80D0C05                BSV     D_PHI_KI                                    11  073480
4501    30           1427  8C20                    AADD    2,0             LOP + N2 CORR               11  073490
4502    34           1428  AC04                    CLAD    0,4                                         11  073500
4503    42  *        1429  F80D0C05                BSV     D_PHI_KI                                    11  073510
4504    46           142B  B820                    SUBD    2,0             LOP + N2 - N1 CORR          11  073520
4505    60           142C  D510                    BBK     1                                           11  073530
```

```
                                        **                                                                  NC073540
                                        * ENTER HERE FOR NCTR DISPLAY                                       *H073550
4506      26R          142D  84A0       POP12       FETM        10,,0       "COMPUTE POINTERS FOR THE 32 BIT DP073560
4507      28           142E  A48C                   CLA         11,12       "SIGMA SQ PHI PHI AND THE 16 BIT DP073570
4508      32           142F  4486                   MPIM        11,,6       "SIGMA SQ N COUNTER FOR THIS     DP073580
4509      36           1430  44C3                   MPIM        12,,3       "STATION (ARG1)                  DP073590
4510      40           1431  F4C91D88               ADDM        12,,SIGMA_SQ_N_COUNTER                       NC073600
                                        *                                   "READ AND CONVERT THE 2 DIGIT    *I073610
4511      48  *        1433  F80D1459               BSV         NCT$1       "KALMAN DUMPS FOR 10.2           DP073620
                                        *                                   "GET SIGMA AND N FOR 10.2 (2 DIG-*I073630
4512      56  *        1435  F80D1444               BSV         NCT         "ITS) AND K DUMPS FOR 13.6 (2)   DP073640
4513      60           1437  AC53                   CLAD        5,3         "SET UP FIRST 6 DIGITS FOR THE   DP073650
4514      64           1438  B833                   SUBD        3,3         "LEFT DISPLAY REGISTER           DP073660
                                        *                                   "GET SIGMA AND N FOR 13.6 (2 DIG-*I073670
4515      72  *        1439  F80D1444               BSV         NCT         "ITS) AND K DUMPS FOR 11-3 (2)   DP073680
4516      78           1438  FC340100               LSAD        3,,8        "SET UP THESE 4 DIGITS FOR THE 4 DP073690
                                        *                                   "HIGH ORDER DIGITS OF THE RIGHT  DP073700
4517      82           143D  AC83                   CLAD        8,3         "DISPLAY                         DP073710
                                        *                                   "GET SIGMA AND N FOR 11-3 (2 DIG-*I073720
4518      90  *        143E  F80D1444               BSV         NCT         "ITS) - IGNORE REMAINING 2 DIGITSDP073730
4519      96           1440  FC340100               LSAD        3,,8        "PLACE LAST 2 DIGITS INTO THE LOWDP073740
4520     100           1442  AC93                   CLAD        9,3         "DIGITS OF THE RIGHT DISPLAY     DP073750
                                        *                                   "                                DP073760
4521     120           1443  D540                   BBK         4           "RETURN TO MAIN DISPLAY ROUTINE  DP073770
                                        *                                                                    NC073780
                                        *                   CONVERT N, KALMAN DUMPS AND VARIANCE             *H073790
                                        *                                                                    *H073800
                                        * THIS ROUTINE IS USE BY THE NCTR DISPLAY ROUTINE TO GET THE N COUNTS, *H073810
                                        * KALMAN DUMPS AND SQURE ROOT OF THE TRACKING FILTER VARIANCE.  THE   *H073820
                                        * ARGUMENTS CONSIST OF POINTERS TO N COUNT AND SIGMA.  THE OUTPUT DIGITS*H073830
                                        * ARE LEFT IN THE 6 MOST SIGNIFICANT DIGITS OF A 32 BIT REGISTER.     *H073840
                                        *                                                                    *H073850
4522       6R          1444  A60C       NCT         CLA         10,12       "READ AND EXTRACT THE 1 DIGIT N  DP073860
4523      14           1445  E4001770               EXT         0,0,HX000F  "COUNT (N NEVER EXCEEDS 7)       DP073870
4524      18           1447  F4040010               LSA         0,,4        "PLACE DIGIT IN 2ND POSITION OF  DP073880
4525      20           1449  B440                   ADD         4,0         "THE 32 BIT REGISTER             DP073890
4526      30           144A  FDBA1E33               CLAD        X11,,SIGMA_SQ_PHI_PHI                        DP073900
4527     476           144C  1000                   SQRT        0           "COMPUTE SQUARE ROOT OF SIGMA SQ DP073910
4528     486           144D  F8040064               MPYDM       0,,100      "PHI PHI + .005 CYCLE            DP073920
4529     494           144F  96F1    (00F1)        ADDD        0,,=DX(00008000) "     SCALED .01815     DP073930
4530     496           1450  9809                   COMM        0,,9                                         DP073940
                                        *                                   "IS THE RESULT                   *I073950
4531     500           1451  D051    (1453)        BRL         $2          "GREATER THAN .08 CYCLES?"       *R073960
```

```
4532    2R      1452  9C09                    CLAM    0,,9          "SET DISPLAY DIGIT TO 9 FOR MAX  DP073970
                                              *                     "STANDARD DEVIATION              DP073980
4533    2R      1453  B440              $2    ADD     4,0           "ADD STANDARD DEVIATION DIGIT    DP073990
4534    8       1454  FC340100                LSAD    3,,8          "TO THE LOW DIGIT OF THE 32 BIT  DP074000
                                              *                     "REGISTER AND SHIFT REGISTER LEFTDP074010
                                              *                     "2 DIGITS                        DP074020
4535    10      1456  9482                    ADDM    11,,2         "INCREMENT POINTERS TO N AND     %S074030
4536    12      1457  B011                    SUB     1,1           "SIGMA FOR THE NEXT FREQUENCY    DP074040
4537    14      1458  94C1                    ADDM    12,,1         INCREMENT N CT ADDRESS           NC074050
                                              * ENTER HERE FOR KALMAN DUMPS ONLY                     *H074060
4538    6R      1459  A62C              $1    CLA     12,12         "GET 8 BIT KALMAN DUMP COUNT     DP074070
                                              *                     "(NEVER EXCEEDS 99) FROM N COUNT DP074080
4539    12      145A  FC140100                LSAD    1,,8          "WORD                            DP074090
                                              *                     "CONVERT DUMPS TO BCD AND SHIFT  *I074100
4540    20  *   145C  F80D13D2                BSV     POP9$7        "INTO 32 BIT REGISTER            DP074110
4541    28      145E  D5F0                    BBK     15            "EXIT"                           DP074120
                                              *                                                      NC074130
                                              * ENTER HERE FOR MAN V/H                               *H074140
4542    2R      145F  981C              POP10 COMM    1,,12         SHIP OR RZ                         074150
4543    6       1460  D168   (147C)           BRE     POP13         RZ                                 074160
4544    14R     1461  F80C1F88                FETD    0,,PSI_INSERT "READ INSERTED HEADING             074170
4545    590     1463  0C00                    GEN     BEARING_DISPLAY  "CONVERT HEADING FOR DISPLAY  DP074180
4546    604     1464  F80C1FF4                FETD    0,,V_INSERT   "READ INSERTED VELOCITY          DP074190
4547    606     1466  9C10                    CLAM    1,,0          "      SCALE AT 812 FT/SEC       DP074200
4548    614     1467  4263   (00E3)           MPY     0,,HX4000                                      DP074210
4549    1190    1468  0C05                    GEN     SPEED_DISPLAY  "CONVERT VELOCITY FOR DISPLAY  DP074220
4550    1194    1469  D307   (14A1)           BUC     SWAP                                             074230
                                              * ENTER HERE FOR OMEGA - DR                           *H074240
4551    6R      146A  9E65   (00E5)  POP11   CLA     0,,STATIONS_IN_USE "READ OMEGA STATIONS AND NAV DP074250
                                              *                     "MODE SELECTED BY THE OPERATOR   DP074260
                                              *                     "AND DISPLAY IN THE UPPER RIGHT  DP074270
                                              *                     "KEYBOARD LAMPS                  DP074280
4552    8R      146B  E420010F              $1    EXT     2,0,HX00FF                                 074290
4553    10      146D  B422                      ADD     2,2                                        074300
4554    18      146E  E41000DF                  EXT     1,0,HX0400    GET AUTO BIT FOR UL          074310
4555    26      1470  E40000DE                  EXT     0,0,HX0200    GET MAN  BIT FOR UR          074320
4556    28      1472  B420                      ADD     2,0                                        074330
4557    34      1473  9E4C   (00CC)           CLA     0,,BASE+1     "READ LAMP BIT CORRESPONDING TO  %S074340
                                              *                     "THE BASE STATION NUMBER AND     DP074350
                                              *                     "DISPLAY IN THE UPPER LEFT       DP074360
                                              *                     "KEYBOARD LAMPS                  DP074370
4558    42      1474  F50A00D6                CLA     X0,,POWERS_OF_TWO+1                        074380
4559    44      1476  B410                    ADD     1,0                                        074390
```

```
4560      56        1477  F8170008                STAD    1,,C_I_UPPER_LEFT_KEYBOARD_LAMPS                    074400
4561      58        1479  94E2                    ADDM    14,,2           "THIS ROUTINE DID NOT DEVELOP AN  %S074410
                                                  *                       "IMAGE OF THE DISPLAY REGISTERS  DP074420
                                                  *                       "AND LEGENDS SO IT MUST MAKE AN  DP074430
                                                  *                       "ABNORMAL RETURN TO THE MAIN     DP074440
                                                  *                       "DISPLAY ROUTINE                 DP074450
                                                  *                       "ADJUST R14 RETURN STACK         DP074460
                                                  *                       "BRANCH DIRECTLY TO MAIN DISPLAY DP074470
                                                  *                       "ROUTINE                         DP074480
4562      64        147A  04C01261                BUC     PANELOUTPUT$5                                       DP074490
                                                  * ENTER HERE FOR RZ V/H                                     *H074500
4563      30R       147C  F05C1F8E          POP13 FET     5,,RZ_BETA      "COMPUTE GREAT CIRCLE HEADING    DP074510
4564      50        147E  F8261F8C                MPYD    2,,RZ_POS+4     "= ARCTAN (BETA1)/(BETA2*RZ POS3 DP074520
4565      70        1480  F8461F8A                MPYD    4,,RZ_POS+2     "      - BETA3*RZ POS2)          DP074530
4566      74        1482  B824                    SUBD    2,4                                                DP074540
4567      78        1483  BC22                    ADDD    2,2             RESCALE  B1                        DP074550
4568      82        1484  AC40                    CLAD    4,0                                                DP074560
4569      92        1485  D710                    PRN     1                                                  DP074570
4570     630        1486  1800                    ATAN    0                                                  DP074580
4571    1206        1487  0C00                    GEN     BEARING_DISPLAY "CONVERT HEADING FOR DISPLAY       DP074590
4572    1220        1488  F80C1FDB                FETD    0,,RZ_VEL       "READ INSERTED RZ VELOCITY       DP074600
4573    1224        148A  D104    (149F)          BUC     POP15$1                                            DP074610
                                                  * ENTER HERE FOR OMEGA V/TK                                *H074620
4574      22R       148B  F03C1F4C          POP14 FET     3,,VC2_STAR-2   "COMPUTE TRACK ANGLE              DP074630
4575      24        148D  A403                    CLA     0,3             "= ARCTAN (VC2 / VC3) - THETA P  DP074640
4576     562        148E  1800                    ATAN    0,0                                                DP074650
4577     572        148F  F80B1F50                SUBD    0,,THA_P_STAR                                      DP074660
4578    1148        1491  0C00                    GEN     BEARING_DISPLAY "CONVERT TRACK FOR DISPLAY         DP074670
4579    1162        1492  F80C1F4E                FETD    0,,VC2_STAR                                        % 074680
4580    1170  *     1494  F80D1751                BSV     MAKE_VELOCITY   "COMPUTE SPEED FROM VC2, 3       DP074690
4581    1746        1496  0C05                    GEN     SPEED_DISPLAY   "CONVERT SPEED FOR DISPLAY       DP074700
4582    1750        1497  D009    (14A1)          BUC     SWAP                                               074710
                                                  * ENTER HERE FOR SUB V/H                                   *H074720
4583      14R       1498  F80C1F53          POP15 FETD    0,,SMOOTH_DATA_STAR   AUTO HEADING                 074730
4584     590        149A  0C00                    GEN     BEARING_DISPLAY "CONVERT HEADING FOR DISPLAY       DP074740
4585     604        149B  F80C1F48                FETD    0,,V_TAS_STAR   "READ SHIP'S LOG                  DP074750
4586     614        149D  F8044000                RSAD    0,,1            SCALE B12                          DP074760
4587     576R       149F  0C05              $1  GEN     SPEED_DISPLAY   "CONVERT V FOR DISPLAY"           DP074770
4588     580        14A0  D800    (14A1)          BUC     SWAP                                               074780
                                                  *                                                          074790
                                                  *                                                          074800
                                                  *                                                          074810
4589      10R       14A1  C022              SWAP  FET     2,2             SWAP LEFT AND RIGHT DISPLAYS       074820
```

```
4590    14    14A2  AC47    CLAD    4,7     074830
4591    16    14A3  A436    CLA     3,6     074840
4592    20    14A4  AC71    CLAD    7,1     074850
4593    22    14A5  A460    CLA     6,0     074860
4594    38    14A6  D520    BBK     2       074870
```

```
                **                                                                    DP074880
                *                          MAKE LAT LONG                              *H074890
                *                                                                     *H074900
                * THIS ROUTINE WILL COMPUTE LATITUDE AND LONGITUDE FROM A POSITION    *H074910
                * VECTOR.  THE ARGUMENT CONSISTS OF A POINTER TO THE VECTOR           *H074920
                *                                                                     *H074930
                *       ENTER WITH ADDRESS OF V IN R0:                                DP074940
                *       V1 = SIN LAT, V2 = COS LAT.COS LONG, V3 = COS LAT.SIN LONG    DP074950
                *       EXIT WITH LAT IN R0,1   LONG IN R2,3   (3 REGISTERS ADDED)    DP074960
                MAKE_LAT_LONG;                                                        DP074970
4595
4595      28R   14A7  C250          FET     I5,0      V1,V2,V3                        DP074980
4596       40   14A8  C035          FET     3,5       V2,V3                           DP074990
4597      578   14A9  1800          ATAN    0,0       LONGITUDE                       DP075000
4598      594   14AA  6866          MPYD    6,6       "LAT = ARCTAN  R1 / (R3**2      DP075010
4599      610   14AB  6844          MPYD    4,4       "       + R2**2)**.5            DP075020
4600      614   14AC  BC46          ADDD    4,6       COS LAT SQUARED                 DP075030
4601      618   14AD  AC70          CLAD    7,0       "LONG = ARCTAN R3 / R2          DP075040
4602      622   14AE  AC04          CLAD    0,4                                       DP075050
4603     1068   14AF  1000          SQRT    0,0                                       DP075060
4604     1606   1480  1800          ATAN    0,0       LATITUDE                        DP075070
4605     1610   1481  AC30          CLAD    3,0                                       DP075080
4606     1626   1482  D520          BBK     2                                         DP075090
```

```
                                **                                                                  DP075100
                                *                    MAKE RANGE AND BEARING                         #H075110
                                *                                                                   #H075120
                                *THIS ROUTINE WILL COMPUTE THE RANGE AND BEARING BETWEEN 2 POINTS AND #H075130
                                * CONVERT THE BEARING FOR DISPLAY.  THE ARGUMENTS CONSIST OF POINTERS #H075140
                                * TO THE SELECTED DESTINATIONS (13 INDICATES THAT THE CRAFT IS TO BE  #H075150
                                * USED AS THE START POINT).                                          #H075160
                                *                                                                   #H075170
4607                            MAKE_RANGE_AND_BEARING:                                             CI075180
4607    4R      14B3 9F22               CLAM    IX2,2           "READ END POINTER                   DP075190
                                *                               "COMPUTE POSITION VECTOR TO THE     #I075200
4608    12  *   14B4 F80D173E           BSV     MAKE_DESTINATION_VECTOR  "SELECTED END POINT"       DP075210
4609    42      14B6 F4571F30           PTR     5,,BEARING_TEMPS "SAVE VECTOR (D)                   DP075220
4610    44      14B8 9818               COMM    1,,11            SHIP                                075230
                                *                               "WAS THE CRAFT                      #I075240
4611    48      14B9 D017   (14C1)      BNE     $1              "SELECTED AS THE START POINT?       $R075250
4612    10R     14BA F82A00C0           CLSD    2,,THETA_P      "SET ALPHA = - THETA P              DP075260
4613    80      14BC F0FC1F57           FET     15,,RIJ_STAR+2  "READ RIJ POSITION MATRIX           DP075270
4614    94      14BE F80C1F55           FETD    0,,RIJ_STAR                                         DP075280
4615    98      14C0 D008   (14C9)      BUC     $2                                                  DP075290
4616    2R      14C1 8411       $1      ADD     1,1             "SET ALPHA = 0                      DP075300
4617    6       14C2 8822               SUBD    2,2             "READ SELECTED START POINT          DP075310
                                *                               "LATITUDE AND LONGITUDE             DP075320
4618    20      14C3 F91C1FC4           FETD    X1,,DESTINATION_LONGITUDE                           DP075330
4619    34      14C5 F93C1FDE           FETD    X3,,DESTINATION_LATITUDE                            DP075340
                                *                               "COMPUTE POSITION MATRIX (RIJ)      #I075350
4620    42  *   14C7 F80D0FA6           BSV     PANEL_MAIN$8    "FOR SELECTED START POINT           DP075360
4621    30R     14C9 F4571F36   $2      PTR     5,,BEARING_TEMPS+6 "COMPUTE BEARING                 DP075370
                                *                               "= -ARCTAN (-R2.D/R3.D) + ALPHA     DP075380
4622    60      14C8 F05C1F30           FET     5,,BEARING_TEMPS                                    DP075390
4623    68  *   14CD F80D1728           BSV     REGISTER_DOT                                        % 075400
4624    72      14CF A880               CLSD    8,0                                                 DP075410
4625    82      14D0 D710               PRN     1                                                   DP075420
4626    112     14D1 FC5C1F30           FET     5,,BEARING_TEMPS                                    DP075430
4627    120 *   14D3 F80D1728           BSV     REGISTER_DOT                                        % 075440
4628    658     14D5 1800               ATAN    0                                                   DP075450
4629    666     14D6 C013               FET     1,3                                                 DP075460
4630    670     14D7 8802               SUBD    0,2                                                 DP075470
4631    1246    14D8 0CC0               GEN     BEARING_DISPLAY  "CONVERT BEARING FOR DISPLAY       DP075480
4632    1284    14D9 F07C1F2E           FET     7,,BEARING_TEMPS-2                                  CI075490
4633    1314    14DB F05C1F36           FET     5,,BEARING_TEMPS+6                                  DP075500
4634    1322 *  14DD F80D1714           BSV     REGISTER_CROSS                                      % 075510
4635    1338    14DF 6800               MPYD    0,0             "COMPUTE CENTRAL ANGLE FOR RANGE    DP075520
```

```
4636  1354        14E0  6822          MPYD    2,2          "= ARCTAN (MAG(D X R1)/D.R1)   DP075530
4637  1370        14E1  6844          MPYD    4,4                                         CI075540
4638  1374        14E2  8C02          ADDD    0,2                                         CI075550
4639  1378        14E3  8C04          ADDD    0,4                                         CI075560
4640  1824        14E4  1000          SQRT    0                                           CI075570
4641  1854        14E5  FC5C1F30      FET     5,,BEARING_TEMPS                            CI075580
4642  1884        14E7  FC5C1F36      FET     5,,BEARING_TEMPS+6                          DP075590
4643  1892  *     14E9  F80D1728      BSV     REGISTER_DOT                                % 075600
4644  2430        14E8  1800          ATAN    0                                           CI075610
4645  2434        14EC  AC60          CLAD    6,0                                         CI075620
4646  2456        14ED  D550          BBK     5                                           CI075630
                  *                           VARSAVE                                   *H075640
                  *                                                                     *H075650
                  * THIS ROUTINE TRANSFERS THE CRAFT RELATED DATA USED BY THE VARIOUS    *H075660
                  * DISPLAY PROGRAMS INTO A SPECIAL STORAGE AREA.  THIS TRANSFER DOES NOT *H075670
                  * OCCUR DURING THE HOLD MODE                                          *H075680
                  *                                                                     *H075690
4647   12R        14EE  F4280013      VARSAVE FETM    2,,PANEL_BOUND-PANEL_DATA-1         CI075700
                  *                                   "TRANSFER PARAMETERS THAT RESIDE  DP075710
                  *                                   "IN THE UPPER END OF MEMORY INTO  DP075720
                  *                                   "THE HOLD AREA.  (RIJ AND V SEA)  DP075730
4648    8R        14F0  F51A1F67      $1      CLA     X1,,PANEL_DATA                      % 075740
4649   18         14F2  F1171F53              STA     X1,,PANEL_BUFFER                    CI075750
4650   26         14F4  C415   (14F0)         BXU     1,,$1                               % 075760
4651   38R        14F5  FC7C0088              FET     7,,V_TAS      "TRANSFER PARAMETERS THAT RESIDE %S075770
4652   76         14F7  F4771F48              PTR     7,,V_TAS_STAR "IN THE LOWER END OF MEMORY INTO DP075780
                  *                                                 "THE HOLD AREA.  (V LOG, TIME,  DP075790
4653   92         14F9  D520                  BBK     2             "VC2, VC3, THETA P, PSI A)      DP075800
```

```
                **                                                                  DP075810
                *                          DISPLAY CONVERSION ROUTINE               *H075820
                *                                                                   *H075830
                * THIS PIN ROUTINE WILL CONVERT DATA TO BCD FOR DISPLAY AND SET UP THE *H075840
                * LEGEND.  THE INPUT CONSISTS OF A 32 BIT WORD TO BE DISPLAYED AND A  *H075850
                * POINTER TO A CONVERSION TABLE.  EACH ENTRY IN THE TABLE CONTAINS A 32 *H075860
                * BIT SCALE FACTOR AND A 16 BIT CONTROL WORD.  EACH INPUT WORD WILL BE *H075870
                * MULTIPLIED BE THE SCALE FACTOR BEFORE CONVERSION TO BCD.  THE SCALE  *H075880
                * FACTOR SHOULD PUT THE INPUT WORD INTO THE UNITS OF THE LOWEST DIGIT OF*H075890
                * THE DISPLAY (VELOCTY WOULD BE IN UNITS OF KNOTS) SCALED D+5 B+3.    *H075900
                * THIS ROUTINE WILL THEN CONVERT THE NUMBER TO 6 BCD DIGITS WITH THE  *H075910
                * LAST DIGIT APPEARING IN THE LOWEST DIGIT OF THE DISPLAY.            *H075920
                *                                                                   *H075930
                * THE 8 MSB'S OF THE CONTROL WORD ARE TRANSFERED DIRECTLY TO THE UPPER 8*H075940
                * BITS OF THE LEGEND TO TURN ON THE PUNCTUATION AND/OR L, R, W, E FOR *H075950
                * THE RIGHT DISPLAY AND KTS, NMI, S, N FOR THE LEFT DISPLAY.  IF THE  *H075960
                * SCALED INPUT WORD IS NEGATIVE BITS 9 TO 12 ARE ADDED TO THE LEGEND. *H075970
                * THIS HAS THE EFFECT OF CHANGING N TO S, E TO W OR R TO L.  THE FOUR  *H075980
                * LSB'S OF THE CONTROL WORD DEFINE THE NUMBER OF LEADING BLANKS FOR A  *H075990
                * DISPLAY.  ALL ZERO'S IN THE FIRST N CHARACTERS ARE CHANGED TO BLANKS *H076000
                *                                                                   *H076010
                * WHENEVER THE POINTER POINTS TO THE FIRST ENTRY IN THE CONVERSION TABLE*H076020
                * (0) THE INPUT IS SHIFTED RIGHT ONE BIT WITHOUT SIGN SPREAD.  THIS IS *H076030
                * USED FOR THE CONVERSION OF ANGLES WITH A RANGE OF +180 TO -180 TO   *H076040
                * ANGLES BETWEEN 0 AND 360.                                          *H076050
                *                                                                   *H076060
                * SPECIAL HANDLING OF LATITUDE AND LONGITUDE HAS BEEN PROVIDED BECAUSE *H076070
                * THEY ARE DISPLAYED IN UNITS OF DEGREES AND MINUTES.  THE PUNCTUATION *H076080
                * BIT IN THE CONTROL WORD THAT TURNS ON THE HIGH ORDER DEGREE LAMP IS  *H076090
                * USED AS A MARKER SIGNIFYING LAT OR LONG.  THE SCALE FACTOR MUST CON- *H076100
                * VERT THEM TO DEGRESS SCALED D283.                                  *H076110
                *                                                                   *H076120
                * THE OUTPUT IS ALL SET UP FOR THE MAIN DISPLAY ROUTINE TO OUTPUT TO THE*H076130
                * C/I PANEL.  EACH ENTRY SETS UP THE DISPLAY FOR EITHER THE LEFT OR THE *H076140
                * RIGHT SIDE OF THE PANEL.  THE FIRST ENTRY IS THE RIGHT SIDE AND THE  *H076150
                * SECOND ENTRY SETS UP THE LEFT SIDE UNLESS THE CALLING PROGRAM SETS UP *H076160
                * ONE OF THE DISPLAYS SEPARATELY                                     *H076170
                *                                                                   *H076180
                * NUMBER IN R1,2                                                     DP076190
                * POINTER TO TABLE IN R0                                             DP076200
4654      4R    14FA 4403 GEN_PIN  MPIM   0,,3          "FIX POINTER FOR 3 WORDS    DP076210
4655      6     14FB DEAD          FLG    BT+EOR+8      "PER ENTRY                    076220
                *                                      "IS IT POINTING             *1076230
```

```
4656  10  14FC  D013 (1500)        BNE    $10          "TO THE FIRST TABLE ENTRY?      %R076240
4657  10R 14FD  F8154000           RSLD   1,,1         "RESCALE ANGLE TO 2PI OR 360 DEG DP076250
                                   *                   "AND MAKE IT POSITIVE           DP076260
4658  12  14FF  DE01               FLG    8            "FLAG HEADING TO FORCE BLANKS     076270
                                   *                   "IN LAST THREE DIGITS             076280
4659  4R  1500  F4091541     $10   ADDM   0,,CONVERSION_DATA                            CI076290
4660  20  1502  C220               FET    I2,0         "READ SCALE FACTOR AND          DP076300
4661  34  1503  8440               FETM   4,,0         "CONTROL WORD                   DP076310
                                   *       SCALE, AND ADJUST FOR SIGN                  CI076320
                                   *   REGISTERS:  0,0,0,0,0F00,SCALE FACTOR,,LEGEND,INDEX,NUMBER,,  CI076330
4662  50  1504  6895               MPYD   9,5          "RESCALE INPUT WORD WITH        DP076340
                                   *                   "SCALE FACTOR                   DP076350
4663  54  1505  D026 (150C)        BGE    $2           "IS THE RESULT NEGATIVE?"       %R076360
4664  2R  1506  9475               ADDM   7,,5         "CHANGE LEGEND FROM N OR E TO S    076370
4665  6   1507  F879A133           COMM   7,,X(A133)   "OR J AND TEST IF S                076380
4666  10  1509  D061 (1508)       BRE    $1           "YES                               076390
4667  2R  150A  947D               ADDM   7,,13        "CHANGE J TO W                     076400
                                   *                                                      076410
4668  4R  150B  A899         $1    CLSD   9,9          "COMPLIMENT INPUT WORD             076420
4669  8R  150C  E487173D     $2    EXT    8,7,HX0F00   "EXTRACT LEADING BLANKS FROM      076430
4670  14  150E  FC850080           RSL    8,,8         "CONTROL WORD AND SHIFT            076440
                                   *                   "RIGHT 8 BITS                      076450
                                   *                   "SET NUMBER FOR ROUNDING        DP076460
                                   *                   "     = .5 D58-13               DP076470
                                   *       ROUND UP                                    CI076480
4671  18  1510  FC39053E           CLAM   3,,F((1)/2D58-13)                           CI076490
4672  22  1512  D083 (1516)       BBF    $85           IS IT HEADING                     076500
4673  10R 1513  FC981562           ADDD   9,,ROUND_FOR_H YES, SO USE THIS              076510
4674  14  1515  D006 (151C)       BUC    $86                                            076520
4675  2R  1516  9870         $85   COMM   7,,0                                         076530
                                   *                   "IS THIS A                     *076540
4676  6   1517  D023 (151B)       BGE    $9           "LATITUDE OR LONGITUDE DISPLAY? %R076550
4677  4R  1518  D0A2 (1518)       BBT    $9           "BYPASS IF HEADING                076560
4678  4R  1519  F439037F           ADDM   3,,F((1)/3D58-13) "ADD 1/3 D58-13 TO ROUNDING DP076570
                                   *                   "NUMBER BECAUSE LAT AND LONG WILLDP076580
                                   *                   "BE CONVERTED TO MINUTES LATER  DP076590
4679  4R  151B  BC92         $9    ADDD   9,2          "ROUND INPUT"                   DP076600
                                   *                   "                               DP076610
                                   *                   "CLEAR DOUBLE REGISTER FOR      DP076620
                                   *                   "THE BCD CHARACTERS             DP076630
                                   *                   "                               DP076640
                                   *                   "SET UP 2 AND 3 COUNTS TO CONVERTDP076650
                                   *                   "THE SIX DIGITS.  THE TWO COUNT- DP076660
```

```
                                                                                                                                    "ERS ARE USED BECAUSE LAT AND      DP076670
                                                                                                                                    "LONG ARE CONVERTED IN 2 GROUPS    DP076680
                                                                                                                                    "OF 3 DIGITS                       DP076690
4680      4R    151C  8855                  $86          SUBD        5,5                                                                                          076700
4681      6     151D  9C32                               CLAM        3,,2                           COUNT OF 3                    CI076710
4682      8     151E  9C11                               CLAM        1,,1                           COUNT OF 2                    CI076720
4683      12    151F  D008    (1528)                     BUC         $6                                                           CI076730
                                                * THE ENTRY TO THE CONVERSION                                                   *H076740
                                                * LOOP IS AT $6                                                                 *H076750
                                                *   REGISTERS:   0,1,0,2,0F00/0800,DIGIT WORDS,,LEGEND,BLANKS,NUMBER,,         CI076760
4684      2R    1520  9870                  $3           COMM        7,,0                           "EXAMINE HIGH DEGREE BIT      DP076770
                                                *                                                  "IS THIS A                    *1076780
4685      6     1521  D023    (1525)                     BGE         $4                             "LATITUDE OR LONGITUDE DISPLAY? %R076790
4686      4R    1522  D1A7    (153A)                     BBT         $30                            "END CONVERSION IF HEADING     076800
4687      6R    1523  4C96                               MPIDM       9,,6                           "MULTIPLY BY 6 INSTEAD OF 10 THISDP076810
                                                *                                                  "TIME TO CONVERT FRACTIONS OF A DP076820
                                                *                                                  "DEGREE TO 10'S OF MINUTES     DP076830
4688      10    1524  D001    (1526)                     BUC         $5                                                           CI076840
4689      6R    1525  4C9A                  $4           MPIDM       9,,10                          "MULTIPLY REMAINDER BY 10 TO GET DP076850
                                                *                                                  "THE NEXT BCD CHARACTER        DP076860
4690      6R    1526  FC540010              $5           LSAD        5,,4                           "SHIFT PREVIOUS DIGITS OVER    DP076870
                                                *                                                  "1 DIGIT TO MAKE ROOM FOR      DP076880
                                                *                                                  "THE NEXT DIGIT                DP076890
4691      8R    1528  E4091788              $6           EXT         0,9,HXF000                     "EXTRACT THE NEW DIGIT         DP076900
4692      12    152A  D015    (1530)                     BNE         $7                             "IS THIS DIGIT A ZERO?        %R076910
                                                * BCD WORD IS INITIALLY ALL ZERO'S                                              *H076920
4693      2R    152B  9880                               COMM        8,,0                           "                             % 076930
                                                *                                                  "IS THE BLANK                 *1076940
4694      6     152C  D047    (1534)                     BLE         $8                             "COUNT DOWN TO ZERO YET?"      DP076950
4695      4R    152D  F4690F00                           ADDM        6,,X(0F00)                     "SET NEW DIGIT IN THE BCD WORD DP076960
4696      8     152F  D004    (1534)                     BUC         $8                             "TO A BLANK                    DP076970
4697      2R    1530  8090                  $7           SUB         9,0                            "DELETE THIS DIGIT FROM        DP076980
4698      4     1531  8C81                               CLSM        8,,1                           "CONVERSION WORD               DP076990
4699      12    1532  5260    (00E0)                     MPLM        10,,HX0800                     "INHIBIT ANY MORE BLANKS NOW THATDP077000
4700      14    1533  8460                               ADD         6,0                            "THERE IS A NON ZERO DIGIT     DP077010
                                                *                                                  "                              DP077020
                                                *                                                  "ADD NEW DIGIT TO THE BCD WORD DP077030
4701      2R    1534  9081                  $8           SUBM        8,,1                           "DECREMENT BLANKS COUNT BY 1   DP077040
                                                *                                                  "HAS THE SET OF 3              *1077050
4702      10    1535  C521    (1525)                     BXU         2,,$4                          "DIGITS BEEN CONVERTED YET?   %R077060
                                                *                                                  "HAVE THE 2 SETS               *1077070
4703      8R    1536  C517    (1520)                     BXU         1,,$3                          "OF 3 DIGITS BEEN CONVERTED YET? %R077080
4704      2R    1537  A4A7                  $29          CLA         10,7                           "CONVERSION COMPLETE"          077090
```

```
4705      6     1538  AC85                    CLAD    8,5       "REPOSSITION RESULTS FOR DISPLAY DP077100
4706     32     1539  D570                    BBK     7                                          CI077110
4707     6R     153A  FC541000      $30       LSAD    5,,12     "SHIFT TO DEGREES POSITION          077120
4708      8     153C  8C61                    CLSM    6,,1      "FORCE BLANKS IN LAST               077130
4709     16     153D  E4551128                EXT     5,5,HXFFF0 "3 DIGITS IF                     077140
4710     18     153F  945F                    ADDM    5,,15     "HEADING"                           077150
4711     22     1540  D80A    (1537)          BUC     $29                                           077160
```

```
                        **  PARAMETER BLOCKS FOR GEN PIN                                                    DP077170
4712                    CONVERSION_DATA;                                                                    DP077180
4712    1541 3999999A           COND        F(360/10283)                                                     077190
4713    1543 8024               CON         X(8024)         DEG , 0 BLANKS                                   DP077200
4714                    BEARING_DISPLAY;                                                                    DP077210
4714    0000                    EQU         0               BEARING MUST HAVE ZERO CODE                      DP077220
4715    0715            CDD     EQU         CONVERSION_DATA/3   (CONVERSION DATA DIVIDED)                    DP077230
                        *                                                                                   DP077240
4716    1544 1CCCCCCD   CD2     COND        F(.225)         180/100,B-3                                      DP077250
4717    1546 A12E               CON         X(A12E)         DEGREE , DOT , 1 BLANK , N                       077260
4718                    LATITUDE_DISPLAY;                                                                   DP077270
4718    0001                    EQU         CD2/3-CDD                                                        DP077280
                        *                                                                                   DP077290
4719    1547 1CCCCCCD   CD3     COND        F(.225)         180/100B-3                                       077300
4720    1549 A025               CON         X(A025)         DEGREE , DOT, E                                  077310
4721                    LONGITUDE_DISPLAY;                                                                  077320
4721    0002                    EQU         CD3/3-CDD                                                        077330
                        *                                                                                   DP077340
4722    154A 20C498A6   CD4     COND        F(.12881)                                                        DP077350
4723    154C 4300               CON         X(4300)         HIGH DOT, 3 BLANKS                               077360
4724    0003            LOP_DISPLAY EQU     CD4/3-CDD                                                        DP077370
                        *                                                                                   DP077380
4725    154D 114FB49C   CD5     COND        F(.135244919)   PI*2.0926/6.0761033,B-3                          DP077390
4726    154F 242D               CON         X(242D)         LOW  DOT, 4 BLANKS, M                            077400
4727                    RANGE_DISPLAY;                                                                      DP077410
4727    0004                    EQU         CD5/3-CDD                                                        DP077420
                        *                                                                                   DP077430
                        *                                                                                   DP077440
4728    1550 03E23001   CD7     COND        F(.030340195)                                                    DP077450
4729    1552 2328               CON         X(2328)         LOW DOT, 3 BLANKS, K                             077460
4730                    SPEED_DISPLAY;                                                                      DP077470
4730    0005                    EQU         CD7/3-CDD                                                        DP077480
                        *                                                                                   DP077490
4731    1553 0199999A   CD8     COND        F((1)/80)                                                        DP077500
4732    1555 2428               CON         X(2428)         LOW DOT, 4 BLANKS, H                             077510
4733    0006            ETE_DISPLAY EQU     CD8/3-CDD                                                        DP077520
                        *                                                                                   DP077530
4734    1556 Q03E6264   CD9     COND        X(003E6264)                                                      DP077540
4735    1558 242D               CON         X(242D)         LOW DOT, 4 BLANKS, M                             077550
4736    0007            SIG_DISPLAY EQU     CD9/3-CDD                                                        DP077560
                        *                                                                                   DP077570
4737    1559 0199999A   CD11    COND        F((1)/10B3)                                                      DP077580
4738    1558 0000               CON         X(0000)                                                          DP077590
```

```
4739                        BASE_DISPLAY;                                                    DP077600
4739  0008                          EQU   CD11/3-CDD                                       DP077610
4740  155C  0051F000   CD12        COND  X(0051F000)                                      077620
4741  155E  222E                    CON   X(222E)          2 BLANKS XXX.X                  077630
4742  0009              T_0_PEAVG   EQU   CD12/3-CDD      USED FOR PCI TEST               077640
4743  155F  000FA000    CD13        COND  F(18-210+3)      THIS MAKES FULL SCALE = 3.8     077650
4744  1561  212E                    CON   X(212E)          LOW DOT 3 BLNKS,  XXX.XX        077660
4745  000A              T_0_DOT_CVT EQU   CD13/3-CDD                                       077670
4746  1562  00147AE1    ROUND_FOR_H COND  F((1)/20283)                                     077680
```

```
                                **                                                                  CI077690
                                *                          BCD TO BINARY                            *H077700
                                *                                                                   *H077710
                                * THIS ROUTINE WILL CONVERT THE 6 CHARACTER DISPLAY IMAGE TO BINARY *H077720
                                * WITH THE LSB OF THE BINARY WORD EQUAL TO 1 COUNT IN THE LSD OF THE *H077730
                                * DISPLAY.  THE BIT IN THE LEGEND THAT TURNS ON THE HIGH ORDER DEGREE *H077740
                                * LAMP ON THE DISPLAY IS USED AS A MARKER TO SIGNIFY A LATITUDE OR LONG-*H077750
                                * ITUDE CONVERSION.                                                 *H077760
                                *                                                                   *H077770
4747  20R  1564  8472           BCDTOBIN  FETM  7,,2          "SET UP A 3 COUNT AND 2 COUNT TO    DP077780
4748  22   1565  9C51                     CLAM  5,,1          "CONTROL THE 6 DIGIT CONVERSION     DP077790
4749  26   1566  D007  (156E)             BUC   $3                 AND 5 WORKING REGS             CI077800
4750   8R  1567  F41A0007        $1        CLA   1,,C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION      CI077810
                                *                                 "EXAMINE THE HIGH DEGREE BIT    DP077820
                                *                                 "IS THIS A                      *1077830
4751  12   1569  4414                     LSA   1,,2          "BYPASS IF HEADING                    077840
4752  16   156A  D022  (156D)             BGE   $2                                                  077850
4753   6R  156B  4C26                     MPIDM 2,,6          "MULTIPLY BY 6 TO CONVERT           DP077860
4754  10   156C  D001  (156E)             BUC   $3            "DEGREES TO 10'S OF MINUTES         DP077870
4755   6R  156D  4C2A           $2        MPIDM 2,,10         "MULTIPLY CONVERTED DATA BY 10      DP077880
                                *                                 "BEFORE ADDING IN THE NEXT DIGIT DP077890
4756   8R  156E  FC850010       $3        LSED  8,,4          "SHIFT BCD CHARACTERS END AROUND     DP077900
4757  16   1570  E419177D                 EXT   1,9,HX000F    "LEFT TO GET NEXT MOST SIGNIFI-     DP077910
                                *                                 "CANT DIGIT IN THE LOW BITS AND DP077920
4758  18   1572  9819                     COMM  1,,X(9)       "EXTRACT THE NEW DIGIT              DP077930
                                *                                 "                               *2077940
4759  22   1573  D031  (1575)             BRG   $5            "IS THIS DIGIT GREATER THAN 9?      DP077950
                                *                                 "(BLANK IS 15)                  DP077960
4760   4R  1574  BC20           $4        ADDD  2,0           "ADD NEW DIGIT TO BINARY            DP077970
                                *                                 "ACCUMULATION                   DP077980
                                *                                 "HAS THE SET OF 3               *1077990
4761   8R  1575  C469  (156D)    $5        BXU   6,,$2         "DIGITS BEEN CONVERTED YET?         $R078000
                                *                                 "HAVE THE 2 SETS                *1078010
4762   8R  1576  C550  (1567)             BXU   5,,$1         "OF 3 DIGITS BEEN CONVERTED YET?    $R078020
4763   4R  1577  AC82                     CLAD  8,2           "REPOSITION RESULTS"                DP078030
4764  30   1578  D570                     BBK   7                                                   CI078040
```

```
                        **                                                                  DP078050
                        *           RZ POSITION UPDATE                                      *H078060
                        *                                                                   *H078070
                        * THIS ROUTINE IS A SLOW NON OMEGA TASK                            *H078080
                        * (ONCE PER SEC) THAT UPDATES THE MOVING                           *H078090
                        * DESTINATION POSITION                                            *H078100
4765      12R   1579  8430  RZ_UPDATE  FETM    3,,0          "COMPUTE AND SAVE RZ RATE IN  DP078110
4766      20    157A  F42A1FD8           CLA     2,,RZ_VEL     "RADIANS/SEC AT B-14          DP078120
4767      30    157C  FC0A1FB8           CLAD    0,,RZ_POS     "                             DP078130
4768      46    157E  6800              MPYD    0,0           B2                            DP078140
4769      66    157F  F8061AD4          MPYD    0,,=DF(((-3.36D-5)*20.926428D6)/1824)       DP078150
4770      76    1581  FC081AD6          ADDD    0,,=DF((20.926428D6)/1826)                  DP078160
4771      202   1583  DC20              DIVD    2,0           "RZ RATE = RZ VEL/EARTH RADIUS DP078170
4772      214   1584  F8271FF2          STAD    2,,RZ_RATE    "WHERE ER = RHO(1 - K*RZ1**2)  DP078180
4773      224   1586  4824              RSAD    2,,13         SCALE RAD/SEC B-1             DP078190
4774      254   1587  F05C1FB8          FET     5,,RZ_POS                                   DP078200
4775      292   1589  F07C1FBE          FET     7,,RZ_BETA                                  DP078210
4776      300 * 158B  F80D1714          BSV     REGISTER_CROSS  "COMPUTE RZ C = BETA X RZ POS DP078220
4777      316   158D  C055              FET     5,5           REPEAT                        DP078230
4778      346   158E  F4571FB2          PTR     5,,RZ_C       "SAVE RZ C AT B2              DP078240
4779      362   1590  680A              MPYD    0,10          "UPDATE RZ POS"               %S078250
4780      378   1591  682A              MPYD    2,10          "NEW RZ POS = OLD RZ POS +    DP078260
4781      394   1592  684A              MPYD    4,10          "          (RZ RATE)*(RZ C)   DP078270
4782      424   1593  F05C1FB8          FET     5,,RZ_POS                                   DP078280
4783      428   1595  BC06              ADDD    0,6           NEW RZ                        DP078290
4784      432   1596  BC28              ADDD    2,8                                         DP078300
4785      436   1597  BC4A              ADDD    4,10                                        DP078310
4786      466   1598  F4571FB8          PTR     5,,RZ_POS                                   DP078320
4787      504   159A  D5D0              BBK     13                                          DP078330
```

```
                                **                                                                                  DP078340
                                *           RZ TIME UPDATE                                                         *H078350
                                *                                                                                  *H078360
                                * THIS ROUTINE IS A SLOW NON OMEGA TASK                                             *H078370
                                * (ONCE PER SEC) THAT DETERMINES THE                                               *H078380
                                * POINT OF INTERCEPTION OF THE MOVING                                              *H078390
                                * DESTINATION AND THE CRAFT (ASSUMING                                              *H078400
                                * THE CRAFT CHANGES COURSE TO THE OPTIMUM                                          *H078410
                                * HEADING)                                                                         *H078420
 4788                           RZ_TIME_UPDATE;                                                                    DP078430
 4788      30R          1598  F05C1F69                FET       5,,RIJ          "READ VECTORS R1 AND RZ C TO       DP078440
                                *                                                 "FORM SIN OF ANGLE BETWEEN CRAFT   DP078450
 4789      60           159D  F05C1FB2                FET       5,,RZ_C         "AND MOVING DESTINATION            DP078460
                                *                                                 "THE SIN WILL BE PLUS IF THE       DP078470
                                *                                                 "DEST IS MOVING TOWARDS THE CRAFT  DP078480
                                *                                                 "OTHERWISE IT WILL BE MINUS        DP078490
                                *                                                 "CL1 = SIN(GAMMA) = R1 . RZ C      *I078500
 4790      68   *       159F  F80D1728                BSV       REGISTER_DOT    "                  SCALED B2       DP078510
 4791      72           15A1  8C00                    ADDD      0,0             CL1 B2                             DP078520
 4792      102          15A2  F05C1F69                FET       5,,RIJ          "READ VECTORS R1 AND RZ POS TO     DP078530
                                *                                                 "FORM COS OF ANGLE BETWEEN CRAFT   DP078540
 4793      132          15A4  F05C1FB8                FET       5,,RZ_POS       "AND MOVING DESTINATION            DP078550
                                *                                                 "BL1 = COS(GAMMA) = R1 . RZ POS    *I078560
 4794      140  *       15A6  F80D1728                BSV       REGISTER_DOT     "                 SCALED B2       DP078570
 4795      152          15A8  C033                    FET       3,3             REPEAT CL1, BL1                    DP078580
 4796      168          15A9  6800                    MPYD      0,0             "COMPUTE (BL1**2 + CL1**2)**.5     DP078590
 4797      184          15AA  6822                    MPYD      2,2             "         FOR F(T) COMPUTATION     DP078600
 4798      188          15AB  8C20                    ADDD      2,0                                                DP078610
 4799      198          15AC  0710                    PRN       1                                                  DP078620
 4800      644          15AD  1001                    SQRT      1               (CL1**2 + BL1**2)**.5     B2       DP078630
 4801      656          15AE  C035                    FET       3,5             "COMPUTE GAMMA = ATAN (CL1/BL1)    DP078640
 4802      1194         15AF  1800                    ATAN      0               "         FOR F(T) COMPUTATION     DP078650
 4803      1206         15B0  86BE    (00BE)          FETD      0,,VC2          FT/SEC B12                         DP078660
 4804      1214 *       15B1  F80D1751                BSV       MAKE_VELOCITY    "COMPUTE CRAFT GROUND SPEED (GS)  DP078670
 4805      1228         15B3  F80C1F69                FETD      0,,R11          "CRAFT RATE = GS/EARTH RADIUS      DP078680
 4806      1244         15B5  6800                    MPYD      0,0             "WHERE ER = RHO(1 - K*R11**2)      DP078690
 4807      1264         15B6  F8061AD4                MPYD      0,,=DF(((-3.36D-5)*20.926428D6)/1B24)              DP078700
 4808      1274         15B8  FC0B1AD6                ADDD      0,,=DF((20.926428D6)/1B26)                         DP078710
 4309      1400         15BA  DC20                    DIVD      2,0             A/C RATE RAD/SEC B-14              DP078720
 4810      1410         15BB  FC0A1FF2                CLAD      0,,RZ_RATE                                         DP078730
 4811      1424         15BD  F80C1AD8                FETD      0,,=DF(((5)*3600)/3.14159265B14) "SET FIRST GUES$S078740
                                *                                                 "T(0) = 5 HOURS                    DP078750
 4812      1432         15BF  8410                    FETM      1,,0                                               DP078760
```

```
4813   1434          15C0  9880                    COMM    8,,0          ALPHA                                  DP078770
                                                   *                     "IS THE DEST                           *2078780
4814   1438          15C1  D058  (15CA)             BRL     $10           "MOVING AWAY FROM THE CRAFT?           DP078790
                                                   *                     "(GAMMA MINUS)                         DP078800
4815     4R          15C2  AC08                    CLAD    0,8                                                  DP078810
4816     8           15C3  8804                    COMD    0,4                                                  DP078820
4817    12           15C4  D025  (15CA)             BGE     $10            CHECK FOR OVERFLOW                    % 078830
4818   126R          15C5  DC04                    DIVD    0,4           "COMPUTE TIME FOR DEST TO ARRIVE       DP078840
                                                   *                     "AT CRAFT IF IT WAS HEADING AT         DP078850
4819   130           15C6  8802                    COMD    0,2           "THE CRAFTS CURRENT POSITION           DP078860
                                                   *                     "IS THE TIME TO                        *1078870
4820   134           15C7  D022  (15CA)             BGE     $10           "ARRIVE MORE THEN T(0)?  (5 HR)        DP078880
4821     2R          15C8  DE00                    FLG     A             "SET T(0) = TIME TO ARRIVE             DP078890
                                                   *                     "                                      DP078900
                                                   *                     "SET PROGRAM FLAG A TRUE FOR           DP078910
                                                   *                     "LATER FIXUP OF DELTA T IF THIS        DP078920
                                                   *                     "NEW T(0) IS TOO LARGE                 DP078930
                                                   *                     "                                      DP078940
                                                   *                     "THIS PATH IS NECESSARY TO INSUREDP078950
                                                   *                     "THAT THE INTERCEPT POINT WILL         DP078960
                                                   *                     "OCCUR BETWEEN THE DEST AND THE        DP078970
                                                   *                     "CRAFT AND NOT AFTER THE DEST          DP078980
4822     6           15C9  AC20                    CLAD    2,0           "HAS PASSED THE CRAFT                  DP078990
4823    10R          15CA  FC0A1ADA        $10     CLAD    0,,=DF(((10)*3600)/3.141592658 14) 10 HR             DP079000
4824    14           15CC  B802                    SUBD    0,2           "SET DELTA T = 10 HOUR - T(0)          DP079010
                                                   *         R0,1  =  DELTA T   SECONDS AT PI B14                 DP079020
                                                   *         R2,3  =        T   SECONDS AT PI B14                 DP079030
                                                   *         R4,5  =  RZ RATE   RAD / SEC B-14                    DP079040
                                                   *         R6,7  =  A/C RATE  RAD / SEC B-14                    DP079050
                                                   *         R8,9  =  ATAN (CL1/BL1) RAD AT PI                    DP079060
                                                   *         RA,B  =  SQRT (BL1**2 + CL1**2) AT B2                DP079070
                                                   *         RC,D  =  BL1  B2                                     DP079080
                                                   *         (RF,RF+1) = CL1 B2                                   DP079090
                                                   *                                                              DP079100
4825    10R          15CD  F8044000        $1      RSAD    0,,1          "REDUCE DELTA T BY HALF FOR USE        DP079110
4826    18           15CF  C015                    FET     1,5           "AT THE END OF THIS ITERATION          DP079120
4827    34           15D0  6804                    MPYD    0,4           "COMPUTE F(T)"                         DP079130
4828    38           15D1  B80A                    SUBD    0,10          "= ((BL1**2 + CL1**2)**.5)*            DP079140
4829    46  *        15D2  F80D1655                BSV     COS                                                  % 079150
4830    62           15D4  680C                    MPYD    0,12          "  COS((RZ RATE)*T(0) - GAMMA)         DP079160
4831    68           15D5  4C04                    LSAD    0,,2          "  - COS((CRAFT RATE)*T(0))            DP079170
4832    76           15D6  C019                    FET     1,9           A/C RATE                               DP079180
4833    92           15D7  6806                    MPYD    0,6           T                                      DP079190
```

```
4834  100  *   15D8  F80D1655                BSV   COS                                  % 079200
4835  104      15DA  8820                    SUBD  2,0          F(T)                    DP079210
                                 *                              "IS F(T) NEGATIVE       *2079220
4836  108      15DB  D056   (15E2)           BRL   $2           "(INDICATING THAT T(0) SHOULD BE DP079230
                                 *                              "LARGER)?               DP079240
4837   4R      15DC  D093   (15E0)           BAF   $11          "IS PROGRAM FLAG A TRUE?  %R079250
4838   4R      15DD  AC46                    CLAD  4,6          "SPECIAL FIXUP OF DELTA T" DP079260
4839  14       15DE  F8444000                RSAD  4,,1         "DELTA T = T(0)/2        DP079270
4840   4R      15E0  8864           $11      SUBD  6,4          "NEW T = T - DELTA T     DP079280
4841   8       15E1  D001   (15E3)           BUC   $3                                    DP079290
4842   4R      15E2  8C64           $2       ADDD  6,4          "NEW T = T + DELTA T     DP079300
4843   2R      15E3  DE8C           $3       FLG   AT+EOR+A     "RESET PROGRAM FLAG A    DP079310
4844  16       15E4  D730                    PRN   3                                     DP079320
4845  26       15E5  F8081ADC                CGMD  0,,=DF((1)/3.14159265814) 1 SEC      DP079330
                                 *                              "ARE MORE ITERA-        *2079340
4846  30       15E7  D038   (15CD)           BRG   $1           "TIONS NEEDED? (DELTA T GREATER DP079350
                                 *                              "THEN 1 SECOND)         DP079360
4847  12R      15E8  F8271FD8                STAD  2,,RZ_TIME   "THE TIME TO INTERCEPT IS NOW DP079370
                                 *                              "AVAILABLE              DP079380
4848  28       15EA  6842                    MPYD  4,2          "COMPUTE ANGLE THAT DESTINATION DP079390
                                 *                              "WILL MOVE THROUGH DURING TIME T DP079400
4849  38       15EB  7A4F                    STAD  I4,15        "ANGLE = RZ RATE * T     DP079410
4850  72       15EC  D7D0                    PRN   13           GET RID OF SOME REGISTERS DP079420
4851  506      15ED  1400                    SINCOS 0                                    DP079430
4852  526      15EE  8474                    FETM  7,,4                                  DP079440
4853  528      15EF  90F6                    SUBM  15,,6                                 DP079450
4854  10R      15F0  FD6A1FB2         $20      CLAD  X6,,RZ_C     "COMPUTE POSITION OF INTERCEPT BYDP079460
4855  14       15F2  AC20                    CLAD  2,0          "ROTATING RZ POS THROUGH ANGLE DP079470
4856  30       15F3  682A                    MPYD  2,10         "INTERCEPT VECTOR = (RZ POS)*COS DP079480
4857  36       15F4  4C22                    LSAD  2,,1         "                 + (RZ C)*SIN DP079490
4858  46       15F5  FD6A1FB8                CLAD  X6,,RZ_POS                            DP079500
4859  62       15F7  6808                    MPYD  0,8          COS                      DP079510
4860  66       15F8  BC02                    ADDD  0,2                                   DP079520
4861  72       15F9  4C02                    LSAD  0,,1                                  DP079530
4862  82       15FA  7B6F                    STAD  IX6,15       INTERCEPT POS            DP079540
                                 *                              "HAVE ALL THREE         *2079550
4863  90       15FB  CC6C   (15F0)           BXUD  6,,$20       "ELEMENTS OF THE VECTOR BEEN %R079560
                                 *                              "COMPUTED?              DP079570
4864   2R      15FC  A40F                    CLA   0,15                                  % 079580
                                 *                              "CONVERT INTERCEPT POSITION *I079590
4865  10  *    15FD  F80D14A7                BSV   MAKE_LAT_LONG  "VECTOR TO LATITUDE / LONGITUDE DP079600
4866  22       15FF  F8071FF6                STAD  0,,INTERCEPT_LAT "SAVE INTERCEPT POSITION FOR DP079610
4867  34       1601  F8271FDC                STAD  2,,INTERCEPT_LONG "DISPLAY WITH OTHER FIXED  DP079620
```

```
4868    46    1603  D720          PRN      2       EVEN UP F      DP079630
4869    84    1604  D506          BBK      13,6    "DESTINATIONS  DP079640
```

```
                                **                                                                  PB079650
                                *                    BEARING SUBROUTINE                             PB079660
                                *                                                                   PB079670
                                * ENTER WITH ADDRESS OF R2 IN R0 AND ADDRESS OF D IN R1.  THE ROUTINE PB079680
                                * WILL COMPUTE - ARCTAN (-D.R3, D.R2) AND LEAVE IT IN R0, R1        PB079690
                                *                      BEARING                                      *H079700
                                *                                                                   *H079710
                                * THIS ROUTINE WILL COMPUTE THE ANGLE BETWEEN THE R3 AXIS AND A VECTOR *H079720
                                * IN THE PLANE OF R2,R3 POINTING AT A FIXED POSITION.  THE ARGUMENTS *H079730
                                * CONSIST OF A POINTER TO THE R2 VECTOR OF THE RIJ MATRIX AND A POINTER *H079740
                                * TO A VECTOR THAT DEFINES THE FIXED POSITION.                       *H079750
                                *                                                                   *H079760
                                *                                                                   PB079770
4870          8R    1605 8506   BEARING  FETM   X0,,6      ADDRESS OF R3                            PB079780
4871          28    1606 8474            FETM   7,,4      "COMPUTE BEARING                         PB079790
4872          8R    1607 AF68   $1       CLAD   IX6,8                                              % 079800
4873          26    1608 6B6A            MPYD   IX6,10     "                                        PB079810
4874          30    1609 BC20            ADDD   2,0        D.R3                                     PB079820
4875          38    160A AF69            CLAD   IX6,9      "= - ARCTAN - (D . R2) / (D . R3)        PB079830
4876          56    160B 6B6A            MPYD   IX6,10     "                                        PB079840
4877          60    160C BC40            ADDD   4,0        D.R2                                     PB079850
4878          68    160D CC67   (1607)    BXUD   6,,$1                                             % 079860
4879          10R   160E D710            PRN    1          "                  SCALED PI             PB079870
4880          14    160F A822            CLSD   2,2        -D.R3                                    PB079880
4881          552   1610 1800            ATAN   0,0                                                 PB079890
4882          556   1611 A850            CLSD   5,0        - ANGLE                                  PB079900
4883          576   1612 D540            BBK    4                                                   PB079910
```

```
                                **
                                *   CORRECT TIME ENTRY TO CLOSEST SYNC TIME MOD 10 SECONDS                          079920
                                *                                                                                   079930
                                CALC_TIME_CORRECTION:                                                               079940
4884                                                                                                                079950
4884        30R     1613  F05C00C6          FET     5,,GMT          GMT PLUS 4 REGISTERS                          079960
4885        38      1615  92BC   (00BC)     SUBD    0,,TIME                                                       079970
4886        46      1616  9688   (0088)     ADDD    0,,START_SYNC_TIME R0 IS GMT SINCE SYNC                       079980
4887        56      1617  FC081785          ADDD    0,,LEAP_SECOND                                                079990
4888        60      1619  AC40              CLAD    4,0             SAVE GMT SYNC SYNC                          1079990
4889        70      161A  FC2A1ADE          CLAD    2,,=DF((.005)/10)                                             080000
4890        86      161C  6802              MPYD    0,2             RESCALE TO  10 SECONDS AT 831               3080010
4891       212      161D  DC02              DIVD    0,2             IN ORDER TO ROUND                           4080020
4892       216      161E  B804              SUBD    0,4             CORR TO GMT                                 5080030
4893       220      161F  AC40              CLAD    4,0                                                         6080040
4894       228      1620  96C6   (00C6)     ADDD    0,,GMT                                                      7080050
4895       238      1621  7846   (00C6)     STAD    0,,GMT                                                      8080060
4896       258      1622  F84600E7          MPYD    4,,=DF((((50-3831)/24)/3600)/1811)                          9080070
4897       268      1624  FC4800C4          ADDD    4,,DAY_SINCE_JAN1_1972                                     10080080
4898       280      1626  F84700C4          STAD    4,,DAY_SINCE_JAN1_1972                                     11080090
4899       302      1628  D550              BBK     5                                                          12080100
```

```
                                                                                                                    080110
                **                                                                                                  080110
                *                                SQUARE ROOT                                                        *H080120
                *                                                                                                   *H080130
                * THIS ROUTINE WILL TAKE THE SQUARE ROOT OF THE ARGUMENT.  A NEGATIVE                               *H080140
                * ARGUMENT WILL RESULT IN AN ANSWER THAT IS THE INITIAL ARGUMENT NORMA-                             *H080150
                * LIZED.  A ZERO ARGUMENT WILL GIVE A ZERO RESULT.                                                 *H080160
                *                                                                                                   *H080170
                *   INCLUDE TABLE OF ASCENDING POWERS OF TWO LABELED POWERS_OF_TWO                                   080180
                *    DOUBLE PRECISION SQUARE ROOT                                                                   080190
                *   ARGUMENT IN R0,1.  RESULT IN R0,1.                                                              080200
                *   TIME IN MICROSECONDS:                                                                           080210
                *       296 + 4N IF N IS ODD  (1 THROUGH 31)                                                        080220
                *       318 + 4N IF N IS EVEN (2 THROUGH 30)                                                        080230
                *        54      IF N IS 32   (ARGUMENT ZERO)                                                       080240
                *   WHERE N IS THE NUMBER OF LEADING ZEROS IN THE ARGUMENT                                          080250
4900      4R    1629 FC09001F   SQUARE_ROOT CLAM     0,,31                                                        080260
4901     136    1628 DD10                   NMLD     1,0          "NORMALIZE ARGUMENT (G)                         080270
                *                                                 "COMPUTE N = 31 - NUMBER OF LEFT                080280
4902     146    162C C023                   FET      2,3          "SHIFTS NECESSARY TO NORMALIZE                  080290
                *                                                 "IS THE ARGUMENT                                *I080300
4903     150    162D D14E   (164C)          BLE      $2           "EQUAL TO ZERO OR NEGATIVE?                     080310
4904      6R    162E F004E5D6               MPYM     0,,F(-.204406) "OBTAIN FIRST APPROXIMATION FOR               080320
4905      10    1630 F40971F2               ADDM     0,,F(+.890194) "NEWTON'S FORMULA                             080330
4906      16    1632 6004                   MPY      0,4          "                                               080340
4907      20    1633 F4092823               ADDM     0,,F(+.313567) "X(0) = A + (B - C*G)*G                       080350
4908      22    1635 A424                   CLA      2,4          USE NEWTON'S ALGORITHM                          080360
4909      24    1636 8020                   COM      2,0                                                          080370
4910      28    1637 D042   (163A)          BLE      $3           "IS THE ARGUMENT GREATER THAN X?                %R080380
4911      4R    1638 F4090015               ADDM     0,,21        "ADJUST X(C) BY ADDING K TO                     080390
                *                                                 "PREVENT POSSIBLE UNDERFLOW                     080400
4912     32R    163A D420                   $3       DIV      2,0          "FIRST ITERATION"                       080410
4913      34    163B B402                   ADD      0,2          "                                               080420
4914      42    163C 5263   (00E3)          MPLM     I0,,HX4000   "X(1) = (X(0) + G/X(0))/2                     080430
4915     168    163D DC40                   DIVD     4,0          "SECOND ITERATION"                              %S080440
4916     172    163E BC04                   ADDD     0,4          "                                               080450
4917     184    163F 5A63   (00E3)          MPLDM    I0,,HX4000   "X(2) = (G/X(1) + G)/2                        080460
                * CORRECT FOR NORMALIZATION                                                                         *H080470
4918     190    1640 F4358000               LSE      3,,15        "COMPUTE N/2 (TRUNCATED)                        080480
4919     194    1642 D054   (1647)          BRL      $1           "WAS N ODD?"                                    %R080490
4920      20R   1643 F8061640               MPYD     0,,$4        "MODIFY X(2) BY SQUARE ROOT OF 2                080500
4921      24    1645 F4398000               ADDM     3,,X(8000)   "TO START NORMALIZATION FIX                    080510
4922      4R    1647 F43980D5   $1          ADDM     3,,POWERS_OF_TWO+X(8000)                                     080520
4923      10    1649 A633                   CLA      I3,3         "MULTIPLY X(2) BY 2**(-N/2)                     080530
```

```
4924    20      164A  5930                MPLDM   X3,0          "TO GET FINAL RESULT      080540
4925    24      164B  AC40                CLAD    4,0                                     080550
4926    18R     164C  0530          $2    BBK     3             "EXIT"                    080560
4927            164D  5A82799A      $4    COND    F(.70710678121)    (SQUARE ROOT OF .5)  080570
```

```
                                                                                                                    080580
                                **                                                                                  080580
                                *                          SINE - COSINE                                           *H080590
                                *                                                                                  *H080600
                                * THIS SUBROUTINE WILL COMPUTE THE SIN AND COS OF ANY ANGLE SCALED PI               *H080610
                                * THE OUTPUTS ARE SCALED B1.  IT HAS SEPARATE ENTRIES FOR SIN OR COS               *H080620
                                * ONLY.                                                                            *H080630
                                *                                                                                  *H080640
                                * ENTER WITH ANGLE X SCALED PI IN R0,1                                              080650
                                * RETURN WITH SINE IN R2,3 AND COSINE IN R0,1 (2 REGISTERS ADDED)                   080660
                                *   MAXIMUM TIME IN MICROSECONDS:                                                  080670
                                *       SIN 188,  COS 192, SIN_COS 414.                                            080680
4928     8R        164F  D700   SC_ENTRY     PRN         0              "COPY THE ANGLE X TO SAVE FOR COS          080690
4929     12R       1650  C031   SIN_COS      FET         3,1                                                      % 080700
                                *                                       "USE THE SEPARATE ENTRY TO                 *I080710
4930     20  *     1651  F8001656           BSV         SIN            "COMPUTE THE SIN FIRST                      080720
4931     24        1653  AC40               CLAD        4,0            "SAVE THE SIN                               080730
                                *                                       "FALL INTO THE SEPARATE COS ENTRY          080740
4932     34        1654  0710               PRN         1              "AND THEN RETURN                            080750
                                * SINGLE FUNCTION ENTRIES                                                          080760
                                * FOR EITHER ENTRY, THE RESULT REPLACES X IN R0,1                                   080770
                                * ENTER HERE FOR COS ONLY                                                          *H080780
4933     6R        1655  9663   (00E3) COS          ADD         0,,HX4000      "FORM X + PI/2 SINCE                080790
                                *                                       "       COS X = SIN X + PI/2                080800
                                * ENTER HERE FOR SIN ONLY                                                          *H080810
4934     16R       1656  F4481670     SIN          FETM        4,,$5          "READ POINTER TO S COEFFICIENTS     080820
4935     20        1658  AC25               CLAD        2,5            "COMPUTE 2X     (= Y IF 1ST OR              080830
4936     24        1659  BC22               ADDD        2,2            "4TH QUADRANT)                              080840
                                *                                       "WAS X IN THE 2ND                          *1080850
4937     28        165A  D071   (165C)      BND         $1             "OR 3RD QUADRANTS?"                        %R080860
4938     4R        1658  A822               CLSD        2,2            "COMPLIMENT RESULT   2(1- X) = Y            080870
                                *                                       "IF X IN 2ND OR  -2(1 + X) = Y              080880
                                *                                       "IF X IN 3RD QUADRANT                       080890
4939     4R        165C  F82948CF     $1           COMM        2,,F((+62)/109) "CHECK Y TO DETERMINE WHICH        080900
4940     8         165E  D033   (1662)      BRG         $2                                                       % 080910
4941     4R        165F  F8298731           COMM        2,,F((-62)/109) "SERIES TO USE                              080920
                                *                                       "IS Y OUTSIDE THE                          *1080930
4942     8         1661  D023   (1665)      BGE         $3             "RANGE OF +62/109 TO -62/109?              %R080940
4943     2R        1662  944A     $2           ADDM        4,,$6-$5       "CHANGE POINTER TO POINT TO THE              080950
4944     6         1663  BC22               ADDD        2,2            "C COEFFICIENTS                             080960
                                *                                       "COMPUTE Z = 1 - ABSOLUTE Y                 080970
4945     10        1664  D001   (1666)      BUC         $4             "RESCALED BY 2                              080980
4946     4R        1665  AC52     $3           CLAD        5,2            "SAVE Y FOR FINAL MULTIPLY IN               080990
                                *                                       "THE S SERIES                               081000
```

```
4947    16R     1666  6822          $4      MPYD    2,2          "COMPUTE POWER SERIES"                  081010
4948    20      1667  AC02                  CLAD    0,2          "IN X**2 OR Z**2                        081020
4949    38      1668  6940                  MPYD    X4,,0        "                                       081030
4950    46      1669  BD42                  ADDD    X4,,2        "((S7X**2 + S5)X**2 + S3)X**2 +S1       081040
4951    62      166A  6802                  MPYD    0,2          "          OR                           081050
4952    70      1668  BD44                  ADDD    X4,,4        "((C7Z**2 + C5)Z**2 + C3)Z**2 +C1       081060
4953    86      166C  6802                  MPYD    0,2                                                  081070
4954    94      166D  BD46                  ADDD    X4,,6                                                081080
4955    100     166E  05400008              BUC     X4,,8        "EXIT TO S END OR C END                 081090
4956          1670  FF84FDE4      $5      COND    F(-.002289069985)  C7                                  081100
4957          1672  051$5681              COND    F(+.039835751436)  C5 SINE                            081110
4958          1674  D6A88C08              COND    F(-.322981354578)  C3 COEFFICIENTS                    081120
4959          1676  6487ED41              COND    F(+.785398156180)  C1                                  081130
4960    16R     1678  6850                  MPYD    5,0          "S END"                                 081140
4961    36      1679  D540                  BBK     4            "SIN X = Y * (SERIES)                   081150
4962          167A  FFFABF46      $6      COND    F(-.000160303804)  C6                                  081160
4963          167C  0103B73E              COND    F(+.007925896961)  C4 COSINE                          081170
4964          167E  EC42C4DA              COND    F(-.154212373234)  C2 COEFFICIENTS                    081180
4965          1680  3FFFFFF5              COND    F(+.499999995214)  C0                                  081190
4966    2R      1682  9850                  COMM    5,,0         "C END"                                 081200
                                    *                            "ABSOLUTE SIN X = (SERIES)              081210
4967    6       1683  D022   (1686)        BGE     $7           "IS X POSITIVE?"                        081220
4968    4R      1684  A850                  CLSD    5,0          "SIN X = - (SERIES)                     081230
4969    24      1685  D540                  BBK     4                                                    081240
4970    4R      1686  AC50          $7      CLAD    5,0          "SIN X = (SERIES)                       081250
4971    24      1687  D540                  BBK     4                                                    081260
```

```
                                                                                                                    081270
                                                                                                                   *H081280
                                                                                                                   *H081290
                                                                                                                   *H081300
                                                                                                                   *H081310
                                                                                                                   *H081320
                                                                                                                   *H081330
                                                                                                                    081340
                                                                                                                    081350
                                                                                                                    081360
                                                                                                                    081370
4972      8R    1688  D700          ATAN_ENTRY  PRN       0              "ADJUST R15 STACK                        081380
                                    * ENTER HERE WHEN NOT USING PIN ENTRY                                         *H081390
4973     10R    1689  F8044000      ARCTAN      RSAD      0,,1           HALVE COS                                081400
4974     12     168B  DE52                      FLG       5,2            "PUT THE SIGN OF THE COS AND SIN         081410
                                                                          "INTO PROGRAM FLAGS C AND D RE-          081420
                                                                          "SPECTFULLY (FLAG TRUE IF MINUS)         081430
                                                                          "                                        081440
                                                                          "COMPUTE ABSOLUTE VALUE OF SIN/2         081450
                                                                          "AND COS/2                               081460
                                                                          "                                        081470
                                                                          "READ POINTER TO COEFFICIENTS            081480
                                                                          "AND SET UP TERM COUNT                   081490
4975     16     168C  D021  (168E)              BGE       $1                                                    % 081500
4976      4R    168D  A800                      CLSD      0,0            TAKE MAGNITUDE                           081510
4977     12R    168E  F42816CE      $1          FETM      2,,ATC                                                % 081520
4978     14     1690  9C0C                      CLAM      0,,ATC1-ATC                                              081530
4979     22     1691  C016                      FET       1,6                                                      081540
4980     32     1692  F8044000                  RSAD      0,,1           HALVE SINE                               081550
4981     34     1694  DE53                      FLG       5,3            SET D IF .LT.                            081560
4982     38     1695  D021  (1697)              BGE       $2                                                    % 081570
4983      4R    1696  A800                      CLSD      0,0            TAKE MAGNITUDE                           081580
4984      4R    1697  AC70          $2          CLAD      7,0                                                   % 081590
4985      8     1698  B875                      SUBD      7,5            "COMPUTE X = (S - C) / (S + C)          %S081600
4986     12     1699  BC05                      ADDD      0,5            "  WHERE S AND C BOTH POSITIVE           081610
4987    138     169A  DC70                      DIVD      7,0            "                                        081620
4988    142     169B  AC57                      CLAD      5,7            "  Z = X**2                              081630
4989    158     169C  6855                      MPYD      5,5            Z=X**2                                   081640
4990    166     169D  AD4E                      CLAD      X4,,ATC2-ATC                                             081650
4991     16R    169E  6805          $3          MPYD      0,5                                                   % 081660
                                                                          "COMPUTE SERIES"                         081670
                                                                          "                                        081680
                                                                          "=(((((((T7Z +T6)Z + T5)Z + T4)Z         081690
```

```
                                    *                                                  "  + T3)Z + T2)Z + T1)Z + T0)X      081700
4992    24      169F  BF24                        ADDD    IX2,4                                                       081710
4993    32      16A0  CC23    (169E)              BXUD    2,,$3                                                    % 081720
4994    16R     16A1  6807                        MPYD    0,7               FINISH ODD SERIES IN X                    081730
4995    18      16A2  DEEE                        FLG     14,14             "SET FLAG C TRUE IF SIN OR COS          %S081740
                                    *                                       "ARE MINUS BUT NOT BOTH MINUS             081750
                                    *                                       "(FLAC C .EOR. FLAG D)                    081760
                                    *                                       "IS THE PRODUCT                         *1081770
4996    22      16A3  D0D1    (16A5)              BCF     $4                "OF THE 'SIGN'S' NEGATIVE?              %R081780
4997     4R     16A4  A800                        CLSD    0,0               "FORM - (SERIES)                          081790
4998     6R     16A5  4022                  $4    ROF     2,,2              "USE FLAGS D AND C +45 DEGREES TO         081800
4999    10      16A6  F4244000                    LSA     2,,14             "FIX THE QUADRANT                         081810
5000    16      16A8  F5292000                    ADDM    X2,,F(.25)        "D TRUE = 180, C TRUE = 90 DEG            081820
5001    20      16AA  AC70                        CLAD    7,0               MOVE ANSWER                               081830
5002    44      16AB  D560                        BBK     6                 PRUNE SEVEN AND RETURN                    081840
```

```
                                                **                                                    081850
                                                *                                                     081860
5003                                            NORTH_MAGNETIC_POLE_VECTOR;                           PP081870
5003                    16AC  78A3                      CON     F(.9659)                              PP081880
5004                    16AD  0094                      CON     F(.004529)                            PP081890
5005                    16AE  DEE0                      CON     F(-.2588)                             PP081900
                                                *                                                     081910
5006                    16AF  7478              ALPHA_0 CON     F(.91)          10.2                  PP081920
5007                    16B0  7852                      CON     F(.94)          13.6                  PP081930
5008                    16B1  7666                      CON     F(.925)         11.3                  PP081940
                                                *                                                     081950
5009                                            LAMBDA_TABLE;                                         CF081960
5009                    16B2  361D3851                  COND    F((217.021)*.99748-9)       10.2      CF081970
5010                    16B4  4826F9C1                  COND    F((((217.021)*.99748-9)*4)/3) 13.6    CF081980
5011                    16B6  3C207ACC                  COND    F((((217.021)*.99748-9)*10)/9) 11.3   CF081990
                                                *                                                     082000
                                                *                                                     082010
                                                *                       ARCSINE                       *H082020
                                                *                                                     *H082030
                                                * THIS ROUTINE WILL COMPUTE AN ANGLE SCALED PI FROM A SINE ARGUMENT (B1)*H082040
                                                *                                                     *H082050
                                                *   REQUIRES SQUARE ROOT AND ARCTAN ROUTINES          082060
                                                *       ENTER WITH SINE SCALED 2 IN R0,1              082070
                                                *       RETURN WITH ANGLE SCALED PI IN R0,1 (SAME SIGN) 082080
5012          8R        16B8  C011              ARCSIN  FET     1,1     "COMPUTE COS"                 082090
5013          12        16B9  A800                      CLSD    0,0     "= (1 - SIN**2)**.5           082100
5014          28        16BA  6802                      MPYD    0,2     "                             082110
5015          34        16BB  9662    (00E2)            ADD     0,,HX2000 "SET COS = 0 IF SIN MORE THAN 1 082120
5016          38        16BC  D021    (16BE)            BGE     $1      "                             % 082130
5017          4R        16BD  8800                      SUBD    0,0      GREATER THAN ONE             082140
5018          446R      16BE  1000              $1      SQRT    0,0     "                             % 082150
                                                *                       "COMPUTE ANGLE"               %S082160
                                                *                       "= ARCTAN SIN/COS             082170
                                                *                       "                             082180
5019          452       16BF  04001689                  28UC    ARCTAN  "(EXIT ASIN FROM ARCTAN)      082190
                                                *                                                     082200
                                                *                                                     082210
                                                *   CUMULATIVE DAYS BY MONTH                          DP082220
5020                                            DAYS_BY_MONTH;                                        DP082230
5020                    16C1  0000                      CON     0       JAN                           DP082240
5021                    16C2  001F                      CON     31      FEB                           DP082250
5022                    16C3  0038                      CON     59      MAR                           DP082260
5023                    16C4  005A                      CON     90      APR                           DP082270
```

```
5024  16C5  0078                CON   120          MAY                        DP082280
5025  16C6  0097                CON   151          JUN                        DP082290
5026  16C7  00B5                CON   181          JUL                        DP082300
5027  16C8  00D4                CON   212          AUG                        DP082310
5028  16C9  00F3                CON   243          SEP                        DP082320
5029  16CA  0111                CON   273          OCT                        DP082330
5030  16CB  0130                CON   304          NOV                        DP082340
5031  16CC  014E                CON   334          DEC                        DP082350
5032  16CD  016D                CON   365          JAN (NEXT YEAR)            DP082360
                          *                                                   DP082370
                          *  CONSTANTS FOR ARCTAN                             082380
5033  16CE  28BE6096    ATC     COND  F(+.318309854667)                        082390
5034  16D0  F26B58E6            COND  F(-.106099021806)                        082400
5035  16D2  0822EAF2            COND  F(+.063565605401)                        082410
5036  16D4  FA498711            COND  F(-.044625936711)                        082420
5037  16D6  040A1927            COND  F(+.031558174030)                        082430
5038  16D8  FD9388D0            COND  F(-.018935106721)                        082440
5039  16DA  00FCF634    ATC1    COND  F(+.007719779427)                        082450
5040  16DC  FFCF0C20    ATC2    COND  F(-.001493916081)                        082460
                          *                                                   082470
5041                      SYNC_LIMIT_TABLE;                                   SY082480
5041  16DE  0000                CON   0                                       SY082490
5042  16DF  0008                CON   8                                       SY082500
5043  16E0  0016                CON   22                                      SY082510
5044  16E1  0009                CON   9                                       SY082520
5045  16E2  002E                CON   46                                      SY082530
5046  16E3  000A                CON   10                                      SY082540
5047  16E4  0048                CON   72                                      SY082550
5048  16E5  000B                CON   11                                      SY082560
5049  16E6  0064                CON   100                                     SY082570
5050  16E7  000A                CON   10                                      SY082580
5051  16E8  007E                CON   126                                     SY082590
5052  16E9  0008                CON   8                                       SY082600
5053  16EA  0094                CON   148                                     SY082610
5054  16EB  000B                CON   11                                      SY082620
5055  16EC  00B0                CON   176                                     SY082630
5056  16ED  0009                CON   9                                       SY082640
                          *                                                   SY082650
5057                      DIURNAL_CONSTANT_TABLE;                             PP082660
5057  16EE  2280                CON   F(.271)   IS=0   10.2                   PP082670
5058  16EF  1823                CON   F(.212)   IS=0   13.6                   PP082680
5059  16F0  1ED9                CON   F(.241)   IS=0   11.3                   PP082690
5060  16F1  2666                CON   F(.300)   IS=1   10.2                   PP082700
```

```
5061                16F2  1E56                CON     F(.237)          IS=1  13.6      PP082710
5062                16F3  224E                CON     F(.268)          IS=1  11.3      PP082720
5063                16F4  2B85                CON     F(.340)          IS=2  10.2      PP082730
5064                16F5  226F                CON     F(.269)          IS=2  13.6      PP082740
5065                16F6  26E9                CON     F(.304)          IS=2  11.3      PP082750
5066                16F7  1AE1                CON     F(.210)          IS=3  10.2      PP082760
5067                16F8  14BC                CON     F(.162)          IS=3  13.6      PP082770
5068                16F9  17CF                CON     F(.186)          IS=3  11.3      PP082780
5069                16FA  1E68                CON     F(.240)          IS=4  10.2      PP082790
5070                16FB  17F0                CON     F(.187)          IS=4  13.6      PP082800
5071                16FC  1864                CON     F(.214)          IS=4  11.3      PP082810
                    *                                                                  PP082820
5072                TF_SIGMA_SQ_DATA_ADDRESSES;                                        TF082830
5072                16FD  1DD3                CON     SIGMA_SQ_PHI_DOT_PHI_DOT         TF082840
5073                16FE  1E03                CON     SIGMA_SQ_PHI_PHI_DOT             TF082850
5074                16FF  1E33                CON     SIGMA_SQ_PHI_PHI                 TF082860
5075                1700  1D88                CON     SIGMA_SQ_N_COUNTER               TF082870
                    *                                                                    082880
5076                TF_PHI_DATA_ADDRESSES;                                             TF082890
5076                1701  0085                CON     TF_TEMP                          TF082900
5077                1702  1798                CON     STATION_VECTOR_TABLE             TF082910
5078                1703  1F69                CON     RIJ                              TF082920
5079                1704  1E63                CON     PHI_DOT_DR                       TF082930
5080                1705  1E73                CON     PHI_DOT_ESTIMATE                 TF082940
5081                1706  1EA3                CON     PHI_ESTIMATE                     TF082950
                    *                                                                    082960
                    *                       VECTOR BY MATRIX MULTIPLY                  *H082970
                    *                                                                  *H082980
                    * THIS ROUTINE MULTIPLIES A 3X3 MATRIX (R) BY A VECTOR U TO GET A NEW *H082990
                    * VECTOR X.  THE ARGUMENTS CONSIST OF POINTERS TO R, U AND X.       *H083000
                    *                                                                  *H083010
                    *   MATRIX 3 - MULTIPLY 3X3 MATRIX (POINTER IN R2) DOUBLE            083020
                    *                INTO 3-VECTOR     (POINTER IN R1) PRECISION         083030
                    *                  ANSWER TO       (POINTER IN R0) ARITHMETIC        083040
                    *       TIME: 362 MICROSECONDS                                     083050
                    *       ALL POINTERS PRUNED                                        083060
5082      16R       1707  8454    MATRIX_3D   FETM    5,,4          WORKING STORAGE (6)  083070
5083       8R       1708  AE28    $1          CLAD    I2,8                             $ 083080
5084       26       1709  6A27                MPYD    I2,7          *X = V*R           083090
5085       34       170A  AD82                CLAD    X8,,2         *                  083100
5086       52       1708  6972                MPYD    X7,,2         *X1 = SUM V(I)*R(I)1, I = 1 TO 3  083110
5087       56       170C  BC20                ADDD    2,0           *X2 = SUM V(I)*R(I)2, I = 1 TO 3  083120
5088       64       170D  AD84                CLAD    X8,,4         *X3 = SUM V(I)*R(I)3, I = 1 TO 3  083130
```

```
5089      82      170E  6574                    MPYD    X7,,4                          083140
5090      86      170F  BC02                    ADDD    0,2                            083150
5091      96      1710  7846                    STAD    IX4,6                          083160
5092      98      1711  9486                    ADDM    8,,6                           083170
5093     106      1712  CC48   (1708)           BXUD    4,,$1                        * 083180
5094      28R     1713  D580                    BBK     8                              083190
                                                                                       083200
                                *                                                      083210
                                *                    CROSS PRODUCT                     *H083210
                                *                                                      *H083220
                                * THIS ROUTINE COMPUTES THE CROSS PRODUCT OF TWO VECTORS U AND V *H083230
                                *                                                      *H083240
                                *   CROSS PRODUCT UXV IN R0 TO R5                      DP083250
                                *       U IN R0 TO R6                                  DP083260
                                *       V IN R8 TO R13                                 DP083270
                                REGISTER_CROSS;                                        DP083280
5095                                                                                   *H083290
5095      4R      1714  AC6C                    CLAD    6,12            "X = U X V     083300
5096      20      1715  6862                    MPYD    6,2             "              083310
5097      36      1716  6828                    MPYD    2,8             "X1 = U2*V3 - U3*V2 083320
5098      52      1717  6884                    MPYD    8,4             "X2 = U3*V1 - U1*V3 083330
5099      68      1718  684A                    MPYD    4,10            "X3 = U1*V2 - U2*V1 083340
5100      84      1719  68A0                    MPYD    10,0            U1V2           DP083350
5101     100      171A  680C                    MPYD    0,12            U1V3           DP083360
5102     104      171B  B864                    SUBD    6,4             X1=U2V3-U3V2   DP083370
5103     108      171C  B880                    SUBD    8,0             X2=U3V1-U1V3   DP083380
5104     112      171D  B8A2                    SUBD    10,2            X3=U1V2-U2V1   CI083390
5105     134      171E  D550                    BBK     5               PRUNE 5        CI083400
                                *                                                      083410
5106              171F  4000    RAT_TABLE       CON     F(18-1)         10.2           PP083420
5107              1720  5555                    CON     F((4)/381)      13.6           PP083430
5108              1721  471C                    CON     F((10)/981)     11.3           PP083440
                                *                                                      083450
                                *                                                      083460
5109              1722  12000000  V_LAMBDA      COND    X(12000000)     10.2D3(441D-6)/2**5 CF083470
5110              1724  18000000                COND    X(18000000)                    CF083480
5111              1726  14000000                COND    X(14000000)                    CF083490
                                *                                                      083500
                                *                    DOT PRODUCT                       *H083510
                                *                                                      *H083520
                                * THIS ROUTINE FORMS THE DOT PRODUCT OF THE TWO VECTORS U AND V *H083530
                                *                                                      *H083540
                                *   DOT PRODUCT: U.V IN R0,1.   10 REGISTERS PRUNED    DP083550
                                *       U  IN R0 TO R5                                 DP083560
                                *       V  IN R6 TO R11
```

```
                    REGISTER_DOT;                                                    DP083570
5112                                                                                 083580
5112      16R   1728  68A4          MPYD    10,4    "U . V = SUM U(I)*V(I), I=1 TO 3
5113      32    1729  6882          MPYD    8,2     22                              DP083590
5114      48    172A  6860          MPYD    6,0     11                              DP083600
5115      52    172B  BCA8          ADDD    10,8    33+22                           DP083610
5116      56    172C  BCA6          ADDD    10,6    33+22+11                        DP083620
5117      86    172D  D590          BBK     9       PRUNE 10                        DP083630
                *                                                                    083640
```

```
                                    **                                                                  EX083650
                                    *           OMEGA TASK                                              *H083660
                                    *                                                                   *H083670
                                    *  PIN ROUTINE TO SET UP THE ADDRESS AND TIME OF THE NEXT OMEGA TASK EX083680
                                    *           THE ROUTINE NUMBER MUST BE IN REGISTER 0                EX083690
                                    *           THE CURRENT TIME SHOULD BE IN REGISTERS 1 AND 2         EX083700
                                    *           ALL THREE REGISTERS ARE PRUNED OFF WITH THE BBK         EX083710
                                    * THIS PIN ROUTINE SELECTS THE NEXT OMEGA                           *H083720
                                    * TASK FROM A TABLE AND COMPUTES THE TIME                           *H083730
                                    * OF THE NEXT OMEGA TASK FROM THE TIME                              *H083740
                                    * INCREMENT IN THE TABLE                                           *H083750
                                    * THE ARGUMENTS CONSIST OF A POINTER TO                            *H083760
                                    * THE TABLE AND THE CURRENT REAL TIME                              *H083770
                                    *                                                                   EX083780
5118                                OMEGA_TASK_PIN;                                                     EX083790
5118      2R    172E  B400                      ADD     0,0          "READ THE TASK AND TIME INTERVAL EX083800
5119      16    172F  F90C02BF                  FETD    X0,,OMEGA_TASK_TABLE "FROM THE TASK TABLE    EX083810
5120      24    1731  7019   (0099)             STA     0,,OMEGA_TASK "SAVE THE ADDRESS OF THE NEXT  EX083820
                                    *                                 "OMEGA TASK FOR THE 5 MILLISEC  EX083830
                                    *                                 "INTERRUPT PROGRAM              EX083840
5121      26    1732  9C00                      CLAM    0,,0         "ADD TIME TO THE TIME INCREMENT  %S083850
5122      30    1733  BC03                      ADDD    0,3          "TO GET THE TIME OF THE NEXT    EX083860
5123      40    1734  7817   (0097)             STAD    0,,OMEGA_TIME "OMEGA TASK AND SAVE FOR THE 5 EX083870
                                    *                                 "MSEC INTERRUPT PROGRAM         EX083880
5124      44    1735  FC194000                  CLAM    1,,X(4000)   "USE PROGRAM FLAG C TO DEFINE    %S083890
                                    *                                 "RHO-RHO (C FALSE) OR PHASE     EX083900
                                    *                                 "DIFFERENCE (C TRUE) NAVIGATION EX083910
                                    *                                 "                               EX083920
                                    *                                 "--SUBMARINE ALWAYS OPERATES IN--EX083930
                                    *                                 "--PHASE DIFFERENCE NAVIGATION-- EX083940
                                    *                                 "                               EX083950
                                    *                                 "A MODE CHANGE CAN ONLY OCCUR   EX083960
                                    *                                 "FROM THE PROGRAM MONITOR UNIT  EX083970
                                    *                                 "                               EX083980
5125      50    1737  9E4A   (00CA)             CLA     0,,MODE      "SET UP MASK TO MAKE FLAG C FALSEEX083990
5126      54    1738  D011   (173A)             BNE     $1           "IS THE MODE SET FOR RHO-RHO?   EX084000
5127      2R    1739  A401                      CLA     0,1          *PHASE DIFFERENCE"              EX084010
                                    *                                 "SET UP MASK TO MAKE FLAG C TRUE EX084020
5128      12R   173A  E1E10000      $1          MRG     X14,1,0      "SET SELECTED STATE OF FLAG C IN EX084030
                                    *                                 "THE APPROPIATE BIT IN THE      EX084040
                                    *                                 "INDICATOR WORD OF THE R14      EX084050
                                    *                                 "SUBROUTINE RETURN PUSHDOWN STACKEX084060
                                    *                                 "AFTER EXITING THIS PIN ROUTINE EX084070
```

```
                                *                                    "WITH A BRANCH BACK FLAG C WILL   EX084080
                                *                                    "HAVE THE PROPER STATE            EX084090
5129        32      173C 0540                B8K       4                                             EX084100
                                *                                                                      EX084110
5130                173D 0F00   HX0F00       CON       X(0F00)                                        084120
                                *                                                                      084130
                                *                      POSITION VECTOR                                 *H084140
                                *                                                                      *H084150
                                * THIS ROUTINE COMPUTES A 3 ELEMENT POSITION VECTOR FROM LATITUDE AND   *H084160
                                * LONGITUDE ARGUMENTS                                                  *H084170
                                *                                                                      *H084180
                                *   GENERATE POSITION VECTOR FROM DESTINATION NUMBER (0 TO 9) IN R0     CI084190
                                *         REGISTERS MADE: SIN LAT, COS LAT.COS LONG, COS LAT.SIN LONG   CI084200
5131                            MAKE_DESTINATION_VECTOR,;                                              CI084210
5131        14R     173E F90C1FC4 PLOT1      2FETD     X0,,DESTINATION_LONGITUDE                      084220
5132        448     1740 1400                SINCOS    0,0                                            CI084230
5133        14R     1741 F94C1FDE PLOT6      2FETD     X4,,DESTINATION_LATITUDE                       % 084240
5134        448     1743 1400                SINCOS    0,0             "R1 = SIN(LAT)            B1   084250
5135        452     1744 BC00                ADDD      0,0             "R2 = COS(LAT) * COS(LONG) B1   084260
5136        468     1745 6860                MPYD      6,0             "R3 = COS(LAT) * SIN(LONG) B1   084270
5137        484     1746 6840                MPYD      4,0                                            CI084280
5138        498     1747 0510                B8K       1                                              CI084290
                                *                                                                      084300
                                *SUN CONSTANTS CALCULATED FOR JULIAN DAY NUMBER  2,44/,317.5           084310
                                *   JANUARY 1.0, 1972 @ 0000 HOURS GMT                                 084320
                                * K2 IS LONGITUDE OF MEAN SUN =       279.75764 DEGREES*PI/180          084330
5139                1748 C6F0   SUN_CONS     CON       F(((-2.)*3.14159+4.882691926)/3.14159)  K2     084340
                                *K1=2PI/NUMBER OF DAYS IN TROPICAL YEAR = 365.2421943 DAYS             084350
5140                1749 59873F77            COND      F((.017202791S)/3.141592658-7)          K1     084360
                                *K3=2PI/NUMBER OF DAYS IN ANOMALISTIC YEAR  = 365.2596435 DAYS         084370
5141                174B 59B62696            COND      F((.017201969T)/3.141592658-7)          K3     084380
                                * K5 =SIN(E)  E = OBLIQUITY OF ECLIPTIC = 23.44292452 DEGREES          084390
5142                174D 32EC                CON       F(0.397835337)                          K5     084400
                                *K4= MEAN ANOMALY = 357.29877 DEGREES*PI/180                           084410
5143                174E FE14                CON       F(((-2.)*3.1415+6.236039952)/3.14159)   K4     084420
                                *K6 =ECCENTRICITY OF ORBIT   0.01672087925*2                           084430
5144                174F 028A                CON       F((0.0334417585)/3.141598-1)            K6     084440
                                *K7 = TAN**2(E/2) *(-1)                                                084450
5145                1750 FC7E                CON       F((-.0430482519)/3.141598-1)            -K7    084460
                                *                                                                      084470
                                *                                                                      084480
                                *                      VELOCITY MAGNITUDE                              *H084490
                                *                                                                      *H084500
```

```
                                    * THIS ROUTINE COMPUTES THE MAGNITUDE OF THE TWO ELEMENT VELOCITY      #H084510
                                    * VECTOR ARGUMENTS                                                    #H084520
                                    *                                                                     #H084530
5146                                MAKE_VELOCITY;                                                        CI084540
5146      8R        1751  C012            FET       1,2       V2 IN R2  V3 IN R0                        CI084550
5147      10        1752  B011            SUB       1,1       " V (MAG) = (V2**2 + V3**2)**.5            084560
5148      12        1753  B033            SUB       3,3                                                 DP084570
5149      28        1754  6822            MPYD      2,2                                                 CI084580
5150      44        1755  6800            MPYD      0,0                                                 CI084590
5151      48        1756  BC02            ADDD      0,2                                                 CI084600
5152     494        1757  1000            SQRT      0,0                                                 CI084610
5153     498        1758  AC20            CLAD      2,0                                                 CI084620
5154     512        1759  D510            BBK       1                                                   CI084630
                                    *                                                                     084640
                                    *                                                                     084650
5155                                STATION_BURST_TIMES;                                                  SB084660
5155                1754  008C            CON       140       .7 SEC                                    SB084670
5156                175B  00A0            CON       160       .8 SEC                                    SB084680
5157                175C  00B4            CON       180       .9 SEC                                    SB084690
5158                175D  00C8            CON       200       1  SEC                                    SB084700
5159                175E  00B4            CON       180       .9 SEC                                    SB084710
5160                175F  008C            CON       140       .7 SEC                                    SB084720
5161                1760  00C8            CON       200       1  SEC                                    SB084730
5162                1761  00A0            CON       160       .8 SEC                                    SB084740
                                    *                                                                     084750
                                    *                         THETA BR IS THE CCW ANGLE FROM              ES084760
                                    *                         +A TO THE STATION                           ES084770
                                    *                         +A IS 135 DEG CCW FROM KEEL LINE            ES084780
                                    *                         +B IS 270 DEG CCW FROM +A                   ES084790
5163                                ANTENNA_SELECT_TABLE;     BEARING LIMITS FOR THETA BR                 ES084800
5163                1762  0001            CON       X(1)      +A                                        ES084810
5164                1763  0004            CON       X(4)      +B                                        ES084820
5165                1764  8001            CON       X(8001)   -A                                        ES084830
5166                1765  8004            CON       X(8004)   -B                                        ES084840
                                    *                                                                     ES084850
5167                                FLOATER_SELECT_TABLE;                                                 ES084860
5167                1766  0001            CON       X(0001)   A                                         ES084870
5168                1767  8001            CON       X(8001)   -A                                        ES084880
                                    *                                                                     084890
5169                                TF_LAMBDA_CONSTANT_TABLE;                                             TF084900
5169                1768  60000000        COND      F(.75)    10.2KC                                    TF084910
5170                176A  7FFFFFFF        COND      X(7FFFFFFF)  13.6KC                                 TF084920
5171                176C  6AAAAAAA        COND      F(.833333333)  11.3KC                               TF084930
```

```
                                        *                                                                                  084940
5172          176E  0007                HX0007      CON         X(0007)                                                  084950
                                        *                                                                                  084960
5173          176F  0004AC6A            DCAY_ONE    COND        F(((((207D-8)*.9974)*217.021)*1)/3.141593) 10.2 PP084970
5174          1771  0004AA7D                        COND        F(((((((155D-8)*.9974)*217.021)*4)/3)/3.141593) 1PP084980
5175          1773  0004A411                        COND        F(((((((185D-8)*.9974)*217.021)*10)/9)/3.141593) PP084990
                                        *                                                                                  085000
5176          1775  001F                HX001F      CON         X(001F)                                                  085010
                                        *                                                                                  085020
5177                                    POS_NOISE_TABLE;                                                               DP085030
5177          1776  0000084A                        COND          F(.5*.5*6076*6076/2.095D+7/2.095D+78-6)  A     DP085040
5178          1778  000468F5                        COND          F(5*5*6076*6076/2.095D+7/2.095D+78-6)    B     DP085050
5179          177A  00468F4F                        COND          F(20*20*6076*6076/2.095D+7/2.095D+78-6)  C     DP085060
                                        *   NOISE = 64*(NMI/R)**2                                                      DP085070
5180          177C  03C0                HD03C0      CON         X(03C0)        FOLLOW BY X(000F) MASK FOR LOP      085080
5181          177D  000F                HX000F      CON         X(000F)                                                  085090
5182          177E  6000                HX6000      CON         X(6000)                                                 HH085100
5183          177F  0FFF                HX0FFF      CON         X(0FFF)                                                 HH085110
5184          1780  2010                HX2010      CON         X(2010)        FOR OSC TEST                             HH085120
                                        *                                                                                  085130
5185                                    CALIBRATE_DATA_ADDRESSES;                                                      ES085140
5185          1781  1EF6                            CON         CALIBRATE_DATA          C3 DATA                    ES085150
5186          1782  1EFC                            CON         CALIBRATE_DATA+6        C2 DATA                    ES085160
5187          1783  1F02                            CON         CALIBRATE_DATA+12       C1 DATA                    ES085170
5188          1784  1F08                            CON         CALIBRATE_DATA+18       C4 DATA                    ES085180
                                        *                                                                                  085190
5189                                    LEAP_SECOND;                                                                  11   085200
5189          1785  00000320                        LITD        800         JAN 1 1975 VALUE ( 4 SECONDS)             01   085210
                                        *                                                                                  085220
5190                                    BURST_ADDRESSES;                                                               EB085230
5190          1787  0032                            CON         Q_SUB_T                                                EB085240
5191          1788  1EF3                            CON         PHI_ZERO                                               EB085250
5192          1789  0024                            CON         SIGMA_SQUARED_PHI_SUB_M                                EB085260
5193          178A  1EED                            CON         PHI_SUB_M                                              EB085270
                                        *                                                                                  085280
5194          178B  F000                HXF000      CON         X(F000)                                                  085290
5195          178C  DFFF                HXDFFF      CON         X(DFFF)                                                  085300
                                        *                                                                                  085310
5196                                    ANTENNA_NOISE_AND_CALIBRATE_CODES;                                             EB085320
5196          178D  0010                            CON         X(0010)                                                EB085330
5197          178E  0001                            CON         X(0001)        LOOP A                                  EB085340
5198          178F  0060                            CON         X(0060)                                                EB085350
5199          1790  0001                            CON         X(0001)        LOOP A                                  EB085360
```

```
5200  1791  0020                    CON     X(0020)                                          EB085370
5201  1792  0004                    CON     X(0004)        LOOP B                            EB085380
5202  1793  0050                    CON     X(0050)                                          EB085390
5203  1794  0004                    CON     X(0004)        LOOP B                            EB085400
                          *                                                                  085410
5204  1795  00023C8F    CAY_ONE     COND    F(((323D-6)*.9974)*217.0218-10)          10.2    PP085420
5205  1797  00023C28                COND    F(((((242D-6)*.9974)*217.0218-10)*4)/3)  13.6    PP085430
5206  1799  00023D57                COND    F(((((291D-6)*.9974)*217.0218-10)*10)/9) 11.3    PP085440
                          *                                                                  085450
```

```
                                                                                                                    SV085460
                **                                                                                                  
                *  OMEGA TRANSMITTER COORDINATES ARE REFERENCED TO THE MERCURY DATUM                                 085470
                *  ON THE FISHER 1960 ELLIPSOID(F = 1/298.3, REQ = 6378166. METERS                                   085480
                *  GEOCENTRIC DIRECTION COSINES AND GEODETIC LAT/LONG                                                085490
                *                                                                                                    085500
5207            STATION_VECTOR_TABLE;                                                                               085510
5207    179B    752F840D        COND        F(+.91551829)  NORWAY                =STATION A                         085520
5208    179D    3223FD8B        COND        F(+.39172334)  LAT  = N  66 25 15.00                                    085530
5209    179F    08B77EC7        COND        F(+.09153733)  LONG = E  13 09 10.00                                    085540
5210    17A1    179D8D80        COND        F(+.18449565)  TRINIDAD              =STATION B                         085550
5211    17A3    38C26F26        COND        F(+.46687116)  LAT  = N  10 42 06.20                                    085560
5212    17A5    914C14AC        COND        F(-.86486570)  LONG = W  61 38 20.30                                    085570
5213    17A7    2E714E36        COND        F(+.36283281)  HAWAII                =STATION C                         085580
5214    17A9    918A3DF1        COND        F(-.86296869)  LAT  = N  21 24 16.90                                    085590
5215    17AB    D2FE1498        COND        F(-.35162108)  LONG = W 157 49 52.70                                    085600
5216    17AD    5C5837FA        COND        F(+.72144222)  NORTH DAKOTA          =STATION D                         085610
5217    17AF    F326652F        COND        F(-.10039077)  LAT  = N  46 21 57.20                                    085620
5218    17B1    A84C85E6        COND        F(-.68515898)  LONG = W  98 20 08.77                                    085630
5219    17B3    D27368C3        COND        F(-.35585299)  ILE DE LA REUNION     =STATION E                         085640
5220    17B5    441D7343        COND        F(+.53214875)  LAT  = S  20 58 26.47                                    085650
5221    17B7    625B8D91        COND        F(+.76823587)  LONG = E  55 17 24.25                                    085660
5222    17B9    A8EE3E21        COND        F(-.68022941)  ARGENTINA             =STATION F                         085670
5223    17BB    275E3392        COND        F(+.30756230)  LAT  = S  43 03 12.53                                    085680
5224    17BD    AAD5BE4E        COND        F(-.66535207)  LONG = W  65 11 27.69                                    085690
                * NEW YORK IS INTERMITTENTLY RADIATING IN THE G SLOT                                                 085700
5225    17BF    57B52B3C        COND        F(+.68521633)  NEW YORK              =STATION G                         085710
5226    17C1    17FE6764        COND        F(+.18745129)  LAT  = N  43 26 40.92                                    085720
5227    17C3    A5E98D08        COND        F(-.70380437)  LONG = W  75 05 09.80                                    085730
5228    17C5    4861680F        COND        F(+.56547261)  TSUSHIMA ISLAND       =STATION H                         085740
5229    17C7    BCEA4FEA        COND        F(-.52409936)  LAT  = N  34 36 53.26                                    085750
5230    17C9    5183DAD6        COND        F(+.63683639)  LONG = E 129 27 12.49                                    085760
```

```
                                    **                                                                  085770
5231    17CB  028F      PHI_ZERO_0  CON     F((1.0)/50)     10.2   RECEIVER INPUT                       ES085780
5232    17CC  03D7                  CON     F((1.5)/50)     13.6   PHASE                                ES085790
5233    17CD  03D7                  CON     F((1.5)/50)     11.3   SHIFT                                ES085800
5234                    PHI_ZERO_FLOATER;                                                               ES085810
5234    17CE  E664                  CON     X(E664)         90 CEC'S                                     ES085820
5235    17CF  2E15                  CON     X(2E15)         18 CEC'S                                     ES085830
5236    17D0  051F                  CON     X(051F)         02 CEC'S                                     ES085840
                                    *                                                                   ES085850
5237                    PHI_ZERO_LOOP;                                                                  ES085860
5237    17D1  D26F                  CON     F((-17.8)/50)                                                ES085870
5238    17D2  1917                  CON     F((9.8)/50)                                                  ES085880
5239    17D3  F168                  CON     F((-5.7)/50)                                                 ES085890
5240    17D4  0000      OVERLAY     CON     0               ECS WORD FOR OVERLAYS                        085900
5241    17D5  0021      ASCII       CON     X(0021)         A                                            085910
5242    17D6  0022                  CON     X(0022)         B                                            085920
5243    17D7  0023                  CON     X(0023)         C                                            085930
5244    17D8  0024                  CON     X(0024)         D                                            085940
5245    17D9  0025                  CON     X(0025)         E                                            085950
5246    17DA  0026                  CON     X(0026)         F                                            085960
5247    17DB  0027                  CON     X(0027)         G                                            085970
5248    17DC  0028                  CON     X(0028)         H                                            085980
```

```
                                    **                                                          085990
                                    *           VARIABLE STORAGE NOT CLEARED AT TURN ON         086000
                                    *                                                           086010
5249                1B3C            ROLL        BSS         0                                   086020
5250                1B3C            ROLL_15     BSS         175                                 086030
5251                1BEB            ROLL_14     BSSD        12                                  086040
5252                1C03            ROLL_END    BSS         0                                   086050
```

```
                        **                                                                  086060
 5253                   HEADING_GROUP;                                                      086070
 5253  1C03             BSS       1                                                         086080
 5254  1C04             TYPE_OUT  BSS       1                                               086090
 5255                   DB_CKSUM_IGNORE;                                                    086100
 5255  1C05             BSS       1                                                         086110
 5256  1C06             KAL_TEMP  BSS       18                                            HH086120
 5257                   CALIBRATE_FAIL_COUNT;                                             HH086130
 5257  1C18             BSS       6                                                       HH086140
 5258  1C1E             XXX       BSS       9         AVE ESTIMATE VECTOR                 CF086150
 5259  1C1E             SYNC_DATA EQU       XXX                                           SY086160
 5260  1DAE             SYNC_C    EQU       SYNC_DATA+400                                 SY086170
 5261  1E78             SYNC_COUNT EQU      SYNC_C+202                                    086180
 5262  1E7A             SYNC_BASE EQU       SYNC_COUNT+2                                  086190
 5263                   SYNC_DATA_COUNTER;                                                086200
 5263  1E7D             EQU       SYNC_BASE+3                                           086210
 5264  1C27             X         BSS       120                                         086220
 5265                   PROP_PRED_RESULTS;                                                086230
 5265  1C63             EQU       X+60                                                  086240
 5266  1C80             AUR_SAVE  EQU       X+89                                          086250
 5267                   SEASON_INDEX_NORTH;                                               086260
 5267  1C9F             BSS       1                                                       086270
 5268                   SEASON_INDEX_SOUTH;                                               086280
 5268  1CA0             BSS       1                                                       086290
 5269  1CA1             PROP_C    BSS       OS*3                                        086300
 5270  1CB9             PP_THETA3 BSS       OS*3                                        086310
 5271  1CD1             ERROR_NORTH BSSD    2                                           086320
 5272  1CD3             ERROR_EAST EQU      ERROR_NORTH+2                               086330
 5273  1CD5             BI        BSS       19        WEIGHTING_MATRIX + CODE           CF086340
 5274  1CE8             XXXX      BSS       5         SAVE AVERAGE P1,P2,P3,V2,V3       CF086350
 5275  1CED             XX        BSS       9           WORKING STORAGE                 CF086360
 5276  1CF6             X2XX      BSS       9                                           CF086370
 5277  1CFF             MISFIRE_CNT BSS     1                                           CF086380
 5278                   SIGMA_SQ_KICK;                                                    CF086390
 5278  1D00             BSSD      1                                                       CF086400
 5279  1D02             RES3      BSSD      1                                           086410
 5280  1D04             RES2      BSSD      1                                           086420
 5281                   P44_INC_RATE;                                                     086430
 5281  1D06             BSS       1                                                       086440
 5282  1D07             DF_COUNTER BSS      OS                                          086450
 5283  1D0F             PP_THETA2 BSS       OS                                          086460
 5284  1D17             P_MATRIX  BSSD      81        COVARIANCE_MATRIX                 CF086470
 5285  1D17             P11       EQU       P_MATRIX                                    CF086480
```

```
5286  1D19  P12  EQU  P_MATRIX+2   CF086490
5287  1D1B  P13  EQU  P_MATRIX+4   CF086500
5288  1D1D  P14  EQU  P_MATRIX+6   CF086510
5289  1D1F  P15  EQU  P_MATRIX+8   CF086520
5290  1D21  P16  EQU  P_MATRIX+10  CF086530
5291  1D23  P17  EQU  P_MATRIX+12  CF086540
5292  1D25  P18  EQU  P_MATRIX+14  CF086550
5293  1D27  P19  EQU  P_MATRIX+16  CF086560
5294  1D29  P21  EQU  P_MATRIX+18  CF086570
5295  1D2B  P22  EQU  P_MATRIX+20  CF086580
5296  1D2D  P23  EQU  P_MATRIX+22  CF086590
5297  1D2F  P24  EQU  P_MATRIX+24  CF086600
5298  1D31  P25  EQU  P_MATRIX+26  CF086610
5299  1D33  P26  EQU  P_MATRIX+28  CF086620
5300  1D35  P27  EQU  P_MATRIX+30  CF086630
5301  1D37  P28  EQU  P_MATRIX+32  CF086640
5302  1D39  P29  EQU  P_MATRIX+34  CF086650
5303  1D3B  P31  EQU  P_MATRIX+36  CF086660
5304  1D3D  P32  EQU  P_MATRIX+38  CF086670
5305  1D3F  P33  EQU  P_MATRIX+40  CF086680
5306  1D41  P34  EQU  P_MATRIX+42  CF086690
5307  1D43  P35  EQU  P_MATRIX+44  CF086700
5308  1D45  P36  EQU  P_MATRIX+46  CF086710
5309  1D47  P37  EQU  P_MATRIX+48  CF086720
5310  1D49  P38  EQU  P_MATRIX+50  CF086730
5311  1D4B  P39  EQU  P_MATRIX+52  CF086740
5312  1D4D  P41  EQU  P_MATRIX+54  CF086750
5313  1D4F  P42  EQU  P_MATRIX+56  CF086760
5314  1D51  P43  EQU  P_MATRIX+58  CF086770
5315  1D53  P44  EQU  P_MATRIX+60  CF086780
5316  1D55  P45  EQU  P_MATRIX+62  CF086790
5317  1D57  P46  EQU  P_MATRIX+64  CF086800
5318  1D59  P47  EQU  P_MATRIX+66  CF086810
5319  1D5B  P48  EQU  P_MATRIX+68  CF086820
5320  1D5D  P49  EQU  P_MATRIX+70  CF086830
5321  1D5F  P51  EQU  P_MATRIX+72  CF086840
5322  1D61  P52  EQU  P_MATRIX+74  CF086850
5323  1D63  P53  EQU  P_MATRIX+76  CF086860
5324  1D65  P54  EQU  P_MATRIX+78  CF086870
5325  1D67  P55  EQU  P_MATRIX+80  CF086880
5326  1D69  P56  EQU  P_MATRIX+82  CF086890
5327  1D6B  P57  EQU  P_MATRIX+84  CF086900
5328  1D6D  P58  EQU  P_MATRIX+86  CF086910
```

```
5329  1D6F  P59          EQU   P_MATRIX+88                    CF086920
5330  1D71  P61          EQU   P_MATRIX+90                    CF086930
5331  1D73  P62          EQU   P_MATRIX+92                    CF086940
5332  1D75  P63          EQU   P_MATRIX+94                    CF086950
5333  1D77  P64          EQU   P_MATRIX+96                    CF086960
5334  1D79  P65          EQU   P_MATRIX+98                    CF086970
5335  1D7B  P66          EQU   P_MATRIX+100                   CF086980
5336  1D7D  P67          EQU   P_MATRIX+102                   CF086990
5337  1D7F  P68          EQU   P_MATRIX+104                   CF087000
5338  1D81  P69          EQU   P_MATRIX+106                   CF087010
5339  1D83  P71          EQU   P_MATRIX+108                   CF087020
5340  1D85  P72          EQU   P_MATRIX+110                   CF087030
5341  1D87  P73          EQU   P_MATRIX+112                   CF087040
5342  1D89  P74          EQU   P_MATRIX+114                   CF087050
5343  1D8B  P75          EQU   P_MATRIX+116                   CF087060
5344  1D8D  P76          EQU   P_MATRIX+118                   CF087070
5345  1D8F  P77          EQU   P_MATRIX+120                   CF087080
5346  1D91  P78          EQU   P_MATRIX+122                   CF087090
5347  1D93  P79          EQU   P_MATRIX+124                   CF087100
5348  1D95  P81          EQU   P_MATRIX+126                   CF087110
5349  1D97  P82          EQU   P_MATRIX+128                   CF087120
5350  1D99  P83          EQU   P_MATRIX+130                   CF087130
5351  1D9B  P84          EQU   P_MATRIX+132                   CF087140
5352  1D9D  P85          EQU   P_MATRIX+134                   CF087150
5353  1D9F  P86          EQU   P_MATRIX+136                   CF087160
5354  1DA1  P87          EQU   P_MATRIX+138                   CF087170
5355  1DA3  P88          EQU   P_MATRIX+140                   CF087180
5356  1DA5  P89          EQU   P_MATRIX+142                   CF087190
5357  1DA7  P91          EQU   P_MATRIX+144                   CF087200
5358  1DA9  P92          EQU   P_MATRIX+146                   CF087210
5359  1DAB  P93          EQU   P_MATRIX+148                   CF087220
5360  1DAD  P94          EQU   P_MATRIX+150                   CF087230
5361  1DAF  P95          EQU   P_MATRIX+152                   CF087240
5362  1DB1  P96          EQU   P_MATRIX+154                   CF087250
5363  1DB3  P97          EQU   P_MATRIX+156                   CF087260
5364  1DB5  P98          EQU   P_MATRIX+158                   CF087270
5365  1DB7  P99          EQU   P_MATRIX+160                   CF087280
                         *                                  CF087290
                         *                                    087300
                         *                                    087310
5366  1DB9  N_CTR_SAVE   BSSD  1                           11  087320
5367        SIGMA_SQ_N_COUNTER;                              087330
5367  1DBB              BSS   OS*3                           087340
```

```
5368                        SIGMA_SQ_PHI_DOT_PHI_DOT;                    087350
5368  1DD3                        BSSD        OS*3                       087360
5369                        SIGMA_SQ_PHI_PHI_DOT;                        087370
5369  1E03                        BSSD        OS*3                       087380
5370                        SIGMA_SQ_PHI_PHI;                            087390
5370  1E33                        BSSD        OS*3                       087400
5371  1E63                  PHI_DOT_DR  BSSD        OS                   087410
5372                        PHI_DOT_ESTIMATE;                            087420
5372  1E73                        BSSD        OS*3                       087430
5373                        PHI_ESTIMATE;                                087440
5373  1EA3                        BSSD        OS*3                       087450
```

```
                                **                                                                  TF087460
5374    1ED3                    Q_STORAGE   BSS         24                                          087470
5375    1EE8                    AVIONICS    BSSD        1                                           MT087480
5376    1EED                    PHI_SUB_M   BSSD        3                                           087490
5377    1EF3                    PHI_ZERO    BSS         3                                           087500
5378                            CALIBRATE_DATA:                                                     087510
5378    1EF6                                BSS         24                                          087520
5379    1F08                    NOISE_DATA  EQU         CALIBRATE_DATA+18                           087530
5380                            END_OF_BURST_DATA:                                                  087540
5380    1F08                                EQU         CALIBRATE_DATA+18                           087550
5381                            PHI_DOT_OR_BASE:                                                    087560
5381    1F0E                                BSS         9                                           087570
5382    1F17                    BURST_TIME  BSSD        1                                           087580
5383                            SS_PHI_M_BASE:                                                      087590
5383    1F19                                BSSD        3                                           087600
5384    1F1F                    PHI_M_BASE  BSSD        3                                           087610
5385    1F25                    RAW_M       BSSD        3                                           087620
5386                            DELTA_THETA_2:                                                      RU087630
5386    1F28                                BSSD        2                                           RU087640
5387                            DELTA_THETA_3:                                                      RU087650
5387    1F2D                                EQU         DELTA_THETA_2+2                             RU087660
5388    1F2F                    MODE_CHANGE BSS         1                                           087670
5389                            BEARING_TEMPS:                                                      087680
5389    1F30                                BSSD        6                                           087690
5390    1F3C                    PHI_OFFSET  BSS         1                                           **087700
5391    1F3D                    IMAGE11     BSS         2                                           CI087710
5392    1F3E                    IMAGE12     EQU         IMAGE11+1                                   CI087720
5393    1F3F                    IMAGE13     BSS         1                                           CI087730
                                *                                                                   087740
                                *   CONTROL AND INDICATOR VARIABLES                                 087750
                                *       ORDER CRITICAL - DO NOT DISTURB                             CI087760
5394    1F40                    CALLWORD    BSS         1                                           CI087770
5395    1F41                    ARGWORD1    BSS         1                                           CI087780
5396    1F42                    ARGWORD2    BSS         1                                           CI087790
5397    1F43                    LINKWORD    BSS         1                                           CI087800
5398    1F44                    PROCWORD    BSS         1                                           CI087810
5399    1F45                    PANELTIME   BSSD        1                                           CI087820
5400    1F47                    PANELMODE   BSS         4                                           CI087830
                                *       END OF ORDERED VARIABLES                                    CI087840
                                *                                                                   087850
                                *                       START - CRITICALLY ORDERED STORAGE          087860
                                *                                                                   087870
5401    1F48                    V_TAS_STAR  BSS         1                                           087880
```

```
5402  1F4C        TIME_STAR    BSSD    1                                    087890
5403  1F4E        VC2_STAR     BSS     2                                    087900
5404  1F50        THA_P_STAR   BSSD    1                                    087910
5405  1F52        PSI_A_STAR   BSS     1                                    087920
5406                PANEL_BUFFER;                                          087930
5406  1F53                     BSS     0                                    087940
5407                SMOOTH_DATA_STAR;                                      087950
5407  1F53                     BSS     2                                    087960
5408  1F55        RIJ_STAR     BSSD    9                                    087970
5409  1F67        PANEL_DATA   BSS     0                                    087980
5410  1F67        SMOOTH_DATA  BSS     2                                    087990
5411  1F69        RIJ          BSSD    9                                    088000
5412  1F69        R11          EQU     RIJ+00                               088010
5413  1F6B        R12          EQU     RIJ+02                               088020
5414  1F6D        R13          EQU     RIJ+04                               088030
5415  1F6F        R21          EQU     RIJ+06                               088040
5416  1F71        R22          EQU     RIJ+08                               088050
5417  1F73        R23          EQU     RIJ+10                               088060
5418  1F75        R31          EQU     RIJ+12                               088070
5419  1F77        R32          EQU     RIJ+14                               088080
5420  1F79        R33          EQU     RIJ+16                               088090
5421  1F7B        PANEL_BCUND  BSS     0                                    088100
                  *                                                        088110
                  *          END STORAGE NOT CLEARED AT TURN ON            088120
                  *                                                        088130
                  *                            END - CRITICALLY ORDERED STORAGE 088140
                  *                                                        088150
                  *                                                        088160
5422  1F7B        H_BURST      BSSD    05                                   088170
5423  1F8B        PSI_INSERT   BSS     1                                    088180
5424  1F8C        FLOATER      BSS     1                                    HH088190
5425                HEADING_MODE;                                          088200
5425  1F8D                     BSS     2                                    088210
5426  1F8E        NAV_MODE     EQU     HEADING_MODE+1                       088220
5427                CHANNEL_FAIL;                                          088230
5427  1F8F                     BSS     3                                    088240
5428  1F92        COS_THETA_P  BSSD    2                                    088250
5429  1F94        SIN_THETA_P  EQU     COS_THETA_P+2                        088260
5430                SAVE_POSITION_VARIANCES;                               CF088270
5430  1F96                     BSSD    2                                    CF088280
5431                CALIBRATE_RESULTS;                                     HH088290
5431  1F9A                     BSS     12                                   HH088300
                  * YPA,YPA,YPA,XPA,XPA,XPA,YPB,YPB,YPB,XPB,XPB,XPB    12 SINGLE WORDS  088310
```

```
5432  1FA6          Y_P             BSS         12                                  088320
5433  1FB2          RZ_C            BSSD        3                                   088330
5434  1FB8          RZ_PCS          BSSD        3                                   088340
5435  1FBE          RZ_BETA         BSSD        3                                   088350
5436                DESTINATION_LONGITUDE:                                          088360
5436  1FC4                          BSSD        26                                  088370
5437                DESTINATION_LATITUDE:                                           088380
5437  1FDE                          EQU         DESTINATION_LONGITUDE+26            088390
5438                INTERCEPT_LAT:                                                  088400
5438  1FF6                          EQU         DESTINATION_LATITUDE+24             088410
5439                INTERCEPT_LONG:                                                 088420
5439  1FDC                          EQU         DESTINATION_LONGITUDE+24            088430
5440  1FD8          RZ_TIME         EQU         DESTINATION_LONGITUDE+20            088440
5441  1FF2          RZ_RATE         EQU         DESTINATION_LATITUDE+20             088450
5442  1FDA          RZ_ALPHA        EQU         RZ_TIME+2                           088460
5443  1FD8          RZ_VEL          EQU         RZ_ALPHA+1                          088470
5444  1FF4          V_INSERT        EQU         RZ_RATE+2                           088480
5445  1FF8          DB_WAT          BSS         8                                   088490
```

```
                                **                                          088500
                                *                                           CT088510
                                *                                           CT088520
                                *          CONDUCTIVITY TABLE               CT088530
                                *                                           CT088540
5446  17DD  FFFFFFFF  LAT_N85_N90 COND   X(FFFFFFFF)                        CT088550
5447  17DF  F700                  CON    X(F700)                            CT088560
5448  17E0  FFFFFF9C  LAT_N80_N85 COND   X(FFFFFF9C)                        CT088570
5449  17E2  8AA78898              COND   X(8AA78898)                        CT088580
5450  17E4  776579F7              COND   X(776579F7)                        CT088590
5451  17E6  DF5ECCF2  LAT_N75_N80 COND   X(DF5ECCF2)                        CT088600
5452  17E8  D7BA8DFF              COND   X(D7BA8DFF)                        CT088610
5453  17EA  F7CC88BC              COND   X(F7CC88BC)                        CT088620
5454  17EC  ABA8D832              COND   X(ABA8D832)                        CT088630
5455  17EE  0000002F              COND   X(0000002F)                        CT088640
5456  17F0  5CE0                  CON    X(5CE0)                            CT088650
5457  17F1  EEF3CCF0  LAT_N70_N75 COND   X(EEF3CCF0)                        CT088660
5458  17F3  DD897774              COND   X(DD897774)                        CT088670
5459  17F5  6589BDCA              COND   X(6589BDCA)                        CT088680
5460  17F7  8DDF7EEF              COND   X(8DDF7EEF)                        CT088690
5461  17F9  499A9CCC              COND   X(499A9CCC)                        CT088700
5462  17FB  877BF260              COND   X(877BF260)                        CT088710
5463  17FD  0002EF70              COND   X(0002EF70)                        CT088720
5464  17FF  9898DC88  LAT_N65_N70 COND   X(9898DC88)                        CT088730
5465  1801  97A88865              COND   X(97A88865)                        CT088740
5466  1803  65557777              COND   X(65557777)                        CT088750
5467  1805  77778767              COND   X(77778767)                        CT088760
5468  1807  BCF09778              COND   X(BCF09778)                        CT088770
5469  1809  89999756              COND   X(89999756)                        CT088780
5470  180B  6669BE87              COND   X(6669BE87)                        CT088790
5471  180D  CF0E003A              COND   X(CF0E003A)                        CT088800
5472  180F  8DDF4D90              COND   X(8DDF4D90)                        CT088810
5473  1811  A99ABAA8  LAT_N60_N65 COND   X(A99ABAA8)                        CT088820
5474  1813  9A999987              COND   X(9A999987)                        CT088830
5475  1815  67777777              COND   X(67777777)                        CT088840
5476  1817  677A89AC              COND   X(677A89AC)                        CT088850
5477  1819  F1EB9999              COND   X(F1EB9999)                        CT088860
5478  181B  99998777              COND   X(99998777)                        CT088870
5479  181D  49DDD88F              COND   X(49DDD88F)                        CT088880
5480  181F  256F2EDF              COND   X(256F2EDF)                        CT088890
5481  1821  3C88                  CON    X(3C88)                            CT088900
5482  1822  C9ABAAA9  LAT_N55_N60 COND   X(C9ABAAA9)                        CT088910
5483  1824  9AAAAA88              COND   X(9AAAAA88)                        CT088920
5484  1826  88645559              COND   X(88645559)
```

```
5485  1828  DEEBCF5E              COND  X(DEEBCF5E)  CT088930
5486  182A  CDF1D899              COND  X(CDF1D899)  CT088940
5487  182C  9865BDCF              COND  X(9865BDCF)  CT088950
5488  182E  0857AFAA              COND  X(0857AFAA)  CT088960
5489  1830  F0D8D000              COND  X(F0D8D000)  CT088970
5490  1832  AAA8AAA9  LAT_N50_N55 COND  X(AAA8AAA9)  CT088980
5491  1834  9AAAAA76              COND  X(9AAAAA76)  CT088990
5492  1836  7755566A              COND  X(7755566A)  CT089000
5493  1838  EF1CFCE8              COND  X(EF1CFCE8)  CT089010
5494  183A  99AAA977              COND  X(99AAA977)  CT089020
5495  183C  B97878F8              COND  X(B97878F8)  CT089030
5496  183E  DDE8A800              COND  X(DDE8A800)  CT089040
5497  1840  AA88A88A  LAT_N45_N50 COND  X(AA88A88A)  CT089050
5498  1842  BAAAA977              COND  X(BAAAA977)  CT089060
5499  1844  6689789C              COND  X(6689789C)  CT089070
5500  1846  EFFF188A              COND  X(EFFF188A)  CT089080
5501  1848  AA989877              COND  X(AA989877)  CT089090
5502  184A  7E9CF8CA              COND  X(7E9CF8CA)  CT089100
5503  184C  A9A0                  CON   X(A9A0)      CT089110
5504  184D  98DDACD8  LAT_N40_N45 COND  X(98DDACD8)  CT089120
5505  184F  BAA9AAAA              COND  X(BAA9AAAA)  CT089130
5506  1851  AAA8A7DF              COND  X(AAA8A7DF)  CT089140
5507  1853  0DFFF198              COND  X(0DFFF198)  CT089150
5508  1855  A98AAA6A              COND  X(A98AAA6A)  CT089160
5509  1857  AFBCBCDC              COND  X(AFBCBCDC)  CT089170
5510  1859  8000                  CON   X(8000)      CT089180
5511  185A  ECB999A9  LAT_N35_N40 COND  X(ECB999A9)  CT089190
5512  185C  A9789999              COND  X(A9789999)  CT089200
5513  185E  AAABF0BF              COND  X(AAABF0BF)  CT089210
5514  1860  0DEFFF1D              COND  X(0DEFFF1D)  CT089220
5515  1862  A6ABAAC9              COND  X(A6ABAAC9)  CT089230
5516  1864  CFCCCEDF              COND  X(CFCCCEDF)  CT089240
5517  1866  1000                  CON   X(1000)      CT089250
5518  1867  DEEAA99A  LAT_N30_N35 COND  X(DEEAA99A)  CT089260
5519  1869  AAA89999              COND  X(AAA89999)  CT089270
5520  186B  AAAAEF0E              COND  X(AAAAEF0E)  CT089280
5521  186D  FFF488AA              COND  X(FFF488AA)  CT089290
5522  186F  A8A8EFC8              COND  X(A8A8EFC8)  CT089300
5523  1871  AAADE000              COND  X(AAADE000)  CT089310
5524  1873  AA8B98DB  LAT_N25_N30 COND  X(AA8B98DB)  CT089320
5525  1875  AAAA9999              COND  X(AAAA9999)  CT089330
5526  1877  9A99EFFF              COND  X(9A99EFFF)  CT089340
5527  1879  7CAADF1C              COND  X(7CAADF1C)  CT089350
```

```
5528  187B  FCC9AAAA                    COND  X(FCC9AAAA)  CT089360
5529  187D  A000                        CON   X(A000)      CT089370
5530  187E  AA9C7AAC  LAT_N20_N25       COND  X(AA9C7AAC)  CT089380
5531  1880  F0EA998C                    COND  X(F0EA998C)  CT089390
5532  1882  A98CDFFF                    COND  X(A98CDFFF)  CT089400
5533  1884  8EC9CF0E                    COND  X(8EC9CF0E)  CT089410
5534  1886  FCEA9A89                    COND  X(FCEA9A89)  CT089420
5535  1888  A900                        CON   X(A900)      CT089430
5536  1889  998ABACE  LAT_N15_N20       COND  X(998ABACE)  CT089440
5537  188B  F1C9CF0E                    COND  X(F1C9CF0E)  CT089450
5538  188D  8ACF1EFF                    COND  X(8ACF1EFF)  CT089460
5539  188F  F9CCCDFC                    COND  X(F9CCCDFC)  CT089470
5540  1891  EAAA98AA                    COND  X(EAAA98AA)  CT089480
5541  1893  7998ADF4  LAT_N10_N15       COND  X(7998ADF4)  CT089490
5542  1895  9F2EC8F1                    COND  X(9F2EC8F1)  CT089500
5543  1897  EFFF8EDD                    COND  X(EFFF8EDD)  CT089510
5544  1899  F0DEEF7C                    COND  X(F0DEEF7C)  CT089520
5545  189B  99899AA0                    COND  X(99899AA0)  CT089530
5546  189D  88A898F4  LAT_N05_N10       COND  X(88A898F4)  CT089540
5547  189F  EEF2EF1E                    COND  X(EEF2EF1E)  CT089550
5548  18A1  EFFFDEC9                    COND  X(EFFFDEC9)  CT089560
5549  18A3  98CF7C77                    COND  X(98CF7C77)  CT089570
5550  18A5  A879                        CON   X(A879)      CT089580
5551  18A6  8778AEF8  LAT_N00_N05       COND  X(8778AEF8)  CT089590
5552  18A8  EDF0CDFF                    COND  X(EDF0CDFF)  CT089600
5553  18AA  FFCA8779                    COND  X(FFCA8779)  CT089610
5554  18AC  FAE78000                    COND  X(FAE78000)  CT089620
5555  18AE  9878EFAB  LAT_S05_S00       COND  X(9878EFAB)  CT089630
5556  18B0  F0CEEF0E                    COND  X(F0CEEF0E)  CT089640
5557  18B2  CEFFF9EA                    COND  X(CEFFF9EA)  CT089650
5558  18B4  A9999B8E                    COND  X(A9999B8E)  CT089660
5559  18B6  F889                        CON   X(F889)      CT089670
5560  18B7  9978FCEE  LAT_S10_S05       COND  X(9978FCEE)  CT089680
5561  18B9  F3ECDFFF                    COND  X(F3ECDFFF)  CT089690
5562  18BB  9AAA9979                    COND  X(9AAA9979)  CT089700
5563  18BD  98F88900                    COND  X(98F88900)  CT089710
5564  18BF  A877F0DF  LAT_S15_S10       COND  X(A877F0DF)  CT089720
5565  18C1  EEADDFFF                    COND  X(EEADDFFF)  CT089730
5566  18C3  AC9A99A8                    COND  X(AC9A99A8)  CT089740
5567  18C5  8EF8C900                    COND  X(8EF8C900)  CT089750
5568  18C7  A98BF09F  LAT_S20_S15       COND  X(A98BF09F)  CT089760
5569  18C9  DC89AAEF                    COND  X(DC89AAEF)  CT089770
5570  18CB  FFAC89AA                    COND  X(FFAC89AA)  CT089780
```

```
5571  18CD  98EF8AA0          COND   X(98EF8AA0)   CT089790
5572  18CF  A8AF0EAF LAT_S25_S20 COND  X(A8AF0EAF)  CT089800
5573  18D1  8E88AAAA          COND   X(8E88AAAA)   CT089810
5574  18D3  8EFFF9E8          COND   X(8EFFF9E8)   CT089820
5575  18D5  AAA9AF9D          COND   X(AAA9AF9D)   CT089830
5576  18D7  9000              CON    X(9000)       CT089840
5577  18D8  99CFEE87 LAT_S30_S25 COND  X(99CFEE87)  CT089850
5578  18DA  AAAAACFF          COND   X(AAAAACFF)   CT089860
5579  18DC  F9E7AAAD          COND   X(F9E7AAAD)   CT089870
5580  18DE  F8A0              CON    X(F8A0)       CT089880
5581  18DF  ACFFF08A LAT_S35_S30 COND  X(ACFFF08A)  CT089890
5582  18E1  DDAA9DFF          COND   X(DDAA9DFF)   CT089900
5583  18E3  FAC9AABF          COND   X(FAC9AABF)   CT089910
5584  18E5  8D00              CON    X(8D00)       CT089920
5585  18E6  FFF7C8F3 LAT_S40_S35 COND  X(FFF7C8F3)  CT089930
5586  18E8  EEFFF5BA          COND   X(EEFFF5BA)   CT089940
5587  18EA  8DF0              CON    X(8DF0)       CT089950
5588  18E8  FFF8EF3D LAT_S45_S40 COND  X(FFF8EF3D)  CT089960
5589  18ED  FFF6BAFF          COND   X(FFF6BAFF)   CT089970
5590  18EF  FFFCEFFF LAT_S50_S45 COND  X(FFFCEFFF)  CT089980
5591  18F1  79DFF000          COND   X(79DFF000)   CT089990
5592  18F3  FFFFFFF5 LAT_S55_S50 COND  X(FFFFFFF5)  CT090000
5593  18F5  8EFF              CON    X(8EFF)       CT090010
5594  18F6  FFFFF300 LAT_S60_S55 COND  X(FFFFF300)  CT090020
5595  18F8  FFFFF300 LAT_S65_S60 COND  X(FFFFF300)  CT090030
5596  18FA  F1A89D76 LAT_S70_S65 COND  X(F1A89D76)  CT090040
5597  18FC  4566ADFC          COND   X(4566ADFC)   CT090050
5598  18FE  8F70              CON    X(8F70)       CT090060
5599  18FF  32213310 LAT_S75_S70 COND  X(32213310)  CT090070
5600  1901  0000226F          COND   X(0000226F)   CT090080
5601  1903  5DED9994          COND   X(5DED9994)   CT090090
5602  1905  F3943300          COND   X(F3943300)   CT090100
5603  1907  00002210 LAT_S80_S75 COND  X(00002210)  CT090110
5604  1909  00001398          COND   X(00001398)   CT090120
5605  1908  CCA52211          COND   X(CCA52211)   CT090130
5606  1900  12348A95          COND   X(12348A95)   CT090140
5607  190F  2200              CON    X(2200)       CT090150
5608  1910  00000000 LAT_S85_S80 COND  X(00000000)  CT090160
5609  1912  00123445          COND   X(00123445)   CT090170
5610  1914  55532211          COND   X(55532211)   CT090180
5611  1916  12233333          COND   X(12233333)   CT090190
5612  1918  2200              CON    X(2200)       CT090200
5613  1919  00000000 LAT_S90_S85 COND  X(00000000)  CT090210
```

```
5614    1918  00223333          COND      X(00223333)     CT090220
5615    191D  33322222          COND      X(33322222)     CT090230
5616    191F  22222222          COND      X(22222222)     CT090240
5617    1921  2100              CON       X(2100)         CT090250
```

```
                                                                    090260
                **                                                  090270
                *                                                   CT090280
5618  1922 1919 COND_TABLE  CON   LAT_S90_S85                       CT090290
5619  1923 1910             CON   LAT_S85_S80                       CT090300
5620  1924 1907             CON   LAT_S80_S75                       CT090310
5621  1925 18FF             CON   LAT_S75_S70                       CT090320
5622  1926 18FA             CON   LAT_S70_S65                       CT090330
5623  1927 18F8             CON   LAT_S65_S60                       CT090340
5624  1928 18F6             CON   LAT_S60_S55                       CT090350
5625  1929 18F3             CON   LAT_S55_S50                       CT090360
5626  192A 18EF             CON   LAT_S50_S45                       CT090370
5627  192B 18EB             CON   LAT_S45_S40                       CT090380
5628  192C 18E6             CON   LAT_S40_S35                       CT090390
5629  192D 18DF             CON   LAT_S35_S30                       CT090400
5630  192E 18D8             CON   LAT_S30_S25                       CT090410
5631  192F 18CF             CON   LAT_S25_S20                       CT090420
5632  1930 18C7             CON   LAT_S20_S15                       CT090430
5633  1931 18BF             CON   LAT_S15_S10                       CT090440
5634  1932 18B7             CON   LAT_S10_S05                       CT090450
5635  1933 18AE             CON   LAT_S05_S00                       CT090460
5636  1934 18A6             CON   LAT_N00_N05                       CT090470
5637  1935 189D             CON   LAT_N05_N10                       CT090480
5638  1936 1893             CON   LAT_N10_N15                       CT090490
5639  1937 1889             CON   LAT_N15_N20                       CT090500
5640  1938 187E             CON   LAT_N20_N25                       CT090510
5641  1939 1873             CON   LAT_N25_N30                       CT090520
5642  193A 1867             CON   LAT_N30_N35                       CT090530
5643  193B 185A             CON   LAT_N35_N40                       CT090540
5644  193C 184D             CON   LAT_N40_N45                       CT090550
5645  193D 1840             CON   LAT_N45_N50                       CT090560
5646  193E 1832             CON   LAT_N50_N55                       CT090570
5647  193F 1822             CON   LAT_N55_N60                       CT090580
5648  1940 1811             CON   LAT_N60_N65                       CT090590
5649  1941 17FF             CON   LAT_N65_N70                       CT090600
5650  1942 17F1             CON   LAT_N70_N75                       CT090610
5651  1943 17E6             CON   LAT_N75_N80                       CT090620
5652  1944 17E0             CON   LAT_N80_N85                       CT090630
5653  1945 170D END_COND_T  CON   LAT_N85_N90                       CT090640
5654  1946 C72C END_CKSUM   ECS                                     0090640
```

```
                                **                                                                  1090650
5655                                            TAPE        4,X(73)                                 090660
5656                                            TAPE        3,12                                    090670
5657                                            TAPE        4,X(F1)                                 090680
5658                                            TAPE        1                                       090690
5659            1947                            SCS                                                 090700
5660            015F                HOT         EQU         OMEGA_TASK_TABLE/2                      090710
5661            0156                            ORG         PROG_ID_DB                              090720
5662            0156  0100                      CON         X(0100)         DISPLAY 01 FOR DEBUG ON C_I 090730
5663            1947                            ORG         END_CKSUM+1                             090740
5664                                OMEGA_DEBUG ;                                                   090750
5664      4R    1947  D009  (1951)               18UC        OMEGA_DEBUG_ENTRY                       090760
5665      4R    1948  D00F  (1958)  $2           18UC        OMEGA_DEBUG_ENTRY$2                    1090770
5666     14R    1949  D510          AD_IO_TEST   288K        1                                      2090780
5666      4R    194A  D000                       FILL
5667     14R    1948  D510          GP_TEST      288K        1                                      3090790
5667      4R    194C  D000                       FILL
5668     14R    194D  D510          OSC_TEST     288K        1                                       090800
5668      4R    194E  D000                       FILL
5669     70R    194F  0800                       OMEGA       SYNC1/2-HOT                            5090810
5670     78     1950  D5F0                       88K         15                                     6090820
```

```
                                **                                                              090830
                                *   DEBUG PROGRAM                                               DB090840
                                *   INCLUDE THE FOLLOWING CONSTANTS                             090850
                                *       HX1000, HX001F, HX007E, HX000F, HX0007                  090860
                                *   HAVE FOLLOWING LABELS:                                      090870
                                *   1   ROLL            FIRST BSS                               090880
                                *   2   START_CKSUM     START OF CHECKSUM AREA                  090890
                                *   3   END_CKSUM       CHECKSUM AT END OF CHECKSUM AREA        090900
                                *   DEBUG USES THE SPACE BETWEEN 1 AND 3                        090910
                                *      REGISTERS USED                                           DB090920
                                *         0   SCRATCH                                           DB090930
                                *         1   CURRENT ADDRESS                                   DB090940
                                *         2   DATA 1                                           DB090950
                                *         3   DATA 2                                           DB090960
                                *         4   HEX-KEY                                         DB090970
                                *         5   UPDATE INDEX                                     DB090980
                                *         6   DISPLAY MODE                                     DB090990
                                *         7   HOLD MARKER                                      DB091000
                                *         8   PATCH ADDRESS                                    DB091010
                                *         9   CORR. ADDRESS                                    DB091020
5671                            OMEGA_DEBUG_ENTRY;                                              091030
5671    10R     1951  FC0A014D          CLAD    0,,DB_PCHAD                                     091040
5672    38R     1953  FC7C0C78  $1      FET     7,,DB_MODE                                      DB091050
5673    46      1955  F40F8E10          SNS     0,,PMU_KEYBOARD_REQUEST                         DB091060
5674    50      1957  D258   (1980)     BRL     DB_UPDATE       NO KEY                          DB091070
5675     8R     1958  F80FCE08  $2      IOC     0,,READ_PMU_KEYBOARD                            DB091080
5676    18      195A  F40D00D0          PIP     0,,PMU_INPUT                                    DB091090
5677    24      195C  9E50   (00D0)     CLA     0,,PMU_INPUT                                    DB091100
5678    28      195D  F809FFFF          COMM    0,,X(FFFF)                                      DB091110
5679    32      195F  D014   (1964)     BNE     DB_DECODE                                       DB091120
5680     2R     1960  9C00              CLAM    0,,0            NO PMU                          DB091130
5681    10      1961  7050   (00D0)     STA     0,,PMU_INPUT                                    DB091140
5682    16      1962  04001989          BUC     DB_PNBWE$4                                      DB091150
                                *   DECODE KEYBOARD INPUT                                       DB091160
5683     8R     1964  E47000E1  DB_DECODE EXT    7,0,HX1000      BIT 13                          DB091170
5684    16      1966  E4001775          EXT     0,0,HX001F      BITS 1 THROUGH 5                DB091180
5685    20      1968  F8090018          COMM    0,,27                                           DB091190
5686    24      196A  D125   (1980)     BGE     DB_UPDATE                                       DB091200
5687     2R     1968  980F              COMM    0,,15                                           DB091210
5688    12      196C  C7031A40          BRG     IX0,,DB_JUMP_TABLE-16                           DB091220
                                *   HEXADECIMAL CHARACTER RECEIVED                              DB091230
5689     2R     196E  9840              COMM    4,,0            TEST HEX_KEY                    DB091240
5690     8      196F  040519C8          BRL     DB_HEX          DISPLAY SELECT                  DB091250
```

```
5691    4R  1971  D036  (1978)          BRG     $2              NEW ADDRESS                    DB091260
5692    2R  1972  9C10                  CLAM    1,,0                                           DB091270
5693    4   1973  9C41                  CLAM    4,,1                                           DB091280
5694    4R  1974  F4140010      $1      LSA     1,,4            CONTINUE ADDRESS               DB091290
5695    6   1976  8410                  ADD     1,0                                            DB091300
5696   10   1977  D008  (1980)          BUC     DB_UPDATE                                      DB091310
5697    2R  1978  9842          $2      COMM    4,,2                                           DB091320
5698    6   1979  D856  (1974)          BRL     $1                                             DB091330
5699    4R  197A  D032  (197D)          BRG     $3                                             DB091340
5700    4R  197B  8822                  SUBD    2,2             NEW DATA                       DB091350
5701    6   197C  9C43                  CLAM    4,,3                                           DB091360
5702    6R  197D  FC240010      $3      LSAD    2,,4            CONTINUE DATA                  DB091370
5703    8   197F  8430                  ADD     3,0                                            DB091380
                              *   UPDATE DISPLAY                                             DB091390
5704    8R  1980  F40F8E30    DB_UPDATE SNS     PMU_DISPLAY_BUSY                               DB091400
5705   12   1982  D22F  (19B2)          BGE     DB_PNBWE$2                                     DB091410
5706    2R  1983  9451                  ADDM    5,1                                            DB091420
5707   10   1984  E455176E              EXT     5,5,HX0007                                     DB091430
5708   14   1986  D217  (19AE)          BNE     DB_PNBWE$1                                     DB091440
                              *   FILL DISPLAY BUFFER                                        DB091450
5709   10R  1987  8427                  FETM    2,,7                                           DB091460
5710   12   1988  9C0C                  CLAM    0,,ALPHA+BETA   MASK FOR MRG                  DB091470
5711   14   1989  9890                  COMM    9,,0            TEST MODE                      DB091480
5712   18   198A  D026  (1991)          BGE     DB_SPECIALS$4                                  DB091490
5713    8R  198B  F51A1FF8    DB_SPECIALS CLA     X1,,DB_WAT                                     DB091500
5714   18   198D  F11700AA              STA     X1,,DB_BUFFER                                  DB091510
5715   26   198F  C415  (1988)          BXU     1,,DB_SPECIALS                                 DB091520
5716    4R  1990  D10C  (19AD)          BUC     DB_PNBWE                                       DB091530
5717   12R  1991  EC9000A1      $4      MRG     9,0,PMU_INDICATOR_WORD                         DB091540
5718   16   1993  D06A  (199E)          BRE     $1              SKIP UNLESS WRITE OR PATCH MODE DB091550
5719    2R  1994  9C23                  CLAM    2,,3                                           DB091560
5720   14   1995  F85700AE              STAD    5,,DB_BUFFER+4                                 DB091570
5721   16   1997  9898                  COMM    9,,ALPHA                                       DB091580
5722   20   1998  D06A  (19A3)          BRE     $2              SKIP IF WRITE MODE             DB091590
5723   10R  1999  F0B700B0              STA     11,,DB_BUFFER+6 SHOW NEXT PATCH ADDRESS        DB091600
5724   16   199B  A5B0                  CLA     X11,,0          AND CONTENTS                   DB091610
5725   24   199C  7031  (00B1)          STA     0,,DB_BUFFER+7                                 DB091620
5726   28   199D  D00F  (19AD)          BUC     DB_PNBWE                                       DB091630
5727    8R  199E  F40A1FFE      $1      CLA     0,,DB_WAT+6     TEST FOR (CA) DISPLAY          DB091640
5728   14   19A0  9A7C  (00FC)          COM     0,,DB_M1_ADD    IN DISPLAY MODE                DB091650
5729   18   19A1  D011  (19A3)          BNE     $2                                             DB091660
5730    2R  19A2  9C25                  CLAM    2,,5            BLOCK CA OVERWRITE             DB091670
5731   10R  19A3  F0470080      $2      STA     4,,DB_BUFFER+6  PREPARE TO SHOW CA, (CA)        DB091680
```

```
5732    16    19A5  A540                      CLA     X4,,0                                  DB091690
5733    24    19A6  7031   (00B1)             STA     0,,DB_BUFFER+7                         DB091700
5734     8R   19A7  F51A1FF8           $3     CLA     X1,,DB_WAT                             DB091710
5735    14    19A9  A500                      CLA     X0,,0                                  DB091720
5736    24    19AA  F11700AA                  STA     X1,,DB_BUFFER                          DB091730
5737    32    19AC  C416   (19A7)             BXU     1,,$3                                  DB091740
                         *   POP NEXT BUFFER WORD AND EXIT                                   DB091750
5738    12R   19AD  D720              DB_PNBWE  PRN     2                                      DB091760
5739    10R   19AE  F95FDE00          $1        IOC     X5,,LOAD_PMU_REGISTER                  DB091770
5740    20    19B0  FD5D00AA                    POP     X5,,DB_BUFFER                          DB091780
5741     6R   19B2  9E21   (00A1)     $2        CLA     0,,PMU_INDICATOR_WORD                  DB091790
5742    16    19B3  F10F8E10                    SET     X0,,PMU_INDICATORS                     DB091800
5743    18    19B5  9870                        COMM    7,,0            TEST HOLD MARKER       DB091810
5744    22    19B6  D015   (19BC)             BNE     $5              HOLD MODE              DB091820
5745     2R   19B7  9C00          $3          CLAM    0,,0            SET ZERO INDICATOR     DB091830
5746     4    19B8  DF10                      LGC     1,,0            ENABLE INTERRUPTS      DB091840
5747    38R   19B9  F4770078      $4          PTR     7,,DB_MODE                             DB091850
5748    52    19BB  D510                      BBK     1                                      DB091860
5749     2R   19BC  DF00          $5          LGC     0,,0            INHIBIT INTERRUPTS     DB091870
5750    40    19BD  F4770078                  PTR     7,,DB_MODE                             DB091880
5751    46    19BF  04001951                  BUC     OMEGA_DEBUG_ENTRY     LOOP WITHIN DEBUG 091890
                         *   ACTION ROUTINES FOR NON-HEX CHARACTERS                          DB091900
5752     2R   19C1  8C41          DB_DISPLAY CLSM    4,,1            SET HEX-KEY _VE FOR DISPLAY DB091910
5753     8    19C2  04001980                  BUC     DB_UPDATE                              DB091920
5754     2R   19C4  9C42          DB_DATA    CLAM    4,,2            SET HEX-KEY FOR DATA   DB091930
5755     4    19C5  9E6C                      COMM    6,,ALPHA+BETA   TEST FOR PATCH MODE     DB091940
5756    10    19C6  04061980                  BRE     DB_UPDATE                              DB091950
5757     2R   19C8  9C68                      CLAM    6,,ALPHA        SET WRITE MODE         DB091960
5758     8    19C9  04001980                  BUC     DB_UPDATE                              DB091970
                         *   DISPLAY SELECT                                                  DB091980
5759     2R   19CB  9809          DB_HEX     COMM    0,,9                                   DB091990
5760     6    19CC  D168   (19E5)             BRE     $10             SPECIAL                DB092000
5761     4R   19CD  D038   (19D6)             BRG     $7              A TO F                 DB092010
5762     2R   19CE  9800                      COMM    0,,0                                   DB092020
5763     6    19CF  D161   (19E1)             BRE     $9                                     DB092030
5764     4R   19D0  F4091FF7                  ADDM    0,,DB_WAT-1     1 TO 8                 DB092040
5765     8R   19D2  7210          $8         STA     I1,0            STORE IN WAT           DB092050
5766     2R   19D3  9C40          $6         CLAM    4,,0            RESET HEX-KEY TO NEW ADDRESS DB092060
5767     8    19D4  04001980                  BUC     DB_UPDATE                              DB092070
5768     2R   19D6  8400          $7         ADD     0,0                                    DB092080
5769     6    19D7  F809001C                  COMM    0,,28                                  DB092090
5770    10    19D9  D827   (19D3)             BGE     $6              E OR F                 DB092100
5771     4R   19DA  F4091FE5                  ADDM    0,,DB_WAT-19    DOUBLE                 DB092110
```

```
5772    6        19DC  9411                    ADDM    1,,1                                    DB092120
5773    14       19DD  7210                    STA     I1,0                                    DB092130
5774    16       19DE  9011                    SUBM    1,,1                                    DB092140
5775    18       19DF  9001                    SUBM    0,,1                                    DB092150
5776    22       19E0  D80F   (19D2)           BUC     $8                                      DB092160
5777    6R       19E1  9E7C   (00FC)  $9       CLA     0,,DB_M1_ADD    CURRENT ADDRESS         DB092170
5778    16       19E2  F0071FFE                STA     0,,DB_WAT+6                             DB092180
5779    20       19E4  D902   (19D3)           BUC     $6                                      DB092190
5780    2R       19E5  9860           $10      COMM    6,,0            WAT DISPLAY - IGNORE IF DB092200
5781    6        19E6  D934   (19D3)           BRC     $6              WRITE ENABLED           DB092210
5782    2R       19E7  8C61                    CLSM    6,,1                                    DB092220
5783    6        19E8  D906   (19D3)           BUC     $6                                      DB092230
5784    2R       19E9  9411           DB_INCR  ADDM    1,,1            ADVANCE CRNT ADDRESS    DB092240
5785    4        19EA  9868                    COMM    6,,ALPHA        TEST FOR WRITE MODE     DB092250
5786    8        19EB  D100   (19FC)           BUC     DB_WRITE1$2                             DB092260
5787    2R       19EC  986C           DB_CLEAR COMM    6,,ALPHA+BETA   TEST FOR PATCH MODE     DB092270
5788    8        19ED  04061980                BRE     DB_UPDATE                               DB092280
5789    2R       19EF  9C60                    CLAM    6,,0                                    DB092290
5790    6        19F0  D90E   (19D3)           BUC     DB_HEX$6                                DB092300
5791    2R       19F1  A402           DB_WRITE2 CLA    0,2             WRITE LEFT HALF         DB092310
5792    10  *    19F2  F80D1A28                BSV     DB_WRITE                                DB092320
5793    12       19F4  9411                    ADDM    1,,1            ADVANCE CURRENT ADDRESS DB092330
5794    20  *    19F5  F80D1A2A                BSV     WRITE_DATA      RIGHT HALF              DB092340
5795    22       19F7  9011                    SUBM    1,,1                                    DB092350
5796    26       19F8  D002   (19FB)           BUC     DB_WRITE1$1                             DB092360
5797    8R  *    19F9  F80D1A2A       DB_WRITE1 BSV    WRITE_DATA      RIGHT HALF              DB092370
5798    2R       19FB  986C           $1       COMM    6,,ALPHA+BETA   TEST FOR PATCH MODE     DB092380
5799    4R       19FC  DA5A   (19D3)  $2       BRL     DB_HEX$6                                DB092390
5800    2R       19FD  9C42           $3       CLAM    4,,2            SET HEX-KEY FOR DATA    DB092400
5801    8        19FE  04001980                BUC     DB_UPDATE                               DB092410
5802    2R       1A00  9868           DB_PATCH COMM    6,,ALPHA        TEST FOR WRITE MODE     DB092420
5803    6        1A01  DA1F   (19D3)           BNE     DB_HEX$6        IGNORE IF NOT           DB092430
5804    10R      1A02  F01700A0                STA     1,,DB_SAVE      SAVE CA FOR CLEAR AND RETURN BUC DB092440
5805    22       1A04  C211                    FET     I1,1            SAVE LONG INSTRUCTION   DB092450
5806    36       1A05  F41700AA                PTR     1,,DB_BUFFER    IN DISPLAY BUFFER       DB092460
5807    46       1A07  FC87C031                STA     8,,DB_SAVEPATCHSTART                    DB092470
5808    48       1A09  9C6C                    CLAM    6,,ALPHA+BETA   SET PATCH MODE          DB092480
5809    54       1A0A  9E2A   (00AA)           CLA     0,,DB_BUFFER    TRANSPLANT SAVED INSTRUCTION DB092490
5810    62  *    1A0B  F80D1A28                BSV     DB_WRITE                                DB092500
5811    68       1A0D  9E28   (00A8)           CLA     0,,DB_BUFFER+1                          DB092510
5812    76  *    1A0E  F80D1A28                BSV     DB_WRITE                                DB092520
5813    80       1A10  D904   (19FD)           BUC     DB_WRITE1$3                             DB092530
5814    2R       1A11  986C           DB_RETURN COMM   6,,ALPHA+BETA   TEST FOR PATCH MODE     DB092540
```

```
5815        6        1A12  D113   (1A26)            BNE     DB_END_PCH$2    IF NOT, IGNORE                    DB092550
5816        8R *     1A13  F80D1A28                  BSV     WRITE_LBUC      BUILD RETURN BUC                  DB092560
5817       14        1A15  9E20   (00A0)            CLA     0,,DB_SAVE                                        DB092570
5818       16        1A16  9402                     ADDM    0,,2                                              DB092580
5819       24 *      1A17  F80D1A28                  BSV     DB_WRITE                                          DB092590
5820        2R       1A19  986C           DB_END_PCH COMM    6,,ALPHA+BETA   TEST FOR PATCH MODE              DB092600
5821        6        1A1A  D01A   (1A25)              BNE     $1              DECREMENT CA IF DISPLAY OR WRITE  DB092610
5822        2R       1A18  9C68                     CLAM    6,,ALPHA        FORCE FROM PATCH TO WRITE         DB092620
5823       10        1A1C  F41A00A0                 CLA     1,,DB_SAVE      RESTORE CA                        DB092630
5824       18 *      1A1E  F80D1A28                  BSV     WRITE_LBUC      BUILD AND PLANT LBUC TO PATCH     DB092640
5825       20        1A20  9411                     ADDM    1,,1                                              DB092650
5826       28        1A21  F40A0031                 CLA     0,,DB_SAVEPATCHSTART LSH OF LBUC                  DB092660
5827       36 *      1A23  F80D1A28                  BSV     DB_WRITE                                          DB092670
5828        2R       1A25  9011           $1         SUBM    1,,1            RESTORE OR DECRMNT, MODE DEPNDNT  DB092680
5829        6R       1A26  04001903       $2         BUC     DB_HEX$6                                          DB092690
5830        6R       1A28  9E5F   (000F)  WRITE_LBUC CLA     0,,HX0400                                         DB092700
5831       10        1A29  D001   (1A2B)             BUC     DB_WRITE                                          DB092710
5832        2R       1A2A  A403           WRITE_DATA CLA     0,3                                               DB092720
5833        2R       1A2B  9868           DB_WRITE   COMM    6,,ALPHA        TEST MODE                         DB092730
5834        6        1A2C  D250   (1A4D)             BRL     $7              NO WRITE ENABLE                   DB092740
5835        4R       1A2D  D064   (1A32)             BRE     $1                                                DB092750
5836        6R       1A2E  C008                     FET     0,8             PATCH MODE                        DB092760
5837       16        1A2F  782C   (00AC)             STAD    0,,DB_BUFFER+2  DISPLAY                          DB092770
5838       18        1A30  9491                     ADDM    9,,1            ADVANCE PATCH ADDRESS             DB092780
5839       22        1A31  D001   (1A33)             BUC     $2                                                DB092790
5840        6R       1A32  C001           $1         FET     0,1             CHANGE MODE                       DB092800
5841        8R       1A33  C100           $2         FET     X0,,0           OLD DATA                          DB092810
5842       16        1A34  F00F8E20                 SET     DISABLE_MEMORY_PROTECT                            DB092820
5843       24        1A36  7221                     STA     I2,1            NEW DATA                          DB092830
5844       26        1A37  8002                     SUB     0,2             OLD - NEW FOR CHECKSUM            DB092840
                                         *  COMPARE WITH CHECKSUM LIMITS (32K ONLY)                           DB092850
5845       30        1A38  F81900D5                 COMM    1,,START_CKSUM                                    DB092860
5846       34        1A3A  D05F   (1A4A)             BRL     $6                                                DB092870
5847        4R       1A3B  F819183C                 COMM    1,,ROLL                                           DB092880
5848        8        1A3D  D02C   (1A4A)             BGE     $6                                                DB092890
5849        8R       1A3E  F4080158                 ADD     0,,DB_CKSUM                                       DB092900
5850       10        1A40  9888                     COMM    8,,ALPHA                                          DB092910
5851       14        1A41  D063   (1A45)             BRE     $8              CHANGE MODE                       DB092920
5852        2R       1A42  9001           $5         SUBM    0,,1            ALLOW FOR INCREMENT OF PATCH ADD  DB092930
5853       12        1A43  F0A70140                 STA     10,,DB_PCHAD                                      DB092940
5854       10R       1A45  F0070158           $8    STA     0,,DB_CKSUM                                       DB092950
5855       12        1A47  9C01                     CLAM    0,,1                                              DB092960
5856       22        1A48  F0071C05                 STA     0,,DB_CKSUM_IGNORE MRKR FOR PRESENT CKSUM PASS    DB092970
```

```
5857        8R      1A4A  F00F8E21      $6          SET     ENABLE_MEMORY_PROTECT      D8092980
5858        22      1A4C  0510                      BBK     1                          D8092990
5859        2R      1A4D  94E2          $7          ADDM    14,,2                      D8093000
5860        8       1A4E  04001903                  BUC     DB_HEX$6                   D8093010
```

```
                **                                                      DB093020
                *                KEYBOARD CODING AND LAYOUT             DB093030
                *                                                       DB093040
                *    -------                  ---------------          DB093050
                *   |21     |                |22     |25     |         DB093060
                *   |       |                | WRITE | WRITE |         DB093070
                *   |       |                |   1   |   2   |         DB093080
                *   | CLEAR |                |-------|-------|         DB093090
                *   |       |                |17     |26     |         DB093100
                *   |       |                | PATCH |       |         DB093110
                *   |       |      HEX       |       |       |         DB093120
                *   |-------|                |-------|  INC  |         DB093130
                *   |20     |      KEYS      |18     |       |         DB093140
                *   |       |                |RETURN |       |         DB093150
                *   |       |                |       |       |         DB093160
                *   | DISP  |                |-------|-------|         DB093170
                *   |       |                |19     |24     |         DB093180
                *   |       |                |END PCH| DATA  |         DB093190
                *   |       |                |       |       |         DB093200
                *    -------                  ---------------          DB093210
                *                                                       DB093220
                *   JUMP TABLE FOR ACTION KEYS                          DB093230
5861            D8_JUMP_TABLE:                                         DB093240
5861  1A50 1980          CON     D8_UPDATE                             DB093250
5862  1A51 1A00          CON     D8_PATCH                              DB093260
5863  1A52 1A11          CON     D8_RETURN                             DB093270
5864  1A53 1A19          CON     D8_END_PCH                            DB093280
5865  1A54 19C1          CON     D8_DISPLAY                            DB093290
5866  1A55 19EC          CON     D8_CLEAR                              DB093300
5867  1A56 19F9          CON     D8_WRITE1                             DB093310
5868  1A57 1980          CON     D8_UPDATE                             DB093320
5869  1A58 19C4          CON     D8_DATA                               DB093330
5870  1A59 19F1          CON     D8_WRITE2                             DB093340
5871  1A5A 19E9          CON     D8_INCR                               DB093350
5872  1A58 C8F6          ECS                                           093360
```

```
                                                                                                093370
5873                                    TAPE        4,X(73)                                     093380
5874                                    TAPE        3,12                                        093390
5875                                    TAPE        4,X(71)                                     093400
5876                                    TAPE        1                                           093410
5877                1ASC                SCS                                                     093420
5878                0156                ORG         PROG_ID_DB                                  093430
5879                0156  0000          CON         0           DISPLAY 00 FOR BIT ON C_I       093440
```

```
                                                                                                                    093450
                                                                                                                    093460
                    *    PRE-FLIGHT RUNNING TESTS                                                                  TS093470
                    *        THIS IS THE FIRST OMEGA TASK                                                          TS093480
                    *        R0,1 = TIME                                                                           TS093490
5880        1947                    ORG         END_CKSUM+1                                                         093500
5881   14R  1947  D510              BBK         1                       OMEGA_DEBUG ENTRY                           093510
5882   30R  1948  D590              BBK         9                         '     '  $2 ENTRY                       093520
5883    6R  1949  04001984          2BUC        AD_IO_TEST_ENTRY                                                    093530
5884    6R  194B  04001A31          2BUC        GP_TEST_ENTRY                                                       093540
5885    6R  194D  04001A63          2BUC        OSC_TEST_ENTRY                                                      093550
5886                    PREFLIGHT_TEST,;                                                                            TS093560
5886   70R  194F  0809              PREAMP_TEST OMEGA       TEST2/2-HOT     "NEXT TST AFTER A 1 SEC DELAY       TS093570
                    *                                                       "INITIALIZE PREC. FREQUENCY         *I093580
5887   78   1950  030A                        SET         RESET_PFG_COUNTDOWN  "GENERATOR IN RCVR                TS093590
                    *                                                       "RESET ALL TEST SIGNALS IN          *I093600
5888  124   1951  3000                        SIGNAL      0               "TEST SIGNAL OUTPUT WORD            TS093610
5889  132   1952  8655   (00D5)               FET         0,,HX0001       "OUTPUT SIGNALS TO                  TS093620
5890    8R  1953  C010            $11         FET         1,0             "ANTENNA SWITCHING MATRICES         TS093630
5891   26   1954  F427002C                    PTR         2,,ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2             TS093640
5892   34   1956  8410                        FETM        1,,0            "CLEAR SIN/COS REGISTERS            TS093650
5893   48   1957  F4170011                    PTR         1,,COS_10_2     "TO START DATA COLLECTION           TS093660
                    *                                                       "                                   TS093670
5894   56   1959  D5F0                        BBK         15              "RETURN TO $1 AFTER 1 SEC           TS093680
                    *                                                                                           TS093690
                    *                                                       "SET NEXT OMEGA TASK = $2           *I093700
5895   70R  195A  080A            $1          OMEGA       TEST3/2-HOT     "TO OCCUR AFTER 1 SEC DELAY         TS093710
5896   78   1958  8410                        FETM        1,,0            "COMPUTE ANGLE FOR LOOP A           TS093720
5897   92   195C  F01C0011                    FET         1,,COS_10_2                                         TS093730
5898   94   195E  A421                        CLA         2,1                                                 TS093740
5899   96   195F  B011                        SUB         1,1                                                 TS093750
5900  634   1960  1800                        ATAN        0               "COMPUTE ANGLE FOR LOOP A.          TS093760
5901  648   1961  F4171F30                    PTR         1,,BEARING_TEMPS  SAVE FOR TEST                      TS093770
5902  656   1963  8657   (00D7)               FET         0,,HX0004       "SELECT LOOP B SIGNAL               TS093780
5903  660   1964  D902   (1953)               BUC         $11                                                 TS093790
                    *                                                                                           TS093800
5904    8R  1965  8410            $2          FETM        1,,0                                                TS093810
5905   22   1966  F01C0011                    FET         1,,COS_10_2                                          093820
5906   24   1968  A421                        CLA         2,1                                                  093830
5907   26   1969  B011                        SUB         1,1                                                  093840
5908  564   196A  1800                        ATAN        0               "COMPUTE ANGLE LOOP B               TS093850
5909  572   196B  F00B1F30                    SUB         0,,BEARING_TEMPS                                     093860
5910  576   196D  D021   (196F)               BGE         $4                                                   093870
```

```
5911      2R      196E  A000                      CLS     0,0                                                  093880
5912      4R      196F  F8090580          $4      COMM    0,,PREAMP_TEST_ANGLE_LIMIT                           093890
5913      12      1971  8410                      FETM    1,0                                                  TS093900
5914      16      1972  D034   (1977)             BRG     $12                                                  TS093910
                        *       TEST PASS                                                                      *H093920
                        *                                                 FALL THROUGH                         093930
5915      14R     1973  D730              $21     PRN     3                                                    093940
5916      86      1974  F8000013                  OMEGA   TEST12/2-HOT    "SET NEXT OMEGA TASK RF TEST         093950
5917      94      1976  D5F0                      BBK     15                                                   093960
                        *         TEST  FAIL                                                                   TS093970
                        *                                                 "TEST FAIL-TURN ON MALF LAMP         *I093980
5918      18R *   1977  2EDC   (00DC)      $12     FAILD   I0,,HX0080     "                                    093990
                        *                                                 "POST ERROR TYPE IN FAIL WORD        *I094000
5919      30  *   1978  340F                      MARK    0,,15           "PREAMP - BIT 16                     TS094010
5920      34      1979  D807   (1973)             BUC     $21                                                  TS094020
5921      70R     197A  C808              RF_TEST OMEGA   TEST4/2-HOT    "TO OCCUR AFTER A 1 SEC DELAY        TS094030
5922      78      197B  8659   (00D9)             FET     0,,HX0010       "SELECT TEST+90 DEG SIGNAL           TS094040
5923      8R      197C  C010              $11     FET     1,0             "OUTPUT SELECTED SIGNAL TO ALL 3     TS094050
                        *                                                 "ANTENNA SWITCHING MATRICIES         TS094060
5924      26      197D  F427002C                  PTR     2,,ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2              TS094070
5925      16R     197F  8450              $9      FETM    5,,0            "CLEAR SIN/COS REGISTERS FOR ALL     TS094080
5926      46      1980  F4570011                  PTR     5,,COS_10_2     "3 FREQ TO START DATA COLLECTION     TS094090
                        *                                                 "                                    TS094100
5927      54      1982  D5F0                      BBK     15              "RETURN TO $1 OR $2 AFTER 1 SEC      TS094110
                        *                                                                                      TS094120
                        *                                                 "SET NEXT OMEGA TASK = RF TEST $2    *I094130
5928      70R     1983  C80D              $1      OMEGA   TEST6/2-HOT     "TO OCCUR AFTER A 1 SECOND DELAY     TS094140
5929      100     1984  F05C0011                  FET     5,,COS_10_2     "READ SIN/COS DATA COLLECTED WITH    TS094150
                        *                                                 "TEST + 90 SIGNAL                    TS094160
5930      130     1986  F4571F30                  PTR     5,,BEARING_TEMPS                                     TS094170
5931      138     1988  865A   (00DA)             FET     0,,HX0020       "SELECT TEST SIGNAL                  *S094180
5932      142     1989  D80E   (197C)             BUC     $11                                                  TS094190
                        *                                                                                      TS094200
5933      10R     198A  8424              $2      FETM    2,,4            "SET UP 3 COUNTER TO CYCLE THE       TS094210
                        *                                                 "3 FREQ IF PREFLIGHT ENTRY           TS094220
5934      6R      198B  8400              $4      FETM    0,,0            "READ SIN/COS FOR THIS FREQ FROM     TS094230
5935      16      198C  F12C0012                  FET     X2,,SIN_10_2    "SIN/COS REGISTERS.  THIS DATA       TS094240
5936      22      198E  8400                      FETM    0,,0            "WAS COLLECTED WITH TEST SIGNAL      TS094250
5937      32      198F  F14C0011                  FET     X4,,COS_10_2    "                                    TS094260
5938      570     1991  1800                      ATAN    0               "FORM ALPHA(T) = ATAN SIN/COS        TS094270
5939      576     1992  8400                      FETM    0,,0            "READ SAVED SIN/COS FOR TEST +90     *S094280
5940      586     1993  F14C1F31                  FET     X4,,BEARING_TEMPS+1                                  TS094290
5941      592     1995  8400                      FETM    0,,0            "                                    TS094300
```

```
5942    602          1996  F16C1F30                FET     X6,,BEARING_TEMPS                          TS09431
5943    1140         1998  1800                    ATAN    0               "FORM ALPHA(T+90) = ATAN SIN/COS TS09432
5944    1142         1999  8002                    SUB     0,2                                        TS09433
5945    1146         199A  F8095000                COMM    0,,RF_HI_LIM                               TS09434
                                                   *                       "IS ALPHA(T+90)            *20943
5946    1150         199C  D02A   (19A7)           BGE     $5              "- ALPHA(T) GREATER THAN"  TS09436
                                                   *                       "112.5 DEG?                TS09437
5947    4R           199D  F8093000                COMM    0,,RF_LO_LIM                               % 09438
                                                   *                       "IS ALPHA(T+90)            *20943
5948    8            199F  D047   (19A7)           BLE     $5              "- ALPHA(T) LESS THAN"     TS09440
                                                   *                       "67.5 DEG?                 TS09441
                                                   *       TEST PASS                                  *H0942
5949    14R          19A0  D730                $6  PRN     3               "ADJUST R15 ROLL           TS09443
5950    16           19A1  9401                    ADDM    0,,1                                       TS09444
                                                   *                       "DOES THE COUNTER          *20944
5951    24           19A2  CD18   (1988)           BXUD    1,,$4           "INDICATE THAT THERE ARE MORE TS09446
                                                   *                       "FREQ TO PROCESS?          TS09447
5952    12R          19A3  D720                    PRN     2                                          % 09448
                                                   *                       "SET PHASE TO DIGITAL TEST AS THE*I0944
5953    84           19A4  F8000012                OMEGA   TEST11/2-HOT    "NEXT OMEGA TASK IN .02 SEC TS09450
5954    92           19A6  D5F0                    BBK     15              "NEXT TASK = PHASE TO DIGITAL TS09451
                                                   *   TEST FAIL                                      TS09452
                                                   *                       "TEST FAIL - TURN ON MALF LAMP *I0945
5955    18R *        19A7  2EDC   (00DC)       $5  FAILD   IO,,HX0080      "                          TS09454
                                                   *                       "POST ERROR TYPE IN FAILURE WORD *I0945
5956    44 *         19A8  3551                    MARK    X5,,1           "RF = BITS 2, 4 OR 6       TS09456
5957    48           19A9  D80A   (19A0)           BUC     $6              "CONTINUE RF TEST          TS09457
```

```
                                        **                                                                  TS094580
                                        *     SIGNAL PIN                                                    #H094590
                                        *                                                                   #H094600
                                        *                                                                   #H094610
                                        * THIS RCUTINE WILL MERGE THE                                       #H094620
                                        * SINGLE ARGUMENT INTO THE TEST                                     #H094630
                                        * SIGNAL SELECT WORD WITHOUT                                        #H094640
                                        * DISTURBING THE INTERRUPT INHI-                                    #H094650
                                        * BIT OR SYSTEM OR COMPUTER OK                                      #H094660
                                        * BITS (12, 10 AND 9)                                              #H094670
                                        *                                                                   #H094680
5958      8R    19AA  F40874FF          SIGNAL_PIN  FETM    0,,X(74FF)     "GET MASK TO SAVE BITS 9, 10, 12  TS094690
5959      20    19AC  E0100023                      MRG     1,0,OUTPUT_TEST_AND_MISCELLANEOUS_SIGNALS         TS094700
                                        *                                  "AND MERGE ARGUMENT INTO TEST      TS094710
                                        *                                  "SIGNAL SELECT WORD                TS094720
5960      34    19AE  0510                        88K     1                                                 TS094730
```

```
                                                                                                                    TS094740
                                **                                                                                  TS094740
                                *                          AVIONICS TEST                                            #H094750
                                *                                                                                   #H094760
                                * THIS TEST IS EXECUTED EVERY .1 SECOND DURING SYSTEM OPERATION.                    #H094770
                                * IT EXAMINES THE A/D TEST WORD AND INDICATES A FAILURE WHEN IT                     #H094780
                                * IS OUT OF LIMITS AN EXCESSIVE NUMBER OF TIMES.  THE TEST IS                       #H094790
                                * DIVIDED UP INTO SETS OF 12 SAMPLES.  A FAILURE CONSISTS OF 3                      #H094800
                                * OR MORE BAD READINGS IN 5 CONSECUTIVE SETS.                                       #H094810
                                * SPECIAL CONTROL PROGRAM TO ENTER                                                  #H094820
                                * THE AVIONICS TEST EVERY 40 MSEC                                                   #H094830
                                * AS AN OMEGA TASK                                                                  #H094840
5961    10R   19AF  8420        AD_TEST     FETM    2,,0          "CLEAR AVIONICS TEST SCRATCH                     TS094850
5962    28    1980  F4270028              PTR     2,,AD_DATA    "STORAGE                                         TS094860
                                *                                 "SET UP NEXT OMEGA TASK TO RETURN                #I094870
5963    70R   1982  080C        $1          OMEGA   TEST5/2-HOT   "HERE IN 40 MILLISECONDS                        TS094880
                                * THE EXECUTIVE WILL START THIS                                                     #H094890
                                * OMEGA TASK EVERY 40 MSEC WHICH                                                    #H094900
                                * WILL CAUSE THE AVIONICS TEST                                                      #H094910
                                * TO BE CYCLED ONCE.  THIS PROCESS                                                  #H094920
                                * WILL CONTINUE UNTIL THE TEST                                                      #H094930
                                * GIVES A PASS OR FAIL INDICATION.                                                  #H094940
5964    78    1983  C011                  FET     1,1           "ADJUST R15 ROLL                                 TS094950
                                *                                                                                   TS094960
                                *                                                                                   TS094970
                                *                                                                                   TS094980
                                * START AVIONICS TEST - A NON                                                       #H094990
                                * OMEGA TASK                                                                        #H095000
                                *   AVIONICS TEST - PERIODIC VERSION                                                TS095010
5965                            AD_IC_TEST_ENTRY;                                                                   TS095020
5965    22R   1984  F03C002B        FET     3,,AD_DATA    "READ AD TEST PARAMETERS                                 TS095030
5966    24    1986  9C3B            CLAM    3,,11         " 1. SET COUNTER (0 TO 11)                               TS095040
                                *                           " 2. NUMBER FAILURES IN THIS SET                         TS095050
                                *                           " 3. NUMBER OF CONSECUTIVE SETS                          TS095060
                                *                           "       WITH 3 OR MORE FAILURES                          TS095070
5967    34    1987  F00C001C        FET     0,,A_TO_D_CONVERTER_TEST_LOCATION "                                     TS095080
                                *                           "THE EXPECTED VALUE IS 486 COUNTS                        TS095090
                                *                           "IN THE 10 MAGNITUDE BITS                                TS095100
5968    38    1989  F8094FF0        COMM    0,,AD_HI_LIM                                                            TS095110
                                *                           "DOES THE TEST                                           #2095120
5969    42    198B  D023  (198F)      BGE     $1            "WORD EXCEED THE EXPECTED VALUE                          TS095130
                                *                           "BY 24 COUNTS?                                           TS095140
5970    4R    198C  F8094D10        COMM    0,,AD_LO_LIM                                                            % 095150
                                *                           "IS THE TEST WORD                                        #2095160
```

```
5971    8       198E  D031  (19C0)        BRG   $2          "LESS THAN THE EXPECTED VALUE   %R095170
                                *                            "BY 24 COUNTS?                  TS095180
5972    2R      198F  9421            $1  ADDM  2,,1        "FAILURE"                       TS095190
                                *                            "INCREMENT THE NUMBER OF FAILURESTS095200
                                *                            "IN THIS SET BY 1               TS095210
                                *                            "HAVE 12 SAMPLES                *2095220
5973    10R     19C0  F43C19C8        $2  BXU   3,,$3       "BEEN TESTED TO COMPLETE"       %R095230
                                *                            "THIS SET?                      TS095240
5974    2R      19C2  9823            $3  COMM  2,,AD_SMALL                                 % 095250
                                *                             "WERE THERE"                   *1095260
5975    6       19C3  D055  (19C9)        BRL   $4           "3 OR MORE FAILURES IN THIS SET?%R095270
5976    2R      19C4  9411            $4  ADDM  1,,1         "BAD SET"                       TS095280
                                *                            "INCREMENT THE NUMBER OF SETS   TS095290
                                *                            "THAT HAVE FAILED IN A ROW      TS095300
5977    4       19C5  9815            $5  COMM  1,,AD_BIG                                  TS095310
5978    8       19C6  D053  (19CA)        BRL   $5           "HAVE 5 CONSECUTIVE SETS FAILED?%R095320
                                *                            "TEST FAIL - TURN ON MALF LAMP  *1095330
5979    18R *   19C7  2E0C  (00DC)        FAILD IO,,HX0080                                   TS095340
                                *                            "POST ERROR TYPE IN FAILURE WORD *1095350
5980    30  *   19C8  3407            $6  MARK  0,,7         "AVIONICS = BIT 8               TS095360
5981    2R      19C9  B011            $4  SUB   1,1          "RESET COUNT OF CONSECUTIVE TESTSTS095370
                                *                            "THAT HAVE FAILED               TS095380
5982    2R      19CA  B022            $5  SUB   2,2          "RESET NUMBER OF FAILURES IN THISTS095390
                                *                            "SET                            TS095400
5983    8R      19CB  D700            $3  PRN   0                                          TS095410
5984    26      19CC  F4270028            PTR   2,,AD_DATA   "SAVE AD TEST PARAMETERS        TS095420
5985    28      19CE  9C00                CLAM  0,,0         "SET TEST WORD TO ZERO SO THAT  %S095430
                                *                            "TEST WILL FAIL IF THERE IS NO  TS095440
                                *                            "INPUT FROM A/D                 TS095450
5986    38      19CF  F0070010            STA   0,,A_TO_D_CONVERTER_TEST_LOCATION            TS095460
5987    46      19D1  0230                SNS   HEADING_EXITATION_A                           095470
5988    50      19D2  D017  (19DA)        BNE   $12                                         095480
5989    6R      19D3  8401                FETM  0,,1         POST BIT 1                      095490
5990    14      19D4  0240                SNS   SPEED_EXITATION_B                           095500
5991    18      19D5  D011  (19D7)        BNE   $11                                         095510
5992    2R      19D6  9402                ADDM  0,,2                                        095520
5993    8R  *   19D7  F80D0262      $11   BSV   FAIL_EXTERNAL  POST BITS IN R0              095530
5994    12      19D9  D004  (19DE)        BUC   $13                                         095540
5995    8R      19DA  0240          $12   SNS   SPEED_EXITATION_B                           095550
5996    12      19DB  D012  (19DE)        BNE   $13                                         095560
5997    6R      19DC  8402                FETM  0,,2         POST BIT 2                      095570
5998    10      19DD  D807  (19D7)        BUC   $11                                         095580
5999    8R      19DE  F80FCE0B      $13   IOC   0,,READ_PMU_KEYBOARD                        095590
```

```
6000   18    19E0  F40D00D0            PIP    0,,PMU_INPUT   "SET INPUT FOR LAB VELOCITY   095600
6001   24    19E2  9E50   (00D0)       CLA    0,,PMU_INPUT                                 095610
6002   28    19E3  F809FFFF            COMM   0,,X(FFFF)                                   095620
6003   32    19E5  D012   (19E8)       BNE    $6             " PMU CONNECTED               095630
6004    2R   19E6  9C00                CLAM   0,,0                                        095640
6005   10    19E7  7050   (00D0)       STA    0,,PMU_INPUT                                 095650
6006   16R   19E8  D520          $6    BBK    2                                            095660
```

AD-A050 501 NORTHROP CORP HAWTHORNE CALIF ELECTRONICS DIV F/G 17/7
AN/BRN-7 COMPUTER PROGRAM SPECIFICATION. VOLUME XIII. APPENDIX.(U)
OCT 73 N00039-73-C-0209
UNCLASSIFIED NORT-73-48 NL

4 OF 4
AD A050501



END
DATE FILMED
4 -78
DDC

```
                                                                                                                    TS095670
                                **                                                                                  TS095670
                                *                    PHASE TO DIGITAL TEST                                          *H095680
                                *                                                                                   *H095690
                                * THIS TEST COMMANDS THE CONVERSION OF A FIXED SIGNAL AND CHECKS THE                *H095700
                                * RESULTING INPUT.  IT IS AN OMEGA TASK EXECUTED AFTER THE RF TEST AND             *H095710
                                * IT THEN SEQUENCES TO THE PC TEST IF IN PREFLIGHT.                                 *H095720
                                *                                                                                   *H095730
                                *                                                                                   *I095740
 6007      70R      19E9  080E  PD_TEST   OMEGA     TEST7/2-HOT   "SET NEXT OMEGA TASK = PD TEST $1               TS095750
                                *                                  "TO OCCUR AFTER A 1 SECOND DELAY               *I095760
 6008      116      19EA  3004            SIGNAL    4             "SET PHASE TO DIGITAL TEST SELECT              TS095770
                                *                                  "IN THE TEST SIGNAL OUTPUT WORD                TS095780
                                *                                  "USE COMMON PART OF RF TEST PRO-               TS095790
                                *                                  "GRAM TO CLEAR THE SIN/COS REGIS-              TS095800
                                *                                  "TERS AND EXIT UNTIL THE 1 SECOND              TS095810
 6009      122      19EB  0400197F          BUC       RF_TEST$9     "DELAY HAS ELAPSED AND PROGRAM                 TS095820
                                *                                  "RETURNS TO $1                                 TS095830
 6010      14R      19ED  8444  $1        FETM      4,,4          "SET UP 3 COUNTER TO CYCLE THE                 TS095840
                                *                                  "3 FREQ IF PREFLIGHT ENTRY                     TS095850
 6011      10R      19EE  FD3A0011 $10     CLAD      X3,,COS_10_2  "READ SIN/COS FOR THIS FREQUENCY               TS095860
 6012      12       19F0  9834            COMM      3,,4          "FROM THE SIN/COS REGISTERS                    TS095870
 6013      16       19F1  D022  (19F4)    BGE       $40           "IS THIS FREQUENCY 13.6?                       TS095880
 6014      2R       19F2  A000            CLS       0,0           "10.2 OR 11.3"                                 TS095890
                                *                                  "COMPLIMENT THE SIN AND COS SO                 TS095900
                                *                                  "THAT ALL 3 FREQ CAN BE PROCESSED              TS095910
 6015      4        19F3  A011            CLS       1,1           "IN THE SAME LOOP                              TS095920
 6016      4R       19F4  F8090640 $40     COMM      0,,PD_HI_LIM  "EXAMINE TEST INPUT                            TS095930
 6017      8        19F6  D029  (1A00)    BGE       $2            "DOES THE COS EXCEED 1600 COUNTS?              TS095940
 6018      4R       19F7  F8090200        COMM      0,,PD_LO_LIM                                                 % 095950
 6019      8        19F9  D046  (1A00)    BLE       $2            "IS THE COS LESS THAN 512 COUNTS?              TS095960
 6020      4R       19FA  F8190640        COMM      1,,PD_HI_LIM                                                 % 095970
 6021      8        19FC  D023  (1A00)    BGE       $2            "DOES THE SIN EXCEED 1600 COUNTS?              TS095980
 6022      4R       19FD  F8190200        COMM      1,,PD_LO_LIM                                                 % 095990
 6023      8        19FF  D032  (1A02)    BRG       $3            "IS THE SIN LESS THAN 512 COUNTS?              %R096000
                                *                                  "TEST FAIL - TURN ON MALF LAMP                 *I096010
 6024      18R *    1A00  2EDC  (00DC)    $2        FAILD     IO,,HX0080  "                                      TS096020
                                *                                  "POST ERROR TYPE IN FAILURE WORD               *I096030
 6025      40 *     1A01  3532            MARK      X3,,2         "PD = BITS 3, 5 OR 7                           TS096040
                                *                                  "DOES THE COUNTER                              *2096050
 6026      8R       1A02  CD35  (19EE)    $3        BXUD      3,,$10  "INDICATE THAT THERE ARE MORE              TS096060
                                *                                  "FREQ TO PROCESS?                              TS096070
 6027      16R      1A03  D740            PRN       4             "CONTINUE TO PC TEST                           TS096080
```

```
                                                                                                                    TS096090
                                **                                                                                  TS096090
                                *                          PHASE COUNTER TEST                                       *H096100
                                *                                                                                   *H096110
                                * THIS TEST COMMANDS THE PHASE COUNTER TO COUNT UP AND DOWN IN THE TEST             *H096120
                                * LOCATION AND CHECKS THE RESULT.  IT IS AN OMEGA TASK THAT IS EXECUTED             *H096130
                                * AFTER THE PD TEST DURING PREFLIGHT.  IT THEN SEQUENCES TO THE DMA TEST           *H096140
                                *                                                                                   *H096150
                                *   PHASE COUNTER IO TEST                                                           TS096160
                                *                                                    "SET NEXT OMEGA TASK = PC TEST $1  *I096170
6028    70R     1A04  080F      PC_TEST     OMEGA       TEST8/2-HOT                 "TO OCCUR AFTER A 1 SECOND DELAY   TS096180
6029    76      1A05  8400                  FETM        0,,0                        "SET PHASE COUNTER TEST LOCATION   TS096190
                                *                                                   "TO ZERO TO START DATA COLLECTION  TS096200
6030    86      1A06  F4070010              PTR         0,,PHASE_COUNTER_TEST_LOCATION                                 TS096210
                                *                                                   "SET PHASE COUNTER 'UP' TEST       *I096220
6031    132     1A08  3008                  SIGNAL      8                           "IN THE TEST SIGNAL OUTPUT WORD    TS096230
6032    140     1A09  D5F0                  BBK         15                          "RETURN TO $1 AFTER 1 SECOND       TS096240
                                *                                                                                   TS096250
                                * THE UP TEST IS COMPLETE NOW                                                       *H096260
                                * AND THE RESULTS ARE IN THE                                                        *H096270
                                * PHASE COUNTER TEST LOCATION                                                       *H096280
                                *                                                    "SET NEXT OMEGA TASK = PC TEST $2  *I096290
6033    72R     1A0A  F800001C  $1          OMEGA       TEST9/2-HOT                 "TO OCCUR AFTER A 1 SECOND DELAY   TS096300
                                *                                                   "SET PHASE COUNTER 'DOWN' TEST     *I096310
6034    118     1A0C  3000                  SIGNAL      0                           "IN THE TEST SIGNAL OUTPUT WORD    TS096320
6035    128     1A0D  F00C0010              FET         0,,PHASE_COUNTER_TEST_LOCATION                                 TS096330
6036    132     1A0F  F809C190              COMM        0,,PC_PLUS_LIM              "READ THE 'UP' TEST RESULTS        TS096340
                                *                                                   "DOES THE 'UP'                     *I096350
6037    136     1A11  D032    (1A14)        BRG         $3                          "COUNT EXCEED 400 COUNTS?          TS096360
                                *                                                   "TEST FAIL - TURN ON MALF LAMP     *I096370
6038    18R *   1A12  2EDC    (00DC)        FAILD       IO,,HX0080                                                     TS096380
                                *                                                   "POST ERROR TYPE IN FAILURE WORD   *I096390
6039    30  *   1A13  3408                  MARK        8                           "PC 'UP' = BIT 9                   TS096400
6040    12R     1A14  D5C0    $3            BBK         0                           "RETURN TO $2 AFTER 1 SECOND       TS096410
                                *                                                                                   TS096420
                                * THE DOWN TEST IS COMPLETE NOW                                                     *H096430
                                * AND THE RESULTS ARE IN THE                                                        *H096440
                                * PHASE COUNTER TEST LOCATION                                                       *H096450
6041    10R     1A15  F00C0010  $2          FET         0,,PHASE_COUNTER_TEST_LOCATION                                 TS096460
6042    12      1A17  980F                  COMM        0,,PC_END_HI_LIM            "READ THE 'DOWN' TEST RESULTS      TS096470
                                *                                                   "WHICH IS THE SUM OF THE 'UP'      TS096480
                                *                                                   "AND 'DOWN' COUNTS OVER THE TWO    TS096490
                                *                                                   "1 SECOND TEST PERIODS             TS096500
6043    16      1A18  D033    (1A1C)        BRG         $4                                                             % 096510
```

```
6044        4R      1A19  F809FFF1          *       CORM    0,,PC_END_LO_LIM    "IS THE UP - DOWN                    TS096520
                                                                                 "TOTAL OUTSIDE THE RANGE OF + 15     *2096530
6045        8       1A1B  D022   (1A1E)     *       BGE     $5                  "TO - 15 COUNTS?                     &R096540
                                             *                                   "TEST FAIL - TURN ON MALF LAMP       TS096550
                                             *                                                                        *I096560
6046        18R *   1A1C  2EDC   (000C)     $4      FAILD   IO,,HX0080                                              TS096570
                                             *                                   "POST ERROR TYPE IN FAILURE WORD     *I096580
6047        30  *   1A1D  3409                          MARK    9               "PC 'DOWN' = BIT 10                  TS096590
6048         8R     1A1E  D700               $5      PRN     0                   "SEQUENCE ON TO DMA TEST             TS096600
```

```
                                                                                                                    TS096610
                                                **                                                                  *H096620
                                                *                  DIRECT MEMORY ACCESS TEST                        *H096630
                                                *                                                                   *H096640
                                                * THIS TEST COMMANDS THE DIRECT MEMORY ACCESS TO GO TO THE TEST MODE AND*H096650
                                                * DECREMENT THE DMA TEST LOCATION WORD FOR EACH DMA INPUT (A TOTAL OF 7 *H096660
                                                * EVERY 5 MILLISEC) AND THEN CHECKS THE RESULTS.  IT IS AN OMEGA TASK   *H096670
                                                * THAT IS EXECUTED AFTER THE PC TEST  DURING PREFLIGHT.  IT IS THE LAST *H096680
                                                * PREFLIGHT TEST AND IT SEQUENCES TO THE SYNCHRONIZATION PROCESS.       *H096690
                                                *                                                                   TS096700
                                                *   IC DMA TEST                                                     *H096710
                                                *                                                                   TS096720
6049    72R     1A1F  F8000011                  DMA_TEST    OMEGA       TEST10/2-HOT    "SET NEXT OMEGA TASK = DMA TEST$1"TO OCCUR AFTER A 5 MILLISEC WAIT"SET DMA TEST BIT (13) IN THE  *I096730
                                                *                                                                   TS096740
6050    120     1A21  F0031000                              SIGNAL      X(1000)         "TEST SIGNAL OUTPUT WORD            TS096750
6051    126     1A23  8400                                  FETM        0,,0            "SET THE DMA TEST LOCATION WORD     TS096760
                                                *                                       "TO ZERO TO START DATA COLLECTION   096770
6052    136     1A24  F0070017                              STA         0,,DIRECT_MEMORY_ACCESS_TEST_LOCATION               TS096780
6053    148     1A26  D500                                  BBK         0               "RETURN TO $1 AFTER 5 MILLISEC      TS096790
                                                *                                                                   *H096800
                                                * DMA TEST IS COMPLETE NOW                                          *H096810
                                                * RESULTS ARE IN THE DMA                                            *H096820
                                                * TEST LOCATION                                                     *I096830
                                                *                                       "SET NEXT OMEGA TASK = SYNC TO      TS096840
6054    70R     1A27  0800                      $1          OMEGA       SYNC1/2-HOT     "OCCUR AFTER A 200 MILLISEC DELAY% 096850
6055    80      1A28  F00C0017                              FET         0,,DIRECT_MEMORY_ACCESS_TEST_LOCATION               % 096860
6056    84      1A2A  F809FFF9                              COMM        0,,1(-7)                                            *I096870
                                                *                                       "ARE THE DMA TEST                   TS096880
6057    88      1A2C  D062    (1A2F)                        BRE         $2              "RESULTS EQUAL TO - 7 COUNTS?       *I096890
                                                *                                       "TEST FAIL - TURN ON MALF LAMP      TS096900
6058    18R *   1A2D  2EDC    (00DC)                        FAILD       IO,,HX0080      "                                   *I096910
                                                *                                       "POST ERROR TYPE IN FAILURE WORD    TS096920
6059    30  *   1A2E  340A                                  MARK        10              "DMA TEST = BIT 11                  *I096930
                                                *                                       "TURN OFF ALL TEST SELECT BITS      TS096940
6060    46R     1A2F  3000                      $2          SIGNAL      0               "IN THE TEST SELECT OUT WORD        TS096950
6061    58      1A30  D500                                  BBK         0               "EXIT - NEXT TASK IS SYNC
```

```
                                **                                                                      TS096960
                                *                        1070 A/C TEST                                  *H096970
                                *                                                                       *H096980
                                * THIS TEST EXERCISES VARIOUS INSTRUCTIONS IN THE 1070 REPERTOIRE AND   *H096990
                                * CHECKS THE RESULTS.  IT IS A SLOW NON OMEGA TASK (ONCE PER SECOND)    *H097000
                                *                                                                       *H097010
6062                            GP_TEST_ENTRY;                                                          TS097020
6062    20R     1A31 F468F0F0           FETM    6,,X(F0F0)      "USE FETM AND FET TO LOAD REGIS-        TS097030
6063    58      1A33 F07C0159           FET     7,,AUG_MEM_TEST "TERS WITH KNOWN VALUES                 TS097040
6064    62      1A35 BC06               ADDD    0,6             "EXERCISE ADDD AND COMM                 TS097050
6065    66      1A36 F809FF22           COMM    0,,X(FF22)                                              TS097060
                                *                               "                                       *2097070
6066    70      1A38 D01B   (1A44)      BNE     $1              "ARE THE RESULTS IN ERROR?              TS097080
                                *                               "(BNE)"                                 TS097090
6067    2R      1A39 8035               SUB     3,5             "EXERCISE SUB                           TS097100
                                *                               "IS THE SIGN OF                         *2097110
6068    6       1A3A D029   (1A44)      BGE     $1              "THE RESULT IN ERROR?                   TS097120
                                *                               "(BGE)"                                 TS097130
6069    4R      1A3B F839E5E0           COMM    3,,X(E5E0)      "EXERCISE COMM                          TS097140
                                *                               "ARE THE RESULTS                        *2097150
6070    8       1A3D D046   (1A44)      BLE     $1              "OF THE SUB OR COMM IN ERROR?           TS097160
                                *                               "(BLE)                                  TS097170
6071    2R      1A3E B424               ADD     2,4             "EXERCISE ADD TO GET AN OVERFLOW        TS097180
                                *                               "DID THE ATTEMPT                        *2097190
6072    6       1A3F D074   (1A44)      BNO     $1              "TO GET AN OVERFLOW FAIL?               TS097200
                                *                               "(BNO)                                  TS097210
6073    6R      1A40 A5F0               CLA     X15,0           "EXERCISE CLA(X) FROM R15 STACK         TS097220
6074    10      1A41 F809F0F0           COMM    0,,X(F0F0)                                              TS097230
                                *                               "DID THE INDEXING                       *2097240
6075    14      1A43 D064   (1A48)      BRE     $2              "AND ROLL WORK CORRECTLY?               TS097250
                                *                               "(BRE)                                  TS097260
6076    22R     1A44 D770               $1      PRN     7       "FAILURE - ADJUST R15 STACK             TS097270
                                *                               "TEST FAIL - TURN ON MALF LAMP          *I097280
6077    18R *   1A45 2EDC   (00DC)      $10     FAILD   10,,HX0080 "                                    TS097290
                                *                               "POST ERROR TYPE IN FAILURE WORD        *I097300
6078    30  *   1A46 3408               MARK    11              "GP TEST = BIT 12                       TS097310
6079    58      1A47 D580               BBK     8               "EXIT"                                  TS097320
6080    22R     1A48 D770               $2      PRN     7       "ADJUST ROLL WITH PRN                   TS097330
6081    26      1A49 F869F0F0           COMM    6,,X(F0F0)                                              TS097340
                                *                               "DID THE PUSHDOWN                       *2097350
6082    30      1A4B D817   (1A45)      BNE     $10             "STACK ROLL THE REGISTERS WRONG?        TS097360
                                *                               "(BNE)"                                 TS097370
6083    10R     1A4C FC0A1A58           CLAD    0,,$3                 SIN ARGUMENT                      TS097380
```

```
6084    24    1A4E  F80C1A5D                FETD    0,,$4      COS ARGUMENT                          TS097390
6085   562    1A50  1800                     ATAN    0,0        "EXERCISE THE ARCTANGENT ROUTINE      TS097400
6086   572    1A51  F8081A5F                COMD    0,,$5                                            TS097410
                                  *                                "DID THE ARCTAN                   *1097420
6087   576    1A53  D81F   (1A45)            BNE     $10        "GIVE THE WRONG ANSWER?               TS097430
6088    10R   1A54  FC0A1A58                CLAD    0,,$3      SQUARE ROOT ARGUMENT                  TS097440
6089   456    1A56  1000                     SQRT    0,0        "EXERCISE THE SQUARE ROOT ROUTINE     TS097450
6090   466    1A57  F8081A61                COMD    0,,$6                                            TS097460
                                  *                                "DID THE SQUARE                   *1097470
6091   470    1A59  D815   (1A45)            BNE     $10        "ROOT GIVE THE WRONG ANSWER?          TS097480
                                  * THE TEST HAS PASSED                                             *HC97490
6092    28R   1A5A  D580                     BBK     8          "EXIT"                                TS097500
6093         1A5B  01237654           $3     COND    X(01237654)  SIN/SQRT ARG                       TS097510
6094         1A5D  89ABFEDC           $4     COND    X(89ABFEDC)  COS ARG                           TS097520
6095         1A5F  7F98A533           $5     COND    X(7F98A533)  ATAN RESULT                       TS097530
6096         1A61  0C1268F6           $6     COND    X(0C1268F6)  SQRT RESULT                       TS097540
```

```
                                    **                                                                          097550
                                    *  OSCILATOR FREQUENCY STABILITY TEST                                       097560
                                    OSC_TEST_ENTRY;                                                             097570
6097                                                                                                            097570
6097        14R         1A63  F01C0009          FET     1,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES             097580
6098        22          1A65  E4001780          EXT     0,0,HX2010      TEST FOR SYNC AND POS UNC              097590
6099        26          1A67  DC61   (1A69)     BRE     $1              BRANCH IF NO                           097600
6100        18R         1A68  D530              BBK     3                                                      097610
6101        10R         1A69  FC0A1D53    $1    CLAD    0,,P44          GET VAR OF T_O_DOT                     097620
6102        20          1A6B  F8C81AEC          COMD    0,,=DF((.05)*.250-128+36) VAR LIMIT                    097630
6103        24          1A6D  D02A   (1A78)     BGE     $23                                                    097640
6104        10R         1A6E  FC0A1C21          CLAD    0,,XXX+3        GET T_O_DOT                            097650
6105        14          1A70  D021   (1A72)     BGE     $11                                                    097660
6106         4R         1A71  A800              CLSD    0,0                                                    097670
6107        10R         1A72  F8C81AE2    $11   COMD    0,,=DF(2.5D-6B+18)  3.8 USEC IS FULL SCALE             097680
6108        14          1A74  D053   (1A78)     BRL     $23             PASS IF LESS                           097690
                                    *   FAILED THE TEST                                                         097700
6109         6R         1A75  8404              FETM    0,,4                                                   097710
6110        14  *       1A76  F800C262          BSV     FAIL_EXTERNAL                                          097720
6111        18R         1A78  D530    $23       BBK     3                                                      097730
```

```
                        **                                                                    TS097740
                        *   TOLERANCE LIMITS FOR TEST ROUTINES                                TS097750
6112    5000            RF_HI_LIM   EQU         X(5000)                                       TS097760
6113    3000            RF_LC_LIM   EQU         X(3000)                                       TS097770
6114                    PREAMP_TEST_MAGNITUDE_LIMIT;                                          TS097780
6114    0000                        EQU         0                                             TS097790
6115                    PREAMP_TEST_ANGLE_LIMIT;                                              TS097800
6115    05B0                        EQU         X(05B0)     APPROX 8 DEGREES SCALED PI        097810
                        *       ANALOG TO DIGITAL CONVERTER   RATIO                           TS097820
6116    4FF0            AD_HI_LIM   EQU         X(4FF0)                                       HH097830
6117    4010            AD_LC_LIM   EQU         X(4010)                                       HH097840
6118    0003            AD_SMALL    EQU         3                                             TS097850
6119    0005            AD_BIG      EQU         5                                             TS097860
6120    0640            PD_HI_LIM   EQU         X(0640)                                       HH097870
6121    0200            PD_LC_LIM   EQU         X(0200)                                       HH097880
6122    0190            PC_PLUS_LIM EQU         400                                           TS097890
6123                    PC_END_HI_LIM;                                                        TS097900
6123    000F                        EQU         15                                            TS097910
6124                    PC_END_LO_LIM;                                                        TS097920
6124    FFF1                        EQU         I(-15)                                        TS097930
                        *                                                                     097940
                        *                                                                     097950
6125    1A79  94C2      END_TEST    ECS                                                       097960
```

```
                                **                                                                                  097970
                                *                                                                                   097980
6126                                        TAPE        4,X(73)                                                     097990
6127                                        TAPE        3,12                                                        098000
6128                                        TAPE        4,X(F1)                                                     098010
6129                                        TAPE        1                                                           098020
6130                1A7A                    SCS                                                                     098030
6131                0157                    ORG         PROG_ID_OVL                                                 098040
6132                0157  F000              CON         X(F000)         DISPLAY ILLEGAL DIGIT (BLANK)               098050
                                *                                                                                   098060
                                *                                                                                   098070
6133                0542                    ORG         PLOT16                                                      098080
6134          6R    0542  040018AE          BUC         MAG_TAPE                                                    098090
                                *                                                                                   098100
                                *                                                                                   098110
6135                18AE                    ORG         LAT_S05_S00                                                 098120
                                *                                                                                   MT098130
                                * MAG TAPE OUTPUT PROGRAM                                                          MT098140
                                *       ENTERED BY BUC AT BEGINNING OF RECORD                                       MT098150
                                *       ENTERED BY INTERRUPT DURING RECORD OUTPUT                                   MT098160
                                *                                                                                   MT098170
6136          2R    18AE  DF00  MAG_TAPE  LGC         INTERRUPT_INHIBIT                                           MT098180
6137          20    18AF  F02C0047        FET         2,,MAG_TAPE_DATA+7                                          MT098190
6138          26    18B1  040218EF        BGE         $50                                                         MT098200
6139           8R   18B3  F80F9800        IOC         RESET_RECORDER_INTERRUPT                                    MT098210
6140          16    18B5  F80FB800        IOC         ENABLE_RECORDER_INTERRUPT                                   MT098220
6141          24    18B7  F80FC800        IOC         LOAD_RECORDER                                               MT098230
6142          34    18B9  FD1D0040        POP         X1,,MAG_TAPE_DATA                                           MT098240
6143          60    18BB  F04C0042        FET         4,,MAG_TAPE_DATA+2                                          MT098250
6144          68    18BD  F16B0040        SUB         X6,,MAG_TAPE_DATA CHECKSUM                                  MT098260
6145          78    18BF  F46C18C8        BXU         6,,$99                                                      MT098270
                                *                                                                                   MT098280
6146          10R   18C1  F41C18D0  $1    BXU         1,,$2                                                       MT098290
6147           4R   18C3  F859FFFF        COMM        5,,X(FFFF)                                                  MT098300
6148           8    18C5  D014   (18CA)   BNE         $32                                                         MT098310
6149           4R   18C6  FC290060        CLAM        2,,96           MAX MPX WORDS PER FRAME COUNT               MT098320
6150           6    18C8  9051            SUBM        5,,1            START MKR FFFE FOR MPX MODE                 MT098330
6151          10    18C9  D0C6   (18D0)   BUC         $2                                                          MT098340
6152           2R   18CA  9C51  $32       CLAM        5,,1            START MKR + FOR END OF FRAME                MT098350
                                *                                                                                   MT098360
6153          38R   18CB  F4770042  $99   PTR         7,,MAG_TAPE_DATA+2                                          MT098370
6154           6R   18CD  8400    $90    FETM        0,,0                                                        MT098380
6155           8    18CE  DF10            LGC         INTERRUPT_INHIBIT+NE                                        MT098390
```

```
6156    20      18CF  D500                    BBK     0                                                MT098400
                                              *                                                        MT098410
6157     8R     18D0  C010              $2    FET     1,0             SET UP TO OUTPUT                 MT098420
6158    12      18D1  F879FFFF                COMM    7,,X(FFFF)                                       MT098430
6159    16      18D3  D06A    (18DE)           BRE     $3              NOT MPX MODE                     MT098440
6160     8R     18D4  F55A1929                CLA     X5,,MPX_ADD     READ MPX START ADDRESSES         MT098450
6161    12      18D6  9733                    ADDM    IX3,3           ADD 2 TIMES WORD COUNT = DATA ADDMT098460
6162    16      18D7  F8390060                COMM    3,,96           CHECKSUM IF LAST WORD            MT098470
6163    20      18D9  D019    (18E3)           BNE     $10                                              MT098480
6164     2R     18DA  9C81                    CLAM    8,,1            DOUBLE MKR = 1                   MT098490
6165    46R     18DB  F4970040          $98   PTR     9,,MAG_TAPE_DATA                                 MT098500
6166    50      18DD  D901    (18CD)           BUC     $90                                              MT098510
                                              *                                                        MT098520
6167     8R     18DE  F53A1904          $3    CLA     X3,,MAG_TABLE                                    MT098530
6168    12      18E0  D022    (18E3)           BGE     $10             NOT MPX                          MT098540
6169     6R     18E1  9664    (00E4)           ADD     0,,HX8000       CLEAR MPX BIT                    MT098550
6170    12      18E2  A750                    CLA     IX5,0           READ ADDRESS                     MT098560
6171     8R     18E3  AEC0              $10   CLAD    I0,0            READ DATA                        MT098570
6172    10      18E4  9830                    COMM    3,,0            OUTPUT WORD NOW IF               MT098580
6173    14      18E5  D81B    (18D8)           BNE     $98              THIS IS FIRST WORD              MT098590
6174     2R     18E6  9850                    COMM    5,,0             OF FRAMES 2 TO 8                MT098600
6175     6      18E7  D86D    (18DB)           BRE     $98                                              MT098610
6176     4R     18E8  F879FFFF                COMM    7,,I(-1)                                         MT098620
6177     8      18EA  D910    (18DB)           BNE     $98                                              MT098630
6178    46R     18EB  F4970040                PTR     9,,MAG_TAPE_DATA                                 MT098640
6179    52      18ED  040018AE                BUC     MAG_TAPE                                         MT098650
                                              *                                                        MT098660
6180     4R     18EF  D062    (18F2)   $50    BRE     $60             START FRAME  IF 0                MT098670
6181    12R     18F0  D720                    PRN     2                                                098680
6182    16      18F1  DA05    (18CD)           BUC     $90                                              MT098690
                                              *                                                        MT098700
6183    18R     18F2  F02C0044          $60   FET     2,,MAG_TAPE_DATA+4                               MT098710
6184    26      18F4  F41A0085                CLA     1,,STATION_COUNTER                               MT098720
6185    30      18F6  D016    (18FD)           BNE     $61                                              MT098730
6186     8R     18F7  F8CF9800                IOC     RESET_RECORDER_INTERRUPT                         MT098740
6187    16      18F9  F00F8801                SET     INTER_RECORD_GAP                                 MT098750
6188    24      18F8  F80F8800                IOC     ENABLE_RECORDER_INTERRUPT                        MT098760
6189     2R     18FD  8C31              $61   CLSM    3,,1            START MKR -                      MT098770
6190     6      18FE  FC09001C                CLAM    0,,28           MAX WORD CT-1 (NOT MPX)          MT098780
6191     8      1900  9C51                    CLAM    5,,1            MAX DOUBLE COUNT                 MT098790
6192    10      1901  9C40                    CLAM    4,,0            FIRST DOUBLE COUNT               MT098800
6193    22      1902  8430                    FETM    3,,0                                             MT098810
6194    26      1903  DA06    (18DE)           BUC     $3                                               MT098820
```

```
                                *                                                                  MT098830
                                *                                                                  MT098840
                                * MAG TAPE DATA +9 = DOUBLE COUNT MAX                              MT098850
                                * MAG TAPE DATA +8 = DOUBLE COUNT                                 MT098860
                                * MAG TAPE DATA +7 = START MARKER                                 MT098870
                                *                                                                  MT098880
                                * MAG TAPE DATA +5 = FRAME COUNT                                   MT098890
                                * MAG TAPE DATA +4 = WORD COUNT MAX                               MT098900
                                * MAG TAPE DATA +3 = WORD COUNT                                   MT098910
                                * MAG TAPE DATA +2 = CHECKSUM                                     MT098920
                                * MAG TAPE DATA +1 = DATA (LSB)                                   MT098930
                                * MAG TAPE DATA +0 = DATA (MSB)                                   MT098940
                                *                                                                  MT098950
                                *                                                                  MT098960
                                *                                                                  MT098970
                                *                                                                  MT098980
                                *                                                                  MT098990
6195  1904  C0C6  MAG_TABLE  CON  GMT                                                             MT099000
6196  1905  1F08            CON  END_OF_BURST_DATA          10.2 BURST                           MT099010
6197  1906  1F0A            CON  END_OF_BURST_DATA+2        13.6 BURST                           MT099020
6198  1907  1F0C            CON  END_OF_BURST_DATA+4        11.3 BURST                           MT099030
6199  1908  1EED            CON  PHI_SUB_M                                                       MT099040
6200  1909  1EEF            CON  PHI_SUB_M+2                                                     MT099050
6201  190A  1EF1            CON  PHI_SUB_M+4                                                     MT099060
6202  190B  0024            CON  SIGMA_SQUARED_PHI_SUB_M                                         MT099070
6203  190C  0026            CON  SIGMA_SQUARED_PHI_SUB_M+2                                       MT099080
6204  190D  0028            CON  SIGMA_SQUARED_PHI_SUB_M+4                                       MT099090
6205  190E  1F69            CON  R11                                                             MT099100
6206  190F  1F6B            CON  R12                                                             MT099110
6207  1910  1F6D            CON  R13                                                             MT099120
6208  1911  1F6F            CON  R21                                                             MT099130
6209  1912  1F71            CON  R22                                                             MT099140
6210  1913  1F73            CON  R23                                                             MT099150
6211  1914  1F75            CON  R31                                                             MT099160
6212  1915  1F77            CON  R32                                                             MT099170
6213  1916  1F79            CON  R33                                                             MT099180
6214  1917  00C2            CON  PSI_A                                                           MT099190
6215  1918  0032            CON  Q_SUB_T                                                         MT099200
6216  1919  0034            CON  Q_SUB_T+2                                                       MT099210
6217  191A  1F08            CON  END_OF_BURST_DATA          10.2 SLOT                            MT099220
6218  191B  1F0A            CON  END_OF_BURST_DATA+2        13.6 SLOT                            MT099230
6219  191C  1F0C            CON  END_OF_BURST_DATA+4        11.3 SLOT                            MT099240
6220  191D  008C            CON  TIME                                                            MT099250
```

```
6221  191E  00A2                CON     V2                                  MT099260
6222  191F  008E                CON     VC2                                 MT099270
6223  1920  9921                CON       MPX_SP_ADD+X(8000)                MT099280
                          *                                                 MT099290
6224  1921  014F          MPX_SP_ADD CON  PROGRAM_ID                          MT099300
6225  1922  0151                CON     TAPE_ID                             MT099310
6226  1923  0009                CON     X(0009)                             MT099320
6227  1924  00E5                CON     STATIONS_IN_USE                     MT099330
6228  1925  0000                CON     0                                   MT099340
6229  1926  0000                CON     0                                   MT099350
6230  1927  0000                CON     0                                   MT099360
6231  1928  0000                CON     0                                   MT099370
                          *                                                 MT099380
6232  1929  1F40          MPX_ADD   CON  X(1F40)                             MT099390
6233  192A  1D8B                CON     SIGMA_SQ_N_COUNTER                  MT099400
6234  192B  1E7B                CON     SIGMA_SQ_N_COUNTER+192              MT099410
6235  192C  0022                CON     X(0022)                             MT099420
6236  192D  1C03                CON     ROLL_END                             099430
6237  192E  1CE8                CON     XXXX                                 099440
6238  192F  1D17                CON     P_MATRIX                            MT099450
6239  1930  0000                CON     0                                   MT099460
6240  1931  89D8                ECS                                         MT099470
```

```
                                                **                                                                  099480
                                                * PLOT                                                              099490
6241                                                    TAPE    4,X(73)                                             099500
6242                                                    TAPE    3,12                                                099510
6243                                                    TAPE    4,X(F1)                                             099520
6244                                                    TAPE    1                                                   099530
6245                1932                                SCS                                                         099540
6246                0157                                ORG     PROG_ID_OVL                                         099550
6247                0157  F000                          CON     X(F000)         DISPLAY ILLEGAL DIGIT (BLANK)       099560
                                                *                                                                   099570
                                                *                                                                   099580
6248                18AE                                ORG     LAT_S05_S00                                         PT099590
6249          8R    18AE  F40F8F10            PT_TYPE     SNS     PUNCH_OR_PRINTER_BUSY                               PT099600
6250          12    18B0  D025    (18B6)                BGE     $20                                                 PT099610
6251          38R   18B1  F07C1FC1                      FET     7,,PT_IMAGE-3                                       PT099620
6252          40    18B3  9840                          COMM    4,0                                                 PT099630
6253          44    18B4  D023    (18B8)                BGE     $1                                                  PT099640
6254          22R   18B5  D770                          PRN     7                                                   PT099650
6255          6R    18B6  C4000285            $20         BUC     EXEC                                                PT099660
6256          4R    18B8  D038    (18C4)      $1          BRG     $2                                                  PT099670
6257          4R    18B9  FC390084                      CLAM    3,,X(0084)      CARRIAGE RETURN                     PT099680
6258          2R    18BB  9041                $3          SUBM    4,1                                                 PT099690
6259          12R   18BC  D720                $4          PRN     2                                                   PT099700
6260          38    18BD  F4471FC4                      PTR     4,,PT_IMAGE                                         PT099710
6261          46    18BF  F80FDF01                      IOC     LOAD_PRINTER                                        PT099720
6262          56    18C1  FC0D1FC4                      POP     0,,PT_IMAGE                                         PT099730
6263          60    18C3  D80E    (18B6)                BUC     $20                                                 PT099740
6264          4R    18C4  FC390081            $2          CLAM    3,,X(0081)      SPACE                               PT099750
6265          6     18C6  8064                          COM     6,4                                                 PT099760
6266          10    18C7  D058    (18D0)                BRL     $5                                                  PT099770
6267          4R    18C8  D036    (18CF)                BRG     $6                                                  PT099780
6268          4R    18C9  FC390040                      CLAM    3,,X(0040)                                          PT099790
6269          8     18CB  F869001A                      COMM    6,,26                                               PT099800
6270          12    18CD  D011    (18CF)                BNE     $6                                                  PT099810
6271          2R    18CE  9038                          SUBM    3,,8                                                PT099820
6272          2R    18CF  9065                $6          SUBM    6,5                                                 PT099830
6273          4R    18D0  FC291FC9            $5          CLAM    2,,PT_IMAGE+5                                       PT099840
6274          2R    18D2  8027                $7          COM     2,7                                                 PT099850
6275          6     18D3  D939    (18BB)                BRG     $3                                                  PT099860
6276          6R    18D4  A602                          CLA     I0,2                                                PT099870
6277          14    18D5  E41001 0F                     EXT     1,0,HX00FF                                          PT099880
6278          22    18D7  525C    (00DC)                MPLM    I0,,HX0080                                          PT099890
6279          26    18D8  D065    (18DE)                BRE     $10                                                 PT099900
```

```
6280      2R    18D9  8014            COM     1,4                          PT099910
6281      6     18DA  D011  (18DC)    BNE     $14                          PT099920
6282      2R    18DB  A430            CLA     3,0                          PT099930
6283      2R    18DC  9424      $14   ADDM    2,4                          PT099940
6284      6     18DD  D80C  (18D2)    BUC     $7                           PT099950
6285      2R    18DE  8014      $10   COM     1,4                          PT099960
6286      6     18DF  D062  (18E2)    BRE     $11                          PT099970
6287      2R    18E0  9423            ADDM    2,3                          PT099980
6288      6     18E1  D900  (18D2)    BUC     $7                           PT099990
6289      2R    18E2  9850      $11   COMM    5,0                          PT100000
6290      6     18E3  D011  (18E5)    BNE     $12                          PT100010
6291      2R    18E4  9C54            CLAM    5,4                          PT100020
6292      6R    18E5  A522      $12   CLA     X2,2                         PT100030
6293      14    18E6  5659  (00D9)    MIEM    IO,,HX0010                   PT100040
6294      22    18E7  7122            STA     X2,2                         PT100050
6295      30    18E8  5664  (00E4)    MIEM    IO,,HX8000                   PT100060
6296      32    18E9  DE50            FLG     A+L                          PT100070
6297      40    18EA  E400176E        EXT     0,0,HX0007                   PT100080
6298      48    18EC  F50A18F5        CLA     X0,,$16                      PT100090
6299      52    18EE  D081  (18F0)    BAT     $13                          PT100100
6300      8R    18EF  525C  (00DC)    MPLM    IO,,HX0080                   PT100110
6301      2R    18F0  9051      $13   SUBM    5,1                          PT100120
6302      6     18F1  D011  (18F3)    BNE     $15                          PT100130
6303      2R    18F2  9044            SUBM    4,4                          PT100140
6304      2R    18F3  A430      $15   CLA     3,0                          PT100150
6305      6     18F4  D8C9  (18BC)    BUC     $4                           PT100160
6306            18F5  387F      $16   CON     X(387F)          0,1         PT100170
6307            18F6  763E            CON     X(763E)          2,3         PT100180
6308            18F7  753D            CON     X(753D)          4,5         PT100190
6309            18F8  347C            CON     X(347C)          6,7         PT100200
6310            18F9  7931            CON     X(7931)          8,9         PT100210
6311            18FA  4F46            CON     X(4F46)          A,B         PT100220
6312            18FB  0E45            CON     X(0E45)          C,D         PT100230
6313            18FC  0D04            CON     X(0D04)          E,F         PT100240
                                      *                                    PT100250
                                      *                                    PT100260
6314                                  PT_TYPE_SETUP;                       PT100270
6314      8R    18FD  8635  (0085)    FET     0,,STATION_COUNTER           PT100280
6315      10    18FE  9807            COMM    0,7                          PT100290
6316      14    18FF  D061  (1901)    BRE     $40                          PT100300
6317      12R   1900  D500            BBK     0                            PT100310
6318      4R    1901  FC091FC4  $40   CLAM    0,,PT_IMAGE                  PT100320
6319      28    1903  C240            FET     I4,0                         PT100330
```

```
6320    32      1904  9D55                    CLAM    X5,5            PT100340
6321    34      1905  8040                    COM     4,0             PT100350
6322    38      1906  D052  (1909)            BRL     $1              PT100360
6323     2R     1907  9810                    COMM    1,,0            PT100370
6324     6      1908  D051  (190A)            BRL     $2              PT100380
6325    22R     1909  D550            $1      BBK     5               PT100390
6326     6R     190A  A610            $2      CLA     I1,0            PT100400
6327    20R     190B  C230            $3      FET     I3,0            PT100410
6328    28      190C  525C  (000C)            MPLM    I0,,HX0080      PT100420
6329    32      190D  D019  (1917)            BNE     $4              PT100430
6330     6R     190E  A510                    CLA     X1,0            PT100440
6331    14      190F  7142                    STA     X4,2            PT100450
6332    28      1910  D730                    PRN     3               PT100460
6333    30      1911  9403                    ADDM    0,3             PT100470
6334    32      1912  8004                    COM     0,4             PT100480
6335    36      1913  D849  (1908)            BLE     $3              PT100490
6336     4R     1914  8822                    SUBD    2,2             PT100500
6337    20R     1915  7635            $5      PTR     I3,5            PT100510
6338    34      1916  D510                    BBK     1               PT100520
6339     2R     1917  DE8C            $4      FLG     A+EOR+AT        PT100530
6340    10      1918  AE61                    CLAD    I6,1            PT100540
6341     4R     1919  8862            $6      COMD    6,2             PT100550
6342     8      191A  D053  (191E)            BRL     $7              PT100560
6343     4R     191B  B862                    SUBD    6,2             PT100570
6344     8      191C  B862                    SUBD    6,2             PT100580
6345    12      191D  D805  (1919)            BUC     $6              PT100590
6346     4R     191E  D083  (1922)  $7        BAT     $8              PT100600
6347     2R     191F  DE00                    FLG     A               PT100610
6348     6      1920  A866                    CLSD    6,6             PT100620
6349    10      1921  D809  (1919)            BUC     $6              PT100630
6350   126R     1922  DC62            $8      DIVD    6,2             PT100640
6351   132      1923  4650  (000D)            MPI     0,,HX0100       PT100650
6352   142      1924  F0661932                MPY     6,,$10          PT100660
6353   148      1926  F569001A                ADDM    X6,,26          PT100670
6354   168      1928  7634                    PTR     I3,4            PT100680
6355   170      1929  9404                    ADDM    0,4             PT100690
6356   172      192A  8004                    COM     0,4             PT100700
6357   176      192B  DA41  (1908)            BLE     $3              PT100710
6358     4R     192C  FC190050                CLAM    1,,80           PT100720
6359     8      192E  FC390033                CLAM    3,,51           PT100730
6360    10      1930  9C20                    CLAM    2,0             PT100740
6361    14      1931  D90D  (1915)            BUC     $5              PT100750
6362            1932  0019            $10     CON     25              PT100760
```

```
                                        *                                                                   PT100770
                                        *                                                                    100780
6363                    1FE4            PT_DEST_LNG EQU     DESTINATION_LONGITUDE+32                        PT100790
6364                    1FE8            PT_DEST_LAT EQU     PT_DEST_LNG+4                                   PT100800
6365                    1FC4            PT_IMAGE    EQU     DESTINATION_LONGITUDE                           PT100810
6366                    173E                        ORG     PLOT1                                           PT100820
6367    14R             173E  F90C1FE4              2FETD   X0,,PT_DEST_LNG                                 PT100830
6368                    1273                        ORG     PLOT2                                           PT100840
6369    28              1273  F91C1FE4              2FETD   X1,,PT_DEST_LNG                                 PT100850
6370                    0F81                        ORG     PLOT3                                           PT100860
6371    42              0F81  FD771FE8              2PTRD   X7,,PT_DEST_LAT                                 PT100870
6372                    0F83                        ORG     PLOT4                                           PT100880
6373    54              0F83  F9571FE4              2STAD   X5,,PT_DEST_LNG                                 PT100890
6374                    1276                        ORG     PLOT5                                           PT100900
6375    68              1276  F94C1FE8              2FETD   X4,,PT_DEST_LAT                                 PT100910
6376                    1741                        ORG     PLOT6                                           PT100920
6377    82              1741  F94C1FE8              2FETD   X4,,PT_DEST_LAT                                 PT100930
6378                    113F                        ORG     PLOT11                                          PT100940
6379    86              113F  FC490003              2CLAM   4,,X(0003)      0,1                             PT100950
6380                    0146                        ORG     PLOT15                                          PT100960
6381    94  *           0146  F80D18AE              2BSV    PT_TYPE                                         PT100970
6382                    0542                        ORG     PLOT16                                          PT100980
6383    100             0542  040018FD              2BUC    PT_TYPE_SETUP                                   PT100990
                                        *                                                                   PT101000
6384                    1933                        ORG     PT_TYPE_SETUP$10+1                              PT101010
6385                    1933  43D2                  ECS                                                     PT101020
```

```
                                **                                                                  101030
                                *                                                                   101040
                                * DECIMAL PRINT ROUTINES                                           101050
                                *                                                                   101060
6386                                        TAPE        4,X(73)                                     101070
6387                                        TAPE        3,12                                        101080
6388                                        TAPE        4,X(F1)                                     101090
6389                                        TAPE        1                                           101100
                                *                                                                   101110
                                *                                                                   101120
6390            1934                        SCS                                                     101130
6391            0157                        ORG         PROG_ID_OVL                                 101140
6392            0157 F000                   CON         X(F000)                                     101150
                                *                                                                   AT101160
6393            1893                        ORG         LAT_N10_N15                                 101170
                                *                                                                   OM101180
                                * HIGH SPEED PRINTER - OUTPUT SUBROUTINES - DECIMAL OR HEXADECIMAL   OM101190
                                *                                                 REGS PRUNED:      OM101200
                                *  HSP        PRINT BITS 1-4 OF R0 AS 1 HEX CHARACTER             1 OM101210
                                *  HSP_OUT    PRINT CHARACTER IN R0                               1 OM101220
                                *  HSP_16H    PRINT R0 AS 4 HEX CHARACTERS                        1 OM101230
                                *  HSP_32H    PRINT R0,1 AS 8 HEX CHARACTERS                      2 OM101240
                                *  HSP_LINE   LINE ADVANCE                                        0 OM101250
                                *  HSP_D      PRINT R1,2 AS N DEC CHARACTERS (N-1 IN R0)          4 OM101260
                                *                                                                   OM101270
                                *                                   OUTPUT 1 CHARACTER              OM101280
6394         8R 1893 E400177D   HSP         EXT         0,0,HX000F                                  OM101290
6395        16  1895 F50A18C8               CLA         X0,,TYPE_TABLE                              OM101300
                                *                                                                   OM101310
6396         8R 1897 8663  (00E3) HSP_OUT   FET         0,,HX4000                                   OM101320
6397         2R 1898 9001   $1             SUBM        0,,1          OF 18 MICROSEC EACH = 540     OM101330
6398          6 1899 D069  (18A3)           BRE         $2                                          OM101340
6399         8R 189A F40F8F10               SNS         PUNCH_OR_PRINTER_BUSY                       OM101350
6400        12  189C D825  (1898)           BGE         $1                                          OM101360
6401        10R 189D F0171C04              STA         1,,TYPE_OUT                                 OM101370
6402        18  189F F80FDF01              IOC         0,,LOAD_PRINTER                             OM101380
6403        28  18A1 FC0D1C04              POP         0,,TYPE_OUT                                 OM101390
6404        14R 18A3 0510      $2          BBK         1                                           OM101400
                                *                                                                   OM101410
                                *                                   OUTPUT 8 CHARACTERS             OM101420
6405         8R * 18A4 F80018A6 HSP_32H     BSV         HSP_16H                                     OM101430
                                *                                                                   OM101440
                                *                                   OUTPUT 4 CHARACTERS             OM101450
```

```
6406        8R      18A6  8413          HSP_16H     FETM    1,,3                                                    0M101460
6407        6R      18A7  F425001C      $2          LSE     2,,4                                                    0M101470
6408       12       18A9  C002                      FET     0,2                                                     0M101480
6409       20  *    18AA  F8CD1893                  BSV     HSP                                                     0M101490
6410       28       18AC  C406   (18A7)             BXU     0,,$2                                                   0M101500
6411       16R      18AD  D520                      BBK     2                                                       0M101510
                                                    *                                                               0M101520
                                                    *                                   LINE ADVANCE AND DELAY      0M101530
6412       14R  *   18AE  F0020084      HSP_LINE_D  PLINE   0,,X(0084)                                              0M101540
6413        2R      18B0  9001          $1          SUBM    0,,1                                                    0M101550
6414        6       18B1  0812   (18B0)             BNE     $1                                                      0M101560
6415       12R      18B2  D500                      BBK     0                                                       0M101570
                                                    *                                                               0M101580
                                                    *                                   OUTPUT N DECIMAL CHARACTERS 0M101590
6416        8R      18B3  F4080081      HSP_D       FETM    0,,X(0081)  SPACE IN CASE DATA IS +                     0M101600
6417       10       18B5  9820                      COMM    2,,0                                                    0M101610
6418       14       18B6  0023   (18BA)             BGE     $1          PLUS                                        0M101620
6419        4R      18B7  FC090057                  CLAM    0,,X(0057)  -                                           0M101630
6420        8       18B9  A822                      CLSD    2,2                                                     0M101640
6421        8R  *   18BA  F8CD1897      $1          BSV     HSP_OUT                                                 0M101650
6422       14       18BC  8400                      FETM    0,,0        INDEX TO GO WITH NO CHAR IN R0              0M101660
6423        2R      18BD  8040          $2          COM     4,0         =0 IF NO CHAR TO LEFT OF DEC .              0M101670
6424        6       18BE  D012   (18C1)             BNE     $3                                                      0M101680
6425       14R  *   18BF  F0020040                  PLINE   0,,X(0040)  DECIMAL POINT                               0M101690
6426        6R      18C1  C002          $3          FET     0,2         GET NEXT CHAR FROM BITS 12-15 OF            0M101700
6427       12       18C2  F0040010                  RSA     0,,11       MOST SIG HALF OF DATA = BCD CHAR            0M101710
6428       20  *    18C4  F8CD1893                  BSV     HSP                                                     0M101720
6429       30       18C6  EC221AE4                  EXTD    2,2,=DX(07FFFFFF) GET RID OF LAST CHAR OUTPUT           0M101730
6430       36       18C8  4C2A                      MPIDM   2,,10       GET NEXT CHAR                               0M101740
6431       44       18C9  C40D   (18BD)             BXU     0,,$2                                                   0M101750
6432       20R      18CA  D540                      BBK     4                                                       0M101760
                                                    *                                                               0M101770
                                                    *                                                               0M101780
6433                18CB  0038          TYPE_TABLE  CON     X(0038)                                                 0M101790
6434                18CC  007F                      CON     X(007F)                                                 0M101800
6435                18CD  0076                      CON     X(0076)                                                 0M101810
6436                18CE  003E                      CON     X(003E)                                                 0M101820
6437                18CF  0075                      CON     X(0075)                                                 0M101830
6438                18D0  003D                      CON     X(003D)                                                 0M101840
6439                18D1  0034                      CON     X(0034)                                                 0M101850
6440                18D2  007C                      CON     X(007C)                                                 0M101860
6441                18D3  0079                      CON     X(0079)                                                 0M101870
6442                18D4  0031                      CON     X(0031)                                                 0M101880
```

```
6443  18D5  004F          CON     X(004F)          OM101890
6444  18D6  0046          CON     X(0046)          OM101900
6445  18D7  000E          CON     X(000E)          OM101910
6446  18D8  0045          CON     X(0045)          OM101920
6447  18D9  000D          CON     X(000D)          OM101930
6448  18DA  0004          CON     X(0004)          OM101940
                  *                                OM101950
                  *                                ATI01960
                  *                                ATI01970
6449  18DB  48CC          ECS                      101980
```

```
                                **                                                                  101990
                                *  THIS BLOCK FOR PI AND PCI TESTS WHICH REQUIRE INHIBITING THE USE  102000
                                *  OF PRCP PRED CORRECTION, ANTENNA SWITCHING ALL +, AND PROGRMR     102010
                                *  CONTROLLER FAILURE DISPLAY                                        102020
6450                                        TAPE    4,X(73)                                         102030
6451                                        TAPE    3,12                                            102040
6452                                        TAPE    4,X(F1)                                         102050
6453                                        TAPE    1                                               102060
6454                    18DC                SCS                                                     102070
6455                    0157                ORG     PROG_ID_OVL                                     102080
6456                    0157  2000          CON     X(2000)         DISPLAY DIGIT FOR C_I           102090
6457                    0E0E                ORG     PLOT17                                          102100
6458    4R              0E0E  8800          2SUBD   0,0             CAUSES PP_THETA3=0 IF SIMLTR    102110
6458    8               0E0F  0000          FILL
6459                    1764                ORG     ANTENNA_SELECT_TABLE+2                          102120
6460                    1764  0001          CON     X(1)            +A                              102130
6461                    1765  0004          CON     X(4)            +B                              102140
6462                    17CE                ORG     PHI_ZERO_FLOATER  AND PHI_ZERO_LOOP           102150
6463                    17CE  00000000      COND    0               SET TO ZERO, CAUSES DISABLED    102160
6464                    17D0  00000000      COND    0               PHASE SHIFT FOR RHO-RHO         102170
6465                    17D2  00000000      COND    0               OPERATION                       102180
6466                    17D4  57F8          ECS                                                     102190
```

```
                                                **                                                          102200
                                                *  THIS BLOCK IS FOR PRODUCTION INSP. I/O TEST OF UNUSED I/O.               102210
                                                *  REQUIRES SIS TO GENERATE INTERRUPT TO                    102220
6467                                                    TAPE    4,X(73)                                     102230
6468                                                    TAPE    3,12                                        102240
6469                                                    TAPE    4,X(F1)                                     102250
6470                                                    TAPE    1                                           102260
6471                    17D5                            SCS                                             102270
6472                    0157                            ORG     PROG_ID_OVL                             102280
6473                    0157  4000                      CON     X(4000)         C_I DISPLAY DIGIT       102290
6474                    039C                            ORG     END_OF_BURST$66                         102300
6475                    039C  D001                      CON     X(D001)         PREVENT STORE IN Q_M=38 102310
6476                    014A                            ORG     PLOT20                                  102320
6477      8R *          014A  F80D1893                  BSV     IOTEST                                  102330
6478                    0688                            ORG     VELOCITY_PROCESSING$3                   102340
6479                    0688  D000                      CON     X(D000)         NOOP FOR 0-40 KNOTS RANGE 102350
6480                    1893                            ORG     LAT_N10_N15                             102360
6481      14R           1893  F80C18F0    IOTEST        FETD    0,,HX10100      INIT RIGHT LEFT MRG BITS  102370
6482      28            1895  8446                      FETM    4,,6            LOAD LIMIT WITH NO. OF DISC'S 102380
                                                *  REG USE: 0- I FOR SNS, 1 AND 2- ACCUMULATED BIT PATTERN,  102390
                                                *                3 AND 4- BXU COUNTS, 5 AND 6- RIGHT AND LEFT 102400
                                                *                SIDE MERGE BITS.                          102410
6483      10R           1896  F50F0000    $1            SNS     X0,DOPPLER_IN_MEMORY                      102420
6484      14            1898  DC12  (1898)              BNE     $2              BRANCH IF HI              102430
6485       2R           1899  8415                      ADD     1,5             WAS LO SO ADD R BIT TO ACUM. 102440
6486       6            189A  D001  (189C)              BUC     $3                                        102450
6487       2R           189B  8416        $2            ADD     1,6             WAS HI SO ADD L BIT TO ACUM. 102460
6488       6R           189C  4C52        $3            LSAD    5,,1            MOVE L AND R BITS FOR NEXT I 102470
6489      10            189D  F4090010                  ADDM    0,,16           I+1 TO I AT 811 FOR SNS CMND 102480
6490      14            189F  F8090050                  COMM    0,,80           IS IT  HEX 50 SPECIAL CASE 102490
6491      18            18A1  D066  (18A8)              BRE     $100            IF SO MAKE IT 70          102500
6492       4R           18A2  F8090080                  COMM    0,,128          IS IT HEX 80 RSLT OF SP CASE 102510
6493       8            18A4  D015  (18AA)              BNE     $101            JMP IF NOT 80             102520
6494       4R           18A5  FC090060                  CLAM    0,,96           MAKE IT HEX 60 FOR CH 6   102530
6495       8            18A7  D002  (18AA)              BUC     $101                                      102540
6496       4R           18A8  FC090070    $100          CLAM    0,,112          MAKE IT HEX 70 FOR CH 5   102550
6497       8R           18AA  C535  (1896)  $101        BXU     3,,$1                                     102560
6498      10R           18AB  F017003A                  STA     1,,DMAX1        SAVE IN DMA WD FOR DISPLAY 102570
6499      20            18AD  F8150010                  RSLD    1,,11           STRIP BITS 12,13, KEEP BITS. 102580
6500      26            18AF  F0152000                  RSL     1,,2            15,14,11,10,9 AND RIGHT ADJ 102590
6501      32            18B1  4C18                      LSAD    1,,3            DISPLAY NO. IN R1.        102600
6502      34            18B2  9813                      COMM    1,,3                                      102610
6503      38            18B3  D240  (18D4)              BLE     $20             GO DO SYNCHRO DISPLAY.    102620
```

```
6504        2R      1884  981A                    COMM    1,,10                                   102630
6505        6       1885  D141   (18C7)           BLE     $10             GO DO LO DISPLAY.       102640
6506        4R      1886  F8190011                COMM    1,,17                                   102650
6507        8       1888  D231   (18DA)           BRC     $99                                     102660
6508        8R      1889  F51A18D8                CLA     X1,,IOTAB1-4    START HI DISPLAY        102670
6509       10       188B  981E                    COMM    1,,14                                   102680
6510       14       188C  D045   (18C2)           BLE     $4                                      102690
6511       10R      188D  F007003C                STA     0,DMAX3                                 102700
6512       16  *    188F  F11D18DE                XEQ     X1,,IOTAB3-15                           102710
6513       20       18C1  D108   (18DA)           BUC     $99                                     102720
6514       10R      18C2  F007003B          $4    STA     0,,DMAX2                                102730
6515       22       18C4  E0000023                MRG     0,0,DMAX23                              102740
6516       26       18C6  D103   (18DA)           BUC     $99                                     102750
6517        8R      18C7  F51A18D8          $10   CLA     X1,,IOTAB1-4    START LO DISPLAY        102760
6518       18       18C9  F007003C                STA     0,,DMAX3                                102770
6519       20       18CB  9817                    COMM    1,,7                                    102780
6520       24       18CC  D043   (18D0)           BLE     $57                                     102790
6521        6R  *    18CD  F11D18E2                XEQ     X1,,IOTAB2-8                            102800
6522       10       18CF  D00A   (18DA)           BUC     $99                                     102810
6523        2R      18D0  8022                $57   SUB     2,2                                     102820
6524       14       18D1  E0200023                MRG     2,0,DMAX23                              102830
6525       18       18D3  D006   (18DA)           BUC     $99                                     102840
6526        2R      18D4  8411                $20   ADD     1,1             SYNCHRO DISPLAY         102850
6527        4       18D5  A421                    CLA     2,1                                     102860
6528       14       18D6  F02A0018                CLAD    X2,,CH0                                 102870
6529       26       18D8  F8070038                STAD    0,,DMAX4                                102880
6530       20R      18DA  D760                $99   PRN     6                                       102890
6531        8R      18DB  D5F0                $90   BBK     15              EXIT UNTILL NEXT INTERRUPT  102900
6532                 18DC  8000          IOTAB1    CON     X(8000)                                 102910
6533                 18DD  4000                    CON     X(4000)                                 102920
6534                 18DE  2000                    CON     X(2000)                                 102930
6535                 18DF  0400                    CON     X(0400)                                 102940
6536                 18E0  0008                    CON     X(0008)                                 102950
6537                 18E1  0010                    CON     X(0010)                                 102960
6538                 18E2  0020                    CON     X(0020)                                 102970
6539                 18E3  8000                    CON     X(8000)                                 102980
6540                 18E4  4000                    CON     X(4000)                                 102990
6541                 18E5  2000                    CON     X(2000)                                 103000
6542                 18E6  0400                    CON     X(0400)                                 103010
6543                 18E7  0001                    CON     X(0001)                                 103020
6544                 18E8  0002                    CON     X(0002)                                 103030
6545                 18E9  0004                    CON     X(0004)                                 103040
6546        8R       18EA  0300          IOTAB2    SET     0               DC LO 4                 103050
```

```
6547    16      18E8  0304                    SET     4               DC LO 5     103060
6548    24      18EC  0306                    SET     6               DC LO 6     103070
6549     8R     18ED  0302      IOTA83        SET     2               DC HI 4     103080
6550    16      18EE  0304                    SET     4               DC HI 5     103090
6551    24      18EF  0306                    SET     6               DC HI 6     103100
6552            18F0  00010100  HX10100       COND    X(00010100)     MASK        103110
6553            003A              DMAX1       EQU     X(003A)                     103120
6554            0038              DMAX2       EQU     X(0038)                     103130
6555            003C              DMAX3       EQU     X(003C)                     103140
6556            0038              DMAX4       EQU     X(0038)                     103150
6557            0023              DMAX23      EQU     X(0023)                     103160
6558            18F2  DFE4                    ECS                                 103170
```

```
                                                **                                                      103180
                                                *  THIS BLOCK IS THE PCI NAVIGATION PERFORMANCE 24 HOUR TEST,           103190
                                                *  IT ALSO IS USED FOR PCI TIMMING TEST. NO RZ CALCULATIONS ARE         103200
                                                *  ALLOWED BECAUSE RZ UPDATES ARE DELETED.                              103210
6559                                                        TAPE    4,X(73)                                             103220
6560                                                        TAPE    3,12                                                103230
6561                                                        TAPE    4,X(F1)                                             103240
6562                                                        TAPE    1                                                   103250
6563                    18F3                                SCS                                                         103260
6564                    00E5                                ORG     STATIONS_IN_USE                                     103270
6565                    00E5    040E                        CON     X(040E)                                             103280
6566                    00E6    F8F2                        CON     X(F8F2)                                             103290
6567                    0157                                ORG     PROG_ID_OVL                                         103300
6568                    0157    6000                        CON     X(6000)                                             103310
6569                    0286                                ORG     ONE_SEC$101                                         103320
6570                    0286    0297                        CON     END_EXEC                                            103330
6571                    0287    0297                        CON     END_EXEC                                            103340
6572                    028C                                ORG     ONE_SEC$103                                         103350
6573                    028C    1815                        CON     TYPE_NAV_PERF_OUTPUT                                103360
6574                    028D    1873                        CON     NAV_PERF_DATA                                       103370
6575                    0240                                ORG     MAIN_PROGRAM                                        103380
6576      6R            0240    040017EA                    BUC     PCI_INIT        INITIALIZE PARAMETERS               103390
6577                    17DD                                ORG     LAT_N85_N90                                         103400
6578      8R *          17DD    F80D142D    POP_12_SUB      BSV     POP12           GET COUNT                           103410
6579      16            17DF    E400010E                    EXT     0,0,HXFF00      PUT CCCCCCFF, COUNTS AND            103420
6580      22            17E1    F0150080                    RSL     1,,8            2 BLANKS IN REGS 0 AND 1            103430
6581      24            17E3    8401                        ADO     0,1             FOLLOWED BY R2-R3 BOTH              103440
6582      26            17E4    A413                        CLA     1,3                                                 103450
6583      30            17E5    F4140100                    LSA     1,,8                                                103460
6584      34            17E7    F41900FF                    ADDM    1,,X(00FF)                                          103470
6585      42            17E9    D5F0                        BBK     15              EXIT                                103480
6586      32R           17EA    F4C80040    PCI_INIT        FETM    12,,I(64)       SET NUM CHARS TO TYPE OUT           103490
6587      34            17EC    A4AC                        CLA     10,12           SET CHAR POINTER                    103500
6588      36            17ED    94A1                        ADDM    10,,1           BY ONE TO INHBT IMMED. T/O          103510
6589      38            17EE    A4BC                        CLA     11,12                                               103520
6590      48            17EF    FC6A1811                    CLAD    6,,TIME_INC2    SET NEXT T/O TO OCCUR IN 15M        103530
6591      106           17F1    F4C71FE0                    PTR     12,,SXSQ        LEAVE REST ZERO                     103540
6592      128           17F3    8480                        FETM    8,,0                                                103550
6593      170           17F4    F4871F82                    PTR     8,,N6_15_COUNT  ZERO GOOD RECEPTION COUNTERS        103560
6594        8R *        17F6    F80D0243    $1              BSV     MP_CKSUM        ALL ZERO.                           103570
6595      12            17F8    D803   (17F6)               BUC     $1                                                  103580
                                                *ACCUMULATE MEAN  (SUMMATION X**2/N) AND (SUMMATION X/N)**2 TERMS    103590
                                                *FOR COMPUTATION OF STANDARD DEVIATION. ENTER ONCE FOR EACH X        103600
```

```
                                *WITH  R0 = SXSQ  2 WORDS  SUM X**2/N                                    103610
                                *      R2 = SX    2 WORSS  MEAN TERM                                     103620
                                *      R4 = N SCALED                                                     103630
                                *      R5 = N                                                            103640
                                *      R6-R8 SCRATCH                                                     103650
                                *      R9 NEW VALUE TO BE AVERAGED 2 WORDS                               103660
6596      42R   17F9 F08C1FE0   ACCUMULATE  FET   8,,SXSQ                                               103670
6597      52    17FB FC481813               ADDD  4,,N_INC       INCREMENT COUNT N                      103680
6598      54    17FD 9890                   COMM  9,,0                                                  103690
6599      58    17FE D021   (1800)          BGE   $1                                                    103700
6600       4R   17FF A899                   CLSD  9,9                                                   103710
6601       4R   1800 AC79             $1    CLAD  7,9                                                   103720
6602       8    1801 B892                   SUBD  9,2           NEWX-SX                                 103730
6603     134    1802 DC94                   DIVD  9,4           (NEWSX-SX)/N RESULT B7 OFF              103740
6604     144    1803 F8940100               RSAD  9,,7          SCALE SAME AS SX                        103750
6605     148    1805 BC29                   ADDD  2,9           (NEWX-SX)/N + SX TO SX                  103760
6606     154    1806 FC740040               LSAD  7,,6                                                  103770
6607     170    1808 6877                   MPYD  7,7           NEWX**2                                 103780
6608     174    1809 B870                   SUBD  7,0                                                   103790
6609     300    180A DC74                   DIVD  7,4                                                   103800
6610     310    1808 F8740100               RSAD  7,,7                                                  103810
6611     314    180D BC07                   ADDD  0,7           (NEWX**2 - SXSQ)/N + SXSQ               103820
6612     344    180E F4571FE0               PTR   5,,SXSQ                                               103830
6613     364    1810 D540                   BBK   4                                                     103840
6614            1811 00000384         TIME_INC2 COND  X(00000384)  I(900) SEC = 15 MIN                  103850
6615            1813 01000001         N_INC     COND  X(01000001)                                       103860
6616                                  TYPE_NAV_PERF_OUTPUT;                                             103870
6616      10R   1815 F00C0009               FET   0,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES           103880
6617      18    1817 E40000E2               EXT   0,0,HX2000    TEST FOR TRYING TO SYNC                 103890
6618      22    1819 D061   (1818)          BRE   $10                                                   103900
6619      16R   181A D520                   BBK   2             YES, SO EXIT.                           103910
6620       8R   181B F40A1FEA          $10  CLA   0,,CHAR_POINTER                                       103920
6621      20    181D 8430                   FETM  3,0                                                   103930
6622      28    181E F0481FE8               COM   4,,MAX_COUNT                                          103940
6623      32    1820 D051   (1822)          BRL   $2                                                    103950
6624      24R   1821 D560             $1    BBK   6             EXIT IF NO TYPE OUT                     103960
6625       8R   1822 F40F8F10         $2    SNS   PUNCH_OR_PRINTER_BUSY                                 103970
6626      12    1824 D824   (1821)          BGE   $1                                                    103980
6627      10R   1825 F8452000               RSLD  4,,2                                                  103990
6628      16    1827 5052                   RSL   5,,14                                                 104000
6629      18    1828 A435                   CLA   3,5                                                   104010
6630      26    1829 F54A1FC6               CLA   X4,,T_O_BUFFER                                        104020
6631       6R   182B F405C010         $3    LSE   0,,4                                                  104030
```

```
6632        14        1820  C423   (1828)          BXU     2,,$3                                    104040
6633         8R       182E  E4C0177D               EXT     0,0,HX000F                               104050
6634        16        1830  F50A183E               CLA     X0,,T_0_TABLE                            104060
6635        26        1832  F0C71C04               STA     0,,TYPE_OUT                              104070
6636        34        1834  F80FDF01               IOC     0,,LOAD_PRINTER                          104080
6637        44        1836  FC0D1C04               POF     0,,TYPE_OUT                              104090
6638        52        1838  F41A1FEA               CLA     1,,CHAR_POINTER                          104100
6639        54        183A  9411                   ADDM    1,,1                                     104110
6640        64        183B  F0171FEA               STA     1,,CHAR_POINTER                          104120
6641        88        183D  0560                   88K     6               EXIT AFTER 1CHAR TYPEOUT.  104130
6642                  183E  0038         T_0_TABLE CON     X(0038)         0                        104140
6643                  183F  007F                   CON     X(007F)         1                        104150
6644                  1840  0076                   CON     X(0076)         2                        104160
6645                  1841  003E                   CON     X(003E)         3                        104170
6646                  1842  0075                   CON     X(0075)         4                        104180
6647                  1843  0030                   CON     X(0030)         5                        104190
6648                  1844  0034                   CON     X(0034)         6                        104200
6649                  1845  007C                   CON     X(007C)         7                        104210
6650                  1846  0079                   CON     X(0079)         8                        104220
6651                  1847  0031                   CON     X(0031)         9                        104230
6652                  1848  004F                   CON     X(004F)         A                        104240
6653                  1849  0015                   CON     X(0015)         B=M                      104250
6654                  184A  0070                   CON     X(0070)         C=#                      104260
6655                  184B  0045                   CON     X(0045)         D                        104270
6656                  184C  0084                   CON     X(0084)         CR                       104280
6657                  184D  0081                   CON     X(0081)         SPACE                    104290
```

```
                                **
                                                ORG         LAT_N25_N30                                                 104300
                                                ORG         LAT_N25_N30                                                 104310
                    NAVIGATION_PERFORMANCE_DATA_COLLECTION,NAV_PERF_DATA;                                               104320
6659      10R   1873  F00C0009                  FET         0,,C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES                  104330
6660      18    1875  E40000E2                  EXT         0,0,HX2000      TEST FOR TRYING TO SYNC                     104340
6661      22    1877  D061   (1879)             BRE         $99             BRANCH IF NO                                104350
6662      16R   1878  D520                      BBK         2               YES SO EXIT                                 104360
6663      50R   1879  F0AC1FE0          $99      FET         10,,SXSQ        GET DATA.                                   104370
6664      60    187B  FC8B00EB                  ADDD        8,,=DX(00000001)  INCR SECOND COUNTER                       104380
6665      72    187D  F8871FE8                  STAD        8,,T_0_SEC_COUNT                                            104390
6666      82    187F  F8881921                  COMD        8,,ONE_DAY      IS ONE DAY UP                               104400
6667      86    1881  D063   (1885)             BRE         $1                                                          104410
6668       4R   1882  8868                      COMD        6,8             IS IT TIME TO GET DATA RDY                  104420
6669       8    1883  D26C   (1880)             BRE         $2              YES.                                        104430
6670      38R   1884  D5D0                      BBK         13              NO.                                         104440
6671       8R   1885  8410              $1      FETM        1,,0            DO END OF DAY TYO                           104450
6672      10    1886  A407                      CLA         0,7             GET NO. OF GOODS                            104460
6673       2R   1887  980A              $10     COMM        0,,10           START CONV OF GOODS NO.                     104470
6674       6    1888  D054   (188D)             BRL         $11                                                         104480
6675       2R   1889  900A                      SUBM        0,,10                                                       104490
6676       6    188A  F4190010                  ADDM        1,,16                                                       104500
6677      10    188C  D806   (1887)             BUC         $10                                                         104510
6678       2R   188D  B401              $11     ADD         0,1             CONVERTED RESULT                            104520
6679       6    188E  F409EC00                  ADDM        0,,X(EC00)      CR # BEFORE FINAL T/O.                      104530
6680      16    1890  F0071FC6                  STA         0,,T_0_BUFFER                                               104540
6681      26    1892  FC0A1FE0                  CLAD        0,,SXSQ                                                     104550
6682      36    1894  4808                      RSAD        0,,12                                                       104560
6683      46    1895  FC2A1FE2                  CLAD        2,,SX                                                       104570
6684      62    1897  6822                      MPYD        2,2             10                                          104580
6685      64    1898  A400                      CLA         0,0             WAS SUBD 0,2                                104590
6686      68    1899  D021   (189B)             BGE         $13                                                         104600
6687       4R   189A  A800                      CLSD        0,0                                                         104610
6688     446R   189B  1000              $13     SQRT        0                                                           104620
6689    1022    189C  0C04                      GEN         RANGE_DISPLAY                                               104630
6690    1026    189D  F41900FF                  ADDM        1,,X(00FF)                                                  104640
6691    1030    189F  FC09FFBF                  CLAM        0,,X(FFBF)                                                  104650
6692    1044    18A1  FC071FC7                  PTRD        0,,T_0_BUFFER+1                                             104660
6693    1048    18A3  FC09EEEE                  CLAM        0,,X(EEEE)      PUT 4 CRS IN LAST WORD                      104670
6694    1058    18A5  F0071FC9                  STA         0,,T_0_BUFFER+3                                             104680
6695    1072    18A7  F4380010                  FETM        3,,16           COUNT = 16                                  104690
6696    1094    18A9  F4371FE8                  PTR         3,,T_0_SEC_COUNT 0 TO CHAR POINTE                           104700
6697    1104    18AB  FC7A1813                  CLAD        7,,N_INC        MAKE NEXT T/O LONG TIME                     104710
6698    1116    18AD  F8771FE6                  STAD        7,,T_0_TIME                                                 104720
```

```
                    **                                                                  104740
                    *  PREPARE DATA FOR T_0_BUFFER                                      104750
6700      2R        18B0  9C11          $2          CLAM    1,,1            STATION B COUNTS   104760
6701      10  *     18B1  F80D17DD                    BSV     POP_12_SUB                      104770
6702      32        18B3  F4371FCF                  PTR     3,,T_0_BUFFER+9                 104780
6703      34        18B5  9C12                      CLAM    1,,2            STATION C  COUNTS   104790
6704      42  *     18B6  F80D17DD                    BSV     POP_12_SUB                      104800
6705      64        18B8  F4371FD1                  PTR     3,,T_0_BUFFER+11                104810
6706      66        18BA  9C13                      CLAM    1,,3            STATION D  COUNTS   104820
6707      74  *     18BB  F80D17DD                    BSV     POP_12_SUB                      104830
6708      78        18BD  FC29FFEE                  CLAM    2,,X(FFEE)      PUT CRS IN LAST WORD 104840
6709      96        18BF  F4271FD3                  PTR     2,,T_0_BUFFER+13                104850
6710     132        18C1  D7E0                      PRN     14              START TIME CALCULATION 104860
6711     140  *     18C2  F80D1386                    BSV     POP9                            104870
6712     148        18C4  E444010E                  EXT     4,4,HXFF00                      104880
6713     156        18C6  F448C10F                  ADD     4,,HX00FF                       104890
6714     168        18C8  D720                      PRN     2                               104900
6715     186        18C9  F4271FC6                  PTR     2,,T_0_BUFFER                   104910
6716     188        18CB  9C18                      CLAM    1,,11           GET LAT/LONG FOR SHIP 104920
6717     196  *     18CC  F80D1270                    BSV     POP1                            104930
6718     204        18CE  E411010E                  EXT     1,1,HXFF00                      104940
6719     212        18D0  F418010F                  ADD     1,,HX00FF                       104950
6720     220        18D2  E444010E                  EXT     4,4,HXFF00                      104960
6721     228        18D4  F448010F                  ADD     4,,HX00FF                       104970
6722     246        18D6  F4271FC8                  PTR     2,,T_0_BUFFER+2                 104980
6723     264        18D8  F4271FCA                  PTR     2,,T_0_BUFFER+4                 104990
6724     272  *     18DA  F80D12C2                    BSV     POP4            GET VAR         105000
6725     274        18DC  A424                      CLA     2,4             REPOSITION      105010
6726     280        18DD  FC141000                  LSAD    1,,12                           105020
6727     282        18DF  941F                      ADDM    1,,15           PUT BLANK ON RIGHT 105030
6728     290        18E0  D700                      PRN     0               FOR STORE.      105040
6729     300        18E1  F4071FCD                  PTR     0,,T_0_BUFFER+7 END OF VAR      105050
6730     310        18E3  FC0A1C21                  CLAD    0,,XXX+3        START T_3_DOT   105060
6731     886        18E5  0C0A                      GEN     T_0_DOT_CVT                     105070
6732     892        18E6  FC041000                  LSAD    0,,12                           105080
6733     894        18E8  940F                      ADDM    0,,15           PUT BLANK ON RIGHR 105090
6734     904        18E9  F4071FCE                  PTR     0,,T_0_BUFFER+8                 105100
6735     918        18EB  8448                      FETM    4,,8                            105110
6736     928        18EC  F0071FEC                  STA     0,,GOOD_BAD_FL  CLEAR THE FLAG  105120
6737     938        18EE  FC0A1FE6                  CLAD    0,,T_0_TIME     INNC TO NEXT T/0 TIME 105130
6738     948        18F0  FC081811                  ADDD    0,,TIME_INC2    BY 15 MIN       105140
6739     960        18F2  F8071FE6                  STAD    0,,T_0_TIME                     105150
6740      8R        18F4  F53A1D8E        $100      CLA     X3,,SIGMA_SQ_N_COUNTER+3        105160
```

```
6741    10          18F6  A410                      CLA     1,0             TO UPDATE  LATER                    105170
6742    18          18F7  F13B1FB2                  SUB     X3,,N6_15_COUNT  N TIMES UPDATED IN 15 MIN        105180
6743    20          18F9  A420                      CLA     2,0             SAVE IT                             105190
6744    22          18FA  A401                      CLA     0,1             REPLACE FOR NEXT TIME               105200
6745    32          18FB  F1371FB2                  STA     X3,,N6_15_COUNT                                     105210
6746    38          18FD  F0240080                  RSA     2,,8            RIGHT ADJUST                        105220
6747    40          18FF  9820                      COMM    2,,0            MAKE IT MOD 100                     105230
6748    44          1900  D022   (1903)             BGE     $20             IF NEGATIVE                         105240
6749     4R         1901  F4290064                  ADDM    2,,X(0064)      ADD 100                             105250
6750     2R         1903  9826            $20       COMM    2,,6            NEED 6 IN 15 MIN                    105260
6751     6          1904  D022   (1907)             BGE     $3              IF GOOD JUMP                        105270
6752    10R         1905  F0471FEC                  STA     4,,GOOD_BAD_FL   ELSE SET FLAG NON ZERO             105280
6753     8R         1907  C534   (18F4)    $3       BXU     3,,$100         TEST FOR 9 TIMES                    105290
6754    10R         1908  F0371FEA                  STA     3,,CHAR_POINTER                                     105300
6755    18          190A  F40A1FEC                  CLA     0,,GOOD_BAD_FL   TEST FLAG                          105310
6756    22          190C  D065   (1912)             BRE     $4              JUMP IF ALL GOOD                    105320
6757     8R         190D  F40A178C                  CLA     0,,HXDFFF       ELSE STORE D AND BLANKS             105330
6758    18          190F  F0071FCC                  STA     0,,T_O_BUFFER+6                                     105340
6759    58          1911  D5E0                      BBK     14              RETURN TO EXEC                      105350
6760    24R         1912  D780            $4        PRN     8                                                   105360
6761    26          1913  9C18                      CLAM    1,,11           SHIP TO                             105370
6762    28          1914  9C20                      CLAM    2,,0            FOR WAYPT NO. 1                     105380
6763    36  *       1915  F80D1483                  BSV     MAKE_RANGE_AND_BEARING                              105390
6764    44          1917  8410                      FETM    1,,0            PRESERVE FOR LATER                  105400
6765    48          1918  AC02                      CLAD    0,2                                                 105410
6766    56  *       1919  F80D17F9                  BSV     ACCUMULATE                                          105420
6767   632          191B  0C04                      GEN     RANGE_DISPLAY   RANGE IN R0,1.                       105430
6768   642          191C  F8040080                  RSAD    0,,8            POSITION RESULT                     105440
6769   652          191E  F0171FCC                  STA     1,,T_O_BUFFER+6                                     105450
6770   686          1920  D580                      BBK     11                                                  105460
6771                1921  000151C1        ONE_DAY   COND    1(86465)        ONE DAY + 65 SEC IN SECS            105470
6772                1FE0                  SXSQ      EQU     DESTINATION_LATITUDE+2  2 WORDS SQUARED TERM        105480
6773                1FE2                  SX        EQU     DESTINATION_LATITUDE+4  2 WORDS MEAN                105490
6774                                      N_GOODS_SCALED;                                                     105500
6774                1FE4                            EQU     DESTINATION_LATITUDE+6  1 WORD                      105510
6775                1FE5                  NO_GOODS  EQU     DESTINATION_LATITUDE+7  1 WORD                      105520
6776                1FE6                  T_O_TIME  EQU     DESTINATION_LATITUDE+8  2 WORDS                    105530
6777                                      T_O_SEC_COUNT;                                                      105540
6777                1FE8                            EQU     DESTINATION_LATITUDE+10 2 WORDS                    105550
6778                                      CHAR_POINTER;                                                       105560
6778                1FEA                            EQU     DESTINATION_LATITUDE+12 1 WORD                     105570
6779                1FEB                  MAX_COUNT EQU     DESTINATION_LATITUDE+13 1 WORD                     105580
6780                1FEC                  GOOD_BAD_FL EQU   DESTINATION_LATITUDE+14 1 WORD                     105590
```

```
6781  1F82            N6_15_COUNT EQU   RZ_C                          9 WORD      105600
6782  1FC6            T_O_BUFFER  EQU   DESTINATION_LONGITUDE+2       16 WORDS    105610
6783  1923  94F5                  ECS                                               105620
```

```
                    ** THIS BLOCK IS FOR PCI DYNAMIC RANGE AND RANDOM NOISE TEST                105630
                    *  IT RUNS VIA SIMULATOR, HENCE THAT BLOCK SHOULD ALSO BE LOADED            105640
6784                                        TAPE        4,X(73)                                 105650
6785                                        TAPE        3,12                                    105660
6786                                        TAPE        4,X(F1)                                 105670
6787                                        TAPE        1                                       105680
6788                1924                    SCS                                             105690
6789                00E5                    ORG         STATIONS_IN_USE                     105700
6790                00E5    040EF8F2        COND        X(040EF8F2)                         105710
6791                0146                    ORG         PLOT15                              105720
6792          8R *  0146    F80D0C4D        BSV         TYPE_DYN_RNG_DATA                   105730
6793                0157                    ORG         PROG_ID_OVL                         105740
6794                0157    9000            CON         X(9000)                             105750
6795                028C                    ORG         ONE_SEC$103                         105760
6796                028C    0297            CON         END_EXEC                            105770
6797                028D    0297            CON         END_EXEC                            105780
6798                0542                    ORG         PLOT16                              105790
6799          14    0542    040000C82       BUC         GET_DYN_RNG_DATA                    105800
6800                0683                    ORG         START_OF_BURST$77-3                 105810
6801          2R    0683    A400            CLA         0,0             NO OP               105820
6802                0767                    ORG         KALMAN_FILTER+2                     105830
6803          4     0767    A400            CLA         0,0                                 105840
6804                0240                    ORG         MAIN_PROGRAM                        105850
6805          10    0240    040017DD        BUC         DYN_RNG_INIT                        105860
6806                02B6                    ORG         ONE_SEC$101                         105870
6807                02B6    0297            CON         END_EXEC        DISABLE RZ          105880
6808                02B7    0297            CON         END_EXEC        UPDATES             105890
6809                0470                    ORG         MEASUREMENT_UPDATE$15               105900
6810          6R    0470    040017F5        BUC         SAVE_BP_DATA                        105910
6811                0686                    ORG         START_OF_BURST$77                   105920
6812          2R    0686    9C06            CLAM        0,,6            FORCE BASE STATION  105930
6813          4     0687    9C13            CLAM        1,,3            TO D                105940
6814                0C49                    ORG         PROPAGATION_PREDICTION              105950
6815          12    0C49    D5F0            BBK         15              STOP PROP           105960
6816                0380                    ORG         END_OF_BURST$8                      105970
6817                0380    D000            CON         X(D000)         STOP PHANTOM CORRECTION 105980
6818                155F                    ORG         CD13                                105990
6819                155F    CC51E000        COND        X(0051E000)     THIS GIVES XX.X IN CEC  106000
6820                1561    232E            CON         X(232E)         3 BLANKS            106010
6821                12F8                    ORG         POP8$1                              106020
6822          2R    12F8    B000            SUB         0,0                                 106030
6823                1306                    ORG         POP8$5-1                            106040
6824          4     1306    A400            CLA         0,0                                 106050
```

```
6825                1763                    ORG     ANTENNA_SELECT_TABLE+1                          106060
6826                1763  0001              CON     X(1)                                            106070
6827                1764  0001              CON     X(1)                                            106080
6828                1765  0001              CON     X(1)                                            106090
6829                17DD                    ORG     LAT_N85_N90                                     106100
6830                                DYN_RNG_INIT;                                                   106110
6830      28R       17DD  8480              FETM    11,,0                                           106120
6831      82        17DE  F4871FC6          PTR     11,,SXSC2       CLEAR DATA COLLECTOR CELLS      106130
6832      98        17E0  8450              FETM    5,,0                                            106140
6833     128        17E1  F4571FD2          PTR     5,,BPDATA2                                      106150
6834     138        17E3  F00C112A          FET     0,,HXFEFF       GET CR AND BLANKS               106160
6835     148        17E5  F0071F82          STA     0,,T_O_BUFFER2                                  106170
6836     158        17E7  F0071F89          STA     0,,T_O_BUFFER2+7                                106180
6837     168        17E9  F4071FC0          PTR     0,,T_O_BUFFER2+14                               106190
6838     180        17EB  8430              FETM    3,,0            ZEROES TO                       106200
6839     202        17EC  F4371FE0          PTR     3,,T_O_SEC_COUNT2  AND NN                       106210
6840     224        17EE  F03C0D43          FET     3,,FIVE_MIN     INITIALIZE                      106220
6841     246        17F0  F4371FE4          PTR     3,,T_O_TIME2    ,CHAR_POINT AND MAX COUNTER     106230
6842       8R *     17F2  F80D0243    $1    BSV     MP_CKSUM                                        106240
6843      12        17F4  D803   (17F2)     BUC     $1              END OF INITIALIZATION           106250
6844                                SAVE_BP_DATA;                                                   106260
6844      10R       17F5  F9581F1F          SUBD    X9,,PHI_M_BASE                                  106270
6845      12        17F7  9862              COMM    6,,2            TEST FOR STATION B              106280
6846      18        17F8  0401183D          BNE     $1                                              106290
6847       8R       17FA  C011              FET     1,1                                             106300
6848      14        17FB  C008              FET     0,11            FREQ INDEX              D01     106310
6849      18        17FC  D015   (1802)     BNE     $2              NOT 10.2                        106320
6850       8R       17FD  F0081CA1          COM     0,,SAMPLE_MKR                                   106330
6851      12        17FF  D062   (1802)     BRE     $2              NOT SAMPLE TIME                 106340
6852       8R *     1800  F80D183F          BSV     ACCUMULATEX                                     106350
6853       6R       1802  C000        $2    FET     0,0             FREQUENCY INDEX                 106360
6854      16        1803  F0071CB0          STA     0,,BPHISTORY+14                                 106370
6855      20        1805  F4091FD2          ADDM    0,,BPDATA2                                      106380
6856      38        1807  F6380D47          FETM    13,,N_SMOOTHING D(0),D(N)                       106390
6857      42        1809  F4591CA2          ADDM    5,,BPHISTORY                                    106400
6858      44        180B  9032              SUBM    3,2             N-2                             106410
6859      46        180C  B433              ADD     3,3             LIMIT=2N-4                      106420
6860      54        180D  C017              FET     1,7                                             106430
6861     488        180E  1400              SINCOS  0                                               106440
6862     498        180F  F00C1CB0          FET     0,,BPHISTORY+14                                 106450
6863     504        1811  C000              FET     0,0                                             106460
6864     508        1812  440E              MPIM    0,,14                                           106470
6865     512        1813  F4091CC2          ADDM    0,,BPHISTORY+32                         01      106480
```

```
6866   524        1815  C035                        FET       3,5                                          106490
6867   534        1816  F8241000                    RSAD      2,,3                                         106500
6868   544        1818  F8041000                    RSAD      0,,3                                         106510
6869   554        181A  F418001A                    FETM      1,,26                                        106520
6870   562        181C  C015                        FET       1,5                                          106530
6871    8R        181D  8F28              $4        ADDD      IX2,8                                        106540
6872    10        181E  9422                        ADDM      2,,2                                         106550
6873    18        181F  CC23   (181D)               BXUD      2,,$4                                        106560
6874    2R        1820  9082                        SUBM      8,,2                                         106570
6875    10        1821  C015                        FET       1,5                                          106580
6876    8R        1822  8F4A              $5        ADDD      IX4,10                                       106590
6877    10        1823  9442                        ADDM      4,,2                                         106600
6878    18        1824  CC43   (1822)               BXUD      4,,$5                                        106610
6879    6R        1825  C008                        FET       0,11                                         106620
6880    10        1826  4402                        MPIM      0,,2                                         106630
6881    14        1827  F4091D1F                    ADDM      0,,BPDATA4                                   106640
6882    26        1829  C034                        FET       3,4                                          106650
6883    46        182A  7634                        PTR       I3,4                                         106660
6884    54        182B  D700                        PRN       0                                            106670
6885   592        182C  1800                        ATAN      0                                            106680
6886   604        182D  F9971CA2                    STAD      X9,,BPHISTORY                                106690
6887   610        182F  C008                        FET       0,8                                          106700
6888   612        1830  9404                        ADDM      0,,4                                         106710
6889   618        1831  8400                        FETM      0,,0                                         106720
6890   626        1832  F4080016                    FETM      0,,22                                  01    106730
6891    12R       1834  CB08              $6        FETD      IX0,11                                       106740
6892    24        1835  7F24                        PTRD      IX2,4                                        106750
6893    32        1836  CC03   (1834)               BXUD      0,,$6                                  01    106760
6894    20R       1837  D760                        PRN       6                                            106770
6895    40        1838  7634                        PTR       I3,4                                         106780
6896    50        1839  D710                        PRN       1                                            106790
6897    52        183A  A412                        CLA       1,2                                          106800
6898    62        183B  7A08                        STAD      I0,8                                         106810
6899    92        183C  D780                        PRN       11                                           106820
6900    6R        183D  04000472          $1        BUC       MEASUREMENT_UPDATE$10                        106830
                                        * THIS ROUTINE KEEPS A RUNNING AVERAGE (SX = SUMMATION X/N) AND    106840
                                        * ALSO  SXSQ = SUMMATION X**2/N FOR THE 3 VALUES OF BP, ONE FOR    106850
                                        * EACH FREQUENCY. S.D.=ROOT(SXSQ-SX**2). RMS= ROOT(SXSQ).          106860
6901    18R       183F  F02C0D39    ACCUMULATEX FET       2,,MSXSQ2       GET ADDRESSES FOR DATA       106870
6902    32        1841  F01C0D3F                FET       1,,N_INC2                                    106880
6903    42        1843  FC081FE2                ADDD      0,,NN           INCREMENT N                  106890
6904    54        1845  F8071FE2                STAD      0,,NN                                        106900
6905    64        1847  F00C1FE2                FET       0,,NN                                        106910
```

```
6906      72    1849  841A                    FETM    1,,10                                                    106920
6907     14R    184A  F90C1D1F          $2    FETD    X0,,BPDATA4                                              106930
6908      28    184C  F92C1D2F                FETD    X2,,BPDATA4+16                                           106940
6909      32    184E  B820                    SUBD    2,0                                                      106950
6910      42    184F  F8240100                RSAD    2,,7                                                     106960
6911     168    1851  DC26                    DIVD    2,6                                                      106970
6912     172    1852  BC02                    ADDD    0,2                                                      106980
6913     186    1853  FD471D2F                PTRD    X4,,BPDATA4+16                                           106990
6914     196    1855  D710                    PRN     1                                                        107000
6915     204    1856  CC0D    (184A)          BXUD    0,,$2                                                    107010
6916     12R    1857  D720                    PRN     2                                                        107020
6917      20    1858  8414                    FETM    1,,4            GET 3 DBL CNT AND INDEX REG.             107030
6918     12R    1859  CB06              $1    FETD    IX0,6           GET LATEST BP THIS FREQ                  107040
6919      24    185A  CB27                    FETD    IX2,7                                                    107050
6920      32    185B  C014                    FET     1,4                                                      107060
6921      34    185C  B003                    SUB     0,3                                                      107070
6922      36    185D  B042                    SUB     4,2                                                      107080
6923      46    185E  F8040100                RSAD    0,,7                                                     107090
6924      56    1860  F8440100                RSAD    4,,7                                                     107100
6925     182    1862  DC08                    DIVD    0,8                                                      107110
6926     308    1863  DC48                    DIVD    4,8                                                      107120
6927     310    1864  B430                    ADD     3,0                                                      107130
6928     312    1865  B424                    ADD     2,4                                                      107140
6929     322    1866  D710                    PRN     1                                                        107150
6930     332    1867  7B49                    STAD    IX4,9                                                    107160
6931     340    1868  AF48                    CLAD    IX4,8                                                    107170
6932     354    1869  F94C1CA2                FETD    X4,,BPHISTORY                                            107180
6933     366    186B  5A63    (00E3)          MPLDM   I0,,HX4000      RSLD 1                            01     107190
6934     382    186C  6800                    MPYD    0,0             BP**2                                    107200
6935     386    186D  B802                    SUBD    0,2                   - SXSQ                             107210
6936     396    186E  F8040100                RSAD    0,,7                                                     107220
6937     522    1870  DC08                    DIVD    0,8                                                      107230
6938     526    1871  BC02                    ADDD    0,2             (BP**2-SXSQ)/N + SXSQ                    107240
6939     536    1872  7B6A                    STAD    IX6,10          SAVE SXSQ                                107250
6940     554    1873  D750                    PRN     5                                                        107260
6941     562    1874  CD0C    (1859)          BXUD    0,,$1           DO IT 3 TIMES                            107270
6942     24R    1875  D560                    BBK     6               THEN EXIT                                107280
                          *                                                                                    107290
6943            0C4D                          ORG     PROPAGATION_PREDICTION$10                                107300
6944                        TYPE_DYN_RNG_DATA;                                                                 107310
6944      8R    0C4D  F40F8F10                SNS     PUNCH_OR_PRINTER_BUSY                                    107320
6945      12    0C4F  D027    (0C57)          BGE     $21                                                      107330
6946     18R    0C50  F02C1FE6                FET     2,,CHAR_POINT                                            107340
```

```
6947    30      0C52  8430                      FETM    3,,0                                    107350
6948    38      0C53  F0481FE7                  COM     4,,MAX_COUNTER                          107360
6949    42      0C55  D053   (0C59)             BRL     $20                                     107370
6950    20R     0C56  D760                $19   PRN     6                                       107380
6951     6R     0C57  04000285          $21   BUC     EXEC                                    107390
6952    10R     0C59  F8452000          $20   RSLD    4,,2                                    107400
6953    16      0C5B  5052                      RSL     5,,14                                   107410
6954    18      0C5C  A435                      CLA     3,5                                     107420
6955    26      0C5D  F54A1FB2                  CLA     X4,,T_0_BUFFER2                         107430
6956     6R     0C5F  F4050010          $3    LSE     0,,4                                    107440
6957    14      0C61  C423   (0C5F)             BXU     2,,$3                                   107450
6958     8R     0C62  E400177D                  EXT     0,0,HX000F                              107460
6959    16      0C64  F50A0C72                  CLA     X0,,T_0_TABLES                          107470
6960    26      0C66  F0071C04                  STA     0,,TYPE_OUT                             107480
6961    34      0C68  F80FDF01                  IOC     0,,LOAD_PRINTER                         107490
6962    44      0C6A  FC0D1C04                  POP     0,,TYPE_OUT                             107500
6963    52      0C6C  F41A1FE6                  CLA     1,,CHAR_POINT                           107510
6964    54      0C6E  9411                      ADDM    1,,1                                    107520
6965    64      0C6F  F0171FE6                  STA     1,,CHAR_POINT                           107530
6966    68      0C71  D90C   (0C56)             BUC     $19                                     107540
6967            0C72  0038            T_0_TABLES CON    X(0038)         0                       107550
6968            0C73  007F                      CON     X(007F)         1                       107560
6969            0C74  0076                      CON     X(0076)         2                       107570
6970            0C75  003E                      CON     X(003E)         3                       107580
6971            0C76  0075                      CON     X(0075)         4                       107590
6972            0C77  0030                      CON     X(0030)         5                       107600
6973            0C78  0034                      CON     X(0034)         6                       107610
6974            0C79  007C                      CON     X(007C)         7                       107620
6975            0C7A  0079                      CON     X(0079)         8                       107630
6976            0C7B  0031                      CON     X(0031)         9                       107640
6977            0C7C  0057                      CON     X(0057)         -                       107650
6978            0C7D  0015                      CON     X(0015)         M                       107660
6979            0C7E  0026                      CON     X(0026)         S                       107670
6980            0C7F  0045                      CON     X(0045)         D                       107680
6981            0C80  0084                      CON     X(0084)         CR                      107690
6982            0C81  0081                      CON     X(0081)         SPACE                   107700
6983                                  GET_DYN_RNG_DATA:                                         107710
6983    14R     0C82  F01C0085                  FET     1,,STATION_COUNTER                      107720
6984    18      0C84  D061   (0C86)             BRE     $99                                     107730
6985    14R     0C85  D510                      BBK     1               RETURN IF NOT BURST 0   01 107740
6986    10R     0C86  FC0A1FE0          $99   CLAD    0,,T_0_SEC_COUNT2                       107750
6987    18      0C88  96E8   (00E8)             ADDD    0,,=DX(00000001) INCR 1 SEC             107760
6988    30      0C89  F8071FE0                  STAD    0,,T_0_SEC_COUNT2                       107770
```

```
6989      40    0C88  F8080D3D                COMD    0,,TEN_MIN                                    107780
6990      44    0C8D  D065    (0C93)           BRE     $1              END OF TEST                   107790
6991     10R    0C8E  F8C81FE4                COMD    0,,T_0_TIME2                                  107800
6992      16    0C90  04060D1C                BRE     G_0_R_D                                       107810
6993     14R    0C92  0510                     BBK     1               RETURN TO EXEC                107820
6994     22R    0C93  F03C0D39          $1    FET     3,,MSXSQ2       END OF TEST TYPE OUT          107830
6995      24    0C95  9435                     ADDM    3,,5                                          107840
6996      32    0C96  8414                     FETM    1,,4            GET 3 DOUBLE COUNTER          107850
6997      8R    0C97  C010              $10    FET     1,0                                           107860
6998      12    0C98  4402                     MPIM    0,,2                                          107870
6999      16    0C99  F4091D2F                 ADDM    0,,BPDATA4+16                                 107880
7000      36    0C9B  C230                     FET     I3,0                                          107890
7001     574    0C9C  1800                     ATAN    0                                             107900
7002     578    0C9D  AC20                     CLAD    2,0                                           107910
7003     588    0C9E  D710                     PRN     1                                             107920
7004     598    0C9F  F8C54000                 RSLD    0,,1                                    01    107930
7005     610    0CA1  CB24                     FETD    IX2,4           GET SXSQ                      107940
7006     626    0CA2  6822                     MPYD    2,2             SX**2                         107950
7007     630    0CA3  B802                     SUBD    0,2             SXSQ-SX**2              D01   107960
7008     634    0CA4  D021    (0CA6)           BGE     $11                                           107970
7009      4R    0CA5  A800                     CLSD    0,0                                           107980
7010    446R    0CA6  1000              $11    SQRT    0               S. D.                         107990
7011     458    0CA7  7F49                     PTRD    IX4,9           STORE IN T_0_BUFFER+6         108000
7012     466    0CA8  AF25                     CLAD    IX2,5           GET SX                        108010
7013     474    0CA9  C011                     FET     1,1                                           108020
7014     476    0CAA  A421                     CLA     2,1                                           108030
7015     478    0CAB  B011                     SUB     1,1                                           108040
7016     480    0CAC  B033                     SUB     3,3                                           108050
7017    1018    0CAD  1800                     ATAN    0                                             108060
7018    1028    0CAE  F8C54000                 RSLD    0,,1                                          108070
7019    1032    0CB0  D031    (0CB2)           BRG     $12                                           108080
7020      4R    0CB1  A800                     CLSD    0,0             MAKE IT PLUS                  108090
7021      2R    0CB2  A487              $12    CLA     8,7             COMPUTE                       108100
7022       4    0CB3  9486                     ADDM    8,,6            STORE ADDRESS                 108110
7023      14    0CB4  7B28                     STAD    IX2,8           THEN STORE IT                 108120
7024      24    0CB5  D710                     PRN     1                                             108130
7025      32    0CB6  CE00    (0C97)           BXUD    0,,$10                                        108140
7026     10R    0CB7  F4180018                 FETM    1,,24           NO. OF CHARS TO TYPE AND 0.   108150
7027      24    0CB9  F417IFE6                 PTR     1,,CHAR_POINT   ZERO CHAR POINT               108160
7028      34    0CBB  F00C0D3F                 FET     0,,N_INC2                                     108170
7029      44    0CBD  F017ICA1                 STA     1,,SAMPLE_MKR   ZERO                          108180
7030      62    0CBF  D750                     PRN     5                                             108190
7031     116    0CC0  F0BC1F88                 FET     11,,T_0_BUFFER2+6  START SD COMPUTATION        108200
```

```
7032    136          0CC2  F8060D10                MPYD    0,,THIRD                                    108210
7033    156          0CC4  F8260D18                MPYD    2,,FIFTYB1                                  108220
7034    176          0CC6  F8460D1A                MPYD    4,,SIXTYB1                                  108230
7035    180          0CC8  BC02                    ADDD    0,2                                         108240
7036    184          0CC9  BC04                    ADDD    0,4                                         108250
7037    194          0CCA  FC2A0D10                CLAD    2,,THIRD                                    108260
7038    770          0CCC  0C08                    GEN     BASE_DISPLAY                                108270
7039    774          0CCD  F41900FF                ADDM    1,,X(00FF)                                  108280
7040    778          0CCF  FC29FEFF                CLAM    2,,X(FEFF)                                  108290
7041    796          0CD1  F4271F85                PTR     2,,T_O_BUFFER2+3                            108300
7042    806          0CD3  F8480D16                SUBD    4,,FRTYFIV                                  108310
7043    816          0CD5  F8680D14                SUBD    6,,SIXTY                                    108320
7044    826          0CD7  F8880D12                SUBD    8,,FIFTY                                    108330
7045    846          0CD9  F8460D10                MPYD    4,,THIRD                                    108340
7046    866          0CDB  F8660D18                MPYD    6,,FIFTYB1                                  108350
7047    886          0CDD  F8860D1A                MPYD    8,,SIXTYB1                                  108360
7048    890          0CDF  BC46                    ADDD    4,6                                         108370
7049    894          0CE0  BC48                    ADDD    4,8                                         108380
7050    904          0CE1  FC2A0D1C                CLAD    2,,THIRD                                    108390
7051    934          0CE3  F05C1E85                FET     5,,PHI_ESTIMATE+18      "D"                 108400
7052    940          0CE5  FC040800                LSAD    0,,11                                       108410
7053    946          0CE7  FC240800                LSAD    2,,11                                       108420
7054    952          0CE9  FC440800                LSAD    4,,11                                       108430
7055    972          0CEB  F8060D10                MPYD    0,,THIRD                                    108440
7056    992          0CED  F8260D18                MPYD    2,,FIFTYB1                                  108450
7057   1012          0CEF  F8460D1A                MPYD    4,,SIXTYB1                                  108460
7058   1016          0CF1  BC02                    ADDD    0,2                                         108470
7059   1020          0CF2  BC04                    ADDD    0,4                                         108480
7060   1030          0CF3  F8045D70                MPYDM   0,,X(5D70)                                  108490
7061   1040          0CF5  F8054000                RSLD    0,,1                                    01  108500
7062   1044          0CF7  F8094000                COMM    0,,X(4000)                                  108510
7063   1048          0CF9  D041    (0CFB)          BLE     $14                                         108520
7064     8R          0CFA  92F3    (00F3)          SUBD    0,,=DI(1831-1)                              108530
7065     4R          0CFB  B8A0            $14     SUBD    10,0                                        108540
7066     22          0CFC  D750                    PRN     5                                           108550
7067     24          0CFD  9C60                    CLAM    6,,0                                        108560
7068     28          0CFE  AC04                    CLAD    0,4                                         108570
7069     32          0CFF  D022    (0D02)          BGE     $13                                         108580
7070     4R          0D00  A800                    CLSD    0,0                                         108590
7071      6          0D01  9465                    ADDM    6,,5                                        108600
7072   576R          0D02  0C08            $13     GEN     BASE_DISPLAY                                108610
7073    580          0D03  F41900FF                ADDM    1,,X(00FF)                                  108620
7074    590          0D05  F00C0D0F                FET     0,,CMFO                                     108630
```

```
7075    592     0D07  BC08                    SUB     0,8                                                  108640
7076    610     0D08  F4271FB2                PTR     2,,T_O_BUFFER2                                       108650
7077    636     0D0A  D790                    PRN     9                                                    108660
7078    650     0D0B  0510                    BBK     1                                                    108670
7079            0D0C  00000018        DINC    COND    X(00000018)                                          108680
7080            0D0E  FCDF          BSDB    CON     X(FCDF)         .SD.                                 108690
7081            0D0F  EE8F          CMFO    CON     X(EE8F)                                          01  108700
7082            0D10  2AAAAAAB        THIRD   COND    X(2AAAAAAB)                                          108710
7083            0D12  40000000C     FIFTY   COND    X(40000000)                                          108720
7084            0D14  4CCCCCCC      SIXTY   COND    X(4CCCCCCC)                                          108730
7085            0D16  39999999      FRTYFIV COND    X(39999999)                                          108740
7086            0D18  20000000C     FIFTY81 COND    X(20000000)                                      01  108750
7087            0D1A  26666666      SIXTY81 COND    X(26666666)                                      01  108760
7088     14R    0D1C  F01C0D38      G_D_R_D FET     1,,MBPDATA                                           108770
7089     22     0D1E  8414                    FETM    1,,4            3 COUNTER                            108780
7090     12R    0D1F  CB02          $20     FETD    IX0,2           GET 1ST VALUE                        108790
7091     20     0D20  C011                    FET     1,1                                                  108800
7092     22     0D21  A421                    CLA     2,1                                                  108810
7093     24     0D22  B033                    SUB     3,3                                                  108820
7094    562     0D23  1800                    ATAN    0                                                    108830
7095    572     0D24  F8C54000                RSLD    0,,I                                                 108840
7096   1148     0D26  0C08                    GEN     BASE_DISPLAY                                         108850
7097   1152     0D27  F41900FF                ADDM    1,,X(00FF)                                           108860
7098   1164     0D29  7F36                    PTRD    IX3,6           STORE RESULT IN T_O_BUFFER           108870
7099   1172     0D2A  D7C0                    PRN     0                                                    108880
7100   1180     0D2B  CC0D    (001F)          BXUD    0,,$20          DO IT 3 TIMES                        108890
7101     10R    0D2C  F0E71CA1                STA     14,,SAMPLE_MKR  NON-ZERO                            108900
7102     20     0D2E  F418001C                FETM    1,,28           SET POINT 0 AND MAX CNT 28           108910
7103     34     0D30  F4171FE6                PTR     1,,CHAR_POINT                                        108920
7104     48     0D32  F80C1FE4                FETD    0,,T_O_TIME2    INCR NEXT T_O_TIME                   108930
7105     58     0D34  FC080D41                ADDD    0,,TIME_INC3                                         108940
7106     72     0D36  FCC71FE4                PTRD    0,,T_O_TIME2                                         108950
7107     94     0D38  D550                    BBK     5                                                    108960
                                *  CONSTANTS USED FOR PCI DYN RANGE ONLY                                  108970
7108            0D39  1FC6          MSXSQ2  CON     SXSQ2                                                108980
7109            0D3A  1FCC          MSX2    CON     SX2                                                  108990
7110            0D3B  1FD2          MBPDATA CON     BPDATA2                                              109000
7111            0D3C  1FB3          MT_O_BUFFER CON T_O_BUFFER2+1                                        109010
7112            0D3D  0000005A      TEN_MIN COND    I(90)                                                109020
7113            0D3F  01000000      N_IN52  COND    X(01000000)     NN COUNT INCREMENT  187              109030
7114            0D41  00000001      TIME_INC3 COND  I(1)                                                 109040
7115            0D43  0000000C      FIVE_MIN COND   I(12)                                                109050
7116            0D45  0021                    CON     X(0021)         INITIAL CHAR_POINT = 33              109060
```

```
7117  0046 0020            CON     X(0020)          INITIAL MAX_COUNT = 32   109070
7118  0047 0008  N_SMOOTHING CON     I(8)             RANGE IS 2 TO 8          109080
7119  1CA1       SAMPLE_MKR  EQU     PROP_C                    1 S WDS         109090
7120  1CA2       BPHISTORY   EQU     PROP_C+1                 21 D WDS         109100
                 * VARIABLE STORAGE FOR PCI DYN RANGE TEST                    109110
7121  1FC6       SXSQ2       EQU     DESTINATION_LONGITUDE+2   3 D WDS        109120
7122  1FCC       SX2         EQU     DESTINATION_LONGITUDE+8   3 D WDS        109130
7123  1FD2       BPDATA2     EQU     DESTINATION_LONGITUDE+14  3 D WDS        109140
7124  1FB2       T_O_BUFFER2 EQU     RZ_C             15 WORDS                109150
7125               T_O_SEC_COUNT2;                                            109160
7125  1FE0                   EQU     DESTINATION_LATITUDE+2    1 D WDS        109170
7126  1FE2       NN          EQU     DESTINATION_LATITUDE+4    1 D WDS        109180
7127  1FE4       T_O_TIME2   EQU     DESTINATION_LATITUDE+6    1 D WDS        109190
7128  1FE6       CHAR_POINT  EQU     DESTINATION_LATITUDE+8    1 S WDS        109200
7129  1FE7       MAX_COUNTER EQU     DESTINATION_LATITUDE+9    1 S WDS        109210
7130  1D1F       BPDATA4     EQU     P15                                      109220
7131  0048 E108              ECS                                            109230
```

```
                                **                                                                  109240
                                *                SRN - 17  OPERATIONAL PROGRAM OVERLAY              109250
                                *                  MODIFIES ANTENNA SELECTION FOR                  109260
                                *                    USE WITH WHIP ANTENNA                        109270
                                *                  MODIFIES SCALEING ON LOG INPUT                 109280
                                *                                                                 109290
7132                                          TAPE     4,X(73)                                    109300
7133                                          TAPE     3,12                                       109310
7134                                          TAPE     4,X(F1)                                    109320
7135                                          TAPE     1                                          109330
7136                 0049                     SCS                                                 109340
7137                 02EC                     ORG      SYNC$81                                    109350
7138          2R     02EC   9C01              CLAM     0,,1                                       109360
7139                 0683                     ORG      VELOCITY_PROCESSING$81                     109370
7140           8     0683   F0040A8C          MPYM     0,,F(6076*100/3600811)  100 KNOTS PER 360 DEG 109380
7141          12     0685   F8090A05          COMM     0,,F(6076*95/3600811)                      109390
7142                 1762                     ORG      ANTENNA_SELECT_TABLE                       109400
7143                 1762   00010001          COND     X(00010001)                                109410
7144                 1764   00010001          COND     X(00010001)                                109420
7145                 1766   00010001          COND     X(00010001)                                109430
7146                 17D4                     ORG      OVERLAY                                    109440
7147                 17D4   6758              ECS                                                 109450
```

```
                                                                                                  109460
7148                                                TAPE        4,X(73)                           109470
7149                                                TAPE        3,12                              109480
7150                                                TAPE        4,X(F1)                           109490
7151                                                TAPE        1                                 109500
7152                1705                            SCS                                           109510
7153                1A7A                            ORG         ENC_TEST+1                        109520
7154                1A7A  C0000000                  LITERAL
7154                1A7C  26666666                  LITERAL
7154                1A7E  00206666                  LITERAL
7154                1A80  01FFFFFF                  LITERAL
7154                1A82  00C0C098                  LITERAL
7154                1A84  000007D0                  LITERAL
7154                1A86  00000004                  LITERAL
7154                1A88  00000010                  LITERAL
7154                1A8A  01900000                  LITERAL
7154                1A8C  033EC5EC                  LITERAL
7154                1A8E  0005D23C                  LITERAL
7154                1A90  517CC1B9                  LITERAL
7154                1A92  00000006                  LITERAL
7154                1A94  65DBF227                  LITERAL
7154                1A96  08A87495                  LITERAL
7154                1A98  506C8DD9                  LITERAL
7154                1A9A  40000000                  LITERAL
7154                1A9C  001D7DBF                  LITERAL
7154                1A9E  00008620                  LITERAL
7154                1AA0  06666666                  LITERAL
7154                1AA2  0002900C9                 LITERAL
7154                1AA4  006DDE18                  LITERAL
7154                1AA6  0011A304                  LITERAL
7154                1AA8  0B115555                  LITERAL
7154                1AAA  04010047                  LITERAL
7154                1AAC  0A000000                  LITERAL
7154                1AAE  01F40000                  LITERAL
7154                1AB0  0E49D201                  LITERAL
7154                1AB2  00084A21                  LITERAL
7154                1AB4  0000FEA                   LITERAL
7154                1AB6  08000000                  LITERAL
7154                1AB8  80000001                  LITERAL
7154                1ABA  0CCCCCCD                  LITERAL
7154                1ABC  00000D18                  LITERAL
7154                1ABE  000084A2                  LITERAL
7154                1AC0  04000000                  LITERAL
```

```
7154  1AC2  00008852          LITERAL
7154  1AC4  6487ED4F          LITERAL
7154  1AC6  7F24AB82          LITERAL
7154  1AC8  00684DC5          LITERAL
7154  1ACA  00028F20          LITERAL
7154  1ACC  000174D4          LITERAL
7154  1ACE  0517CC1C          LITERAL
7154  1AD0  0001A5E0          LITERAL
7154  1AD2  0092174F          LITERAL
7154  1AD4  FFFEA070          LITERAL
7154  1AD6  27E9F880          LITERAL
7154  1AD8  2CC327EA          LITERAL
7154  1ADA  59864FD4          LITERAL
7154  1ADC  0000A2FA          LITERAL
7154  1ADE  0010624E          LITERAL
7154  1AE0  001C25C2          LITERAL
7154  1AE2  53E2D624          LITERAL
7154  1AE4  07FFFFFF          LITERAL
7154  1AE6  6622      LAST_WORD  END                                    EX109530
```

NUMBER OF ERRORS = 0

THE COUNT OF UNUSED STORAGE IS 85

ROLL	USED/TOTAL	= PERCENT
0	12237/ 40800	= 29.99
4	11232/ 33600	= 33.43
8	512/ 2400	= 21.33
12	0/ 800	= 0.0
16	0/ 8192	= 0.0
20	0/ 48	= 0.0
24	0/ 80	= 0.0
28	180/ 192	= 93.75
32	0/ 0	= 0.0
36	0/ 0	= 0.0
40	0/ 0	= 0.0
44	0/ 0	= 0.0
48	0/ 0	= 0.0
52	0/ 0	= 0.0
56	0/ 0	= 0.0
60	0/ 0	= 0.0
64	0/ 0	= 0.0
68	0/ 0	= 0.0
72	3744/ 3744	= 100.00
76	9324/ 39872	= 23.38
----	37229/129728	= 28.70

ADDR	LITERAL	USE
00E7	07C46929	5
00E9	0AAAAAA8	2
00EB	00000001	10
00ED	00000014	2
00EF	1999999A	2
00F1	00008000	3
00F3	7FFFFFFF	8
00F5	20000000	4
00F7	008CBCCC	2
1A7A	C0000000	1
1A7C	26666666	1
1A7E	00206666	1
1A80	01FFFFFF	1
1A82	0000009B	1
1A84	000007D0	1
1A86	00000004	1
1A88	00000010	1
1A8A	01900000	1
1A8C	033E05EC	1
1A8E	0005D23C	2
1A90	517CC1B9	1
1A92	00000006	2
1A94	65DBF227	1
1A96	08A87495	1
1A98	506CBDD9	2
1A9A	40000000	1
1A9C	001D7D8F	1
1A9E	00008620	1
1AA0	06666666	1
1AA2	000290C9	2
1AA4	006DDE18	3
1AA6	0011A304	1
1AA8	0B115555	1
1AAA	04010D47	1
1AAC	0A000000	1
1AAE	01F40000	1
1AB0	0E49D201	2
1AB2	00084A21	2
1AB4	00000FEA	1
1AB6	08000000	2
1AB8	80000001	1
1ABA	0CCCCCCD	2

ADDR	LITERAL	USE
1ABC	00000D18	1
1ABE	000084A2	1
1AC0	04000000	1
1AC2	00008852	1
1AC4	6487ED4F	2
1AC6	7F24A882	1
1AC8	00684DC5	1
1ACA	0002BF20	2
1ACC	000174D4	1
1ACE	0517CC1C	1
1AD0	0001A5E0	1
1AD2	0092174F	1
1AD4	FFF6A070	2
1AD6	27E9FB80	2
1AD8	2CC327EA	1
1ADA	59864FD4	1
1ADC	0000A2FA	1
1ADE	0010624E	1
1785	00000320	0
1AE0	001C25C2	1
1AE2	53E2D624	1
1AE4	07FFFFFF	1

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
497 / 1F5F	_BLOCK_NO	109 168 190 200 231 471 473 498
495 / 1F5D	_BLOCKS	116 191 202 232 496
501 / 1F6C	_BUFFER	417 454 503
502 / 005C	_BUFFER_LIM	407 421 456 460 503
498 / 1F61	_CHECK_SUM	193 197 238 251 499
135 / 1041	_COMPARE	120
91 / 2000	_CORE_SIZE	92 223
493 / 1F58	_END_CKSUM	96
496 / 1F5E	_END_TAPE	198 483 497
499 / 1F62	_FILL_COMP	118 187 211 235 500
266 / 1E0F	_PPDATA	264
359 / 1EA0	_PPLEADER	145 155 222
380 / 1EC7	_PPTABLE	319
494 / 1F5C	_PPTEMP	106 113 114 286 289 290 295 296 300 321 325 495
321 / 1E66	_PRINT	310 334
304 / 1E4A	_PRINT_WORD	277 337 340
284 / 1E29	_PUNCH	154 157 218 220 279 282 355 361
140 / 104A	_PUNCH_TAPE	122
332 / 1E78	_PUNCHBCD	150 152
348 / 1E8F	_PUNCHVIS	342 343 345
396 / 1ED7	_READ_DATA	167
503 / 1FC8	_ROLL	504
505 / 1FFA	_ROLL_END	93
504 / 1FE6	_ROLL_14	95 505
158 / 1068	_START	129 134
150 / 1058	_START_READ	139
500 / 1F63	_TAPE_DATA	396 428 429 441 501
426 / 1EFD	_TAPE_INPUT	160
93 / 1000	_VERIFY	97 127 130 506
364 / 1EA7	_VISTABLE	351
492 / 1F5A	_XOFFF	115
488 / 1F56	_XOOOF	318 348
489 / 1F57	_XOO3F	354
491 / 1F59	_XOO7F	430
490 / 1F58	_XOO70	437
74 / 0000	A	1856 2207 3881 4821 4843 6296 6339 6347
539 / 001C	A_TO_D_CONVERTER_TEST_LOCATION	5967 5986
4115 / 0004	ACCEPT_GROUP	4076
548 / 002A	ACCEPT_OLD	3510 3598 3896
6596 / 17F9	ACCUMULATE	6766
6901 / 183F	ACCUMULATEX	6852
6119 / 0005	AD_BIG	5977
549 / 0028	AD_DATA	5962 5965 5984

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
6116 / 4FF0	AD_HI_LIM	5968
5666 / 1949	AD_IO_TEST	1039
5965 / 19B4	AD_IO_TEST_ENTRY	5883
6117 / 4D10	AD_LO_LIM	5970
6118 / 0003	AD_SMALL	5974
5961 / 19AF	AD_TEST	1082
67 / 0090	AF	
4458 / 13EE	ALLSTATIONS	4456
43 / 0008	ALPHA	5710 5721 5755 5757 5785 5787 5798 5802 5808 5814 5820 5822 5833 5850
5006 / 16AF	ALPHA_0	3195 3202
83 / 0008	AND	
5196 / 178D	ANTENNA_NOISE_AND_CALIBRATE_CODES	1186
353 / 0035	ANTENNA_SELECT_SAVE	1199 1225 1608
5163 / 1762	ANTENNA_SELECT_TABLE	1602 6459 6825 7142
543 / 0020	ANTENNA_SWITCHING_MATRIX_OUTPUT_10_2	1104 1188 1607 5891 5924
545 / 0022	ANTENNA_SWITCHING_MATRIX_OUTPUT_11_33	
544 / 0021	ANTENNA_SWITCHING_MATRIX_OUTPUT_13_6	
5012 / 1688	ARCSIN	3076 3135
4973 / 1689	ARCTAN	5019
4070 / 120D	ARGINPUT	4112
4128 / 000C	ARGUMENT	3855 3858 3924 3966
5395 / 1F41	ARGWORD1	3878 3903 3971 4072 4274 4298
5396 / 1F42	ARGWORD2	3862 3873 3916 3930 4027 4032
5241 / 17D5	ASCII	4040
2803 / 08A0	ASSEMBLE_XX	2091 2569 2586
66 / 0080	AT	4843 6339
4972 / 1688	ATAN_ENTRY	684
5033 / 16CE	ATC	4977 4978 4990
5039 / 16DA	ATC1	4978
5040 / 16DC	ATC2	4990
771 / 0159	AUG_MEM_TEST	6063
615 / 0088	AUGMENTER_KEY	
3419 / 0E90	AUR_DATA	3079
3395 / 0E78	AUR_LIMITS	3081
5266 / 1C80	AUR_SAVE	3127
2711 / 0830	AVERAGE_X	2100 2648
5375 / 1EE8	AVIONICS	3442 3445
75 / 0001	B	2201 2226 2981 3003 4253 4255 4477 4481 4655 4658
629 / 00C8	BASE	1345 1353 1391 1414 1794 1815 1817 1827 2324 2412 2685 2883 3284 3324 4256 4299 4478 4483 4557
4739 / 0008	BASE_DISPLAY	4371 7038 7072 7096
4747 / 1564	BCDTOBIN	3455 3457

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
4870 / 1605	BEARING	1594
4714 / 0000	BEARING_DISPLAY	4545 4571 4578 4584 4631
5389 / 1F30	BEARING_TEMPS	4609 4621 4622 4626 4632 4633 4641 4642 5901 5909 5930 5940
	5942	
785 / 0166	BEGIN	754 1123
44 / 0004	BETA	5710 5755 5787 5798 5808 5814 5820
2910 / 0C26	BETA_LOG	
2909 / 0C24	BETA_NRA	2055
2911 / 0C28	BETA_PSEUDO	
69 / 0080	BF	
5273 / 1CD5	BI	2039 2041 2118 2325 2538 2541 2591 2593 2771 2772
4229 / 128F	BLANKS_GEN	4190 4236
7123 / 1FD2	BPDATA2	6833 6855 7110
7130 / 1D1F	BPDATA4	6881 6907 6908 6913 6999
7120 / 1CA2	BPHISTORY	6854 6857 6862 6865 6886 6932
7080 / 0D0E	BSDB	
68 / 00A0	BT	2201 3003 4255 4477 4655
5190 / 1787	BURST_ADDRESSES	1222
5382 / 1F17	BURST_TIME	1195 1767
76 / 0002	C	1858 2209 2222 3467 4141
512 / 0002	C_I_INPUT_KEYBOARD_SWITCHES	3775
511 / 0001	C_I_INPUT_MISCELLANEOUS_SWITCHES	3760 3767 3768 3771 3773
513 / 0003	C_I_LEFT_DISPLAY	821 3456 3521 3732 4091 4095 4143
515 / 0004	C_I_LEFT_DISPLAY_DIGITS_2_TO_1	
514 / 0003	C_I_LEFT_DISPLAY_DIGITS_6_TO_3	
519 / 0007	C_I_LEFT_DISPLAY_LEGEND_AND_PUNCTUATION	3746 3766 3808 4457 4750
525 / 000D	C_I_LOWER_KEYBOARD_LAMPS	
521 / 0009	C_I_OUTPUT_LAMPS_MISCELLANEOUS_SWITCHES	806 3512 3562 3565 3593 3725 3758 4136 6097 6616 6659
522 / 0009	C_I_OUTPUT_MALFUNCTION_STATUS_INDICATORS	3484 3558
516 / 0005	C_I_RIGHT_DISPLAY	3454 3541 4025 4066 4096
518 / 0006	C_I_RIGHT_DISPLAY_DIGITS_2_TO_1	
517 / 0005	C_I_RIGHT_DISPLAY_DIGITS_6_TO_3	
520 / 0008	C_I_RIGHT_DISPLAY_LEGEND_AND_PUNCTUATION	4455
595 / 009F	C_I_STATUS_IMAGE	1112 1174 1397 2269 3465
523 / 0008	C_I_UPPER_LEFT_KEYBOARD_LAMPS	4187 4560
524 / 000C	C_I_UPPER_RIGHT_KEYBOARD_LAMPS	
667 / 00F8	CAL_R_ADD	1192 1622 1715
4884 / 1613	CALC_TIME_CORRECTION	1178 3560
590 / 009A	CALIBRATE_COMPUTED_MARKER	1699 1709 4196
5378 / 1EF6	CALIBRATE_DATA	1616 1617 1618 1620 5185 5186 5187 5188 5379 5380
5185 / 1781	CALIBRATE_DATA_ADDRESSES	1625
5257 / 1C18	CALIBRATE_FAIL_COUNT	1661 1669
5431 / 1F9A	CALIBRATE_RESULTS	667

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5394 / 1F40	CALLWORD	3451 3835 3915
5204 / 1795	CAY_ONE	3305
3399 / 0E7C	CAY_TABLE	3214
3346 / 0E47	CAY1_TABLE	3224
4715 / 0715	CDD	4718 4721 4724 4727 4730 4733 4736 4739 4742 4745
4737 / 1559	CD11	4739
4740 / 155C	CD12	4742
4743 / 155F	CD13	4745 6818
4716 / 1544	CD2	4718
4719 / 1547	CD3	4721
4722 / 154A	CD4	4724
4725 / 1540	CD5	4727
4728 / 1550	CD7	4730
4731 / 1553	CD8	4733
4734 / 1556	CD9	4736
71 / 00D0	CF	2222
5427 / 1F8F	CHANNEL_FAIL	1704 1705
7128 / 1FE6	CHAR_POINT	6946 6963 6965 7027 7103
6778 / 1FEA	CHAR_POINTER	6620 6638 6640 6754
535 / 0018	CH0	6528
536 / 0019	CH1	
540 / 001D	CH5	
541 / 001E	CH6	
542 / 001F	CH7	
3394 / 0E77	CI_TABLE	3241
765 / 0153	CKSUM_LINK	953
4116 / 0000	CLEAR_PANEL	3813 3832 3912
7081 / 0D0F	CMFO	7074
614 / 00B7	COLD_START_MKR	2018 2037 3517 3595 3606
2516 / 0A2F	COMPUTE_BI	2540
2502 / 0A1E	COMPUTE_BI_AND_C	2223 2450
2042 / 079E	COMPUTE_PHI	
2752 / 0862	COMPUTE_THETA1	1800 2332 2942 3285 4302 4307
5618 / 1922	COND_TABLE	3148
562 / 0070	CONNIE	2554 2575 2672 2674 2675
624 / 00C3	CONNIE_LIMIT	2387 2445 2446 2492 2547
4712 / 1541	CONVERSION_DATA	4659 4715
760 / 014C	CORR_CKSUM	137 140 143 216
4933 / 1655	COS	3637 4829 4834
5428 / 1F92	COS_THETA_P	1972 2211 5429
528 / 0011	COS_10_2	1110 1127 1130 1141 1183 1571 1580 1773 5893 5897 5905 5926 5929 5937 6011
532 / 0015	COS_11_33	

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
530 / 0013	COS_13_6	
2010 / 0769	COVARIANCE_INITIALIZATION	2008
1322 / 0407	CP	1317
70 / 00C0	CT	2209
77 / 0003	D	2356 2360 4401 4419
2883 / 0C05	D_PHI_KI	2749 4276 4487 4500 4503
2926 / 0C3D	DATA_TABLE	2175
627 / 00C8	DAY	3530 3538
625 / 00C4	DAY_SINCE_JAN1_1972	793 794 2978 3556 4386 4897 4898
5020 / 16C1	DAYS_BY_MONTH	3536 4426 4429
605 / 00AA	DB_BUFFER	5714 5720 5723 5725 5731 5733 5736 5740 5806 5809 5811 5837
770 / 0158	DB_CKSUM	5849 5854
5255 / 1C05	DB_CKSUM_IGNORE	958 961 5856
5787 / 19EC	DB_CLEAR	5866
5754 / 19C4	DB_DATA	5869
5683 / 1964	DB_DECODE	5679
5752 / 19C1	DB_DISPLAY	5865
5820 / 1A19	DB_END_PCH	5815 5864
5759 / 19CB	DB_HEX	5690 5790 5799 5803 5829 5860
5784 / 19E9	DB_INCR	5871
5861 / 1A50	DB_JUMP_TABLE	5688
566 / 0078	DB_MODE	668 789 5672 5747 5750
668 / 00FC	DB_M1_ADD	5728 5777
5802 / 1A00	DB_PATCH	5862
761 / 014D	DB_PCHAD	788 5671 5853
5738 / 19AD	DB_PNBWE	5682 5705 5708 5716 5726
5814 / 1A11	DB_RETURN	5863
596 / 00A0	DB_SAVE	5804 5817 5823
551 / 0031	DB_SAVEPATCHSTART	5807 5826
5713 / 1988	DB_SPECIALS	5712 5715
5704 / 1980	DB_UPDATE	5674 5686 5696 5753 5756 5758 5767 5788 5801 5861 5868
5445 / 1FF8	DB_WAT	5713 5727 5734 5764 5771 5778
5833 / 1A28	DB_WRITE	5792 5810 5812 5819 5827 5831
5797 / 19F9	DB_WRITE1	5786 5796 5813 5867
5791 / 19F1	DB_WRITE2	5870
5173 / 176F	DCAY_ONE	3302
3404 / 0E81	DCAY_TABLE	3217
705 / 0110	DCAY1_TABLE	3228
5386 / 1F28	DELTA_THETA_2	1960 1962 2117 5387
5387 / 1F2D	DELTA_THETA_3	1959
616 / 0089	DELTA_V2	1892 1893 2135 2144 2158 3516
617 / 008A	DELTA_V3	2140 2145

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5437 / 1FDE	DESTINATION_LATITUDE	3588 4168 4619 5133 5438 5441 6772 6773 6774 6775 6776 6777 6778 6779 6780 7125 7126 7127 7128 7129
5436 / 1FC4	DESTINATION_LONGITUDE	3589 4166 4618 5131 5437 5439 5440 6363 6365 6782 7121 7122 7123
73 / 00F0	DF	
5282 / 1D07	DF_COUNTER	2282 2287 2705
561 / 006F	DF_MKR	2237 2251 2279 2353 2435 2463 2467 2483 2702
7079 / 0C0C	DINC	
534 / 0017	DIRECT_MEMORY_ACCESS_TEST_LOCATION	6052 6055
40 / 8E20	DISABLE_MEMORY_PROTECT	94 3506 5842
4084 / 1221	DISCLEAR	3800
3886 / 1108	DISFINAL	3814 3838 3840 3843 3845 3847 3856 3864 3880 3904 3911
3832 / 10C5	DISTART	3789
5057 / 16EE	DIURNAL_CONSTANT_TABLE	3179
560 / 005C	DIVERGENCE_CONTROL	2205 2221 2425 2428 2434 2517 2784
79 / 0001	DMA_INHIBIT	829
6049 / 1A1F	DMA_TEST	1092
6553 / 003A	DMAX1	6498
6554 / 0038	DMAX2	6514
6557 / 0023	DMAX23	6515 6524
6555 / 003C	DMAX3	6511 6518
6556 / 0038	DMAX4	6529
1022 / 0298	DO_NON_OMEGA_TASK	1020
19 / 0000	DOPPLER_IN_MEMORY	6483
72 / 00E0	DT	2356 4401
6830 / 17DD	DYN_RNG_INIT	6805
64 / 0060	E	163 829 830 3467 4141 4419
4125 / 0009	EAST_OR_WEST	3942
7 / 8F00	ENABLE_CMP_INTERRUPT	110 415
41 / 8E21	ENABLE_MEMORY_PROTECT	787 3508 5857
55 / 0000	ENABLE_READ	158
16 / 8800	ENABLE_RECORDER_INTERRUPT	6140 6188
1072 / 02CD	END_BURST	2006
5654 / 1946	END_CKSUM	172 194 195 5663 5880
5653 / 1945	END_COND_T	
1021 / 0297	END_EXEC	1048 1051 1054 1056 1057 6570 6571 6796 6797 6807 6808
1181 / 0357	END_OF_BURST	1072 6474 6816
5380 / 1F08	END_OF_BURST_DATA	1182 6196 6197 6198 6217 6218 6219
1574 / 0544	END_OF_SLOT	1066
1066 / 02C7	END_SLOT	1566
1042 / 02AE	END_TASK	1023
6125 / 1A79	END_TEST	7153
4060 / 11FE	ENTEREW	4109

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
84 / 000C	EOR	2201 2209 2356 3003 4255 4401 4477 4655 4843 6339
46 / 0001	ERROR	965
5272 / 1CD3	ERROR_EAST	
5271 / 1CD1	ERROR_NORTH	2210 3653 5272
4733 / 0006	ETE_DISPLAY	4251
1006 / 0285	EXEC	757 6255 6951
976 / 0262	FAIL_EXTERNAL	5993 6110
970 / 0258	FAIL_PIN	696
7083 / 0D12	FIFTY	7044
7086 / 0D18	FIFTY81	7033 7046 7056
4123 / 0007	FIVE_DIGITS	3941
7115 / 0D43	FIVE_MIN	6840
3826 / 1080	FLOAT_LOOP	3791
5424 / 1F8C	FLOATER	1100 1598 1689 3479 3826 3830
85 / 0010	FLOATER_ANTENNA	
5167 / 1766	FLOATER_SELECT_TABLE	1606
57 / 0002	FORCE	
48 / 0001	FORWARD	164 204 412 462 477
4129 / 000D	FOUR_DIGITS	3988
3343 / 0E41	FREQ_TABLE	3329
7085 / 0D16	FRTYFIV	7042
61 / 0030	G	
7088 / 0D1C	G_D_R_D	6992
45 / 0002	GAMMA	
60 / 0020	GE	
4654 / 14FA	GEN_PIN	678
6983 / 0C82	GET_DYN_RNG_DATA	6799
626 / 00C6	GMT	1014 1016 3551 4884 4894 4895 6195
6780 / 1FEC	GOOD_BAD_FL	6736 6752 6755
5667 / 1948	GP_TEST	1052
6062 / 1A31	GP_TEST_ENTRY	5884
5422 / 1F7B	H_BURST	1398 1400 1401 1789
3817 / 10AF	HCONTROL	3784
5180 / 177C	HD03C0	4460
665 / 00F9	HD200	984 991 1136 1138
22 / 0030	HEADING_EXITATION_A	5987
5253 / 1C03	HEADING_GROUP	3968 4013 4018 4099
5425 / 1F8D	HEADING_MODE	1888 1900 5426
31 / 8000	HIGH_SPEED_PRINTER_BUSY	
37 / 8000	HIGH_SPEED_PRINTER_OUTPUT	
5660 / 015F	HOT	5669 5886 5895 5916 5921 5928 5953 5963 6007 6028 6033 6049 6054
6394 / 1893	HSP	6409 6428

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
6416 / 18B3	HSP_D	694
6412 / 18AE	HSP_LINE_D	692
6396 / 1897	HSP_OUT	690 6421
6406 / 18A6	HSP_16H	6405
6405 / 18A4	HSP_32H	
5195 / 178C	HXDFFF	6757
3908 / 1120	HXE000	3776
3905 / 112A	HXFEFF	3891 6834
3906 / 1128	HXFFF0	4709
702 / 010E	HXFF00	1531 2291 2472 6579 6712 6718 6720
3909 / 112E	HXF0FF	4084
5194 / 178B	HXF000	3806 4691
666 / 00FA	HX0800	3751 3752 3759
5183 / 177F	HX0FFF	1842
5130 / 173D	HX0F00	4669
672 / 0100	HX00ED	
703 / 010F	HX00FF	1276 2262 2304 4552 6277 6713 6719 6721
5181 / 177D	HX000F	3706 3708 4393 4523 4757 6394 6633 6958
638 / 00D5	HX0001	1612 5889
639 / 00D6	HX0002	
640 / 00D7	HX0004	5902
5172 / 176E	HX0007	5707 6297
641 / 00D8	HX0008	1527 1843
5176 / 1775	HX001F	5684
642 / 00D9	HX0010	2110 3477 5922 6293
643 / 00DA	HX0020	2418 5931
644 / 00DB	HX0040	3464 4054
645 / 00DC	HX0080	820 963 1396 1884 5918 5955 5979 6024 6038 6046 6058 6077 6278 6300 6328
646 / 00DD	HX0100	976 1664 1707 2473 3097 3440 3724 6351
647 / 00DE	HX0200	1144 3104 3500 4555
648 / 00DF	HX0400	3910 4554 5830
649 / 00E0	HX0800	967 968 1446 4699
650 / 00E1	HX1000	1838 1847 5683
6552 / 18F0	HX10100	6481
3907 / 112C	HX17FF	3860
673 / 0101	HX1800	
651 / 00E2	HX2000	1111 1604 3107 3557 5015 6617 6660
5184 / 1780	HX2010	6098
652 / 00E3	HX4000	1861 3112 3143 3561 3611 3615 3921 3954 4058 4059 4548 4914 4917 4933 6396 6933
5182 / 177E	HX6000	1839
653 / 00E4	HX8000	1226 1261 2311 3931 4370 6169 6295

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5391 / 1F3D	IMAGE11	3499 3863 3879 3887 3980 3985 4071 4089 5392
5392 / 1F3E	IMAGE12	3901
5393 / 1F3F	IMAGE13	3836 3883 3888 3917 4090
594 / 009E	IMAGE9	595 3726 3757
20 / 0010	INERTIAL_SYSTEM_NO_GO	85
1 / 8000	INHIBIT_BOTH_CSE_INTERRUPTS	
6 / AF00	INHIBIT_CMP_INTERRUPT	208 405 484
56 / 0001	INHIBIT_READ	111 209 485
15 / A800	INHIBIT_RECORDER_INTERRUPT	
3813 / 10AA	INPUTERROR	3769 3772 3782 3893 4035
3910 / 112F	INSACC	3788 3987
3995 / 11A2	INSFIVE	4107
3993 / 11A0	INSFOUR	4113
3997 / 11A4	INSSIX	3962 3990 3992 3994 3996 4108
3991 / 119E	INSTHREE	4106
3989 / 119C	INSTWO	4105
581 / 008D	INTEGRATION_COUNTER	2943 3248 3250 3281
38 / 8801	INTER_RECORD_GAP	6187
5438 / 1FF6	INTERCEPT_LAT	4866
5439 / 1FDC	INTERCEPT_LONG	4867
78 / 0000	INTERRUPT_INHIBIT	163 780 830 1122 2155 2160 6136 6155
6532 / 19DC	IOTAB1	6508 6517
6546 / 19EA	IOTAB2	6521
6549 / 19ED	IOTAB3	6512
6481 / 1893	IOTEST	6477
2495 / 0A15	K_EXIT	2016 2233 2276 2347 2488
1070 / 02C8	K_FILTER	1776
584 / 0090	KAL_STA_FLG	1176 2014 2498
5256 / 1C06	KAL_TEMP	2440 2444 2490 2493 2811 2877
2006 / 0765	KALMAN_FILTER	1070 1171 6802
63 / 0050	L	1856 1858 2360 3881 6296
1539 / 0518	L_ALPHA	1454 1486
5009 / 1682	LAMBDA_TABLE	2367 2734 4310
7154 / 1AE6	LAST_WORD	174 761
3712 / 101A	LAT_LONG_SCALING	3583
5551 / 18A6	LAT_N00_N05	5636
5546 / 1890	LAT_N05_N10	5637
5541 / 1893	LAT_N10_N15	5638 6393 6480
5536 / 1889	LAT_N15_N20	5639
5530 / 187E	LAT_N20_N25	5640
5524 / 1873	LAT_N25_N30	5641 6658
5518 / 1867	LAT_N30_N35	5642
5511 / 185A	LAT_N35_N40	5643

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5504 / 184D	LAT_N40_N45	5644
5497 / 1840	LAT_N45_N50	5645
5490 / 1832	LAT_N50_N55	5646
5482 / 1822	LAT_N55_N60	5647
5473 / 1811	LAT_N60_N65	5648
5464 / 17FF	LAT_N65_N70	5649
5457 / 17F1	LAT_N70_N75	5650
5451 / 17E6	LAT_N75_N80	5651
5448 / 17E0	LAT_N80_N85	5652
5446 / 17DD	LAT_N85_N90	5653 6577 6829
5555 / 18AE	LAT_S05_S00	5635 6135 6248
5560 / 18B7	LAT_S10_S05	5634
5564 / 18BF	LAT_S15_S10	5633
5568 / 18C7	LAT_S20_S15	5632
5572 / 18CF	LAT_S25_S20	5631
5577 / 18D8	LAT_S30_S25	5630
5581 / 18DF	LAT_S35_S30	5629
5585 / 18E6	LAT_S40_S35	5628
5588 / 18EB	LAT_S45_S40	5627
5590 / 18EF	LAT_S50_S45	5626
5592 / 18F3	LAT_S55_S50	5625
5594 / 18F6	LAT_S60_S55	5624
5595 / 18F8	LAT_S65_S60	5623
5596 / 18FA	LAT_S70_S65	5622
5599 / 18FF	LAT_S75_S70	5621
5603 / 1907	LAT_S80_S75	5620
5608 / 1910	LAT_S85_S80	5619
5613 / 1919	LAT_S90_S85	5618
4718 / 0001	LATITUDE_DISPLAY	4169 4177
62 / 0040	LE	
5189 / 1785	LEAP_SECOND	4887
4126 / 000A	LEFT_STATION_PAIR	3865
5397 / 1F43	LINKWORD	3801 3960 4026 4051 4069 4073 4078
10 / DE00	LOAD_PMU_REGISTER	5739
11 / DE0A	LOAD_PMU_TIMER	
2 / DF01	LOAD_PRINTER	324 6261 6402 6636 6961
3 / DF02	LOAD_PUNCH	299
17 / C800	LOAD_RECORDER	6141
4721 / 0002	LONGITUDE_DISPLAY	4167 4175
4724 / 0003	LOP_DISPLAY	4452
4119 / 0003	LOWER_KEY	3834 3872 3892 3914
557 / 004A	M_MATRIX	558 2203 2217 2352 2870 2878
2929 / 0C43	M_4_TABLE	2399

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
6195 / 1904	MAG_TABLE	6167
6136 / 18AE	MAG_TAPE	756 6134 6179
556 / 0040	MAG_TAPE_DATA	1572 6137 6142 6143 6144 6153 6165 6178 6183
951 / 0240	MAIN_PROGRAM	952 6575 6804
5131 / 173E	MAKE_DESTINATION_VECTOR	4608
4595 / 14A7	MAKE_LAT_LONG	3634 4172 4865
4607 / 1483	MAKE_RANGE_AND_BEARING	4237 4242 6763
3705 / 100F	MAKE_TWO_BINARY	3522 3529 3537 3542 3545 3548
5146 / 1751	MAKE_VELOCITY	4244 4580 4804
972 / 025B	MARK_PIN	700
5082 / 1707	MATRIX_3D	1329 2330
6779 / 1FEB	MAX_COUNT	6622
7129 / 1FE7	MAX_COUNTER	6948
7110 / 0D38	MBPDATA	7088
564 / 0074	MEASUREMENT	2216 2419 2448 2874
565 / 0076	MEASUREMENT_RESIDUAL	2572 2583 2875
1378 / 0448	MEASUREMENT_UPDATE	1533 6809 6900
2770 / 0879	MEASUREMENT_UPDATE_P	2657
2558 / 0A64	MEASUREMENT_UPDATE_X	2224 2451 2677
563 / 0072	MEASUREMENT_VARIANCE	2220 2395 2421 2429 2447 2449 2491 2515
36 / 0008	MEMORY_AUGMENTER_GO	
5277 / 1CFF	MISFIRE_CNT	2688 2689
628 / 00CA	MODE	3466 4140 5125
5388 / 1F2F	MODE_CHANGE	
953 / 0243	MP_CKSUM	835 951 6594 6842
6232 / 1929	MPX_ADD	6160
6224 / 1921	MPX_SP_ADD	6223
7108 / 0D39	MSXSQ2	6901 6994
7109 / 0D3A	MSX2	
7111 / 0D3C	MT_0_BUFFER	
571 / 0084	N	2017 2021 2083 2559 2633 2659 2663 3462
5366 / 1089	N_CTR_SAVE	2470 2471 2485
6774 / 1FE4	N_GOODS_SCALED	
6615 / 1813	N_INC	6597 6697
7113 / 0D3F	N_INC2	6902 7028
7118 / 0D47	N_SMOOTHING	6856
21 / 0020	NAV_INERTIAL_DOPPLER_MODE	
5426 / 1F8E	NAV_MODE	1284 2044 2130 2156
6659 / 1873	NAV_PERF_DATA	6574
6659 / 1873	NAVIGATION_PERFORMANCE_DATA_COLLECTION	
4522 / 1444	NCT	4511 4512 4515 4518
3899 / 1121	NCT_DISPLAY	3841 3850 3885
59 / 0010	NE	2160 2207 6155

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
630 / 00CD	NEED_BASE	1778 1796 1812 1832
7126 / 1FE2	NN	6903 6904 6905
65 / 0070	NO	
6775 / 1FE5	NO_GOODS	
2924 / 0C39	NOISE	2030 2690
591 / 0098	NOISE_COMPUTED_MARKER	1189 1744 1761
5379 / 1F08	NOISE_DATA	1712
585 / 0091	NON_OMEGA_TASK_INDEX	1022 1029
1031 / 02A3	NON_OMEGA_TASK_TABLE	1023 1030
586 / 0093	NON_OMEGA_TIME	1019 1028
5003 / 16AC	NORTH_MAGNETIC_POLE_VECTOR	2970 3067
1709 / 05EF	NOT_CALIB	1613
1701 / 05E4	NOT_FOURTH_ITERATION	1621
6781 / 1FB2	N6_15_COUNT	6593 6742 6745
780 / 0161	OFF	755
631 / 00CE	OFF_COUNT	781 783
587 / 0095	OLD_NON_OMEGA_TASK_TIME	1025 1027 1170
5664 / 1947	OMEGA_DEBUG	790 1031 1033 1035 1036 1038 1040
5671 / 1951	OMEGA_DEBUG_ENTRY	5664 5665 5751
589 / 0099	OMEGA_TASK	1018 1172 5120
5118 / 172E	OMEGA_TASK_PIN	676
1058 / 028F	OMEGA_TASK_TABLE	826 1098 1108 1116 1181 1566 1579 1776 2006 5119 5660
588 / 0097	OMEGA_TIME	945 1017 1165 5123
25 / 0060	OMNI_ANTENNA_AVAILABLE	
6771 / 1921	ONE_DAY	6666
1048 / 0285	ONE_SEC	1047 6569 6572 6795 6806
3437 / 0EA2	OPER_P_C	1055
82 / 0004	OR	
509 / 0008	OS	1271 1275 1283 1326 1386 1787 1814 2234 2496 5269 5270 5282
	5283 5367 5368 5369 5370	5371 5372 5373 5422
5668 / 1940	OSC_TEST	1053
6097 / 1A63	OSC_TEST_ENTRY	5885
510 / 01FE	OSHEX	3899 4039
546 / 0023	OUTPUT_TEST_AND_MISCELLANEOUS_SIGNALS	831 970 5959
3795 / 108F	OUTWAL	4104
5240 / 17D4	OVERLAY	7146
5284 / 1D17	P_MATRIX	2011 2073 2079 2080 2807 2849 2879 5285 5286 5287 5288 5289
	5290 5291 5292 5293 5294	5295 5296 5297 5298 5299 5300 5301 5302 5303 5304 5305 5306
	5307 5308 5309 5310 5311	5312 5313 5314 5315 5316 5317 5318 5319 5320 5321 5322 5323
	5324 5325 5326 5327 5328	5329 5330 5331 5332 5333 5334 5335 5336 5337 5338 5339 5340
	5341 5342 5343 5344 5345	5346 5347 5348 5349 5350 5351 5352 5353 5354 5355 5356 5357
	5358 5359 5360 5361 5362	5363 5364 5365 6238
2849 / 0B06	P_SYM	2071 2801

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5421 / 1F7B	PANEL_BOUND	4647
5406 / 1F53	PANEL_BUFFER	4649
555 / 003E	PANEL_COUNT	2013 4130 4133
5409 / 1F67	PANEL_DATA	800 4647 4648
3763 / 1060	PANEL_INPUT	758
3447 / 0EB2	PANEL_MAIN	1037 3605 3703 3704 4135 4620
4074 / 1214	PANEL_PIN	687
4101 / 1238	PANEL_PIN_TABLE	4114
3722 / 1027	PANEL_TEST	3449
5400 / 1F47	PANELMODE	807 3448 3460 3762 3764 3809
4130 / 1248	PANELOUTPUT	3453 4562
5399 / 1F45	PANELTIME	3735 3737
3802 / 109C	PANOUT	3765 3812 3816 3822 3825 3831 4101 4102 4103
3815 / 10AD	PANTEST	3790
593 / 009D	PAST_NAV_MODE	1280 1285 1287
6123 / 000F	PC_END_HI_LIM	6042
6124 / FFF1	PC_END_LO_LIM	6044
602 / 00A6	PC_INSERT	2206 2232 3654
6122 / 0190	PC_PLUS_LIM	6036
6028 / 1AD4	PC_TEST	1088 1090
6586 / 17EA	PCI_INIT	6576
6120 / 0640	PD_HI_LIM	6016 6020
6121 / 0200	PD_LO_LIM	6018 6022
6007 / 19E9	PD_TEST	1086 1094
632 / 00CF	PFG_COUNT	1119 1121
24 / 0050	PFG_COUNTDOWN_NO_GOOD	1117 1567
527 / 0010	PHASE_COUNTER_TEST_LOCATION	6030 6035 6041
2915 / 0C30	PHI_CODE	2816
5371 / 1E63	PHI_DOT_DR	5079
5381 / 1F0E	PHI_DOT_DR_BASE	1347 1349 1359 2401
5372 / 1E73	PHI_DOT_ESTIMATE	5080
5373 / 1EA3	PHI_ESTIMATE	2296 2906 3334 3339 4263 4361 4489 4493 4494 5081 7051
5384 / 1F1F	PHI_M_BASE	1405 1417 6844
559 / 005C	PHI_MATRIX	560 561 562 563 564 565 2042 2046 2137 2141 2812
5390 / 1F3C	PHI_OFFSET	4446 4473 4497
2807 / 08A6	PHI_P_PHIT	2067 2070 2094
5376 / 1EE0	PHI_SUB_M	1448 5193 6199 6200 6201
5377 / 1EF3	PHI_ZERO	946 1695 5191
5234 / 17CE	PHI_ZERO_FLOATER	1692 6462
5237 / 17D1	PHI_ZERO_LOOP	1694
5231 / 17C8	PHI_ZERO_0	1688
80 / 0002	PIN_MODE	
5131 / 173E	PLOT1	6366

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
3987 / 113F	PLOT11	3974 6378
757 / 0146	PLOT15	6380 6791
1573 / 0542	PLOT16	6133 6382 6798
3307 / 0E0E	PLOT17	6457
4179 / 1273	PLOT2	6368
759 / 014A	PLOT20	6476
3703 / 0F81	PLOT3	6370
3704 / 0F83	PLOT4	6372
4180 / 1276	PLOT5	6374
5133 / 1741	PLOT6	6376
30 / 8E30	PMU_DISPLAY_BUSY	5704
597 / 00A1	PMU_INDICATOR_WORD	966 5717 5741
42 / 8E10	PMU_INDICATORS	5742
633 / 00D0	PMU_INPUT	1883 5676 5677 5681 6000 6001 6005
28 / 8E10	PMU_KEYBOARD_REQUEST	5673
29 / 8E20	PMU_TIMER_OVERFLOW	
6578 / 17D0	POP_12_SUB	6701 6704 6707
4163 / 1270	POP1	4161 4179 4180 6717
4542 / 145F	POP10	4158
4551 / 146A	POP11	4150
4506 / 1420	POP12	4153 6578
4563 / 147C	POP13	4543
4574 / 1488	POP14	4157
4583 / 1498	POP15	4159 4573
4191 / 1293	POP2	4151
4232 / 12C2	POP4	4152 6724
4445 / 13D9	POP5	4156
4237 / 12C9	POP6	4160
4240 / 12CE	POP7	4154
4255 / 12E2	POP8	4162 4254 6821 6823
4384 / 1386	POP9	4155 4540 6711
5177 / 1776	POS_NOISE_TABLE	3518 3592
2209 / 0892	POSITION_MEASUREMENT	2227 2229
569 / 0081	POSITION_NOISE	2218 3655
638 / 00D5	POWERS_OF_TWO	858 972 1791 2259 4558 4922
611 / 0084	PP_STATION	2495 2499
5283 / 1D0F	PP_THETA2	2740 3319 4313 4315
5270 / 1CB9	PP_THETA3	2742 3308 4264 4265
4114 / 123A	PPT	4080 4115 4117 4118 4119 4120 4121 4122 4123 4124 4125 4126
	4127 4128 4129	
5886 / 194F	PREAMP_TEST	1076 1078
6115 / 05B0	PREAMP_TEST_ANGLE_LIMIT	5912
6114 / 0000	PREAMP_TEST_MAGNITUDE_LIMIT	

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5886 / 194F	PREFLIGHT_TEST	1074
4457 / 13EC	PROCESS_LEFT_PAIR	4449
4455 / 13E9	PROCESS_RIGHT_PAIR	4447
5398 / 1F44	PROCWORD	3780 3783 4079
768 / 0156	PROG_ID_DB	808 5661 5878
769 / 0157	PROG_ID_OVL	6131 6246 6391 6455 6472 6567 6793
763 / 014F	PROGRAM_ID	809 834 6224
35 / 000C	PROGRAM_SEQUENCING	832 1013 1177
18 / 8CC3	PROGRAMMER_CONTROLLER_GO_LIGHT	833
5269 / 1CA1	PROP_C	2390 2392 3313 7119 7120
5265 / 1C63	PROP_PRED_RESULTS	2932 3318
2932 / 0C49	PROPAGATION_PREDICTION	2500 3341 6814 6943
623 / 00C2	PSI_A	1596 1899 2131 6214
582 / 008F	PSI_A_SAVE	583 2132 2133
5405 / 1F52	PSI_A_STAR	
5423 / 1F88	PSI_INSERT	1878 3581 4544
6364 / 1FE8	PT_DEST_LAT	6371 6375 6377
6363 / 1FE4	PT_DEST_LNG	6364 6367 6369 6373
6365 / 1FC4	PT_IMAGE	6251 6260 6262 6273 6318
6249 / 18AE	PT_TYPE	6381
6314 / 18FD	PT_TYPE_SETUP	6383 6384
4101 / 123B	PT1	4117
4110 / 1244	PT10	4126
4111 / 1245	PT11	4127
4112 / 1246	PT12	4128
4113 / 1247	PT13	4129
4102 / 123C	PT2	4118
4103 / 123D	PT3	4119
4104 / 123E	PT4	4120
4105 / 123F	PT5	4121
4106 / 1240	PT6	4122
4107 / 1241	PT7	4123
4108 / 1242	PT8	4124
4109 / 1243	PT9	4125
26 / 8F10	PUNCH_OR_PRINTER_BUSY	297 322 6249 6399 6625 6944
5285 / 1017	P11	2035 2170 2243 2693 2695
5286 / 1019	P12	
5287 / 1018	P13	
5288 / 101D	P14	
5289 / 101F	P15	7130
5290 / 1021	P16	
5291 / 1023	P17	
5292 / 1025	P18	

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5293 / 1027	P19	
5294 / 1029	P21	
5295 / 1028	P22	2036 2246 2696 2698
5296 / 102D	P23	
5297 / 102F	P24	
5298 / 1031	P25	
5299 / 1033	P26	
5300 / 1035	P27	
5301 / 1037	P28	
5302 / 1039	P29	
5303 / 1038	P31	
5304 / 103D	P32	
5305 / 103F	P33	2031 2239 2700 3471
5306 / 1041	P34	
5307 / 1043	P35	
5308 / 1045	P36	
5309 / 1047	P37	
5310 / 1049	P38	
5311 / 1048	P39	
5312 / 104D	P41	
5313 / 104F	P42	
5314 / 1051	P43	
5315 / 1053	P44	2029 2168 2169 2640 6101
5281 / 1006	P44_INC_RATE	2163 2165
5316 / 1055	P45	
5317 / 1057	P46	
5318 / 1059	P47	
5319 / 1058	P48	
5320 / 105D	P49	
5321 / 105F	P51	
5322 / 1061	P52	
5323 / 1063	P53	
5324 / 1065	P54	
5325 / 1067	P55	
5326 / 1069	P56	
5327 / 106B	P57	
5328 / 106D	P58	
5329 / 106F	P59	
5330 / 1071	P61	
5331 / 1073	P62	
5332 / 1075	P63	
5333 / 1077	P64	
5334 / 1079	P65	

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5335 / 1078	P66	
5336 / 1C7D	P67	
5337 / 107F	P68	
5338 / 1C81	P69	
5339 / 1083	P71	
5340 / 1085	P72	
5341 / 1D87	P73	
5342 / 1089	P74	
5343 / 1D88	P75	
5344 / 1D8D	P76	
5345 / 1D8F	P77	
5346 / 1D91	P78	
5347 / 1D93	P79	
5348 / 1D95	P81	
5349 / 1D97	P82	
5350 / 1D99	P83	
5351 / 1D9B	P84	
5352 / 1D9D	P85	
5353 / 1D9F	P86	
5354 / 1DA1	P87	
5355 / 1DA3	P88	
5356 / 1DA5	P89	
5357 / 1DA7	P91	
5358 / 1DA9	P92	
5359 / 1DAB	P93	
5360 / 1DAD	P94	
5361 / 1DAF	P95	
5362 / 1DB1	P96	
5363 / 1DB3	P97	
5364 / 1DB5	P98	
5365 / 1DB7	P99	
554 / 0038	Q_M	1238
5374 / 1ED3	Q_STORAGE	900 901 908 921 933 1246 4195 4203
552 / 0032	Q_SUB_T	1746 1759 5190 6215 6216
558 / 004A	R_MATRIX	2043 2062 2064 2074
4727 / 0004	RANGE_DISPLAY	4238 6689 6767
5106 / 171F	RAT_TABLE	3226 3230
5385 / 1F25	RAW_H	1247 1248 1390 1534 1536
12 / CE0B	READ_PMU_KEYBOARD	5675 5999
8 / CF02	READ_START_ADDRESS	112
9 / CF03	READ_STOP_ADDRESS	
4 / CF01	READ_TAPE	427
1702 / 05E5	REC_ERROR	1641 1665

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
2877 / 08FB	REG_SETUP	2502 2770
5095 / 1714	REGISTER_CROSS	2759 2946 4634 4776
5112 / 1728	REGISTER_DOT	2761 2766 4623 4627 4643 4790 4794
5 / 9F00	RESET_CMP_INTERRUPT	426
34 / 000A	RESET_PFG_COUNTDOWN	827 5887
13 / 9E00	RESET_PMU_INTERRUPT	
14 / 9800	RESET_RECORDER_INTERRUPT	6139 6186
568 / 0080	RESET_TF	1268 1281 1830 3610
1902 / 06E3	RESOLVE	1882 2151
5280 / 1004	RES2	2138 2139
5279 / 1002	RES3	2142 2143
52 / 0000	REVERSE	210 486
6112 / 5000	RF_HI_LIM	5945
6113 / 3000	RF_LO_LIM	5947
5921 / 197A	RF_TEST	1080 1084 1096 6009
4127 / 0008	RIGHT_STATION_PAIR	3866
5411 / 1F69	RIJ	669 762 2038 2040 3607 4788 4792 5078 5412 5413 5414 5415
	5416 5417 5418 5419 5420	
669 / 00FD	RIJ_ADD	1798 1964 2940 3283 3633
5408 / 1F55	RIJ_STAR	4171 4301 4306 4613 4614
1927 / 0701	RIJ_UPDATE	1034
5249 / 183C	ROLL	181 397 799 5847
5252 / 1C03	ROLL_END	786 6236
5251 / 18E8	ROLL_14	785
5250 / 183C	ROLL_15	766
766 / 0154	ROLLADDRESS	
1974 / 0743	ROTATE_RIJS	1966 2120
4746 / 1562	ROUND_FOR_H	4673
49 / 0002	RUN	164 204 210 412 486
5442 / 1FDA	RZ_ALPHA	3667 3679 5443
5435 / 1FBE	RZ_BETA	3701 4563 4775
5433 / 1FB2	RZ_C	4778 4789 4854 6781 7124
5434 / 1FB8	RZ_POS	3665 3681 4564 4565 4767 4774 4782 4786 4793 4858
5441 / 1FF2	RZ_RATE	4772 4810 5444
5440 / 1FD8	RZ_TIME	4847 5442
4788 / 1598	RZ_TIME_UPDATE.	1050
4765 / 1579	RZ_UPDATE	1049
5443 / 1FDB	RZ_VEL	3677 4572 4766
5412 / 1F69	R11	1932 2945 4805 6205
5413 / 1F68	R12	227 6206
5414 / 1F6D	R13	6207
5415 / 1F6F	R21	228 1593 1936 1967 6208
5416 / 1F71	R22	6209

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
5417 / 1F73	R23	6210
5418 / 1F75	R31	1939 1968 6211
5419 / 1F77	R32	6212
5420 / 1F79	R33	229 3608 6213
7119 / 1CA1	SAMPLE_NKR	6850 7029 7101
6844 / 17F5	SAVE_BP_DATA	6810
5430 / 1F96	SAVE_POSITION_VARIANCES	2032 2081 3468 3520 3604 4232 4233
2038 / 0796	SAVE_RIJ	2019
4928 / 164F	SC_ENTRY	682
5267 / 1C9F	SEASON_INDEX_NORTH	3001 3131
5268 / 1CA0	SEASON_INDEX_SOUTH	3005 3133
2201 / 0888	SELECT_MEASUREMENT	
51 / 0008	SELFTEST_ON	
538 / 0018	SHIP_SPEED_INPUT	
4736 / 0007	SIG_DISPLAY	4235
2913 / 0C2C	SIGMA_LOG	
2912 / 0C2A	SIGMA_NRA	2058
2914 / 0C2E	SIGMA_PSUDO	
5278 / 1D00	SIGMA_SQ_KICK	2034 2692
5367 / 1D88	SIGMA_SQ_N_COUNTER	1277 2257 2344 2469 2477 2486 4510 5075 6233 6234 6740
5368 / 1DD3	SIGMA_SQ_PHI_DOT_PHI_DOT	2307 2462 5072
5370 / 1E33	SIGMA_SQ_PHI_PHI	1273 2299 2460 4526 5074
5369 / 1E03	SIGMA_SQ_PHI_PHI_DOT	1493 2458 5073
547 / 0024	SIGMA_SQUARED_PHI_SUB_M	5192 6202 6203 6204
5958 / 19AA	SIGNAL_PIN	698
4934 / 1656	SIN	2334 3016 3020 3030 4930
4929 / 1650	SIN_COS	
5429 / 1F94	SIN_THETA_P	
529 / 0012	SIN_10_2	5935
533 / 0016	SIN_11_33	
531 / 0014	SIN_13_6	
4124 / 0008	SIX_DIGITS	3944 3963 3964 3969
7084 / 0D14	SIXTY	7043
7087 / 0D1A	SIXTYB1	7034 7047 7057
1043 / 02AF	SLOW	1041
600 / 00A4	SLOW_RATE	1043 1046
1913 / 06EE	SMOOTH	1852
5410 / 1F67	SMOOTH_DATA	1913 1923 1925
5407 / 1F53	SMOOTH_DATA_STAR	4583
4730 / 0005	SPEED_DISPLAY	4549 4581 4587
23 / 0040	SPEED_EXITATION_B	5990 5995
4900 / 1629	SQUARE_ROOT	680
5383 / 1F19	SS_PHI_M_BASE	1412 1416

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
4036 / 11DD	STAPAIR	4110 4111
4104 / 123E	START_ACCEPT_GROUP	4115
1068 / 02C9	START_BURST	1579
636 / 0005	START_CKSUM	165 765 5845
609 / 0082	START_CNT	1423 1425 1777 1788
610 / 0083	START_MKR	1426 1785 1831
1763 / 0635	START_OF_BURST	1068 6800 6811
1566 / 0538	START_OF_SLOT	1064
1156 / 0334	START_OMEGA	1042
592 / 009C	START_OMEGA_NOW	950 1156 1175
1064 / 02C5	START_SLOT	1181
580 / 0088	START_SYNC_TIME	942 943 1107 1158 4886
5155 / 175A	STATION_BURST_TIMES	1766 2897
612 / 0085	STATION_COUNTER	1185 1240 1378 1582 1611 1614 1728 1763 1771 2007 4270 6184 6314 6983
603 / 00A7	STATION_INDEX	
613 / 0086	STATION_NUMBER	2235 2273 2278 2407 2684
5207 / 1798	STATION_VECTOR_TABLE	670 2753 5077
654 / 00E5	STATIONS_IN_USE	859 1792 1854 2258 3507 4551 6227 6564 6789
4253 / 12E0	STATUS_CCOH	4194
4181 / 1284	STATUS_FAIL	4192
3881 / 1105	STATUS_INPUTS	3875 3877
53 / 0000	STOP	102 125 136 141 462 477
526 / 000E	SUM_T_ZERO_DOT	2194 2195
5139 / 1748	SUN_CONS	3006
670 / 00FE	SV_ADD	1592 2328 2939
4589 / 14A1	SWAP	4239 4252 4550 4582 4588
6773 / 1FE2	SX	6683
6772 / 1FE0	SXSQ	6591 6596 6612 6663 6681
7121 / 1FC6	SXSQ2	6831 7108
7122 / 1FCC	SX2	7109
1098 / 02E7	SYNC	1012 1058 1060 1062 1569 7137
5262 / 1E7A	SYNC_BASE	1114 1124 1142 5263
5260 / 1DAE	SYNC_C	845 5261
838 / 01B4	SYNC_CALC	
5261 / 1E78	SYNC_COUNT	5262
5259 / 1C1E	SYNC_DATA	946 947 1113 1134 5260
577 / 0087	SYNC_DATA_ADDRESS	986
576 / 0087	SYNC_DATA_ADDRESS_AND_FREQUENCY	1133
5263 / 1E7D	SYNC_DATA_COUNTER	1154
578 / 0088	SYNC_FREQUENCY	854
5041 / 16DE	SYNC_LIMIT_TABLE	861
583 / 008F	SYNC_N	1143 1147

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
980 / 0268	SYNC_SUMMATION_SUBROUTINE	862 867
575 / 0085	SYNC_10VERN	875 897 1150
1058 / 02BF	SYNC1	5669 6054
1060 / 02C1	SYNC2	1098
1062 / 02C3	SYNC3	1108 1116
6782 / 1FC6	T_0_BUFFER	6630 6680 6692 6694 6702 6705 6709 6715 6722 6723 6729 6734 6758 6769
7124 / 1FB2	T_0_BUFFER2	6835 6836 6837 6955 7031 7041 7076 7111
4742 / 0009	T_0_PEAVG	
6777 / 1FE8	T_0_SEC_COUNT	6665 6696
7125 / 1FE0	T_0_SEC_COUNT2	6839 6986 6988
6642 / 183E	T_0_TABLE	6634
6967 / 0C72	T_0_TABLES	6959
6776 / 1FE6	T_0_TIME	6698 6737 6739
7127 / 1FE4	T_0_TIME2	6841 6991 7104 7106
4745 / 000A	T_0_DOT_CVT	6731
47 / 8F10	TAPE_CONTROL	102 125 136 141 164 204 210 412 462 477 486
54 / 8F20	TAPE_FILL	111 158 209 485
764 / 0151	TAPE_ID	6225
27 / 8F20	TAPE_READER_DATA_READY	
32 / 8801	TAPE_RECORDER_BUSY	
33 / 8802	TAPE_RECORDER_INTERRUPT	
7112 / 0030	TEN_MIN	6989
579 / 0089	TEN_SECOND_SYNC_PERIOD_COMPLETE_MARKER	836 839 1152
634 / 00D1	TEST_FAIL	973 977
550 / 002E	TEST_FAIL_TEMP	974 978 3438 3756 4181
835 / 0180	TEST_SYNC	837 904 918 931 934
1074 / 02CF	TEST1	826
1092 / 02E1	TEST10	6049
1094 / 02E3	TEST11	5953
1096 / 02E5	TEST12	5916
1076 / 02D1	TEST2	5886
1078 / 02D3	TEST3	5895
1080 / 02D5	TEST4	5921
1082 / 02D7	TEST5	5963
1084 / 02D9	TEST6	5928
1086 / 02DB	TEST7	6007
1088 / 02DD	TEST8	6028
1090 / 02DF	TEST9	6033
5169 / 1768	TF_LAMBDA_CONSTANT_TABLE	1362 1440 2403 2741 4316
5076 / 1701	TF_PHI_DATA_ADDRESSES	1325 1438
5072 / 16FD	TF_SIGMA_SQ_DATA_ADDRESSES	1282
572 / 0085	TF_TEMP	575 576 577 578 579 1451 1468 1484 1494 5076

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
1293 / 03E5	TF_TIME_UPDATE	1286 1323
5404 / 1F50	THA_P_STAR	4577
2733 / 0847	THETA_C	2408 2413 3320 3325
622 / 00C0	THETA_P	1595 1902 1970 4612
7082 / 0D10	THIRD	7032 7037 7045 7050 7055
4122 / 0006	THREE_DIGITS	3975
619 / 008C	TIME	791 796 1006 1008 1159 1576 2976 3552 4885 6220
604 / 00A8	TIME_INC	1574 1578 2199
6614 / 1811	TIME_INC2	6590 6738
7114 / 0041	TIME_INC3	7105
5402 / 1F4C	TIME_STAR	4387
2065 / 07C1	TIME_UPDATE_P	
2082 / 07DE	TIME_UPDATE_X	
779 / 0080	TITLE	767
767 / 0155	TITLE_LINK	
1268 / 03C1	TRACKING_FILTER	
2234 / 08B5	TRACKING_FILTER_MEASUREMENT	2208 2679 2706
538 / 0018	TRUE_AIR_SPEED_INPUT	
537 / 001A	TRUE_HEADING_INPUT	1834
4121 / 0005	TWO_DIGITS	
6944 / 0C4D	TYPE_DYN_RNG_DATA	6792
6616 / 1815	TYPE_NAV_PERF_OUTPUT	6573
5254 / 1C04	TYPE_OUT	6401 6403 6635 6637 6960 6962
6433 / 18C8	TYPE_TABLE	6395
58 / 0000	UC	2226
81 / 0000	UCO	2207 2222 2226
4117 / 0001	UPPER_LEFT_KEY	3797 3861 3868 3900 3981 4000 4070
4118 / 0002	UPPER_RIGHT_KEY	3936 4030 4041 4045 4061
5444 / 1FF4	V_INSERT	1879 3576 4546
5109 / 1722	V_LAMBDA	2386 2430 4284
618 / 0088	V_TAS	1866 4651
5401 / 1F4B	V_TAS_STAR	4585 4652
4647 / 14EE	VARSAVE	3819 4139
620 / 00BE	VC2	621 1897 1929 4803 6222
5403 / 1F4E	VC2_STAR	4243 4574 4579
621 / 00BF	VC3	1928
1834 / 0690	VELOCITY_PROCESSING	1032 6478 7139
50 / 0004	VERIFY_ON	
598 / 00A2	V2	599 1337 1898 6221
599 / 00A3	V3	1336
601 / 00A5	WINDOWAD	4001 4012 4022 4024 4067 4092
4120 / 0004	WITH_ACCEPT_LIGHT	3934 3958 4034
5832 / 1A2A	WRITE_DATA	5794 5797

STMT# / ADDR	LABEL	STMT# WHERE REFERENCED
39 / 8802	WRITE_FILE_GAP	
5830 / 1A28	WRITE_LBUC	5816 5824
5264 / 1C27	X	2022 2087 2121 2558 2634 2638 4268 4271 5265 5266
5275 / 1CED	XX	2086 2092 2570 2601 2602 2608 2619 2645 2805
5258 / 1C1E	XXX	671 2085 2104 2123 2126 2146 2147 2161 2192 2565 2661 3328
		5259 6104 6730
671 / 00FF	XXX_ADD	2096 2644 2711
5274 / 1CE8	XXXX	2023 2162 2662 2803 6237
5276 / 1CF6	X2XX	2108 2635 2716
2867 / 0BED	Y_MINUS_MX	2571
5432 / 1FA6	Y_P	1201 1727