


1842 EEG/ EETET TR 79-6

TECHNICAL REPORT

A MICROPROCESSOR-BASED CONTROL EVENT SCANNER

Approved for public releases

Distribution Unlimited



409646

AD AO 65222

DOC FILE COPY

AFCS SYSTEMS TECHNICAL APPLICATIONS FACILITY

1842 ELECTRONICS ENGINEERING GROUP (AFCS)

SCOTT AIR FORCE BASE, ILLINOIS 62225

**31 JANUARY 1979** 

79 02 21 056

## 1842 ELECTRONICS ENGINEERING GROUP

## MISSION

The 1842 Electronics Engineering Group (EEG) has the mission to provide communications-electronics-meteorological (CEM) systems engineering and consultive engineering support for AFCS. In this respect, 1842 EEG responsibilities include: Developing engineering and installation standards for use in planning, programming, procuring, engineering, installing and testing CEM systems, facilities and equipment; performing systems engineering of CEM requirements that must operate as a system or in a system environment; operating a specialized Digital Network System Facility to analyze and evaluate new digital technology for application to the Defense Communications System (DCS) and other special purpose systems; operating a facility to prototype systems and equipment configurations to check out and validate engineering-installation standards and new installation techniques; providing consultive CEM engineering assistance to HQ AFCS, AFCS Areas, MAJCOMS, DOD and other government agencies.

#### APPROVAL PAGE

This report has been reviewed and is approved for publication and distribution.

ZYGMUND J. BARA

Chief, Telecommunications Systems

**Engineering Division** 

WILLIAM R. BROWN, MAJ, USAF

Chief, Engineering Services Branch

CALVIN R. TAYLOR

Technical Area Manager

JAMES R. HAMMER, Capt, USAF

**Electronics Engineer** 

DISTRIBUTION STATEMENT A

Approved for public release;
Distribution Unlimited

MICHAEL D. VERSTEGEN, 2LT, USAF Electronics Engineer

79 02 21 05

SECURITY CLASSIFICATION OF THIS PAGE (When Date Entered) **READ INSTRUCTIONS** REPORT DOCUMENTATION PAGE BEFORE COMPLETING FORM REPORT NUMBER 2. GOVT ACCESSION NO. 3. RECIPIENT'S CATALOG NUMBER TR 79-6 N/A TYPE OF REPORT & PERIOD COVERED 4. TITLE (and Subtitio) Final / A Microprocessor-Based Control Event Scanner • 6. PERFORMING ORG. REPORT NUMBER N/A 8. CONTRACT OR GRANT NUMBER(s) AUTHOR( ) James R. N/A Michael D. Verstegen 10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS PERFORMING ORGANIZATION NAME AND ADDRESS 1842EEG/EETET Scott AFB, IL 62225 N/A REPORT DATE 11. CONTROLLING OFFICE NAME AND ADDRESS 31 Jane 1842EEG/EEISG NUMBER OF PAG 58 P. Scott AFB, IL 62225 15. SECURITY CLASS. (of this report) 14. MONITORING AGENCY NAME & ADDRESS(II different from Controlling Office) Unclassified 15a. DECLASSIFICATION/DOWNGRADING SCHEDULE N/A 16. DISTRIBUTION STATEMENT (of this Report) Approved for public release. Distribution unlimited. 17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report) 18. SUPPLEMENTARY NOTES 19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Performance Monitoring Digital Communications IEEE Standard 488-1975 Microprocessor Microcomputer Performance Assessment 20. ABSTRACT (Continue on reverse side if necessary and identify by block number) The Control Event Scanner (CES) is a microprocessor-based device which will

control and sense relay contract closures via the IEEE Standard 488-1975 Interface Bus, hereafter known as the General Purpose Interface Bus (GPIB). Through the use of a microcomputer, other functions such as pulse counting, analog to digital conversion, digital timing, etc., are easily implemented. With a fully implemented unit, the capability exists to realize a low-cost, fully programmable automated test fixture suitable for use in a distributed

DD 1 JAN 73 1473 EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED

409646 SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

ernal microcomputer, on-line reconfi- iety of dedicated performance assess	guration is possible to implement a ment instruments. Performance asse
a fault isolation example are discu	ssed.
6.8	

### **ABSTRACT**

The Control Event Scanner (CES) is a microprocessor-based device which will control and sense relay contact closures via the IEEE Standard 488-1975 Interface Bus, hereafter known as the General Purpose Interface Bus (GPIB). Through the use of a microcomputer, other functions such as pulse counting, analog to digital conversion, digital timing, etc., are easily implemented. With a fully implemented unit, the capability exists to realize a low-cost, fully programmable automated test fixture suitable for use in a distributed performance assessment network (DPAN). With the use of the GPIB and an internal microcomputer, on-line reconfiguration is possible to implement a variety of dedicated performance assessment instruments. Performance assessment and a fault isolation example are discussed.



NTIS		White	Section	A
DDC		Bitt	Section	
UNANN	SUMOTO			
JUSTIT	CATTON	_1361-130		
RICT#!	BUTION	WALLAS	LITY COD	ES
Dist.			or SPI	

-A

ASCII - American Standard Code of Information Interchange

CES - Control Event Scanner

DPAN - Distributed Performance Assessment Network

Defined in 1842 Technical Report TR 77-4 (Automated Data Acquisition Applied to Monitoring of Communications Systems) 1 Oct 76

EPROM - Erasable Programmable Read Only Memory. A semiconductor memory device which is electrically non-volatile.

Event Sensing - Process of sensing relay states indicating equipment and/or parameter status.

Fault Isolation - Process of localizing system malfunctions based on parameter samples at strategic points in the system.

GPIA - General Purpose Interface Adapter. A system of five integrated circuits that implement the protocol of the IEEE Standard 488-1975 General Purpose Interface Bus between a microprocessor and a compatible device.

GPIB - General Purpose Interface Bus. The electrical and logical interface between compatible equipment specified by IEEE Standard 488-1975. See Appendix A.

Histogram - A graphic representation of a frequency or relative frequency distribution consisting of vertical rectangles whose widths correspond to a definite range of frequencies and whose heights correspond to the number of frequencies occurring in the range. (Webster's Second Collegiate Dictionary)

LED - Light Emitting Diode

Nodal Controller - A processor located at a "node" in a distributed performance assessment network (see Figure 3-

2). The nodal controller has the mass storage and data analysis capability necessary for a large performance assessment network.

RAM - Random Access Memory. Semiconductor read write memory that is electrically volatile.

Remote Processor - A processor located at a communications site which communicates with the nodal controller, the Control/Event Scanner, and other remote processors in the network (see Figure 3-2). The remote processor may accomplish data analysis in addition to collecting parameter information from the CES.

SPDT - Single Pole, Double Throw.

uP - Microprocessor

## TABLE OF CONTENTS

Paragraph No.	Page No.
1.0 BACKGROUND	
1.1 GENERAL	
1.2 STATUS	and management to the late of
2.0 THE CONTROL EVENT SCANNER	
2.1 DESIGN PHILOSOPHY	mangini Andri Amir
2.2 DESIGN CRITERIA	Control transit (a)
2.3 THEORY OF OPERATION-HARDWARE	2
2.3.1 Alarm/Event Sensing Subystem	2
2.3.2 Relay Control Subsystem	2
2.3.3 Analog to Digital Converter Card	2
2.3.4 Pulse Counter Card	2
2.3.5 GPIB Interface	7
2.4 SYSTEM SOFTWARE-THEORY OF OPERATION	7
2.4.1 Alarm Scanner	7
2.4.2 Histogram Processing	7
2.4.3 Relay Control	7
2.4.4 GPIA Control	7
2.4.5 Communications Executive	7
3.0 CES APPLICATIONS	8
3.1 STAND-ALONE CES	8
3.2 CES WITH REMOTE PROCESSOR	8
3.3 CES AND DPAN	8
3.4 FAULT ISOLATION	10
4.0 CONCLUSIONS	11
5.0 RECOMMENDATIONS	11
6.0 ACKNOWLEDGEMENTS	11
APPENDICES	
A. IEEE STANDARD 488-1975 (EXCERPT)	A-1 thru A-4
B. AIR FORCE ACADEMY PROJECT ORDER	B-1 Thru B-3
C. CES SYSTEM SOFTWARE	C-1 thru C-24
D CES PROGRAMMING CODES	D-1

## LIST OF ILLUSTRATIONS

FIG	JRE	1	Page
2-1	Alarm Input Subsystem		3
2-2	Relay Control Subsystem	. 49	4
2-3	Analog to Digital Converter Card		5
2-4	Pulse Counter Card		6
2-5	GPIA Block Diagram		8
3-1	CES "Smart Sensor"	ARRESTACE	10
3-2	Distributed Performance Assessment Network	SCHARLES STREET, SECOND SOLD	11
3-3	CES Fault-Isolation Configuration	assessed grown worth	13

#### 1.0 BACKGROUND.

- 1.1 GENERAL. The CES was a joint Air Force Academy/1842 EEG project which began during a cadet summer (1976) research program, sponsored by the 1842 EEG. The CES was developed in two stages. Stage I was the interface between CES functions; i.e., relay control/sensing, A/D conversion, and a microcomputer. Stage II was the development of the IEEE Standard Bus 488-1975 interface adapter. The CES is the first joint AFA/1842 EEG project to use the GPIA (see Glossary) to implement the GPIB and will serve as the pilot for any further joint projects using the GPIB. The project served as course material for both students and faculty at the Air Force Academy.
- 1.2 STATUS. The CES development hardware and software are complete. Some functions, such as analog/digital conversion and pulse counting, were not implemented since it would be easier to do so at a later date. The CES has the capability to scan alarms (relay contact closures) and control selected relays. In addition, it can communicate with an on-site or remote processor to exchange data, commands, and configuration programs via the GPIB. Through the use of a "local" command, the CES may be operated as a stand-alone device with all functions accessed and displayed through local terminal control. The CES easily meets or exceeds all original specifications generated in the project order given to the Air Force Academy (see Appendix 2). Additionally, the CES provides enhanced data acquisition and network communication techniques.

#### 2.0 THE CONTROL EVENT SCANNER.

- 2.1 DESIGN PHILOSOPHY. One problem area foreseen in a distributed performance assessment network, within a digital communication system, is the overloading of the remote processor with many mundane data acquisition tasks as well as handling data reduction and communication protocol to the nodal controller. To overcome this problem and relieve the remote processor of having to acquire data at a relatively fast acquisition rate, it is desired to have a dedicated monitoring unit to perform specific functions such as monitoring Receive Signal Level, Eye Pattern Degradation, Bit Error Rate, and Frame Alarm State Sensing. Then, on a periodic basis, the transfer of this information from the dedicated monitor to the remote processor may be accomplished. The remote processor can then store the measured parameters for that time period, transmit them upon command from the nodal controller, or further reduce the data for statistical analysis. The use of standard interfaces and communications protocol is assumed in order to reduce development costs and utilize off-the-shelf equipment as much as possible. In addition, with the advent of the microprocessor, the capability to do moderately fast, low-cost data acquisition is readily apparent.
- 2.2 DESIGN CRITERIA. The project order, sent to the Air Force Academy in the Fall of 1975, outlined all major design concepts and is included in this report as Appendix 2. Air Force Academy project personnel suggested certain hardware and software changes to improve the overall effectiveness of the scanner. For example, instead of activating switches from the front panel to select a particular relay, a terminal device is used under software control for complete control of the scanner in the local mode. Furthermore, by using software control techniques, the front panel controls may be locked-out and control may then be transferred to the remote processor. These types of changes have improved overall performance and increased the capabilities of the scanner without additional expense.

#### 2.3 THEORY OF OPERATION-HARDWARE.

2.3.1 Alarm/Event Sensing Subsystem. The event/alarm scanner is capable of sampling and detecting up to 256

alarm conditions characterized by normally open contacts closing on the alarm. This function is implemented with one decoder/driver card and up to 16 alarm input cards (Figure 2-1).

The decoder/driver card consists of a decoder to select a particular alarm card. Level regeneration and buffering are provided to prevent high system data bus loading when many alarm cards are installed. The decoder board is installed on the microprocessor bus and is connected to the alarm board rack via a 24 line cable. This cable carries the board select code, word select and data bus connections to the alarm rack.

Each alarm card consists of two tri-state octal buffers and 16 LED displays with associated resistors. (Reference Fig. 2-1) One contact of each alarm is tied to the +5 supply and the other contact is connected to an input of the buffer. The inputs are connected to show a logic  $\emptyset$  when the alarm is inactive. When the alarm contact closes, the input is pulled high and also sources the current to the LED to give a visual indication of the alarm. When the microprocessor addresses the alarm card, the actual state of the alarms is available on the system data bus to be read by the processor. Using this input scheme, any alarm input that is not connected shows up as an inactive alarm, and allows the monitoring of TTL level alarm inputs as well as relay contact closures.

2.3.2 Relay Control Subsystem. The relay control system (Figure 2-2) is capable of controlling up to 128 SPDT relay contacts independently. This function is implemented using one decoder/driver card and up to 16 relay cards.

The relay control section is very similar to the design of the alarm section. The decoder/driver card includes a decoder to select one of the relay cards to be accessed. The driver provides a high current capability to drive the inputs of the relay cards and prevent loading on the uP data bus by the relay rack bus. The relay rack is connected to the decoder/driver card by a 24 conductor cable carrying the data bus and the board select.

The relay board consists of an octal D flip-flop, two high voltage inverting buffers and eight relays. When the board is selected by the decoder, the data that is on the data bus is strobed into the latch. The outputs of the flip-flops in the latch are connected to the high voltage drivers which control the coil current in the relays.

- 2.3.3 Analog to Digital Converter Card. The Analog to Digital (A/D) Converter card is implemented using an off-the-shelf 8-bit A/D module. As shown in Figure 2-3, the A/D card consists of a decoder, and A/D module and an operational amplifier. The analog input is buffered by the operational amplifier to provide isolation and to prevent input loading. Additionally, the operational amplifier may be configured to provide a linear scaling factor, or non-linear (e.g. exponential) transfer function for specialized applications. The A/D conversion begins when a module is selected by the address decoder and ends when the processor "Ready" line goes high. Processor utilization is thus determined by the conversion speed of its A/D converter module since processing cannot continue until the conversion is complete.
- 2.3.4 Pulse Counter Card. The Pulse Counter Card (Figure 2-4) is based on the Intel 8253 counter. Each of these integrated circuits consists of three independent 16 bit counters that may be configured as one 48 bit counter. The decoder in this application selects only the chip with each counter in the chip being addressable by the system address bus. The signal conditioner shown in Figure 2-4 may include Schmitt triggers, level convertors and/or a prescaler to divide the pulse rate to the 2MHz limit of the 8253.

Through the use of various software configurations, the pulse counter card may be used for a multitude of performance assessment parameters; e.g., percent error free seconds, instantaneous bit error rate, recursive bit error rate, etc.




FIGURE 2-1 Alarm Input Subsystem




FIGURE 2-2 Relay Control Subsystem




FIGURE 2-3 Analog to Digital Converter Card




FIGURE 2-4 Pulse Counter Card

2.3.5 GPIB Interface. The GPIB (Figure 2-5) controls all the transfers to and from the GPIB and the uP. The protocol and handshaking are transparent to the uP thus only a minimal amount of overhead is incurred for GPIB communications. Four special bus drivers provide the high drive capability and tri-state or open-collector outputs required for GPIB compatibility.

#### 2.4 SYSTEM SOFTWARE-THEORY OF OPERATION.

- 2.4.1 Alarm Scanner. The alarm scanner software uses the alarm input subsystem to read the current state of the alarm inputs. Alarms are scanned sequentially and the current condition of the inputs is compared to the status saved during the last scan. Any difference in status causes the histogram subroutine to be invoked.
- 2.4.2 Histogram Processing. The histogram processing section is broken up into four subroutines. These subroutines allocate and clear the histograms in addition to processing alarm status changes.

The allocation routine computes the size of storage required for histograms and tables. The user must supply the number of alarm cards installed; the processor then sets up the appropriate memory partitions for the histograms.

The histogram clear function sets the histograms and tables to zero values before processing is begun, or after the system has dumped the histogram data to the controlling device.

Histogram data on the alarms consists of the total time that the alarm has been active since the last histogram clear and the total number of times that the alarm has activated over the same period. Two routines process the change of alarm state depending on the change. If the alarm is set (goes from an inactive to active state), the current time is stored in a location associated with the alarm and the alarm occurance count is incremented. If the alarm resets (goes to an inactive state), the difference between the current time and the time saved when it is activated is added to the total time that the alarm has been active.

- 2.4.3 Relay Control. Relays can be controlled either by front panel control, or by the GPIB from a controller. Each relay is assigned a unique identifier and is accessed by that name.
- 2.4.4 GPIA Control. The GPIA interface chip requires some software support for configuration and input/output of data. These routines are of a utility nature and are accessed through the monitor read/write subroutines. Various special functions are available from the GPIA chip but are not currently supported in the driver software.
- 2.4.5 Communications Executive. The communications executive routes all requests from the controller to the appropriate subroutine designed for that function. These commands fall into the categories of processor control, histogram commands and relay operation.

The processor control group consists of three commands. The "P" command loads a program from the controller to the processor's memory. This allows the configuration of the system to be changed remotely. The "G" command tells the uP to go to a specified location and start execution of the program at that point. "L" is the local enable function which allows commands to be entered from the processor's terminal device. The "R" command locks out the keyboard and puts the CES into a totally remote status.




FIGURE 2-5 GPIA Block Diagram

The histogram command section implements three commands. The "A" command allocates a block of memory to the histogram storage. The controller must tell the CES how many alarms are to be monitored when this command is sent. The "D" command dumps the histogram data from the CES to the controller. Depending on the parameters with the command, any or all of the histograms may be dumped. The last function is to clear the histograms with the "C" command. This sets all histogram locations to zero as an initialization step. This command also resets the system clock.

The "K" command specifies a relay to be activitated or deactivated. The parameters specify the relay and the action to be taken. A summary of Executive commands are included in Appendix 4.

#### 3.0 CES APPLICATIONS.

- 3.1 STAND-ALONE CES. The internal architecture of the CES, in a stand-alone mode, is determined by the software monitor program which resides in EPROM. The monitor allows the operator to do the same functions as under computer control but from local terminal control. In addition, the operator may examine RAM locations to determine what value has been stored in the histogram or if any input card is not responding and so on. A listing of terminal commands is contained in Appendix 3. The stand-alone or "local" mode is intended for use when no controller is available or when side maintenance is being accomplished.
- 3.2 CES WITH REMOTE PROCESSOR. The full potential of the CES is realized when it is used in conjunction with a calculator or minicomputer-based controller that conforms to the IEEE 488-1975 Standard for GPIB controllers. Commands, data, and configuration programs may be exchanged between the controller and the CES over the GPIB. The controller may initiate any function or read any data contained in the CES by transmitting the appropriate command. It is also possible to reconfigure the software of the CES to change performance assessment algorithms by downloading the appropriate software modules to the CES from the controller. For example, suppose it is desired to have the CES measure percent error free seconds instead of instantaneous bit error rate. Simply download the appropriate software module from the controller and, using the same hardware configuration, the CES will transfer control to the new program in RAM, and will now process percent error free seconds. Naturally the CES will probably already contain most of the performance assessment type algorithms in EPROM, however, should any additions or modifications be desired, the CES has this capability. Should the new algorithm prove more useful than the old one, it is a simple matter to permanently install the program in EPROM within the CES.

When used in conjuntion with a controller, the CES may be thought of as a "smart" sensor (Figure 3-1) since it has the ability to pre-process the data collected into system parameters before passing the information to its controller. This frees the controller to do more important data analysis and prevents the time consuming process of transmitting unprocessed data.

3.3 CES AND DPAN. The CES becomes an even more important concept, in terms of a "smart" sensor, when viewed in a distributed performance assessment network (ref. 1842 EEG TR-77-4) as shown in Figure 3-2. It is conceivable that with the appropriate input cards, the CES might be the only sensor needed at each site to accomplish data acquisition and parameter processing. Through the use of communication executive program control, the nodal controller, as well as the remote processor, would have the capability to reconfigure the CES software architecture.




FIGURE 3-1 CES "Smart Sensor"




FIGURE 3-2 Distributed Performance Assessment Network

The Rest Advantage of

3.4 FAULT ISOLATION. Figure 3-3 shows how the CES might be configured in a typical digital communications size. By connecting various input cards to strategic points, at the site equipment, a level of fault isolation may be accomplished. In this case, the fault may be isolated to a particular equipment. For example, suppose the CES indicates that it is receiving error counts on pulse counter card 1. A quick check of A/D cards 1 and 2 indicate AGC voltage (and thus radio received signal level) and the noise level on the digital eye pattern (radio baseband) are within tolerance. One would suspect, in this case, that the 2nd level multiplexer might have a bad module. This is a simple example, however, with the use of other input cards in the CES, the resolution of the fault isolation algorithm may be extended to the very module causing the problem. The capability of the CES to use an adequate number of input cards and its compatibility with the IEEE Standard Bus makes the CES a viable solution to fault isolation problems.

#### 4.0 CONCLUSIONS.

The CES is an extremely flexible test fixture. Its variety of input cards, GPIB compatability, microcomputer control, low cost, and inherent reliability, make the CES concept a logical choice in the areas of performance assessment and fault isolation. Since the start of this project, several manufacturers have developed similar capabilities in what are now off-the-shelf test equipments. Through the use of the IEEE Standard (488-1975) Bus, these equipments may be configured together to provide basically the same functions as the CES.

#### 5.0 RECOMMENDATIONS.

The CES concept of remote pre-processing should be considered in specifying future large-scale performance assessment networks. Test fixtures which utilize such desirable features as GPIB compatability, variable internal software architecture, standard communication protocol, and both local and remote control should be considered essential to provide an accurate and reliable military performance assessment network.

#### 6.0 ACKNOWLEDGEMENTS.

Special recognition is merited for the following Air Force Academy students and faculty:

Maj. Ed Pearsol AFA AFCS Liaison Officer Maj. John Schmidt AFA AFCS Liaison Officer Cadet Zak LaPlant 1976 Project Cadet Cadet Bert Halbert 1976 Project Cadet \*Cadet M. D. Verstegen 1977 Project Cadet

\*2Lt Verstegen is currently assigned to the 1842 EEG, Scott AFB and is the co-author of this report.




FIGURE 3-3 CES Fault-Isolation Configuration

#### APPENDIX A

#### GENERAL PURPOSE INTERFACE BUS DESCRIPTION

The overall purpose of an interface system is to provide an effective communication media so that two or more devices or systems can transmit meaningful messages between each other. The IEEE STD 488-1975 Standard Digital Interface for Programmable Instrumentation is such an interface. This interface will be referred to as a General Purpose Interface Bus (GPIB) hereinafter.

The bus is made up of 16 lines to carry information between instruments connected to the GPIB. Figure A-1 gives a pictorial representation of the GPIB. The 16 lines can be divided into three functional groups.

Eight lines are used to transfer data between devices in ASCII coded bit parallel, byte serial format. Other information codes could be used for device dependent messages, however, and the ASCII code is not required by the IEEE standard.

Three lines are dedicated to the control of data byte transfers between devices and are commonly called handshake lines, thus allowing the data to be transferred asynchronously over the GPIB. See Figure A-2.

Five additional lines are used for general interface management. One line is used to determine the data mode or the command (addressing) mode for the eight data lines. See Figure A-1 for the purpose of each.

Since it takes more than just the physical interconnection of black boxes to have an effective communication media, specific interface functions must be defined. Ten different possible functions are shown in Figure A-3 as defined by the standard. The list gives a general idea of the purpose of each function. A description of each function as it relates to hardware can be found in more detail in the IEEE Standard 488-1975. The handshake functions, however, are what make the GPIB a viable interface and are best described by the flow diagram in Figure A-2.

For any given device, only those functions required to satisfy the operation of the device need to be included in the design of an instrument.




FIGURE A-I GENERAL PURPOSE INTERFACE BUS (GPIB) STRUCTURE





FIGURE A-2 DATA TRANSFER USING SOURCE AND ACCEPTOR HANDSHAKE PROCESS

THE PROPERTY OF THE PARTY OF



- 1. Interface Bus Signal Lines
- 2. Remote Interface Messages to and from Instrument Functions
- 3. Instrument Dependent Messages to and from Instrument Functions
- 4. State Linkages Between Interface Functions
- 5. Local Messages Between Interface Functions and Instrument Functions
- 6. Interface Messages Sent by a Controllers Instrument Functions

#### APPENDIX B

# Proposed Hardware Concept of Dedicated Monitors

## SECTION I CONTROL/EVENT SCANNER

1.0 Scope: This attachment applies to a stand alone monitoring instrument that can (1) detect and process the state of up to 256 alarms (Form C contact closure) in groups of 16 inputs per card, or (2) provide 8 Form A relay contact closures per card for a total of 128 relay control points. Any combination of alarm and relay cards will be allowed per mainframe. The instrument will be automated with interface to system controller conforming to IEEE STD 488-1975. Local control will be accomplished with front panel controls.

### 2.0 Applicable Documents:

IEEE 488-1975


IEEE Standard Digital Interface for Programmable Instrumentation.

DNSF TR-75-100

Radio Service Channel Techniques in a Digital Communication System

## 3.0 Requirements:

Design and construct two prototype Control/Event Scanner that will perform the following functions. A block diagram is shown in Figure B-1.



#### 3.1.0 Stand Alone Requirement.

- 3.1.1 Sense on-off (True-False) indications from communication equipment that uses Form C relay contacts for alarm indications. Necessary voltage or current sources should be contained within the monitoring equipment. Current sensing shall be limited to .5 amp. Voltage sensing shall be possible from 4 to 50 volts.
- 3.1.2 Sample rate for each alarm should be at least one sample/second or 256 alarms/second scan rate.
- 3.1.3 Each unit shall have the capability to sense up to 256 alarm states in groups of 16 alarms per plug in printed circuit card.
- 3.1.4 Control communication equipment by the activation of two pole Form C relay contacts. Contacts shall have a current rating of at least 1.0 amps at 48 volts.
- 3.1.5 Each unit shall have the capability of controlling 128 separate relays in groups of eight relays per card.
- 3.1.6 Display alarms on front panel of each card using red LED's.
- 3.1.7 Activate selected control relays from front panel and display activated relays with LED indicators.
- 3.2.0 Interface Functions.
- 3.2.1 All functions of the Control/Event Scanner should be programmable.
- 3.2.2 The interface to a system controller shall conform to the IEEE Standard Digital Interface for Programmable Instrumentation Std 4881975.
- 3.2.3 Interface Functions shall contain the following, as defined in Section 2 of IEEE Std 488-1975:
  - a. Source Handshake.
  - b. Acceptor Handshake.
  - c. Talker.
  - d. Listener.
  - e. Service Request.
  - f. Remote Local.
  - g. Device Clear.
- 3.3.0 <u>Device Programmable Functions</u>. This area requires study into the necessary programming requirements for this device and the required complexity of the programmable logic. Proposed data requirements are stated in the following paragraphs that will help in determining the controller complexity.

- 3.3.1 Scan inputs to determine alarm states.
- 3.3.2 Transmit information over interface when addressed to talk.
- 3.3.2.1 Each alarm should be characterized by a multiple ASCII coded character. As an example:



- 3.3.2.2 Only active alarms will be transmitted.
- 3.3.2.3 Active control relays will be included in the data transfer.
- 3.3.2.4 When addressed to listen, accept control information to activate or deactivate relays specified by a multiple ASCII coded character.
- 3.3.2.5 Store histogram of each alarm giving number of times each alarm was activated and total time each alarm is in the active state.
- 4.0 Mechanical Considerations.
- 4.1 It is desired that all cards be accessible from the front of the equipment.
- 4.2 Figure A2-2 shows a proposed front panel layout.
- 4.3 Unit shall be capable of being rack mounted in a 19-inch rack.
- 5.0 Power.
- 5.1 Unit shall operate with a power line frequency anywhere between 47 and 63 Hz.
- 5.2 Unit shall operate with a power line voltage of 110V or 220VC (+20%) switch selectable.

## Appendix C

AFCS 8000 ASSEMBLER		CES SYSTEM SOFTWARE			00:40 32	PAGE 1	
SYMBOL TAB	LE						
SYMBOL	VALUE	SYMBOL	VALUE	SYMBOL	VALUE	SYMBOL	VALUE
LWAM	ØF FF	EXEC	09 00	JMPTBL	09 14	NOGOOD	09 3A
ALARMS	7F EØ	NCARDS	OF FF	STATUS	ØF FD	TIMEON	OF FB
OCCUR	0F F9	MITTOT	0F F7	TYPCHG	0F F5	HSTTOP	0F F4
HSTMEM	09 3C	DBLSUB	09 71	HSTCLR	09 78	CLRH1	09 80
SCAN	09 BD	CHECK	09 98	UPDATE	09 AC	UPLOOP	09 B4
UPSTOR	09 BF	UPDSET	09 C7	UPDRST	09 D2	HSTGRM	09 DA
HSTSET	09 F0	HSTRST	0A 0C	HSDMDR	ØA 35	HSDMAL	0A 49
HSTDMP	ØA 54	EXCUTE	ØA A6	PLOAD	ØA AA	PLLOOP	ØA CZ
GPIA	BF CB	GPTALK	0A D5	GTTRAN	ØA EA	GTLAST	ØA FB
GPL IST	ØB Ø3	GLREC	ØB 19	GLSTAT	ØB 21	GLSKIP	03 30
CTLPRT	00 OC	BDRTPT	00 0B	CHSLPT	00 09	USTAT	00 08
DATAIN	00 09	DATOUT	00 0A	ASNIO	ØB 38	TTY	ØB 44
CASETT	ØB 47	READS	0B 4A	RNOERR	ØB 56	WRITES	ØB 60
DMPASC	0B 6C	BLKDMP	ØB 77	BKDP1	ØB BA	SEQFIL	0B 97
SQF IL 1	0B A0	MEMACC	ØB B2	MEMAC 1	ØB DB	ERROR	ØB DE
ERRMSG	0B F8	READ	0B 19	WRITE	ØA EA	CNTR	BF CØ
TIME	09 FE	CCTLWD	BF C3	IN8253	OC OA	RS8253	0C 1E
RD8253	ØC 26	HEX1	ØC 37	HEX1A	ØC 45	HEX2	ØC 49
ASCII	ØC 59	CMPHND	ØC 63	RD1BHX	OC 68	RD2BHX	ØC 73
RD4BHX	ØC 7C	RD1BI3	ØC 85	WR1BHX	DC A4	WR2BHX	ØC B7
WR1813	ØC CØ	WR1BI2	ØC CF	CR	00 0D	LF	00 0A
CRLF	ØC E3	MLTPLY	ØC EE	MULTO	ØC F2	DIVIDE	ØD Ø1
DIVO	0D 04	DIVI	ØD 15	DIVZ	ØD 1D		
LINE LOC	B1 82 83		SOURCE LI	NE .			
1		• • •		STEM SOFTW			tederla kata kata ka
2			****	*****	****	-	
3		*	CONTROL	EVENT CCO	NNED COET	MOF	*
4		*	CUNTRUL	EVENT SCA	MINER SUF I	WHICE	
5		*	. T MIVE	FROTECEN	1042 556	~~~~	*
6		*	LI HIKE	ERSTEGEN.	1842 EEG	EEIEI	*
7		*			-1-1-1-1-1-1-1-1-1-1		*
8				NOKANDKANDIO	okakokokokokokokoko		plototototok
9			KG 10900		T 1000 411		I MENOR
10			OU 'OFFF			AILABLE RA	
12			intototototototo	etakokalatok tolok	okototokokototoko		
13		*					*
14			MMAN	n E X E	CUTI	VE	*
15		>k					*
16		Olokokokokoko	iotototototototo	KOKOKOKOKOKO	OKOKOKOKOKOKOKOKOKOKOKOKOKOKOKOKOKOKOK		solototototok

```
AFCS 8080 ASSEMBLER
                       CES SYSTEM SOFTWARE
                                              00:40 322/78
                                                                 PAGE
                           SOURCE LINE
LINE LOC
           B1 B2 B3
  18
  19
                    * EXEC USES THE ASCII CHARACTER IN THE ACCUMULATOR
                         TO JUMP TO THE APPROPRIATE SUBROUTINE.
 20
 21
                    *
                            REGISTERS AFFECTED: ALL
  22
     0900 D6 41
                    EXEC
                           SUI "A"
                                           OFFSET FOR COMMANDS
 23
                           CPI "S"-"A"+1
     0902 FE 13
                                           LIMIT NUMBER OF COMMANDS
 24
     0904 D2 3A 09
                           JNC NOGOCD
  25
                                           INVALID COMMAND
     0907
                           RLC
                                           MULTIPLY BY 2
 26
           07
                           MOY E.A
                                           MOVE TO LSB OF DE
     0908
           5F
  27
     0909
          16 00
                           MVI D.0
                                           CLEAR MSB
  28
                           LXI H. JMPTBL
                                           LOAD BASE OF JUMP TABLE
     0908 21 14 09
  29
                                          COMPUTE ABSOLUTE INDEX TO TBL GET MSB OF ADDRESS
     090E
                           DAD D
  30
           19
                           MOV D.M
  31
     090F
           56
                           INX H
                                           POINT TO LSB
     0910
          23
  32
  33
     0911
          5E
                           MOY E,M
                                           GET LSB
     0912 EB
                           XCHG
                                           PUT ADDRESS IN HL
  34
  35
     0913 E9
                           PCHL
                                           JUMP THERE - RETURN TO SECTION
                                             THAT CALLED EXEC
  36
                                           VERIFIED 22 AUG 78
  37
                    JMPTBL DW HSTMEM
                                           A - ALLOCATE MEMORY
     0914 09 3C
  38
                           DW NOGOOD
  39
     0916
          09 3A
                                           B NOT USED
  40
     0918 09 78
                           DW HSTCLR
                                           C - CLEAR HISTOGRAM
                                           D - DUMP HISTOGRAM DATA
                           DW HSDMDR
  41
     091A
          ØA 35
  42
     091C
          09 3A
                           DW NOGOOD
                           DW NOGOOD
  43
     091E
           09 3A
     0920
          0A A6
                           DW EXCUTE
                                          G - GO
  44
                           DW NOGOOD
  45
     0922
           09 3A
  46
     0924
           09 3A
                           DW NOGOOD
                                           1
  47
     0926
           09 3A
                           DW NOGOOD
  48
     0928
           00 00
                           DW 0
                                          K - RELAY CONTROL
                           DW 0
  49
     092A
           00 00
                                          L - LOCAL ENABLE
                           DW NOGOOD
  50
     Ø92C
           09 3A
  51
     092E
           09 3A
                           DW NOGOOD
                           DW NOGOOD
 52
     0930 09 3A
                                          0
                           DW PLOAD
                                          P - PROGRAM LOAD
  53
     0932
          ØA AA
          09 3A
                           DW NOGOOD
                                          0
  54
     0934
                           DW 0
                                           R - REMOTE
  55
     0936
           00 00
                                           S - SCAN
  56
     0938
           09 BD
                           DW SCAN
                    NOGOOD EI
  57
     093A FB
                                           INVALID COMMAND
  58
     0938 C9
                           RET
                                             NO ACTION
  60
                    61
                    *EXECUTIVE ROUTINES LIBRARY*
  62
  63
  64
                    65
                    56
  67
                               SYSTEM MEMORY MAP
```

AFCS	8080	ASSEMBL	ER	CES S'	YSTEM SOFTL	JARE	00:40 322/78 PAGE 3
LINE	LOC	B1 B2	B3		SOURCE LINE		
68 69					SIZE		DESCRIPTION
70 71 72 73			*	ALARMS	*7FE0-*7FF	F	MEMORY MAPPED I/O LOCATION OF ALARM INPUTS. ADDRESS IS HARDWIRED ON DECODER BOARD.
74 75 76 77			**	STATUS	1 BIT/ALAR 2 BYTES/CA		STATUS OF ALARMS DURING LAST SCAN CYCLEE
78 79 80				TIMEON	2 BYTES/AL 32 BYTES/C		TIME ALARM WAS ACTIVATED.
81 82 83				MITTOT			TOTAL TIME ALARM HAS BEEN ON SINCE LAST HISTOGRAM CLEAR.
84 85 86			* *				NUMBER OF TIMES THE ALARM HAS HAD AN OFF TO ON TRANSITION.
87 88			•••			lolokslolo	
89 90 91 92			A	LARMS ECCARDS EC	OU '7FE0 LOWING FOU	JR WOR	HARDWIRED ADDRESS OF ALARMS NUMBER ALARM CARDS INSTALLED RDS CONTAIN THE ADDRESS OF THE
93 94 95			9	TOTILS FO	II NCARDS-2		ALARM STATUS TIME ALARM TURNED ON COUNT OF ALARM ACTIVATIONS TOTAL TIME ALARM ON TYPE OF UPDATE PROCESSED
96 97 98 99			**		DU OCCUR-2 DU TOTTIM-2	2	TOTAL TIME ALARM ON  TYPE OF UPDATE PROCESSED  0 = TURNED OFF (RESET)  1 = TURNED ON (SET)
100 102			H *	STTOP EO			TOP OF HISTOGRAMS
103 104 105 106 107 108 109			*	HSTMEM FROM DOWN	1 THE HIGHE N. NUMBER REGISTERS A REMORY AFFE	OF AL	RY TO THE HISTOGRAMS IN BLOCKS MAILABLE MEMORY (PASSED IN HL) LARM CARDS INSTALLED IN REG. C. TED: A, B, C, H, L STATUS, OCCUR, TIMEON, TOTTIM LED: DBLSUB
111 112 113 114 115 116 117	0944 0945 0946	79 E6 0F 32 FF 07 4F 5 4F 5 21 F4	0F 0F	STMEM M MC AI ST RL MC LX	OV A.C HI 'ØF TA NCARDS LC OV C.A KI H.HSTTOP	, ,	CLEAR MSB GET CARDCOUNT LIMIT TO 15 CARDS SAVE NUMBER OF CARDS CONFIGURE MULTIPLY BY 2 SAVE BLOCKSIZE (2 BYTES/CARD) OAD BOUNDARY VALUE GENERATE BASE OF BLOCK

```
AFCS 8080 ASSEMBLER
                         CES SYSTEM SOFTWARE
                                                   00:40 322/78
                                                                       PAGE
            B1 B2 B3
                              SOURCE LINE
LINE LOC
      094C
                             SHLD STATUS
                                              SAVE ADDRESS
 119
            22 FD 0F
                                              CLEAR CARRY
            AF
                             XRA A
 120
      094F
                                              MULTIPLY BY B
 121
      0950
            07
                             RLC
                                                 NOW IS NUMBER CARDS X 16
                             RLC
 122
      0951
            07
                                                    FOR 16 BYTES/CARD
 123
      0952
            07
                             RLC
                                              SAVE BLOCKSIZE
NEXT TABLE BASE
SAVE ADDRESS
 124
      0953
            4F
                             MOV C.A
            CD 71 09
                             CALL DBLSUB
 125
      0954
                             SHLD OCCUR
            22 F9 0F
 126
      0957
 127
      095A
            79
                             MOV A.C
                                               GET BLOCKSIZE
                             RLC
 .28
      0958
                                              TIMES 2 FOR CARDS X 32
            87
 29
      095C
            D2 60 09
                             JNC $+4
                                              BUMP MSB ONLY IF ACC
                                                 OVERFLOWED (IE CARDS > 8)
      095F
            04
                             INR B
  30
  17
      0960
            4F
                             MOV C.A
                                              SAVE BLOCKS IZE (LSB)
            CD 71 09
                             CALL DBLSUB
                                              FIND BASE OF BLOCK
      0961
 2
 173
      0964
            22 FB 0F
                             SHLD TIMEON
                                              SAVE ADDRESS
                             CALL DBLSUB
                                              LAST BLOCK
      0967
            CD 71 09
  34
                                              SAVE IT
                             SHLD TOTTIM
 135
      096A
            22 F7 OF
                             CALL HSTCLR+3
                                               ZERO ALL NEW HISTOGRAMS
 136
      096D
            CD 78 09
                                              WITH MEMORY CONFIGURED PER MAP
            C9
                             RET
 137
      0970
                             139
 140
                      *
                        DBLSUB HL = HL - BC
 141
                           REGISTERS AFFECTED: A, H, L
 142
 143
                      DBLSUB MOY A.L
      0971
            70
                                              GET LSB
 144
 145
           91
                             SUB C
                                              SUBTRACT LSB
      0972
      0973
            6F
                             MOV LA
                                              SAVE IT
 146
                             MOY A.H
      0974
           70
                                              GET MSB
 147
      0975
           98
                             SBB B
                                               INCLUDE BORROW FROM LSB
 148
           67
                             MOV H.A
                                              SAVE IT
 149
      0976
 150
      0977
                             RET
                      152
 153
 154
                      * HSTCLR ZEROES ALL HISTOGRAM ENTRIES. CALLED BY
                           HSTMEM (INITIALIZATION) OR ON COMMAND.
 155
                              REGISTERS AFFECTED: A. B. C. H. L.
 156
 157
                              MEMORY AFFECTED: ALL HISTOGRAM STORAGE
 158
            21 F7 0F
                      HSTCLR LXI H. TOTTIM
                                              LOWEST ADDRESS IN HISTOGRAM
 159
      0978
                                              GET NUMBER OF CARDS INSTALLED
      097B
            3A FF OF
                             LDA NCARDS
 160
      097E
            47
                             MOY B.A
                                              MAKE IT A COUNTER
 161
                             XRA A
                                              CLEAR ACC
            AF
      097F
 162
 163
      0980
            ØE 52
                      CLRH1
                             MVI C.82
                                              NUMBER OF BYTES OF HIST/CARD
                             A.M VOM
                                              ZERO MEMORY LOCATION
      0982
            77
 164
 165
      0983
            23
                             INX H
                                               BUMP POINTER UP
      0984
            PD
                             DCR C
                                                 AND BYTE COUNTER DOWN
 166
                             JNZ CLRH1+2
 167
      0985
            C2 82 09
                                              SMALL LOOP
      0988
            05
                             DCR B
                                              BUMP CARD COUNTER
 158
                             JNZ CLRH1
 169
      0989
            C2 80 09
                                              DO ALL CARDS
 170
      098C
            C9
                             RET
```

The state of the state of the state of

AFCS	8080	ASSE	MBL	ER	CES	SYSTEM SOFTWARE	00:40 322/78 PAGE	6
LINE	LOC	B1	82	83		SOURCE LINE		
223					*		MODIFY AND STORE NEW STATUS	
224	098F	C5			UPSTOR	PUSH B	SAVE COUNTERS	
225	0900	18				LDAX D	GET STATUS WORD	
226	09C1	4F				MOV C.A	SAVE STATUS WORD	
227	09C2	A4				ANA H	AND IN XRA'D BYTE	
228	09C3	A5				ANA L	AND IN MASK	
229	09C4	C2	D2	09		JNZ UPDRST	BIT CHANGE WAS A RESET	
230					*		OTHERWISE IT WAS SET	
231	Ø9C7	79			UPDSET	MOV A.C	COPY OF STATUS	
232	Ø9C8	85				ORA L	OR IN MASK BIT	
233	<b>09C9</b>	12				STAX D	RETURN UPDATED BYTE TO TABLE	
234	09CA		01			MVI A.1	SET CHANGE CODE TO 1	
235	Ø9CC			0F		STA TYPCHG	SAVE CODE	
236	09CF	C3	DA	09		JMP HSTGRM	UPDATE HISTOGRAM DATA	
237	Ø9D2				UPDRST	MOV A.L	GET MASK	
238	09D3	2F				CMA	COMPLEMENT IT	
239	09D4	A1				ANA C	AND IN RESET BIT	
240						STAX D	RETURN UPDATED BYTE TO TABLE	
241	Ø9D6	AF				XRA A	CLEAR ACC	
242	09D7	32	F5	ØF		STA TYPCHG	SAVE TYPE OF CHANGE	
244						totokolokolokolololololol	akkkelelelelelelelelelelelelelelelelekel	*
245					*			
246								
							S NEEDED TO THE HISTOGRAM	
247					*	WHEN AN ALARM CH	ANGES STATE BY USING HSTSET	
247 248					*	WHEN AN ALARM CHOOR HSTRST DEPEND		D
247 248 249					* *	WHEN AN ALARM CH	ANGES STATE BY USING HSTSET	D
247 248 249 250					* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF.	IANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE	D
247 248 249 250 251	<b>09DA</b>				* *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF.	ANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE RECOVER A COPY	D
247 248 249 250 251 252	Ø9D8	C5			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B	ANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE RECOVER A COPY OF COUNTERS	D
247 248 249 250 251 252 253	09DB	C5			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C	ANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE  RECOVER A COPY OF COUNTERS ROTATE WORD CNT	D
247 248 249 250 251 252 253 254	09DB 09DC 09DD	79 07			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC	RANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE  RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE	D
247 248 249 250 251 252 253 254 255	09DE	79 07 07			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC RLC	RANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE  RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT	D
247 248 249 250 251 252 253 254 255 256	09DB 09DD 09DE 09DE	C5 79 07 07			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC RLC RLC	RANGES STATE BY USING HSTSET ING ON WHETHER THE ALARM TURNE  RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS	D
247 248 249 250 251 252 253 254 255 256 257	09DB 09DC 09DD 09DE 09DF 09E	79 07 07 07 08			* * * *	WHEN AN ALARM CHOR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC RLC RLC RLC ORA B	RECOVER A COPY OF COUNTERS ROTATE WORD CHT ROTATE LEFT THREE BITS OR IN BIT CHTR	D
247 248 249 250 251 252 253 254 255 256 257 258	09DB 09DD 09DE 09DE	79 07 07 07 08			* * * *	WHEN AN ALARM CH OR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC RLC RLC	RECOVER A COPY OF COUNTERS ROTATE WORD CHT ROTATE LEFT THREE BITS OR IN BIT CHTR ACC NOW HAS RELATIVE ADDRESS	D
247 248 249 250 251 252 253 254 255 256 257 258 259	09DB 09DC 09DD 09DE 09DF 09E	79 07 07 07 08			* * * *	WHEN AN ALARM CHOR HSTRST DEPEND ON OR OFF. POP B PUSH B MOV A.C RLC RLC RLC RLC ORA B	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY)	D
247 248 249 250 251 252 253 254 255 256 257 258 259 260	09DB 09DC 09DD 09DE 09DF 09E0	C5 79 07 07 07 80			* * * *	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC RLC RLC RLC RL	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE	D
247 248 249 250 251 252 253 254 255 256 257 258 259 260 261	09DB 09DD 09DB 09DF 09E0 09E1	C5 79 07 07 07 80 07			* * * *	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC RLC RLC RLC RL	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO	D
247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262	09DB 09DD 09DB 09DF 09E0 09E1	79 97 97 97 97 97 97 97 5F	99	95	* * * *	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC RLC MOV E.A MVI D.00	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR	D
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263	09DB 09DD 09DE 09DF 09E1 09E1	79 97 97 97 97 97 97 16 16 21	00 FB	ØF	* * * *	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC DRA B RLC  MOV E.A MVI D.000 LXI H.TIMEON	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE	D
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263 264	09DB 09DD 09DE 09DF 09E1 09E1	79 97 97 97 97 97 97 16 16 21		<b>0</b> F	* * * HSTGRM	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC RLC MOV E.A MVI D.00	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE	D
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263 264 265	09DB 09DD 09DB 09DB 09E1 09E1 09E3 09E3	C5 79 07 07 07 80 07 5F 16 21 19	FB		* * * *	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC RLC RLC RLC DRA B RLC  MOV E.A MVI D.000 LXI H.TIMEON DAD D	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE ADDRESS INTO TABLE	D
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263 264 265	09DB 09DD 09DB 09DB 09E1 09E2 09E3 09E8	79 97 97 97 97 97 97 16 16 21 19			* * * HSTGRM	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC ORA B RLC  MOV E.A MVI D.00 LXI H.TIMEON DAD D  LDA TYPCHG	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE ADDRESS INTO TABLE GET TYPE OF CHANGE	D
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263 264 265 266	09DB 09DD 09DB 09DB 09E1 09E2 09E3 09E5 09E8	79 97 97 97 97 97 97 16 16 21 19	FB F5	ØF	* * * HSTGRM	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC ORA B RLC  MOV E.A MVI D.00 LXI H.TIMEON DAD D  LDA TYPCHG ANA A	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE ADDRESS INTO TABLE GET TYPE OF CHANGE SET FLAGS	D
247 248 249 250 251 252 253 254 255 256 257 268 261 262 263 264 265 266 267 268	09DB 09DD 09DB 09DB 09E1 09E2 09E3 09E8	79 97 97 97 97 97 97 16 16 21 19	FB	ØF	* * * HSTGRM	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC ORA B RLC  MOV E.A MVI D.00 LXI H.TIMEON DAD D  LDA TYPCHG	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE ADDRESS INTO TABLE GET TYPE OF CHANGE SET FLAGS GO TO APPROPRIATE SECTION	
247 248 249 250 251 252 253 254 255 256 257 258 269 261 262 263 264 265 266	09DB 09DD 09DB 09DB 09E1 09E2 09E3 09E5 09E8	79 97 97 97 97 97 97 16 16 21 19	FB F5	ØF	* * * HSTGRM	WHEN AN ALARM CHOR HSTRST DEPENDON OR OFF.  POP B PUSH B MOV A.C RLC RLC RLC ORA B RLC  MOV E.A MVI D.00 LXI H.TIMEON DAD D  LDA TYPCHG ANA A	RECOVER A COPY OF COUNTERS ROTATE WORD CNT ROTATE LEFT THREE BITS OR IN BIT CNTR ACC NOW HAS RELATIVE ADDRESS INTO TWO BYTE (PER ENTRY) TABLE MOVE ACC TO TO REG PAIR LOAD TABLE BASE HL NOW HAS ABSOLUTE ADDRESS INTO TABLE GET TYPE OF CHANGE SET FLAGS	

AFCS	8888	ASSE	1BL	ER	CES SYSTEM SOFTWARE	00:40 322/78 PAGE 7
LINE	LOC	81	82	B3	SOURCE LINE	
272						
273					*	
274					* HSTSET PROCESSES CHAN	NGES TO THE HISTOGRAM WHEN THE
275					* ALARM IS SET (TI	URNED ON).
276					* THE ACTION REQUI	IRED IS:
277					* 1) THE TIMEON	WORD FOR THAT ALARM IS SET
278					* TO THE CURP	RENT TIME
279						NCE COUNT FOR THAT ALARM IS
280					* INCREMENTED	D.
281					*	
282	09F0				HSTSET PUSH D	SAVE BYTES
283	09F1	11	FE	09	LXI D.TIME	POITER TO TIME STORED
284					***	BY RD8253 ROUTINE
285	09F4		26	ØC.	CALL RD8253	GET CURRENT TIME
286	09F7				LDAX D	GET LSB OF TIME
287	09F8				MOV M.A	STORE IN TIME-ON TABLE
288	09F9	-			INX D	GET AND
289	09FA				INX H	STORE
290	09FB				LDAX D	MSB OF
291	Ø9FC	77			MOV M.A	TIME
292	09FD	1000000			POP D	RECOVER BYTES
293	Ø9FE	78			MOV A.E	RELATIVE ADDRESS IN
294	09FF	10000000			RRC	2 BYTE TABLE SHIFTED TO
295	0A00			-	MOV E.A	USE IN ONE BYTE TABLE
296	0A01		F9	91	LXI H.OCCUR	BASE OF OCCURANCE TABLE GENERATE ABSOLUTE ADDRESS
297 298	0A04 0A05	-			INR M	INCREMENT ENTRY IN TABLE
299	0A06	118 03			POP B	RECOVER
300	0A07	150,700			POP D	SCANNING
301	0A08				POP H	STATUS
302	ØAØ9		98	09	JMP CHECK	END OF PROCESSING FOR
303	ONOS	-	-	0.5	*	THIS CHANGE OF ALARM STATE
305						
306					*	
307						CHANGES TO THE HISTOGRAM WHEN
308					* THE ALARM RESETS	
309					* WHEN THE ALARM RE	
310					* 1) THE CURRENT	TIME IS SUBTRACTED FROM TIMEON
311					* (SINCE IT IS	S A DOWN COUNTER) AND THE
312					* DIFFERENCE	IS ADDED TO TOTTIM.
313					* 2) TIMEON IS CL	LEARED.
314					*	
315	GAGC		25	ØC.	HSTRST CALL RD8253	LOAD CURRENT TIME
716	ØAØF	D5			PUSH D	SAVE RELATIVE POINTER
517	0A10	100	FE	09	LXI D.TIME	SET POINTER TO TIME
318	ØA13				LDAX D	GET LSB OF TIME
319	0A14				MOV C.A	SAVE IT
320	ØA15				MOV A.M	GET LSB OF TIMEON
321	ØA16	91			SUB C	FIND DIFFERENCE

AFCS	8080	ASSE	MBL	ER	CES	SYSTEM S	SOFTWARE	00:40 322/78	PAGE	8
LINE	LOC	81	82	83		SOURCE	LINE			
322	ØA17	4F				MOV C.A		SAVE DIFFERENCE		
323	0A16	13				INX D		POINT TO MSB OF TIME		
324	ØA15	23				INX H		POINT TO MSB OF TIME	ON	
325	8A16					LDAX D		GET MSB OF TIME		
326	ØAIE	47				MOV B.A		SAVE IT		
327	0A10					MOV A.M		GET MSB OF TIME ON		
328	ØAII					SBB B		FIND DIFFERENCE INCL	UD ING	
329					*			BORROW FROM FIRST	SUBTRACT	
330	ØAIE	47				MOV B.A		SAVE DIFF		
331					*			B.C NOW HAS TWO BYTE	DIFFEREN	C
332					*			INDICATING TIME A	LARM WAS	0
333	ØA 1F	D1				POP D		RECOVER RELATIVE ADD	RESS	
334	0A20	AF				XRA A		CLEAR ACC		
335	0A21	77				MOV MA		CLEAR MSB OF TIMEON		
336	0A22	2 B				DCX H		CLEAR		
337	ØA23	77				MOV M.A		LSB		
338	0A24	1 21	F7	0F		LXI H.TO	MITTE	POINTR TO TOTAL-TIME	-ON	
339					*			HISTOGRAM		
340	ØA27					DAD D		ADD RELATIVE ADDRESS		
341	ØA28					MOV A.M		GET LSB FROM HISTOGR	AM	
342	ØA29					ADD C		ADD NEW DATA IN		
343	ØAZA					MOV M.A		SAVE UPDATED TIME		
344						INX H		POINT TO MSB OF HIST		
345	0A20					MOV A.M		GET MSB FROM HISTOGR	AM	
346	0A21					ADC B		ADD NEW DATA		
347	ØA2E					MOY M.A		SAVE MSB		
348	ØAZF					POP B		RECOVER		
349	ØA36	2 Salary				POP D		SCANNING		
350	ØA3:					POP H	-	STATUS		
351	0A32	2 63	98	09		JMP CHEC	-K	DONE PROCESSING TIME	NG	
352					*	ula la l		ALARM kalalalalalalalalalalalalalalalalalalal	aladalalalalalalalala	
354					*	****		*****	****	-
355 356						DD 15 THE	LISTOCH	AM DUMP DRIVER. A NUM	DED DIII 1 E	n
357								CE SPECIFIES THE HIST		v
358								R > NUMBER OF ALARMS		
359							HISTOGRA		IIIO INICCED	
360					*		ERS AFFFE			
361					*			ED: HSTDMP		
362					*					
363	0A35	5 CD	68	ØC	HSDMDR	CALL RD	1BHX	GET ALARM NUMBER		
364	0A36	4F				MOV C.A		SAVE IT		
365	ØA39		FF	0F		LDA NCAF	RDS	GET NUMBER OF CARDS		
366	0A30	07				RLC		MULTIPLY BY 16		
367	0A31	07				RLC		TO GET NUMBER		
368	ØA3E					RLC		OF ALARMS		
369	ØA3F					RLC		INSTALLED		
370	ØA46					DCR A		ADJUST TO START COUN	the second of the second of the second	
371	0A4					CMP C		CHECK IF INPUT IN VA		
372	ØA42	. DA	49	ØA		JC HSDM	4L	OUT OF RANGE, DUMP A	LL	

AFCS	8080	ASSEI	<b>18</b> L6	ER	CES	SYSTEM SOFTWARE	00:40 322/78 PAGE 9
LINE	LOC	81	82	83		SOURCE LINE	
373 374			54	ØA		CALL HSTDMP	OTHERWISE, DUMP ONE
375					HSDMAL	MOV C.A	SAVE NUMBER OF ALARMS
376	ØA4A	C5				PUSH B	SAVE REG
377	0A48	CD	54	ØA			DUMP THAT ONE
378	ØA4E						RECOVER ALARM NUMBER
379							BUMP COUNTER
380			48	ØA		JP HSDMAL+1	LOOP UNTIL ALL ALARMS DONE
381	ØA53	C9				RET	
382							okokokokokokokokokokokokokokokokokokok
383					*		W 2070 FOR THE ALABA SECTION
384							M DATA FOR THE ALARM DESIGNATED
385						THE C REGISTER.	FD. 011
386					*	REGISTER AFFECT	LED: WRIBI3, WRIBI2, DIVIDE
387 388					*	SUBRUUTINES CHE	LED: WRIBIS, WRIBIZ, DIVIDE
389	9054	06	99			MVI B.0	CLEAR B BEFORE PUSH
390	0A56		00		1131211	PUSH B	SAVE ALARM NUMBER IN C
391	ØA57		CA	ØC		CALL WRIBIS	OUTPUT ALARM NUMBER
392	0A5A		-	-		POP 8	RECOVER
393						PUSH B	ALARM NUMBER
394						MOV A.C	GET ALARM NUMBER
395		E6	07			ANI #00000111	MASK OFF 3 LSB
396	ØA5F	47				MOV B.A	SAVE BIT NUMBER
397	0A68	79				MOV A.C	GET ALARM NUMBER
398	ØA61	E6	78			ANI #01111000	
399						RRC	RIGHT
400						RRC	JUSTIFY
401						RRC	
402							WORD NUMBER IN LSB
403	10-10-10-10-10-10-10-10-10-10-10-10-10-1	-	00			MVI D.0	CLEAR MSB
404			FD	0F		LHLD STATUS	BASE OF STATUS TABLE
405							GENERATE POINTER INTO TABLE
406						MOV A.M DCR B	GET STATUS WORD BUMP BIT COUNTER
408						RRC	ROTATE STATUS BIT INTO CARRY
409		F2	SE	ao.			LOOP UNTIL COUNTER UNDERFLOWS
410	Carrie Day of Control	- Contract	30	OH		MVI A. "0"	Ø = ALARM INACTIVE
411	ØA75		79	MA		JNC \$+4	IF CARRY NOT SET, I.E. ALARM
412				•••		INR A	INACTIVE, LEAVE @ OTHERWISE
413					*		CHANGE TO 1
414	ØA79	CD	EA	ØA		CALL WRITE	OUTPUT CHARACTER
415						POP B	ANOTHER COPY
416						PUSH B	OF ALARM NUMBER
117	0A7E	2A	F9	ØF		LHLD OCCUR	BASE OF OCCURANCE TABLE
418						DAD B	PTR INTO TABLE
419						MOV A.M	GET TABLE ENTRY
420				1			SAVE BC
421			CØ	ØC		CALL WRIBI3	OUTPUT IN 13 FORMAT
422	ØA87	CI				POP B	RECOVER

AFCS	8080	ASSE	<b>1</b> 8L	ER	CES	SYSTEM SOFTWARE	00:40 322/78 PAGE 10
LINE	LOC	81	82	B3		SOURCE LINE	
423	0A80	AF				XRA A	CLEAR CARRY
424	0A89	79				MOV A.C	MULTIPLY ALARM * BY 2
425	ØABA	17				RAL	INSURING LSB RESET
426	0A88					MOV C.A	RESTORE LSB OF OFFSET
427	ØABC		F7	0F		LHLD TOTTIM	BASE OF TOTAL TIME TABLE
428						DAD B	ADD OFSET
429						MOV B.M	GET MSB FROM TABLE
430						INX H	BUMP POINTER
431	0A92	12.77				MOV C.M	GET LSB FROM TABLE
432				-		MVI D.100 CALL DIVIDE	DIVISOR SEPERATE TIME
433			01	עט		MON C'U	GET QUOTIENT
434						PUSH B	SAVE DATA
436			CØ	ac		CALL WRIBI3	OUTPUT TIME DIV 100 IN
437	חכחט	CD	CO	00	*	CHEE WAIDIS	IN 13 FORMAT
438	ØASD	CI				POP B	RECOVER
439						MOV C.B	GET REMAINDER
440	ØA9F	1 1000	CF	ØC		CALL WRIBI2	OUTPUT REMIANDER IN 12 FORMAT
441	ØAA2	CD	E3	ØC		CALL CRLF	SPECIFY END OF RECORD
442	ØAA5	C9				RET	
444							ojejojojojojojojojojojojojojojojojojojo
445					*		
446							RACTERS FROM THE BUS AS A START
447						DDRESS FOR EXECUT	
448					*	SUBROUTINES CAL	TED: A, B, C, H, L
449 450					Ţ.	SUBRUUTTINES CHE	LED. KDIBNA
451	0AA6	CD	73	AC.	EXCUTE	CALL RD2BHX	GET TRANSFER ADDRESS
452	ØAA9			-		PCHL	TRANSFER TO THAT ADDRESS
454	- · · · · ·				statatatatak		
455					*		
456					* PLOA	D LOADS OBJECT CO	DE FROM THE ASSEMBLER
457							A THE INPUT DEVICE.
458					*	REGISTERS AFFEC	
459					*		: DEPENDENT ON ASSEMBLER ORG
460					*	SUBROUTINES CAL	LED: RD18HX, RD28HX
461	2000			00	*	COLL BEAD	CET CHARACTER ARE THE BUC
462 463	ØAAA		19 3A	00	PLOAD	CALL READ	GET CHARACTER OFF THE BUS CHECK FOR COLON INDICATING
464	ОННО	, LE	JH		*	Cr.	BEGINNING OF RECORD
465	DAAF	C2	AA	no.	•	JNZ PLOAD	LOOP UNTIL BEGIN RECORD
466			68			CALL RDIBHX	GET RECORD LENGTH
467	ØA85					MOV E.A	SAVE BYTE COUNTER
458						MOV D.A	START ON CHECKSUM
469	ØAB7	CD	73	ØC		CALL RD2BHX	GET LOAD ADDRESS
470	ØAEA	82				ADD D	ADD CHECKSUM TO LO BYTE
471	ØABB					ADD H	ADD HI BYTE
472						MOV D.A	SAVE IT
473			68	ØC		CALL RDIBHX	GET RECORD TYPE
474	ØACØ	82				ADD D	ONLY USE FOR CHECKSUM

```
AFCS 8000 ASSEMBLER
                        CES SYSTEM SOFTWARE
                                                 00:40 322/78
                                                                      PAGE 11
LINE LOC
            B1 B2 B3
                              SOURCE LINE
                             MOV D.A
                                                 OTHERWISE IGNORED
 475
      ØAC1
           CD 68 0C PLLOOP CALL RDIBHX
                                              GET PROGRAM WORD
 476
      ØAC2
      ØAC5
                             MOV MA
                                              STORE IT
 477
           77
                                              UPDATE
 478
      ØAC6
            82
                             ADD D
      ØAC7
                             MOV D.A
                                                CHECKSUM
 479
            57
                                              BUMP POINTER UP
 480
      ØACB
            23
                             INX H
      ØAC9
                             DCR E
                                                AND BYTE CHITR DOWN
 481
           1 D
            C2 C2 0A
                             JNZ PLLOOP
                                              LOOP UNTIL RECORD READ
 482
      ØACA
                                              READ CHECKSUM FROM RECORD
      ØACD
           CD 68 0C
                             CALL RDIBHX
 483
 484
      0AD0 82
                             ADD D
                                              FINAL ADD - SHOULD BE ZERO
 485
     ØAD1
                             RZ
                                              DONE IF CHECKSUM OK
           CB
 486
      ØAD2
            3E 01
                             MVI A.01
                                              SET ERROR CODE
 487
                             CALL ERROR
                                              OUTPUT MESSAGE
      ØAD4 C9
                             RET
                                              VERIFIED 22 AUG 78
 488
                      GPIA
                             EQU 'BFC8
                                              HARDWIRED ADDRESS
 489
 490
                                                 OF GPIA REGISTER Ø
                      492
 493
 494
                            GPIA TALKER
                                                   ROUTINES
 495
 496
                      498
                      *GPTALK WILL CONFIGURE THE GPIA TO BE A TLAKER
 499
                             REGISTERS AFFECTED: A
 500
 501
                      GPTALK LXI H.GPIA+3
            21 CB BF
                                              AUX COMMAND REGISTER
 502
      ØAD5
           36 80
                             MVI M. '80
                                              STROBE RESET BIT
 503
      PITAR
                             MVI M. '00
      ØADA
            36 00
                                                 TO POWER ON CONDITION
 504
      ØADC
                             INX H
                                              ADDRESS SWITCH REGISTER
 505
            23
                                              READ SWITCHES
 506
      ØADD
            7E
                             MOV A.M
                             MOV M.A
                                              WRITE TO ADDRESS SWITCH REGIST
      ØADE
 507
            77
      ØADF
            3E 00
                             MYI A.0
                                              CLEAR INTERRUPT MASK
 508
 509
      ØAE1
           32 CB BF
                             STA GPIA
                                                 IN MASK REGISTER
                             MVI A. '40
                                              TALKER ONLY ADDRESS MODE
 510
      ØAE4
            3E 40
           32 CA BF
                             STA GPIA+2
                                                 IN ADDRESS MODE REGISTER
 511
      ØAE6
 512
      ØAE9
            C9
                             RET
 514
                          <u>ialialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidialaidiala</u>
 515
                      *GTTRAN TRANSMITS THE CHARACTER IN THE ACC VIA THE
 516
                          GPIB. NOT USED FOR LAST CHAR OF STRING.
 517
                      *
                             REGISTERS AFFECTED: A
 518
                      *
 519
                      GTTRAN PUSH PSW
                                              SAVE DATA TO BE OUTPUT
 520
     DAEA
           F5
           3A CB BF
                             LDA GPIA
                                              READ INTERRUPT STATUS REGISTER
 521
     DAEB
                             ANI '40
                                              MASK OFF BIT 0 (BO)
 522
     0AEE E6 40
 523
     OAFO
           CA EB ØA
                             JZ GTTRAN+1
                                              CONITNUE LOOP UNTIL BO GOES HI
                             POP PSW
 524
     0AF3
           F1
                                              GET DATA
 525 0AF4
           32 CF BF
                             STA GPIA+7
                                                AND WRITE TO DATA OUT REG
526
     0AF7 C9
                             RET
```

1000年中华中国中国

```
AFCS CORE ASSEMBLER
                       CES SYSTEM SOFTWARE
                                                                 PAGE 12
                                              00:40 322/78
LINE LOC
           B1 B2 B3
                           SOURCE LINE
528
                    529
 530
                    *GTLAST TRANSMITS A CHARACTER FROM THE A REG. USED
                         ONLY FOR THE LAST CHARACTER OF A STRING.
 531
 532
                           REGISTERS AFFECTED: A
533
 534
     ØAF8
          F5
                    GTLAST PUSH PSW
                                          SAVE DATA
     ØAF9
          3E 20
                           MVI A. 20
                                          SET EOI BIT
535
536
     ØAFB
          32 CB BF
                           STA GPIA+3
                                           STORE IN AUX COMMAND
                                             REG PRIOR TO LAST CHAR
537
                           POP PSW
538
     DAFE
           F1
                                           GET CHARACTER
          32 CF BF
 539
     ØAFF
                           STA GPIA+7
                                          STORE IN DATA OUT REG
     0802 C9
 540
                           RET
542
                    543
                    *
544
                           GPIA
                                    LISTENER
                                                    ROUTINES
 545
546
                       547
                    *GPLIST CONFIGURES THE GPIA TO BE A LISTENER
 548
549
                           REGISTERS AFFECTED: A
550
     0B03 21 CB 8F
 551
                    GPLIST LXI H, GP IA+3
                                          AUX COMMAND REGISTER
          36 80
                           MYI M. '80
                                          STROBE RESET BIT
 552
     0B06
                           MYI M. '00
          36 00
 553
     0808
 554
     ØBØA
          23
                           INX H
                                          ADDRESS SWITCH REGISTER
 555
     0808
           7E
                           MOV A.M
                                          READ ADDRESS SWITCHES
                           MOV M.A
                                          WRITE TO ADDRESS REGISTER
 556
     ØBØC
           77
          3E 81
 557
     ØBØD
                           MYI A. '81
                                           INTERRUPT ON BYTE RECEIVED
558
     080F
           32 C8 BF
                           STA GPIA
                                             IN MASK REGISTER
                           MVI A. 20
559
     0812
           3E 20
                                          LISTENER ONLY ADDRESS MODE
                                             IN ADDRESS MODE REG
     0814
          32 CA BF
                           STA GPIA+2
560
 561
     ØB17
           FB
                           EI
                                           GPIA WILL INTERRUPT
                                             WHEN READY
562
563
     ØB18
          C9
                           RET
                    565
566
                    *GLREC RECEIVES ON CHARACTER FROM THE GPIB AND

* STORES IT IN THE ACCUMULATOR. RETURNING
567
 568
                          WITH THE CARRY SET INDICATES EOI WAS RECIEVED
 569
 570
                    *
                          AND THUS IS THE END OF THE INPUT STRING.
571
                            REGISTERS AFFECTED: A
572
573
     ØB19 C5
                    GLREC
                          PUSH B
                                          MAKE REGISTER AVAILABLE
574
     081A
          06 40
                           MVI B. 40
                                          SET A DELAY TIME
575
     ØB1C
                           DCR B
                                          BUMP COUNTER
          05
          C2 1C 0B
576
     0B1D
                           JNZ $-1
                                          LOOP ON DELAY
                           POP B
                                          DONE WITH DELAY
577
     0820
          CI
           3A CB BF
                    GLSTAT LDA GPIA
578
     ØB21
                                          READ INTERRUPT STATUS REG
```

```
AFCS 8080 ASSEMBLER
                       CES SYSTEM SOFTWARE
                                               00:40 322/78
                                                                  PAGE 13
LINE LOC
           B1 B2 B3
                            SOURCE LINE
579
     0824
           E6 01
                           ANI 01
                                           MASK OFF BIT 0 (BI)
580
     0826
           CA 19 0B
                           JZ GLREC
                                           CONTINUE CHECKING UNTIL
581
                                             BI GOES HIGH
                           ANI '02
                                           MASK OFF BIT 1 (EOI)
     ØB29
           E6 02
582
583
     0B2B
           37
                           STC
                                           SET CARRY FLAG
           CA 30 0B
                           JZ GLSKIP
                                           EOI NOT SENT, LEAVE CARRY SET
584
     ØB2C
                                           RESET CARRY WHEN EOI IS SENT
585
     ØB2F
           3F
                           CMC
                    GLSKIP LDA GPIA+7
           3A CF BF
                                           GET DATA IN
586
     0830
587
     ØB33
           FE ØA
                           CPI '0A
                                           LINE FEED ALSO SIGNALS
           CØ
                                              END OF RECORD
588
     ØB35
                           RNZ
           37
                           STC
589
     ØB36
                                                 SO SET CARRY
590
     ØB37
           C9
                           RET
591
                    592
593
                       TELETYPE TERMINAL DRIVERS. USED AS THE TERMINAL
594
                       DEVICE IN THE LOCAL MODE.
595
596
                    CTLPRT EQU 'C
                                           UART CONTROL PORT
597
                    BDRTPT EQU 'B
598
                                           BAUD RATE GENERATOR PORT
                    CHSLPT EQU '9
599
                                           CHANNEL SELECT PORT
                    USTAT EQU '8
                                           UART STATUS PORT
600
                    DATAIN EQU '9
 601
                                           DATA INPUT BUFFER
602
                    DATOUT EQU 'A
                                           DATA OUTPUT BUFFER
604
                    605
                    * ASNIO ASIGNS THE OUTPUT DEVICE ON THE SERIAL IO
606
                         CARD BY SELECTING THE PROPER DATA FORMAT. BAUD
607
608
                         RATE AND CHANNEL. ON ENTRY, HL MUST POINT TO THE
                         APPROPRIATE TABLE ENTRY.
609
610
                            REGISTERS AFFECTED: A, H, L
611
612
                    ASNIO
                                          GET UART COMMAND
     ØB38
                           MOV A.M
613
                           OUT CTLPRT
614
     ØB39
           D3 0C
615
     ØB3B
           23
                           INX H
     ØB3C
           7E
                           MOV A.M
                                          GET BAUD RATE
616
617
     083D
           D3 0B
                           OUT BDRTPT
618
                           INX H
     0B3F
           23
619
     0840
                           MOY A.M
                                          GET CHANNEL NUMBER
           7E
620
     0B41
           D3 09
                           OUT CHSLPT
621
     ØB43
           C9
                           RET
                                           UART COMMAND
622
     0B44
           18
                    TTY
                           DB #11000
                           DB '03
                                           BAUD RATE
623
     0845
           93
                           DB 2
     ØB46
           02
                                           CHANNEL SELECT
625
                    CASETT DB 0
     PR47
           99
026
     0848
           00
                           DB 0
     ØB49
           99
                           DB Ø
627
```

```
AFCS 8080 ASSEMBLER
                      CES SYSTEM SOFTWARE
                                             00:40 322/78
                                                               PAGE 14
LINE LOC
          B1 B2 B3
                           SOURCE LINE
629
                   630
631
                    * READS INPUTS DATA FROM THE SERIAL IO CARD RETURNING
632
                        WITH THE INPUT CHARACTER IN THE ACC.
                          REGISTERS AFFECTED: A
633
                   *
634
635
     084A DB 08
                   READS IN USTAT
                                        ERROR MASK
636
     0B4C
          E6 ØE
                          ANI #1110
637
     084E
          CA 56 0B
                          JZ RNOERR
638
     0851
          3E 02
                          MVI A.2
                                        SET ERROR CODE
     ØB53
         CD DE 0B
                          CALL ERROR
639
640
     0856
          DB 08
                   RNOERR IN USTAT
                                        GET STATUS
                          ANI '10
     0858
641
          E6 10
                                        MASK DATA AVAILABLE
642
     083A
          CA 4A 0B
                          JZ READS
                                        LOOP UNTIL UART RECIEVES
     085D
          DB 09
                          IN DATAIN
                                        GET DATA
643
 644
     085F
          C9
                          RET
646
                    647
                    * WRITES OUPTUS A CHARACTER TO THE SERIAL IO CARD
548
649
                        FROM THE ACC.
                          REGISTERS AFFECTED: NONE
650
651
                   WRITES PUSH PSW
     0860
         F5
                                        SAVE OUTPUT DATA
652
653
     0861 DB 00
                          IN USTAT
         E6 01
                          ANI 1
                                        MASK TBMT
654
     0863
          CA 61 0B
                          JZ WRITES+1
                                        LOOP UNTIL BUFFER EMPTY
655
     0865
                          POP PSW
656
     ØB68
          F1
                                        RECOVER DATA
     0869 D3 0A
                          OUT DATOUT
657
                                        FILL BUFFER
 658
     0868 C9
                          RET
                    660
661
                    * DMPASC DUMPS AN ASCII STRING OF LENGTH (HL) STARTING
662
663
                          REGISTERS AFFECTED: A.....E. H. L
664
665
                           SUBROUTINES CALLED: WRITE
666
                   DMPASC MOY E.M
667
     085C
         5E
                                         GET LENGTH
668, 086D 23
                          INX H
                                         POINT TO CHARACTER
                                         BUMP CHARACATER COUNTER
     086E
          1 D
                          DCR E
669
670 086F
          FB
                          RM
                                         DONE WHEN CHTR UNDERFLOWS
671 0870
                          MOY A.M
                                         GET CHARACTER
          7E
         CD EA ØA
672 0871
                          CALL WRITE
                                         OUTPUT IT
673
     0874 C3 6D 0B
                          JMP DMPASC+1
```

"以为是要是一种"的

```
AFCS 8080 ASSEMBLER
                        CES SYSTEM SOFTWARE
                                                 00:40 322/78
                                                                     PAGE 16
                             SOURCE LINE
           B1 B2 B3
LINE LOC
                            CALL WRIBHX
                                             DISPLAY IT
726
     ØBB3
          CD A4 0C
727
     0886
           CD 19 ØB
                             CALL READ
                                             GET COMMAND
                            CPI " "
                                             SPACE ?
 728
     ØBB9
           FE 20
 729
     0888
           CA DB ØB
                             JZ MEMAC1
                             CPI "X"
                                             BACKSPACE COMMAND ?
 730
     ØBBE
           FE 58
                             JNZ $+6
     0800
           C2 C6 ØB
731
     ØBC3
           2B
                             DCX H
                                             BACKSPACE
732
           AF
                             XRA A
                                             CLEAR CARRY
733
     0BC4
     08C5
           C9
                             RET
                                              WITH CARRY RESET
734
           FE 5A
                            CPI "Z"
                                             EXIT COMMAND
     08C6
 735
           CZ CD ØB
                             JNZ $+5
 736
     ØBC8
                                             SET END FLAG (CARRY)
     ØBCB
           37
                             STC
 737
           C9
                             RET
                                              WITH CARRY SET
 738
     ØBCC
                                             ALTERNATE ENTRY POINT
           CD 68 0C
                             CALL RDIBHX+3
 739
     OBCD
                                                SINCE CHARACTER ALREADY REA
 740
                                              RETURNS WITH CARRY IF BAD DATA
           D2 DA 0B
                             JNC MEMAC1-1
 741
     0800
 742
     0BD3
           3E 3F
                             MVI A. "?"
                                             UNRECOGNIZED COMMAND
           CD EA ØA
 743
     ØBD5
                             CALL WRITE
                             XRA A
                                             CLEAR CARRY
     08D8
           AF
 744
 745
     08D9
           C9
                             RET
                                              STORE NEW DATA
 746
     ØBDA
           77
                             MOV M.A
                                             NEXT LOCATION
                     MEMACI INX H
747
     ØBDB
           23
748
     ØBDC
           AF
                            XRA A
                                             CLEAR CARRY
749
     ØBDD
           C9
                             RET
751
                      752
                       ERROR PRINTS THE ERROR MESSAGE:
 753
 754
                                    "ERROR XX NEAR LOC XXXX"
                              REGISTERS AFFECTED: ALL
 755
                              SUBROUTINES CALLED: DMPASC, WRIBI3, WR2BHX
 756
 757
     OBDE 21 F8 OB ERROR LXI H. ERRMSG
                                             BASE OF ERROR MESSAGE
 758
                                              SAVE ERROR CODE
 759
     08E 1
           47
                             MOV B.A
     OBE2
           CD E3 OC
                             CALL CRLF
                                              NEXT LINE
 769
                             CALL DMPASC
                                             OUTPUT "ERROR "
 761
      ØBE5
            CD 6C 0B
                             MOY A.B
                                             GET ERROR CODE
     08E8
 762
           78
 763
     ØBE9
           CD CO OC
                             CALL WRIBI3
                                              WRITE CODE
           CD 6C 0B
                             CALL DMPASC
                                             CUTPUT " NEAR LOC "
 764
     ØBEC
                             POP H
                                              GET A COPY OF RETURN ADDRESS
 765
     ØBEF
           E1
 766
     08F0
           E5
                             PUSH H
                             CALL WRZBHX
                                             OUTPUT LOC THAT CALLED ERROR
     ØBF1 CD B7 ØC
 767
 768 69F4
          CD E3 ØC
                             CALL CRLF
                                             NEXT LINE
 759 ØBF7
           C9
                             RET
 779
     06F8
           06
                      ERRMSG DB 6
                                             MESSAGE LENGTH
 771
          45 52
                                             MESSAGE CHARACTERS
                             DW "ER"
     08F9
          52 4F
                             DW "RO"
     OBFB
            52 20
                             DW "R "
 773
     OBFD
                            DB 10
            ØA
                                             LENGTH
 774
     ØBFF
            20 4E
                             DW " N"
 775
     0000
            45 41
                             DW "EA"
 776
     0002
```

```
AFCS 8080 ASSEMBLER
                       CES SYSTEM SOFTWARE
                                               00:40 322/78
                                                                  PAGE 17
LINE
    LOC
           B1 B2 B3
                            SOURCE LINE
                           DW "R "
 777
     0004
           52 20
 778
     0006
           4C 4F
                           DW "LO"
                           DW "C "
 779
     0008
          43 20
                    READ
                           EQU GLREC
 760
 781
                    WRITE
                          EQU GTTRAN
                           EQU 'BFC0
                                           HARDWIRED ADDRESS OF COUNTER 0
 782
                    CNTR
 783
                     TIME
                           EQU '09FE
                    CCTLWD EQU CHTR+3
                                           COUNTER CONTROL WORD
 784
                     786
 787
 788
                            8253 TIMER
                                               CONTROL
 789
 790
                     791
                      THE 8253 INTERVAL TIMER CONTROL WORD IS DEFINED AS
 792
                    *
 793
                         BITS 7.6 SELECT WHICH COUNTER THIS CONTROL
                                   WORD IS FOR 00, 01, 10 ARE +0, 1, 2
 794
 795
                                   RESPECTIVELY. 11 IS NOT ALLOWED
                         BITS 5.4
                                   OPERATION MODE: 00 LATCH COUNTER TO
 796
 797
                                   INTERNAL REG; 01 READ/LOAD MSB ONLY
                                   10 R/L LSB ONLY; 11 R/L LSB THEN MSB
 798
                                   CONSECUTIVELY
 799
                         BITS 3.2.1 COUNTER MODE 000 ALLOWS
 800
                                   NORMAL (DOWN) COUNTING. MODE 010
 801
                                   CONFIGURES THE 8253 TO A DIVIDE BY N
 802
                                   COUNTER. (DISCUSSED IN MANFUFACTURER'S
 803
                                   DOCUMENTS)
 804
 805
                         BIT 0
                                   0 SELECTS 16 BIT BINARY.
                                   1 SELECTS 4 DECADES OF BCD
 306
 907
                     808
 810
                     *IN8253 INITIALIZES THE 8253 AS FOLLOWS:
 811
                           CNTR 0. DIVIDE BY 960
 812
                             CLK 0 = 8080 CLK, OUT 0 = 960 HZ
 813
                           CNTR 1, DIVIDE BY 960
CLK 1 = OUT 0 = 960 HZ, OUT 1 = 1 HZ
 814
 815
                           CNTR 2. 16 BIT DOWN COUNTER (CLOCK)
 316
                              CLK 2 - OUT 1 - 1 HZ
 817
                                  REGISTERS AFFECTED: B. C. H. L
 818
 819
                    INB253 LXI H.CCTLWD
                                           PTR TO CONTROL WORD
 620
     OCOA
           21 C3 BF
                           MVI M. '34
                                           CHTR Ø MODE 2
 821
      OCOD
           36 34
                           MVI M. '74
 322
      ØCØF
           36 74
                                           CNTR 1 MODE 2
 23
      ØC11
                           MYI M. '80
                                           CHTR 2 MODE 0
           36 BØ
                                           PTR TO CNTR Ø
 824
      ØC13
           21 CØ BF
                           LXI H, CHTR
                                           SET DIVIDE QUANTITY
      ØC16
           01 CO 03
                           LXI B.960
 325
 826
      ØC19
           71
                           MOY M.C
                                           WRITE LSB
                           MOY M.B
                                              AND MSB TO CHTR 0
 827
      ØC1A
           78
                                           PTR TO CNTR 1
           23
 328
      ØC1B
                           INX H
```

THE REST WHEN THE PARTY OF THE

```
AFCS 8080 ASSEMBLER
                    CES SYSTEM SOFTWARE
                                         00:40 322/78
                                                             PAGE 18
                          SOURCE LINE
LINE LOC
          B1 B2 B3
                                        WRITE LSB
    OCIC
                         MOV M.C
829
         71
830
     ØC1D 70
                         MOV M.B
                                          AND MSB TO CNTR 1
                   831
832
                    RS8253 RESETS COUNTER 2 TO MAX COUNT ('FFFF)
833
834
                   *
                         THIS ALTERNATE ENTRY POINT SHOULD BE USED ONLY
                   *
                         RESET THE REAL TIME CLOCK.
835
836
                               REGISTERS AFFECTED: H. L
837
838
    ØC1E 21 C2 BF
                   RS8253 LXI H, CNTR+2
                                        PTR TO CNTR 2
          36 FF
                                        SET MAX COUNT IN LSB AND
839
     ØC21
                         MVI M, FF
                                        MSB OF CHTR 2
CHTR 2 IS DOWN COUNTING
840
     ØC23
          36 FF
                         MVI M, 'FF
841
     ØC25 C9
                         RET
                                          FROM 'FFFF
842
843
                   844
                   *RD8253 READS THE CURRENT TIME FROM THE COUNTER
845
                         WITH THE RESULTS IN TIME (LSB) AND TIME+1 (MSB)
846
                               REGISTERS AFFECTED: A. H. L
847
                               MEMEORY AFFECTED: TIME, TIME+1
RAR
849
                   RD8253 MVI A. '80
    ØC26
          3E 80
                                        SELECTS COUNTER 2 TO LATCH
850
     ØC28
          32 C3 BF
                         STA CCTLWD
                                        WRITE TO CONTROL WORD
851
                         LXI H, CNTR+2
                                        PNTR TO CNTR 2
852
     ØC2B
          21 C2 BF
                         MOV A.M
853
     ØCZE
                                        READ LSB
          7E
          32 FE 09
                         STA TIME
854
     ØC2F
                                        STORE LSB
                         MOY A.M
855
     ØC32
          7E
                                        READ MSB
          32 FF 09
856
     ØC33
                         STA TIME+1
                                        STORE MSB
857
     ØC36
          C9
                         RET
                                        COUNTER IS STILL COUNTING
859
                   860
861
                       MENIAL
                                   FUNCTION LIBRARY
862
                   863
865
                   866
867
                   * HEX1 CONVERTS ONE ASCII CHARACTER IN THE ACCUMULATOR
                        TO 4 BITS RIGHT JUSTIFIED IN THE ACCUMULATOR
868
                        RETURNING WITH CARRY SET FOR A CHARACTER OUT OF
869
870
                        THE RANGE 0-F.
871
                           REGISTERS AFFECTED: A
872
973
    ØC37
         D6 30
                  HEX1
                         SUI "0"
874
    0C39
         DB
                         RC
                                        FILTER OUT 00-2F
                         ADI "0"-"G"
675
     OC3A
          C6 E9
676
    OC3C
          DB
                         RC
                                        FILTER OUT 47-FF
377
    OC3D
          C6 06
                         ADI 6
878
    ØC3F
          F2 45 0C
                         JP HEXIA
                                        BRANCH FOR A-F
                         ADI 7
    0C42
          C6 07
879
689
    0C44
          DB
                         RC
                                        FILTER OUT 3A-40
```

```
AFCS 8080 ASSEMBLER
                       CES SYSTEM SOFTWARE
                                               00:40 322/78
                                                                 PAGE 19
                            SOURCE LINE
LINE LOC
           B1 B2 B3
 881
     0C45
           C6 0A
                    HEX1A ADI 10
                           ORA A
                                           CLEAR ERROR FLAG
 882
     0C47
           87
     ØC48
                                           VERIFIED 18 AUG 78
 883
          C9
                           RET
 885
                    886
                      HEXZ CONVERTS THE ASCII CHARACTERS IN ACC (LSB) AND
 887
                          B (MSB) TO ONE 8 BIT HEX WORD RETURNED IN THE
 888
 889
                          ACCUMULATOR.
 890
                    *
                             REGISTERS AFFECTED: A. C
                             SUBROUTINES CALLED: HEX1
 891
 892
 893
     0C49
           CD 37 0C HEX2
                           CALL HEX1
                                           CONVERT LSB
394
     ØC4C
           DB
                           RC
                                           RETURN IF BAD DATA
     ØC4D
                           MOV C.A
                                           SAVE IT
 895
           4F
           78
                           MOV A.B
                                           GET MSB CHARACTER
 896
     OC4E
 897
     0C4F
           CD 37 0C
                           CALL HEXI
                                           CONVERT MSB
     ØC52
 898
           DB
                           RC
 899
     ØC53
           07
                           RLC
                                           ROTATE
 900
     0C54
           07
                           RLC
                                              FOUR
 901
     0C55
           07
                           RLC
                                                 BIT
 902
     0C56
           07
                           RLC
                                                   POSITIONS
                                           CONCATONATE LSB
 903
     ØC57
           B1
                           ORA C
 904
     ØC58
           C9
                           RET
                                           WITH RESULTANT WORD IN ACC
 905
                                           VERIFIED 18 AUG 78
 907
                    908
 909
                    * ASCII CONVERTS THE 4 LSB OF THE ACC TO ONE ASCII
                         CHARACTER 0-9, A-F.
 910
 911
                         REGISTERS AFFECTED: A
 912
                    ASCII ANI 'OF
                                           LIMIT TO 4 LSB
 913
     0C59 E6 0F
                           ADI "0"
 914
     0C5B C6 30
                                           ADD ASCII OFFSET FOR DIGITS
                           CPI "9"
                                           CHECK IF IT WAS A DIGIT
 915
     0C5D
          FE 39
                                           DONE IF DIGIT
 916
     0C5F
           DB
                           RC
                           ADI "A"-"9"-1
                                           OTHERWISE ADD ALPHA OFFSET
 917
     0060
          C6 07
                                           VERIFIED 21 AUG 78
 918
     ØC62 C9
                           RET
 920
                    921
 922
                    * CMPHND COMPARES HL 'N' DE (HENCE THE NAME).
                         CARRY = 1 IF DE < HL OTHERWISE 0
 923
                    *
                            REIGSTERS AFFECTED: A
 24
 925
 926
     0063
                    CMPHND MOV A.E.
                                           GET LSB OF DE
          78
 927
     0064
           95
                           SUB L
                                           LSB OF HL
 28
     0065
           7A
                           MOV A.D
                                           GET MSB
 129
     0C66
           9C
                           SBB H
                                           MSB OF HL
 . 59
     0067
           C9
                           RET
                                           VERIFIED 21 AUG 78
```

```
CES SYSTEM SOFTWARE
                                         00:40 322/78
                                                          PAGE 20
AFCS 8080 ASSEMBLER
          B1 B2 B3
                        SOURCE LINE
LINE LOC
                  932
933
                      FORMATTING READ
                                                 LIBRARY
934
935
                  936
                  938
939
                  * RDIBHX GETS TWO CHARACTERS FROM THE INPUT DEVICE AND
940
                      RETURNS WITH THE HEX WORD IN THE ACCUMULATOR.
 941
                         REGISTERS AFFECTED: A. B. C
942
                         SUBROUTINES CALLED: READ , HEX2
 943
944
                                      GET ONE CHARACTERS OFF THE BUS
 945
    0C68 CD 19 0B
                 RD18HX CALL READ
                        MOV B.A
                                      SAVE MSB CHARACTER
 946
    ØC6B 47
                                      GET NEXT CHARACTER
947
     0C6C
         CD 19 0B
                        CALL READ
                                      CONVERTS TO HEX WORD
         CD 49 0C
                        CALL HEX2
 948
     0C6F
                                      VERIFIED 18 AUG 78
949
    ØC72 C9
                        RET
                  951
 952
                  * RD28HX READS FOUR CHARACTERS AND RETURNS THE TWO
 953
                      BYTES IN HL.
954
                      REGISTERS AFFECTED: A. B. C
 955
                      SUBROUTINES CALLED: RD18HX
 956
 957
    0C73 CD 68 0C RD2BHX CALL RD1BHX
                                      GET MSB OF DATA
 958
                                      SAVE IT
                        MOV H.A
 959
     0C76
         67
          CD 68 0C
                                      GET LSB
                        CALL RDIBHX
 960
     0C77
     ØC7A
          6F
                        MOY L.A
 961
                                      VERIFIED 21 AUG 78
                        RET
          C9
 962
     0C7B
                  963
 964
                  * RD48HX USES EIGHT INPUT CHARACTERS TO FILL THE HL
 965
                      PAIR, THEN THE DE PAIR.
 966
                         REGISTERS AFFECTED: ALL
 967
                         SUBROUTINES CALLED: RD2BHX
                  *
 968
 969
                  RD48HX CALL RD28HX
                                      GET HL
    ØC7C
         CD 73 0C
 970
 971
                        XCHG
                                      SAVE THEM
     ØC7F
         EB
                                      GET DE
     0080
         CD 73 0C
                        CALL RD2BHX
 972
                                      PUT THEM WHERE THEY SHOULD BE
                        XCHG
     0C83
 973
         EB
          C9
                        RET
 974
     0C84
                  975
 276
                  * RD1B13 READS 3 CHARACTERS FROM THE INPUT DEVICE AND
 977
                      INTERPRETS THESE AS DECIMAL DIGITS TO PRODUCE A
 978
                      NUMBER BETWEEN Ø AND 255 RETURNED IN THE ACC.
                  *
 979
                         REGISTERS AFFECTED: A. B. C. D. E
 980
                         SUBROUTINES CALLED: READ, MLTPLY, HEX1
 981
 982
```

以外的一种人

```
AFCS 8080 ASSEMBLER
                       CES SYSTEM SOFTWARE
                                              00:40 322/78
                                                                PAGE 21
LINE LOC
           B1 B2 B3
                           SOURCE LINE
 983
     ØC85
           CD 19 0B
                    RD1813 CALL READ
                                          GET 100'S DIGIT
 984
     ØC88
           CD 37 0C
                          CALL HEXI
                                          ASCII TO BINARY
 985
     ØC8B
           4F
                          MOV C.A
                                          MOY TO MULTIPLICAND
           16 ØA
                          MVI D. 10
 966
     ØC8C
                                          SET MULTIPLIER
 987
     ØC8E
           CD EE ØC
                          CALL MLTPLY
                                          C = 10 × HUNDREDS DIGIT (HD)
 988
     ØC91
           CD 19 0B
                          CALL READ
                                          GET TENS DIGIT
                          CALL HEXI
                                          CONVERT IT
 989
     0C94
           CD 37 0C
 990
     0C97
           81
                          ADD C
                                          ACC - 10 X HD + TENS DIGIT (TD
                          MOV C.A
                                          MOVE TO MULTIPLICAND
 991
     ØC98
           4F
 992
     ØC99
           CD EE ØC
                          CALL MLTPLY
                                          X 10
                          CALL READ
           CD 19 0B
                                          GET UNITS DIGIT (UD)
 993
     ØC9C
                          CALL HEXI
 994
     ØC9F
           CD 37 0C
                                          ACC - 100 X HD + 10 X TD + UD
 995
     ØCA2
           81
                          ADD C
          C9
                          RET
                                          VERIFIED 21 AUG 78
 996
     ØCA3
 998
                    999
1000
                       FORMATTING
                                           WRITE LIBRARY
1001
1002
                    1004
1005
                    * WRIBHX OUTPUTS ONE BYTE OF HEX DATA FROM THE ACC
1006
                         AS TWO CONSECUTIVE ASCII CHARACTERS.
1007
                           REGISTERS AFFECTED: A. B
1008
1009
                           SUBROUTINES CALLED: ASCII. WRITE
1010
     ØCA4 47
                    WRIBHX MOV B.A
                                          SAVE DATA
1011
                          RLC
1012
     ØCA5
          07
                                          SWAP
                          RLC
                                             HALF
     ØCA6
           07
1013
                                                BYTES
                          RLC
1014
     ØCA7
           07
                          RLC
1015
     ØCA8
           07
           CD 59 0C
                          CALL ASCII
                                          CONVERT 4 LSB TO ASCII CHAR
1016
     ØCA9
                          CALL WRITE
                                          OUTPUT MSB OF DATA
1017
     ØCAC
           CD EA ØA
                          MOY A.B
                                          GET LSB OF DATA
1018
     ØCAF
           78
                          CALL ASCII
                                          CONVERT IT
1019
     ØCBØ
           CD 59 0C
                                          OUTPUT LSB OF DATA
1020
     ØCB3
           CD EA ØA
                          CALL WRITE
1021
     ØCB6
           C9
                          RET
                                          VERIFIED 22 AUG 78
1023
                          1024
                      WR28HX OUTPUTS THE CONTENTS OF HL AS FOUR ASCII CHAR
1025
                         REGISTERS AFFECTED: A. B
1626
1027
                         SUBROUTINES CALLED: WRIBHX
1620
                    WRZBHX MOY A.H
                                          GET MSB OF HL
1029
     ØCB7
           70
           CD A4 0C
                          CALL WRIEHX
1039
     OCB6
                                          OUTPUT IT
           70
                          MOY A.L
1031
     OCBB
                                          GET LSB
                                          OUTPUT IT
1032
     ØCBC
           CD A4 OC
                          CALL WRIBHX
     ØCBF
           C9
                          RET
                                          VERIFIED 22 AUG 78
1033
```

10大多种产品的1个中央的1分

```
AFCS 8080 ASSEMBLER
                        CES SYSTEM SOFTWARE
                                                 00:40 322/78
                                                                     PAGE 22
LINE
     LOC
           B1 B2 B3
                             SOURCE LINE
1035
                     1036
1037
                       WRIBI3 FORMATS THE DATA IN THE ACCUMULATOR INTO AN
1038
                           13 FORMAT (3 ASCII DIGITS). WRIBI2 CONVERTS
1039
                           THE DATA IN THE C REGISTER INTO AN 12 FORMAT.
                             REGISTERS AFFECTED: A. B. C. D. E
1040
1041
                             SUBROUTINES CALLED: DIVIDE, WRITE
1042
                     WRIBI3 MOV C.A
                                             MOY TO LSB
1043
     ØCCØ
           4F
1044
      ØCC1
           06 00
                            MVI B.0
                                             CLEAR MSB
1045
      OCC3
           16 64
                            MYI D. 100
                                             SET DIVISOR
     ØCC5
           CD 01 0D
                            CALL DIVIDE
1046
1047
      ØCC8
           79
                            MOV A.C
                                             GET QUOTIENT FOR OUTPUT
                            MOV C.B
                                             MOV REMAINDER TO LSB
1048
      ØCC9
           48
1049
      ØCCA
           C6 30
                            ADI '30
                                             ADJUST TO ASCII
                                             OUTPUT DATA DIV 100
1050
      ØCCC
           CD EA ØA
                            CALL WRITE
                     * ENTER HERE FOR 12 FORMAT - DATA (REG C) MUST

* BE LESS THAN 100 !!!
1051
1052
                     WRIBIZ MYI B.O
                                              CLEAR MSB
1053
     ØCCF
           06 00
                            MVI D. 10
                                             DIVISOR
1054
      ØCD1
           16 ØA
1055
      ØCD3
           CD 01 0D
                            CALL DIVIDE
                                             MOY QUOTIENT TO ACC
                            MOV A.C
1056
      ØCD6
           79
1057
     ØCD7
           C6 30
                            ADI '30
                                             ADJUST TO ASCII
1058
      ØCD9
           CD EA ØA
                            CALL WRITE
                                             OUTPUT 10'S DIGIT
                            MOV A.C
                                             GET REMAINDER
1059
      ØCDC
           79
                            ADI '38
                                             ASCII
1060
      OCDD
           C6 30
                            CALL WRITE
                                             OUTPUT UNITS DIGIT
           CD EA ØA
1061
      ØCDF
                                             VERIFIED 18 AUG 78
1062
      ØCE2 C9
                            RET
1064
                     1065
                     * CRLF OUTPUTS A CARRIAGE RETURN AND LINE FEED ON THE
1066
                          OUTPUT DEVICE.
1067
1068
                             REIGSTERS AFFECTED: A
1069
1070
                     CR
                            EQU 'OD
                                             CARRIAGE RETURN IN ASCII
                            EQU '0A
                     LF
1071
                                             LINE FEED
1072
     00E3 3E 0D
                     CRLF
                            MVI A. '0D
                                             CARRIAGE RETURN
1073
      ØCE.
           CD EA OA
                            CALL WRITE
           3E 0A
                            MVI A. '0A
                                             LINE FEED
1074
      ØCEB
                                             LAST CHARACTER OF STRING
1075
           CD EA ON
                            CALL WRITE
     OCEA
1076
                                             VERIFIED 22 AUG 78
      OCED
           C9
                            RET
1078
                     1079
1080
                           TWO
                                   BYTE
                                             ARITHMETIC
                     *
                                                                          *
1061
1082
                     yciciologiciologiciologiciologiciologiciologiciologiciologiciologiciologiciologiciologiciologiciologiciologici
```

AFCS	8080	ASSEMBLER	CES SYSTEM SOFTWARE	00:40 322/78	PAGE 24
LINE	LOC	B1 B2 B3	SOURCE LINE		
1134	ØDIF	3E FF	MVI A. FF		
1135	ØD21	A9	XRA C		
1136	0D22	4F	MOV C.A		
1137	0D23		MOY A.E		
1138	ØD24	1F	RAR		
1139	0D25		RET	VERIFIED 18 AUG 78 FO	OR WRIBIS
1140			END		

\*\* ASSEMBLY COMPLETE, NO ERRORS 1062 BYTES ASSEMBLED

## APPENDIX D

## CES Programming Code Summary

Commands from the GPIB are interpreted as ASCII characters and are decoded as follows.

Command	Description
Axx	Allocate memory block to histogram. xx is the two digit number of alarm cards installed.
C	Clear histograms and reset system clock.
Dxxx	Dump Histograms.xxx specifies the number of the histogram to dump. An out-of-range number dumps all histograms.
Gxxxx	Go to specific location in memory and start execution xxxx is the four hex digit address to start at.
Kxxxy	Relay control. xxx is the relay code. $y = \emptyset$ turns the relay off, $y > \emptyset$ turns the relay on.
L	Local enable. Terminal device is enabled for operator input.
P	Load program. Program in Intel format representation is loaded into RAM.
R	Remote. Locks out the local control of the processor.
S	Start Scanning. If not preceded by an "A" command, defaults to scanning only one alarm card.

## DISTRIBUTION LIST

		NO OF CYS
DCA/470		
Washington DC 20305		3
DCEC/R220		
1860 Wiehle Avenue		
Reston VA 22070		4
Naval Telecommunications Command		
ATTN: 2633		
Massachusetts Avenue, NW		
Washington DC 10390	• •	
Naval Electronics System Command		
ATTN: 41014, 41025		
Washington DC 20360		
US Department of Commerce		
National Telecommunications and Information Administration		
Institute for Telecommunication Sciences		
Boulder CO 80303		4
NSA/S254		
Ft Meade MD 20755		
USACEEIA/CCC-CED		
USACEEIA/CCC-TED		2
USACEEIA/CCC-CED-XEM		
Ft Huachuca AZ 85613		1
AFLC/MMWE		
Wright-Patterson AFB OH 45433		1
AFCD/MMCY		
Kelly AFB TX 78241		1
AFSS/SREE		
Kelly AFB TX 78241		1
ESD/DCDE		
Hamscom AFB MA 01730		. 1
NCA/EPE		
Griffiss AFB NY 13440	٠.	. 2
ECA/EPE		
APO New York 09633		. 1
SCA/EPE		
Oklahoma City AFS OK 73145		. 1
PCA/EPE		
APO San Francisco 96515		. 1
Defense Documentation Center		
Cameron Station		
Alexandria VA 22314		. 15

## 1839 EIS **EMC Measurements Division/EPEF HQ AFCS** 1 LGMSR.......... 1 1842 EEG 2 EETTW........... 5 **HQ AFCS** 10 DFEE/CSL