NPS-ME-99-007

# NAVAL POSTGRADUATE SCHOOL Monterey, California



## IMPLEMENTATION OF A SHELL ELEMENT WITH PRESSURE AND VOID EFFECTS INTO DYSMAS

by

Patrick M. McDermott

and

Young W. Kwon

September 1999

Approved for public release; distribution is unlimited.



DTIC QUALITY INSPECTED 4

### Naval Postgraduate School Monterey, California

RADM Robert C. Chaplin Superintendent R.S. Elster Provost

This report was prepared in conjunction with research conducted for Naval Surface Warfare Center, Carderock Division.

This report was prepared by:

Patrick M. McDermott Lieutenant, United States Navy

Www

Young W. Kwon Associate Professor of Mechanical Engineering

which the

Reviewed By:

for M. D. Kelleher, Acting Chair Department of Mechanical Engineering

Released By:

D. W. Netzer Associate Provost and Dean of Research

¢

# **REPORT DOCUMENTATION PAGE**

Form Approved OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instruction, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188) Washington DC 20503.				
1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE September 1999	3. REPORT TYPE AND DATES COVERED		

	September 1999		
4. TITLE AND SUBTITLE IMPLEMENTATION OF A SHELL ELEMENT WITH PRESSURE AND VOID EFFECTS INTO DYSMAS		5. FUNDING NUMBERS N0016799WX90504	
6. AUTHOR(S) McDermott, Patrick M. and Kwor	n, Young W.		
7. PERFORMING ORGANIZATION NAME(S Naval Postgraduate School Monterey, CA 93943-5000	3) AND ADDRESS(ES)		8. PERFORMING ORGANIZATION REPORT NUMBER NPS-ME-99-007
9. SPONSORING / MONITORING AGENCY Naval Surface Warfare Center, Ca	NAME(S) AND ADDRESS(ES) arderock Division		10. SPONSORING / MONITORING AGENCY REPORT NUMBER
11. SUPPLEMENTARY NOTES	3700		
The views expressed in this thesis of the Department of Defense or t	are those of the author and do he U.S. Government.	not reflect 1	the official policy or position
12a DISTRIBUTION / AVAILABILITY STAT	EMENT		12b DISTRIBUTION CODE

12a. DISTRIBUTION / AVAILABILITY STATEMENT	12b. DISTRIBUTION CODE
Approved for public release; distribution unlimited.	A

## 13. ABSTRACT (maximum 200 words)

A shell formulation was developed from a three-dimensional solid. The shell element has four corner nodes at which there are three displacements and three rotations as nodal degrees of freedom, and includes both transverse shear and transverse normal deformations. The element utilizes reduced integration along the in-plane axes and full integration along the transverse axis. The formulation incorporates the Gurson constitutive model for void growth and plastic deformation. An algorithm for stable solutions of the nonlinear constitutive equations is also developed. Hourglass mode control is provided by adding a small fraction of internal force determined through full integration along the in-plane axes and reduced integration along the transverse axis. Implementation into both a specialized research finite element program and DYSMAS, a derivative of DYNA3D, is discussed. Numerical examples are provided to verify the accuracy of the new element and to show the importance of the transverse normal stress, void effects on plastic strain, and the necessity of applying a drilling moment.

#### 14. SUBJECT TERMS

14. SUBJECT TERMS Finite Element, Shell Formulation, Void Model, Elasto-plastic, DYSMAS, DYNA3D, High Order Element			15. NUMBER OF pages 112
			16. PRICE CODE
17. SECURITY CLASSIFICATION OF REPORT Unclassified	18. SECURITY CLASSIFICATION OF THIS PAGE Unclassified	19. SECURITY CLASSIFI- CATION OF ABSTRACT Unclassified	20. LIMITATION OF ABSTRACT UL

NSN 7540-01-280-5500 239-18

Standard Form 298 (Rev. 2-89) Prescribed by ANSI Std.

#### ABSTRACT

A shell formulation was developed from a three-dimensional solid. The shell element has four corner nodes at which there are three displacements and three rotations as nodal degrees of freedom, and includes both transverse shear and transverse normal deformations. The element utilizes reduced integration along the in-plane axes and full integration along the transverse axis. The formulation incorporates the Gurson constitutive model for void growth and plastic deformation. An algorithm for stable solutions of the nonlinear constitutive equations is also developed. Hourglass mode control is provided by adding a small fraction of internal force determined through full integration along the inplane axes and reduced integration along the transverse axis. Implementation into both a specialized research finite element program and DYSMAS, a derivative of DYNA3D, is discussed. Numerical examples are provided to verify the accuracy of the new element and to show the importance of the transverse normal stress, void effects on plastic strain, and the necessity of applying a drilling moment.

I. INTRODUCTION			
II. FIN	ITE ELEMENT FORMULATION	5	
A. B. C. D. E. F. G. H. I.	GEOMETRY DISPLACEMENT COORDINATE TRANSFORMATION STRAIN DISPLACEMENT RELATION JACOBIAN MATRIX STRESS-STRAIN RELATIONSHIP DRILLING MOMENTS INTERNAL FORCE, MASS AND THEIR ASSEMBLY EXPLICIT TIME INTEGRATION	5 7 8 10 11 12 12 14 15	
III. DA	MAGE CONSTITUTIVE EQUATIONS	17	
A. B. C. IV. HO	GURSON'S VOID MODEL IMPROVING STABILITY IN THE CONSTITUTIVE EQUATIONS STRAIN HARDENING DURGLASS MODE CONTROL	17 20 22 <b>25</b>	
VI. NU	MERICAL EXAMPLES	31	
A. B. C. D. E. F. G. H. I.	ELASTIC PLATE	31 32 37 40 42 42 42 46 48 49	
V. DYS	SMAS IMPLEMENTATION	57	
A. G B. SI C. M D. IN	ENERAL IMPLEMENTATION ISSUES HELL FORMULATION IATERIAL MODEL MPLEMENTATION ISSUES	57 58 59 60	
VI. DY	SMAS VERIFICATION	63	
A. E B. SI C. B	LASTIC CANTILEVER PLATE WITH SMALL DISPLACEMENT INGLE CURVATURE VERIFICATION: ELASTIC-PLASTIC CYLINDER ALL IMPACT PROBLEM	63 65 68	
VII. CO	ONCLUSIONS AND RECOMMENDATIONS	73	
APPEN	DIX A. CORRECTIONS IMPLEMENTED INTO DYSMAS.	75	
APPEN	DIX B. NEW DYSMAS SUBROUTINE LISTINGS	77	
ΔΡΡΓΝ	DIX C DVSMAS MODIFIED SUBBOUTINE LISTINGS	110	

# **TABLE OF CONTENTS**

iii

APPENDIX D. DOCUMENTATION PAGE FOR NEW MATERIAL TYPE.	
LIST OF REFERENCES	
INITIAL DISTRIBUTION LIST	

# LIST OF FIGURES

Figure 1. Element Cross Section
Figure 2. Displacement Vector Orientation
Figure 3. Calculating a New Yield Stress
Figure 4. Hourglass Modes in a Pinched Cylinder Model
Figure 5. Hourglass Mode Control Integration Points
Figure 6. Pinched Cylinder Model with Hourglass Mode Control
Figure 7. Nine Element Clamped Plate Mesh
Figure 8. Void Effects in a Clamped Plate with Pressure Loading: Top (a) - No Void
Effects, Bottom (b) - Void Effects
Figure 9. Transverse Normal Stress Variation through Shell Thickness: Clamped Plate
with Pressure Loading and Void Effects
Figure 10. Stress Component Time History in Bottom Fiber: Clamped Plate with
Concentrated Load, Void Effects, and Drilling Moment Applied
Figure 11. Porosity versus Effective Plastic Strain in Bottom Fiber: Clamped Plate with
Concentrated Load, Void Effects, and Drilling Moment Applied
Figure 12. Mesh Structure for Pinched Cylinder
Figure 13. Stress Component Time History in Bottom Fiber: Pinched Cylinder, No Void
Effects or Drilling Moment
Figure 14. Stress Component Time History in Bottom Fiber: Pinched Cylinder, Void
Effects and Drilling Moment Applied 46
Figure 15. Mesh Structure for Spherical Cap
Figure 16. Node One Displacement Time History: Pinched Spherical Cap with Impact
Loading
Figure 17. Porosity versus Effective Plastic Strain in Inner Fiber: Spherical Cap with
Void and Drilling Moment Effects
Figure 18. Comparison of Void and Drilling Moment Effects in a) Compression (Top)
and b) Tension (Bottom) for Spherical Cap
Figure 19. Contact Node Mean Displacement Time History: Spherical Cap with Void
and Drilling Moment Effects
Figure 20. Contact Node Displacement: Spherical Cap with 5% Greater Load
Figure 21. Deformed Structure at End of Analysis: Spherical Cap with 5% Greater Load.
Figure 22. Comparison of Element Formulations for Cantelever Plate
Figure 23. Mesh Structure for Pinched Cylinder using TECPLOT
Figure 24. Elastic-Plastic Pinched Cylinder using DYSMAS
Figure 25. Ball Impact Problem Center Node Displacement with 5:1 Aspect Ratio 68
Figure 26. Ball Impact Problem with Plate Modeled using Solid Elements
Figure 27. Ball Impact Problem with Shell Elements
Figure 28. Center Node Displacement Comparison for Ball Impact Problem

vi

# LIST OF TABLES

Table 1.	Comparison of Results for Elastic Clamped Plate	32
Table 2.	Material Properties of Clamped Plate	32
Table 3.	Void Characteristics of Clamped Plate.	32
Table 4.	Summary of Results for Clamped Plate with Pressure Load	37
Table 5.	Summary of Results for Clamped Plate Subjected to Point Force	40
Table 6.	Summary of Results for a Simply Supported Plate with a Point Force	41
Table 7.	Comparison of Results for Elastic Pinched Cylinder.	42
Table 8.	Summary of Results for Elasto-Plastic Pinched Cylinder.	43
Table 9.	Comparison of Results for Spherical Cap with Elastic Loading, and Results	
from	MacNeal and Harder [26]	47
Table 10.	Summary of Results for Elasto-Plastic Spherical Cap	51
Table 11.	DYSMAS Solution of Cantilever Plate.	64
Table 12.	DYSMAS Elastic Pinched Cylinder Results.	67

#### I. INTRODUCTION

Since shell structures are efficient load-carrying structural members, they have been dominant in most structural applications. However, the finite element formulation of shells poses some difficulty. As a result, extensive study has been devoted to developing better shell elements. Because of the abundance of papers on this subject, no attempt is made here to summarize all of them. Some of the related past work is given in references [1-12].

Void growth and nucleation can have a significant effect on plastic flow [13]. Since voids act as stress concentrators, the overall effect is to reduce the stress under plastic flow, and increase the plastic strain [14-16]. The model proposed by Gurson appears to have been adopted as the standard for incorporating void growth and nucleation effects into a numerical solution of elasto-plastic problems [17]. Previous work has been done on improving the efficiency and accuracy of plasticity computations, applying plasticity to plate/shell elements, and incorporating void growth and nucleation effects in solid elements [18-20]. The element presented in this paper incorporates a modified version of the algorithm for three-dimensional solids proposed by Aravas [21] into a shell element. This shell element assumes a modified plane-stress condition, and utilizes both the hydrostatic pressure and the deviatric stress. Due to the importance of the hydrostatic pressure on void growth and nucleation, this element includes the transverse normal stress.

The algorithm proposed by Aravas is not unconditionally stable when applied to this modified plane stress condition [21]. This paper also presents modifications to the original algorithm, which greatly enhance the stability of the solution, at the cost of a slight decrease in computational efficiency. This algorithm also allows for more complicated work-

hardening profiles than the typical exponent law ( $\sigma = K\epsilon^n$ ). Full modeling of the entire stress-strain curve is accomplished by a piece-wise linear approximation. While this method is not particularly useful for analytic approaches, it appears to be helpful in strictly numerical solutions. The stress-strain relationship may be taken directly off the results of a standard tensile test.

For thick shell applications, the transverse normal stress and strain cannot be neglected. The transverse normal stress and strain affect both the hydrostatic pressure and the deviatoric stress, which in turn affect plastic deformation and void growth and nucleation. The element presented here extends the typical use of the drilling degree of freedom (DOF), as outlined in Hughes and Brezzi [22], to incorporate the effects of transverse normal strain. The drilling DOF is important in transmitting stress and strain to elements across sharp bends and curves, and is therefore already included in a variety of shell elements [2,4,6,7,10]. In addition to this traditional usage, the present element utilizes the drilling DOF to compute the transverse normal deformation. The importance of including the transverse normal deformation is outlined in Essenburg [23].

The present study formulates a shell element for transient analysis. The element can have elasto-plastic deformation with void growth and nucleation. Gurson's void model is used as a basis for the void constitutive model. The shell element includes both transverse shear deformation and the transverse normal deformation for thick shell applications. The drilling degree of freedom is used for computing the deformation through the thickness of a thick shell. An algorithm for stable solutions of the nonlinear constitutive equations is also

developed.

Some example problems are presented to evaluate the formulation and to investigate the effects of the transverse normal strain for thick shells in association with elasto-plastic deformation, including void effects. Implementation and verification for DYSMAS is then discussed.

#### **II. FINITE ELEMENT FORMULATION**

#### A. GEOMETRY

A point in a shell structure can be expressed by a vector sum of two vectors. The first vector is a position vector from the origin of the global coordinate system to a point on a reference surface of the shell element. The second vector is a position vector from this reference surface to the point under consideration. The surface that spans the center of the transverse axis is used as the reference surface in this formulation, although any surface would suffice. The first vector terminates at the reference surface directly below the point in question. The second vector is then the normal from the reference surface that intersects the desired point. Figure 1 shows this relationship. Two shape functions are used to describe



Figure 1. Element Cross Section.

a position in the element;  $N^k$  is the two dimensional shape function in the  $\xi$ - $\eta$  plane, and  $H^k$  is the one dimensional shape function along the  $\zeta$  axis, where  $(\xi, \eta, \zeta)$  describes a point in the natural coordinate system. A generic point in the shell may now be described in terms of the position vectors of the nodes and the shape functions:

$$x_{i}(\xi,\eta,\zeta) = \sum_{k=1}^{n} N^{k}(\xi,\eta) \ x_{i}^{k} + \sum_{k=1}^{n} N^{k}(\xi,\eta) \ H^{k}(\zeta) V_{3i}^{k} \ (i = 1,2,3)$$
(1)

where  $x_i^k$  is the position vector of node k in the reference surface;  $V_{3i}^k$  is the unit vector at the node k; and n is the number of nodes per element. In the present formulation, a four-node shell element is considered. The unit vector  $V_{3i}^k$  is defined as:

$$V_{3i}^{k} = \frac{(x_{i}^{k})^{lop} - (x_{i}^{k})^{bottom}}{\left\| (x_{i}^{k})^{lop} - (x_{i}^{k})^{bottom} \right\|}$$
(2)

where top and bottom indicate the top and bottom surfaces of the shell, and || || denotes the Euclidean norm. The one-dimensional shape function  $H^k$  is expressed as:

$$\mathbf{H}^{k}(\zeta) = \left[\frac{1}{4}(1+\zeta)(1-\overline{\zeta}) - \frac{1}{4}(1-\zeta)(1+\overline{\zeta})\right] \quad \left\| (x_{i}^{k})^{top} - (x_{i}^{k})^{bottom} \right\|$$
(3)

in which  $\overline{\zeta}$  indicates the location of the reference surface and varied from -1 to 1 ( $\overline{\zeta} = 0$  denotes the mid-surface). The two-dimensional shape function  $N^k$  is expressed as:

$$N^{l} = \frac{1}{4} (l - \xi) (l - \eta)$$

$$N^{2} = \frac{1}{4} (l + \xi) (l - \eta)$$

$$N^{3} = \frac{1}{4} (l + \xi) (l + \eta)$$

$$N^{4} = \frac{1}{4} (l - \xi) (l + \eta)$$
(4)

#### **B. DISPLACEMENT**

The displacement field in a shell can be written as:

$$u_{i}(\xi,\eta,\zeta) = \sum_{k=1}^{n} N^{k}(\xi,\eta) u_{i}^{k} + \sum_{k=1}^{n} N^{k}(\xi,\eta) H^{k}(\zeta)(-V_{2i}^{k}\theta_{1}^{k} + V_{1i}^{k}\theta_{2}^{k} + V_{3i}^{k}\theta_{3}^{k}) (i = 1,2,3)$$
(5)

in which  $u_i$  is the displacement along the  $x_i$  axis,  $u_i^k$  is the nodal displacement at the node k, and unit vectors  $V_{1i}^k$  and  $V_{2i}^k$  lie along the reference surface.  $V_{1i}^k, V_{2i}^k$  and  $V_{3i}^k$  are mutually perpendicular.  $\theta_1^k$ ,  $\theta_2^k$  and  $\theta_3^k$  are rotational degrees of freedom along the unit vectors  $V_{1i}^k, V_{2i}^k$  and  $V_{3i}^k$ , respectively. The right-hand rule is assumed for the positive direction of each rotation. Figure 2 illustrates the relationship among these vectors.



Figure 2. Displacement Vector Orientation.

 $\theta_1^k$  and  $\theta_2^k$  are the bending rotations, while  $\theta_3^k$  is the drilling rotational degree of freedom. The role of  $\theta_3^k$  can be clarified by considering a flat plate parallel to the  $x_1-x_2$  plane. Now Eq. (5) can be rewritten for the transverse displacement as:

$$u_{3} = \sum_{k=1}^{n} N^{k} u_{3}^{k} + \sum_{k=1}^{n} N^{k} H^{k} \theta_{3}^{k}$$
(6)

Equation (6) demonstrates that the transverse deformation varies through the plate thickness (i.e. along the  $\zeta$  axis) with  $\theta_3^k$ . In this way, the transverse normal deformation is included in this formulation, along with the transverse shear deformations.

#### C. COORDINATE TRANSFORMATION

Combining the three unit direction vectors into matrix  $[\mathbf{T}_p]$  provides the rotation transformation matrix, or matrix of direction cosines, as shown in Eq. (7).  $[\mathbf{T}_p]^{-1}$  is used to transform the nodal degrees of freedom from the global coordinate system to local coordinates, as shown in Eq. (8), where k is the node number. The components of  $\{d\}$  at the four nodes of an element are shown in Eq. (9). Once the internal force vector is generated in local coordinates,  $[\mathbf{T}_p]$  is used to transform the local vectors back into global coordinates. This procedure will be discussed later.

$$\left[\mathbf{T}_{p}\right] = \left| \vec{\mathbf{V}}_{1} \vec{\mathbf{V}}_{2} \vec{\mathbf{V}}_{3} \right|_{(3x3)}$$

(7)

$$\{d\} = \{d^{1} d^{2} d^{3} d^{4}\}^{T}$$
(9)

The strain transformation matrix,  $[\mathbf{T}]$ , is used to transform calculated strain from the global coordinate system to local coordinates. Transforming the resulting stress from local coordinates to the global coordinate system would normally require using  $[\mathbf{T}]^{-1}$ , but since  $[\mathbf{T}]$  is orthogonal,  $[\mathbf{T}]^{-1} = [\mathbf{T}]^{\mathrm{T}}$ , where  $[\mathbf{T}]^{\mathrm{T}}$  is the transpose of  $[\mathbf{T}]$ . This property negates the requirement to invert a six by six matrix. For a detailed derivation of these transformations, refer to Cook [24]. The strain transformation matrix is explicitly defined in Eq. (10), where  $V_{ij}$  is the cosine of the direction vector  $V_i$  in the  $x_j$  direction.

$$\left[ \mathbf{T} \right] = \begin{bmatrix} V_{11}^2 & V_{12}^2 & V_{13}^2 & V_{11}V_{12} & V_{12}V_{13} & V_{11}V_{13} \\ V_{21}^2 & V_{22}^2 & V_{23}^2 & V_{21}V_{22} & V_{22}V_{23} & V_{21}V_{23} \\ V_{31}^2 & V_{32}^2 & V_{33}^2 & V_{31}V_{32} & V_{32}V_{33} & V_{31}V_{33} \\ 2V_{11}V_{21} & 2V_{12}V_{22} & 2V_{13}V_{23} & V_{11}V_{22} + V_{21}V_{12} & V_{12}V_{23} + V_{22}V_{13} & V_{13}V_{21} + V_{23}V_{11} \\ 2V_{21}V_{31} & 2V_{22}V_{32} & 2V_{23}V_{33} & V_{21}V_{32} + V_{31}V_{22} & V_{22}V_{33} + V_{32}V_{23} & V_{23}V_{31} + V_{33}V_{21} \\ 2V_{11}V_{31} & 2V_{12}V_{32} & 2V_{13}V_{33} & V_{11}V_{32} + V_{31}V_{12} & V_{12}V_{33} + V_{32}V_{13} & V_{13}V_{31} + V_{33}V_{11} \end{bmatrix}$$
(10)

# D. STRAIN DISPLACEMENT RELATION

The six components of the strain tensor are computed from Eq. (5) by taking its derivative with respect to the  $x_i$  axis. In matrix form, the result for a four-node element is:

$$\{\varepsilon\} = [\mathbf{B}]\{d\} \tag{11}$$

$$\{\varepsilon\} = \{\varepsilon_{11} \varepsilon_{22} \varepsilon_{33} \gamma_{12} \gamma_{23} \gamma_{13}\}^T$$
(12)

where

$$[\mathbf{B}] = \left[ \left[ \mathbf{B}^{1} \right] \left[ \mathbf{B}^{2} \right] \left[ \mathbf{B}^{3} \right] \left[ \mathbf{B}^{4} \right] \right]$$
(13)

The detailed expression for  $[\mathbf{B}^k]$  is:

$$\left[ \mathbf{B}^{k} \right] = \begin{bmatrix} \frac{\partial N^{k}}{\partial x_{l}} & 0 & 0 & -g_{1}^{k} V_{2l}^{k} & g_{1}^{k} V_{1l}^{k} & g_{1}^{k} V_{3l}^{k} \\ 0 & \frac{\partial N^{k}}{\partial x_{2}} & 0 & -g_{2}^{k} V_{22}^{k} & g_{2}^{k} V_{12}^{k} & g_{2}^{k} V_{32}^{k} \\ 0 & 0 & \frac{\partial N^{k}}{\partial x_{3}} & -g_{3}^{k} V_{23}^{k} & g_{3}^{k} V_{13}^{k} & g_{3}^{k} V_{33}^{k} \\ \frac{\partial N^{k}}{\partial x_{2}} & \frac{\partial N^{k}}{\partial x_{1}} & 0 & -g_{2}^{k} V_{2l}^{k} - g_{1}^{k} V_{22}^{k} & g_{2}^{k} V_{1l}^{k} + g_{1}^{k} V_{12}^{k} & g_{2}^{k} V_{3l}^{k} + g_{1}^{k} V_{32}^{k} \\ 0 & \frac{\partial N^{k}}{\partial x_{3}} & \frac{\partial N^{k}}{\partial x_{2}} & -g_{k}^{k} V_{22}^{k} - g_{k}^{k} V_{23}^{k} & g_{k}^{k} V_{12}^{k} + g_{k}^{k} V_{13}^{k} & g_{k}^{k} V_{32}^{k} + g_{k}^{k} V_{33}^{k} \\ \frac{\partial N^{k}}{\partial x_{3}} & 0 & \frac{\partial N^{k}}{\partial x_{1}} & -g_{3}^{k} V_{2l}^{k} - g_{1}^{k} V_{23}^{k} & g_{3}^{k} V_{1l}^{k} + g_{1}^{k} V_{13}^{k} & g_{3}^{k} V_{3l}^{k} + g_{1}^{k} V_{33}^{k} \\ \frac{\partial N^{k}}{\partial x_{3}} & 0 & \frac{\partial N^{k}}{\partial x_{1}} & -g_{3}^{k} V_{2l}^{k} - g_{1}^{k} V_{23}^{k} & g_{3}^{k} V_{1l}^{k} + g_{1}^{k} V_{13}^{k} & g_{3}^{k} V_{3l}^{k} + g_{1}^{k} V_{33}^{k} \end{bmatrix}$$

$$(14)$$

in which

$$g_i^k = \frac{\partial N^k}{\partial x_i} H^k + N^k \frac{\partial H^k}{\partial x_i}$$
(15)

The vector  $\{d^k\}$  is defined as:

$$\left\{d^k\right\} = \left\{u_1^k u_2^k u_3^k \theta_1^k \theta_2^k \theta_3^k\right\}$$

(16)

where  $u_i$  is the displacement along the  $x_i$  direction at node k, and  $\theta_i$  is the rotational displacement about the  $x_i$  axis at node k. The matrix  $[\mathbf{B}^k]$  must be calculated for each integration point.

#### E. JACOBIAN MATRIX

Computing the derivatives  $\frac{\partial N^k}{\partial x_i}$  and  $\frac{\partial H^k}{\partial x_i}$  requires the Jacobian matrix, defined as

 $\begin{bmatrix} \mathbf{J} \end{bmatrix} = \begin{bmatrix} x_{1,\xi} & x_{2,\xi} & x_{3,\xi} \\ x_{1,\eta} & x_{2,\eta} & x_{3,\eta} \\ x_{1,\zeta} & x_{2,\zeta} & x_{3,\zeta} \end{bmatrix}$ (17)

where

$$x_{i,\xi} = \frac{\partial x_i}{\partial \xi} = \sum_{k=1}^n \frac{\partial N^k}{\partial \xi} x_i + \sum_{k=1}^n \frac{\partial N^k}{\partial \xi} H^k V_{3i}^k \quad (i = 1, 2, 3)$$
(18)

$$x_{i,\eta} = \frac{\partial x_i}{\partial \eta} = \sum_{k=1}^n \frac{\partial N^k}{\partial \eta} x_i + \sum_{k=1}^n \frac{\partial N^k}{\partial \eta} H^k V_{3i}^k \quad (i = 1, 2, 3)$$
(19)

$$x_{i,\zeta} = \frac{\partial x_i}{\partial \zeta} = \sum_{k=1}^n N^k \frac{\partial H^k}{\partial \zeta} V_{3i}^k \quad (i = 1, 2, 3)$$
(20)

[**R**] is defined as the inverse of the Jacobian matrix,  $[\mathbf{J}^{-1}]$ . Then the required partial derivatives are defined as:

$$\frac{\partial N^{k}}{\partial x_{i}} = R_{il} \frac{\partial N^{k}}{\partial \xi} + R_{i2} \frac{\partial N^{k}}{\partial \eta} \quad (i = 1, 2, 3)$$
(21)

$$\frac{\partial H^{k}}{\partial x_{i}} = R_{i3} \frac{\partial H^{k}}{\partial \zeta} \quad (i = 1, 2, 3)$$
(22)

#### F. STRESS-STRAIN RELATIONSHIP

The strain calculated in Eq. (11) is in the global coordinate, and is transformed to a local coordinate system using

$$\{\varepsilon_{local}\} = [\mathbf{T}]\{\varepsilon_{global}\}$$
(23)

where [T] is defined in Eq. (10). Stress is calculated from the strain in the local coordinate system using the plane-strain assumption for the in-plane stress components:

$$\sigma_{x} = \frac{E}{1 - v^{2}} (\varepsilon_{x} + v \varepsilon_{y}) \qquad \tau_{xy} = G \gamma_{xy}$$

$$\sigma_{y} = \frac{E}{1 - v^{2}} (v \varepsilon_{x} + \varepsilon_{y}) \qquad \tau_{yz} = K G \gamma_{yz}$$

$$\sigma_{z} = E \varepsilon_{z} \qquad \tau_{xz} = K G \gamma_{xz}$$
(24)

where K is the shear correction factor, E is the elastic modulus, G is the shear modulus, and v is Poisson's ratio. The resulting stresses are in the local coordinate system and are converted to the global coordinate system with

$$\{\sigma_{global}\} = [\mathbf{T}]^{\mathrm{T}} \{ \sigma_{local} \}$$
(25)

$$\{\sigma\} = \{\sigma_{x} \sigma_{y} \sigma_{z} \gamma_{xy} \gamma_{yz} \gamma_{xz}\}$$
(26)

where [T] is from Eq. (10).

#### G. DRILLING MOMENTS

Let  $u_3$  be the transverse deflection as defined in Eq. (6). The work done by a pressure loading, p, on an element is:

$$W = \int_{\mathcal{A}^c} u_3 \ p \ dA \tag{27}$$

where  $A^e$  is the element area. Substituting Eq. (6) into Eq. (27), the work is now:

$$W = \left\{ u_3 \right\}^T \int_{\mathcal{A}^e} \left[ \mathbf{N} \right] p \, dA + \left\{ \theta_3 \right\}^T \int_{\mathcal{A}^e} \left[ \mathbf{N}^k \mathbf{H}^k \right] p \, dA \tag{28}$$

The first term gives the conventional forces at each node, while the second term yields the new nodal load, which will be called the Drilling Moment (DM). For example, if p is a concentrated force P at node n, then the drilling moment associated with  $\theta_3^n$  becomes  $\frac{1}{2}\zeta tP$ , where t is the shell thickness and the mid-plane is the reference plane.

When P is applied at the top plane,  $\zeta$  equals one, and the drilling moment is  $\frac{1}{2}tP$ . If P is applied at the bottom plane (still with a positive loading direction), the drilling moment is  $-\frac{1}{2}tP$ . That is, the load results in compression or tension in the transverse normal stress depending on whether the loading is applied to the top or bottom surface of the shell. The transverse normal stress is assumed constant through the shell thickness for elastic deformation. However, as plastic deformation progresses, the transverse normal stress becomes non-uniform through the thickness in order to satisfy the yield function.

The drilling moment direction coincides with the direction of drilling rotation, but affects the transverse normal stress. The drilling moment is used as a mathematical convenience, and thus, lacks a physical interpretation.

## H. INTERNAL FORCE, MASS AND THEIR ASSEMBLY

The stress resulting from Eq. (25) is then converted to an internal force vector and summed over all integration points using

$$\{f_{int}\} = \int_{-I}^{I} \int_{-J}^{I} \int_{-I}^{I} [\mathbf{B}]^{T} \{\sigma\} d\xi d\eta d\zeta = \sum_{i=1}^{nx} \sum_{j=1}^{ny} \sum_{k=1}^{nz} [\mathbf{B}]^{T} \{\sigma\}_{W_{i}W_{j}W_{k}} |\mathbf{J}|$$
(29)

where  $|\mathbf{J}|$  is the determinant of the Jacobian matrix, nx, ny, and nz are the number of integration points in the  $\xi$ ,  $\eta$ , and  $\zeta$  directions, respectively, and  $w_i$ ,  $w_j$ , and  $w_k$ , are the Gauss weights related to those integration points. The resulting force vector,  $\{f_{int}\}$ , must have its components transformed back to the global coordinate system using:

A lumped mass method is used for the element mass matrix. The matrix for each element is diagonal, with equal diagonal elements:

$$[\mathbf{M}_{e}] = \begin{bmatrix} \mathbf{m}_{e} & 0 & 0 & \dots & 0 \\ 0 & \mathbf{m}_{e} & 0 & \dots & 0 \\ 0 & 0 & \mathbf{m}_{e} & \dots & 0 \\ \dots & \dots & \dots & \dots & \dots \\ 0 & 0 & 0 & \dots & \mathbf{m}_{e} \end{bmatrix}$$
(31)

where

$$m_e = \frac{\left(\sum_{i=l}^{nx} \sum_{j=l}^{ny} \sum_{k=l}^{nz} w_i w_j w_k \left| \mathbf{J} \right| \right) \rho}{\mathbf{n}}$$
(32)

with n = 4 in this four-node element. Using a diagonal mass matrix greatly simplifies time integration, since inverting it is a trivial task requiring little computation time. The internal force vector and element mass vector (each 24 by 1) are then assembled into the corresponding system vectors.

#### I. EXPLICIT TIME INTEGRATION

The use of internal force vectors and explicit time integration negates the need to explicitly form the system stiffness matrices. The acceleration vector is computed from

$$\left\{ \ddot{U} \right\}' = \left[ \mathbf{M} \right]^{-1} \left( \left\{ F_{ext} \right\}' - \left\{ F_{int} \right\}' \right)$$
(33)

where  $\{\ddot{U}\}$  is the system acceleration vector, [M] is the system mass matrix,  $\{F_{ext}\}$  is the system external force vector, and superscript *t* denotes the time step. Of course, the system mass matrix in Eq. (33) is simply symbolic, since a system mass vector, formed from the diagonal of the mass matrix, is used in actual computation. Velocity and displacement are then found using

$$\left\{ \dot{U} \right\}^{\prime+\frac{M}{2}} = \left\{ \dot{U} \right\}^{\prime-\frac{M}{2}} + \left\{ \ddot{U} \right\}^{\prime} \Delta t$$

$$\left\{ U \right\}^{\prime+\Delta t} = \left\{ U \right\}^{\prime} + \left\{ \dot{U} \right\}^{\prime+\frac{M}{2}} \Delta t$$

$$(34)$$

#### **III. DAMAGE CONSTITUTIVE EQUATIONS**

#### A. GURSON'S VOID MODEL

Yielding and plastic deformation in the element follows the model proposed by Gurson for symmetric deformations around a spherical void [17]. The yielding condition is

$$F = \left(\frac{q}{\sigma_{\theta}}\right)^{2} + 2q_{I}\Phi\cosh\left(-\frac{3}{2}\frac{q_{2}p}{\sigma_{\theta}}\right) - \left(1 + q_{3}\Phi^{2}\right) = 0$$
(35)

where  $\Phi$  is the current porosity, p is the hydrostatic stress, q is the effective stress, and  $\sigma_{\theta}$  is the current yield stress. This model assumes equivalent yield stress in both tension and compression. The constants  $q_1, q_2$ , and  $q_3$  were introduced by Tvergaard in order to provide a better match with numerical studies [16]. Aravas provides a detailed explanation of implementing this model in a static finite element algorithm for three-dimensional solid elements [21]. The procedure used here is essentially the same, with some modifications due to the different element formulation. The stress is then transformed to local coordinates, and the internal force vector is computed as described above. One thing to be noted in Eq. (35) is that if  $\Phi$  is initially 0, the yielding criteria surface is identical to the von Mises yield condition.

After calculating the strain tensor using Eq. (23), any previous plastic strain is subtracted using

$$\left\{\varepsilon^{e}\right\} = \left\{\varepsilon^{total}\right\} - \left\{\varepsilon^{p}\right\}$$
(36)

The stress is then calculated using Eq. (24) with the components of  $\{\varepsilon^e\}$ . Using these values, the hydrostatic stress, deviatoric stress and effective stress are calculated as follows:

$$p = \frac{-l}{3} \left( \sigma_{xx} + \sigma_{yy} + \sigma_{zz} \right)$$
(37)

$$\{s\} = \{\sigma\} + p\{\delta\}$$
(38)

$$q = \sqrt{\frac{3}{2} \left( s_1^2 + s_2^2 + s_3^2 + 2 \left( s_4^2 + s_5^2 + s_6^2 \right) \right)}$$
(39)

where  $\delta$  is the Kronecker delta function:

$$\{\delta\} = \{11100\}^T \tag{40}$$

At this point, F is calculated from Eq. (35). If F is greater than zero, indicating plastic flow, iteration is required to determine the new porosity and change in plastic strain. The predictor-corrector method used in Aravas [21] is also used here. Using the values of p and q previously calculated as a first guess, correction factors are calculated using

$$\left\{C_f\right\} = \left[\mathbf{A}\right]^{-1} \left\{\mathbf{A}\mathbf{1}\right\} \tag{41}$$

where

$$\{AI\} = \begin{cases} -F \\ -\Delta \varepsilon_p \frac{\partial F}{\partial q} - \Delta \varepsilon_q \frac{\partial F}{\partial p} \end{cases}$$
(42)

$$\begin{bmatrix} \mathbf{A} \end{bmatrix} = \begin{bmatrix} \mathbf{K} \frac{\partial F}{\partial p} + \frac{\partial F}{\partial \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_p} & -3\mathbf{G} \frac{\partial F}{\partial q} + \frac{\partial F}{\partial \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_q} \\ \frac{\partial F}{\partial q} + \Delta \varepsilon_q \begin{bmatrix} \mathbf{K} \frac{\partial^2 F}{\partial p^2} + \frac{\partial^2 F}{\partial \rho \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_p} \end{bmatrix} + \Delta \varepsilon_p \frac{\partial^2 F}{\partial \rho \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_p} & \frac{\partial F}{\partial p} + \Delta \varepsilon_p \begin{bmatrix} -3\mathbf{G} \frac{\partial^2 F}{\partial q^2} + \frac{\partial^2 F}{\partial \rho \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_q} \end{bmatrix} + \Delta \varepsilon_q \frac{\partial^2 F}{\partial \rho \sigma_0} \frac{\partial \sigma_0}{\partial \Delta \varepsilon_q} \end{bmatrix}$$
(43)
$$\{C_f\} = \begin{cases} \alpha \\ \beta \end{cases}$$

and

$$\begin{split} \frac{\partial F}{\partial q} &= \frac{2 q}{\sigma_0^2} \\ \frac{\partial^2 F}{\partial q^2} &= \frac{2}{\sigma_0^2} \\ \frac{\partial F}{\partial p} &= 2 q_1 \Phi \left(\frac{-3 q_2}{2 \sigma_0}\right) \sinh\left(\frac{-3 q_2 p}{2 \sigma_0}\right) \\ \frac{\partial^2 F}{\partial p^2} &= 2 q_1 \Phi \left(\frac{3 q_2}{2 \sigma_0}\right)^2 \cosh\left(\frac{-3 q_2 p}{2 \sigma_0}\right) \\ \frac{\partial F}{\partial \sigma_0} &= \frac{-q^2}{2 \sigma_0^3} + 2 q_1 \Phi \frac{3 q_2 p}{2 \sigma_0^2} \sinh\left(\frac{-3 q_2 p}{2 \sigma_0^2}\right) \\ \frac{\partial^2 F}{\partial \rho \partial \sigma_0} &= -2 q_1 \Phi p \left(\frac{3 q_2}{2 \sigma_0^2}\right)^2 \cosh\left(\frac{-3 q_2 p}{2 \sigma_0^2}\right) + \frac{3 q_2}{2 \sigma_0^3} \sinh\left(\frac{-3 q_2 p}{2 \sigma_0^2}\right) \\ \frac{\partial^2 F}{\partial q \partial \sigma_0} &= \frac{-q}{\sigma_0^3} \end{split}$$

The values for  $\alpha$  and  $\beta$  are used to correct the change in strain caused by hydrostatic pressure and the change in strain caused by effective stress (See Eq. (46)), which are then used to determine the change in the plastic strain vector, as shown in Eq. (47).

$$\Delta \varepsilon_p^{new} = \Delta \varepsilon_p^{old} + \alpha \quad (\Delta \varepsilon_p^0 = 0)$$

$$\Delta \varepsilon_q^{new} = \Delta \varepsilon_q^{old} + \beta \quad (\Delta \varepsilon_q^0 = 0)$$
(46)

(45)

$$\left\{\Delta_{\varepsilon^{p}}\right\} = \frac{1}{3}\Delta_{\varepsilon_{p}}\left\{\delta\right\} + \Delta_{\varepsilon_{q}}\left(\frac{3}{2q}\right)\left\{s\right\}$$

$$(47)$$

This change in plastic strain,  $\{\Delta_{\mathcal{E}}{}^{p}\}$ , is then added to the total plastic strain, and the new elastic strain is calculated using Eq. (36), and the stress vector is calculated again using Eq. (24). Next, the change in void content, or porosity, is calculated as:

$$\Delta \Phi = \Delta \Phi_{growth} + \Delta \Phi_{nucleation} \tag{48}$$

$$\Delta \Phi_{growth} = (1 - \Phi) \sum \mathcal{E}_{ii}^{p}$$
(49)

$$\Delta \Phi_{nucleation} = \frac{\Phi_N}{s_N \sqrt{2\pi}} \exp\left[-\frac{1}{2} \left(\frac{\varepsilon^p - \varepsilon_N}{s_N}\right)^2\right] \Delta \varepsilon_p \tag{50}$$

where  $\Phi_N$  is the volume fraction of void nucleating particles and  $\varepsilon_N$  and  $s_N$  are the mean and standard deviation of a normal distribution of nucleation strain, as suggested by Chu and Needleman [15] and utilized by Aravas [21]. Then the effective plastic strain, and void content are updated with

$$\Delta \varepsilon^{p} = \frac{-p \Delta \varepsilon_{p} + q \Delta \varepsilon_{q}}{(l - \Phi) \sigma_{0}}$$
(51)

$$\varepsilon_{l+\Delta l}^{p} = \varepsilon_{l}^{p} + \Delta \varepsilon^{p} \tag{52}$$

where  $\varepsilon_i^p$  is the effective plastic strain from the previous time step. At this point, the change in yield stress due to strain hardening is calculated (see below). If either  $\alpha$  or  $\beta$  is greater than a predetermined tolerance, the process iterates beginning with Eq. (41). The tolerance used for all examples presented in the paper is  $1.0 \times 10^{-4}$ .

#### **B.** IMPROVING STABILITY IN THE CONSTITUTIVE EQUATIONS

Stability in the procedure outlined above is very dependent on the order in which the various equations are evaluated. Aravas discusses the stability problem when considering problems involving large plastic strains [21]. While the change in plastic strain from one time step to the next will theoretically be small, high strain rate and changes in the strain-hardening characteristics of the material act to degrade stability. Equations (42), (43) and (45) are not complete in that they do not contain all of the derivative terms required by the chain rule.

The predictor-corrector method used is based on Newton's method, where the correction factors,  $\alpha$  and  $\beta$ , are found from

$$\begin{bmatrix} f_{1,\Delta\varepsilon_{\rho}} & f_{1,\Delta\varepsilon_{q}} \\ f_{2,\Delta\varepsilon_{\rho}} & f_{2,\Delta\varepsilon_{q}} \end{bmatrix} \begin{bmatrix} \alpha \\ \beta \end{bmatrix} = \begin{cases} f_{1} \\ f_{2} \end{cases}$$
(53)

where

$$f_1 = \left(\frac{q}{\sigma_0}\right)^2 + 2q_1 \Phi \cosh\left(\frac{-3q_2p}{2\sigma_0}\right) - \left(1 + q_3 \Phi^2\right)$$
(54)

$$f_2 = \Delta \varepsilon_p \, \frac{\partial f_1}{\partial q} + \Delta \varepsilon_q \, \frac{\partial f_1}{\partial p} \tag{55}$$

$$f_{1,\Delta\varepsilon_p} = K \frac{\partial f_1}{\partial p} + \frac{\partial f_1}{\partial \Phi} \frac{\partial \Phi}{\partial \Delta\varepsilon_p} + \frac{\partial f_1}{\partial \sigma_0} \frac{\partial \sigma_0}{\partial \Delta\varepsilon_p}$$
(56)

$$f_{1,\Delta\varepsilon_q} = -3G\frac{\partial f_1}{\partial q} + \frac{\partial f_1}{\partial \Phi}\frac{\partial \Phi}{\partial \Delta\varepsilon_q} + \frac{\partial f_1}{\partial \sigma_0}\frac{\partial \sigma_0}{\partial \Delta\varepsilon_q}$$
(57)

$$f_{2,\Delta\varepsilon_{p}} = \frac{\partial f_{1}}{\partial q} + \Delta\varepsilon_{p} \frac{\partial^{2} f_{1}}{\partial \sigma_{0} \partial q} \frac{\partial \sigma_{0}}{\partial \Delta\varepsilon_{p}} + \Delta\varepsilon_{q} \left[ K \frac{\partial^{2} f_{1}}{\partial p^{2}} + \frac{\partial^{2} f_{1}}{\partial p \partial \Phi} \frac{\partial \Phi}{\partial \Delta\varepsilon_{p}} + \frac{\partial^{2} f_{1}}{\partial p \partial \sigma_{0}} \frac{\partial \sigma_{0}}{\partial \Delta\varepsilon_{p}} \right]$$
(58)

$$f_{2,\Delta\varepsilon_q} = \frac{\partial f_1}{\partial p} + \Delta\varepsilon_q \left[ \frac{\partial^2 f_1}{\partial p \partial \Phi} \frac{\partial \Phi}{\partial \Delta\varepsilon_q} + \frac{\partial^2 f_1}{\partial p \partial \sigma_0} \frac{\partial \sigma_0}{\partial \Delta\varepsilon_q} \right] + \Delta\varepsilon_p \left[ -3G \frac{\partial^2 f_1}{\partial q^2} + \frac{\partial^2 f_1}{\partial q \partial \sigma_0} \frac{\partial \sigma_0}{\partial \Delta\varepsilon_q} \right]$$
(59)

Derivative terms that are zero have been dropped, and K and G are the bulk and shear moduli, respectively.  $f_1$  is Gurson's void function, and  $f_2$  is the flow rule, both of which are driven to zero. As void content increases, the number of iterations required to achieve convergence increases dramatically, and often diverges, instead. By removing all partial derivatives relating to void content, the stability of the algorithm is greatly increased, at the cost of only 2 to 3 extra iterations, depending on the current void content. The dependence

on the current yield stress is retained to allow convergence across a transition in the slope of the yield stress versus strain relationship.

The partial derivatives of yield stress with respect to  $\Delta \varepsilon_p$  and  $\Delta \varepsilon_q$  are computed by calculating the slope from the current yield stress to the yield stress corresponding to the increase in plastic strain from the corrected values of  $\Delta \varepsilon_p$  and  $\Delta \varepsilon_q$ . This means that these derivatives will be zero on the first iteration, since both of the control variables are initialized to zero. Several error traps must be included to prevent round-off and truncation error from causing the algorithm to diverge, and to prevent porosity from decreasing or becoming negative. One of the assumptions used in this implementation is that once voids form, they do not disappear. In other words, voids do not disappear when the element is placed in compression.

#### C. STRAIN HARDENING

Modeling the nonlinear elasto-plastic behavior of the material used is simplified by constructing a piece-wise linear version of the stress-strain plot. Using the tangent modulus,  $E_T$ , for each piece-wise region, the yield stress is calculated with

$$\sigma_0^{\prime+\Delta\prime} = \sigma_0^0 + \sum_{i=1}^{j-1} E_{Ti} \left( \varepsilon_i - \varepsilon_{i-1} \right) + E_{Tj} \left( \varepsilon_i^{eff} - \varepsilon_{j-1} \right)$$
(60)

where  $\sigma_0^{\prime+\Delta\prime}$  is the yield stress for this time step,  $\sigma_0^0$  is the original yield stress,  $\varepsilon_i^{eff}$  is the total effective strain for the time step under consideration, and  $\varepsilon_i$  is the upper strain limit of the *i*th linear segment.  $\varepsilon_0$  is the original yield strain, and is calculated by the program as

simply  $\sigma_0^0/E$ . The current effective elastic strain is calculated by dividing the current yield stress by the elastic modulus, *E*. This is added to the current effective plastic strain to obtain the total effective strain.

As an example, let the total effective strain from Eq. (49) lie within the second workhardening segment. The new yield stress is

$$\sigma_0^{\prime+\Delta\prime} = \sigma_0^0 + E_{TI} \left( \varepsilon_I - \varepsilon_0 \right) + E_{T2} \left( \varepsilon_{\ell+\Delta\prime}^{eff} - \varepsilon_l \right)$$
(61)

Figure 3 illustrates this example. The algorithm calculates the new yield stress as a function of the cumulative effective plastic strain, the current effective elastic strain, and the original yield stress for each iteration of the damage constitutive equations.



Figure 3. Calculating a New Yield Stress.

#### **IV. HOURGLASS MODE CONTROL**

Only one integration point is used in each plane parallel to the reference plane, which results in under-integration in the  $\xi$ - $\eta$  plane. This leads to spurious, hourglass, or zero-energy modes in the element, which will yield useless results if left uncontrolled. The effects of these modes are shown in Fig. 4, a pinched cylinder where one eighth of the structure is modeled by utilizing symmetry boundary conditions. Clearly, no useful information can be obtained from the resulting solution.



Figure 4. Hourglass Modes in a Pinched Cylinder Model.

Belytschko, et al., proposed an efficient means of controlling the hourglass modes of a similar element [25]. The method described uses a portion of a stiffness matrix generated by full integration in all directions to modify the stiffness matrix generated by under-integration. Although the formulation proposed in this paper does not use a stiffness matrix, a similar approach is just as effective in controlling these modes.

Rather than fully integrating in all three directions, the element is fully integrated in the  $\xi$ - $\eta$  plane, but under-integrated in the  $\zeta$  direction, as shown in Fig. 5. The procedure described above for calculating the internal force vector is followed to generate an internal force vector related to these four integration points.



Figure 5. Hourglass Mode Control Integration Points.

The algorithm for calculating strain, stress, and force for the hourglass mode control integration points is identical to the algorithm used to produce the main internal force vector,
with the exception of plastic strain. The damage constitutive equations described in the previous section are not utilized for hourglass mode control. The internal forces generated from the two integration schemes are treated like the stiffness matrices in Belytschko et al. [25]. For *nz* integration points through the element thickness, the new force vector is

$$\left\{f_{int}\right\} = \left\{f_{int}^{I \times I \times nz}\right\} + h\left\{f_{hour}\right\}$$
(62)

where

$$\left\{ f_{hour} \right\} = \left\{ f_{int}^{2x2x1} \right\} - \left\{ f_{int}^{1x1x nz} \right\}$$
(63)

and

$$h = \frac{r t^2}{A} \tag{64}$$

The variable h is used here in Eqs. (62) and (64) instead of the  $\varepsilon$  used in Belytschko et al. [25], to avoid confusion with the various strains discussed in this paper. The variables used to calculate h are the element thickness (t) and the element's surface area (A). The effect of r follows that described in Belytschko et al. [25], and is set to 0.05. The range of values for r that effectively controls the hourglass modes, but does not greatly affect the overall element stiffness is roughly 0.046 to 0.057 (determined experimentally). Since the elements are in arbitrary orientation in 3-D space, the area calculation is computed as the sum of the area of the two triangles formed by dividing the element at the diagonal between nodes one and three:

$$A = \frac{1}{2}\sqrt{l_1^2 l_2^2 - D_1^2 + l_3^2 l_4^2 - D_2^2}$$
(65)

where

$$D_{I} = (x_{1}^{1} - x_{1}^{2})(x_{1}^{3} - x_{1}^{2}) + (x_{2}^{1} - x_{2}^{2})(x_{2}^{3} - x_{2}^{2}) + (x_{3}^{1} - x_{3}^{2})(x_{3}^{3} - x_{3}^{2})$$

$$D_{2} = (x_{1}^{1} - x_{1}^{4})(x_{1}^{3} - x_{1}^{4}) + (x_{2}^{1} - x_{2}^{4})(x_{2}^{3} - x_{2}^{4}) + (x_{3}^{1} - x_{3}^{4})(x_{3}^{3} - x_{3}^{4})$$
(66)

and

$$I_{1} = \sqrt{\left(x_{1}^{2} - x_{1}^{1}\right)^{2} + \left(x_{2}^{2} - x_{2}^{1}\right)^{2} + \left(x_{3}^{2} - x_{3}^{1}\right)^{2}}$$

$$I_{2} = \sqrt{\left(x_{1}^{3} - x_{1}^{2}\right)^{2} + \left(x_{2}^{3} - x_{2}^{2}\right)^{2} + \left(x_{3}^{3} - x_{3}^{2}\right)^{2}}$$

$$I_{3} = \sqrt{\left(x_{1}^{4} - x_{1}^{3}\right)^{2} + \left(x_{2}^{4} - x_{2}^{3}\right)^{2} + \left(x_{3}^{4} - x_{3}^{3}\right)^{2}}$$

$$I_{4} = \sqrt{\left(x_{1}^{1} - x_{1}^{4}\right)^{2} + \left(x_{2}^{1} - x_{2}^{4}\right)^{2} + \left(x_{3}^{1} - x_{3}^{4}\right)^{2}}$$
(67)

and  $(x_1^k, x_2^k, x_3^k)$  is the location of node k in the global coordinate system. For these calculations, the element is assumed to be flat (no curvature along either the  $\xi$  or  $\eta$  directions). The effectiveness of this method of control is shown in Fig. 6, the same problem as shown in Fig. 4, but with the hourglass mode control described above.



Figure 6. Pinched Cylinder Model with Hourglass Mode Control.

28

All verification problems analyzed in the following section were completed with hourglass control enabled. The current implementation uses hourglass control consistently, but allows easy modification to make hourglass control a user-defined option. The internal hourglass mode control can be disabled when the element is used in a general finite element program that includes various methods of spurious mode control.

### VI. NUMERICAL EXAMPLES

The element presented here has been extensively tested using a variety of problems in which an analytic solution was available, and has produced satisfactory results in all cases studied. The transformation matrices and constitutive equations were verified with specifically tailored problems, and the element passes the patch test. The examples presented below are representative of the test cases used to verify the element, and are presented in the order of curvature: flat, singly curved, and doubly curved. For each case, an elastic solution is compared to available results, and then the elasto-plastic solutions are presented. Examples A through I were solved using a locally written, research oriented finite element program in conjunction with a locally developed preprocessor and postprocessor.

### A. ELASTIC PLATE

A plate clamped on all four sides is subjected to a concentrated force at its center. The elastic modulus is 10 Msi (68.95 GPa), the density is  $0.1647 \text{ slugs/in}^3$  ( $0.147 \text{ kg/cm}^3$ ), and Poisson=s ratio is 0.2. The dimensions of the plate are 10 in x 10 in x 0.1 in thick (25.4cm x 25.4 cm x 0.254 cm). The yield stress is set high enough to ensure a completely elastic response. Two integration points through the thickness are used. The applied force is 40 lbf (177.9 N). The finite element mesh uses symmetry to model one quarter of the plate, with appropriate symmetry boundary conditions applied. Both a 2x2 (4 element) and 4x4 (16 element) mesh are used in the finite element analysis. The results for both meshes

and the analytic solution are shown in Table 1. Using a four-element mesh, the new shell element obtained a displacement within 3.27% of the analytic solution, and 0.82% using a 16 element mesh.

Table 1. Comparison of Results for Elastic Clamped Plate.

Analysis Type	Center Node Peak Displacement (in)
2 x 2 FE Mesh (Dynamic)	-4.74x10 <sup>-2</sup>
4 x 4 FE Mesh (Dynamic)	-4.94x10 <sup>-2</sup>
Analytic (Twice the Static Solution)	-4.90x10 <sup>-2</sup>

# B. THICK CLAMPED PLATE UNDER PRESSURE LOAD IN ELASTO-PLASTIC REGION

A thick steel plate, clamped on all four sides, is subjected to dynamic pressure load.

The plate is 6m by 6m by 0.6m thick (for a 10:1 ratio). Table 2 shows the material

properties for the structure. Table 3 shows the properties for the void model.

Table 2. Material Properties of Clamped Plate.

Property	Value	Units
Elastic Modulus (E)	2x10 <sup>11</sup>	Pa
Tangent Modulus (E <sub>T</sub> )	2x10 <sup>10</sup>	Pa
Density (ρ)	7850	kg/m <sup>3</sup>
Poisson's ratio (v)	0.29	(none)
Yield Stress (S <sub>YP</sub> )	2.5x10 <sup>8</sup>	Pa

Table 3. Void Characteristics of Clamped Plate.

Initial Void Content ( $\Phi_0$ )	0.0
Nucleating Particle Content $(\Phi_N)$	0.04
Mean Nucleation Strain (e <sub>N</sub> )	0.3
Nucleation Strain Standard Deviation $(s_N)$	0.1
Model Constant q <sub>1</sub>	1.5
Model Constant q <sub>2</sub>	1.0
Model Constant $q_3 (= q_1^2)$	2.25

One quarter of the plate is modeled with a three by three element mesh, for a total of nine elements, with appropriate symmetry boundary conditions applied, and is shown below in Fig. 8.



Figure 7. Nine Element Clamped Plate Mesh.

Four integration points are used through the thickness of each element. The calculation time step is  $10^{-5}$  seconds, while the data is plotted at  $2x10^{-4}$  second increments. The analysis terminates at 0.04 seconds. The plate is subjected to a uniformly distributed pressure acting downwards, and includes the appropriate drilling moment. The pressure

increases linearly from 0.0 Pa at the start to 80 MPa at 0.01 seconds, then remains constant for the duration of the analysis. Three cases were analyzed: no void effects, void growth effects only, and void growth and nucleation. Figure 9 illustrates the effect of voids on the effective stress versus the effective strain relationship in the top of one of the border elements. When void effects are not included, the Von-Mises Equivalent (VME) stress follows the yield stress in the plastic region (See Fig. 9a).

Including void effects causes the yielding before the VME stress reaches the yield stress. As the void content increases with continued plastic flow, the VME stress falls farther below the yield stress, as shown in Fig. 9b (see Eq. (35)). Table 4 summarizes the results of the three cases. The most significant difference is in the transverse normal stress,  $\sigma_{zz}$ . This difference resulted in a 2.0% increase in the effective plastic strain, and a 2.6% increase in the peak deflection of the center of the plate.

Another interesting point is that the transverse normal stress was compressive and constant throughout the thickness up until plastic flow, as assumed in the formulation, then varied as the stress in the bottom fiber decreased and became tensile. Figure 10 shows the variation of transverse normal stress through the thickness of the element at the time of peak stress. Eventually, the transverse normal stress varied from compressive at the top, where the pressure was applied, and tensile at the bottom. The examples that follow will not include a separate analysis for void growth effects only, since the difference of including nucleation effects at the resulting small plastic strains obtained do not cause significantly different results.



Figure 8. Void Effects in a Clamped Plate with Pressure Loading: Top (a) - No Void Effects, Bottom (b) - Void Effects.



Figure 9. Transverse Normal Stress Variation through Shell Thickness: Clamped Plate with Pressure Loading and Void Effects.

Peak Values for Element #3	No Void Effects	Void Growth	Growth and Nucleation
σ <sub>vm</sub> (Gpa)	1.4498	1.3789	1.3784
Eeffective	0.0588	0.0597	0.0597
$\sigma_{xx}$ (GPa)	1.4501	1.3603	1.3598
$\sigma_{vv}$ (GPa)	0.6561	0.6030	0.6073
$\sigma_{zz}$ (GPa)	-0.0003	0.0065	0.0091
(Max Tension)			· · ·
$\sigma_{zz}$ (GPa)	-0.0363	-0.0322	-0.0320
(Max Compression)			
$\varepsilon^{\text{plastic}}$ (effective)	0.0540	0.0551	0.0551
Φ (Porosity)	NA	0.0355	0.0357
Deflection (m)	-0.3801	-0.3897	-0.3898
(Center Node)			

Table 4. Summary of Results for Clamped Plate with Pressure Load.

# C. THICK CLAMPED PLATE WITH CENTRAL POINT LOAD IN THE ELASTO-PLASTIC REGION

The geometry and material properties of this example are identical to those used in the previous example. The pressure load has been replaced with a point load at the center node. Four cases are studied: without void effects or a drilling moment, with void effects, with a drilling moment applied, and with both void effects and a drilling moment applied. All four sides are clamped, and the center node displacement is restricted in the x and y directions. Then, a DM equal to the applied force times one-half the plate thickness is applied for both the no-void and void cases. The time history of the stress components in the center element is shown in Fig. 10, and the relationship between porosity and effective plastic strain is illustrated in Fig. 11. The results for all four cases are summarized in Table

5.







Figure 11. Porosity versus Effective Plastic Strain in Bottom Fiber: Clamped Plate with Concentrated Load, Void Effects, and Drilling Moment Applied.

Peak Values for Center	No Voids	Voids	No Voids	Voids
Element	No DM	No DM	Drilling Moment	Drilling Moment
σ <sub>vm</sub> (GPa)	2.1119	1.9021	2.0540	1.8590
Eeffective	0.0892	0.0929	0.0865	0.0887
$\sigma_{xx}$ (GPa)	2.0008	1.8407	2.0000	1.7498
σ <sub>vv</sub> (GPa)	1.9588	1.7245	1.8589	1.7234
$\sigma_{zz}$ (GPa)	0.0048	0.0213	-0.0003	-0.0003
(Max Tension)				
$\sigma_{zz}$ (GPa)	-0.0036	-0.0057	-0.1751	-0.1691
(Max Compression)		·		
ε <sup>plastic</sup> (effective)	0.0838	0.0880	0.0812	0.0840
$\Phi$ (Porosity)	NA	0.0663	NA	0.0601
Deflection (m)	-0.4413	-0.4544	-0.4350	-0.4451
(Center Node)				

Table 5.	Summary	of Results for	Clamped Plate Su	bjected to Point Force.
			1	3

The drilling moment increases the effective stress on the fiber in compression, and decreases the effective stress on the fiber in tension. The reduction in the tensile stress results in a reduction in the effective plastic strain. Including void effects decreases the VME stress on the fiber in tension, and slightly increases the VME stress on the fiber in tension, and slightly increases the VME stress on the fiber in compression. The effective plastic strain is also increased. All of these results indicate that this formulation correctly predicts, in a qualitative sense, the effects of drilling moments and void growth and nucleation. Including only void effects increased the effective plastic strain by 5.0%, while including only the drilling moment decreased the effective plastic strain by 3.1%. Including both void effects and the drilling moment increased the effective plastic strain by 0.2%, indicating the importance of applying both effects together.

# D. SIMPLY SUPPORTED PLATE WITH CENTRAL POINT LOAD IN THE ELASTO-PLASTIC REGION

The material properties, geometry, mesh, and time values from the clamped plate

problem above are used here. The magnitude of the force is  $8 \times 10^8$  N, and the drilling moment, when applied, is  $-2.4 \times 10^8$  N. The same four cases are analyzed: no void or drilling moment effects, drilling moment effects only, void effects only, and both void and drilling moment effects. The analysis results for all four cases are summarized in Table 6.

Peak Values for Center	No Voids	No Voids	Voids	Voids and
Element	No DM	Drilling Moment	No DM	Drilling Moment
σ <sub>vm</sub> (GPa)	3.0874	3.0089	2.5061	2.4881
E <sub>effective</sub>	0.1360	0.1321	0.1450	0.1393
$\sigma_{xx}$ (GPa)	3.0253	2.9123	2.4686	2.4206
$\sigma_{yy}$ (GPa)	3.0459	2.8889	2.4612	2.3928
$\sigma_{zz}$ (GPa)	0.0060	-0.0003	0.0114	-0.0003
(Max Tension)				
$\sigma_{zz}$ (GPa)	-0.0035	-0.1802	-0.0035	-0.1722
(Max Compression)	:		and the second sec	
$\varepsilon^{\text{plastic}}$ (effective)	0.1277	0.1242	0.1382	0.1327
Φ (Porosity)	NA	NA	0.1197	0.1092
Deflection (m)	-0.9219	-0.8990	-0.9770	-0.9420
(Center Node)				

Table 6. Summary of Results for a Simply Supported Plate with a Point Force.

The qualitative results for this example are the same as for the clamped plate. Since the applied force causes greater initial yielding, void growth and nucleation has a greater effect. The drilling moment, when added to the void effects, reduces the amount of effective plastic strain in tension and displacement.

# E. ELASTIC PINCHED CYLINDER

An open-ended cylinder of radius 5.0 in., length 10.35 in., and thickness 0.094 in. is subjected to a pinching load of 100 lbf (See Fig. 6). The elastic modulus is 10.5 msi, Poisson's ratio is 0.3125, and the density is  $3.125 \times 10^{-3}$  slugs/in<sup>2</sup>. The load is applied as a step function beginning at time t = 0 seconds. Using symmetry, the problem was reduced to a one-eighth section of the cylinder. The dynamic value should be twice the analytic static value. Inextensional shell theory gives a static radial contraction of 0.1117 in. The maximum radial contraction of the model is 0.1995 in., which translates to a static radial contraction of 0.09975 in. Using a 256-element mesh (16 by 16), the maximum radial contraction was 0.2207 in., for a static contraction of 0.1104 in. The results are summarized in Table 7. The 16-element solution is within 10.7% of the analytic solution, while the 256-element mesh is within 1.21%.

Table 7. Comparison of Results for Elastic Pinched Cylinder.

Analysis Type	Radial Contraction (in)
Finite Element with 16 Element Mesh	0.1995
Finite Element with 256 Element Mesh	0.2207
Analytic (Twice the Static Solution)	0.2234

# F. THICK PINCHED CYLINDER IN THE ELASTO-PLASTIC REGION

The material and void properties shown in Tables 2 and 3 are used for an open-ended cylinder with a pinching force at its center. The top half of the cylinder is modeled using a

element mesh with appropriate symmetry boundary conditions along the bottom edge of mesh, as shown in Fig. 13. The analysis is calculated in  $10^{-5}$  second steps, with output every  $2\times10^{-4}$  seconds, from 0.0 seconds to 0.04 seconds. The pinching force is 66.792 kN on each side, with a drilling moment of 848.258 Nm applied on the cases indicated. The same four cases are compared: no voids or drilling moment, void effects only, drilling moment only, and both void effects and drilling moment (DM). The effects of void growth and nucleation and the drilling moment is shown in the stress component time histories; Fig. 14 shows the stresses without voids or a drilling moment, and Fig. 15 shows the stresses with both effects included. The results for all cases are summarized in Table 8.

				· · · · · · · · · · · · · · · · · · ·
Peak Values for Center	No Voids	No Voids	Voids	Voids and
Element	No DM	Drilling Moment	No DM	Drilling Moment
$\sigma_{\rm VM}$ (MPa)	262.40	265.05	259.28	283.49
$\varepsilon_{\text{effective}} (x \ 10^3)$	1.6504	1.5722	1.4273	2.7049
σ <sub>xx</sub> (MPa)	182.46	160.38	170.12	150.31
σ <sub>yy</sub> (MPa)	291.71	283.77	291.83	297.97
σ <sub>zz</sub> (MPa)	5.0619	-0.0238	1.0270	7.5235
(Max Tension)				• *
σ <sub>zz</sub> (MPa)	-7.6358	-28.739	-7.0364	-35.373
(Max Compression)				
$\varepsilon^{\text{plastic}}$ (effective) (x 10 <sup>3</sup> )	0.7828	0.7583	0.5771	1.6923
$\Phi$ (Porosity) (x 10 <sup>3</sup> )	NA	NA	0.4773	1.1970
Deflection (mm)	2.7589	12.919	-0.0220	-0.0214
(Center Node)				
Global Maximum				
Deflection (mm)	-31.750	-31.750	-31.750	-31.750
(Center Node)				
Global Minimum		· ·		

Table 8. Summary of Results for Elasto-Plastic Pinched Cylinder.

Since there is only a small amount of plastic strain, the effects of void growth and nucleation are greatly reduced. Even with this small amount of plastic flow, the effective plastic strain was increased by over 116 percent with the inclusion of both drilling moment and void effects, while the peak center node displacement was only increased by approximately 4.5 percent.



Figure 12. Mesh Structure for Pinched Cylinder.



Figure 13. Stress Component Time History in Bottom Fiber: Pinched Cylinder, No Void Effects or Drilling Moment.



Figure 14. Stress Component Time History in Bottom Fiber: Pinched Cylinder, Void Effects and Drilling Moment Applied.

# G. ELASTIC SPHERICAL CAP WITH A CENTER HOLE

The results of analysis with the shell element developed here are compared to results of the problem proposed in MacNeal and Harder [26]. The structure is a hemisphere of radius 10 units with a thickness of 0.04 units, and has an 18° hole cut in the center. Taking advantage of the symmetry in the structure, only ¼ of the structure is modeled. An eight-byeight mesh is used, for a total of 64 elements, with four integration points through the thickness of each element. The mesh used is shown in Fig. 15. The material properties of the structure are:  $E = 6.825 \times 10^7$ ,  $\rho = 0.001$ , and v = 0.3. No void or drilling moment effects are employed in this example. Opposing forces of magnitude 2.0 are applied at each quadrant: the force at node 73 is of magnitude -1.0 and parallel to the y-axis, and the force at node one is of magnitude 1.0 and parallel to the x-axis. To obtain a representative static response using a dynamic model, the applied force begins with 0.0 magnitude at time 0, and increases linearly with a rise time of 0.16 seconds to the specified value. A calculation time step of  $1 \times 10^{-6}$  seconds is used, with termination at 0.22 seconds. The maximum deflection of node one was 0.0929, where the theoretical value is 0.0940, for a normalized displacement of 0.988. This is within the range of the results listed in MacNeal and Harder from the QUAD2 and QUAD4 elements, which are considered to be accurate for this problem [26]. These results are summarized in Table 9.

Table 9. Comparison of Results for Spherical Cap with Elastic Loading, and Results fromMacNeal and Harder [26].

	New Shell Element	QUAD2	QUAD4
Normalized Displacement	0.988	0.986	1.005



Figure 15. Mesh Structure for Spherical Cap.

# H. SPHERICAL CAP WITH A CENTER HOLE, IMPACT LOADING

Key and Hoff [11] used the previous problem to test their element with an impact (step) load. The structure and matrial properties are the same, and the mesh is the same as shown in Fig. 15. The load is applied at its maximum at  $t=0.0^+$  seconds, rather than ramped up. Figure 16, which plots the displacement of node one obtained from both the shell element presented here and the element developed by Key and Hoff [11], shows that the

results of this element are comparable to those obtained by other elements under impact loading.



Figure 16. Node One Displacement Time History: Pinched Spherical Cap with Impact Loading.

# I. SPHERICAL CAP WITH A CENTER HOLE, ELASTO-PLASTIC LOADING

The spherical cap structure shown in Fig. 15 is now used to verify the stability and convergence of the damage-constitutive equations under double curvature, and to illustrate

both the effects of void growth and nucleation and a drilling moment on a more complex structure. The material properties used are the same as shown in Tables 2 and 3. The structure has a radius of 5.0 meters and a thickness of 25 cm, for a radius to thickness ratio of 20:1, commonly considered the limit of thin-shell theory. Although a force is applied at each quadrant, all four loads are directed inwards. Therefore, only one load is applied at node 37 of the mesh shown in Fig. 15. The applied load is 5.9397x10<sup>6</sup> N, with a drilling moment of -7.4246x10<sup>5</sup> Nm applied for the cases indicated. A calculation time step of  $1 \times 10^{-5}$  seconds is used, with output every  $5 \times 10^{-4}$  seconds and stopping at 0.2 seconds. The load is initial zero, and increases linearly to its maximum at 0.01 seconds. The results shown in Table 10 are for the element nearest the applied load, where stress is maximum. The porosity versus effective plastic strain relationship is shown in Fig. 17. Due to the small amount of plastic strain, porosity is restricted to the linear zone, as shown. Figures 18a and 18b illustrate the effective stress versus effective strain in the same element on the compressive side and tensile side, respectively. Note that as the structure returns from a peak displacement, the stress follows the elastic modulus, not the tangent modulus. This reflects the correct behavior of material: the elastic modulus is not affected by plastic deformation, only the yield stress is affected. The node displacement where the force is applied is shown in Fig. 19. This figure shows that there are at least two vibration modes in operation.

Peak Values for	No Voids	No Voids	Voids	Voids and
Element #25	No DM	Drilling Moment	No DM	Drilling Moment
σ <sub>vm</sub> (MPa)	250.26	250.76	250.26	250.75
$\varepsilon_{\text{effective}} (x \ 10^3)$	1.0730	1.1021	1.0731	1.1021
σ <sub>xx</sub> (MPa)	202.09	199.44	202.08	199.43
σ <sub>vv</sub> (MPa)	-47.093	-58.183	-47.087	-58.192
σ <sub>zz</sub> (MPa)	-5.2570	-12.433	-5.2571	-12.433
$\varepsilon^{\text{plastic}}(x \ 10^5)$	2.1002	4.1795	2.1020	4.1849
$\Phi$ (Porosity) (x 10 <sup>6</sup> )	NA	NA	6.7149	12.763
Deflection (m)	0.0233	0.0246	0.0233	0.0246
(Point of Loading)				·





Figure 17. Porosity versus Effective Plastic Strain in Inner Fiber: Spherical Cap with Void and Drilling Moment Effects.



Figure 18. Comparison of Void and Drilling Moment Effects in a) Compression (Top) and b) Tension (Bottom) for Spherical Cap.



Figure 19. Contact Node Mean Displacement Time History: Spherical Cap with Void and Drilling Moment Effects.

During testing, it became apparent that this problem is not suitable for testing elastoplastic analysis. Since the structure is concave, the entire structure quickly collapses once yielding begins. In addition, the single point used to prevent rigid-body motion also provided a stress concentration and additional yielding (the "corner" began folding over). This necessitated using a force that just causes plastic flow, but does not collapse the structure or cause yielding near the anchored node. This is illustrated by an analysis of a 5 percent greater load than used for the above analysis. The resulting node 37 displacement is shown in Fig. 20, and the deformed structure in Fig. 21. However, it is still apparent that the qualitative results obtained in the previous elasto-plastic examples carried through to this problem; both voids and the drilling moment decreased stress in fibers under tension, and increased stress in fibers under compression. Due to the small amount of plastic strain, the increase in porosity was extremely small, which minimized the effects of the voids.



Figure 20. Contact Node Displacement: Spherical Cap with 5% Greater Load.





### V. DYSMAS IMPLEMENTATION

After verifying the formulation using in-house code (see previous section and McDermott and Kwon [27]), the next step was to implement the formulation into DYSMAS, using source code provided by NSWC Carderock. This section will discuss the details of implementing this shell formulation into the DYSMAS source code.

Since DYSMAS treats the constitutive model, or material model, separate from the element formulation, it was necessary to conduct the implementation in two steps: 1) implement the new shell formulation and verify, 2) implement Gurson's void model as a new material type and verify. Since the source code provided was not fully functional, several corrections were required before completing the shell formulation implementation. These corrections are summarized in Appendix A.

### A. GENERAL IMPLEMENTATION ISSUES

The in-house code used to test the formulation was linear, and the integration scheme was to step through all the elements of the same type, with an inner loop for the integration points. DYSMAS is non-linear (based on strain increments), and divides each element type into groups of 32, or some other constant that is determined before compiling (variable NLQ). In addition, DYSMAS steps through each integration point, with an inner loop for each element in the group. This required substantive modification to the in-house implementation. The goal of this implementation is to fully support all functions of DYSMAS. The areas where this implementation falls short will be detailed later.

### **B. SHELL FORMULATION**

The formulation is implemented by providing for the following functions: data input and echo, initialization, computation, and data output. All new subroutines are listed in Appendix B. Changes made to original subroutines are highlighted in Appendix C. The following subroutines required modification in order to support the formulation:

DYNAI - read new formulation number (8), and write to echo file

ELEM2D - calls the new formulation during the solution phase

The following new subroutines have been implemented:

KWNMCD - main algorithm for new shell formulation

KMTRAN - computes variables for traditional hourglass control and element area KMCON - call appropriate material model, including Gurson's Void Model KMFRC - computes hourglass force and puts internal forces into system matrix KMDRILL - computes drilling moment for applied forces, including contact KMCPDP - copies displacements to/from global variables to/from local variables KMSHAP - 1-D shape function

KMINV3 - explicit 3 by 3 matrix inversion

All subroutines have been commented to explain the details of the algorithm, so they will not be repeated here.

# C. MATERIAL MODEL

The implementation of Gurson's void model required modification to the following subroutines:

BLKDAT - number of material constants for new model

IN3DIS - initialization

MATIN - read new material model from input data file

NBSINT - initialization

PENSTF - initialization

STIFFS - initialization

STIFFSN - initialization

PRINTM - echo of input material properties

SCA ASC - output of data in ASCII format

SCA DYS - output of data in DYSMAS format

SCA\_TEC - output of data in TECPLOT format

The following new subroutines were added for the new material model:

SETS44 - initialize material variables and AUX14 variables

SCA\_GET - provide additional contour plot information

SHL44S - new material model

Note that SCA\_GET will also support providing contour plot information for any variable in AUX14 of other formulations, but this has not been implemented. Draft pages

for addition to the user's guide covering the new material model are provided in Appendix D. Gurson's void model is implemented as material type number 44. The current implementation does not allow this material type to be used with any other element type.

### **D. IMPLEMENTATION ISSUES**

The following issues have not been resolved for the new implementation:

The indexing for updating shell thickness is incorrect, and causes a memory violation.
 The option of updating the shell thickness for the new formulation should not be used until this is corrected.

2. The calculation of the drilling moment utilizes some FORTRAN 90 commands, and needs to be revised. A better implementation would place these calculations in FEM3D, prior to calling the appropriate formulation.

3. There is no theoretical basis for the critical time step calculation of this element, even though the method used has survived extensive testing. This involves modifying the computed surface area with a normalized thickness and a constant (see KMTRAN in Appendix B). It is certain that since this element provides full integration through the thickness, the thickness affects the critical time step, but not in a linear manner. Basing the time step on the thickness alone is far too conservative, while neglecting the thickness frequently causes an unstable solution. The method shown in KMTRAN's listing was used with success for all verfication problems.

4. The method of hourglass control is time-consuming and inefficient. However, this

method works when the other methods available in DYSMAS do not. This method also works for other formulations, but is currently available only in the new formulation. The current implementation in KMFRC disregards the choice of hourglass control specified in the input file, strictly using the new method. This needs to be revised, and using a more efficient formulation for hourglass control would greatly improve efficiency.

Failure is not implemented in either the shell formulation, or in the material model.
 This is critical, and should be the next step in implementation.

6. The subroutines listed in the appendices are "first drafts." Although functional, no emphasis was placed on efficiency and/or speed. There is certainly room for improvement in this area.

7. Dynamic Relaxation does not work with the new material model. This is probably caused by faulty energy calculation in SHL44S, and must be corrected.

The current implementation is functional, and several verification problems were analyzed.
#### **VI. DYSMAS VERIFICATION**

The following problems were analyzed using the DYSMAS implementation described in the previous section. Since the DYSMAS preprocessor and postprocessor are not available, both a preprocessor and postprocessor that use the ASCII format were created using MATLAB. All associated script files are available upon request. In addition, TECPLOT was used to show contour plots and animate structural response.

#### A. ELASTIC CANTILEVER PLATE WITH SMALL DISPLACEMENT

A cantilever plate with small displacement that ensured all stresses were below the yield stress was tested using both the in-house code (FEA) and DYSMAS with the Belytschko-Tsay, Hughes-Liu, QPHM, and the formulation presented herein (referred to as the Kwon-McDermott element). The Kwon-McDermott element used the new material model; Gurson's Void model. An analytic solution is available for this problem, and the results are shown in Table 11. Although the Kwon-McDermott element obtains an answer closest to the analytic solution, this will not always be the case. The purpose of this example is only to show that the algorithm has been correctly implemented for the purely elastic case. Table 11. DYSMAS Solution of Cantilever Plate.

Solution Method	Displacement (x10 <sup>-6</sup> m)	Error from Analytic (%)
Analytic	58.6	NA
FEA (in-house)	55.368	11.54
Belytschko-Tsay	56.788	3.09
Hughes-Liu	56.788	3.09
QPHM	57.271	2.27
Kwon-McDermott	57.661	1.60

This problem was also used to verify that the element works correctly across more than one group. A simple four element mesh was used to obtain the results shown in Table 11. The same problem was solved using a 100 element mesh, and the Kwon-McDermott element obtained the same answer;  $57.661 \times 10^{-6}$  m. This is reasonable since the deflection is so small. This problem was also used to verify the solution using the top and bottom surfaces, vice the mid-plane, as the reference surface. The element obtained the same answer for both the top and bottom reference surfaces:  $57.662 \times 10^{-6}$  m. As mentioned in the previous section, the tests on dynamic relaxation and updating the element thickness both failed. Tests on the basis for the sound speed passed for all three options available.

The tests using this example were designed to identify improper coding, and the results show that the element is functional, but the calculations relating to dynamic relaxation and thickness update contain some errors. The same geometry was used for a different set of dimensions and applied force using the Belytschko-Tsay and the Kwon-McDermott Element. The results are shown in Figure 22.



Figure 22. Comparison of Element Formulations for Cantelever Plate.

# **B. SINGLE CURVATURE VERIFICATION: ELASTIC-PLASTIC CYLINDER**

The same elastic pinched cylinder used to verify the in-house code was used with the Kwon-McDermott element in DYSMAS (See Table 7). Figure 23 shows the first run, using a 1/4 cylinder model with appropriate symmetry boundary conditions. This figure also verifies the changes made to the TECPLOT output subroutines, along with other contour plots and animations (animations available upon request).



Figure 23. Mesh Structure for Pinched Cylinder using TECPLOT.

Table 12 compares the results from the mesh shown in Fig. 23 with the results shown in Table 7. The improvement is due to the non-linear solution method used by DYSMAS, vice the linear solution method used in the in-house code.

Solution Method	Radial Contraction (m)	Error from Analytic (%)
Analytic (Twice Static)	0.2234	NA
FEA (16 Element Mesh)	0.1995	10.7
Kwon-McDermott (16	0.2135	4.4
Element Mesh, DYSMAS)		

Table 12. DYSMAS Elastic Pinched Cylinder Results.

Figure 24 shows an elastic-plastic pinched cylinder at the end of a solution run. A one-half structural mesh is used to magnify any problems in the hourglass mode control method. All other hourglass control methods available in DYSMAS failed this test, but as Fig. 24 shows, the new method is effective. Since there is no comparison data for this problem, the displacement and stress field will not be discussed.



Figure 24. Elastic-Plastic Pinched Cylinder using DYSMAS.

### C. BALL IMPACT PROBLEM

A test problem received form NSWC Carderock involved a solid ball striking a fully clamped plate. The original plate was too thick for adequate modeling using shell elements, as shown in Fig. 25. The characteristic length to thickness ratio for this problem was 5:1.



Figure 25. Ball Impact Problem Center Node Displacement with 5:1 Aspect Ratio.

The problem structure modeled with all solid elements at the end of the solution is shown in Fig. 26. The same problem with the plate modeled using the new shell element is shown in Fig. 27. The center node displacement time history is shown in Fig. 28, which also include the solution for the Belytschko-Tsay element. The results for this problem should be the same for both shell formulations. The additional rotational degrees of freedom in shell elements allows an additional mode of vibration in the plate, which explains the difference between the displacement using solid elements and the displacement using the two shell formulations.



Figure 26. Ball Impact Problem with Plate Modeled using Solid Elements.



Figure 27. Ball Impact Problem with Shell Elements.



Figure 28. Center Node Displacement Comparison for Ball Impact Problem.

For the purely elastic case, both the element formulation and the material model provide correct answers for all test problems. Testing in the elastic-plastic region is incomplete.

### VII. CONCLUSIONS AND RECOMMENDATIONS

A new shell formulation was developed for transient dynamic analysis which includes both void effects with plastic deformation and the transverse normal stress with drilling moment. The element is compatible with most shell elements which have three translation and three rotation degrees of freedom per node.

A numerically stable scheme was developed for Gurson's nonlinear constitutive equation model. The model includes both void nucleation and void growth. Furthermore, hourglass control was implemented into the algorithm to avoid spurious modes caused by the under-integration scheme.

The drilling moment was important for thick plates and shells. It induced large transverse normal stress and affected the plastic deformation. Similarly, the effect of voids on plastic deformation was not negligible. Numerical studies show that the effective plastic strain increased up to fifteen percent due to the combined effects of voids and the transverse normal stress.

The element presented here passed all testing when implemented into an in-house finite element analysis code. The element also passed all testing in the elastic region when implemented into DYSMAS. Testing in the elastic-plastic region was not complete at the time of this report. The majority of code modification and new coding required to implement the new element into DYSMAS is complete, although there are a few issues that must be resolved. The current DYSMAS implementation of this element does not support updating element thicknes, dynamic relaxation, or element failure. In addition, there are several areas where improvements in efficiency can be made: drilling moment calculation, critical time step calculation, hourglass control, and main algorithm calculation. Material data indicating the proper values for the constants in Gurson's void model are required, as are structural test results in the elastic-plastic region.

# APPENDIX A. CORRECTIONS IMPLEMENTED INTO DYSMAS.

FEM3D	Corrected print interval calculation which caused all output files to be written at each calculation time step.
PRTDAT	Corrected multiple file writes at each print step.
SCA_TEC	Corrected incorrect use of a scratch file.
TEC_TEN	Corrected incorrect us of a scratch file.
TECPLOT	Assigned text to current zone to prevent all text being written to base frame.

These corrections are included in Appendix C, and comments in the source code detail the changes made.

### APPENDIX B. NEW DYSMAS SUBROUTINE LISTINGS.

```
(The following three subroutines are in the file "kmaux.for")
c Following Subroutines used for Kwon-McDermott Shell Element
    kminv3 - computes inverse of a 3 by 3 matrix (explicitly)
С
    kmshap - returns 1-D shape function values at zeta
С
    kmcpdp - copies displacements to/from global variables
с
С
                                      McDermott 1999
      subroutine kminv3(a, ainv,det)
      Direct calculation of 3x3 matrix inverse
С
      implicit double precision (a-h,o-z)
      dimension a(3,3), ainv(3,3)
      ainv(1,1) = a(2,2)*a(3,3) - a(3,2)*a(2,3)
      ainv(2,1) = -a(2,1)*a(3,3) + a(3,1)*a(2,3)
      ainv(3,1) = a(2,1)*a(3,2) - a(3,1)*a(2,2)
      ainv(1,2) = -a(1,2)*a(3,3) + a(3,2)*a(1,3)
      ainv(2,2) = a(1,1)*a(3,3) - a(3,1)*a(1,3)
      ainv(3,2) = -a(1,1)*a(3,2) + a(3,1)*a(1,2)
      ainv(1,3) = a(1,2)*a(2,3) - a(2,2)*a(1,3)
      ainv(2,3) = -a(1,1)*a(2,3) + a(2,1)*a(1,3)
      ainv(3,3) = a(1,1)*a(2,2) - a(2,1)*a(1,2)
      det = a(1,1) * ainv(1,1) + a(1,2) * ainv(2,1)
          + a(1,3) * ainv(3,1)
     1
      do 20 j = 1,3
do 10 i = 1,3
   10
        ainv(i,j) = ainv(i,j)/det
   20 continue
      return
      end
      subroutine kmshap(r,shapef)
      returns 1D shape function
С
      implicit double precision (a-h,o-z)
      dimension shapef(2)
      shapef(1) = 0.5 * (1 - r)
      shapef(2) = 0.5 * (1 + r)
      return
      end
      subroutine kmcpdp(disp,idir,ie)
c Copy displacements to a local vector
c idir = 1, copy to edispg, idir=0, copy from edispg
      implicit double precision (a-h, o-z)
      include 'nlqpar.inc'
      common/bk02/iburn, isdo, dt1, dt2
      common/aux10/area(nlq),
     1 px1(nlq),px2(nlq),px3(nlq),px4(nlq),
     & px5(nlq),px6(nlq),px7(nlq),px8(nlq),
     2 py1(nlq),py2(nlq),py3(nlq),py4(nlq),
     & py5(nlq),py6(nlq),py7(nlq),py8(nlq),
     3 pz1(nlq),pz2(nlq),pz3(nlq),pz4(nlq),
     & pz5(nlq),pz6(nlq),pz7(nlq),pz8(nlq),
```

```
4 dx1(nlq), dx2(nlq), dx3(nlq), dx4(nlq),
5 dx5(nlq), dx6(nlq), dx7(nlq), dx8(nlq),
6 dy1(nlq), dy2(nlq), dy3(nlq), dy4(nlq),
7 dy5(nlq), dy6(nlq), dy7(nlq), dy8(nlq),
8 dz1(nlq),dz2(nlq),dz3(nlq),dz4(nlq),
9 dz5(nlq), dz6(nlq), dz7(nlq), dz8(nlq)
 common/aux12/
1 wxx1(nlq), wxx2(nlq), wxx3(nlq), wxx4(nlq),
2 wyy1(nlq),wyy2(nlq),wyy3(nlq),wyy4(nlq),
3 wzz1 (nlq), wzz2 (nlq), wzz3 (nlq), wzz4 (nlq),
4 a13(nlq),a23(nlq),a33(nlq)
dimension disp(*)
if (idir.eq.1) then
 disp(1) = dx1(ie)
 disp(2) = dy1(ie)
 disp(3) = dz1(ie)
 disp(4) = wxx1(ie)
 disp(5) = wyy1(ie)
 disp(6) = wzz1(ie)
 disp(7) = dx2(ie)
 disp(8) = dy2(ie)
 disp(9) = dz2(ie)
 disp(10) = wxx2(ie)
 disp(11) = wyy2(ie)
 disp(12) = wzz2(ie)
 disp(13) = dx3(ie)
 disp(14) = dy3(ie)
 disp(15) = dz3(ie)
 disp(16) = wxx3(ie)
 disp(17) = wyy3(ie)
 disp(18) = wzz3(ie)
 disp(19) = dx4(ie)
 disp(20) = dy4(ie)
 disp(21) = dz4(ie)
 disp(22) = wxx4(ie)
 disp(23) = wyy4(ie)
 disp(24) = wzz4(ie)
else
 dx1(ie) = disp(1)
 dy1(ie) = disp(2)
 dz1(ie) = disp(3)
 wxx1(ie) = disp(4)
 wyy1(ie) = disp(5)
 wzz1(ie) = disp(6)
 dx2(ie) = disp(7)
 dy2(ie) = disp(8)
 dz2(ie) = disp(9)
 wxx2(ie) = disp(10)
 wyy2(ie) = disp(11)
 wzz2(ie) = disp(12)
 dx3(ie) = disp(13)
 dy3(ie) = disp(14)
 dz3(ie) = disp(15)
 wxx3(ie) = disp(16)
 wyy3(ie) = disp(17)
 wzz3(ie) = disp(18)
 dx4(ie) = disp(19)
 dy4(ie) = disp(20)
 dz4(ie) = disp(21)
```

wxx4(ie)	=	disp(22)
wyy4(ie)	=	disp(23)
wzz4(ie)	=	disp(24)
endif		
return		
end		

subroutine kmcon (nmtcon, auxvec, cm, lav, mte, nip, ipt, capa, 1 dampk, ym, prv, mxe) \*\*\*\*\*\*\* \*\*\*\*\* C Constitutive Equation Driver for Kwon-McDermott Shell Element С С Works the same as the drivers for the other formulations, but will С calculate sig3 for materials that set it to zero. Only mat #44 С calculates and retains sig3 C McDermott 1999 c \* implicit double precision (a-h,o-z) dp include 'nlqpar.inc' common/bk01/itherm,itemp,ntmp0,ntmp1 common/bk07/n1, n2, n3, n4, n5, n6, n7, n8, n9, n10, n11, n12, n13, n14, n15, 1 n16, n17, n18, n19, n20, n21, n22, n23, n24, n25, n26, n27, n28, n29, n30, n31, 2 n32,n33,n34,n35,n36,n37,n38,n39,n40,n41,n42,n43,n44,n45, 3 n46,n47,n48,n49,n50,n51,n52,n53,n54,n55,n56,n57,n58,n59,n60,n61, 4 n62,n63,n64,n65,n66,n67,n68,n69,n70,n71,n72,n73,n74,n75,n76,n77, 5 n78, n79, n80, n81, n82, n83, n84, locend, iname, lendf common/bk13/lc0,lc1h,lc1b,lc1s,lc1t,lc2,lc3,lc4,lc5,lc6,lc7,lc9, lc10,lc11,lc12,lc13,lc14,lc15,lc16,lc17,lc18,lb0,lb1,lb2, 2 lc7a,lc7b common/aux2/d1(nlq), d2(nlq), d3(nlq), d4(nlq), d5(nlq), d6(nlq), 1 wzzdt(nlg),wyydt(nlg),wxxdt(nlg),einc(nlg) common/aux14/ 1 sig1(nlq),sig2(nlq),sig3(nlq),sig4(nlq), 2 sig5(nlq),sig6(nlq), ep(nlq),epx1(nlq), 3 epx2(nlq), epx4(nlq), epx5(nlq), epx6(nlq), aux(nlq, 59) common/aux36/lft,llt common/shlopt/istrn,istupd,ibelyt,miter common / / a(1)dimension cm(48,\*), auxvec(\*), sg3(nlq), d3t(nlq) c Get previous stress tensor for current ipt lavloc=(ipt-1) \*nmtcon+lav call tbscls (nmtcon, auxvec(lavloc), nip\*nmtcon) c If not a material type that supports KM element, store sig3 & d3 if(mte.ne.44) then do 10 i=lft,llt d3t(i) = d3(i)sg3(i) = sig3(i)10 continue endif c \*\*\* Call appropriate Consitutive Model if (mte.eq.1) then call shlls (cm, capa) elseif (mte.eq.2) then call shl2s (cm, capa) elseif (mte.eq.3) then if (miter.eq.0) then call sh3sc (cm, capa) elseif (miter.eg.1) then call shl3s (cm, capa) elseif (miter.eq.2) then call sh3si (cm, capa) endif elseif (mte.eq.4) then 80

```
call shl4s (cm,a(ntmp0+1),a(n19))
elseif (mte.eq.12) then
 call shl12s (cm, capa)
elseif (mte.eq.15) then
 call shl15s (cm, capa)
elseif (mte.eq.18) then
 call fem18s (cm, capa)
elseif (mte.eq.19) then
if (miter.eq.0) then
  call sh19sc (cm,a(n8),a(n9),capa)
 elseif (miter.eq.1) then
  call shl19s (cm,a(n8),a(n9),capa)
 elseif (miter.eq.2) then
  call sh19si (cm,a(n8),a(n9),capa)
 endif
elseif (mte.eq.21) then
 call shl2ls(cm,capa,a(ntmp0+1),a(n19))
elseif (mte.eq.22) then
 call shl22s(cm, capa)
elseif (mte.eq.23) then
 lthrpr=nint(cm(48,mxe))
 call shl23s(cm, capa, a(ntmp0+1), a(n19), a(lthrpr),
                              a(n8),a(n9),a(lc11))
elseif (mte.eq.24) then
 if (miter.eq.0) then
  call sh24sc (cm,a(n8),a(n9),capa)
 elseif (miter.eq.1) then
  call shl24s (cm,a(n8),a(n9),capa)
 elseif (miter.eq.2) then
 call sh24si (cm,a(n8),a(n9),capa)
 endif
elseif (mte.eq.28) then
 call shl28s (cm, capa)
elseif (mte.eq.30)
                    then
call sh130s (cm, capa)
elseif (mte.eq.33)
                    then
 call sh133s (cm, capa)
elseif (mte.eq.34) then
 call shl34s (cm, capa)
elseif (mte.eq.35)
                    then
 if (miter.eq.0) then
  call shl35s(cm,a(n8),a(n9),capa)
 elseif (miter.eq.1) then
  call shl35s(cm,a(n8),a(n9),capa)
 elseif (miter.eq.2) then
  call shl35s(cm,a(n8),a(n9),capa)
 endif
elseif (mte.eq.38)
                    then
 call shl38s(cm, capa)
elseif (mte.eq.39) then
 call shl39s(cm, capa)
elseif (mte.eq.41) then
 call shl41s(cm, capa)
elseif (mte.eq.42) then
 call shl42s(cm, capa)
elseif (mte.eq.44) then
 call shl44s(cm, capa)
else
write(39,1000)
write(13,1000)
```

```
81
```

call tbsc2s (nmtcon,auxvec(lavloc),lav,nip\*nmtcon,nip,ipt)

```
c Apply Rayleigh Damping
```

if (dampk.ne.0.) call rydmp2(dampk,ym,pr) return

end

```
subroutine kmdrill(e,f,ndlist,nlstm)
c *
c Calculates Drilling Moment associated with external forces
    for Kwon-McDermott shell element
С
С
             (Does this by calculating a normal vector at each node,
             then finding the dot product with the applied forces)
С
                                                 McDermott 1999
С
   Variable Listing
С
     e - nodal force array
С
     f - nodal moment array
С
     ndlist - array of nodes affected by this element group
С
     nlstm - number of entries in ndlist
С
C
      implicit double precision (a-h,o-z)
      include 'nlqpar.inc'
      common/bk00/numnp,numpc,numlp,neq,ndof,nlcur,numcl,numvc,
     1 ndtpts, nelmd, nmmat, numelh, numelb, numels, numelt, numdp,
     2 grvity, idirgv, nodspc, nspcor
      common/bk02/iburn,isdo,dt1,dt2
      common/aux13/
     &zeta(nlq),thick(nlq),fga(nlq),fgb(nlq),fgc(nlq),
     &gl11(nlq),gl12(nlq),gl13(nlq),gl21(nlq),gl22(nlq),gl23(nlq),
     &gl31(nlq),gl32(nlq),gl33(nlq),
     &x1(nlq), y1(nlq), z1(nlq), x2(nlq), y2(nlq), z2(nlq),
     &x3(nlq), y3(nlq), z3(nlq), x4(nlq), y4(nlq), z4(nlq),
     &fx1(nlq),fy1(nlq),fz1(nlq),fx2(nlq),fy2(nlq),fz2(nlq),
     &fx3(nlq),fy3(nlq),fz3(nlq),fx4(nlq),fy4(nlq),fz4(nlq),
     &xmx1(nlq), xmy1(nlq), xmz1(nlq), xmx2(nlq), xmy2(nlq), xmz2(nlq),
     &xmx3(nlq), xmy3(nlq), xmz3(nlq), xmx4(nlq), xmy4(nlq), xmz4(nlq)
      common/aux33/
     1 ix1(nlq), ix2(nlq), ix3(nlq), ix4(nlq), ixs(nlq,4), mxt(nlq)
      common/aux36/lft,llt
      dimension e(3,*),f(3,*),ndlist(*)
      allocatable anorm(:,:),thnod(:),nth(:)
c Set up & initialize nodal arrays
      allocate(anorm(3,numnp),thnod(numnp),nth(numnp))
      call azero(anorm,numnp*3)
      call azero(thnod, numnp)
      call iazero(nth, numnp)
c Get component normal to plane of element and add to nodes
      do 10 i=lft,llt
       anorm(1,ix1(i))=anorm(1,ix1(i))+gl13(i)
       anorm(2, ix1(i))=anorm(2, ix1(i))+gl23(i)
       anorm(3, ix1(i)) = anorm(3, ix1(i)) + g133(i)
       anorm(1, ix2(i))=anorm(1, ix2(i))+gl13(i)
       anorm(2, ix2(i))=anorm(2, ix2(i))+gl23(i)
       anorm(3, ix2(i))=anorm(3, ix2(i))+gl33(i)
       anorm(1, ix3(i))=anorm(1, ix3(i))+gl13(i)
       anorm(2, ix3(i))=anorm(2, ix3(i))+gl23(i)
       anorm(3, ix3(i))=anorm(3, ix3(i))+gl33(i)
       anorm(1, ix4(i))=anorm(1, ix4(i))+gl13(i)
       anorm(2, ix4(i))=anorm(2, ix4(i))+gl23(i)
       anorm(3, ix4(i))=anorm(3, ix4(i))+gl33(i)
       thnod(ix1(i))=thnod(ix1(i))+thick(i)
                                    83
```

```
thnod(ix2(i))=thnod(ix2(i))+thick(i)
        thnod(ix3(i)) = thnod(ix3(i)) + thick(i)
        thnod(ix4(i)) = thnod(ix4(i)) + thick(i)
        nth(ix1(i))=nth(ix1(i))+1
        nth(ix2(i))=nth(ix2(i))+1
       nth(ix3(i))=nth(ix3(i))+1
       nth(ix4(i))=nth(ix4(i))+1
   10 continue
c Loop through each node
      do 20 n=1,nlstm
       i=ndlist(n)
       if(nth(i).ne.0) then
c Make each normal vector a unit vector
        amag=sqrt(anorm(1,i)**2 + anorm(2,i)**2 + anorm(3,i)**2)
        if (amag.gt.0.0) then
          anorm(1,i)=anorm(1,i)/amag
          anorm(2,i) = anorm(2,i) / amag
          anorm(3,i)=anorm(3,i)/amag
        endif
   Dot product of external moment with unit normal
С
        gnorm=f(1,i)*anorm(1,i)+f(2,i)*anorm(2,i)+f(3,i)*anorm(3,i)
   Dot product of external force with unit normal
С
        fnorm=e(1,i)*anorm(1,i)+e(2,i)*anorm(2,i)+e(3,i)*anorm(3,i)
c If gnorm is nonzero, this node as been treated before
        if (abs(gnorm).lt.0.01) then
c If not zero, add h/2 * fnorm to drilling moment
         if(abs(fnorm).gt.0.0001) then
          fdrill=fnorm*0.5*thnod(i)/nth(i)
          f(1,i) = anorm(1,i) * fdrill
          f(2,i) = anorm(2,i) * fdrill
          f(3,i)=anorm(3,i)*fdrill
         endif
        endif
       endif
   20 continue
c Release Nodal Arrays
      deallocate (anorm, thnod, nth)
```

return end

```
subroutine kmfrc(e,f,qs,mte,iblks,sf1,sf2,sf3,sf4,sf5,sf6,
      1
                        ndlist, nlstm, ym, rotall, x, x0)
c '
c Calculates Hourglass force, adds to nodal forces from Kwon-McDermott
     Shell Element, and places in system force matrix
С
     (Note: sf1 through sf6 are already in global coordinates)
C
                                             McDermott 1999
\sim
          С
      implicit double precision (a-h,o-z)
     dp
      include 'nlqpar.inc'
      common/bk00/numnp,numpc,numlp,neq,ndof,nlcur,numcl,numvc,
     1 ndtpts, nelmd, nmmat, numelh, numelb, numels, numelt, numdp,
     2
        grvity, idirgv, nodspc, nspcor
      common/bk02/iburn,isdo,dt1,dt2
      common/bk12/b12.b2.aha
      common/aux01/
     &ft11(nlq),ft12(nlq),ft13(nlq),ft21(nlq),ft22(nlq),ft23(nlq),
     &fm11(nlg),fm12(nlg),fm21(nlg),fm22(nlg),
     &fm31(nlq),fm32(nlq),fm41(nlq),fm42(nlq),
     &fmr11(nlq), fmr12(nlq), fmr21(nlq), fmr22(nlq), fmr31(nlq),
     &fmr32(nlq), fmr41(nlq), fmr42(nlq), sg5(nlq), sg6(nlq)
      common/aux7/
     1 vx1(nlg), vx2(nlg), vx3(nlg), vx4(nlg),
     2 vx5(nlq),vx6(nlq),vx7(nlq),vx8(nlq),
     3 vy1(nlq),vy2(nlq),vy3(nlq),vy4(nlq),
     4 vy5(nlq),vy6(nlq),vy7(nlq),vy8(nlq),
     5 vz1(nlq), vz2(nlq), vz3(nlq), vz4(nlq),
     6 vz5(nlq), vz6(nlq), vz7(nlq), vz8(nlq)
      common/aux10/area(nlg),
     1 px1(nlq),px2(nlq),px3(nlq),px4(nlq),
     & px5(nlq),px6(nlq),px7(nlq),px8(nlq),
     2 py1(nlq), py2(nlq), py3(nlq), py4(nlq),
     & py5(nlq),py6(nlq),py7(nlq),py8(nlq),
     3 pz1(nlq),pz2(nlq),pz3(nlq),pz4(nlq),
     & pz5(nlq),pz6(nlq),pz7(nlq),pz8(nlq),
     4 dx1(nlq), dx2(nlq), dx3(nlq), dx4(nlq),
     5 dx5(nlq), dx6(nlq), dx7(nlq), dx8(nlq),
     6 dy1(nlq), dy2(nlq), dy3(nlq), dy4(nlq),
     7 dy5(nlq), dy6(nlq), dy7(nlq), dy8(nlq),
     8 dz1(nlq),dz2(nlq),dz3(nlq),dz4(nlq),
     9 dz5(nlq), dz6(nlq), dz7(nlq), dz8(nlq)
      common/aux11/
     &ft31(nlq),ft32(nlq),ft33(nlq),ft41(nlq),ft42(nlq),ft43(nlq),
     &htx(nlq),hty(nlq),gm1(nlq),gm2(nlq),gm3(nlq),gm4(nlq),
     &bsum(nlq), qhx(nlq), qhy(nlq), qwz(nlq), qtx(nlq), qty(nlq)
      common/aux13/
     &zeta(nlq),thick(nlq),fga(nlq),fgb(nlq),fgc(nlq),
     &gl11(nlq),gl12(nlq),gl13(nlq),gl21(nlq),gl22(nlq),gl23(nlq),
     &gl31(nlq),gl32(nlq),gl33(nlq),
     &x1(nlq), y1(nlq), z1(nlq), x2(nlq), y2(nlq), z2(nlq),
     &x3(nlq), y3(nlq), z3(nlq), x4(nlq), y4(nlq), z4(nlq),
     &fx1(nlq), fy1(nlq), fz1(nlq), fx2(nlq), fy2(nlq), fz2(nlq),
     &fx3(nlq), fy3(nlq), fz3(nlq), fx4(nlq), fy4(nlq), fz4(nlq),
     &xmx1(nlq),xmy1(nlq),xmz1(nlq),xmx2(nlq),xmy2(nlq),xmz2(nlq),
     &xmx3(nlq), xmy3(nlq), xmz3(nlq), xmx4(nlq), xmy4(nlq), xmz4(nlq)
      common/aux33/
     1 ix1(nlq), ix2(nlq), ix3(nlq), ix4(nlq), ixs(nlq,4), mxt(nlq)
      common/aux35/rhoa(nlq), cxx(nlq), fcl(nlq), fcg(nlq)
```

```
85
```

```
common/aux36/lft.llt
       common/aux40/
      1 x31(nlq), y31(nlq), z31(nlq), x42(nlq), y42(nlq), z42(nlq),
      2 x21(nlq), y21(nlq), z21(nlq), c1(nlq), c2(nlq), c3(nlq), x1(nlq),
       3 x41(nlq), y41(nlq), z41(nlq)
       common/hourg/ymod,gmod,ifsv
      common/sand1/ihf, ibemf, ishlf, itshf
       common/sound/sndspd, sndsp(nlq), diagm(nlq), sarea(nlq), dxl(nlq)
       common/ssbsis/h(8,5,5),pr(8,5,5),ps(8,5,5),pt(8,5,5),ipt,
      1 nip,wgts(5,5),zet(5,5)
      common/presc/voltot(nlq)
       common/failul/sieu(nlq), fail(nlq)
      logical output
      common/csforc/csdinc,csdout,output,ncs1,ncs2,ncs3,ncs4,ncs5,ncs6,
      1 ncs7, ncs8, ncs9, numcsd
      common/csfsav/savfrc(nlq,12), svfail(nlq), ndf, ifail
      common/sorter/nnc,lczc,
      & ns11,ns12,ns13,ns14,ns15,ns16,ns17,
     & nh11,nh12,nh13,nh14,nh15,nh16,nh17,
     & ntl1, ntl2, ntl3, ntl4, ntl5, ntl6, ntl7,
     & nb11, nb12, nb13, nb14; nb15, nb16, nb17
      dimension e(3,*),f(3,*),gs(9,*),iblks(*),sf1(nlg,4),sf2(nlg,4),
                   sf3(nlq,4),sf4(nlq,4),sf5(nlq,4),sf6(nlq,4),ndlist(*),
      edispg(24), eforceh(24), rotall(6,6,nlq), shape1(3), x(3,*),
      shapef(4), deriv1(2,4), derivg(3,4), deri1g(3,4), bmtx(6,24),
      bmtxt(24,6),estrain(6),estrainp(6),estress(6),estressg(6),
     5
      eforcehg(24,nlq),fm13(nlq),fm23(nlq),v1(3),v2(3),v3(3),
      fm33(nlq), fm43(nlq), aj(3,3), ajínv(3,3), hour(nlq), x0(3,*),
      edisp(24), t1(3,3), t1inv(3,3), xc(4), yc(4), zc(4), rot(6,6)
      data ngausxh, ngausyh, ngauszh /2, 2, 1/
      data sfac /0.8333333333333333333
      ifail=0
c Force use of new HG method
      hour1 = 0.5
      method = 5
      if (hourl.gt.l.e-04) then
c *** Specialized hourglass control based on Belytchko Stiffness form
   (Although slower, highly recommended for KM element)
       if (method.eq.5) then
c Parameter setup
        ngaussh=ngausxh*ngausyh*ngauszh
        if (qmod.ne.0.0) then
         pois = ymod / (2.0 * gmod) - 1.0
        else
         pois = 0.3
         gmod = ymod / 2.6
        endif
        front = ymod / (1.0 - pois**2)
```

c Begin Element Loop

do 900 ie=lft,llt

hour(ie) = hour1 \* thick(ie)\*\*2 / area(ie)

c Retreive coordinates

xc(1)=x0(1,ix1(ie))
yc(1)=x0(2,ix1(ie))
zc(1)=x0(3,ix1(ie))
xc(2)=x0(1,ix2(ie))
yc(2)=x0(2,ix2(ie))
zc(2)=x0(3,ix2(ie))
xc(3)=x0(1,ix3(ie))
yc(3)=x0(2,ix3(ie))
zc(3)=x0(3,ix3(ie))
xc(4)=x0(1,ix4(ie))
yc(4)=x0(2,ix4(ie))
zc(4)=x0(3,ix4(ie))

c Retrieve displacments

edispg(1) = x(1, ix1(ie))-xc(1) edispg(2) = x(2, ix1(ie))-yc(1) edispg(3) = x(3, ix1(ie))-zc(1) edispg(7) = x(1, ix2(ie))-xc(2) edispg(8) = x(2, ix2(ie))-yc(2) edispg(9) = x(3, ix2(ie))-zc(2) edispg(13) = x(1, ix3(ie))-zc(3) edispg(14) = x(2, ix3(ie))-yc(3) edispg(15) = x(3, ix3(ie))-zc(3) edispg(19) = x(1, ix4(ie))-xc(4) edispg(20) = x(2, ix4(ie))-yc(4) edispg(21) = x(3, ix4(ie))-zc(4)

c Retreive Rotations (Assumes all initial rotations are zero)
 edispg(4) = x(1,numnp+ix1(ie))

edispg(1) = x(1,nump+ix1(ie)) edispg(5) = x(2,numnp+ix1(ie)) edispg(6) = x(3,numnp+ix1(ie)) edispg(10) = x(1,numnp+ix2(ie)) edispg(11) = x(2,numnp+ix2(ie)) edispg(12) = x(3,numnp+ix3(ie)) edispg(16) = x(1,numnp+ix3(ie)) edispg(18) = x(3,numnp+ix3(ie)) edispg(22) = x(1,numnp+ix4(ie)) edispg(23) = x(2,numnp+ix4(ie))

c Create Transformation Matrix and get inverse

t1(1,1)=gl11(ie)
t1(2,1)=gl21(ie)
t1(3,1)=gl31(ie)
t1(1,2)=gl12(ie)
t1(2,2)=gl22(ie)
t1(3,2)=gl32(ie)
t1(1,3)=gl13(ie)
t1(2,3)=gl23(ie)
t1(3,3)=gl33(ie)

call kminv3(t1,t1inv,det)

c Rotate displacements to local coordinate system

```
do 950 i=1,4
           do 950 j=1,3
              edisp((i-1)*6+j)=edispg((i-1)*6+j)
              edisp((i-1)*6+3+j)=(edispg((i-1)*6+4)*tlinv(j,1) +
       1
                    edispg((i-1)*6+5)*tlinv(j,2) +
       2
                    edispg((i-1)*6+6)*tlinv(j,3))
  950
          continue
c Rename Direction Vectors to allow simple porting of previously
       written code
C
          v1(1) = gl11(ie)
v1(2) = gl21(ie)
          v1(3) = g131(ie)
          v2(1) = gl12(ie)
          v2(2) = gl22(ie)
          v2(3) = g132(ie)
          v3(1) = gl13(ie)
          v3(2) = g123(ie)
          v3(3) = g133(ie)
         hzdt=thick(ie)*0.5
c Initialize Hourglass force vector
          do 901 i=1,24
  901
           eforceh(i) = 0.0
c *** Integration Loop
         do 910 ix=1,ngausxh
           rc=zet(ix,ngausxh)
           wx=wgts(ix,ngausxh)
           do 910 iy=1,ngausyh
            sc=zet(iv,ngausyh)
            wy=wgts(iy,ngausyh)
            do 910 iz=1,ngauszh
             tc=zet(iz,ngauszh)
               wz=wgts(iz,ngauszh)
c 1-D Shape Function
               call kmshap(tc,shape1)
c 2-D Shape Functions
               shapef(1)=0.25*(1.0-rc)*(1.0-sc)
               shapef(2)=0.25*(1.0+rc)*(1.0-sc)
               shapef(3) = 0.25*(1.0+rc)*(1.0+sc)
               shapef(4)=0.25*(1.0-rc)*(1.0+sc)
c 2-D Shape Function Derivatives
              derivl(1,1) = -0.25*(1.0-sc)
               derivl(1,2) = 0.25*(1.0-sc)
               derivl(1,3) = 0.25*(1.0+sc)
              derivl(1, 4) = -0.25*(1.0+sc)
               deriv1(2,1) = -0.25*(1.0-rc)
               derivl(2,2) = -0.25*(1.0+rc)
              deriv1(2,3)=0.25*(1.0+rc)
              deriv1(2, 4) = 0.25*(1.0-rc)
c Compute jacobian matrix and its inverse
              hz=thick(ie)*0.5*(shape1(2)-shape1(1))
      a_1(1,1) = derivl(1,1) * xc(1) + derivl(1,2) * xc(2) + derivl(1,3) * xc(3) +
```

```
. 88
```

1 derivl(1,4)\*xc(4)+derivl(1,1)\*hz\*v3(1)+ 2 deriv1(1,2)\*hz\*v3(1)+deriv1(1,3)\*hz\*v3(1)+ deriv1(1,4)\*hz\*v3(1) 3 aj(2,1)=derivl(2,1)\*xc(1)+derivl(2,2)\*xc(2)+derivl(2,3)\*xc(3)+ 1 derivl(2,4) \*xc(4) + derivl(2,1) \* hz\*v3(1) +2 deriv1(2,2)\*hz\*v3(1)+deriv1(2,3)\*hz\*v3(1)+ 3 deriv1(2,4)\*hz\*v3(1) aj(3,1) = hzdt \* v3(1)aj(1,2)=derivl(1,1)\*yc(1)+derivl(1,2)\*yc(2)+derivl(1,3)\*yc(3)+ 1 derivl(1,4)\*yc(4)+derivl(1,1)\*hz\*v3(2)+ 2 derivl(1,2)\*hz\*v3(2)+derivl(1,3)\*hz\*v3(2)+ 3 deriv1(1,4)\*hz\*v3(2) aj(2,2) = derivl(2,1) \* yc(1) + derivl(2,2) \* yc(2) + derivl(2,3) \* yc(3) +deriv1(2,4)\*yc(4)+deriv1(2,1)\*hz\*v3(2)+ 1 deriv1(2,2)\*hz\*v3(2)+deriv1(2,3)\*hz\*v3(2)+ 2 3 deriv1(2,4)\*hz\*v3(2) aj(3,2) = hzdt \* v3(2)a; (1,3)=derivl(1,1)\*zc(1)+derivl(1,2)\*zc(2)+derivl(1,3)\*zc(3)+ derivl(1, 4) \* zc(4) + derivl(1, 1) \* hz \* v3(3) +1 derivl(1,2)\*hz\*v3(3)+derivl(1,3)\*hz\*v3(3)+ 2 3 derivl(1,4)\*hz\*v3(3) aj(2,3)=derivl(2,1)\*zc(1)+derivl(2,2)\*zc(2)+derivl(2,3)\*zc(3)+ derivl(2,4)\*zc(4)+derivl(2,1)\*hz\*v3(3)+1 derivl(2,2)\*hz\*v3(3)+derivl(2,3)\*hz\*v3(3)+ 2 3 deriv1(2,4)\*hz\*v3(3) aj(3,3) = hzdt \* v3(3)С call kminv3 (aj,ajinv,det) detwt = det \* wx \* wy \* wz c Compute global derivatives and strain-nodal displacement matrix do 902 i=1,4 derivg(1,i)=ajinv(1,1)\*derivl(1,i)+ajinv(1,2)\*derivl(2,i) derivg(2,i)=ajinv(2,1)\*derivl(1,i)+ajinv(2,2)\*derivl(2,i) derivg(3,i)=ajinv(3,1)\*derivl(1,i)+ajinv(3,2)\*derivl(2,i) derilg(1,i)=ajinv(1,3)\*hzdt derilg(2,i)=ajinv(2,3)\*hzdt derilg(3,i)=ajinv(3,3)\*hzdt 902 continue do 903 i=1,6 do 903 j=1,24 bmtx(i,j)=0.0903 continue do 904 i=1,4 i1=(i-1)\*6+1i2=i1+1 i3=i2+1 i4=i3+1 i5=i4+1 i6=i5+1 gkl=derivg(1,i)\*hz+shapef(i)\*derilg(1,i) gk2=derivg(2,i)\*hz+shapef(i)\*derilg(2,i) gk3=derivg(3,i)\*hz+shapef(i)\*derilg(3,i) C C bmtx(1,i1) = derivg(1,i)bmtx(1, i4) = gk1\*(-v2(1))bmtx(1,i5)=gk1\*v1(1) bmtx(1, i6) = gk1\*v3(1)89

bmtx(2,i2) = derivg(2,i)bmtx(2, i4) = qk2\*(-v2(2))bmtx(2, i5) = gk2\*v1(2)bmtx(2, i6) = qk2\*v3(2)bmtx(3,i3) = derivg(3,i)bmtx(3, i4) = gk3\*(-v2(3))bmtx(3, i5) = qk3\*v1(3)bmtx(3, i6) = gk3\*v3(3)bmtx(4,i1) = derivg(2,i)bmtx(4,i2) = derivg(1,i)bmtx(4, i4) = gk2\*(-v2(1))+gk1\*(-v2(2))bmtx(4, i5) = gk2\*v1(1)+gk1\*v1(2)bmtx(4, i6) = gk2\*v3(1)+gk1\*v3(2)bmtx(5,i2) = derivg(3,i)bmtx(5,i3) = derivg(2,i)bmtx(5, i4) = gk3\*(-v2(2)) + gk2\*(-v2(3))bmtx(5, i5) = qk3\*v1(2) + qk2\*v1(3)bmtx(5, i6) = qk3\*v3(2) + qk2\*v3(3)bmtx(6,i1) = deriva(3,i)bmtx(6,i3) = derivg(1,i)bmtx(6, i4) = gk3\*(-v2(1))+gk1\*(-v2(3))bmtx(6, i5) = gk3\*v1(1)+gk1\*v1(3)bmtx(6, i6) = qk3\*v3(1) + qk1\*v3(3)904 continue do 905 i=1,6 do 905 j=1,24 905 bmtxt(j,i)=bmtx(i,j) c Calculate strain do 906 i=1,6 estrainp(i)=0.0 do 906 j=1,24 estrainp(i)=estrainp(i)+bmtx(i,j)\*edisp(j) 906 continue do 920 i=1,6 do 920 j=1,6 rot(i,j)=rotall(i,j,ie) 920 continue c Transform strain to local coordinates system do 907 i=1,6 estrain(i)=0.0do 907 j=1,6 estrain(i)=estrain(i)+rot(i,j)\*estrainp(i) 907 continue c Calculate stress using plane-strain formulas estress(1) = front\*(estrain(1) + pois\*estrain(2)) estress(2) = front\*(pois\*estrain(1) + estrain(2)) estress(3) = ymod \* estrain(3)estress(4) = gmod \* estrain(4)estress(5) = sfac \* gmod \* estrain(5)estress(6) = sfac \* gmod \* estrain(6) c Rotate stresses to global coordinates do 908 i=1,6 estressg(i)=0.0do 908 j=1,6

908 estressg(i) = estressg(i) + rot(j, i) \* estress(j) c Find eforceh for this gauss point and sum to element force do 909 i=1,24 do 909 j=1,6 909 eforceh(i)=eforceh(i)+bmtxt(i,j)\*estressg(j)\*detwt c \*\*\* End of Integration Loop continue 910 c Store force into HG Variables ft11(ie)=eforceh(1) ft12(ie) = eforceh(2)ft13(ie)=eforceh(3) fml1(ie)=eforceh(4) fm12(ie)=eforceh(5) fm13(ie)=eforceh(6) ft21(ie)=eforceh(7) ft22(ie) = eforceh(8)ft23(ie)=eforceh(9) fm21(ie) =eforceh(10) fm22(ie) =eforceh(11) fm23(ie) = eforceh(12) ft31(ie)=eforceh(13) ft32(ie) = eforceh(14) $ft33(ie) \approx eforceh(15)$ fm31(ie)=eforceh(16) fm32(ie) = eforceh(17)fm33(ie) =eforceh(18) ft41(ie)=eforceh(19) ft42(ie)=eforceh(20)  $ft43(ie) \approx eforceh(21)$ fm41(ie)=eforceh(22) fm42(ie)=eforceh(23) fm43(ie) = eforceh(24)c \*\*\* End of Element Loop 900 continue c Other methods else do 200 i=lft,llt fm13(i)=0.0fm23(i)=0.0 fm33(i)=0.0 fm43(i) = 0.0200 continue c Traditional Hour Glass Force Calculation tmode=qhg\*ymod/1920.0 wmode=qhg\*gmod/120.00 xmmode=qhg\*ymod/80.000 do 10 i=lft,llt x2(i) = gl11(i) \* x21(i) + gl21(i) \* y21(i) + gl31(i) \* z21(i)y2(i) =gl12(i)\*x21(i) +gl22(i)\*y21(i) +gl32(i)\*z21(i) x3(i) =gl11(i)\*x31(i) +gl21(i)\*y31(i) +gl31(i)\*z31(i) y3(i) =gl12(i)\*x31(i) +gl22(i)\*y31(i) +gl32(i)\*z31(i) x4(i) =gl11(i)\*x41(i) +gl21(i)\*y41(i) +gl31(i)\*z41(i) y4(i) =gl12(i)\*x41(i) +gl22(i)\*y41(i) +gl32(i)\*z41(i) htx(i) = area(i) \* (x3(i) - x2(i) - x4(i))hty(i) = area(i) \* (y3(i) - y2(i) - y4(i))91

```
gml(i) = 1.-pxl(i) *htx(i) -pyl(i) *hty(i)
       gm2(i)=-1.-px2(i)*htx(i)-py2(i)*hty(i)
       qm3(i) = 2.-qm1(i)
       gm4(i) = -2.-gm2(i)
10
      continue
      if (ifsv.eq.3) then
       do 20 i=lft,llt
        bsum(i) =2.*(px1(i)**2+px2(i)**2+py1(i)**2+py2(i)**2)
        xl(i) = area(i) * bsum(i) * thick(i)
        cl(i)=xl(i)*thick(i)**2
        c2(i) = wmode * c1(i) * area(i)
        c3(i)=xmmode*xl(i)
        c1(i) = tmode * c1(i)
20
       continue
      else
       hgfac=qhg*rhoa(lft)*sndspd/(dt1+1.e-20)
       do 30 i=lft,llt
        c3(i)=hgfac*sqrt(sarea(i))*thick(i)
        c2(i)=c3(i)
        c1(i)=.05*c3(i)*thick(i)
30
     continue
     endif
     do 40 i=lft,llt
      qhx(i) = qm1(i) * vx1(i) + qm2(i) * vx2(i) + qm3(i) * vx3(i) + qm4(i) * vx4(i)
      qhy(i)=gml(i)*vyl(i)+gm2(i)*vy2(i)+gm3(i)*vy3(i)+gm4(i)*vy4(i)
      qwz(i) = qm1(i) * vz1(i) + qm2(i) * vz2(i) + qm3(i) * vz3(i) + qm4(i) * vz4(i)
      qtx(i) =qm1(i) *vx5(i) +qm2(i) *vx6(i) +qm3(i) *vx7(i) +qm4(i) *vx8(i)
      qty(i) = qm1(i) *vy5(i) + qm2(i) *vy6(i) + qm3(i) *vy7(i) + qm4(i) *vy8(i)
40
     continue
     if (ifsv.ne.3) then
      do 50 i=lft,llt
       qs(1,i)=0.
       qs(2,i)=0.
       qs(3,i)=0.
       qs(4,i)=0.
       qs(5,i)=0.
50
      continue
     endif
     do 60 i=lft,llt
      qs(1,i) = qs(1,i) + c3(i) * qhx(i)
      qs(2,i) = qs(2,i) + c3(i) * qhy(i)
      qs(3,i)=qs(3,i)+c2(i)*qwz(i)
      qs(4,i)=qs(4,i)+cl(i)*qtx(i)
      qs(5,i)=qs(5,i)+c1(i)*qty(i)
      ft31(i)=gm3(i)*qs(1,i)
      ft32(i)=gm3(i)*qs(2,i)
      ft33(i)=gm3(i)*qs(3,i)
      ft41(i)=gm4(i)*qs(1,i)
      ft42(i) = qm4(i) * qs(2,i)
      ft43(i)=gm4(i)*qs(3,i)
      ftll(i)=gml(i)*qs(1,i)
      ft12(i)=qm1(i)*qs(2,i)
      ft13(i)=gm1(i)*qs(3,i)
      ft21(i)=gm2(i)*qs(1,i)
      ft22(i) = qm2(i) * qs(2,i)
      ft23(i) = gm2(i) * qs(3,i)
      fmll(i) = gml(i) * qs(4, i)
      fm12(i)=gm1(i)*qs(5,i)
      fm21(i)=gm2(i)*qs(4,i)
      fm22(i)=gm2(i)*qs(5,i)
```

	fm31(i)=gm3(i)*qs(4,i)
	fm32(i)=gm3(i)*qs(5,i)
	fm41(i)=gm4(i)*qs(4,i)
	fm42(i)=gm4(i)*qs(5,i)
60	continue
	endif
	else

***	No Hourglass Control do 70 i=lft,llt ft31(i)=0.0
	ft32(i)=0.0
	ft33(i)=0.0
	ft41(i)=0.0
	ft42(1)=0.0
	ft43(1)=0.0
	ft[1](1)=0.0
	IT12(1)=0.0
	f(1) = 0.0
	f = 22(i) = 0.0
	f+23(i)=0.0
	fm11(i) = 0.0
	fm12(i) = 0.0
	fm13(i) = 0.0
	fm21(i) = 0.0
	fm22(i)=0.0
	fm23(i) = 0.0
	fm31(i) = 0.0
	fm32(i) = 0.0
	fm33(i)=0.0
	fm41(i) = 0.0
	fm42(1)=0.0
70	IM43(1)=0.0
70	endif
	CUMTT

с

c Total Element forces on its nodes if (method.ne.5) then

	- (		,		-															
c	08 ot	i=lft	: <b>,ll</b> t	2																
	fx1(:	i)=gl1	1(i)	*ft]	L1(i)	+gl1	.2(i	)*f	t12	(i)	+gl	13(	i)*	ft1	.3(:	i)+	sf1	(i,	1)	
	fy1(:	i)=gl2	21(i)	*ft]	L1(i)	+g12	2(i	)*f	t12	(i)	+gl	23(	i)*	ft1	.3 (:	i)+	sf2	(i,	1)	
	fz1(:	i)=gl3	31(i)	*ft]	(1)	+g13	32(i	)*f	t12	(i)	+gl	33 (	i)*	ft1	.3(:	i)+	sf3	(i,	1)	
	fx2(:	i)=q11	1(i)	*ft2	21(i)	+g11	.2(i	)*f	t22	(i)	+gl	13(	i)*	ft2	23(:	i)+	sf1	(i,	2)	
	fy2(:	i)=gl2	21(i)	*ft2	21(i)	+g12	22(i	)*f	t22	(i)	+gl	23 (	i)*	ft2	23(:	i)+	sf2	(i,	2)	
	fz2(:	i)=q13	31(i)	*ft2	21(i)	+g13	32(i	)*f	t22	(i)	+gl	33 (	i)*	ft2	23 (:	i)+	sf3	(i,	2)	
	fx3(:	i)=ql]	l1(i)	*ft3	31(i)	+g11	.2(i	)*f	t32	(i)	+gl	13 (	i)*	ft3	33 (:	i)+	sf1	(i,	3)	
	fy3(:	i)=ql2	21(i)	*ft3	31(i)	+g12	22(i	)*f	t32	(i)	+gl	23(	i)*	ft3	33(:	i)+	sf2	(i,	3)	
	fz3(:	i)=ql3	31(i)	*ft3	31(i)	+g13	32(i	)*f	t32	(i)	+gl	33 (	i)*	ft3	33(:	i)+	sf3	(i,	3)	
	fx4(:	i)=ql1	1(i)	*ft4	11(i)	+g11	.2(i	)*f	t42	(i)	+gl	13(	i)*	ft4	13 (:	i)+	sf1	(i,	4)	
	fv4(:	i)=ql2	21(i)	*ft4	11(i)	+g12	22(i	)*f	t42	(i)	+g1	23(	i)*	ft4	13 (:	i)+	sf2	(i,	4)	
	fz4(:	i)=q13	31(i)	*ft4	11(i)	+g13	32 (i	)*f	t42	(i)	+gl	33 (	i)*	ft4	13 (:	i)+	sf3	(i,	4)	
	xmxl	(i)=q]	.11(j	L)*fn	n11(i	)+q]	.12(	i)*	fm1:	2(i	.)+q	113	(i)	*fn	113	(i)	+sf	4(i	,1)	ł
	xmv1	(i)=q]	21 (j	L)*fn	all(i	)+q]	.22 (	i)*	fm1:	2 (i	)+q	123	(i)	*fn	n13	(i)	+sf	5(i	,1)	l
	xmz1	(i)=q]	.31 (j	L)*fn	n11(i	)+q]	.32 (	i)*	fm1:	2(i	)+q	133	(i)	*fn	n13	(i)	+sf	6(i	,1)	į
	xmx2	(i)=a]	11 (j	)*fn	n21(j	.)+q]	.12 (	i)*	fm2	2(i	)+q	113	(i)	*fn	123	(i)	+sf	4(i	,2)	ł
	xmy2	(i)=g]	21 (j	i)*fn	n21(j	)+q]	.22 (	i)*	fm2	2(i	)+g	123	(i)	*fn	123	(i)	+sf	5(i	,2)	Į
	xmz2	(i)=q]	131 (j	L)*fn	n21(j	)+q]	.32 (	i)*	fm2	2(i	)+q	133	(i)	*fn	123	(i)	+sf	6(i	,2)	ł
	xmx3	(i)=a]	11 (j	)*fn	131 (i	.)+q]	12 (	i)*	fm3	2 (i	)+q	113	(i)	*fn	133	(i)	+sf	4 (i	,3)	ļ
	xmy3	(i)=q]	121 (j	L)*fn	n31(i	.)+g]	.22 (	i)*	fm3	2(i	)+g	123	(i)	*fn	133	(i)	+sf	5(i	,3)	ł
				-							_									

	•									
	xmz3(i) = a131(i) * fm31(i) + a132(i) * fm32(i) + a1	1330	i)	*fm3	31	i)-	tsfe	5(i.	31	
	Am20(1) gi01(1) $Im01(1)$ gi02(1) $Im02(1)$ gi	2 1 2 1	÷.	A	5	- /				
•	$xmx4(1) = g_{111}(1) \wedge im41(1) + g_{112}(1) \wedge im42(1) + g_{113}(1)$	ттэ (	1)	^IM4	5(.	1)-	FSI4	±(Ι,	4)	
	xmy4(i)=gl21(i)*fm41(i)+gl22(i)*fm42(i)+gl	123(	i)	*fm4	3(:	i)+	⊦sf5	5(i,	4)	
	$\sqrt{\pi \alpha}$ $\sqrt{1} = \alpha$ $\sqrt{1}$ $\sqrt{1} + \frac{1}{2}$ $\sqrt{1} + \frac{1}$	1 3 3 /		* fm 4	31.	÷،	refé	5/3	11	
	$\operatorname{Am}_{2}(1) - \operatorname{Grot}(1) - \operatorname{Im}_{1}(1) \cdot \operatorname{Groz}(1) - \operatorname{Im}_{2}(1) \cdot \operatorname{Grot}(1)$	100	- /	T10.2	51.	- / ·	( BT C	· ( ± )	=/	
· 80	continue									· ·
	else	2.1								
	$d_{0}$ $100$ $i-1f+11+$									
	ao 400 = 110, 110		14							
	fx1(i)=glll(i)*ftll(i)+gll2(i)*ftl2(i)+gll	13(i	.)*:	Ęt13	(i)	)				
	$f_{v1}(i) = \alpha (21) (i) * f + (11) (i) + \alpha (22) (i) * f + (2) (i) + \alpha (2)$	23(i	1*.	f+13	(i)	)		•		
	$= \frac{1}{2} $		· · ·	6117	( + )	( \				
	$IZI(1) = gISI(1) \land ICII(1) + gIS2(1) \land ICI2(1) + gIS$	53(I	)^.	CT T 3	(1)	/				
	fx2(i)=ql11(i)*ft21(i)+ql12(i)*ft22(i)+ql1	l3(i	)*:	Et23	(i)	)				
	$f_{32}(i) = \alpha (2) (i) + f_{12}(i) + \alpha (2) (i) + f_{12}(i) + \alpha (2) (i) + \alpha (2$	23/1	1 * 1	F+23	(1)	<b>`</b>				
	$= \frac{1}{2} \sum_{i=1}^{2} $		/ · · ·			Į.				
	$fz_2(1) = g_1_3_1(1) * fz_2_1(1) + g_1_3_2(1) * fz_2_2(1) + g_1_3_2(1)$	1) 23	) ^ ]	ETZ3	(1)	)	24			
	fx3(i) = al11(i) * ft31(i) + al12(i) * ft32(i) + al1	L3(i	)*1	Et33	(i)	) .			· .	
	$f_{v,3}(i) = \alpha (i) + (i) + f_{v,3}(i) + \alpha (2) (i) + f_{v,3}(i) + \alpha (2) (i) +$	2211	\ * 1	F+ 33	133					
	$\frac{1}{2} \int \frac{1}{2} \int \frac{1}$		/		(+)					
	$fz_3(1) = g_1_3_1(1) * ft_3_1(1) + g_1_3_2(1) * ft_3_2(1) + g_1_3$	33(1	)*1	Et 33	(1)					
	fx4(i)=al11(i)*ft41(i)+al12(i)*ft42(i)+al1	L3(i	)*1	Et43	(i)	1.1				
	$f_{11}(1) = \alpha (2) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1$	211	, / * f	=+13	1:1			, ·		·
	$1y^{4}(1) - g_{121}(1) + 1(41(1) + g_{122}(1) + 1(42(1) + g_{12})$	- J ( I	1 4		$(\pm)$		•			
	fz4(i)=g131(i)*ft41(i)+g132(i)*ft42(i)+g13	33(1	)*1	:t43	(1)			2 Î.		
	$xmx1(i) = \alpha 111(i) * fm11(i) + \alpha 112(i) * fm12(i) + \alpha 12(i)$	13(	i)*	fm1	3(i	)				
	(1/2) = (1/2	22/		- ž	$\frac{1}{2}$				1. N.	1
	$xmy1(1) = g121(1) \wedge Im11(1) + g122(1) \wedge Im12(1) + g1$	.23(	τ),	TUUT	2(1	-)				
	<pre>xmz1(i)=gl31(i)*fm11(i)+gl32(i)*fm12(i)+gl</pre>	.33(	i)*	fm1	3(i	.)	1			
	$vmv2(i) = \alpha [11(i) * fm21(i) + \alpha [12(i) * fm22(i) + \alpha]$	131	i i x	fm2	3/1	1				
	$\operatorname{AmAZ}(1)$ , $\operatorname{gill}(1)$ , $\operatorname{ImZI}(1)$ , $\operatorname{gill}(2)$ , $\operatorname{ImZI}(1)$ , $\operatorname{gill}(2)$ , $\operatorname{ImZI}(1)$ , $\operatorname{gill}(2)$ , $\operatorname{gill}(2)$ , $\operatorname{ImZI}(1)$ ,			£	$\frac{1}{2}$	- (			÷.,	
	xmy2(1) = g121(1) * Im21(1) + g122(1) * Im22(1) + g1	.23 (	1)^	IMZ.	3(1	-)			÷.,	
	<pre>xmz2(i)=gl31(i)*fm21(i)+gl32(i)*fm22(i)+gl</pre>	.33 (	i)*	fm2	3(i	.)			-	5 A.
	$xmx3(i) = \alpha [11(i) * fm31(i) + \alpha [12(i) * fm32(i) + \alpha ]$	13(	i).*	fm3	3(i	)	1.11			e er j
	$rmr(2(i) - \alpha (2)) + fm (2) (i) + \alpha (2) ($	231	-, ; \ *	fm 2	2/4	- /				
	$x_{my}(\tau) = g_{12}\tau(\tau) + f_{m3}\tau(\tau) + g_{12}\tau(\tau) + f_{m3}\tau(\tau) + g_{12}\tau(\tau)$	.23(	<u>т)</u>	TIII S	$\mathcal{L}$	-!				
	xmz3(1) = g131(1) * im31(1) + g132(1) * im32(1) + g1	.33()	ı)*	1m.3.	3(1	.)				
	<pre>xmx4(i)=gl11(i)*fm41(i)+gl12(i)*fm42(i)+gl</pre>	.13(:	i)*	fm4	3(i	.)				
	$xmv4(i) = \sigma 121(i) * fm41(i) + \sigma 122(i) * fm42(i) + \sigma 1$	23(	i)*	fm4	3(i	)				
	$m_{f}(2) = (2) = (2) (2) (2) (2) (2) (2) (2) (2) (2) (2)$		- / .			- /		1.1		
		221	÷ \ *	fm 1	2/4	A				
	$x m 24 (1) = g 1 51 (1) ^{1} m 41 (1) + g 1 52 (1) ^{1} m 42 (1) + g 1$	.33 (	i)*	fm4	3(i	.)		· · ·		
400	continue	.33 (1	i)*	fm4	3(i	.)				
400	<pre>xm24(1)=g151(1) *1m41(1)+g152(1) *1m42(1)+g1 continue do 405 i=lft,llt</pre>	.33 ( :	i)*	fm4.	3(i	.)				
400	<pre>xm24(1)=g151(1)*1m41(1)+g152(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1))</pre>	.33 (	i)*	fm4.	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fx1(i)=sf2(i,1)+hour(i)*(fx1(i)-sf2(i,1))</pre>	.33 (	i)*	fm4.	3(i	.)	دو - 			
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1))</pre>	.33 (	i)*	fm4.	3(i	.)	• • •			
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1))</pre>	.33 (	i)*	fm4:	3(i	.)	•• •• ••			
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2))</pre>	.33 (	i)*	fm4.	3(i	.)	•			
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2))</pre>	.33 (	i)*	fm4	3(i	.)			- - - - - - -	
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2))</pre>	.33 (	i)*	fm4	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fz2(i)-sf3(i,2))</pre>	.33 (	i)*	fm4.	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3))</pre>	.33 (:	i)*	fm4:	3(i	.)	•			
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3))</pre>	.33 (:	i)*	fm4:	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3))</pre>	.33 (:	i)*	fm4:	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fz3(i)-sf3(i,3))</pre>	.33 (:	i)*	fm4:	3(i	•)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf3(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4))</pre>	.33 ( :	i)*	fm4:	3(i	•••••••••••••••••••••••••••••••••••••••				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fx4(i)-sf1(i,4)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf2(i,4))</pre>	.33 ( :	i)*	fm4:	3(i	•••••••••••••••••••••••••••••••••••••••				· · · · · · · · · · · · · · · · · · ·
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf3(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4))</pre>	.33 (	<b>i)</b> *	fm4	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf3(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4))</pre>	.33 (	<b>i)</b> *	fm4.	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1))</pre>	.33 (:	<b>i)</b> *	fm4:	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf3(i,3)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf5(i,1))</pre>	.33 (:	<b>i)</b> *	fm4:	3(i	.)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf1(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmy1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf6(i,1))</pre>	.33 ( :	<b>i)</b> *	fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fy2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf5(i,1)) xmz1(i)=sf6(i,1)+hour(i)*(xmz1(i)-sf6(i,1))</pre>	33(.	<b>i)</b> *	fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf6(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmx2(i)=sf4(i,2)+hour(i)*(xmx2(i)-sf4(i,2))</pre>	33(.	<b>i)</b> *	fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmx2(i)=sf4(i,2)+hour(i)*(xmx2(i)-sf4(i,2)) xmy2(i)=sf5(i,2)+hour(i)*(xmy2(i)-sf5(i,2))</pre>	33(. , ) ) )	i)*	fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf5(i,1)) xmy2(i)=sf5(i,2)+hour(i)*(xmy2(i)-sf5(i,2))</pre>	33(.	i)*	fm4:	3 (i	-)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf3(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf4(i,2)) xmx2(i)=sf4(i,2)+hour(i)*(xmy2(i)-sf5(i,2)) xmz2(i)=sf6(i,2)+hour(i)*(xmz2(i)-sf6(i,2)) xmz2(i)=sf2(i,2)+hour(i)*(xmz2(i)-sf6(i,2)) xmz2(i)=sf2(i,2)+hour(i)*(xmz2(i)-sf6(i,2)) xmz2(i)=sf2(i,2)+hour(i)*(xmz2(i)-sf6(i,2)) xmz2(i)=sf2(i,</pre>	33(.	i)*	fm4:	3 (i	-)				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf5(i,1)) xmx2(i)=sf4(i,2)+hour(i)*(xmy2(i)-sf4(i,2)) xmy2(i)=sf6(i,2)+hour(i)*(xmy2(i)-sf6(i,2)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3))</pre>	33(.	<b>i</b> ) *	fm4:	3 (i	• )				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf5(i,1)) xmz1(i)=sf4(i,2)+hour(i)*(xmy2(i)-sf4(i,2)) xmy2(i)=sf5(i,2)+hour(i)*(xmy2(i)-sf4(i,2)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmy3(i)-sf4(i,3))</pre>	33(. )) ) ) ) )	<b>i</b> )*	fm4:	3 (i	• )				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fy4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmy1(i)-sf3(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf4(i,1)) xmy2(i)=sf5(i,2)+hour(i)*(xmy2(i)-sf4(i,2)) xmx2(i)=sf4(i,3)+hour(i)*(xmy2(i)-sf4(i,2)) xmx3(i)=sf4(i,3)+hour(i)*(xmy3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmy3(i)-sf5(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmy3(i)-sf6(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmy3(i)-sf6(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmy3(i)-sf6(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmy3(i)-sf6(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmy3(i)-sf6(i,3))</pre>	33(. )) )) )) )) ))	<b>i</b> ) *	fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fz1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmy1(i)-sf5(i,1)) xmx2(i)=sf4(i,2)+hour(i)*(xmy2(i)-sf4(i,2)) xmz2(i)=sf6(i,2)+hour(i)*(xmx2(i)-sf4(i,2)) xmz3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmz3(i)=sf6(i,3)+hour(i)*(xmz3(i)-sf6(i,3)) xmz3(i)=sf6(i,3)</pre>	33(.	<b>i</b> ) *	fm4:	3 (1	• • • • • • • • • • • • • • • • • • • •				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fy2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(xmx1(i)-sf4(i,1)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmx1(i)=sf6(i,1)+hour(i)*(xmx1(i)-sf6(i,1)) xmx2(i)=sf5(i,2)+hour(i)*(xmx2(i)-sf6(i,2)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf4(i,4)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf4(i,4)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf4(i,4)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf4(i,4)+hour(i)*(xmx3(i)-sf4(i,4)) xmx4(i)=sf4(i,4)+hour(i)*(xmx4(i)-sf4(i,4))</pre>	33(.	<b>i</b> ) *	fm4:	3 (i	• • • • • • • • • • • • • • • • • • • •				
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf3(i,1)) fx2(i)=sf1(i,2)+hour(i)*(fy2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf3(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fy4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf4(i,2)) xmx2(i)=sf4(i,2)+hour(i)*(xmx2(i)-sf4(i,2)) xmx2(i)=sf6(i,2)+hour(i)*(xmx2(i)-sf6(i,2)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx4(i)=sf4(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmy4(i)=sf5(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmy4(i)=sf5(i,4)+hour(i)*(xmy4(i)-sf5(i,4))</pre>	33(.	<b>i</b> ) *	fm4:						
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,1)+hour(i)*(fy1(i)-sf2(i,2)) fx2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf4(i,2)) xmx2(i)=sf4(i,2)+hour(i)*(xmx2(i)-sf4(i,2)) xmx2(i)=sf6(i,2)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)</pre>	33(.		fm4:	3 (i					
400	<pre>xm24(1)=g131(1)*1m41(1)+g132(1)*1m42(1)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fy1(i)-sf2(i,1)) fz1(i)=sf3(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fy2(i)-sf2(i,2)) fz2(i)=sf3(i,2)+hour(i)*(fy3(i)-sf1(i,3)) fy3(i)=sf1(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fy3(i)-sf2(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fy4(i)-sf2(i,4)) fz4(i)=sf3(i,4)+hour(i)*(fx1(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmx1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf6(i,1)) xmx2(i)=sf6(i,2)+hour(i)*(xmz2(i)-sf6(i,2)) xmz2(i)=sf6(i,2)+hour(i)*(xmz3(i)-sf4(i,3)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,3)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,3)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(</pre>	33(.	<b>i</b> ) *	fm4:	3(1	• • • • • • • • • • • • • • • • • • • •				
400	<pre>xm24(i)=g131(i)*1m41(i)+g132(i)*1m42(i)+g1 continue do 405 i=lft,llt fx1(i)=sf1(i,1)+hour(i)*(fx1(i)-sf1(i,1)) fy1(i)=sf2(i,1)+hour(i)*(fx1(i)-sf2(i,1)) fz2(i)=sf1(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fy2(i)=sf2(i,2)+hour(i)*(fx2(i)-sf1(i,2)) fx3(i)=sf1(i,3)+hour(i)*(fx3(i)-sf1(i,3)) fy3(i)=sf2(i,3)+hour(i)*(fx3(i)-sf2(i,3)) fz3(i)=sf3(i,3)+hour(i)*(fx3(i)-sf3(i,3)) fx4(i)=sf1(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fx4(i)-sf1(i,4)) fy4(i)=sf2(i,4)+hour(i)*(fx4(i)-sf3(i,4)) xmx1(i)=sf4(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmy1(i)=sf5(i,1)+hour(i)*(xmx1(i)-sf4(i,1)) xmx2(i)=sf6(i,2)+hour(i)*(xm2(i)-sf5(i,2)) xmz2(i)=sf6(i,2)+hour(i)*(xm3(i)-sf4(i,3)) xmx3(i)=sf4(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf5(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf4(i,3)) xmy3(i)=sf6(i,3)+hour(i)*(xmx3(i)-sf6(i,3)) xmx4(i)=sf4(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmy4(i)=sf5(i,4)+hour(i)*(xmx4(i)-sf4(i,4)) xmy4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmy4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmy4(i)=sf6(i,4)+hour(i)*(xmx4(i)-sf6(i,4)) xmx4(i)=sf6(i,</pre>	33(. )))))))))))))))))))))))))))))))))))	<b>i</b> ) *	fm4:	3(1	-)				

С	Apply drilling moments for contact forces call kmdrill(e,f,ndlist,nlstm)
с	Put nodal forces into system force vector if (ishlf ne 1) then
~	No element failure
0	do 90 $i=1ft$ 11t
	e(1 i x 1 (i)) = e(1 i x 1 (i)) = f x 1 (i)
	e(1, 1x1(1)) = e(1, 1x1(1)) = fx1(1)
	e(2, ixi(1)) = e(2, ixi(1)) = iyi(1)
	e(3, 1X1(1)) - e(3, 1X1(1)) - 1Z1(1)
,	f(1, 1X1(1)) = f(1, 1X1(1)) - XmX1(1)
	f(2, 1x1(1)) = f(2, 1x1(1)) - xmy1(1)
	f(3, ix1(i)) = f(3, ix1(i)) - xmz1(i)
	e(1, ix2(i)) = e(1, ix2(i)) - fx2(i)
	e(2,ix2(i))=e(2,ix2(i))-fy2(i)
	e(3,ix2(i))=e(3,ix2(i))-fz2(i)
	f(1, ix2(i)) = f(1, ix2(i)) - xmx2(i)
	f(2, ix2(i)) = f(2, ix2(i)) - xmy2(i)
	f(3, ix2(i)) = f(3, ix2(i)) - xmz2(i)
	e(1, ix3(i)) = e(1, ix3(i)) - fx3(i)
	e(2, ix3(i)) = e(2, ix3(i)) - fy3(i)
	$P(3 ix3(i)) = P(3 ix3(i)) - f_{7}(i)$
	f(1 i x 3(i)) = f(1 i x 3(i)) - x x x x x x x x x x x x x x x x x x
	f(2) i y 2 (i) = f(2) i y 2 (i) = y 2 (i)
	f(2, 1x3(1)) = f(2, 1x3(1)) = xmy3(1)
	I(3, 1X3(1)) = I(3, 1X3(1)) - XMZ3(1)

e(1, ix4(i)) = e(1, ix4(i)) - fx4(i)
e(2, ix4(i)) = e(2, ix4(i)) - fy4(i)
e(3, ix4(i)) = e(3, ix4(i)) - fz4(i)
f(1, ix4(i)) = f(1, ix4(i)) - xmx4(i)
f(2, ix4(i)) = f(2, ix4(i)) - xmy4(i)
f(3, ix4(i)) = f(3, ix4(i)) - xmz4(i)

90 continue

else

С

With Element Failure ifail=1 do 100 i=lft,llt e(1,ix1(i))=e(1,ix1(i))-fail(i)\*fx1(i) e(2,ix1(i))=e(2,ix1(i))-fail(i)\*fy1(i) e(3,ix1(i))=e(3,ix1(i))-fail(i)\*fz1(i) f(1,ix1(i))=f(1,ix1(i))-fail(i)\*xmx1(i) f(2,ix1(i))=f(2,ix1(i))-fail(i)\*xmy1(i) f(3, ix1(i)) = f(3, ix1(i)) - fail(i) \* xmz1(i)e(1, ix2(i))=e(1, ix2(i))-fail(i)\*fx2(i) e(2, ix2(i)) = e(2, ix2(i)) - fail(i) \* fy2(i) e(3,ix2(i))=e(3,ix2(i))-fail(i)\*fz2(i) f(1, ix2(i)) = f(1, ix2(i)) - fail(i) \* xmx2(i)f(2,ix2(i))=f(2,ix2(i))-fail(i)\*xmy2(i) f(3,ix2(i))=f(3,ix2(i))-fail(i)\*xmz2(i) e(1,ix3(i))=e(1,ix3(i))-fail(i)\*fx3(i) e(2,ix3(i))=e(2,ix3(i))-fail(i)\*fy3(i) e(3,ix3(i))=e(3,ix3(i))-fail(i)\*fz3(i) f(1,ix3(i))=f(1,ix3(i))-fail(i)\*xmx3(i) f(2,ix3(i))=f(2,ix3(i))-fail(i)\*xmy3(i) f(3,ix3(i))=f(3,ix3(i))-fail(i)\*xmz3(i) e(1, ix4(i))=e(1, ix4(i))-fail(i)\*fx4(i) e(2,ix4(i))=e(2,ix4(i))-fail(i)\*fy4(i) e(3,ix4(i))=e(3,ix4(i))-fail(i)\*fz4(i)

95

```
f(1,ix4(i))=f(1,ix4(i))-fail(i)*xmx4(i)
f(2,ix4(i))=f(2,ix4(i))-fail(i)*xmy4(i)
f(3,ix4(i))=f(3,ix4(i))-fail(i)*xmz4(i)
100 continue
endif

if (output) then
nblksz=nlq
nwords=12*nblksz
call blkcpy(fx1,savfrc,nwords)
ndof=4
if (ifail.eq.1) call blkcpy (fail,svfail,nlq)
endif
return
end
```

```
subroutine kmtran
      implicit double precision (a-h, o-z)
      include 'nlqpar.inc'
  Computes B matrix based on Belytschko-Tsay shell element needed for
С
    hourglass control of Kwon-McDermott shell element. Also computes
C
    area for time-step control
\sim
      common/bk02/iburn,isdo,dt1,dt2
      common/aux5/
     1b1vx(nlq), b1vy(nlq), b1vz(nlq), b2vx(nlq), b2vy(nlq), b2vz(nlq),
     2b1tx(nlq),b1ty(nlq),b2tx(nlq),b2ty(nlq),bxyv(nlq),bxyt(nlq),
     3epyz(nlq),epzx(nlq)
      common/aux7/
     1 vx1(nlq), vx2(nlq), vx3(nlq), vx4(nlq),
     2 vx5(nlq),vx6(nlq),vx7(nlq),vx8(nlq),
     3 vy1(nlq), vy2(nlq), vy3(nlq), vy4(nlq),
     4 vy5(nlq), vy6(nlq), vy7(nlq), vy8(nlq),
     5 vz1(nlq), vz2(nlq), vz3(nlq), vz4(nlq),
     6 vz5(nlq),vz6(nlq),vz7(nlq),vz8(nlq)
      common/aux10/area(nlq),
     1 px1(nlq),px2(nlq),px3(nlq),px4(nlq),
     & px5(nlq),px6(nlq),px7(nlq),px8(nlq),
     2 py1(nlq),py2(nlq),py3(nlq),py4(nlq),
     & py5(nlq),py6(nlq),py7(nlq),py8(nlq),
     3 pz1(nlq), pz2(nlq), pz3(nlq), pz4(nlq),
     & pz5(nlq),pz6(nlq),pz7(nlq),pz8(nlq),
     4 dx1(nlg), dx2(nlg), dx3(nlg), dx4(nlg),
     5 dx5(nlq), dx6(nlq), dx7(nlq), dx8(nlq),
     6 dy1(nlq), dy2(nlq), dy3(nlq), dy4(nlq),
     7 dy5(nlq), dy6(nlq), dy7(nlq), dy8(nlq),
     8 dz1(nlq), dz2(nlq), dz3(nlq), dz4(nlq),
     9 dz5(nlq), dz6(nlq), dz7(nlq), dz8(nlq)
      common/aux11/
     &gm11(nlq),gm12(nlq),gm13(nlq),gm21(nlq),gm22(nlq),gm23(nlq),
     &gm31(nlq),gm32(nlq),gm33(nlq),px1a(nlq),py1a(nlq),px2a(nlq),
     &py2a(nlq),diag1(nlq),diag2(nlq)
      common/aux13/
     &zeta(nlq),thick(nlq),fga(nlq),fgb(nlq),fgc(nlq),
     &gl11(nlq),gl12(nlq),gl13(nlq),gl21(nlq),gl22(nlq),gl23(nlq),
     &gl31(nlq),gl32(nlq),gl33(nlq),
     &x1(nlq), y1(nlq), z1(nlq), x2(nlq), y2(nlq), z2(nlq),
     &x3(nlq), y3(nlq), z3(nlq), x4(nlq), y4(nlq), z4(nlq)
      common/aux12/
     1 wxx1(nlq), wxx2(nlq), wxx3(nlq), wxx4(nlq),
     2 wyy1(nlq),wyy2(nlq),wyy3(nlq),wyy4(nlq),
     3 wzz1(nlq),wzz2(nlq),wzz3(nlq),wzz4(nlq),
     4 a13(nlq),a23(nlq),a33(nlq)
      common/aux36/lft,llt
      common/aux40/
     &x31(nlq), y31(nlq), z31(nlq), x42(nlq), y42(nlq), z42(nlq),
     &x21(nlq), y21(nlq), z21(nlq), c1(nlq), c2(nlq), c3(nlq), x1(nlq),
     &x41(nlq),y41(nlq),z41(nlq)
      common/sound/sndspd, sndsp(nlq), diagm(nlq), sarea(nlq), dxl(nlq)
      common/sides/sidmn(nlq)
      common/double/iprec,ncpw,unit
C
      dimension vx13(nlq), vx24(nlq), vy13(nlq), vy24(nlq),
     1 vz13(nlq), vz24(nlq), wxx13(nlq), wxx24(nlq), wyy13(nlq),
```

```
97
```

	2 wyy24 3 xt4(r equival	(nlq), nlq),y Lence	sidem t4(nl (wxxl	(nlq) q) ,vx13	), xt2 3), (wz	(nlq) xx2,v	,yt2 x24)	(nl	q),x xx3,	t3(n vy13	lq), ),(w	yt3(: xx4,	nlq), vy24)	) .
	2	(wyy (wzz	1,wxx 1,vz1	13), 3),(v	(wyyz, vzz2.v	$\frac{WXX2}{z24}$	4),(	wуу.	3,wy	y13)	, (wy	y4,w	yy24)	) ;
			-,			/					1			
		- , Č		3 K 1		11. J.		· ·	.'			6 - 1 - 1		
	do 10 i	=lft,	llt		1. J.	÷.,					· •			
	gmil(i	.)=dt1	*g111	(i)										."
	gm21(1	) = dt 1	*g121	( <u>1</u> )		1	- · ·			1.11				
	gm31(1)	.)=at⊥ \d+1	*~1121	(1) /=``									-	
	$g_{m22}(i)$	$\lambda = d t 1$	^g⊥⊥2 *~122	(1) (4)		ta k							•	
	gm22(1	) = d + 1	*a132	(⊥) (i)	i.									'
	gm:52(1	)=dt1	91JZ *α113/	(±) (i)			· .			-				
	am 23 (i	$) = d \pm 1$	*α123	(±) (i)		· · ·					•			
	gm23(i	) = dt 1	*a133(	( <u>1</u> )		14								
	vx1(i)	=cm11	(i) * dx	(1/i)	+am2	1(i):	*dv1	(i)	+~~3	1(1)	* 121	(1)		
	vv1(i)	=am12	(i) * dx	(1)	+am2	2(i)	*dv1	(i)	+am3	2(i)	*dz1	·(±) (i)		
	vz1(i)	=am13	(i)*dx	:1(i)	+0m2	3(i)	tdv1	(±)	+am3	3(i)	*dz1	· ( ± ) ( † )		
	vx2(i)	=qm11	(i)*dx	2(i)	+am2	1(i)'	dv2	(i)	+am3	1(i)	*d72	· ( ± ) ? ( i )		
	vv2(i)	=qm12	(i) * dx	2(i)	+am2	2(i);	dv2	(i)	+am3	2(i)	* 172	·(±)		
	vz2(i)	=qm13	(i) * dx	2(i)	+am2	3(i)'	dv2	(i)	+am3	3(i)	*dz2	( <u>+</u> )	· .	1
	vx3(i)	=gm11	(i)*dx	3(i)	+gm2	1(i)'	dv3	(i)	+am3	1(i)	*dz3	(i)	· · ·	
	vy3(i)	=gm12	(i)*dx	3(i)	+gm22	2(i)'	dy3	(i)	+qm3	2(i)	*dz3	(i)	•	
	vz3(i)	=gm13 (	(i)*dx	3(i)	+gm2:	3(i)'	dy3 (	(i)	+gm3	3(i)	*dz3	(i)		
10	continue	е		۰.							n yr ar a			
	do 20 i=	=lft,1	lt				1. 1. 1. 1.		1		.'		et e e	
	VX4(1)=	=gm11(	(1)*dx	4(i)	+gm2]	L(i)*	dy4 (	i)	+gm3	1(i)	*dz4	(i)		
	vy4(1) =	=gm12 (	1)*dx	4(1)	+gm22	2(ユ)*	dy4 (	i)	+gm3	2(i)	*dz4	(i)		
	v24(1)-	$-g_{m13}$	1)*ux	4 (⊥) ∵1 / i '	+gm2:	>(l)^  /:\*	ay4 (	(그) : (구구) :	+gm3.	3(1)	*dz4	(ユ) コンパン		
	$v_{X5}(1) = v_{X5}(1) = v_{X$	$= \alpha m 12$ (	.⊥) w⊼ i)*wv	∧⊥(⊥, ⊽1/i'	+qm22	- ( + ) ~ > ( <del>i</del> ) *	wyyı	· ( ⊥ ) · / + ) ·	+gm3. +gm3.	1 (1) 2 († )	*WZZ	1(1)		
	$v_{x} \delta(i) =$	=cm11 (	i)*wx	x2(i)	$+\alpha m 21$	·(⊥) (i)*	wyy⊥ www?	(±) (;)	+ cm 3.	2 ( I ) 1 ( i )	~WZZ	⊥(⊥) 2(i)		
	vv6(i)=	=cm12 (	i)*wx	$x^{2}(i)$	$+\alpha m 22$	· ( ± / ) ( i ) *	wyyz wyy2	(1).	+ am 3'	- ( - ) 2 ( i )	* 177	2 (1) 2 (i)		
	vx7(i) =	-am11 (	i)*wx	x3(i)	+am21	(j)*	wvv3	(i).	+am3;	1 (i)	* 107 7	2(1) 3(i)		
	vv7(i)=	-qm12 (	i)*wx	x3(i)	+gm22	!(i)*	wvv3	(i)	+am32	2(i)	* W77	3(i)		
	vx8(i)=	=gm11(	i)*wxx	x4(i)	+qm21	(i)*	wvv4	(i)	+am3	l(i)	*wzz.	4 (i)		
	vy8(i)=	-gm12(	i)*wx	x4(i)	+gm22	:(i)*	wvv4	(i)·	+am32	2(i)	*wzz	4(i)		
	xt2(i)	=g111	(i)*x2	21(i)	- +gl2	1(i)	*y21	(i)	+ql3	31(i	)*z2	1(i)		
	yt2(i)	=g112	(i)*x2	21(i)	+g12	2(i)	*y21	(i)	+g13	32(i	)*z2:	1(i)		
	xt3(i)	=g111	(i)*x3	31(i)	+g12	1(i)	*y31	(i)	+gl3	31(i	)*z3:	1(i)	-	
	yt3(i)	=gl12	(i)*x3	31(i)	+g12	2(i)	*y31	(i)	+gl3	32(i	)*z31	1(i)		
	xt4(i)	=g111	(i)*x4	41(i)	+g12	1(i)	*y41	(i)	+g13	31(i	)*z41	l(i)		
20	yt4(1)	=g112	(i)*x4	41(i)	+g12	2(i)	*y41	(i)	+g13	32(i	)*z41	l(i)		
20	continue					ų.								
	$d_0 = 30 i =$	1 <del>f +</del> 1	1+				· . ·	. •	· · ·					
	nx1(i)	= 5	エレ * ( v+ 2 )	(i)-v	+4(1)	١								
	px2(i)	= .5	* vt3	(1) (1)	C-1 (1)	·		· .				,		
	py1(i)	=5	* (xt2)	(i)~x	t4(i)	)	:		14 - 1 1	· • • .	·•			4
	py2(i)	=5	* xt3	(i)			· ·		·.		· · ·			
	sarea(i	)=2.0	* (py2 (	(i)*p	x1(i)	-py1	(i)*r	ox2 (	(i))				~	
	diagl(i	)=xt3	(i)**2	?+yt3	(i)**	2	1	\						
	diag2(i	)=4.*	(pxl(i	.) <sup>*</sup> px	1(i)+	py1(:	L)*p	y1(i	))			r '		•
	diagm(i	) = ma	ax(dia	ıgl(i	),dia	g2(i)	)							1
	sidel	=xt2	(i)*xt	2(i)	+yt2(.	i)*yt	:2(i)	)			;		с. <sup>1</sup> .	4
	side2	=(xt)	3(i)-x	t2(i	))**2	+(yt:	3(i)-	-yt2	!(i))	**2				
	side3	=(xt4	4(i)-x	:t3(i	))**2·	+(yt4	l(i)-	-yt3	(i))	**2-	-1.e-	14	· · ·	
	side4	=xt4	(i)*xt	4(i)	+vt4(:	i)*vt	:4(i)							

С
```
sida3 =side4*(5.-sign(.5*unit,side3))+side3
sidmn(i)= min(side1,side2,sida3,side4)
sidem(i)= max(side1,side2,side3,side4)*
1 (.625+sign(.375*unit,side3))
fgb(i) =sarea(i)*fgb(i)
30 continue
```

```
С
```

Ċ

```
do 40 i=lft,llt
   area(i)=1./(sarea(i)+1.e-20)
   sarea(i) = sarea(i) * sqrt(2.0*thick(i))
40 continue
   if (isdo.eq.0.or.isdo.eq.2) then
```

```
do 50 i=lft,llt
50 diagm(i) = min(diagm(i),sidem(i))
return
else
```

return endif

```
subroutine kwnmcd(rule, ixp, x, rhs, vt, vr, strain, yhatn, fibl,
     1 auxvec, mtype, ro, cm, csprop, nsubgv, mtnum, nfegp, ihgq, hgq, xies, ener,
     2 mpusr,lav,nmel,nnm1,mxe,iblks,dampk,ym,prv,emain)
      implicit double precision (a-h,o-z)
      include 'nlqpar.inc'
                                  *****
C
      main subroutine for the kwon-mcdermott shell formulation
С
С
          (Call parameters are same as all other shell formulations)
                                           McDermott 1999
С
\mathbf{c}
      common/
                  /b(1)
      common/bk00/numnp, numpc, numlp, neq, ndof, nlcur, numcl, numvc,
     1 ndtpts,nelmd,nmmat,numelh,numelb,numels,numelt,numdp,
        grvity, idirgv, nodspc, nspcor
     2
      common/bk02/iburn, isdo, dt1, dt2
      common/bk12/b12,b2,qhg
      common/bk13/1c0,1c1h,1c1b,1c1s,1c1t,1c2,1c3,1c4,1c5,1c6,1c7,1c9,
     1
         lc10, lc11, lc12, lc13, lc14, lc15, lc16, lc17, lc18, lb0, lb1, lb2,
     2
         lc7a,lc7b
      common/bk19/nconst(60),lenma,ncneos(15)
      common/bk25/dfavg, detavg, davg, iflg, ielmtc, ityptc
      common/aux01/
     &ft11(nlq),ft12(nlq),ft13(nlq),ft21(nlq),ft22(nlq),ft23(nlq),
     &fml1(nlq),fm12(nlq),fm21(nlq),fm22(nlq),
     &fm31(nlq),fm32(nlq),fm41(nlq),fm42(nlq),
     &fmrl1(nlq),fmrl2(nlq),fmr21(nlq),fmr22(nlq),fmr31(nlq),
     &fmr32(nlq),fmr41(nlq),fmr42(nlq),sg5(nlq),sg6(nlq)
      common/aux2/d1(nlq), d2(nlq), d3(nlq), d4(nlq), d5(nlq), d6(nlq),
     1 wzzdt(nlq),wyydt(nlq),wxxdt(nlq),einc(nlq)
       common/aux7/
     1 vx1(nlq), vx2(nlq), vx3(nlq), vx4(nlq),
     2 vx5(nlq),vx6(nlq),vx7(nlq),vx8(nlq),
     3 vy1(nlq),vy2(nlq),vy3(nlq),vy4(nlq),
     4 vy5(nlq),vy6(nlq),vy7(nlq),vy8(nlq),
     5 vz1(nlq), vz2(nlq), vz3(nlq), vz4(nlq),
    6 vz5(nlq), vz6(nlq), vz7(nlq), vz8(nlq)
     common/aux10/area(nlq),
    1 px1(nlq), px2(nlq), px3(nlq), px4(nlq),
     & px5(nlq),px6(nlq),px7(nlq),px8(nlq),
    2 py1(nlq),py2(nlq),py3(nlq),py4(nlq),
     & py5(nlq),py6(nlq),py7(nlq),py8(nlq),
    3 pz1(nlq),pz2(nlq),pz3(nlq),pz4(nlq),
    & pz5(nlq),pz6(nlq),pz7(nlq),pz8(nlq),
    4 dx1(nlq), dx2(nlq), dx3(nlq), dx4(nlq),
    5 dx5(nlq), dx6(nlq), dx7(nlq), dx8(nlq),
    6 dy1(nlq), dy2(nlq), dy3(nlq), dy4(nlq),
    7 dy5(nlq), dy6(nlq), dy7(nlq), dy8(nlq),
    8 dz1(nlq),dz2(nlq),dz3(nlq),dz4(nlq),
    9 dz5(nlq), dz6(nlq), dz7(nlq), dz8(nlq)
     common/aux13/
    &zeta(nlq),thick(nlq),fga(nlq),fgb(nlq),fgc(nlq),
    &gl11(nlq),gl12(nlq),gl13(nlq),gl21(nlq),gl22(nlq),gl23(nlq),
    &gl31(nlq),gl32(nlq),gl33(nlq),
    &x1(nlq), y1(nlq), z1(nlq), x2(nlq), y2(nlq), z2(nlq),
    &x3(nlq), y3(nlq), z3(nlq), x4(nlq), y4(nlq), z4(nlq)
     common/aux14/
    1 sigl(nlq), sig2(nlq), sig3(nlq), sig4(nlq),
    2 sig5(nlq), sig6(nlq), ep(nlq), epx1(nlq),
    3 epx2(nlq), epx4(nlq), epx5(nlq), epx6(nlq), aux(nlq, 59)
                                    100
```

```
common/aux12/
1 wxx1(nlq), wxx2(nlq), wxx3(nlq), wxx4(nlq),
2 wyy1(nlq),wyy2(nlq),wyy3(nlq),wyy4(nlq),
3 wzz1(nlq), wzz2(nlq), wzz3(nlq), wzz4(nlq),
4 a13(nlq),a23(nlq),a33(nlq)
 common/aux33/
1 ix1(nlq), ix2(nlq), ix3(nlq), ix4(nlq), ixs(nlq, 4), mxt(nlq)
 common/aux35/rhoa(nlq), cxx(nlq), fcl(nlq), fcq(nlq)
 common/aux36/lft,llt
 common/sound/sndspd, sndsp(nlq), diagm(nlq), sarea(nlq), dxl(nlq)
 common/bktb/ntbsl,nods,nodm,ips,ipm,ipa,ipb,ipc,ipd,
             ipe, ipf, ipg, iph, ipi, ipj, ipk
 common/ssbsis/h(8,5,5),pr(8,5,5),ps(8,5,5),pt(8,5,5),ipt,
1 nip, wgts(5,5), zet(5,5)
 common/shlopt/istrn,istupd,ibelyt
 common/hourg/ymod,gmod,ifsv
 common/sand1/ihf,ibemf,ishlf,itshf
 common/failul/sieu(nlg), fail(nlg)
 common/energy/xinen
 common/kinet/enkint(nlq), xmomnt(nlq), ymomnt(nlq), zmomnt(nlq)
dimension ixp(5,*),x(3,*),rhs(*),vt(3,*),vr(3,*),yhatn(12,*),
1 auxvec(*),mtype(*),ro(*),cm(*),csprop(24,*),rule(mpusr,3,*),
2 fibl(9,*),nsubgv(*),mtnum(*),nfegp(*),ihgq(*),hgq(*),
3 strain(12,*), isrn(2,6), ener(*), iblks(*), xies(*), emain(6,nlq),
 4 shapef(4),aj(3,3),ajinv(3,3),t1(3,3),t1inv(3,3),edispg(24),
5 edisp(24), shapel(3), derivg(3,4), v1(3), v2(3), v3(3), rot6t(6,6),
6 deriva(4), derivb(4), derilg(3,4), estrain(6), estrainp(6),
 7 bmtx(6,24,nlq),rotall(6,6,nlq),ajdet(nlq),t1all(3,3,nlq),
 8 estress(6), estressg(6), eforce(24), eforceg(24), sforcel(nlq, 4),
 9 sforce2(nlq,4), sforce3(nlq,4), sforce4(nlq,4), sforce5(nlq,4),
 1 sforce6(nlq,4),rotrn(6,6),bmtxt(24,6),str33(nlq),ndlist(nlq*4)
data isrn/1,1,1,2,2,3,1,4,2,5,0,0/
 data deriva/-0.25,0.25,0.25,-0.25/
data derivb/-0.25,-0.25,0.25,0.25/
rho=1./ro(mxe)
nip=nint(csprop(2,mxe))
 irl=nint(csprop(4,mxe))
nrl=iabs(irl)
 if (nip.gt.5.and.irl.eq.0) irl=1
 zbr=csprop(13,mxe)
 ifsv=ihgq(mxe)
 ipt=1
 rhoa(lft)=ro(mxe)
 qhg=.25*hgq(mxe)
mte=mtype(mxe)
 if (mte.eq.20) return
nmtcon=7+nconst(mte)
 sndspd=1.e-20
 ym=cm(48*(mxt(lft)-1)+1)
 do 10 i=lft,llt
  thick(i)=fibl(1,nnm1+i)
  str33(i)=0.0
  do 10 j=1,4
   sforcel(i,j) = 0.0
   sforce2(i,j) = 0.0
   sforce3(i,j) = 0.0
   sforce4(i,j) = 0.0
                               101
```

```
sforce5(i,j) = 0.0
         sforce6(i,j) = 0.0
    10 continue
c *** Support for Drilling Moment addition to reflect pressure
        applied to surface, which requires a list of nodes for this group of elements. This list might be more efficiently generated
С
С
С
        outside the time loop (in the initialize phase), but that would
        require a lot of changes in initlz et al., plus the addition of
С
        and additional global array. Using this list allows the drilling
С
        moment calculations to be made
С
        for only those nodes that are attached to KM shell elements,
С
which
        can result in significant speed gains on large systems with
C
multiple
        multiple element types.
С
c Create node list
       do 15 i=lft,llt
        jn=(i-1)*4
        ndlist(jn+1)=ix1(i)
        ndlist(jn+2)=ix2(i)
        ndlist(jn+3)=ix3(i)
        ndlist(jn+4)=ix4(i)
   15 continue
c Remove duplicates (no need to sort)
      nlstm=(llt-lft+1)*4
      i=1
      do while (i.lt.nlstm)
        j=i+1
         do while (j.le.nlstm)
          if (ndlist(i).eq.ndlist(j)) then
           do 16 k=j,nlstm-1
   16
            ndlist(k)=ndlist(k+1)
           ndlist(nlstm)=0
           nlstm=nlstm-1
          endif
       · j=j+1
       enddo
       i=i+1
      enddo
      if (ishlf.ne.1) then
c Retrieve Nodal Coordinates and velocities for no-failure
       do 20 i=lft,llt
         sieu(i)=xies(nnml+i)
        x1(i) = x(1, ix1(i))
        y1(i) = x(2, ix1(i))
        z1(i) = x(3, ix1(i))
        x2(i) = x(1, ix2(i))
        y2(i) = x(2, ix2(i))
        z2(i) = x(3, ix2(i))
        x3(i) = x(1, ix3(i))
        y_3(i) = x(2, ix_3(i))
```

z3(i) = x(3, ix3(i))x4(i) = x(1, ix4(i))y4(i) = x(2, ix4(i))z4(i) = x(3, ix4(i))

dx1(i) = vt(1, ix1(i))dy1(i)=vt(2,ix1(i)) dz1(i)=vt(3,ix1(i)) dx2(i) = vt(1, ix2(i))dy2(i) = vt(2, ix2(i))dz2(i)=vt(3,ix2(i)) dx3(i) = vt(1, ix3(i))dy3(i)=vt(2,ix3(i)) dz3(i)=vt(3,ix3(i)) dx4(i)=vt(1,ix4(i)) dy4(i)=vt(2,ix4(i)) dz4(i)=vt(3,ix4(i)) wxx1(i)=vr(1,ix1(i)) wyy1(i)=vr(2,ix1(i)) wzz1(i)=vr(3,ix1(i)) wxx2(i) = vr(1, ix2(i)) wyy2(i)=vr(2,ix2(i)) wzz2(i) = vr(3, ix2(i))wxx3(i) = vr(1, ix3(i)) wyy3(i)=vr(2,ix3(i)) wzz3(i) = vr(3, ix3(i))wxx4(i)=vr(1,ix4(i)) wyy4(i)=vr(2,ix4(i)) wzz4(i) = vr(3, ix4(i))continue

20 contin

```
else
```

С	Retrieve Nodal Coordinates and Velocities w/fa	ilure
	do 30 i=lft,llt	
	sieu(i)=xies(nnm1+i)	
	x1(i) = x(1, ix1(i))	
	y1(i) = x(2, ix1(i))	
	z1(i) = x(3, ix1(i))	
	x2(i) = x(1, ix2(i))	
	y2(i) = x(2, ix2(i))	
	z2(i) = x(3, ix2(i))	
	x3(i) = x(1, ix3(i))	
	$y_3(i) = x(2, ix_3(i))$	
	z3(i) = x(3, ix3(i))	
	x4(i) = x(1, ix4(i))	
	y4(i) = x(2, ix4(i))	
	z4(i) = x(3, ix4(i))	
	dx1(i) = vt(1, ix1(i)) * fail(i)	
	dy1(i)=vt(2,ix1(i))*fail(i)	
	dz1(i)=vt(3,ix1(i))*fail(i)	
	dx2(i) = vt(1, ix2(i)) * fail(i)	
	dy2(i) = vt(2, ix2(i)) * fail(i)	
	dz2(i) = vt(3, ix2(i)) * fail(i)	
	dx3(i) = vt(1, ix3(i)) * fail(i)	•
	dy3(i) = vt(2, ix3(i)) * fail(i)	-
	dz3(i)=vt(3,ix3(i))*fail(i)	
	dx4(i) = vt(1, ix4(i)) * fail(i)	
	dy4(i) = vt(2, ix4(i)) * fail(i)	
	dz4(i) = vt(3, ix4(i)) * fail(i)	· · ·
	wxx1(i)=vr(l,ix1(i))*fail(i)	
	wyyl(i)=vr(2,ixl(i))*fail(i)	
	wzz1(i) = vr(3, ix1(i)) * fail(i)	
	wxx2(i) = vr(1, ix2(i)) * fail(i)	
	wyy2(i)=vr(2,ix2(i))*fail(i)	

```
wzz2(i)=vr(3,ix2(i))*fail(i)
         wxx3(i)=vr(1,ix3(i))*fail(i)
         wyy3(i)=vr(2,ix3(i))*fail(i)
         wzz3(i)=vr(3,ix3(i))*fail(i)
         wxx4(i)=vr(1,ix4(i))*fail(i)
         wyy4(i)=vr(2,ix4(i))*fail(i)
         wzz4(i)=vr(3,ix4(i))*fail(i)
    30 continue
       endif
c Calculate Momentums and Kinetic Energy
       rho8th = 0.125 rhoa(lft)
       rho4th = 0.25 rhoa(lft)
       do 35 i=lft.llt
        dx=dx1(i)**2+dx2(i)**2+dx3(i)**2+dx4(i)**2
        dy=dy1(i)**2+dy2(i)**2+dy3(i)**2+dy4(i)**2
        dz=dz1(i)**2+dz2(i)**2+dz3(i)**2+dz4(i)**2
        enkint(i)=fibl(1,nnml+i)*rho8th*(dx+dy+dz)
        xmomnt(i) = fibl(1, nnml+i) * rho4th*(dx1(i) + dx2(i) + dx3(i) + dx4(i))
        ymomnt(i)=fibl(1,nnml+i)*rho4th*(dy1(i)+dy2(i)+dy3(i)+dy4(i))
        zmomnt(i) = fibl(1, nnml+i) * rho4th*(dz1(i)+dz2(i)+dz3(i)+dz4(i))
   35 continue
c Calculate laminae vectors and surface area
      call dfnls(fibl(1,nnml+1),nip)
      call kmtran
c *** Loop through elements, get transormed displacement ***
         and calculate rotation matrices
C .
      do 70 ie=lft,llt
c Rename unit vectors locally to facilitate strain calculation
       Node 1 to 2
С
       v1(1) = gll1(ie)
       v1(2) = gl21(ie)
       v1(3) = g131(ie)
       Node 1 to 4 (Actually V1 x V3)
С
       v2(1) = gl12(ie)
       v2(2) = g122(ie)
       v2(3) \doteq g132(ie)
С
       Normal to reference plane
       v3(1) = gl13(ie)
       v3(2) = g123(ie)
       v3(3) = g133(ie)
c Rotation tranformation matrix, and its inverse
       do 40 i=1,3
        t1(i,1) = v1(i)
        t1(i,2) = v2(i)
        t1(i,3) = v3(i)
   40
      continue
       call kminv3(t1,t1inv,det)
c Store for use in force transformation
       do 50 i=1,3
        do 50 j=1,3
   50
      tlall(i,j,ie)=tl(i,j)
c Strain Transformation Matrix
                                 104
```

```
rotall(1,1,ie)=v1(1)**2
       rotall(1,2,ie)=v1(2)**2
       rotall(1,3,ie)=v1(3)**2
       rotall(1,4,ie)=v1(1)*v1(2)
       rotall(1,5,ie)=v1(2)*v1(3)
       rotall(1,6,ie)=v1(1)*v1(3)
       rotall(2,1,ie)=v2(1)**2
       rotall(2,2,ie)=v2(2)**2
       rotall(2,3,ie)=v2(3)**2
       rotall(2,4,ie)=v2(1)*v2(2)
       rotall(2,5,ie)=v2(2)*v2(3)
       rotall(2,6,ie)=v2(1)*v2(3)
       rotall(3,1,ie)=v3(1)**2
       rotall(3,2,ie)=v3(2)**2
       rotall(3,3,ie)=v3(3)**2
       rotall(3,4,ie)=v3(1)*v3(2)
       rotall(3,5,ie)=v3(2)*v3(3)
       rotall(3,6,ie)=v3(1)*v3(3)
       rotall(4,1,ie)=2.0*v1(1)*v2(1)
       rotall(4,2,ie)=2.0*v1(2)*v2(2)
       rotall(4,3,ie)=2.0*v1(3)*v2(3)
       rotall(4,4,ie)=v1(1)*v2(2)+v2(1)*v1(2)
       rotall(4,5,ie)=v1(2)*v2(3)+v2(2)*v1(3)
       rotall(4,6,ie)=v1(3)*v2(1)+v2(3)*v1(1)
       rotall(5,1,ie)=2.0*v2(1)*v3(1)
       rotall(5,2,ie)=2.0*v2(2)*v3(2)
       rotall(5,3,ie)=2.0*v2(3)*v3(3)
       rotall(5,4,ie)=v2(1)*v3(2)+v3(1)*v2(2)
       rotall(5,5,ie)=v2(2)*v3(3)+v3(2)*v2(3)
       rotall(5, 6, ie) = v2(3) * v3(1) + v3(3) * v2(1)
       rotall(6,1,ie)=2.0*v3(1)*v1(1)
       rotall(6,2,ie)=2.0*v3(2)*v1(2)
       rotall(6,3,ie)=2.0*v3(3)*v1(3)
       rotall(6,4,ie)=v3(1)*v1(2)+v1(1)*v3(2)
       rotall(6,5,ie)=v3(2)*v1(3)+v1(2)*v3(3)
       rotall(6,6,ie)=v3(3)*v1(1)+v1(3)*v3(1)
c Rename displacement for code compatability (Global Coord)
       call kmcpdp(edispg,1,ie)
c Transform rotations into local coordinates
       do 60 i=1,4
        do 60 j=1,3
            edisp((i-1)*6+j)=edispg((i-1)*6+j)
            edisp((i-1)*6+3+j)=(edispg((i-1)*6+4)*tlinv(j,1) +
                  edispg((i-1)*6+5)*tlinv(j,2) +
      1
      2
                   edispg((i-1)*6+6)*tlinv(j,3))
   60 continue
c Put back displacements
       call kmcpdp(edisp,0,ie)
c *** End Element Setup ***
   70 continue
c *** Begin Integration Loop ***
      do 230 iz=1, nip
       ipt = iz
c Get Gauss Point
                                    105
```

```
if(irl.eq.0)then
         zta = zet(iz, nip)
        elseif (irl.gt.0) then
         zta = 2.0 * (iz-1)/(nip-1)-1.0
        else
         zta = rule(iz,1,nrl)
         mtu = nint(rule(iz,3,nrl))
         mtv=mxt(lft)
         if (mtu.ne.0) then
         mxt(lft)=mtu
         endif
        endif
        call kmshap(zta,shape1)
c *** Begin Element Strain Calculation ***
        do 130 ie=lft,llt
c Jacobian, inverse and its determinant (stored)
         hz=thick(ie)*0.5*(shape1(2)*(1.0-zbr)-shape1(1)*(1.0+zbr))
         hzdt=thick(ie)*0.5
         aj(1,1)=0.25*(-x1(ie)+x2(ie)+x3(ie)-x4(ie))
         a_{i}(2,1)=0.25*(-x1(ie)-x2(ie)+x3(ie)+x4(ie))
         aj(3,1)=hzdt*gl13(ie)
         a; (1,2)=0.25*(-y1(ie)+y2(ie)+y3(ie)-y4(ie))
         aj(2,2)=0.25*(-y1(ie)-y2(ie)+y3(ie)+y4(ie))
         aj(3,2)=hzdt*gl23(ie)
         a_1(1,3)=0.25*(-z1(ie)+z2(ie)+z3(ie)-z4(ie))
         a_{1}(2,3)=0.25*(-z1(ie)-z2(ie)+z3(ie)+z4(ie))
         aj(3,3)=hzdt*gl33(ie)
         call kminv3(aj,ajinv,det)
         ajdet(ie) = det
c compute global derivatives and strain-nodal displacement matrix
        do 80 in=1,4
          derivg(1, in) = ajinv(1, 1) * deriva(in) + ajinv(1, 2) * derivb(in)
          derivg(2, in) = ajinv(2, 1) * deriva(in) + ajinv(2, 2) * derivb(in)
          derivg(3, in) = a jinv(3, 1) * deriva(in) + a jinv(3, 2) * derivb(in)
          derilg(1, in) = ajinv(1, 3) * hzdt
          derilg(2, in) = ajinv(2, 3) * hzdt
         derilg(3, in) =ajinv(3, 3) *hzdt
   80
        continue
c Zero out B matrix
        do 90 i=1,6
         do 90 j=1,24
        bmtx(i,j,ie)=0.0
   90
c Calculate B Matrix
        do 100 in=1,4
         i1 = (in-1) * 6 + 1
         i2=i1+1
         i3=i2+1
         i4=i3+1
         i5=i4+1
         i6=i5+1
         gkl=derivg(1,in)*hz+0.25*derilg(1,in)
         gk2=derivg(2, in) *hz+0.25*derilg(2, in)
         gk3=derivg(3,in)*hz+0.25*derilg(3,in)
                                     106
```

```
bmtx(1,i1,ie)=derivg(1,in)
         bmtx(1,i4,ie)=gk1*(-gl12(ie))
         bmtx(1, i5, ie) = gk1*gl11(ie)
         bmtx(1,i6,ie)=gk1*gl13(ie)
         bmtx(2,i2,ie)=derivg(2,in)
         bmtx(2,i4,ie)=gk2*(-gl22(ie))
         bmtx(2,i5,ie)=gk2*gl21(ie)
         bmtx(2,i6,ie)=gk2*gl23(ie)
         bmtx(3,i3,ie)=derivg(3,in)
         bmtx(3,i4,ie)=gk3*(-gl32(ie))
         bmtx(3, i5, ie) = gk3*gl31(ie)
         bmtx(3,i6,ie)=gk3*gl33(ie)
         bmtx(4,i1,ie)=derivg(2,in)
         bmtx(4,i2,ie)=derivg(1,in)
         bmtx(4,i4,ie)=gk2*(-gl12(ie))+gk1*(-gl22(ie))
         bmtx(4, i5, ie) = gk2*gl11(ie) + gk1*gl21(ie)
         bmtx(4,i6,ie)=gk2*gl13(ie)+gk1*gl23(ie)
         bmtx(5,i2,ie)=derivg(3,in)
         bmtx(5,i3,ie)=derivg(2,in)
         bmtx(5,i4,ie)=gk3*(-gl22(ie))+gk2*(-gl32(ie))
         bmtx(5,i5,ie)=gk3*gl21(ie)+gk2*gl31(ie)
         bmtx(5,i6,ie)=gk3*gl23(ie)+gk2*gl33(ie)
         bmtx(6,i1,ie)=derivg(3,in)
         bmtx(6, i3, ie) = derivg(1, in)
         bmtx(6,i4,ie)=gk3*(-gl12(ie))+gk1*(-gl32(ie))
         bmtx(6,i5,ie)=gk3*gl11(ie)+gk1*gl31(ie)
         bmtx(6,i6,ie)=gk3*gl13(ie)+gk1*gl33(ie)
  100
        continue
c Retrieve rotated displacements
        call kmcpdp(edisp,1,ie)
c Calculate Strain
        do 110 i=1,6
         estrainp(i)=0.0
         do 110 k=1,24
        estrainp(i)=estrainp(i)+bmtx(i,k,ie)*edisp(k)
 110
c Transform strain to local coordinates system
        do 120 i=1,6
         estrain(i)=0.0
         do 120 k=1,6
        estrain(i)=estrain(i)+rotall(i,k,ie)*estrainp(k)
  120
c Store Strain increments
        d1(ie) = estrain(1)*dt1
        d2(ie) = estrain(2)*dt1
        d3(ie) = estrain(3)*dt1
        d4(ie) = estrain(4)*dt1
        d5(ie) = estrain(5)*dt1
        d6(ie) = estrain(6)*dt1
        zeta(ie)=zta*thick(ie)
        einc(ie) = 0.0
c *** End of element strain loop ***
  130
       continue
c Constitutive Model Evaluation (ie strain to stress)
```

```
107
```

```
call kmcon (nmtcon, auxvec, cm, lav, mte, nip, ipt, csprop(1, mxe),
       1 dampk, ym, prv, mxe)
 c if strain output is selected, store strain tensor for this ipt
        if (istrn.ne.0) then
         if (irl.eq.0) then
          if (iz.eq.isrn(1,nip)) then
           call tbstbo (strain(1,nnm1+1), cm, nnm1, mte, emain(1,1))
          endif
          if (iz.eq.isrn(2,nip)) then
           call tbstbo (strain(7,nnm1+1), cm, nnm1, mte, emain(4,1))
          endif
         else
          if (iz.eq.1 ) then
           call tbstbo (strain(1,nnm1+1), cm, nnm1, mte, emain(1,1))
          endif
          if (iz.eq.nip) then
          call tbstbo (strain(7,nnm1+1), cm, nnm1, mte, emain(4,1))
          endif
         endif
       endif
c Get gauss weight
       if (irl.eq.0) then
        fac=wgts(iz,nip)
       elseif (irl.gt.0) then
        fac=2./(nip-1)
       else
        fac=rule(iz,2,nrl)
        mxt(lft)=mtv
       endif
c *** Begin Element Force Loop ***
       do 200 ie=lft,llt
c Update epsilon zz, if selected
        if (istupd.ne.0) str33(ie)=str33(ie)+0.5*fac*d3(ie)
c Copy Element stress tensor to local variable
        estress(1)=sigl(ie)
        estress(2)=sig2(ie)
        estress(3)=sig3(ie)
        estress(4)=sig4(ie)
        estress(5)=sig5(ie)
        estress(6)=sig6(ie)
c Get transpose of rotation matrix
        do 140 i=1,6
         do 140 j=1,6
  140
        rotrn(i,j)=rotall(j,i,ie)
c Rotate stresses to global coordinates
        do 150 i=1,6
         estressg(i)=0.0
         do 150 k=1,6
  150
        estressg(i)=estressg(i)+rotrn(i,k)*estress(k)
c Get transpose of B matrix
        do 160 i=1,24
         do 160 j=1,6
                                   108
```

```
bmtxt(i,j)=bmtx(j,i,ie)
  160
c Calculate element forces
        do 170 i=1,24
         eforce(i)=0.0
         do 170 k=1,6
        eforce(i) = eforce(i) + bmtxt(i, k) * estressg(k)
  170
c Rotate moments
        do 180 i=1,4
         do 180 j=1,3
          eforceg((i-1)*6+j)=eforce((i-1)*6+j)
          eforceg((i-1)*6+3+j)=eforce((i-1)*6+4)*t1all(j,1,ie)
             + eforce((i-1)*6+5)*t1all(j,2,ie)
      1
             + eforce((i-1)*6+6)*t1all(j,3,ie)
  180
        continue
c Sum up forces for each node
        detwt=ajdet(ie)*4.0*fac
             4.0 comes from x and y gauss weights (2.0 each)
C
        do 190 i=1,4
         sforce1(ie,i) = sforce1(ie,i) + eforceg((i-1)*6+1)*detwt
         sforce2(ie,i) = sforce2(ie,i) + eforceg((i-1)*6+2)*detwt
         sforce3(ie,i) = sforce3(ie,i) + eforceg((i-1)*6+3)*detwt
         sforce4(ie,i) = sforce4(ie,i) + eforceg((i-1)*6+4)*detwt
         sforce5(ie,i) = sforce5(ie,i) + eforceg((i-1)*6+5)*detwt
         sforce6(ie,i) = sforce6(ie,i) + eforceg((i-1)*6+6)*detwt
  190
        continue
c *** End of Element Force Loop ***
  200 continue
c Do for compatability with output routines; b(ipi) = volf, b(iph) = epf
       faci=1./fac
       do 220 i=lft,llt
        fga(i)=fac*fga(i)
        fgb(i)=fac*fgb(i)
        if (ipi.eq.iph) go to 210
        b(ipi+i+nnm1)=b(ipi+i+nnm1)+fga(i)
        b(iph+i+nnm1)=b(iph+i+nnm1)+ep(i)*fga(i)
        xies(i) =xies(i)+.5*fga(i)*sarea(i)*einc(i)
  210
        fga(i) =faci*fga(i)
        fqb(i) =faci*fgb(i)
  220 continue
*** End of Integration Loop
  230 continue
c Change shell thickness if required
c *** Must be an error in indexing - causes "Access Violation"
      if (istupd.ne.0) then
       do 240 ie=lft,llt
        indfib = nnml+l+ie
        str33(ie)=1.+str33(ie)
        fibl(1, indfib) = str33(i) * fibl(1, indfib)
        b(istupd+ix1(ie)) = max(b(istupd+ix1(ie)),fibl(1,indfib))
        b(istupd+ix2(ie)) = max(b(istupd+ix2(ie)),fibl(1,indfib))
        b(istupd+ix3(ie)) = max(b(istupd+ix3(ie)),fibl(1,indfib))
        b(istupd+ix4(ie)) = max(b(istupd+ix4(ie)),fibl(1,indfib))
  240 continue
```

## endif

c Compute hourglass forces and add to internal forces, then c store in appropriate global variables sndspd=sqrt(sndspd\*rho)

return end

```
subroutine sca_get (mtype,csprop,x,ieost,ixp,auxvec1,
     1 stress,lns,nshpnt,lochvs,nel,nmel,ival,val,ipt)
C
С
      Retrieve scalar value in AUX14 for each integration point
          (for shells)
С
С
С
     called by additional contour plots: sca_asc, sca ten, sca dys,
С
С
       call sca get (a(n1), a(n4f), a(lc11), a(n4a), a(lc1s), a(ns06),
      f
                    sig,lns,a(ns13),a(ns14),nel,nmel,ival,val,ipt)
С
C
С
                                             MCDERMOTT / 1999
       C**
      implicit double precision (a-h,o-z)
      include 'nlqpar.inc'
      common/bk19/nconst(60),lenma,ncneos(15)
      dimension mtype(*), csprop(24, *), x(*), ieost(*),
     2 ixp(5,*),auxvecl(*),stress(49,nlq),ix(20),nshpnt(*),lochvs(*),
     3 val(nlq)
      call azero(val,nlq)
      do 10 k=1,nmel
       Get Relevant Pointers and offsets
С
       nel = nel+1
       nnel = nshpnt(nel)
       lav = lochvs(nnel)
       call unpk(mx,ix,ixp(1,nnel),2)
      mte = mtype(mx)
      nes = ieost(mx)
       nmtcon = 7+nconst(mte)+ncneos(max0(nes,1))
       Extract value for desired integration point
С
      ind = (ipt-1)*nmtcon
       call blkcpy(auxvec1(lav+ind), stress(1, k), nmtcon)
       val(k) = stress(ival, k)
   10 continue
      return
```

```
subroutine sets44(cm)
      implicit double precision (a-h,o-z)
     dp
              *****
c ***
                                                   *******
c called by matin to set parameters for material type 44
С
С
  call sets44 (cm(1,n))
                                       McDermott 1999
С
c ***********
                                                  ******
                                           ******
      dimension cm(48), strain(16), stress(16), slope(16)
       Number of segments in stress-strain curve
С
    . iseg=int(cm(11))
      estrain = cm(4) / cm(1)
       Copy endpoints to temp array
С
      do 10 i=1,16
       strain(i)=cm(i+11)
       stress(i) = cm(i+27)
   10 continue
      Calculate slopes
С
      if (iseg.ge.1) then
       slope(1) = (stress(1)-cm(4))/(strain(1)-estrain)
       if (iseg.ge.2) then
       do 20 i=2, iseg
        slope(i) = (stress(i)-stress(i-1))/(strain(i)-strain(i-1))
   20
      endif
     endif
      Redo cm array (zero unused values)
С
     do 30 i=1,16
      if (iseg.ge.i) then
       cm(2*(i-1)+12) = slope(i)
       cm(2*(i-1)+13) = strain(i)
      else
       cm(2*(i-1)+12) = 0.0
       cm(2*(i-1)+13) = 0.0
      endif
  30 continue
     return
```

```
subroutine shl44s (cm, capa)
      implicit double precision (a-h,o-z)
      include 'nlqpar.inc'
                                C
С
      Elastic-plastic isotropic material with void growth and nucleation
        and piecewise-linear stress-strain curve
С
                                                  McDermott 1999
С
        С
      common/bk02/iburn, isdo, dt1, dt2
      common/aux2/d1(nlg), d2(nlg), d3(nlg), d4(nlg), d5(nlg), d6(nlg),
     1 wzzdt(nlq),wyydt(nlq),wxxdt(nlq),einc(nlq)
       common/aux14/
     1 sig1(nlg), sig2(nlg), sig3(nlg), sig4(nlg),
     2 sig5(nlq), sig6(nlq), ep(nlq), epx1(nlq), epx2(nlq),
     3 epx4(nlq), epx5(nlq), epx6(nlq), epx3(nlq), effs(nlq),
     4 phi(nlq),sig0(nlq),aux(nlq,55)
      common/aux18/dd(nlq), def(nlq)
     common/aux33/
     1 ix1(nlq), ix2(nlq), ix3(nlq), ix4(nlq), ixs(nlq,4), mxt(nlq)
     common/aux35/rhoa(nlq), cb(nlq), davg(nlq), p(nlq)
     common/aux36/lft,llt
      common/sound/sndspd, sndsp(nlq), diagm(nlq), sarea(nlq), dxl(nlq)
     common/hourg/ymod,gmod,ifsv
     common/hour11/ebar(nlq), ebarmn(nlq), eyld(nlq), etanmd(nlq)
     common/failul/sieu(nlq),failu(nlq)
     common/ssbsis/h(8,5,5), hpr(8,5,5), hps(8,5,5), hpt(8,5,5), ipt,
    1 nip,wgts(5,5),zet(5,5)
     dimension fail(nlq), cm(*), strain(20), slope(20)
     data eps/1.0e-4/
c Retrieve Material Properties from CM array
     mx=48*(mxt(lft)-1)
     ym=cm(mx+1)
     pr=cm(mx+2)
     phi0=cm(mx+3)
     syp=cm(mx+4)
     q1=cm(mx+5)
     q2=cm(mx+6)
     q3=cm(mx+7)
     fn=cm(mx+8)
     en=cm(mx+9)
     sn=cm(mx+10)
     iseg=int(cm(mx+11))
     ystrain=syp/ym
     strain(1)=ystrain
     if(iseg.gt.0)then
      do 10 i=1, iseg
       slope(i) = cm(mx+10+i*2)
       strain(i+1) = cm(mx+11+i*2)
  10 continue
     endif
     vmod=vm
     gmod=ym/(2.0*(1.0+pr))
     bulk=ym/(3.0*(1.0-2.0*pr))
     sndspd=ym/(1.0-pr**2)
```

c Set up Element Values

```
do 60 i=lft,llt
        einc(i)=dl(i)*sigl(i)+d2(i)*sig2(i)+d4(i)*sig4(i)+d5(i)*sig5(i)
      1
              +d6(i)*sig6(i)+d3(i)*sig3(i)
       plastrn = ep(i)
       phit = phi(i)
       stress0 = sig0(i)
        sgl=sigl(i)+sndspd*(dl(i)+pr*d2(i))
        sq2=siq2(i)+sndspd*(pr*dl(i)+d2(i))
       sq3=siq3(i)+ym*d3(i)
       sg4=sig4(i)+gmod*d4(i)
       sg5=sig5(i)+sfac*gmod*d5(i)
       sg6=sig6(i)+sfac*gmod*d6(i)
       press=third*(sg1+sg2+sg3)
       s1=sg1+press
       s2=sg2+press
       s3=sq3+press
       q=sqrt(1.5*(s1**2+s2**2+s3**2+2.0*sq4**2+
      1
             2.0*sg5**2+2.0*sg6**2))
       F=(q/stress0)**2+2.0*q1*phit*
            cosh(-1.5*q2*press/stress0)-(1.0+q3*phit**2)
      1
       if (F.gt.0.0) then
        iter = 0
        dep = 0.0
        deq = 0.0
c Begin Iteration Loop
        c1=3.0*q2/(2.0*stress0**2)
  · 20
        Fq1=2.0*q/(stress0**2)
        Fq2=2.0/(stress0**2)
        Fp1=-2.0*ql*phit*cl*sinh(-cl*press)
        Fp2=2.0*q1*phit*c1**2*cosh(-c1*press)
        Fs1=-q**2/(2.0*stress0**3)+2.0*q1*phit*c1*press*sinh(-c1*press)
        Fsp=2.0*q1*phit*(-c1**2*press*cosh(-c1*press)+c1/stress0*
      1
                   sinh(-cl*press))
        Fsq=-q/stress0**3
c Get Partial of Yield Stress with respect to dep
        stress1 = syp
        es1 = stress0/ym
        e1 = -press*dep/((1-phit)*stress0)
        ps1 = plastrn + e1 + es1
        iflag = 0
        do 30 j=1,iseg
         if(iflag .eq. 0) then
    if(ps1 .lt. strain(j+1))then
           stress1 = stress1 + slope(j)*(psl-strain(j))
           iseg1 = j
           iflag = 1
          else
           stress1 = stress1 + slope(j)*(strain(j+1)-strain(j))
          endif
         endif
   30
        continue
           Numerical Error Trap
        if((stressl.eq.stress0) .or. (abs(e1) .eq. 0.0)) then
         dsdep = slope(iseg1)
        else
         dsdep = (stress1-stress0)/e1
        endif
        if (abs(dsdep) .gt. ym) dsdep = slope(iseg1)
                                    114
```

С

```
c Get Partial of Yield Stress with respect to deq
         stress1 = syp
         e1 = q*deq/((1-phit)*stress0)
         psl = plastrn + el
         iflag = 0
         do 40 j=1,iseg
          if(iflag .eq. 0) then
           if(ps1 .lt. strain(j+1))then
            stress1 = stress1 + slope(j)*(ps1-strain(j))
            iseq1 = j
            iflag = 1
           else
            stress1 = stress1 + slope(j)*(strain(j+1)-strain(j))
          endif
         endif
   40
        continue
            Numerical Error Trap
C
         if((stressl.eq.stress0) .or. (abs(e1) .eq. 0.0)) then
         dsdeq = slope(iseg1)
        else
         dsdeq = (stress1-stress0)/e1
        endif
        if (abs(dsdeq) .gt. ym) dsdeq = slope(iseg1)
c Apply Newtons Method
        a22 = bulk*Fp1+Fs1*dsdep
        a12 = 3.0 \times gmod \times Fq1 + Fs1 \times dsdeg
        a21 = -(Fq1+deq^*(bulk^*Fp2+Fsp^*dsdep)+dep^*Fsq^*dsdep)
        all = Fpl+dep*(-3.0*gmod*Fg2+Fsg*dsdeg)+deg*Fsp*dsdeg
        deta = a11*a22-a12*a21
        all = all/deta
        a12 = a12/deta
        a21 = a21/deta
        a22 = a22/deta
        b1 = -1.0 * F
        b2 = -1.0*dep*Fq1-deq*Fp1
        dep = dep + a11*b1 + a12*b2
        deq = deq + a21*b1 + a22*b2
c Reset Key Parameters
        phit = phi(i)
        plastrn = ep(i)
        stress0 = sig0(i)
c Plastic Strain
        deplst1=dep/3.0+1.5*deq*s1/q
        deplst2=dep/3.0+1.5*deg*s2/g
        deplst3=dep/3.0+deq*sg3/q
        deplst4=1.5*deq*sg4/q
        deplst5=1.5*deq*sg5/q
        deplst6=1.5*deq*sg6/q
        degrowth = deplst1+deplst2+deplst3
c Adjust stress, q, pressure, etc.
        sgl = sigl(i) + sndspd*((dl(i)-deplst1)+pr*(d2(i)-deplst2))
        sg2 = sig2(i) + sndspd*(pr*(d1(i)-deplst1)+(d2(i)-deplst2))
        sg3 = sig3(i) + ym*(d3(i)-deplst3)
        sg4 = sig4(i) + gmod*(d4(i)-deplst4)
        sg5 = sig5(i) + sfac*gmod*(d5(i)-deplst5)
                                    115
```

```
sq6 = siq6(i) + sfac*qmod*(d6(i)-deplst6)
         press = third*(sg1+sg2+sg3)
         s1 = sg1 + press
         s2 = sg2 + press
         s3 = sg3 + press
c Calculate Increase in Plastic Strain (must be > 0)
         deltep = (q*deq-press*dep)/((1-phit)*stress0)
         if (deltep .lt. 0.0) deltep = 0.0
        plastrn = plastrn + deltep
c Compute Void Nucleation and Growth
         if(fn .ne. 0.0) then
         anucl = fn/(sn*2.50662827463)*exp(-0.5*((plastrn-en)/sn)**2)
        else
         anucl = 0.0
        endif
        phi1 = phit+(1-phit)*degrowth+anucl*deltep
c Decrease in porosity not allowed
        if(phi1.gt.phit) phit = phi1
c Turn off void effects if q1 is set to zero (elastic-plastic only)
        if(q1 .eq. 0.0) phit = 0.0
c Calculate Strain Hardening
        iflag = 0
        ps1 = plastrn + stress0/ym
        stress0 = syp
        do 50 j=1, iseg
         if(iflag.eq.0) then
          if(ps1.lt.strain(j+1)) then
           estrain = -stress0/vm
           stress0 = stress0 + slope(j)*(ps1-strain(j))
             estrain = estrain + stress0/vm
             stress0 = stress0+slope(j)*estrain
          iflag = 1
          else
           stress0 = stress0 + slope(i)*(strain(j+1)-strain(j))
             ps1 = plastrn + stress0/ym
          endif
         endif
   50
        continue
c Calculate new Yield Function
        q=sqrt(1.5*(s1**2+s2**2+s3**2+2.0*sq4**2+
            2.0*sg5**2+2.0*sg6**2))
      1
        F=(g/stress0)**2+2.0*g1*phit*
      1
            cosh(-1.5*q2*press/stress0)-(1.0+q3*phit**2)
        iter = iter+1
c Check for failure to converge
        if(iter.gt.500) then
          write(*,*) 'SHL44S - Failed to Converge'
            call adios(2)
        endif
        if(abs(F).gt.eps) goto 20
       else
c No increase in plastic strain, set tensor to zero
        deplst1=0.0
        deplst2=0.0
```

```
116
```

```
deplst3=0.0
        deplst4=0.0
        deplst5=0.0
        deplst6=0.0
       endif
c DONE! Load up all required variables
       sig0(i) = stress0
      p(i) = press
       sigl(i) = sgl
       sig2(i) = sg2
       sig3(i) = sg3
       sig4(i) = sg4
       sig5(i) = sg5
       sig6(i) = sg6
       ep(i) = plastrn
       epx1(i) = epx1(i) + deplst1
       epx2(i) = epx2(i) + deplst2
       epx3(i) = epx3(i) + deplst3
       epx4(i) = epx4(i) + deplst4
       epx5(i) = epx5(i) + deplst5
       epx6(i) = epx6(i) + deplst6
       phi(i) = phit
       ebar(i) = ym
       cb(i)=sndspd
       davg(i)=third*(d1(i)+d2(i)+d3(i))
       effs(i) = q
       einc(i)=d1(i)*sig1(i)+d2(i)*sig2(i)+d4(i)*sig4(i)+d5(i)*sig5(i)
             +d6(i)*siq6(i)+einc(i)+d3(i)*sig3(i)
     1
```

```
eyld(i)=stress0
60 continue
```

return



## APPENDIX C. DYSMAS MODIFIED SUBROUTINE LISTINGS.

blockdata blkdat
implicit double precision (a-h,o-z)
dp

include 'nlqpar.inc'

c c \*\*\*\*\*\* Added Number of material constants for material type 44 -McDermott '99

data nconst/0,17,5,3,0,6,12,3,3,4,4,0,1,2,5,6,10,5,2,0,20,14, 1 2,0,2,0,12,5,5,9,12,18,25,0,20,44,11,8,10,25,14,5,26,16,16\*0/

end

С

subroutine dynai (inelflg) implicit double precision (a-h,o-z)

\*\*\*\* Added Support for Kwon-McDermott Shell Element Formulation С (Only change is in format statement 227) - McDermott '99 С C \*\*\* Changed 227 to add Kwon-McDermott Formulation - McD 227 format( \$10x, 'eq.1: hughes-liu shell theory \$10x, 'eq.2: belytschko-lin-tsay shell theory \$10x, 'eq.3: 11 bciz \$10x, 'eq.4: cO-triangular element 1/ \$10x, 'eq.5: 1/ membrane element \$10x, 'eq.6: yase \$10x, 'eq.7: QPHM 1 \$10x, 'eq.8: kwon-mcdermott shell 111 \$ 4x, 'number of non-reflecting boundary segments.....',i7// \$ 4x, 'number of single point constraint nodes......',i7// \$ 4x, 'number of spc coordinate system definitions....',i7// \$ 4x, '# of user specified beam integration rules.....', i7// \$ 4x, 'max number of integration points reqd (beams) .',i7// \$ 4x, '# of user specified shell integration rules....', i7// \$ 4x, 'max number of integration points reqd (shells).', i7// \$ 4x, 'convergence check interval (dynamic relaxation)', i7// \$ 4x, 'convergence tolerance for dynamic relaxation...', e10.2/)

```
subroutine elem2d(ixp,x,rhs,vt,vr,strain,yhatn,fibl,auxvec,
     lmtype, ro, cm, csprop, nsubgv, mtnum, nfegp, ihgq, hgq, xies, ener, rule,
     2mpusr, ishlfm, tfail, isf, lochvs, qextra, nshel, nncs, iblks,
     3 dampk, ym, pr, fails)
      implicit double precision (a-h,o-z)
     dp
      include 'nlqpar.inc'
С
      main subroutine for calling two-dimensional elements
С
С
 *** Added Kwon-McDermott Shell Formulation - McDermott 1999
С
С
С
C ******
c Kwon-McDermott Shell Formulation
      elseif (iop.eq.8) then
         call kwnmcd(rule, ixp, x, rhs, vt, vr, strain, yhatn, fibl, auxvec,
               mtype, ro, cm, csprop, nsubgv, mtnum, nfegp, ihgq, hgq, xies, ener,
     1
               mpusr,lav,nmel,nnm1,mxe,iblks,dampk(mxe),ym(mxe),pr(mxe),
     2
     3
                a(ns02+6*nnm1))
```

endif

. end

C

```
subroutine fem3d(mtype,ro,cm,ic,bcs,npc,pld,nod,idirn,ncur,clfac,
      ilc,nvel,vx,vy,vz,fval,rd,ilcw,nsw,numtp,nodtie,tim,iparm,irects,
      2irectm, nsv, msr, nsegs, nsegm, lnsv, lmsr, ilocs, ilocm, stfs, stfm,
      3irtls, irtlm, xmsm, e, crst, b, tcode, u, v, a, x, xms, ac, nsubgv, mtnum,
      4nfegp,auxvec,rhsi,zfac,ieost,eosp,ihgq,hgq,iqtype,bkqs,rbu,rbv,
      5rba, rbi, rbm, rbcor, nrbn, nrba, nrb, xrb, yrb, zrb, axrb, ayrb, azrb,
      6rbfx, rbfy, rbfz, rbcods, mxrb, xyzkcn, lpntbk, lbcket, chrlen, ethik,
      7fric, iseg, fdat, fthik, icls, irctsi, irctmi, ilcf, itcode, atcode, ifo,
      8slvfrc,msrfrc,ener,rots,failz,sfail,fl9s,tfail,isf,drdsps,nnfpln,
      9thkslv, thkmsr, failh, fails, ihlsnd, islsnd, ifalhl, ifalsl, ihl2sg,
      lisl2sg, isg2el, iacthl, iactsl, irecta, stfa, thka, isndsc, stfsnd,
      2thksnd, thicks, ishltp, islfm, xnew, ftemp, xls, xlm, cntrls, vract, mlbf,
      3bfact, rectd, xndchr, thkseg, ityptp, iclsa, lclsa, nclsa, accslv, accmsr,
         4cornew,tmad,madmat,dbldat)
cfu
      4cornew,tmad,madmat,dbldat,pfric,weldf)
C****
****
С
c *** Fixed bug in disp,vel,accel,etc. plot file write counter -
McDermott 1999
С
if(ncycle.ge.1)goto 10
cte
      output=.false.
      ncedit=0
      ioatb=0
      nfedit=0
C
c.... check for variable plot interval, get load curve number
С
      ipltlc=0
      if( pltc .lt. 0. ) then
      ipltlc=abs(pltc)
      endif
c *** Changed from pltout=pltc to pltout=0. to print 1st time step - McD
99
BUG FIX FOR PRINTOUT INTERVAL - MCDERMOTT
С
    There appears to be code already written to do this, but some
С
    are commented out. This was a temporary fix I implemented.
С
C
      if (tt.lt.prtout) go to 160
      prtout=prtout+prtc
      if (prtc.gt.endtim) go to 160
                  *******
end
```

```
subroutine in3dis(x,matype,den,prop,csprop,ipss,yhat,fibl,
     1 auxvec,icnt,xnrvec,xmst,xmsr,numels,mx,ix,rbm,strain,beta,
     2 fval,tnew,ishlfm,nshl,fails)
      implicit double precision (a-h,o-z)
     dp
С
c called by ibmsh for shell initialization
C
c shell initialization (compute mass at nodes)
С
      call in3dis(a(lc11),a(n1),a(n2),a(n3),a(n4f),a(lc1s),
С
     1 a(ns03), a(ns05), a(ns06), a(lc10), a(lc10+numnp), a(lc14),
С
     2 a(lc14+numnp), numels, ix, ix(2), a(n53), a(ns01), a(ns04),
Ċ
С
     3 a(n19), a(ntmp1), a(n1+nmmat), a(ns17), a(ns17+numels))
С
С
      a shell element
С
С
 *** Added initialization for material type 44 - McDermott 1999
С
С
С
c *** Kwon-McDermott - Initialize AUXVEC for material 44
С
      if (mte.eq.44) then
       do 17 i=1,nmtcon
   17
        auxvec(i+lav)=0.0
        Set initial porosity and yield stress
С
       do 19 i=1, nip
        auxvec((i-1)*npi+15+lav)=prop(3,mx)
        auxvec((i-1)*npi+16+lav)=prop(4,mx)
   19 continue
      endif
С
    *****
С
С
end
```

```
subroutine matin(ieost, eosp, ihgq, hgq, iqtype, bqs, csprop,
     1 mtype, ishlfm, ro, cm, idfrs, nmmat, lc2, mmauxs, iortho, ifb, isf,
      2 numelh, numels)
       implicit double precision (a-h,o-z)
    dp
\sim
c called by dynai to read in material data
С
       call matin (a(n4a), a(n4b), a(n4c), a(n4c+nmmat), a(n4d), a(n4e),
С
     1 a(n4f),a(n1),a(n1+nmmat),a(n2),a(n3),idfrs,nmmat,lc2,mmauxs,
С
С
     2 iortho, ifb, isf, numelh, numels)
  *** Added Material #44 (Elasto-plastic w/void effects) and allow
С
      Kwon-McDermott shell formulation to have a non-zero reference
C
                                              McDermott 1999
c
c if material type is 41
c.... fabric model
      if (mtype(n).eq.41) then
      ifst=1
      ilst=3
      do 82 j=1,5
      call gttxsg (txts, lcount)
      if (j.eq.1) then
      read (unit=txts,fmt=220,err=200) (cm(i,n),i=ifst,ilst),cm(48,n),
     1 (cm(i,n), i=45, 47)
      elseif (j.eq.2) then
      read (unit=txts,fmt=220,err=200) (cm(i,n),i=ifst,ilst),
     1 \text{ cm}(42,n), \text{cm}(43,n), \text{cm}(44,n), \text{cm}(41,n)
      elseif (j.gt.2.and.j.lt.5) then
      read (unit=txts,fmt=220,err=200) (cm(i,n),i=ifst,ilst)
      elseif (j.eq.5) then
      read (unit=txts,fmt=220,err=200) (cm(i,n),i=ifst,ilst)
      endif
      ifst=ifst+3
      ilst=ilst+3
   82 continue
      call gttxsg (txts, lcount)
      read (unit=txts,fmt=220,err=200) (cm(i,n),i=16,18),(cm(i,n),i=26,3
     1 0)
      endif
c Kwon-McDermott
c material type 44 (Elastic Plastic with Void Effects)
      if (mtype(n).eq.44) then
       call gttxsg (txts, lcount).
       read (unit=txts, fmt=220, err=200) (cm(i,n), i=1, 4)
       call gttxsg (txts,lcount)
       read (unit=txts, fmt=220, err=200) (cm(i,n), i=5, 11)
       iseg=cm(11,n)
       ifst=12
       do 25 j=1,4
        if (j.eq.3) iseg=cm(11,n)
        call gttxsg (txts, lcount)
                                   124
```

```
if (iseg.ge.8) then
         lread = 8
         iseg = iseg - 8
        else
         lread = iseg
         iseg = 0
        endif
        if (lread.gt.0) then
         read (unit=txts,fmt=220,err=200) (cm(i,n),i=ifst,ifst+lread)
        endif
        ifst = ifst + 8
   25 continue
       call sets44(cm(1,n))
       call blkcpy(cm(1,n),prop,48)
      endif
                                  * * * * * * * * * * * * * *
  ***
С
С
c if element type not shell goto 100
С
   90 if (itype.ne.2) go to 100
      \operatorname{csprop}(14,n)=0.0
      \operatorname{csprop}(15,n)=0.0
      \operatorname{csprop}(16,n)=0.0
c *** Changed to allow Kwon-McDermott shell to have non-zero ref - McD
'99
      if ((ishlfm(n).eq.1.and.irnxx.ge.0).or.(ishlfm(n).eq.8)) then
290 format(' ***warning*** the reference surface must be the ',/,
        'midsurface for all shell elements except hughes-liu or',/,
     1
        'kwon-mcdermott.',//)
     2
```

```
subroutine nbsint (irect, bulk, shear, nrt, cm, matype, eosp, ieost,
     1 numelh, bh, jx1, jx7, x, ro, nmmat)
      implicit double precision (a-h,o-z)
    dp
С
c called by initlz
С
c if number of non-reflecting boundary segments (nnrbs) greater
c than zero call subroutine nbsint to initialize transmitting
c boundary segments
С
      if (nnrbs.gt.0) then
С
      call nbsint (b(lrb1),b(lrb2),b(lrb3),nnrbs,cm,mtype,eosp,ieost,
с
     & numelh, ipsh, b(ibins1), b(ibins2), x, ro, nmmat)
с
      endif
С
С
С
 *** Added support for Mat #44 - McDermott 1999
С
if (mt.eq.43) then
      bkm(mx) = cm(48*(mx-1)+1)/3.
      shm(mx) = cm(48*(mx-1)+1)/2.
      endif
c *** Elasto-Plastic with Void Effects
      if (mt.eq.44) then
      bkm(mx) = cm(48*(mx-1)+1)/(3.*(1.-2.*cm(48*(mx-1)+2)))
      shm(mx) = cm(48*(mx-1)+1)/(2.*(1.+cm(48*(mx-1)+2)))
      endif
                ***** McD '99
    ******
```

```
subroutine penstf (x,nrb,xyzkcn,rbncod,ipsh,ipss,ipsb,cm,matype,
     1 eosp, ieost, numelh, numels, numelb, nmmat, ro, zf, thicks, fibers,
     2 ishlfm)
      implicit double precision (a-h,o-z)
    dp
С
c called by initlz to compute locations of extra
c rigid body points
с
      call penstf (x,nrb,xyzkcn,rbncod,ipsh,b(lc1s),b(lc1b),cm,mtype,
С
     leosp,ieost,numelh,numels,numelb,nmmat,ro,zfcs,b(ns05),
С
     2 b(nb05), b(n1+nmmat))
С
С
      if (mt.eq.41)bkm(mx) = cm(mx48m1+21)
     Elasto-Plastic with Void Effects - McD '99
С
      if (mt.eq.44) bkm(mx)=cm(mx48m1+1)/(3.*(1.-2.*cm(mx48m1+2)))
      ******
С
```

```
subroutine printm (n,mod,ro,cm,ieost,eosp,ihgq,hgq,iqtype,bqs,
     1 csprop, head, itype, angles, thrmpr, nip, ishlfm)
      implicit double precision (a-h,o-z)
    dp
С
c called by matin to write out (echo) material properties
c 170 call printm (n, mtype(n), ro(n), cm(1, n), ieost(n), eosp(1, n), ihgq(n)
     1 ,hgq(n),iqtype(n),bqs(1,n),csprop(1,n),head,itype,a(langle),a
С
     2 (lthrpr), nip, ishlfm(n))
С
С
      subroutine to print out material properties
С
С
  *** Added Mate #44 (Elasto-Plastic with Void Effects) - McDermott 1999
С
C
С
      go to (10,20,30,40,50,60,70,80,90,100,110,120,130,140,150,160,170,
     1 180, 190, 10, 200, 210, 230, 250, 260, 270, 272, 30, 274, 30,
         275,276,277,278,279,281,282,283,284,105,107,285,286,287), mod
     1
С
      model - 44 Elastic-Plastic w/Void Growth & Nucleation, piecewise
С
                    linear strain hardening
С
                                               McDermott 1999
с
С
  287 write (13,1700) (cm(i), i=1,10), int(cm(11))
      write (13,1701)
      do 288 id=1,int(cm(11))
       ind1 = 13+2*(id-1)
       ind2 = 12+2*(id-1)
       write (13,1702) (cm(ind1),cm(ind2))
  288 continue
      write (13,1703)
     • go to 280
321 format(
                       closed form update elastic-plastic for shells '/,
     $
                eq.30
     $
                       frazer-nash hyperelastic rubber'/,
                eq.31
     $
                       ramberg osgood elastic-plastic'/,
                eq.32
     $
                       hill general anisotropic plasticity'/,
                eq.33
     $
                       hill normal anisotropic plasticity for shells'/,
                eq.34
     $
                       elastic-plastic with forming limit diagram'/,
                eq.35
                       brittle damage (experimental) '/,
     $
                eq.36
     $$ $$ $$ $$ $$ $$ $
                       3-invariant viscoplastic cap '/,
                eq.37
                       bammann plasticity '/,
                eq.38
                eq.39
                       sandia damage '/,
                       fahrenthold brittle damage '/,
                eq.40
                       fabric '/,
                eq.41
                eq.42
                       MTS
                                1.
                       Low Density Polyurethane Foam '/,
                eq.43
                       Elastic-Plastic with Void Effects'//)
     Ś
                eq.44
```

. 810 fo

810	fo:	rmat(											
	\$	5x,'s	shell	form	iu]	Lation						=',	i5/
	\$	5x,'	e	q. 1	:	hughes-1	iu					·	1/
	\$	·5x, '	e	q. 2	:	belytsch	ko-ts	say					'/
	\$	5x,'	e	ą. 3	:	bciz		-					
	\$	5x,'	e	q. 4	:	c0-trian	gula	c eler	ner	nt -			1/
	\$	5x,'	e	ą. 5	:	membrane	eler	nent				· · · .	3.1
	\$	5x,'	e	q. 6	:	yase							1/
	\$	5x,'	e	q. 7	:	QPHM							11
	\$	5x,'	e	q. 8	:	kwon-mcd	ermot	t ele	eme	ent			1//
	1	5x,'f	fiber 1	leng	tł	ns:		node	1	• • •		≈',	e12.4/
	2	5x,'						node	2	• • •		=',	e12.4/
	3	5x,'						node	3	• • •		=',	e12.4/
	4	5x,'						node	4	• • •		.=',	e12.4//
	5	5x,'r	refere	nce	su	irface:		node	1	• • •	• • • •	≈',	e12.4/
	6	5x,'	e	q. 1	.0	):top	-	node	2	• • •		<b>≃'</b> ,	e12.4/
	.7	5x,'	e	q. O	. (	):middle		node	3	• • •		≈',	e12.4/
	8	5x,'	e	71	.0	):bottom		node	4	• • •		≈',	e12.4//
•						r							
•													
1700	fo	ormat (			· _								

1	5x, 'youngs modulus =', e12.4/
2	5x, 'poissons ratio =', e12.4/
3	5x, 'initial porosity =', e12.4/
4	5x, 'yield stress =', e12.4/
5	5x, 'q1 of gursons model =', e12.4/
6	5x, 'q2 of gursons model =', e12.4/
7	5x, 'q3 of gursons model =', e12.4/
8	5x, 'void nucleation content (fn) =', e12.4/
9	5x, 'mean nucleation strain (en) =', e12.4/
1	5x, 'nucleation standard deviation (sn) =', e12.4/
2	5x, 'number of segments in hardening $\dots =', i5/$
1701 f	ormat(
1	5x, 'stress strain curve points:',/
2	7x, 'strain slope')
1702 f	ormat(5x,e12.4,' ',e12.4)
1703 f	ormat(/)
c	

```
subroutine prtdat (mpri,nfegp,nsubgv,u,b,x,mtnum,cm,accls)
      implicit double precision (a-h, o-z)
     dp
С
c called by fem3d at various time during the solution
c phase to write taurus database
c two types of calls
С
       call prtdat (-1, nfegp, nsubgv, u, b, x, mtnum, cm, a)
С
С
       call prtdat (+1,nfegp,nsubgv,u,b,x,mtnum,cm,a)
С
С
The logic for mpri was incorrect: previously if mpri > 0 and mkthf
С
      = 0, the same action is taken as if mpri < 0. This causes the
С
disp,
      velo, and contour files to written twice at each print step. New
С
      logic applied so that it works as it appears it should:
С
С
           mpri = -1 \rightarrow print disp, geometry, velo, contours, etc.
           mpri = +1 -> print history files iff mkthf ne 0
с
                                   McDermott 1999
C
c *** This code causes the plot files to be written twice at each print
step
      New logic applied. McD - '99
if ( mpri .gt.0 .and. mkthf .ne. 0 ) go to 130
с
С
      if(mpri.lt.0) go to 10
С
```

if (mpri.gt.0) goto 130

end

С

SUBROUTINE SCA ASC ( X, V, ACC, X0, NCPOUT, A, PFRIC) С С CALLED BY PRTDAT TO WRITE SCALAR PLOT FILES (ASCII-FORMAT) С REIHENFOLGE WICHTIG !!! С 1.) VOLUMENELEMENTE С 2.) BALKENELEMENTE С 3.) SCHALENELEMENTE С 4.) DICKE SCHALENELEMENTE С C.. CALL SCA ASC (A(LC11), A(LC9), A(LC10), A(LC13), A(NCPLL), A(1), A(LC12)) С c Added Code for AUX14 variables #15 and 16 (Porosity and Yield stress in Material #44) - McDermott - '99 С C\* \*\*\*\* Used for SCA GET - McDermott С dimension val(nlg) С С С SHELL ELEMENTS С 140 IF (NUMELS.EQ.0) GOTO 240 NELG=NUMELS/nlq IF (nlq\*NELG.LT.NUMELS) NELG=NELG+1 C NEL=0 c Seperate Counter for SCA GET - McDermott nelget=0 NUMEL = NUMELH + NUMELB + NUMELS DO 200 NN=1, NELG NMEL=nlq IF (NN.EQ.NELG) NMEL=NUMELS-nlq\*(NELG-1) LNS=49CALL SCALARS (A(N1), A(N4F), A(LC11), A(N4A), A(LC1S), A(NS05),F A(NS06), A(NS03), A(NS01), SIG, LNS, A(NS07), A(N4H), F MPUSR, A(N1+NMMAT), A(NSTSL), A(NS13), A(NS14), NEL, F NMEL, A(NSO2), EMAIN) С \*\*\*\*\* Changed to support Void Material (#44) - McDermott С F С F 155, 156, 157, 158, 180, 180, 180, 180, 180, 180, 165, 180, 180, 180, 180, 170,171,172,173,174,175,176,177,178,179) K F C \*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\* Support for Void Material (#44) - McDermott С Void Content С 157 continue ival=15 call sca get (a(n1), a(n4f), a(lc11), a(n4a), a(lc1s), a(ns06), sig, lns, a (ns13), a (ns14), nelget, nmel, ival, val, iint) 1 do i=1,nmel i1 = i + (nn-1)\*nlq

```
write(91, '(1x, i7, 1x, E12.5)') i1, sngl(val(i))
       end do
С
      goto 200
c
  Yield Stress
С
  158
      continue
       ival=16
       call sca_get (a(n1),a(n4f),a(lc11),a(n4a),a(lc1s),a(ns06),
             sig,lns,a(ns13),a(ns14),nelget,nmel,ival,val,iint)
     1
       do i=1,nmel
        i1 = i + (nn-1)*nlq
        write(91,'(1x,i7,1x,E12.5)') i1,sngl(val(i))
       end do
С
      goto 200
      *******
                                                  *******
С
```

END

```
SUBROUTINE SCA DYS ( X, V, ACC, X0, NCPOUT, A, PFRIC)
С
C.. CALLED BY PRTDAT TO WRITE SCALAR PLOT FILES (DYSMAS/P FORMAT)
C
C.. CALL SCA DYS (A(LC11),A(LC9),A(LC10),A(LC13),A(NCPLL),A(1),A(LC12))
С
С
   Added Support for printing aux14 variables 15 and 16 (porosity and
С
     yield stress in Mat #44 - McDermott 1999
C۶
  **** Used for SCA GET - McD '99
С
      dimension val(nlq)
С
С
              ELEMENTS
   SHELL
C
  140 IF (NUMELS.EQ.0) GOTO 240
      NELG=NUMELS/nlq
      IF (nlq*NELG.LT.NUMELS) NELG=NELG+1
      ikon=ikon+1
С
      NEL=0
c Seperate Counter for SCA_GET - McDermott
      nelget=0
      NUMEL = NUMELH + NUMELB + NUMELS
      NUMEL1 = NUMELH + NUMELB
      DO 200 NN=1, NELG
      NMEL=nlq
       IF (NN.EQ.NELG) NMEL=NUMELS-nlg*(NELG-1)
       LNS=49
      CALL SCALARS (A(N1), A(N4F), A(LC11), A(N4A), A(LC1S), A(NS05),
    F
                   A(NS06), A(NS03), A(NS01), SIG, LNS, A(NS07), A(N4H),
    F
                   MPUSR, A (N1+NMMAT), A (NSTSL), A (NS13), A (NS14), NEL,
    F
                                              NMEL, A(NSO2), EMAIN)
  **** added 57 and 58 - McD
С
      С
     F
    F
         155, 156, 157, 158, 180, 180, 180, 180, 180, 180, 165, 180, 180, 180, 180,
    F
           170,171,172,173,174,175,176,177,178,179) K
C
 ******************* Support for Void Material (#44) - McD '99
С
  Void Content
С
  157
      continue
      ival≈15
      call sca get (a(n1), a(n4f), a(lc11), a(n4a), a(lc1s), a(ns06),
    1
            sig,lns,a(ns13),a(ns14),nelget,nmel,ival,val,iint)
      do i=1,nmel
       il = i + (nn-1)*nlq
       write(91,'(1x,i7,1x,E12.5)') i1,sngl(val(i))
      end do
С
     goto 200
С
```

```
133
```

END
SUBROUTINE SCA TEC ( ACC, NCPOUT, A, PFRIC, nhxpnt,nshpnt,ntxpnt,ixh,ixs,ixt,ss,ival ) 1 С CALLED BY PRTDAT TO WRITE SCALAR PLOT FILES (TECPLOT-FORMAT) С С REIHENFOLGE WICHTIG !!! С 1.) VOLUMENELEMENTE С 2.) BALKENELEMENTE (werden von TECPLOT nicht С unterstuetzt) С 3.) SCHALENELEMENTE С 4.) DICKE SCHALENELEMENTE С С CALL SCA TEC ( A(LC10), A(NCPLL), A(1), A(LC12)) С С Fuchs '97 \*\*\* Variables written to scratch file must be same precision as С variable used to read back - fixed (removed sngl()), added С support for aux14 variables #15 and 16 (Porosity and Yield stress for С Material #44 - McDermott '99 С C\*\*\*\*\*\* implicit double precision (a-h,o-z) dp include 'nlqpar.inc' COMMON/BK00/NUMNP, NUMPC, NUMLP, NEQ, NDOF, NLCUR, NUMCL, NUMVC, NDTPTS, NELMD, NMMAT, NUMELH, NUMELB, NUMELS, NUMELT, NUMDP, 1 2 GRVITY, IDIRGV, NODSPC, NSPCOR cfu common/bk03/endtim, prtc, pltc, ndthl, nsthl, nstsl, nstbl, nsttl, mkthf common/bk03/endtim,prtc,pltc,ngthl,ndthl,nsthl,nstsl,nstbl, 1 nsttl, ncpll, mkthf COMMON/BK04/PRTOUT, PLTOUT, DT2OLD, SLSFAC, TSSFAC, IHYDRO, NDTH, NMST, NSTH, NSTS, NSTB, NSTT, IKEDIT cfu 1 1 ngth,ndth,nmst,nsth,nsts,nstb,nstt,ncpl,ikedit COMMON/BK05/ 1 NH01, NH02, NH03, NH04, NH05, NH06, NH07, NH08, NH09, NH10, 2 NB01, NB02, NB03, NB04, NB05, NB06, NB07, NB08, NB09, NB10, 3 NS01, NS02, NS03, NS04, NS05, NS06, NS07, NS08, NS09, NS10, 4 NT01, NT02, NT03, NT04, NT05, NT06, NT07, NT08, NT09, NT10 REAL\*8 HEAD VAX750 common/bk06/time(2,8),head(12),idmmy,iadd,ifil,maxsiz,ncycle common/bk07/n1,n2,n3,n4,n5,n6,n7,n8,n9,n10,n11,n12,n13,n14,n15, 1 n16,n17,n18,n19,n20,n21,n22,n23,n24,n25,n26,n27,n28,n29,n30,n31, 2 n32,n33,n34,n35,n36,n37,n38,n39,n40,n41,n42,n43,n44,n45, 3 n46,n47,n48,n49,n50,n51,n52,n53,n54,n55,n56,n57,n58,n59,n60,n61, 4 n62,n63,n64,n65,n66,n67,n68,n69,n70,n71,n72,n73,n74,n75,n76,n77, 5 n78, n79, n80, n81, n82, n83, n84, locend, iname, lend common/bk08/n4a,n4b,n4c,n4d,n4e,n4f,n4g,n4h,n7a,n7b,n7c,n7d,n7e, 1 nusir, mpusr, mpubr COMMON/BK13/LC0, LC1H, LC1B, LC1S, LC1T, LC2, LC3, LC4, LC5, LC6, LC7, LC9, LC10, LC11, LC12, LC13, LC14, LC15, LC16, LC17, LC18, LB0, LB1, LB2, 1 LC7A, LC7B COMMON/BK20/NUMSV, JU, JV, NRTM, NRTS, NMN, NSN, NTY, NST, MST, NOCO COMMON/BK28/SUMMSS, XKE, XPE, TT COMMON/AUX14/SIG(49,nlq) COMMON/SHLOPT/ISTRN, ISTUPD, IBELYT, MITER common/sorter/nnc,lczc, & ns11, ns12, ns13, ns14, ns15, ns16, ns17, & nh11, nh12, nh13, nh14, nh15, nh16, nh17, & nt11,nt12,nt13,nt14,nt15,nt16,nt17, 135

& nb11, nb12, nb13, nb14, nb15, nb16, nb17 COMMON/INKTH/ INCHIS, NPOST, NDISP, NVELO, NCYREM, 1 NSTRESS, NSTRAIN CHARACTER\*8 DATU, VS CHARACTER\*60 SBTEXT(20) COMMON/VSNUM/VS, DATU CHARACTER MOFI\*13, COD\*3, COD1\*6, GEOTIT\*13 CHARACTER VARCHAR\*84, ELT\*27 С DIMENSION ACC(3,\*), NCPOUT(\*), A(\*) DIMENSION VLSTRAI(7,nlq), PFRIC(\*), EMAIN(6,nlq) DIMENSION SS(\*), VAL1(7), IVAL(\*) dimension ixh(9,\*), ixs(5,\*), ixt(9,\*) dimension nhxpnt(\*),nshpnt(\*),ntxpnt(\*) c \*\*\*\* Used for SCA GET - McD 99 dimension val(nlq) С IF ( NCPL .EQ. 0 ) RETURN С DO 500 J=1,NCPL II=0K=NCPOUT (J) IF (K.GE.81.AND.K.LE.99) GOTO 500 С WRITE (COD1, '(I6)') NCYCLE WRITE (COD, '(I3)') K IF (K.LT.100) COD(1:1)='0' IF (K.LT.10) COD(2:2)='0' С IF (NCYCLE.LT.100000) COD1(1:1)='0' IF (NCYCLE.LT.10000) COD1(2:2)='0' IF (NCYCLE.LT.1000) COD1(3:3)='0' IF (NCYCLE.LT.100) COD1(4:4)='0' IF (NCYCLE.LT.10) COD1(5:5)='0' С MOFI(1:3) = 'TEC'MOFI(4:9) = COD1MOFI(10:13)='.'//COD C IINT=1 IF (K.GT.99) THEN K=NCPOUT (J) /10 IINT=NCPOUT (J)-10\*K ENDIF С IF ( K .LE. 40 .AND. K .NE. 19) GOTO 500 IF ( K .GE. 43 .AND. K .LE. 54 ) GOTO 500 С OPEN (UNIT=91, POSITION='REWIND', STATUS='SCRATCH', FORM='UNFORMATTED') 1 OPEN (UNIT=93, STATUS='UNKNOWN', FILE=MOFI, FORM='FORMATTED') С IF (K.EQ.19) GOTO 19 GOTO 40 KNOTNWERTE С С C 136

```
,500,19)K
      1
С
   BESCHLEUNIGUNGEN
С
Ċ
     1 CALL KNO ASC (ACC, 1, NUMNP)
С
       GOTO 490
С
     2 CALL KNO ASC (ACC, 2, NUMNP)
С
       GOTO 490
С
     3 CALL KNO ASC (ACC, 3, NUMNP)
С
       GOTO 490
C
                  (noch nicht im richtigen TECPLOT-Format implementiert)
С
  REIBLEISTUNG
С
   19 CONTINUE
      KTYP=0
      MW=1
      LF=1
      WRITE(93, '(315)') KTYP, MW, LF
      WRITE(93,*) ' '
      WRITE(93,*) ' '
      DO 5291 IS=1, numnp
         WRITE (93, '(1X, I7, 1X, E12.5)') IS, sngl(PFRIC(IS))
 5291
      GOTO 490
С
  ELEMENTWERTE
С
С
   40 K=K-40
      DUMMY=0.
С
С
  HEXAHEDRONS
С
      IF ( NUMELH .EQ. 0 ) GOTO 140
      NELG=NUMELH/nlq
      IF (nlg*NELG.LT.NUMELH) NELG=NELG+1
С
      NEL=0
      DO 100 NN=1, NELG
      NMEL=nlq
      IF (NN.EQ.NELG) NMEL=NUMELH-nlq*(NELG-1)
      CALL SCALARH (A(LC1H),A(LC15),A(N1),A(NH13),A(NH14),A(NH04),
     1
                    VLSTRAI, NEL, NMEL)
С
      80,80,80,58,80,80,80,80,80,80,65,80,80,80,80,
     F
            80,80,80,80,80,80,80,80,80,80,80) K
     F
С
C HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG
C
   41 DO 410 J1=1,NMEL
        WRITE (91) SIG(8, J1)
 410
      GOTO 100
С
C PLAST. VERGLEICHSDEHNUNG
C
   42 DO 420 J1=1,NMEL
        WRITE (91) SIG(7,J1)
 420
      GOTO 100
C P-HYD
   58 DO 580 J1=1,NMEL
 580
        WRITE (91) SIG(20, J1)
      GOTO 100
C EQUIVALENT STRAIN RATE
```

```
137
```

```
65 DO 650 J1=1,NMEL
 650
         WRITE (91) VLSTRAI(7, J1)
      GOTO 100
С
С
    BEI GROESSEN, DIE FUER VOLUMENELEMENTE NICHT ZUR VERFUEGUNG STEHEN
С
    MUESSEN BEI GEOMETRIEN MIT GEMISCHTEN ELEMTTYPEN DIESE FELDER MIT
С
    NULL BELEGT WERDEN
C
   80 DO 81 J1=1, NMEL
 81
      WRITE(91) DUMMY
  100 CONTINUE
С
С
   BEAM ELEMENTS
С
  140 IF ( NUMELB .EQ. 0 ) GOTO 240
      NELG=NUMELB/nlq
      IF (nlq*NELG.LT.NUMELB) NELG=NELG+1
С
      NEL=0
      DO 300 NN=1, NELG
      NMEL=nlq
      IF (NN.EQ.NELG) NMEL=NUMELB-nlq*(NELG-1)
      LNS=7
      CALL SCALARB (A(NB04), A(NB13), SIG, NMEL, NEL, LNS)
C
С
   !! KEINE !!
С
  HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG
                                         UND
С
   SPANNUNGEN IM GLOBALEN KOORD.-SYST.
С
   SIG-XX, SIG-YY, SIG-ZZ, SIG-XY, SIG-YZ, SIG-ZX
С
С
  PLAST. VERGLEICHSDEHNUNG UND
С
  DEHNUNGEN IM GLOBALEN KOORD.-SYST.
С
   11
       VORHANDEN !!
C
С
     F
         F
           270,271,272,280,274,275,280,277,280,280) K
C
С
  RESULTIERENDE SCHNITTLASTEN
С
С
     MOMENT-S
 270 DO 27 J1=1,NMEL
 27
        WRITE (91) SIG(4, J1)
     GOTO 300
C
     MOMENT-T
  271 DO 28 J1=1,NMEL
 28
        WRITE (91) SIG(5, J1)
     GOTO 300
     TORSION
С
 272 DO 29 J1=1,NMEL
 29
        WRITE (91) SIG(6, J1)
     GOTO 300
     SHEAR-T
C
 274 DO 30 J1=1,NMEL
30
        WRITE (91) SIG(3, J1)
     GOTO 300
С
     AXIAL
 275 DO 31 J1=1,NMEL
31
        WRITE (91) SIG(1,J1)
```

```
138
```

```
GOTO 300
      SHEAR-S
C
  277 DO 32 J1=1,NMEL
         WRITE (91) SIG(2, J1)
 32
      GOTO 300
  280 DO 33 J1=1, NMEL
         WRITE (91) DUMMY
 33
  300 CONTINUE
Ċ
С
   SHELL ELEMENTS
C
  240 IF ( NUMELS .EQ. 0 ) GOTO 340
      NELG=NUMELS/nlq
      IF (nlg*NELG.LT.NUMELS) NELG=NELG+1
С
      NEL=0
 *** New counter to support SCA_GET - McDermott
C
      nelget=0
      DO 200 NN=1, NELG
      NMEL=nlq
      IF (NN.EQ.NELG) NMEL=NUMELS-nlq*(NELG-1)
     LNS=49
     CALL SCALARS (A(N1), A(N4F), A(LC11), A(N4A), A(LC1S), A(NS05), A(NS06),
     F
                  A(NSO3), A(NSO1), SIG, LNS, A(NSO7), A(N4H), MPUSR,
     F
                  A(N1+NMMAT), A(NSTSL), A(NS13), A(NS14), NEL, NMEL,
     F
                  A(NSO2), EMAIN)
С
  *** Added 57 and 58 - McD '99
C
     F
          С
     E.
          155, 156, 157, 158, 180, 180, 180, 180, 180, 180, 165, 180, 180, 180, 180,
     F
           170,171,172,173,174,175,176,177,178,179) K
C
  HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG UND
С
С
  SPANNUNGEN IM GLOBALEN KOORD.-SYST.
С
  SIG-XX, SIG-YY, SIG-ZZ, SIG-XY, SIG-YZ, SIG-ZX
C
 141 DO 36 J1=1,NMEL
 36
        WRITE (91) SIG(8+(IINT-1)*8,J1)
     GOTO 200
C
  PLAST. VERGLEICHSDEHNUNG UND
С
С
  VERZERRUNGEN AN DER UNTER- UND OBERSEITE DER PLATTE
С
   (IINT=1: UNTERSEITE, IINT=2: OBERSEITE) IM GLOBALEN KOORD.-SYST.
С
  EPS-XX, EPS-YY, EPS-ZZ, EPS-XY, EPS-YZ, EPS-XZ,
С
С
 142 DO 37 J1=1,NMEL
 37
        WRITE (91) SIG(7+(IINT-1)*8,J1)
     GOTO 200
С
С
 principal strains EPS-I, EPS-II, strain rate
С
  155 DO 15 J1=1, NMEL
        WRITE (91) EMAIN(1+3*(IINT-1), J1)
15
     CONTINUE
     GOTO 200
 156 DO 16 J1=1,NMEL
        WRITE (91) EMAIN(2+3*(IINT-1), J1)
16
     CONTINUE
```

```
139
```

```
GOTO 200
C
  C
   Void Content
С
  157 continue
       icode=15
       call sca_get (a(n1),a(n4f),a(lc11),a(n4a),a(lc1s),a(ns06),
     1
              sig, lns, a (ns13), a (ns14), nelget, nmel, icode, val, iint)
       do i=1,nmel
        i1 = i + (nn-1)*nlq
write(91) val(i)
       end do
С
      goto 200
С
   Yield Stress
С
  158 continue
       icode=16
       call sca_get (a(n1),a(n4f),a(lc11),a(n4a),a(lc1s),a(ns06),
     1
            sig,lns,a(ns13),a(ns14),nelget,nmel,icode,val,iint)
       do i=1,nmel
        i1 = i + (nn-1)*nlq
        write(91) val(i)
       end do
C
      goto 200
С
C
  165 DO 17 J1=1,NMEL
         WRITE (91) EMAIN(3+3*(IINT-1),J1)
 17
      CONTINUE
      GOTO 200
С
C RESULTIERENDE SCHNITTLASTEN
С
C M-XX
  170 DO 18 J1=1,NMEL
         WRITE (91) SIG(25, J1)
 18
      GOTO 200
C M-YY
  171 DO 14 J1=1,NMEL
         WRITE (91) SIG(26, J1)
 14
      GOTO 200
C M-XY
  172 DO 20 J1=1,NMEL
         WRITE (91) SIG(27, J1)
 20
      GOTO 200
C Q-XX
  173 DO 21 J1=1,NMEL
         WRITE (91) SIG(28, J1)
 21
      GOTO 200
C Q-YY
  174 DO 22 J1=1,NMEL
 22
          WRITE (91) SIG(29, J1)
      GOTO 200
C N-XX
  175 DO 23 J1=1, NMEL
 23
         WRITE (91) SIG(30, J1)
      GOTO 200
```

```
C N-YY
  176 DO 24 J1=1,NMEL
        WRITE (91) SIG(31, J1)
 24
     GOTO 200
C N-XY
  177 DO 25 J1=1,NMEL
 25
        WRITE (91) SIG(32, J1)
      GOTO 200
C PLATTENDICKE
  178 DO 26 J1=1, NMEL
        WRITE (91) SIG(33, J1)
 26
     GOTO 200
C ENERGIEDICHTE
  179 DO 34 J1=1,NMEL
        WRITE (91) SIG(48, J1)
 34
     GOTO 200
C DUMMY
  180 DO 35 J1=1,NMEL
         WRITE (91) DUMMY
 35
  200 CONTINUE
С
С
  THICK SHELLS
С
  340 IF (NUMELT.EQ.0) GOTO 440
     NELG=NUMELT/nlq
     IF (nlq*NELG.LT.NUMELT) NELG=NELG+1
С
     NEL=0
     DO 400 NN=1, NELG
     NMEL=nla
     IF (NN.EQ.NELG) NMEL=NUMELT-nlq*(NELG-1)
     LNS=41
     CALL SCALART (A(N1), A(N4F), A(N4A), A(NT04), A(NT13), A(NT14),
                   A(LC1T), SIG, NMEL, NEL, LNS)
    1
С
     GOTO (441,442,400,400,400,400,400,400,479,479,479,479,479,479,479,
         F
           F
С
C HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG
С
  441 DO 45 J1=1, NMEL
        WRITE (91) SIG(35+IINT,J1)
 45
     GOTO 400
С
  442 DO 46 J1=1, NMEL
        WRITE (91) SIG(7+(IINT-1)*7,J1)
 46
     GOTO 400
С
  479 DO 47 J1=1,NMEL
 47
        WRITE (91) DUMMY
  400 CONTINUE
С
  440 CONTINUE
C
   UMSCHREIBEN AUF TECPLOT-ELEMENT-SKALARFILES
С
С
     REWIND (91)
С
   Oeffnen und Einlesen der TECPLOT-Geometrie-Datei
С
```

```
141
```

```
IF (NDISP .LT. 1 .AND. NVELO .LT. 1) THEN
          GEOTIT=MOFI(1:9)//'.GEO'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .GE. 1) THEN
         GEOTIT=MOFI(1:9)//'.KIN'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .LT. 1) THEN
          GEOTIT=MOFI(1:9)//'.DIS'
      ELSE IF (NDISP .LT. 1 .AND. NVELO .GE. 1) THEN
          GEOTIT=MOFI(1:9)//'.VEL'
      ENDIF
      OPEN (UNIT=94, FILE=GEOTIT, FORM='FORMATTED', STATUS='OLD')
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      IF( K .EQ. 1 ) THEN
       VARCHAR='VARIABLES= "X", "Y", "Z", "SIGV"'
       WRITE(93,'(1X,A29)') VARCHAR(1:29)
      ELSE IF ( K .EQ. 2 ) THEN
VARCHAR='VARIABLES= "X", "Y", "Z", "EPSV"'
       WRITE(93,'(1X,A29)') VARCHAR(1:29)
      ELSE
       VARCHAR(1:29) = 'VARIABLES= "X", "Y", "Z", "'//COD//'"'
       WRITE(93, '(1X, A29)') VARCHAR(1:29)
      ENDIF
      READ(94, '(A80)') VARCHAR
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      VARCHAR = '
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      ELT = VARCHAR(1:27)
C Elementwerte auf Knotenwerte interpolieren
          DO I = 1, NUMNP
             SS(I) = 0.
             IVAL(I) = 0
          ENDDO
          IEL = 0
          IF (NUMELH.GE.1) THEN
          DO 222 I = 1, NUMELH
             IEL = IEL + 1
             l=nhxpnt(i)
             READ(91) FELD
              DO 201 J2 = 1,8
                  NPP = ixh(j2+1, 1)
                  IVAL (NPP) = IVAL(NPP) + 1
                  SS(NPP) = SS(NPP) + FELD
 201
              CONTINUE
 222
           ENDIF
           IF (NUMELB.GE.1) THEN
           DO 202 I = 1, NUMELB
               IEL = IEL + 1
 202
              READ(91) FELD
           ENDIF
           IF (NUMELS.GE.1) THEN
             DO 203 I = 1, NUMELS
              IEL = IEL + 1
              l=nshpnt(i)
              READ(91) FELD
                                     142
```

С

C

С

С

```
DO 204 J2 = 1,3
                  NPP = ixs(j2+1, 1)
                  IVAL (NPP) = IVAL(NPP) + 1
 204
                  SS(NPP) = SS(NPP) + FELD
               if (ixs(4,1).ne.ixs(5,1))then
                  NPP = ixs(5, 1)
                  IVAL (NPP) = IVAL(NPP) + 1
                  SS(NPP) = SS(NPP) + FELD
               endif
 203
               CONTINUE
            ENDIF
            IF (NUMELT.GE.1) THEN
              DO 205 I = 1, NUMELT
               IEL = IEL + 1
               l=ntxpnt(i)
               READ(91,'(E12.5)') FELD
               DO 206 J2 = 1,8
                  NPP = ixt(j2+1, 1)
                  IVAL (NPP) = IVAL(NPP) + 1
 206
                  SS(NPP) = SS(NPP) + FELD
 205
               CONTINUE
           ENDIF
          DO 901 KK = 1, NUMNP
           IF (IVAL(KK).NE.0) SS(KK) = SS(KK) / FLOAT(IVAL(KK))
           READ(94,*) XX, YY, ZZ
           WRITE(93, '(4(1X, E12.5))') sngl(XX), sngl(YY), sngl(ZZ),
     1
                                      sngl(SS(KK))
 901
          CONTINUE
С
 555
      CONTINUE
      READ(94, '(A80)', END=550) VARCHAR
      WRITE(93, '(A80)') VARCHAR
      GOTO 555
С
  490 CONTINUE
      CLOSE (UNIT=93)
  550 CLOSE(94)
С
  500 CONTINUE
С
      RETURN
```

С

END

```
subroutine stiffs(x,irect,stf,bh,ipss,cm,matype,eosp,ieost,numelh,
     inumels,numelt,nrt,nmmat,ro,zf,thicks,ethik,nty,chrlen,ipst,
     ljx1,jx7,nsv,nsn,stfvg,thk,sftr,ishlfm,ityptp)
      implicit double precision (a-h,o-z)
     dp
С
c called by initlz to compute bulk modulus of each material for sliding
c interface stiffness determination
С
      call stiffs (x,irects(k1),stfs(k9),ipsh,b(lcls),cm,mtype,eosp,
С
     1 ieost, numelh, numels, numelt, nrts, nmmat, ro, zfcs, b(ns05), ethik(k4),
С
     2 nty,chrlen(n),b(lclt),b(ibins1),b(ibins2),nsv(k4),nsn,stfss,
С
     3 thkslv(k9),b(nlcslv),b(n1+nmmat),ityptp)
С
С
С
 *** Added Mat #44 (Elasto-Plastic with Void Effects) - McDermott 1999
С
С
      if (mt.eq.41)bkm(mx)=cm(mx48m1+21)
c Elasto-Plastic with Void Effects - McD '99
      if (mt.eq.44)bkm(mx)=cm(mx48m1+1)/(3.*(1.-2.*cm(mx48m1+2)))
```

end

```
subroutine stifsn(x,irect,stf,ipsh,ipss,cm,matype,eosp,ieost,
     lnumelh, numels, numelt, nrt, nmmat, ro, zf, thicks, ethik, nty, chrlen, ipst,
     ljx1, jx7, nsv, nsn, stfvg, thk, sftr, ihlsnd, islsnd, isg2el, stfsnd,
     lthksnd,ishltp,ishlfm)
      implicit double precision (a-h,o-z)
     dp
С
c called by initlz to compute bulk modulus for each material
c to determine sliding interface stiffness with materials in
c master sand volume
С
      call stifsn (x,irectm(k6), stfm(k10), ipsh, b(lcls), cm, mtype, eosp,
С
     1 ieost,numelh,numels,numelt,nrtm,nmmat,ro,zfcm,b(ns05),fthik(k5),
С
     2 nty,chrlen(n),b(lclt),b(ibins1),b(ibins2),msr(k5),nmn,stfsm,
С
     3 thkmsr(k10),b(nlcmsr),ihlsnd(kd3),islsnd(kd4),
С
С
     4 isg2el(kd7),stfsnd(kd11),thksnd(kd12),ishltp(kd5),b(n1+nmmat))
С
c slave sand volume
С
      call stifsn (x,irects(k1),stfs(k9),ipsh,b(lcls),cm,mtype,eosp,
С
     1 ieost, numelh, numels, numelt, nrts, nmmat, ro, zfcs, b(ns05), ethik(k4),
С
     2 nty,chrlen(n),b(lclt),b(ibins1),b(ibins2),nsv(k4),nsn,stfss,
С
     3 thkslv(k9),b(nlcslv),ihlsnd(kd3),islsnd(kd4),
С
С
     4 isg2el(kd7), stfsnd(kd11), thksnd(kd12), ishltp(kd5), b(n1+nmmat))
С
  *** Added Elasto-Plastic with Void Effects (#44) - McDermott 1999
С
C
      if (mt.eq.39) bkm(mx)=cm(mx48m1+1)/(3.*(1.-2.*cm(mx48m1+2)))
                    ********************
С
 Elasto-Plastic with Void Effects - McD '99
С
      if (mt.eq.44) bkm(mx)=cm(mx48m1+1)/(3.*(1.-2.*cm(mx48m1+2)))
         ******
```

end

SUBROUTINE TEC TEN (A, nhxpnt, nshpnt, ntxpnt, ixh, ixs, ixt, ss, ival ) С С WRITE SCALAR PLOT FILES (TECPLOT-FORMAT) ONLY STRESS- AND STRAIN-С TENSOR С REIHENFOLGE WICHTIG !!! Ċ 1.) VOLUMENELEMENTE С 2.) BALKENELEMENTE (werden von TECPLOT nicht С unterstuetzt) С 3.) SCHALENELEMENTE С 4.) DICKE SCHALENELEMENTE С Corrected bug in some of the scratchfile writes - they must be С the same precision and the variable used for reads (ie double) С (Did not mark changes, since they occur throughout subroutine) С - McDermott, '99 Ċ C\*\*\*\*\* \*\*\*\*\* \*\*\*\*\*\*\*\*\* implicit double precision (a-h,o-z) dp include 'nlqpar.inc' COMMON/BK00/NUMNP, NUMPC, NUMLP, NEQ, NDOF, NLCUR, NUMCL, NUMVC, NDTPTS, NELMD, NMMAT, NUMELH, NUMELB, NUMELS, NUMELT, NUMDP, 1 GRVITY, IDIRGV, NODSPC, NSPCOR 2 cfu common/bk03/endtim, prtc, pltc, ndthl, nsthl, nstsl, nstbl, nsttl, mkthf common/bk03/endtim,prtc,pltc,ngthl,ndthl,nsthl,nstbl, nsttl, ncpll, mkthf 1 COMMON/BK04/PRTOUT, PLTOUT, DT2OLD, SLSFAC, TSSFAC, IHYDRO, NDTH, NMST, NSTH, NSTS, NSTB, NSTT, IKEDIT cfu 1 1 ngth,ndth,nmst,nsth,nsts,nstb,nstt,ncpl,ikedit COMMON/BK05/ 1 NH01, NH02, NH03, NH04, NH05, NH06, NH07, NH08, NH09, NH10, 2 NB01, NB02, NB03, NB04, NB05, NB06, NB07, NB08, NB09, NB10, 3 NS01, NS02, NS03, NS04, NS05, NS06, NS07, NS08, NS09, NS10, 4 NT01, NT02, NT03, NT04, NT05, NT06, NT07, NT08, NT09, NT10 REAL\*8 HEAD VAX750 common/bk06/time(2,8),head(12),idmmy,iadd,ifil,maxsiz,ncycle common/bk07/n1,n2,n3,n4,n5,n6,n7,n8,n9,n10,n11,n12,n13,n14,n15, 1 n16,n17,n18,n19,n20,n21,n22,n23,n24,n25,n26,n27,n28,n29,n30,n31, 2 n32,n33,n34,n35,n36,n37,n38,n39,n40,n41,n42,n43,n44,n45, 3 n46,n47,n48,n49,n50,n51,n52,n53,n54,n55,n56,n57,n58,n59,n60,n61, 4 n62,n63,n64,n65,n66,n67,n68,n69,n70,n71,n72,n73,n74,n75,n76,n77, 5 n78, n79, n80, n81, n82, n83, n84, locend, iname, lendf common/bk08/n4a,n4b,n4c,n4d,n4e,n4f,n4g,n4h,n7a,n7b,n7c,n7d,n7e, 1 nusir, mpusr, mpubr COMMON/BK13/LC0, LC1H, LC1B, LC1S, LC1T, LC2, LC3, LC4, LC5, LC6, LC7, LC9, LC10, LC11, LC12, LC13, LC14, LC15, LC16, LC17, LC18, LB0, LB1, LB2, 1. LC7A, LC7B COMMON/BK20/NUMSV, JU, JV, NRTM, NRTS, NMN, NSN, NTY, NST, MST, NOCO COMMON/BK28/SUMMSS, XKE, XPE, TT COMMON/AUX14/SIG(49,nlq) COMMON/SHLOPT/ISTRN, ISTUPD, IBELYT, MITER common/sorter/nnc,lczc, & ns11, ns12, ns13, ns14, ns15, ns16, ns17, & nh11, nh12, nh13, nh14, nh15, nh16, nh17, & nt11, nt12, nt13, nt14, nt15, nt16, nt17, & nb11, nb12, nb13, nb14, nb15, nb16, nb17 COMMON/INKTH/ INCHIS, NPOST, NDISP, NVELO, NCYREM, 1 NSTRESS, NSTRAIN

```
146
```

```
CHARACTER*8 DATU, VS
       CHARACTER*60 SBTEXT(20)
       COMMON/VSNUM/VS, DATU
       CHARACTER MOFI*13, COD*3, COD1*6, GEOTIT*13
       CHARACTER VARCHAR*84, ELT*27
С
       DIMENSION A(*)
       DIMENSION VLSTRAI(7,nlq), EMAIN(6,nlq)
       DIMENSION SS(*), FELD(14), VAL1(7), IVAL(*)
dimension ixh(9,*),ixs(5,*),ixt(9,*)
       dimension nhxpnt(*), nshpnt(*), ntxpnt(*)
С
С
       WRITE (COD1, '(I6)') NCYCLE
С
       IF (NCYCLE.LT.100000) COD1(1:1)='0'
       IF (NCYCLE.LT.10000) COD1(2:2)='0'
       IF (NCYCLE.LT.1000) COD1(3:3)='0'
       IF (NCYCLE.LT.100) COD1(4:4)='0'
       IF (NCYCLE.LT.10) COD1(5:5)='0'
С
      MOFI(1:3) = 'TEC'
      MOFI(4:9) = COD1
      DUMMY=0.
С
      IF (NSTRESS .EO. 1) THEN
С
       COD = 'Sij'
       MOFI(10:13)='.'//COD
С
       OPEN (UNIT=91, POSITION='REWIND',
      1
                    STATUS='SCRATCH', FORM='UNFORMATTED')
       OPEN (UNIT=93, STATUS='UNKNOWN', FILE=MOFI, FORM='FORMATTED')
С
С
   HEXAHEDRONS
С
       IF ( NUMELH .EQ. 0 ) GOTO 140
       NELG=NUMELH/nlq
       IF (nlq*NELG.LT.NUMELH) NELG=NELG+1
С
       NEL=0
       DO 100 NN=1, NELG
        NMEL=nlq
        IF (NN.EQ.NELG) NMEL=NUMELH-nlq*(NELG-1)
        CALL SCALARH (A(LC1H), A(LC15), A(N1), A(NH13), A(NH14), A(NH04),
     1
                        VLSTRAI, NEL, NMEL)
C
C HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG UND
C SPANNUNGEN IM GLOBALEN KOORD.-SYST.
C SIG-XX, SIG-YY, SIG-ZZ, SIG-XY, SIG-YZ, SIG-ZX
С
        DO J1=1,NMEL
        WRITE (91) SIG(8, J1), SIG(1, J1), SIG(2, J1), SIG(3, J1),
                    SIG(4,J1),SIG(6,J1),SIG(5,J1),
     1
     2
                    SIG(8,J1),SIG(1,J1),SIG(2,J1),SIG(3,J1),
     3
                    SIG(4, J1), SIG(6, J1), SIG(5, J1)
        ENDDO
C
  100 CONTINUE
С
```

```
BEAM ELEMENTS
C
 C
   140
        IF ( NUMELB .EQ. 0 ) GOTO 240
        NELG=NUMELB/nlq
        IF (nlq*NELG.LT.NUMELB) NELG=NELG+1
 С
        NEL=0
        DO 300 NN=1, NELG
         NMEL=nlq
         IF (NN.EQ.NELG) NMEL=NUMELB-nlq*(NELG-1)
С
         LNS=7
С
         CALL SCALARB (A(NB04), A(NB13), SIG, NMEL, NEL, LNS)
         DO J1=1,NMEL
          WRITE (91) ( DUMMY, J14=1,14 )
         ENDDO
       CONTINUE
   300
C
С
   SHELL ELEMENTS
С
   240
        IF ( NUMELS .EQ. 0 ) GOTO 340
        NELG=NUMELS/nlq
        IF (nlq*NELG.LT.NUMELS) NELG=NELG+1
С
        NEL=0
        DO 200 NN=1, NELG
         NMEL=nlq
         IF (NN.EQ.NELG) NMEL=NUMELS-nlq*(NELG-1)
         LNS=49
         CALL SCALARS (A (N1), A (N4F), A (LC11), A (N4A), A (LC1S), A (NS05), A (NS06)
     F
                      , A (NSO3), A (NSO1), SIG, LNS, A (NSO7), A (N4H), MPUSR,
     F
                       A(N1+NMMAT), A(NSTSL), A(NS13), A(NS14), NEL, NMEL,
      F
                       A(NS02), EMAIN)
С
С
   HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG
                                                UND
С
   SPANNUNGEN IM GLOBALEN KOORD.-SYST.
С
   SIG-XX, SIG-YY, SIG-ZZ, SIG-XY, SIG-YZ, SIG-ZX
С
         DO J1=1,NMEL
         WRITE (91)
                      SIG(16, J1), SIG(9, J1), SIG(10, J1), SIG(11, J1),
     1
                      SIG(12, J1), SIG(14, J1), SIG(13, J1), SIG(24, J1),
     2
                      SIG(17, J1), SIG(18, J1), SIG(19, J1), SIG(20, J1),
     3
                      SIG(22, J1), SIG(21, J1)
         ENDDO
 200
      CONTINUE
С
С
   THICK SHELLS
С
  340
       IF (NUMELT.EQ.0) GOTO 440
       NELG=NUMELT/nlq
        IF (nlq*NELG.LT.NUMELT) NELG=NELG+1
С
       NEL=0
       DO 400 NN=1, NELG
        NMEL=nlq
        IF (NN.EQ.NELG) NMEL=NUMELT-nlq*(NELG-1)
        LNS=41
        CALL SCALART (A(N1), A(N4F), A(N4A), A(NT04), A(NT13), A(NT14),
     1
                        A(LC1T), SIG, NMEL, NEL, LNS)
C .
C HUBER-MISES-HENCKY - VERGLEICHSSPANNUNG UND
                                      148
```

```
C SPANNUNGEN IM GLOBALEN KOORD.-SYST.
C SIG-XX, SIG-YY, SIG-ZZ, SIG-XY, SIG-YZ, SIG-ZX
С
         DO J1=1, NMEL
          WRITE (91) SIG(37, J1), SIG(8, J1), SIG(9, J1), SIG(10, J1),
                  SIG(11, J1), SIG(13, J1), SIG(12, J1), SIG(38, J1), SIG(15, J1),
      1
      2
                  SIG(16, J1), SIG(17, J1), SIG(18, J1), SIG(20, J1),
      3
                  SIG(19, J1)
        ENDDO
С
  400 CONTINUE
  440 CONTINUE
С
С
   UMSCHREIBEN AUF TECPLOT-ELEMENT-SKALARFILES
Ċ
      REWIND (91)
С
С
   Oeffnen und Einlesen der TECPLOT-Geometrie-Datei
С
      IF (NDISP .LT. 1 .AND. NVELO .LT. 1) THEN
          GEOTIT=MOFI(1:9)//'.GEO'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .GE. 1) THEN GEOTIT=MOFI(1:9)//'.KIN'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .LT. 1) THEN
GEOTIT=MOFI(1:9)//'.DIS'
      ELSE IF (NDISP .LT. 1 .AND. NVELO .GE. 1) THEN GEOTIT=MOFI(1:9)//'.VEL'
      ENDIF
      OPEN(UNIT=94, FILE=GEOTIT, FORM='FORMATTED', STATUS='OLD')
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
        VARCHAR='VARIABLES= "X", "Y", "Z", "SIGV", "SIG-XX", "SIG-YY"'//
                            ', "SIG-ZZ", "SIG-XY", "SIG-YZ", "SIG-ZX"'
     1
        WRITE(93,'(1X,A84)') VARCHAR(1:84)
      READ(94, '(A80)') VARCHAR
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      VARCHAR = ' '
      READ(94, '(A80)') VARCHAR
      WRITE(93,'(A80)') VARCHAR
      ELT = VARCHAR(1:27)
C
C Elementwerte auf Knotenwerte interpolieren
С
С
   Spannungstensor
С
        DO 880 L = 1, 2
           DO 800 K = (L-1)*7+1, (L-1)*7+7
            REWIND(91)
            IEL = 0
            DO I = 1, NUMNP
             SS(I) = 0.
             IVAL(I) = 0
            ENDDO
            IF (NUMELH.GE.1) THEN
              DO 600 I = 1, NUMELH
               IEL = IEL + 1
               ll=nhxpnt(i)
               READ(91) (FELD(II), II=1, 14)
               DO 700 J2 = 1,8
```

```
149
```

```
)
```

NPP = ixh(j2+1,ll)IVAL (NPP) = IVAL(NPP) + 1700 SS(NPP) = SS(NPP) + FELD(K)600 CONTINUE ENDIF С IF (NUMELB.GE.1) THEN DO 601 I = 1, NUMELB IEL = IEL + 1601 READ(91) FELD(1) ENDIF С IF (NUMELS.GE.1) THEN DO 602 I = 1, NUMELS IEL = IEL + 1ll=nshpnt(i) READ(91) (FELD(II), II=1, 14) DO 702 J2 = 1,3NPP = ixs(j2+1,ll)IVAL (NPP) = IVAL(NPP) + 1702 SS(NPP) = SS(NPP) + FELD(K)if (ixs(4,11).ne.ixs(5,11))then NPP = ixs(5, 11)IVAL (NPP) = IVAL (NPP) + 1SS(NPP) = SS(NPP) + FELD(K)endif 602 CONTINUE ENDIF С IF (NUMELT.GE.1) THEN DO 603 I = 1, NUMELT IEL = IEL + 1ll=ntxpnt(i) READ(91) (FELD(II), II=1, 14) DO 703 J2 = 1,8 NPP = ixt(j2+1,ll)IVAL (NPP) = IVAL(NPP) + 1703 SS(NPP) = SS(NPP) + FELD(K)603 CONTINUE ENDIF С IOP = 23 + K - (L - 1) \* 7OPEN(UNIT=IOP, STATUS='SCRATCH', FORM='UNFORMATTED') DO 900 KK = 1, NUMNP IF (IVAL(KK).NE.0) SS(KK) = SS(KK) / FLOAT(IVAL(KK)) 900 WRITE(IOP) SS(KK) 800 CONTINUE С DO 910 I=1,7 IOP = 23 + I910 REWIND(IOP) С IF (L.EQ.2) THEN VARCHAR(1:50) = ELT//' D=(1,2,3, FECONNECT) WRITE(93,'(A50)') VARCHAR DO 850 I = 1, NUMNPDO 860 II = 1,7IOP=23+II 860 READ(IOP) VAL1(II) WRITE(93,'(7(1X,E12.5))') (sngl(VAL1(IK)),IK=1,7) 850 150

```
GOTO 999
         ENDIF
С
         DO 810 I = 1, NUMNP
          READ(94,*) XX, YY, ZZ
          DO 820 II = 1,7
            IOP=23+II
            READ(IOP) VAL1(II)
          CONTINUE
 820
          WRITE (93, '(10(1X, E12.5))')XX, YY, ZZ, (VAL1(IK), IK=1,7)
 810
         CONTINUE
С
        DO 830 I = 1,7
         IOP = 23+I
 830
         CLOSE (IOP)
С
 888
       CONTINUE
       READ(94, '(A80)', END=880) VARCHAR
       ICOL = INDEX(VARCHAR, 'D=')
       IF (ICOL.GT.0) VARCHAR(ICOL:ICOL+24) = 'D=(1,2,3,4,5,6,7,8,9,10)'
       WRITE(93,'(A80)') VARCHAR
       GOTO 888
 880
      CONTINUE
С
       CLOSE (93)
  999 CLOSE (94)
С
      ENDIF
С
       IF (NSTRAIN .EQ. 1 )
                              THEN
С
       COD = 'Eij'
       MOFI(10:13)='.'//COD
С
       OPEN (UNIT=91, POSITION='REWIND',
      1
                    STATUS='SCRATCH', FORM='UNFORMATTED')
       OPEN (UNIT=93, STATUS='UNKNOWN', FILE=MOFI, FORM='FORMATTED')
С
С
   HEXAHEDRONS
С
      IF ( NUMELH .EQ. 0 ) GOTO 1140
      NELG=NUMELH/nlq
      IF (nlq*NELG.LT.NUMELH) NELG=NELG+1
С
      NEL=0
      DO 1100 NN=1, NELG
      NMEL=nlq
      IF (NN.EQ.NELG) NMEL=NUMELH-nlq*(NELG-1)
      CALL SCALARH (A(LC1H), A(LC15), A(N1), A(NH13), A(NH14), A(NH04),
    . 1
                     VLSTRAI, NEL, NMEL)
С
C PLAST. VERGLEICHSDEHNUNG UND
C DEHNUNGEN IM GLOBALEN KOORD.-SYST.
C EPS-XX, EPS-YY, EPS-ZZ, EPS-XY, EPS-YZ, EPS-XZ,
С
        DO J1=1, NMEL
        WRITE (91) SIG(7, J1), VLSTRAI(1, J1), VLSTRAI(2, J1), VLSTRAI(3, J1),
                    VLSTRAI(4, J1), VLSTRAI(6, J1), VLSTRAI(5, J1),
     1
     2
                    SIG(7, J1), VLSTRAI(1, J1), VLSTRAI(2, J1), VLSTRAI(3, J1),
     3
                    VLSTRAI(4, J1), VLSTRAI(6, J1), VLSTRAI(5, J1)
                                     151
```

```
ENDDO
  1100 CONTINUE
 C
С
    BEAM ELEMENTS
С
  1140 IF ( NUMELB .EQ. 0 ) GOTO 1240
       NELG=NUMELB/nlg
       IF (nlq*NELG.LT.NUMELB) NELG=NELG+1
С
       NEL=0
       DO 1300 NN=1, NELG
        NMEL=nlq
        IF (NN.EQ.NELG) NMEL=NUMELB-nlq*(NELG-1)
С
        LNS=7
С
        CALL SCALARB (A(NB04), A(NB13), SIG, NMEL, NEL, LNS)
        DO J1=1,NMEL
         WRITE (91) ( DUMMY, J14=1,14 )
        ENDDO
 1300 CONTINUE
Ċ
С
   SHELL ELEMENTS
С
 1240 IF ( NUMELS .EQ. 0 ) GOTO 1340
       NELG=NUMELS/nlq
       IF (nlq*NELG.LT.NUMELS) NELG=NELG+1
С
       NEL=0
       DO 1350 NN=1, NELG
       NMEL=nlq
        IF (NN.EQ.NELG) NMEL=NUMELS-nlg*(NELG-1)
       LNS=49
       CALL SCALARS (A(N1), A(N4F), A(LC11), A(N4A), A(LC1S), A(NS05), A(NS06)
     F
                      , A (NS03), A (NS01), SIG, LNS, A (NS07), A (N4H), MPUSR,
     F
                      A(N1+NMMAT), A(NSTSL), A(NS13), A(NS14), NEL, NMEL,
     F
                      A(NS02), EMAIN)
С
С
   PLAST. VERGLEICHSDEHNUNG UND
С
   VERZERRUNGEN AN DER UNTER- UND OBERSEITE DER PLATTE
   (IINT=1: UNTERSEITE, IINT=2: OBERSEITE) IM GLOBALEN KOORD.-SYST.
С
С
   EPS-XX, EPS-YY, EPS-ZZ, EPS-XY, EPS-YZ, EPS-XZ,
С
       DO J1=1, NMEL
       WRITE (91) SIG(15, J1), SIG(36, J1), SIG(37, J1), SIG(38, J1),
     1
                     SIG(39, J1), SIG(41, J1), SIG(40, J1), SIG(23, J1),
                     SIG(42,J1),SIG(43,J1),SIG(44,J1),SIG(45,J1),
     2
     3
                     SIG(47, J1), SIG(46, J1)
       ENDDO
 1350 CONTINUE
С
С
   THICK SHELLS
С
 1340 IF (NUMELT.EQ.0) GOTO 1540
      NELG=NUMELT/nlg
      IF (nlq*NELG.LT.NUMELT) NELG=NELG+1
С
      NEL=0
      DO 1500 NN=1, NELG
       NMEL=nlq
       IF (NN.EQ.NELG) NMEL=NUMELT-nlq*(NELG-1)
       LNS=41
```

```
152
```

```
CALL SCALART (A(N1), A(N4F), A(N4A), A(NT04), A(NT13), A(NT14),
     1
                      A(LC1T), SIG, NMEL, NEL, LNS)
С
       DO J1=1, NMEL
        WRITE (91)
                     SIG(14,J1), (DUMMY, I=1,6),
                     SIG(21, J1), (DUMMY, I=1, 6)
     1
       ENDDO
 1500 CONTINUE
 1540 CONTINUE
C
   UMSCHREIBEN AUF TECPLOT-ELEMENT-SKALARFILES
С
С
      REWIND (91)
С
   Oeffnen und Einlesen der TECPLOT-Geometrie-Datei
С
C
      IF (NDISP .LT. 1 .AND. NVELO .LT. 1) THEN
         GEOTIT=MOFI(1:9)//'.GEO'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .GE. 1) THEN
         GEOTIT=MOFI(1:9)//'.KIN'
      ELSE IF (NDISP .GE. 1 .AND. NVELO .LT. 1) THEN
         GEOTIT=MOFI(1:9)//'.DIS'
      ELSE IF (NDISP .LT. 1 .AND. NVELO .GE. 1) THEN
         GEOTIT=MOFI(1:9)//'.VEL'
      ENDIF
      OPEN (UNIT=94, FILE=GEOTIT, FORM='FORMATTED', STATUS='OLD')
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
       VARCHAR='VARIABLES= "X", "Y", "Z", "EPSV", "E-XX", "E-YY", "E-ZZ"'//
                          ', "E-XY", "E-YZ", "E-ZX"'
     1
       WRITE(93,'(1X,A72)') VARCHAR(1:72)
      READ(94, '(A80)') VARCHAR
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      VARCHAR = ' '
      READ(94, '(A80)') VARCHAR
      WRITE(93, '(A80)') VARCHAR
      ELT = VARCHAR(1:27)
C
C Elementwerte auf Knotenwerte interpolieren
С
С
   Dehnungstensor
С
       DO 1880 L = 1,2
          DO 1800 K = (L-1)*7+1, (L-1)*7+7
           REWIND(91)
           IEL = 0
           DO I = 1, NUMNP
            SS(I) = 0.
            IVAL(I) = 0
           ENDDO
           IF (NUMELH.GE.1) THEN
             DO 1600 I = 1, NUMELH
              IEL = IEL + 1
               ll=nhxpnt(i)
               READ(91) (FELD(II), II=1, 14)
               DO 1700 J2 = 1,8
                  NPP = ixh(j2+1,l1)
                  IVAL (NPP) = IVAL(NPP) + 1
                   SS(NPP) = SS(NPP) + FELD(K)
 1700
                                    153
```

1600	CONTINUE ENDIF
C ·	IF (NUMELB.GE.1) THEN DO 1601 I = 1, NUMELB
1601	READ(91) FELD(1) ENDIF
С	IF (NUMELS.GE.1) THEN
	DO 1602 I = 1,NUMELS IEL = IEL + 1 ll=nshpnt(i)
	READ(91) (FELD(II), II=1,14) DO 1702 J2 = 1,3 NPP = $ixs(j2+1,11)$
1702	IVAL (NPP) = IVAL (NPP) + 1 SS (NPP) = SS (NPP) + FELD (K)
	if (ixs(4,11).ne.ixs(5,11))then NPP = ixs(5,11) IVAL (NPP) = IVAL(NPP) + 1
	SS(NPP) = SS(NPP) + FELD(K)
1602	CONTINUE
С	ENDIE
	IF (NUMELT.GE.1) THEN DO 1603 I = 1,NUMELT TEL = TEL + 1
	ll=ntxpnt(i) READ(91) (FELD(II),II=1,14) DO 1703 J2 = 1,8
1703	NPP = ixt(j2+1,11) IVAL (NPP) = IVAL(NPP) + 1 SS(NPP) = SS(NPP) + FELD(K)
1603 C	CONTINUE ENDIF
-1	<pre>IOP = 23+K-(L-1)*7 OPEN(UNIT=IOP, POSITION='REWIND',         STATUS='SCRATCH', FORM='UNFORMATTED')</pre>
1900 1800	DO 1900 KK = 1,NOMNP IF (IVAL(KK).NE.0) SS(KK) = SS(KK) / FLOAT(IVAL(KK)) WRITE(IOP) SS(KK) CONTINUE
1910	DO 1910 I=1,7 IOP = 23+I REWIND(IOP)
C	<pre>IF (L.EQ.2) THEN VARCHAR(1:50) =ELT//' D=(1,2,3,FECONNECT) ' WRITE(93,'(A50)') VARCHAR DO 1850 I = 1,NUMNP</pre>
1860 1850	DO 1860 II = 1,7 IOP=23+II READ(IOP) VAL1(II) WRITE(93,'(7(1X,E12.5))') (VAL1(IK),IK=1,7) GOTO 2550 ENDLE

```
С
        DO 1810 I = 1, NUMNP
         READ(94,*) XX, YY, ZZ
         DO 1820 II = 1,7
          IOP=23+II
          READ(IOP) VAL1(II)
          CONTINUE
 1820
         WRITE(93,'(10(1X,E12.5))')XX, YY, ZZ, (VAL1(IK),IK=1,7)
         CONTINUE
 1810
С
       DO 1830 I = 1,7
        IOP = 23 + I
 1830
        CLOSE (IOP)
С
 1888 CONTINUE
      READ(94, '(A80)', END=1880) VARCHAR
      ICOL = INDEX(VARCHAR, 'D=')
      IF (ICOL.GT.0) VARCHAR(ICOL:ICOL+24) = 'D=(1,2,3,4,5,6,7,8,9,10)'
      WRITE(93, '(A80)') VARCHAR
      GOTO 1888
 1880 CONTINUE
С
      CLOSE (93)
 2550 CLOSE (94)
      ENDIF
С
      RETURN
      END
```

SUBROUTINE TECPLOT ( V, X, X0, nhxpnt, nshpnt, ntxpnt, ixh, ixs, ixt) C This SBR writes for every flagged cycle the actual node C configuration of the whole structure in TECPLOT-format (ASCII) С С c Added global variable to keep track of number of files (TECPLOT zones), c and attach cycle and time text to the zone, removed a couple associated character variables С С Not complete, since it doesn't work for files where there are two zones in one file (Like stress and strain) - McDermott '99 С C\*\*\*\*\*\*\*\* implicit double precision (a-h,o-z) dp REAL\*8 HEAD VAX750 COMMON/BK00/NUMNP, NUMPC, NUMLP, NEQ, NDOF, NLCUR, NUMCL, NUMVC, 1 NDTPTS, NELMD, NMMAT, NUMELH, NUMELB, NUMELS, NUMELT, NUMDP, GRVITY, IDIRGV, NODSPC, NSPCOR common/bk06/time(2,8),head(12),idmmy,iadd,ifil,maxsiz,ncycle COMMON/BK28/SUMMSS, XKE, XPE, TT COMMON/INKTH/ INCHIS, NPOST, NDISP, NVELO, NCYREM, NSTRESS, NSTRAIN 1 COMMON/ELTYP/ NEV \*\*\* New Variable for current TECPLOT zone number - McD common/TEC/ izone integer save izone C CHARACTER\*8 DATU COMMON/VSNUM/VS, DATU CHARACTER\*24 DISCHAR , XYCHAR CHARACTER\*18 VELCHAR CHARACTER\*13 MOFI CHARACTER\*6 COD CHARACTER VARCHAR\*66, VS\*8, DAT\*9 character\*66 varchal character\*66 TEXT С XO(3,\*), V(3,\*)DIMENSION X(3, \*), dimension ixh(9,\*), ixs(5,\*), ixt(9,\*) dimension nhxpnt(\*),nshpnt(\*),ntxpnt(\*) С DATA XYCHAR /'VARIABLES= "X", "Y", "Z"'/ DATA VELCHAR /', "VX", "VY", "VZ"'/ DATA DISCHAR /', "DISX", "DISY", "DISZ"'/ c \*\*\* Initialize izone of first cycle if (ncycle.le.1) izone = 0 izone = izone + 1 WRITE (COD, '(I6)') NCYCLE IF (NCYCLE.LT.100000) COD(1:1)='0' IF (NCYCLE.LT.10000) COD(2:2)='0' IF (NCYCLE.LT.1000) COD(3:3)='0' IF (NCYCLE.LT.100) COD(4:4)='0' IF (NCYCLE.LT.10) COD(5:5)='0' MOFI(1:3) = 'TEC'MOFI(4:9) = COD IF (NDISP .LT. 1 .AND. NVELO .LT. 1) THEN MOFI(10:13) = '.GEO' 156

```
IDUP = 1
       ELSE IF (NDISP .GE. 1 .AND. NVELO .GE. 1) THEN
          MOFI(10:13)='.KIN'
          IDUP = 3
       ELSE IF (NDISP .GE. 1 .AND. NVELO .LT. 1) THEN
          MOFI(10:13) = '.DIS'
          IDUP = 2
      ELSE IF (NDISP .LT. 1 .AND. NVELO .GE. 1) THEN
          MOFI(10:13) = '.VEL'
          IDUP = 2
      ENDIF
С
      CALL DATE (DAT)
С
С
   Oeffnen und schreiben der TECPLOT Datei
С
С
      NKN=NUMNP
      IZO = 0
      KHILF = 0
      VARCHAR = XYCHAR
      IC = 24
С
      OPEN (UNIT=31, STATUS='UNKNOWN', FILE=MOFI(1:13), FORM='FORMATTED')
С
      IF ( NDISP .GE. 1 ) THEN
            VARCHAR = XYCHAR//DISCHAR
            IC = 48
      ENDIF
      IF ( NVELO .GE. 1 ) then
         VARCHA1 = VARCHAR(1:IC)//VELCHAR
         varchar =varchal
      endif
С
c *** Changed to attach text string to current zone - McD
       TEXT='TEXT X=0.14,Y=0.9,T="CYCLE '//ACYCLE//', TIME '//ATIM//'
С
S"'
      WRITE(31,*) 'TITLE = " DYNA N - VERSION ', VS, ' ', DAT, ' "'
      WRITE(31,*) VARCHAR
       WRITE(31,*) TEXT
С
      write(31,203) izone,ncycle,tt
      IF ( NUMELB + NUMELS .EQ. NEV) THEN
       IF (NUMELS .GE. 1) WRITE(31,201) NKN, NUMELS
      ELSE
       WRITE(31,202) NKN, NUMELH
      ENDIF
      FORMAT(1X,'ZONE F=FEPOINT, N=',I7,', E=',I7,', ET=QUADRILATERAL')
FORMAT(1X,'ZONE F=FEPOINT, N=',I7,', E=',I7,', ET=BRICK')
 201
 202
      format(1x, 'TEXT X=0.14, Y=0.9, ZN=', i6, ', T="CYCLE ', i6, ', TIME ',
 203
      1
               E14.5, ' SEC"')
С
   Knotenkoordinaten, + evtl. Displacements und Velocities
      DO 4711 K = 1, NKN
       IF (NDISP .GE. 1 .AND. NVELO .GE. 1)
        WRITE(31, '(9(1X, E12.5))')
     1
     2
                sngl(X(1,K)), sngl(X(2,K)), sngl(X(3,K)),
     3
                sngl(X(1,K)-XO(1,K)), sngl(X(2,K)-XO(2,K)),
                sngl(X(3,K)-XO(3,K)),
     4
     5
                sngl(V(1,K)), sngl(V(2,K)), sngl(V(3,K))
                                      157
```

```
IF (NDISP .GE. 1 .AND. NVELO .LT. 1)
         WRITE(31,'(6(1X,E12.5))')
      1
      2
                 sngl(X(1,K)), sngl(X(2,K)), sngl(X(3,K)),
                 sngl(X(1,K)-XO(1,K)), sngl(X(2,K)-XO(2,K)),
      3
      4
                 sngl(X(3, K) - XO(3, K))
        IF (NDISP .LT. 1 .AND. NVELO .GE. 1)
         WRITE(31,'(6(1X,E12.5))')
      1
      2
                 sngl(X(1,K)), sngl(X(2,K)), sngl(X(3,K)),
      ٦
                 sngl(V(1,K)), sngl(V(2,K)), sngl(V(3,K))
        IF (NDISP .LT. 1 .AND. NVELO .LT. 1)
         WRITE(31, '(3(1X, E12.5))')
      1
      2
                 \operatorname{sngl}(X(1,K)), \operatorname{sngl}(X(2,K)), \operatorname{sngl}(X(3,K))
  4711 CONTINUE
C
C ELEMENTCONNECTIVITY aufgeteilt in ZONES (je EL-TYP eine ZONE)
C
       IF ( NUMELH .GE. 1 ) THEN
         IZO = IZO + 1
        DO 4712 N=1, NUMELH
           l=nhxpnt(n)
           WRITE(31, '(818)')(ixh(i,l), i=2,9)
 4712
       CONTINUE
       ENDIF
       IEL = NUMELH + NUMELB
С
       IF (NUMELS .GE. 1) THEN
С
        IF (IZO.GE.1.AND.IDUP.EQ.1) WRITE(31,401) NKN, NUMELS
        IF (IZO.GE.1.AND.IDUP.EQ.2) WRITE(31,402) NKN, NUMELS
        IF (IZO.GE.1.AND.IDUP.EQ.3) WRITE(31,403) NKN, NUMELS
 401
           FORMAT(1X, 'ZONE F=FEPOINT, N=', I7, ', E=', I7,
                                 ', ET=QUADRILATERAL, D=(1,2,3)')
 402
        FORMAT(1X, 'ZONE F=FEPOINT, N=', I7, ', E=', I7,
                                  ', ET=QUADRILATERAL, D=(1,2,3,4,5,6)')
      F
        FORMAT(1X, 'ZONE F=FEPOINT, N=', I7, ', E=', I7,
 403
     F
                              ', ET=QUADRILATERAL, D=(1,2,3,4,5,6,7,8,9)')
        DO 4713 N=1, NUMELS
          IEL = IEL + 1
          l=nshpnt(n)
          if (ixs(4,1).eq.ixs(5,1))then
            write(31,'(418)') (ixs(i,1), i=2,4),0
          else
            WRITE(31, '(418)') (ixs(i,1), i=2,5)
          endif
 4713
       CONTINUE
      ENDIF
С
      IEL = NUMELH + NUMELB + NUMELS
      IF (NUMELT .GE. 1) THEN
       DO 4714 N=1, NUMELT
           IEL = IEL + 1
           l=ntxpnt(n)
           WRITE(31, '(818)')(ixt(i,1), i=2,9)
 4714
       CONTINUE
      ENDIF
       CLOSE (UNIT=31)
С
      RETURN
      END
```

```
158
```

## APPENDIX D. DOCUMENTATION PAGE FOR NEW MATERIAL TYPE

Material Type 44

## Elastic-Plastic with Void Growth and Nucleation

Columns	Quantity	Format
	Card 3	
1-10	Young's Modulus (E)	E10.0
11-20	Poisson's Ratio (v)	E10.0
21-30	Initial Porosity/Void Content ( $\Phi_0$ )	E10.0
31-40	Initial Yield Stress (Syp)	E10.0
	Card 4	
	Constants for Gurson's Void Model	<b>`</b> .
1-10	$q_1$ (Default = 1.5)	E10.0
11-20	$q_2$ (Default = 1.0)	E10.0
21-30	$q_3$ (Default = $q_1^2$ )	E10.0
	Constants for Void Nucleation Model	
31-40	Void Nucleation Particle Content $(f_N)$ (Default = 0.0)	E10.0
41-50	Mean Nucleating Strain $(e_N)$ (Default = 0.0)	E10.0
51-60	Nucleating Strain Standard Deviation $(s_N)$ (Default = 0.0)	E10.0
61-70	Number of Strain-Hardening Line Segments Defined (iseg)	E10.0
	Card 5	•
	Upper Strain Points of Line Segments	
1-10	End Point of 1st segment $(\varepsilon_1)$	E10.0
11-20	ε2	E10.0
21-30	ε3	E10.0
31-40	ε <sub>4</sub>	E10.0
41-50	ε,	E10.0
51-60	ε,	E10.0
61-70	ε	E10.0
71-80	ε <sub>8</sub>	E10.0
	Card 6	
	Upper Strain Points of Line Segments, Part 2	
1-10	δ9	E10.0
11-20	ε <sub>10</sub>	E10.0
21-30	ε,,	E10.0
31-40	ξ12	E10.0
41-50	Em. (14)	E10.0
51-60	-13 8	E10.0
61-70	~14 F	E10.0
71-80	e	E10.0
/1-00	C16	E10.0

		Stress End-points of Line Segments	
1-10	Stress at End	Point of 1st segment $(\sigma_1)$	E10.0
11-20	$\sigma_2$		E10.0
21-30	$\sigma_3$		E10.0
31-40	$\sigma_4$		E10.0
41-50	$\sigma_{s}$	• • •	E10.0
51-60	$\sigma_6$	· .	E10.0
61-70	$\sigma_7$	· · · · · · · · · · · · · · · · · · ·	E10.0
71-80	$\sigma_8$		E10.0

Card 8 Upper Strain Points of Line Segments, Part 2

1-10	σ,				E10.0
11-20	$\sigma_{10}$		• •	2	E10.0
21-30	$\sigma_{11}$			·	E10.0
31-40	$\sigma_{12}$				E10.0
41-50	$\sigma_{13}$		•		E10.0
51-60	$\sigma_{14}$	м,			E10.0
61-70	$\sigma_{15}$				E10.0
71-80	$\sigma_{16}$				E10.0



As shown in the figure above, the stress and strain values are taken directly from standard tensiletest results for the material.

## LIST OF REFERENCES

- [1] B. L. Koziey and F. A. Mirza, "Consistent Thick Shell Element," *Comput. Struct.* **65.4**, 531-549 (1997).
- [2] D. J. Allman, Evaluation of the Constant Strain Triangle with Drilling Rotations, Int. J. Numer. Methods Engrg. 26, 2645-2655 (1988).
- [3] A. M. Khaski and A. L Soler, "A Finite Element for General Thick Walled Shell Structures," J. Press. Vessel Tech. 107, 126-133 (1985).
- [4] R. D. Cook, "Four-Node 'Flat' Shell Element: Drilling Degrees of Freedom, Membrane-Bending Coupling, Warped Geometry, and Behavior," *Comput. Struct.* 50.4, 549-555 (1994).
- [5] B. L. Kemp, C. Cho, and S. W. Lee, "A Four-Node Solid Shell Element Formulation with Assumed Strain," *Int. J. Numer. Methods Engrg.* 43, 909-924 (1998).
- Y. Zhu and T. Zacharia, "A New One-Point Quadrature, Quadrilateral Shell Element with Drilling Degrees of Freedom," *Comp. Methods Appl. Mech. Engrg.* 136, 165-203 (1996).
- [7] Q. Zeng and A. Comescure, "A New One-Point Quadrature, General Non-linear Quadrilateral Shell Element with Physical Stabilization," Int. J. Numer. Methods Engrg. 42, 1307-1338 (1998).
- [8] G. Rengarajan, M. A. Aminpour, and N. F. Knight, Jr., "Improved Assumed-Stress Hybrid Shell Element with Drilling Degrees of Freedom for Linear Stress, Buckling and Free Vibration Analysis," *Int. J. Numer. Methods Engrg.* 38, 1917-1943 (1995).
- [9] D. Briassoulis, "The C<sup>0</sup> Shell Plate and Beam Elements Freed from their Deficiencies," *Comp. Methods Appl. Mech. Engrg.* **72**, 243-266 (1989).
- [10] A. Ibrahimbegovic, R. L. Taylor, and E. L. Wilson, "A Robust Quadrilateral Membrane Finite Element with Drilling Degrees of Freedom," Int. J. Numer. Methods Engrg. 30, 445-457 (1990).
- [11] S. W. Key and C. C. Hoff, "An Improved Constant Membrane and Bending Stress Shell Element for Explicit Transient Dynamics," *Comp. Methods Appl. Mech. Engrg.* 124, 33-47 (1995).

- [12] K. S. Lay, "Shell Finite Element Formulated on Shell Middle Surface," J. Engrg Mech. **119.10**, 1973-1992 (1993).
- [13] F. L. Addessio, J. N. Johnson, and P. J. Maudlin, "The Effect of Void Growth on Taylor Cylinder Impact Experiments," J. Appl. Physics 73.11, 7288-7297 (1993).
- [14] J. W. Hancock and R. D. Thomson, "Strain and Stress Concentrations in Ductile Fracture by Void Nucleation, Growth and Coalescence," *Mat. Sci. Tech.* 1, 684-690 (1985).
- [15] C. C. Chu and A. Needleman, "Void Nucleation Effects in Biaxially Stretched Sheets," J. Engrg. Mat. Tech. 102, 249-256 (1980).
- [16] V. Tvergaard, "Influence of Voids on Shear Band Instabilities under Plane Strain Conditions," *Int. J. Fracture* **17.4**, 389-406 (1981).
- [17] A. L. Gurson, "Continuum Theory of Ductile Rupture by Void Nucleation and Growth: Part I – Yield Criteria and Flow Rules for Porous Ductile Materials," J. Engrg. Mat. Tech. 99, 2-15 (1977).
- [18] J. C. Nagtegaal, D. M. Parks, and J. R. Rice, "On Numerically Accurate Finite Element Solutions in the Fully Plastic Range," *Comput. Methods Appl. Mech. Engrg.* 4, 153-177 (1974).
- [19] G. Shi and G. Z. Voyiadjis, "A Computational Model for FE Ductile Plastic Damage Analysis and Plate Bending," J. Appl. Mech. 60, 749-758 (1993).
- [20] J. H. Lee and Y. Zhang, "A Finite-Element Work-Hardening Plasticity Model of the Uniaxial Compression and Subsequent Failure of Porous Cylinders Including Effects of Void Nucleation and Growth – Part I: Plastic Flow and Damage," J. Engrg. Mat. Tech. 116, 69-79 (1994).
- [21] N. Aravas, "On the Numerical Integration of a Class of Pressure-Dependent Plasticity Models," *Int. J. Numer. Methods Engrg.* 24, 1395-1416 (1987).
- [22] T. J. R. Hughes and F. Brezzi, "On Drilling Degrees of Freedom," Comput. Methods Appl. Mech. Engrg. 72, 105-121 (1989).
- [23] F. Essenburg, "On the Significance of the Inclusion of the Effect of Transverse Normal Strain in Problems Involving Beams With Surface Constraints," J. Appl. Mech. 127-132 (March 1975).
- [24] R. D. Cook, *Concepts and Applications of Finite Element Analysis*, 2<sup>nd</sup> ed., Wiley, New York, 1981.

- [25] T. Belytschko, C. S. Tsay, and W. K. Liu, "A Stabilization Matrix for the Bilinear Mindlin Plate Element," *Comput. Methods Appl. Mech. Engrg.* 29, 313-327 (1981).
- [26] R. H. MacNeal and R. L Harder, "A Proposed Set of Problems to Test Finite Element Accuracy," *Finite Elements in Design and Analysis*, ed. W. D. Pilkey, Vol. 1, North-Holland, Amsterdam, 3-20 (1985).
- [27] P.M. McDermott and Y.W. Kwon, "Development of a Shell Element with Pressure Variation through the Thickness - Part II," NPS-ME-98-005 Progress Report (1998).

## INITIAL DISTRIBUTION LIST

1.	Defense Technical Information Center 8725 John J. Kingman Rd., STE 0944 Ft. Belvoir, Virginia 22060-6218	2
2.	Dudley Knox Library, Code 013 Naval Postgraduate School 411 Dyer Rd. Monterey, California 93943-5101	2
3.	Professor Young W. Kwon, Code ME/Kw Naval Postgraduate School Monterey, California 93943	4
4.	LT Patrick M. McDermott, USN 80 La Havre Circle Florissant, MO 63031	2
5.	Mr. John McKirgan, Code 614 Naval Surface Warfare Center Carderock Division 9500 MacArthur Boulevard West Bethesda, Maryland 20817-5700	1
6.	Mr. Edward Johnson Naval Surface Warfare Center Indian Head Division Code 40E, Bldg 302 Indian Head, Maryland 20640-5035	1
7.	Research Office, Code 09 Naval Postgraduate School Monterey, California 93942	1