


AD-A083 113

BOEING AEROSPACE CO SEATTLE WA BOEING MILITARY AIRPL--ETC F/6 9/2
COMPUTER PROGRAM DEVELOPMENT SPECIFICATION FOR IDAMST OPERATION--ETC(U)
NOV 76 F33615-76-C-1099
SPEC-58-4042 AFAL-TR-76-208-ADD-2 NL

UNCLASSIFIED

1 of 3
AD
A083 113



PRO 47163
NOV 55940

LEVEL III

① ms

⑥ COMPUTER PROGRAM DEVELOPMENT SPECIFICATION
FOR IDAIST OPERATIONAL FLIGHT PROGRAMS
Addendum 2 APPLICATIONS SOFTWARE

ADA083113

Prepared by

THE BOEING AEROSPACE COMPANY
✓ BOEING MILITARY AIRPLANE DEVELOPMENT
SEATTLE, WASHINGTON

⑪ NOV 1976

⑭ SPEC-SB-4042

⑱ AFAL

⑲ TR-76-208-ADD-2



⑫ 2672

⑮ F33615-76-C-1099

APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED

PREPARED FOR
AIR FORCE AVIONICS LABORATORY
AIR FORCE SYSTEM COMMAND
UNITED STATES AIR FORCE
WRIGHT-PATTERSON AFB, OHIO 45433

SDTIC
ELECTE
APR 17 1980

THIS DOCUMENT IS BEST QUALITY PRACTICABLE.
THE COPY FURNISHED TO DDC CONTAINED A
SIGNIFICANT NUMBER OF PAGES WHICH DO NOT
REPRODUCE LEGIBLY.

DDC FILE COPY

80 4 15 059
410258

DISCLAIMER NOTICE

**THIS DOCUMENT IS BEST QUALITY
PRACTICABLE. THE COPY FURNISHED
TO DTIC CONTAINED A SIGNIFICANT
NUMBER OF PAGES WHICH DO NOT
REPRODUCE LEGIBLY.**

FOREWORD

This document establishes performance and design requirements for the IDAMST Operational Flight Program Applications Software.

It was prepared for the Air Force Avionics Laboratory under Contract Number F33615-76-C-1099, in fulfillment of Contract Data Requirement List item 0001, sequence number 7.

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DDC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Date	
Initials	
A	23 CP

DISTRIBUTION STATEMENT
Approved for Distribution
Disin

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
	Foreword	ii
	Table of Contents	iii
	List of Figures	vi
	List of Tables	vii
	Abbreviations	viii
1.0	SCOPE	1
1.1	Identification	1
1.2	Functional Summary	1
2.0	APPLICABLE DOCUMENTS	2
2.1	Government Documents	2
3.0	REQUIREMENTS	3
3.1	Computer Program Definition	3
3.1.1	Interface Requirements	3
3.1.1.1	Interface Block Diagram	3
3.1.1.2	Detailed Interface Definition	7
3.1.1.2.1	IDAMST System Hardware Interfaces	7
3.1.1.2.2	Function Identification	7
3.1.1.2.2.1	Flight and Propulsion	7
3.1.1.2.2.2	Communication	20
3.1.1.2.2.3	Navigation and Guidance	20
3.1.1.2.2.4	Payload	24
3.1.1.2.2.5	Aircraft Systems	27
3.1.1.2.2.6	Defense	30
3.1.1.2.3	Software Interfaces	30
3.1.1.2.3.1	Executive Software Interface	31
3.1.2	Applications Software Architecture	41
3.1.2.1	Software Structure	41
3.1.2.2	Software Relationships	55
3.2	Detailed Functional Requirements	62
3.2.1	System Control Modules	62
3.2.1.1	Master Sequencer	62
3.2.1.2	Request Processor	62
3.2.1.3	Configurator	64
3.2.1.4	Subsystem Status Monitor	65
3.2.2	Operational Sequencers	66
3.2.3	Specialist Functions	67
3.2.3.1	Brute Force Specialist Functions	67
3.2.3.2	Computational	69

TABLE OF CONTENTS (Continued)

<u>Section</u>	<u>Title</u>	<u>Page</u>
3.2.3.3	Tailored Mode Specialist Functions	79
3.2.3.4	Handler Specialist Functions	87
3.2.4	Display Processes	90
3.2.4.1	Lights Display Process	90
3.2.4.2	Instruments Display Process	91
3.2.4.3	HUD Display Process	91
3.2.4.4	HSD Display Process	92
3.2.4.5	MPD Checklist Display Process	94
3.2.4.6	MPD Parameters/Status Display Process	95
3.2.4.7	Error/Warning Display Process	95
3.2.4.8	IMK Fixed Text Display Process	99
3.2.4.9	DEK Mark Display Process	99
3.2.4.10	IMK Status Display Process	101
3.2.5	Equipment Processes	103
3.2.5.1	UHF-AM Equipment Process	103
3.2.5.2	VHF-AM Equipment Process	105
3.2.5.3	VHF-FM Equipment Process	106
3.2.5.4	HF/SSB Equipment Process	107
3.2.5.5	ICS Equipment Process	108
3.2.5.6	Public Address Equipment Process	109
3.2.5.7	Secure Voice Equipment Process	109
3.2.5.8	DEK Equipment Process	110
3.2.5.9	DSMU Equipment Process	111
3.2.5.10	TACAN Equipment Process	112
3.2.5.11	HCU Equipment Process	113
3.2.5.12	OMEGA Equipment Process	114
3.2.5.13	CCA Equipment Process	116
3.2.5.14	Flight Control System Equipment Process	116
3.2.5.15	Flares Dispenser System Equipment Process	118
3.2.5.16	G-Meter Equipment Process	118
3.2.5.17	INS Equipment Process	119
3.2.5.18	SKE/ZM Equipment Process	120
3.2.5.19	LF ADF Equipment Process	121
3.2.5.20	UHF ADF Equipment Process	122
3.2.5.21	Radar Altimeter Equipment Process	124
3.2.5.22	ILS Equipment Process	126
3.2.5.23	Compass Equipment Process	127
3.2.5.24	Long Range Radar Equipment Process	128
3.2.5.25	IRD & W System Equipment Process	129
3.2.5.26	RHAW System Equipment Process	129
3.2.5.27	Flight Surfaces Equipment Process	130
3.2.5.28	Aircraft Sensors Equipment Process	130
3.2.5.29	Brakes/Gear/Caution Equipment Process	131
3.2.5.30	Avionics On/Off Equipment Process	132

TABLE OF CONTENTS (Continued)

<u>Section</u>	<u>Title</u>	<u>Page</u>
3.2.5.31	FDR Equipment Process	133
3.2.6	Special Requirements	134
3.3	Adaptation	135
3.3.1	General Environment	135
3.3.2	System Parameters	135
3.3.3	System Capacities	135
4.0	Quality Assurance Provisions	138
4.1	Introduction	138
4.2	Computer Program Verification	139
4.2.1	Program Element Tests	139
4.2.2	CPCI Integration Tests	140
4.2.3	Formal Software Testing	140
5.0	Preparation for Delivery	141
6.0	Notes	142
6.1	Growth Items	142
6.1.1	JTIDS	142
6.1.2	TF/TA	145
6.1.3	GPS	146
10.0	Appendix I: Hardware/Software Signal List	147

LIST OF FIGURES

<u>Number</u>	<u>Title</u>	<u>Page</u>
3.0-1	IDAMST Composite Mission Requirements	4
3.1-1	IDAMST OFF Interfaces	5
3.1-2	IDAMST System Block Diagram	6
3.1-3	IDAMST Signal List for Applications Software/Example	9
3.1-4	IDAMST Function Identification List	10
3.1-5	IDAMST Cockpit Instrument Panel	12
3.1-6	IMK-DEK-HCM	15
3.1-7	Avionics - Flight Control System Interface	19
3.1-8	Communication Equipment Control Requirements	21
3.1-9	INS Block Diagram	22
3.1-10	Navigation Control Requirements	25
3.1-11	Task States and Control	32
3.1-12	Application Software Organization	42
3.1-13	Master Sequencer Interface	43
3.1-14	Request Processor Interface	44
3.1-15	Configurator Interface	45
3.1-16	Subsystem Status Monitor Interface	46
3.1-17	Operational Sequencer Interface	47
3.1-18	Computational Specialist Function Interface	49
3.1-19	Brute Force Specialist Function Interface	50
3.1-20	Tailored Mode Specialist Function Interface	51
3.1-21	Handler Specialist Function Interface	52
3.1-22	Display Processes Interface	53
3.1-23	Equipment Processes Interface	54
3.1-24	Applications Software Control/Data Interfaces	56
3.2-1	Applications Software Components	63
3.2-2	IMK (UHF-AM) Software Function	80
3.2-3	MFDC Software Function	83
3.2-4	CCA (Pushbutton) Software Function	85
3.2-5	HCH Software Function	86
3.2-6	Sample MPD Display Combined NAV/COMM Status	98
3.2-7	Sample IMK Fixed - Text Display	100
3.2-8	Sample IMK Status Display	102
	Baseline JTIDS Transient/Receive Functions	143

LIST OF TABLES

<u>Number</u>	<u>Title</u>	<u>Page</u>
3.1-1	Display Parameters	13
3.1-2	Categories of Compool Blocks	36
3.2-1	HUD Parameters	93
3.2-2	Nominal Display vs. MPD Assignment	96
3.2-3	Normal Displays at Beginning of Mode	97
3.2-4	EQUIP Summary	104
3.3-1	IDAMST Storage/Timing Estimates	136

ABBREVIATIONS

ADC	Air Data Computer
ADF	Automatic Direction Finder
AFAL	Air Force Avionics Laboratory
AMST	Advanced Medium STOL Transport
BCIU	Bus Controller Interface Unit
CARP	Computed Air Release Point
CCA	Column Control Assembly
CCIP	Continually Computed Impact Point
CCT	Combat Control Team
CRT	Cathode Ray Tube
DAIS	Digital Avionics Information System
DEK	Data Entry Keyboard
DITS	Digital Integrated Test System
DS/MU	Display Switch/Memory Unit
ECM	Electronic Counter Measure
EFCS	Electronic Flight Control System
EHARS	Error Handling and Recovery Software
FCS	Flight Control System
GMT	Greenwich Mean Time
IDAMST	Integrated Digital Avionics for a Medium STOL Transport
IFF/SIF	Identification Friend or Foe/Selective Identification Feature
ILS	Instrument Landing System
HCU	Hand-Controller Unit
HF/SSB	High Frequency/Single Side Band
HSD	Horizontal Situation Display
HUD	Head-Up Display
IMK	Integrated Multifunction Keyboard
INS	Inertial Navigation System
LAPES	Low Altitude Parachute Extraction System
MCL	Master Caution Light
MDSO	Modular Digital Scan Converter

MFDC	Multi-Function Display Controls
MMK	Master Mode Keyboard
MMU	Mass Memory Unit
MPD	Multi-Purpose Display
MPDG	Modular Programmable Display Generator
OPF	Operational Flight Program (Software)
OPS	Operational Sequencer
RF	Radio Frequency
RTU	Remote Terminal Unit
SCP	Sensor Control Panel
SKE	Station Keeping Equipment
STOL	Short Take-Off and Landing
TACAN	Tactical Air Navigation
TM	Tailored Mode
T/R	Transmit/Receive
T/R+G	Transmit/Receive Plus Guard
UHF	Ultra High Frequency
VHF	Very High Frequency
VLF	Very Low Frequency
ZM	Zone Marker

1.0 SCOPE

1.1 IDENTIFICATION

This part of this specification establishes the requirements for performance, design, test, and qualification of a computer program identified as IDAMST Operational Flight Program Applications Software.

1.2 FUNCTIONAL SUMMARY

→ This document specifies the software functional requirements for the AMST Mission Scenario, defined in Reference 2-7.1(a), Appendix A. Applications Software functions consist of providing the calculation and control capability necessary for the following mission/operations task areas:

- o Flight and Propulsion,
- o Communications,
- o Navigation and Guidance,
- o Payload,
- o Aircraft Systems,
- o Defense.

Section 2.0 contains a list of government/non-government documents which contribute to this specification.

Section 3.0 describes the design and structure of the Applications Software, and details the hardware/software interface and functional requirements.

Section 4.0 contains procedures to test and verify the Applications Software.

Section 5.0 (Preparation and Delivery) is not applicable.

Section 6.0 contains a description of identified growth areas: JTIDS, TF/TA, GPS.

Section 10.0 contains a complete IDAMST signal list.

2.0 Applicable Documents

2.1 Government Documents

2.1.1 Appendices to Contract F33615-76-C-1099 Statement of Work (SOW).

- (a) Appendix A - "AMST Mission Profile and Scenario (updated)".
- (b) Appendix C - "System Architecture".
- (c) Appendix E - "DAIS Mission Software, OFP Applications (SA-201-303)", 17 Jan 75.
- (d) Appendix F - "DAIS Mission Software, Executive (SA-201-320)", 26 Dec 75.
- (e) Appendix H - "Software Management Plan".
- (f) Appendix M - "TRW System Backup and Recovery Strategy (TRW 6404-5-6-06)", Sept 75.

2.1.2 DAIS Documents (Reference)

2.1.2.1 ICD - Mission Operation Sequence

Pilot/Controls and Displays/Interface with Application Software (SA-803-200), 15 March 76.

2.1.2.2 Mission Software/Controls and Displays Interface (SA-802-301), 12 March 76.

2.1.2.3 DAIS System Control Procedures, (SA-100-101 Appendix A), 7 Nov 75.

2.1.3 IDAMST Documents (Program generated).

2.1.3.1 Computer Program Development Specification, IDAMST OFP Executive (SB 4041), July 76.

2.1.3.2 Computer Program Development Specification, IDAMST OFP Error Handling and Recovery (SB 4043) July 76.

2.1.4 IDAMST Documents (Reference)

The following documents, because of release dates, serve only as reference documentation for this specification; however, are considered prime to further definition of the IDAMST system design.

2.1.4.1 System Specification for IDAMST, Type A (SI-1010), June 76.

2.1.4.2 Prime Item Development Specification, IDAMST Processor, Type B1 (SI-4030), June 76.

2.1.4.3 System Segment Specification, IDAMST Control/Display Subsystem, Type A (SI-5020), June 76.

3.0 REQUIREMENTS

This section contains interface and functional requirements for the IDAMST OFP Applications Software.

The AMST mission defined in Reference 2.1.1, Appendix A "AMST Mission Profile and Scenario" requires avionics software support in the areas of flight and propulsion, communications, navigation and guidance, payload, aircraft systems, and defense. The Applications Software provides the support necessary to satisfy the design and performance requirements for these mission areas. These support functions include:

- o C&D control
- o Sensor control
- o Specialized calculations (e.g., navigation, CARP)
- o Equipment health monitoring
- o Status maintenance
- o Mission mode control
- o Limited software reconfiguration

An overview scenario of the AMST mission is shown in Figure 3.0-1.

3.1 COMPUTER PROGRAM DEFINITION

3.1.1 Interface Requirements

This section describes interface requirements imposed on the Applications Software design by other IDAMST equipment/computer programs.

Figure 3.1-1 identifies the three computer program configuration items comprising the OFP software subsystem for IDAMST. The Applications Software functionally interfaces with the AMST hardware subsystems integrated into IDAMST. This functional interface is shown by dashed lines on Figure 3.1-1 as a part of the OFP Executive Software. Overall control of interface operations is provided by the Executive.

The basic IDAMST software design and core element hardware design (processors, data bus, remote terminals and control/displays core elements) are influenced by the Digital Avionics Information System (DAIS) design currently being developed by the Air Force Avionics Laboratory (AFAL). This is evidenced by specific architectural design requirements stated in this specification (Section 3.1.2). Also imposed on the OFP software as design considerations are guidelines and techniques for structured software design as noted in Sections 3 and 10 of Reference 2.1.1, Appendix H "Software Management Plan".

The relevant characteristics of the IDAMST core element hardware effecting the OFP applications software design are defined in Reference 2.1.1, Appendix C "System Architecture".

3.1.1.1 Interface Block Diagram

Figure 3.1-2 is a block diagram of the IDAMST system. Three mission processors are employed in which the OFP Applications Software resides in support of the AMST mission. Overall system control is directed by the Executive Software,




Figure 3.0-1 IDAMST Composite Mission Requirements




FIGURE 3.1-1 IDAMST OPF INTERFACES




FIGURE 3.1.2: IDAMST SYSTEM BLOCK DIAGRAM

including control of the functional interfaces between the Applications Software and the IDAMST system hardware. The task of the Executive with respect to these hardware/software interfaces is to make the mechanization of data transfer transparent to the Applications Software and thereby decouple the system core element hardware programming considerations from the purely functional Applications Software tasks. To the Applications Software, the task of communicating with IDAMST system hardware is essentially the formatting, ordering, and generation or interpretation of avionics hardware parameter (signal) lists.

3.1.1.2 Detailed Interface Definition

The intent of this paragraph and subparagraphs is to define the functional relationships of the Applications Software to the IDAMST system hardware and associated OFP software (Executive and EHARS).

3.1.1.2.1 IDAMST System Hardware Interfaces

Figure 3.1-2 illustrated the IDAMST system hardware in block diagram form. Figure 3.1-2.1 is the complete IDAMST equipment/disposition list.

The Executive software is tasked with the responsibility of making the mechanism and frequency of communication transparent to the Applications Software. Programming considerations imposed by the core element design are not apparent to the Applications Software. Therefore the Applications Software/hardware interfaces can be described by a signal list. Figure 3.1-3 is an example of such a list which is required to define the functional interface to the avionics hardware. The Application Software/IDAMST Hardware interface shall be as listed in Section 10.

3.1.1.2.2 Function Identification

Figure 3.1-4 identifies the selected functions for IDAMST requiring Applications Software support. These functions are categorized into six basic mission/operations task areas:

- o Flight and Propulsion
- o Communications
- o Navigation and Guidance
- o Payload
- o Aircraft Systems
- o Defense

3.1.1.2.2.1 Flight and Propulsion

The IDAMST functions in this category are those associated with pilot/copilot control and management of the AMST flight. Five subcategories are identified:

- o Crew Displays
- o Crew Controls
- o Flight Control System
- o Weights and Balance
- o Energy Management

2 5 0 VERTICAL NAVIGATION SYSTEM		INPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
HEADS UP DISPL IN	1	25015	10				200	2	416
PAC HEADING BAC	25029	1	+28 VDC		28VDC=TRUE		1	0	0
RANGE TO DEST UNITS	25023	9		0/9		1/2 MILE PR	14	0	56
RANGE TO DEST TENS	25024	9		0/90			14	0	56
RANGE TO DEST HOURS	25025	9		0/900			14	0	56
DEST REL BEARING	25026	9		0/360 DEG	1DEG=1DEG	5 DEG	14	0	56
MAG HEADING	25027	9		0/360 DEG	1DEG=1DEG	5 DEG	14	0	56
ATTITUDE GDCO	25022	1	A/C+28 VDC		28VDC=TRUE		1	0	0
HEADING/3BT	26002	10					32	16	512
STEERING ERROR	25030	5		+/-10 DEG	150 UA/10 DEG	1/16 DISP	11	32	352
ROLL	2501A	9		0/360 DEG	1DEG=1DEG	0.1 DEG RMS	14	32	848
PITCH	25021	9		+/-90 DEG	1DEG=1DEG	0.1 DEG RMS	14	64	896

FIGURE 3.3-3: IDAMST SIGNAL LIST OF APPLICATIONS SOFTWARE (EXAMPLE)




FIGURE 3.1-4 IDAMST FUNCTION IDENTIFICATION LIST

Figure 3.1-5 is a cockpit layout of the controls and displays integrated into the IDAMST system.

3.1.1.2.2.1.1 Crew Displays

The Application Software shall transfer formatted parameter lists and control commands to the various IDAMST display devices. These devices are divided into two categories:

- o CRT displays
- o Dedicated displays

CRT Displays

CRT-type displays integrated into the IDAMST system are:

- o HUD (pilot's, co-pilot's)
- o HSD (pilot's, co-pilot's)
- o MPD (pilot's, co-pilot's, center)
- o IMK (pilot's, co-pilot's)

Functionally the interface between the HUD, HSD, MPD displays and the Applications Software shall be a list of ordered parameters and control data transmitted to the Modular Programmable Display Generator (MPDG). Display formatting and symbol generation is the task of the MPDG. Table 3.1-1 lists the parameters and types of information to be displayed on the HUD, HSD, and MPD.

The interface between the IMK CRT and the Applications Software shall be control and page identification transmitted to the Alpha/Numeric Symbol Generator.

Dedicated Displays

Several dedicated displays have been integrated into the IDAMST system. The following displays shall be controlled by the Applications Software.

- o Mach
- o Airspeed
- o Altitude
- o Vertical Velocity
- o G Meter
- o Warning Lights
 - EFCS
 - Speed Low
 - Ground Proximity Warning
- o Marker Beacon Lights




FIGURE 3.1-5 IOMST COCKPIT INSTRUMENT PANEL

HUD FUNCTIONS (VSD ALTERNATE)	HSI DISPLAY	MAP DISPLAY	MPD FUNCTIONS
Attitude (Pitch & Roll) Heading	Distance to Waypoint Time to Go	MAP Scale Way Points	Checklist
Air Speed	Heading & Heading Annunciator	Nav aids	Nav. Status
Altitude (BARO)	Bearing Pointers (2)	Key Elevations	Comm. Status
Altitude (Radar)	Bearing Identifiers	Projected A/C Position	System Status
Flight Director Command	Selected Heading	"Killer" Data	Warning/Caution Info.
Flight Path Angle	Selected Course	Alternate Track	Departure Area Data
Flight Path Acceleration	To - From	Airport/Target Location (Cursor Position)	Take-off Parameters
Drift Angle	Deviation		Cruise Parameters
Vertical Velocity	Vertical Deviation Path		Refuel Status
Localizer & GS Deviation	Pointer		Air Drop Flight Parameters
Speed Error	Vertical Track Change Alert		Air Drop Area Data
Warnings	Lateral Track Change Alert		Approach Data
Pitch Reference	Offset Annunciator		Landing Area Data
Sideslip	Nav. Mode Annunciator		Weight and Balance Data (Gross Weight & Total Fuel)
Rate of Turn	Heading Warn		Flare Inventory
Mach	Navigation Warn		SKE Display
Command Airspeed			Radar Display
Command Heading			Engine Parameters (Cursor Position)
Command Altitude			
Target Designator			
Fall Line			
Constantly Computer Impact Point (Cursor)			

3.1.1.2.2.1.2 Crew Controls

The controls shown on Figures 3.1-5 and 3.1-6 are as follows:

- o Integrated Multifunction Keyboard - IMK (pilot's, co-pilot's)
- o Data Entry Keyboard - DEK (pilot's, co-pilot's)
- o Column Control Assembly - CCA (pilot's, co-pilot's)
- o Multifunction Display Controls - MFDC (pilot's HSD and MPD, co-pilot's HSD and MPD, center MPD)
- o Hand Controller Unit - HCU
- o Master Mode Keyboard - MMK

The Applications Software shall accept input from these devices, and after processing display requested information and/or acknowledge receipt of control action.




FIGURE 3.1-6 IMK-DEK-HCU

Integrated Multifunction Keyboard (IMK)

The two IMKs (pilot's and co-pilot's) are the primary crew control devices. The IMK (Figure 3.1-6) consists of two sets of keys and a CRT. There are eight keys across the top of the IMK. These top keys allow the crew to select special functions that do not normally occur during a current mission phase. These functions are:

- o Communications - used to control the radio equipment
- o Navigation - used to control the navigation equipment and steering modes.
- o Sensors - provides sensor mode control.
- o Systems - provides the crew with various system functions.
- o Library - allows the crew to activate several special function that do not fit into other functional areas.
- o Checklist - enables the crew to request MPD checklists.
- o Payload - provides control for loading and dropping of cargo.
- o DITS - provides access to test system.

The functions implied by the ten IMK side keys depend upon the current state of the IMK. Each side key has a corresponding legend on the IMK CRT which indicates the current meaning of the key. There are one or more IMK pages for each mission phase and for each special function invoked by one of the eight IMK top keys.

The eight IMK top keys are backlighted green (active) or yellow (inactive). The ten side keys are backlighted white.

The IMK CRT was discussed as a display device in Section 3.1.1.2.2.1.1.

Data Entry Keyboard (DEK)

The two DEKs (pilot's and co-pilot's) provide data entry capability and allow crew to perform MPD checklist functions.

The DEK (Figure 3.1-6) consists of 16 pushbuttons used as follows:

- o Data Entry
 - . digits 0 through 9
 - . CASE : upper/lower case
 - . ENTER : indicating end of data to software
 - . CLEAR : indicating restart to software
- o Checklist
 - . CHECK : check off item
 - . SPACE : skip item
 - . PAGE : advance page

The identification of each key depressed is sent (one at a time) to the Applications Software and shall be processed upon receipt of an ENTER.

Column Control Assembly (CCA)

The two CCAs (pilot's and co-pilot's) allow microphone control by crew members. Shaker commands to the CCAs shall be generated by the Application Software whenever a stall condition becomes imminent.

Multi-Function Display Controls (MFDC)

The MFDC consists of the six pushbuttons functionally attached to each MPD/HSD device. These pushbuttons are used by the crew to:

- o Switch a display from one device to another.
- o Request sub-types of a display.
- o Vary the display scale.
- o Request sensor video.
- o Etc.

The selected pushbutton(s) are backlighted.

Hand Controller Unit (HCU)

The HCU is used for: 1) navigation data entry and 2) radar antenna control. Figure 3.1-6 shows its layout.

HCU control consists of:

- o Seven pushbuttons allowing selection of the CRT where cursor is applicable.
- o A hand control to move cursor.
- o A button on the hand control which activates output of cursor displacement (1st push) and terminates or designates to software the final cursor position (2nd push).

The pushbuttons are backlighted green (active) or white (inactive).

Master Mode Keyboard (MMK)

The MMK (Figure 3.1-6) allows crew members to select high-level mission modes. These modes determine the parameters to be displayed and the control capability to be offered by the Application Software. Only one Master Mode can be active at any time.

MMK pushbuttons are backlighted green (active) or yellow (inactive).

The Master Modes are:

START	Includes flight crew preflight
TAKEOFF	Taxi, takeoff, area departure
ENROUTE	Later climb, cruise, early descent
AIR REFUEL	Rendezvous, acquisition, refuel
TF/TA	Terrain Following/Terrain Avoidance
AIR DROP	All except LAPES

LAPES	
LAND	Approach, land, taxi
GO AROUND	
SHUTDOWN	Includes flight crew post flight
GROUND TEST	Ground crew preflight and postflight

3.1.1.2.2.1.3 Flight Control System

The Flight Control System is assumed to be flight critical; therefore it was mechanized in a triplex configuration. The air data and aircraft attitude information is required for flight control and assumed to be available for use by the avionics. In addition, the avionics system shall provide steering signals to the flight control system and monitor the flight control status.

The IDAMST - Flight Control System interface is shown in Figure 3.1-7.

3.1.1.2.2.1.4 Weights and Balance

A simple weight and balance function is assumed, whereby aircraft gross weight, total fuel, and calculated center of gravity (c.g.) is displayed via an MPD. The crew must input aircraft gross weight and c.g. position prior to takeoff and decremented weight and c.g. shift after cargo drop. The mission processors will maintain current estimated gross weight and c.g. position prior to takeoff and decremented weight and c.g. shift after cargo drop. The mission processors will maintain current estimated gross weight and c.g. position throughout the flight, based upon crew inputs, remaining fuel, and fuel distribution. Cargo weight decrements and c.g. shifts may be pre-stored and only the drop event need be signalled to the processors via the IMK.

3.1.1.2.2.1.5 Energy Management

Engine performance and airplane operations can be optimized by energy management technique. Energy management has been noted only as a potential growth item.




Figure 3.1-7 Avionics/Flight Control System Interface

3.1.1.2.2.2 Communications

IDAMST provides the flight crew with the capability to control various communication devices for air-ground, air-air, and internal communications. A description of the function(s) associated with each device is given below.

The Intercommunication Set (AN/AIC-18) provides:

- o two-way voice communication between crew stations
- o interfaces with radio transceivers, navigation receivers, public address amplifier, and maintenance intercom outlets

The ICS allows for selection, control, and distribution of radio systems for airborne/ground station communication and monitoring.

The P.A. System (AN/AIC-13) is used for voice announcements in the cargo areas.

The two UHF-AM (AN/ARC-164) are used for military communications and as backup ADF receivers. They provide short-range, line-of-sight, two-way simplex voice communication with ground systems and other aircraft, operating in the 225-399.95 MHz frequency band. When the radio is in backup ADF mode, bearing is obtained via the ADF EQUIP.

The VHF-AM radio (Wilcox-807A) is used for CCT and civilian communications. It provides two-way simplex 160 nautical mile voice communication in the 118 - 135.975 MHz frequency band over line-of-site propagation paths.

The VHF-FM radio (FM622A) is used primarily for military/CCT communications. It provides short-range line-of-sight, two way simplex voice communication in the 30 - 75.95 MHz frequency range.

The HF/SSB radio (AN/ARC-123) is used for long-range military communications. It provides two-way simplex voice communications at distances up to 2,500 nautical miles, operating in the 2 - 30 MHz frequency band.

The Secure Voice System (TSEC/KY-58) encrypts and decrypts VHF/UHF voice communication.

The IFF/SIF (AN/APX-101) is used for automatic radar identification and position/altitude reporting in the civil air traffic control system and similar data in the tactical traffic control environment. Its operational frequency band is 1030 - 1090 MHz.

Control is implemented by the flight crew via IMK. The particular control associated with each device shall be as shown in Figure 3.1-8.

3.1.1.2.2.3 Navigation and Guidance

IDAMST provides an Integrated Navigation System (Figure 3.1-9) which performs the following functions:

COMMUNICATIONS CONTROL FUNCTIONS

<u>UHF #1</u>	<u>UHF #2</u>	<u>VHF-AM</u>	<u>VHF-FM</u>	<u>IFF ON/OFF</u>	<u>HF/SSB</u>	<u>SEC VOICE ON/OFF</u>
OFF	OFF	ON/OFF	OFF	(NOTE)	ON/OFF	(NOTE)
T/R	T/R	*FREQ SEL	T/R		SSB	
T/R+G	T/R+G	SQUELCH	RE-TRANS		AME	
ADF	ADF	DISABLE	HOME		FREQ SHIFT KEY	
GUARD XMIT	GUARD XMIT	*VOLUME	*FREQ SEL		CW	
*CHAN SEL	*CHAN SEL		SQUELCH		*FREQ SEL	
*FREQ SEL	*FREQ SEL		DISABLE		*SQUELCH	
CHAN PRESET	CHAN PRESET		CARRIER		DISABLE	
SQUELCH	SQUELCH		tone		NOISE BLANK	
DISABLE	DISABLE		*VOLUME		RF GAIN	
*VOLUME	*VOLUME				*VOLUME	

ICS ON/OFF

(NOTE)


P.A. ON/OFF

(NOTE)

*DEK INPUT

NOTE: DEDICATED CONTROL PANELS FOR - IFF
 - SECURE VOICE
 - INTERCOMM AND PA

FIGURE 3.1-8 COMMUNICATIONS EQUIPMENT CONTROL REQUIREMENTS



INS BLOCK DIAGRAM

FIGURE 3.1-9

Area Navigation

The following enroute and terminal navigation functions are provided:

- o Automatic three dimensional navigation and guidance within the ATC environments
- o TACAN slant range correction
- o Automatic tuning of navigation radio receivers
- o Great circle navigation and optimization of navigation position
- o Route and terminal navigation data storage capacity adaptable to Air Force requirements
- o Simple reversion to VORTAC or Inertial navigation
- o Offset track capability

Computed Air Release Point (CARP)

Automatic CARP calculation capability shall be provided. Means of entering load characteristics, wind data, relative target location, and position update capability shall be designed for pilot ease of operation.

Rendezvous

Navigation data will be processed to compute guidance and steering data to enable rendezvous with other aircraft.

Flight Director

Flight Director Command Signals are provided for display on the pilots' Altitude Director Indicator.

Steering

Steering signals are provided for the Flight Control System.

To accomplish the above functions, the following sensors are provided:

- o The TACAN System (AN/ARN-118) furnishes data relative to a selected TACAN facility operating in the 962 - 1213 MHz frequency band.
- o The two Radar Altimeters (AN/APN-194) are range tracking radars which provide altitude information from 0 - 5000 feet.
- o The OMEGA Radio Navigation System (AN/ARN-) provides airplane position fixes using the worldwide network of VLF ground transmitters.

- o The Magnetic Compass (C-12) provides heading information for navigation.
- o The LF/ADF (DF-206) provides the navigation calculation with bearing to a selected low frequency radio station.
- o The UHF/ADF (DF-301E) provides the navigation calculation with bearing to a selected ultra-high frequency radio station.
- o The INS (Carousel IV) is a self-contained inertial navigation system (including a digital computer) which provides worldwide aircraft navigation entirely independent of ground communication.
- o The Instrument Landing System (AN/ARN-108) is used in conjunction with ground transmitting equipment and airplane flight director calculations to provide display capability for marker beacon, glide-slope, and localizer signals.
- o The Station Keeping Equipment (AN/APN-169) is a cooperative air-to-air station keeping system for flights of up to 36 aircraft. It enables these aircraft to locate and identify one another; and to maintain formation/rendezvous regardless of visibility. The SKE interfaces with the MDSC to provide a formation display.
- o The Long Range Radar (AN/APQ-122) provides precise navigation capabilities for long-range ground mapping, weather detection, and beacon interrogation. A high-resolution CRT radar display is available to the crew upon request. Data is input into the navigation function via HCU in conjunction with the CRT display.
- o The Flight Control System provides air data, attitude, and mode and status information. This information is processed by the avionics system to provide steering data for the flight control system.

Sensor control is implemented by the flight crew via IMK. The particular control associated with each sensor shall be as shown in Figure 3.1-10.

3.1.1.2.2.4 Payload


IDAMST functions in this area consist of providing payload status reporting and automatic load release control.

Status

The Applications Software shall monitor, maintain and report (via CRT display) status of -

- o Ramp and cargo door
- o Chute release
- o Caution signal

NAVIGATION CONTROL FUNCTIONS



*DEK INPUT

FIGURE 3.1-10: NAVIGATION CONTROL REQUIREMENTS

NAVIGATION CONTROL FUNCTIONS

<u>AIRDROP DATA ENTER</u>	<u>DIRECTION FINDER</u>	<u>SKE (IPS)</u>	<u>NAV DATA DISPLAY</u>	<u>NAV DATA ENTER</u>
*LAT/LONG	<u>LF-DF</u>	ON-OFF	RNG BRG	*ROUTE SELECT
*TYPE	ON-OFF	FREQ A/FREQ B	OFS	*WAY POINT LOAD
*WEIGHT	AUTO/MANUAL	*IN TRK OFFSET	WAY POINT	*WAY POINT SEQ
*WIND	*FREQ SEL	*ALT OFFSET	FROM-TO	*PRESENT POSITION
*RELATIVE FIX	TEST	*CROSS TRK OFFSET	GS/GTK	MARK
-RANGE	*VOLUME	*LDR # SEL	WIND	HOLD
-BEARING	VHF-ADF	*PRX WARM RNG	TTG/XTK	OFFSET
*ALTITUDE		PRX WARM TONE	PP	**UPDATE
		ON-OFF	MON	*NAVAID SELECT
	ON-OFF	PRX WARM TONE	NAVAID DATA	AUTO/MANUAL
	AUTO/MANUAL	RESET		ENTER
	*FREQ SEL	MASTER-FOLLOW SEL		<u>MANUAL SELECT</u>
	TEST	MASTER IND		*ALT SEL
	*VOLUME	BIT TEST		*AIRSPEED CMD
		ID FUNC SEL		*PITCH ATT CMD
		*RNG SCALE SEL		*FPA CMD
		*RNG MARK INTEN		*SEL CRSE
		DISPLAY CENTERING		*SEL MDA
		BLANKING		*SEL DH
	<u>MANUAL</u>			
	AUTO			
	INS			
	OMEGA			
	TACAN			
	VOR/ILS			
	FORMATION			
	HDG SEL			

*DEK INPUT
**HCU INPUT

FIGURE 3.1-10: NAVIGATION CONTROL REQUIREMENTS
Continued

- o Jump signal
- o Paratroop alarm
- o Aft door deflection

Release Control

Cargo delivery control consists of a load release signal output from the CARP function.

3.1.1.2.2.5 Aircraft Systems

The IDAMST functions relating to this area include warning, caution/monitoring, electrical control, and test of the various subsystems.

Warning

IDAMST incorporates either copied or generated warning functions. Copied warning functions are monitored at the flight crew's hardwired (dedicated) indicators and their status copied into IDAMST processors. Warnings are subsequently displayed on the crew's primary flight displays and appropriate emergency checklist procedures are selected for display on the pilot's or copilot's MPD. Copied warning functions do not have responsibility for originating the warning signal. This is the responsibility of the affected system or equipment. Generated warning signals originate within the IDAMST system. Primary responsibility for detection and warning is an IDAMST responsibility.

Copied Warning functions shall be

Fire

Gear

Stabilizer Trim

Generated Warning functions:

Ground proximity warning shall be generated on the basis of aircraft altitude (above ground), vertical velocity, gear position, and flight mode. Visual and aural warnings will be commanded.

Stall warning shall be generated on the basis of flap position, angle of attack, and thrust computations in the STOL configuration. Visual readout on flight instruments and the "stick shaker" command shall be initiated by the IDAMST system.

Low Speed warning shall be generated when the computed airspeed approaches minimum airplane requirements. A visual warning will be provided.

Overspeed warning shall be generated when the computed airspeed exceeds the airplane maximum speeds (V_H/M_H). Aural warning (clacker) and visual display shall be provided.

EFCS warning shall be generated when the IDAMST processor is error status is received from the Flight Control System. Aural warning and visual display shall be provided.

Caution Monitoring

IDAMST provides secondary control for caution functions: It shall copy current status and provide (on request) an MPD procedure checklist display to assist the crew in determining the cause of the caution message. Monitored functions are derived from monitor sensors, and displays of significant parameters are provided to the crew via MPD display.

Copied Caution Functions shall consist of

- Electrical System
- Hydraulic System
- Fuel System
- Boundary Layer Control
- Air Conditioning
- Anti-Ice
- Overhead Caution Annunciator
- Brakes
- EFCS

Monitored Functions shall consist of

- Engine Parameters (N1, EGT, N2, FF, oil pressure and oil quantity)
- Flap Position (left USB, right USB, left outboard flap, left inboard flap, right inboard flap, and right outboard flap).
- Control Surfaces Position (spoiler elevator and rudder)
- Avionics Systems Hardware Status

Electrical Control

Control is included in the IDAMST processor to provide automatic on/off control of the remote power controllers. Avionics power management is maintained based on the following criteria:

- o Manual crew entry
- o Automatic start-up
- o Master mode
- o Minimal power requirements for overload conditions
- o Automatic reset of nuisance trips

IDAMST provides on/off control for the following:

Instruments and Aircraft Systems

- o counting accelerometer
- o gear-up and locked-left
- o gear-up and locked-right
- o weight on gear - left
- o weight on gear - right
- o stick shaker 1
- o stick shaker 2
- o stab. trim position
- o flap position - left
- o flap position - right
- o fuel totalizer
- o engine 1
- o engine 2

Navigation and Guidance

- o long range radar
- o radar altimeter 1
- o radar altimeter 2
- o magnetic compass
- o INS
- o OMEGA
- o ILS 1
- o ILS 2
- o LF ADF
- o UHF ADF
- o TACAN
- o SKE

Communications

- o public address
- o intercommunication set
- o HF/SSB radio
- o VHF-AM radio
- o VHF-FM radio
- o UHF-AM radio 1
- o UHF-AM radio 2
- o IFF
- o secure voice

Controls and Displays

- o HUD 1
- o HUD 2
- o HSD 1
- o HSD 2
- o MPD 1
- o MPD 2
- o MPD 3
- o MPDG 1
- o MPDG 2
- o DSMU
- o MDSC
- o MFDC
- o HCU
- o MMK

Defensive Measures

- o IRD & W
- o RI & W
- o flares dispenser

Test

IDAMST shall incorporate a limited, in-flight test capability by virtue of BITE, software reasonableness test on input data or associated computed values, and correlation of sensor data by direct comparison with redundant hardware or similar hardware. The extent of in-flight testing which will be practical is TBD. Test data shall be recorded on the DITS recorder. Selected data shall also be input to the Crash Data Recorder.

3.1.1.2.2.6 Defense

The IDAMST functions in this area are those associated with threat detection, warning, display, and flare dispensing.

Infrared Detection and Warning System

The IRD & W System is a defensive countermeasure which detects heat sources. A quadrant-oriented threat display is produced automatically on an MPD upon detection. IRD & W crew control consists of on/off.

Radar Homing and Warning System

The RHAW System is a defensive countermeasure which detects radar sources. A quadrant-oriented threat display is produced automatically on an MPD upon detection. RHAW crew control consists of on/off.

Flares Dispenser System

The Flares Dispenser System contains four volleys of flares which are used as a defensive measure against infrared seeker threats. Crew control consists of on/off, and the capability to drop flare volleys in any combination, either individually or as a group. Flare status is displayed on request.

Simultaneous threat information from the IRD & W and RHAW Systems will be merged into one display.

3.1.1.2.3 Software Interfaces

The only external software interface defined for the Applications Software is with the OFF Executive Software. The Executive Software provides services for the execution of real-time applications, sharing of common data, interprocessor communication, and communication with and between remote terminal units.

Those EHARS functions relating to the Applications Software are performed by code imbedded in the Applications Software. This interface is described in detail in Reference 2.1.3.2.

3.1.1.2.3.1 Executive Software Interface

The Applications Software consists of Tasks, Comsubs, Compool Blocks, and Events.

Tasks and Comsubs are processing modules, containing executable code and local data. Compool Blocks are data modules used for communication between Tasks. Events are boolean values used for control interactions between Tasks.

Tasks interact with the Executive through Real Time Pseudo-Declarations and Real Time Pseudo-Statements.

3.1.1.2.3.1.1 Tasks

Tasks are the principal components of the Applications Software.

At any time, any Task in the system has a "state". The possible states of a Task are shown in Figure 3.1-11. Note that not all states are mutually exclusive; thus, a Task which is "executing" is also dispatchable, active and invoked.

Immediately following system initialization, one Task, the Master Sequencer, is Invoked by the Executive, and all other Tasks are in Uninvoked state. Thereafter, Tasks can be put into Invoked state (Scheduled) or put into Uninvoked state (Cancelled) only by Real-Time Pseudo-Statements executed within other Tasks.

Immediately after being Scheduled, a Task is Inactive; however, it has the potential to become Active, depending upon its Event Condition Set. The Event Condition Set is a collection of Conditions, each of which may be either "on" or "off". Each Condition has a "desired" value. When all the conditions in the Event Condition Set have their desired values, if the Task is Inactive, the Executive will put it into Active state. A Task may have a null Event Condition Set, in which case it can only be Inactive momentarily.

Each Condition in an Event Condition Set is associated with a set of Events. When any of these Events is set on, the Condition is set on; when any of these Events is set off, the Condition is set off. One Event may be associated with more than one Condition in an Event Condition Set. In addition, one Condition may be associated with a "Minor Cycle Event". These are Executive-generated Events which are set "on" at certain specified times and are otherwise inaccessible to the Application Software. If a Condition is associated with a Minor Cycle Event, it may not be associated with any other Event.

A Condition may be either Latched or Unlatched. A Condition associated with a Minor Cycle Event must be Unlatched. The sole difference between a Latched and an Unlatched Condition is that upon the Scheduling or Activation of a Task, the Unlatched Conditions are set to the undesired value. Thus, a Task can only be Activated by an Unlatched Condition when the value of that condition is changed to the desired value subsequent to the last Scheduling or Activation of the Task. By contrast, Latched Conditions are changed only




Figure 3.1-11 Task States and Control

when one of their associated Events is changed. Therefore, a Task with only Latched Conditions in its Condition Set will be immediately Activated after it is Scheduled if all the Conditions were satisfied before the Schedule Statement.

A Task may return from Active to Inactive state from two causes: either because it completes execution, or because it is forcibly Terminated by another Task. In either case, immediately after it returns to Inactive state, the Event Condition Set is evaluated, and if all the Conditions have their desired values, the Task is immediately re-Activated.

When a Task is Activated, it is immediately put into Dispatchable state. If, at any point during its execution, a Task executes a Wait Statement, the Executive will place it into Wait state until the specified condition is satisfied, upon which the Task will again become Dispatchable.

All Dispatchable Tasks should theoretically be executed immediately. However, since there may be more than one Dispatchable Task at any time within any one of the Processors, Tasks are ordered by Priority to resolve possible conflicts. Whenever the Executive in any Processor is not called upon for immediate action, it selects the highest Priority Dispatchable Task, and causes the Processor to execute it.

If a Task is Active but has not yet been executed, it is said to be Ready. If it has been in the process of execution, but has been interrupted by a higher priority Task, it is said to be Suspended. If it is executing, it is said to be Executing.

Any given Task may only be Scheduled by one Task, which is called its Controller. Two Tasks with a common Controller are said to be "siblings". The Tasks Scheduled by any Task are said to be its "sons". If a Task has no sons, it is said to have no "descendents;" otherwise, its descendents are its sons and all the descendents of its sons.

Only a Task's Controller may Cancel or Terminate it; however, when a Task is Cancelled or Terminated, all of its descendents are Cancelled or Terminated. If a Task attempts to Cancel or Terminate itself, it will Cancel or Terminate all of its descendents, but will leave its own state unchanged.

3.1.1.2.3.1.2 Comsubs

In addition to Tasks, the Applications Software may include another kind of processing module, known as the "Comsub". A Comsub may be called from many Tasks; there is a copy of each Comsub in any processor containing a Task from which the Comsub may be called.

A Comsub communicates with a Task which calls it only through its parameters and/or function result. No Comsub may execute any Real-Time Pseudo-Statements; however, one Comsub may call another.

When a Task calls a Comsub, the Task is considered to be executing within the code of the Comsub. Thus, it is possible for one Task to be suspended within the code of a Comsub at the same time that another Task is executing within

the same Comsub. In other words, A Comsub must be re-entrant. To implement this, every Task has a Comsub Local Storage Area assigned by PALEFAC for storage of local data by the Comsubs which it calls. At any time, there is a Comsub Stack Pointer which points to the area available for storage to the next called Comsub. This Comsub Stack Pointer is considered to be part of the process state of the Task, and is saved upon the occurrence of an Interrupt.

3.1.1.2. 3.1.3 Compool Blocks

All communication of data between Tasks or between Tasks and the external environment (RT's) is done by means of "Compool Blocks".

Conceptually, a Compool Block is a Block existing outside of any Task. No Task may directly access a Compool Block when a GLOBAL Copy is declared; instead, a Task references a "Local Copy" which has size and attributes identical to the Compool Block. A Task may copy the Compool Block into its Local Copy by a READ Statement, or copy the Local Copy into the Compool Block by a WRITE or TRIGGER statement. From the point of view of the Application Software, READs, WRITEs, and TRIGGERs occur instantaneously, so a Compool Block can never be read when it has been partially updated by a WRITE. If a Global Copy has been declared, then the task in which the Compool is declared Global Copy is allowed to access the Global Data Block directly, rather than using Executive Read and Write Requests into and out of local copies of Global data blocks. The Executive Read and Write Requests will not actually move the data if the requesting task has declared the Global Data Block as a GLOBAL'COPY rather than as a LOCAL'COPY. The GLOBAL'COPY provides for the same central control of table formats as the LOCAL'COPY does.

Compool Blocks are divided into three classes: Input, Output, and Intertask. Input Compool Blocks can only be accessed by Tasks in a READ statement. Their values are determined by RT's. Output Compool Blocks can only be accessed by Tasks in a WRITE or TRIGGER statement; their values are "received" only by RT's. Intertask Compool Blocks are used solely for communication between tasks.

Since a Compool Block may be accessed in more than one processor and also, possibly, in an RT, Compool Blocks may exist in multiple copies. Any processor in which a Compool Block is read has a Physical Copy of the Block; any RT which references the Block, or any processor which only WRITEs or TRIGGERs the Compool Block, is considered to have a Virtual Copy of the Block. To maintain consistency between the various copies of a Compool Block, the Executive must send Compool Update Messages across the Data Bus. Compool Blocks are further classified according to when these Update Messages are sent as: Synchronous, Asynchronous, and Critically Timed.

Synchronous Compool Blocks are updated from a single authoritative Copy, whether in a processor or an RT, at a specified rate and phase. All copies of an Asynchronous Compool Block are updated when any of those copies are changed, either by the hardware of an RT or by a WRITE statement within a processor. Critically Timed Compool Blocks are a special category used only for Output. They may only be TRIGGERed within a Task. A TRIGGER statement includes a "time to go". The Master Executive sends the Update to the appropriate RT at the specified time.

The various categories of Compool Blocks are shown in Table 3.1-2, along with the ways which they may be referenced in a Task.

The first word of each Physical Copy of a Compool Block is a "Minor Cycle Time Tag" which indicates the last time the Physical Copy was updated.

3.1.1.2.3.1.4 Events

Events are used for control communication between Tasks. An Event has two possible values: on and off. A Task may READ the value of an Event, may WAIT on an Event, and an Event may appear in the Event Condition Set of a Task.

There are two general classes of Events: Application Events and System Events. Application Events are set on and off explicitly by Tasks. System Events are set on and off by the Executive upon certain occurrences. The initial value of all events is off.

System Events are further classified as:

- o Task Activation Events,
- o Compool Update Events,
- o Minor Cycle Events.

Any Task may have an associated Task Activation Event. Such an Event is set on when the Task is Activated and set off when the Task returns to Inactive or Uninvoked state. The Activation Event associated with a Task must have the same name as the Task.

Any Compool Block may have an associated Compool Update Event. Such an Event is set on when the Compool Block is updated, either by a Task or an RT. The Update Event associated with a Compool Block must have the same name as the Compool Block.

Minor Cycle Events are set on by the Executive according to specified rates and phases. They may only be referenced in Event Condition Sets.

3.1.1.2.3.1.5 Time

The Application Software may interact with time in two ways: it may reference absolute time, or it may specify that certain occurrences should happen cyclically. Absolute time is measured in seconds from the initialization of the system. Cyclic time is maintained in terms of Minor Cycles and Major Frames.

A Minor Cycle is the shortest period of time at which a cyclic occurrence may be specified. A Major Frame is the longest period of time at which a cyclic occurrence may be specified. There are a fixed number of Minor Cycles to a Major Frame (currently 64), and each Major Frame has a fixed duration (currently one second). Every Minor Cycle is numbered in order of its occurrence within a Major Frame, starting with zero.

	SYNCHRONOUS	ASYNCHRONOUS	CRITICALLY TIMED
INPUT	May be READ in in many Tasks	May be READ in one Task	
OUTPUT	May be written in one Task.	May be written in many Tasks.	May be triggered in in many Tasks.
INTERTASK	May be written in one Task, read in many Tasks.	May be written in many Tasks, read in many Tasks.	

Table 3.1-2 Categories of Compool Blocks

Cyclic occurrences are specified by period and phase. Period is the number of Minor Cycles between successive occurrences; phase is the Minor Cycle number of the first occurrence within any Major Frame. Clearly, 0 phase period.

In practice, Minor Cycles will not always occur exactly when they theoretically should, partly because of the inherent latency of a federated system; partly because the Data Bus may be overloaded in any given Minor Cycle. However, the Executive guarantees that these errors are not cumulative; it will always generate the next Minor Cycle as close as possible to the theoretical time, regardless of when the previous Minor Cycle occurred.

With one exception, the Minor Cycle is the finest granularity of time knowable with the system. Thus, when a Task reads the absolute time, it receives the theoretical time of the last Minor Cycle. The sole exception to this rule is the Critically Timed Compool Block. When a Task TRIGGERS such a Compool Block, the Executive will attempt to send the Update Message to the RT at the precise time specified.

3.1.1.2.3.1.6 Real Time Pseudo-Declarations

Real Time Pseudo-Declarations are used to declare the real time entities referred to within a Task. There are four kinds of Real Time Pseudo-Declarations:

- o Task Declarations,
- o Event Declarations,
- o Compool Block Declarations,
- o Comsub Declarations.

Task Declarations are used to declare Tasks referred to in Real Time Pseudo-Statements. They create a reference to the Task Table A entry for the appropriate Task.

Event Declarations are used to declare Events referred to in Real Time Pseudo-Statements. They create a reference to the Event Table entry for the appropriate Event. If the Event is a Compool Update or Task Activation Event, it must be declared as such in this Declaration.

Compool Block Declarations are used to declare any Compool Blocks referenced in READ, WRITE, or TRIGGER statements. They do two things:

- o They create a reference to the Data Descriptor Block for the Compool Block,
- o They access the Compool within which the Compool Block is declared, and from it create a declaration for the Local Copy of the Compool Block.

A Compool Block Declaration must indicate whether a Compool Block is read, written updated (both read and written) or triggered within the Task.

Comsub Declarations are used to declare Comsubs called within the Task. They simply generate the appropriate REF PROC declaration.

3.1.1.2.3.1.7 Real Time Pseudo-Statements

The Applications Software requests the services of the Executive through Real Time Pseudo-Statements. There are 8 kinds of Real Time Pseudo-Statements:

- o Schedule Statements
- o Cancel Statements
- o Terminate Statements
- o Wait Statements
- o Signal Statements
- o Read Statements
- o Write Statements
- o Trigger Statements
- o EREAD
- o INVOKED
- o TIME

Real Time Pseudo-Statements compile as calls to Executive routines, passing the appropriate information as parameters.

Schedule Statements

Schedule Statements are used by one Task to Schedule another Task. A Schedule Statement includes the following information:

- o The name of the Scheduled Task,
- o The priority of the Scheduled Task,
- o The Latched Conditions (if any) in the Event Condition Set of the Task.
- o The Unlatched Conditions (if any) in the Event Condition Set of the Task.
- o The period and phase of a Minor Cycle Event (if any) in the Event Condition Set of the Task.

The Latched and Unlatched parts of the Condition Sets are defined by event expressions . The syntax for event expression is:

```
< event expression > ::= < condition > | < condition > AND < event expression >
< condition > ::= < event set > | NOT < event set >
< event set > ::= < event > | (< or set >)
< or set > ::= < event > | < event > OR < or set >
```

Each condition in this expression corresponds to a Condition in the Event Condition Set. The presence of a NOT indicates that the desired value is off; the absence indicates that the desired value is on. The Events named in the event set are the Events associated with the Condition. Note that although multiple Events associated with a single condition are combined with ORs, the actual value of the Condition is not necessarily the OR of the value of the Events. Thus, for instance, the Condition denoted by (A OR B) will be set off if Event A is set off, regardless of the value of Event B.

Cancel Statements

The Cancel Statement is used by one Task to put another Task into Uninvoked state. The Cancel Statement includes the name of the Task to be Cancelled. This Task must either be the Task within which the Statement is executed, or a son of that Task. If a son is cancelled, all the descendents of the son are also cancelled automatically. If a Task attempts to Cancel itself, it will not affect its own state, but will Cancel all of its descendents. If a Task specifies itself in a Cancel Statement, it must be declared in a Task Declaration within itself.

Terminate Statements

The Terminate Statement functions identically to the Cancel Statement, except that it de-Activates instead of de-Invoking Tasks. When the event condition set for the terminated task becomes true, the Task will become dispatchable.

Wait Statements

Wait Statements are used by Tasks to place themselves into Wait State pending certain occurrences. There are four kinds of Wait statements:

- o Absolute Time Waits,
- o Relative Time Waits,
- o Latched Waits,
- o Unlatched Waits.

An Absolute Time Wait places the Task into Wait state until a specified absolute time. If the specified time has already occurred, this statement is a No-Op.

A Relative Time Wait places the Task into Wait state for a specified period of time. If the specified period is non-positive, this statement is a No-Op.

A Latched Wait places the Task into Wait state until a specified Event reaches a specified "desired value". If the Event already has the desired value, this statement is a No-Op.

An Unlatched Wait places the Task into Wait state until the specified Event is changed to the specified value. This statement is never a No-Op.

Signal Statement

A Signal Statement sets a specified Event to a specified value.

Read Statement

A Read Statement copies the value of a specified Compool Block into the corresponding Local Copy. If the Compool Block is a Global Copy, then no data transfer occurs.

Write Statement

A Write Statement copies the corresponding Local Copy into the specified Compool Block. If the Compool Block is a Global Copy, then no data transfer occurs.

Trigger Statement

A Trigger Statement requests the Executive to send the Local Copy of the specified Compool Block to the appropriate RT in a specified time. The specified time must be between two Minor Cycles and one Major Frame from the time the Trigger Statement is executed.

EREAD

EREAD yields the value of the Event which has been passed as an argument. This Event must have been previously declared in an Event Declaration.

INVOKED

INVOKED is applied to a Task. This function yields the value TRUE if the task is Invoked, FALSE if it is not.

TIME

TIME returns the absolute time as a 31 bit signed integer signifying the elapsed time since system initialization.

3.1.1.2.3.1.8 Master Executive Interfaces

Master Sequencer Interface

At the end of Master Initialization or Master Re-Initialization, the Master Executive schedules the Master Sequencer task. This task then schedules the other Applications Tasks.

Application System Error Interface

Applications Software can detect error conditions and communicate the conditions to the Subsystem Status Monitor. The primary source of errors will be the Equip functions. These functions will determine any errant status with equipment and sensors and communicate the errors to the Subsystem Status Monitor.

The Subsystem Status Monitor records the error and gathers error statistics. If the last error was within too short a time or there were too many such errors, the Subsystem Status Monitor invokes the Configurator. The Configurator will cancel errant functions if appropriate. If the errors are of such a magnitude to warrant reconfiguration, the Configurator can invoke the Reconfiguration function via the IO device function.

3.1.2 Applications Software Architecture

3.1.2.1 Software Structure

The Applications Software is organized into:

- o System Control Modules
- o Operational Sequencers (OPSs)
- o Specialist Functions (SPECS)
- o Display Processes (DISPs)
- o Equipment Processes (EQUIPs)

as shown in Figure 3.1-12 . A brief functional description of each is given below.

System Control Modules

The four System Control Modules (Master Sequencer, Request Processor, Configurator, Subsystem Status Monitor) are responsible for initializing and controlling the Applications Software.

The Master Sequencer, the first Application's Software task activated by the Executive Software, performs data initialization and schedules the other System Control Modules. Its control interfaces are shown in Figure 3.1-13.

The Request Processor receives and interprets control panel input requests. It will activate appropriate software tasks to handle legal requests; illegal requests are ignored. Request Processor control interfaces are shown in Figure 3.1-14.

The Configurator controls the operation of application tasks. It is activated whenever a new Operational Sequencer or Brute Force Specialist Function is to be initiated, or when a severe equipment health problem is detected. Configurator control interfaces are shown in Figure 3.1-15.

The Subsystem Status Monitor maintains status of the avionics subsystems. If a subsystem has failed or is generating degraded data, it determines the type and severity of the problem, and activates the configurator if the severity is significantly high. The Subsystem Status Monitor control interface is shown in Figure 3.1-16.

Operational Sequencers

Operational Sequencers are responsible for the control of a particular mission phase. They are activated by the Configurator as a result of master mode selections, and by the current Handler Specialist Function whenever a new display page is requested. Operational Sequencer interface control is shown in Figure 3.1-17.

Specialist Functions

Specialist Functions carry out computational and control functions required by an OPS or by the crew. The four categories are Computational, Brute Force, Tailored Mode, and Handler.




FIGURE 3.1-12 APPLICATIONS SOFTWARE ORGANIZATION




FIGURE 3.1-13 MASTER SEQUENCER INTERFACE




FIGURE 3.1-14 REQUEST PROCESSOR INTERFACE




FIGURE 3.1-15 CONFIGURATOR INTERFACE




FIGURE 3.1-16 SUBSYSTEM STATUS MONITOR INTERFACE




FIGURE 3.1-17 OPERATIONAL SEQUENCER INTERFACE

Computational Specialist Functions carry out cyclic processing and are usually active throughout most of the mission (e.g., navigation). Computational SPEC interface control is shown in Figure 3.1-18.

Brute Force Specialist Functions allow the pilot to initiate, sequence, and terminate mission operations that are not automatically available in the current OPS (e.g., sensor moding). They are accessed via the top keys on the IMK. Brute Force SPEC interface control is shown in Figure 3.1-19.

Tailored Mode Specialist Functions primarily perform those functions necessary to process selections by the crew via control devices (IMK, MFDC, HCU, CCA). They are activated by the current Handler Specialist Function to process IMK/DEK inputs, and by the Configurator to process other control requests. Tailored Mode SPEC interface control is shown in Figure 3.1-20.

Handler Specialist Functions perform the control processing involved with display pages. There is a Handler SPEC for each device: IMK, MPD. Handler SPEC interface control is shown in Figure 3.1-21.

Display Processes

Display Processes control cockpit displays. They obtain data generated by various Application Software tasks, perform required scaling/formatting, and output the resulting data messages to compools for subsequent transmission to display hardware. Interface control for Display Processes is shown in Figure 3.1-22.

Equipment Processes

Equipment Processes represent the Applications Software interface with IDAMST sensors.

Input Equipment Processes receive data generated by the sensors, perform required selection scaling, etc., and output the resulting parameters to a compool for use by other Applications Software tasks. They also monitor equipment status and initiate action when failure or degraded data is detected.

Output Equipment Processes receive data generated by various Application Software tasks, format corresponding sensor data/control messages, and output these messages to a compool for subsequent transfer to the sensor.

Interface control for Equipment Processes is shown in Figure 3.1-23.




FIGURE 3.1-18 COMPUTATIONAL SPEC INTERFACE




FIGURE 3.1-19 BRUTE FORCE INTERFACE




FIGURE 3.1-20 TAILORED MODE SPEC INTERFACE




FIGURE 3.1-21 HANDLER INTERFACE




FIGURE 3.1-22 DISPLAY PROCESSES INTERFACE




FIGURE 3.1-23 EQUIPMENT PROCESSES INTERFACE

3.1.2.2 Software Relationships

This section describes the control and data relationships of the various software components comprising the Application Software.

Figure 3.1.2-12 shows the primary control/data interfaces for the Application Software. Appearing below is a more detailed explanation of each control interface:

1. Cyclic activation via Executive initiated by the Configurator. Activation of cyclic mode-dependent Computational Specialist Functions and Display Processes is initiated by the Configurator during transition from one mission mode to another.

The Computational Specialist Functions access data residing in a Compool for their calculations, and store the results in another software compool.

2. Cyclic activation initiated and cancelled by the Configurator. Activation of cyclic Equipment Processes, Air Data Display Processes, and certain Computational Specialist Functions is initiated by the Configurator during transition from the INITIALIZE mode.

Each input Equipment Process will access data moved by the Executive to a Compool, check the device status word, check for validity/reasonableness, generate substitute data (if necessary), convert/format the data, and store the result in an Applications Software Compool. If the device status has changed or if the device is generating incorrect/degraded data, the Subsystem Status Monitor is notified.

Each output Equipment Process will access data residing in an Applications Software Compool, scale/format the data, and store the result in a Compool for subsequent output.

Each output Display Process will access data residing in an Applications Software Compool, scale/format the data, and store the resulting parameter in a Compool for subsequent output.

3. Cyclic activation by the Executive, initiated when the Request Processor is scheduled by the Master Sequencer.

The Request Processor will access control panel data residing in a Compool, check the panel status word, decode/interpret any crew input, and store the result in an Applications Software Compool. It will then activate the Subsystem Status Monitor (if panel status has changed) or the IMK Handler Specialist Function (if IMK side key input) or the Configurator (other input).




FIGURE 3.1-24 APPLICATIONS SOFTWARE RELATIONSHIPS

4. Synchronous activation by the Executive, initiated by the Handler Specialist Function; this cyclic activation is initiated when a side key select is received which requires DEK input, and is terminated when an Enter Key is recognized.

The DEK input Equipment Process will access data residing in a Compool, check device status word, and check data for Enter Key indication. If device status has changed, the Subsystem Status Monitor is notified. If an Enter Key is recognized, the input buffer is converted and stored in an Applications Software Compool and the Handler Specialist Function is activated.

5. Demand activation by Tailored Mode Specialist Functions.

Each output Equipment Process will access data residing in an Applications Software Compool, scale/format the data, and store the result in a Compool for subsequent output to the device.

6. Demand activation by Tailored Mode Specialist Functions.

Each output Display Process will access data residing in an Applications Software Compool, scale/format the data, and store the resulting parameter in a Compool for subsequent output.

7. Demand activation by DEK input Equipment Process indicating receipt of an Enter Key.

The Handler Specialist Function will access data residing in an Applications Software Compool pertaining to the IMK activity leading up to the DEK input request, and activate the appropriate Tailored Mode Specialist Function for action. A Display Process will be activated to note on the IMK that required DEK input is complete.

8. Demand activation by the Request Processor indicating receipt of an IMK side key.

The Handler Specialist Function will access data residing in a Compool, and if the indicated side key requires DEK input, cyclic activation of the DEK input Equipment Process will be initiated (via request to Executive Software), and a Display Process will be activated to note on the IMK that input is required.

If the side key requires a new IMK CRT page to be displayed, the current Brute Force Specialist Function, or if none, the current Operational Sequence, is activated to accomplish this.

IMK key status/history and other status pertaining to the IMK Handler Specialist Function is stored in an Applications Software Compool.

9. Demand activation by the Handler Specialist Function indicating that processing of crew input selections (IMK side key and/or DEK input) is required.

The tailored Mode Specialist Function will access data residing in an Applications Software Compool (both input and status data), determine validity, perform processing, and store results in an Applications Software Compool. The proper Equipment Process will be activated to complete the data transfer to the device.

Further, if the data requires an update of a current display, a Display Process is activated.

10. Demand activation by the Handler Specialist Function requesting a new CRT page.

The Operational Sequencer or Brute Force Specialist Function will access data residing in an Applications Software Compool and display the new CRT page.

11. Demand activation by the Handler Specialist Function to display parameter values or to indicate DEK activity.

The Display Process will access data residing in an Applications Software Compool, scale/format the data if necessary, and store the result in an Executive Software Compool for subsequent output.

12. Demand activation by the Brute Force Specialist Function or Operational Sequencer to display the new display page.

The Display Process will access data residing in an Applications Software Compool, scale/format the data if necessary, and store the result in an Executive Software Compool for subsequent output.

13. Demand activation by the Request Processor because of a control panel input.

The Configurator will access the input data residing in an Applications Software Compool and activate the appropriate Tailored Mode Specialist Function, Brute Force Specialist Function, or Operational Sequencer to perform the necessary processing.

14. Demand activation by the Configurator because of control panel input.

The Tailored Mode Specialist Function corresponding to the type of input (HCU, CCA, MFDC) will access data residing in an Applications Software Compool, and perform the processing required to satisfy the request. A Display Process will be activated to control panel lamp configuration.

The Operational Sequencer associated with the MMK selection will perform the necessary processing and control to establish the new mission mode. Display Processes will be activated to control new IMK/MPD pages, as well as panel lamp configuration.

The Brute Force Specialist Function associated with the IMK top key will perform the necessary processing to satisfy the request. The request may be to cancel the current Brute Force Specialist Function, change to another one, or establish a new one. Display Processes will be activated to control CRT pages on the IMK(s) and to control the top key lamp configuration.

15. Demand activation by input Equipment Processes or by the Request Processor.

The Subsystem Status Monitor will access data residing in an Applications Software Compool and store, if appropriate, in an Applications Software Compool to maintain the equipment status. If current status indicates a failure requiring a different software configuration, the configurator is activated.

16. Demand activation by the Subsystem Status Monitor indicating an equipment health problem.

The Configurator will access data residing in an Applications Software Compool and determine required action. The Executive Software will be notified if the equipment failure is severe. Software re-configuration because of less severe failures will be handled by the Configurator.

17. One-time-only activation by the Executive to start the Applications Software.

The Master Sequencer will perform required initialization processing, and activate the Configurator to mode the Applications Software.

18. One-time-only activation by the Master Sequencer for Applications Software startup.

The Configurator will perform any required processing, and activate an Operational Processor to put the Application Software into an INITIALIZE mission mode.

19. Demand activation by the IMK Handler Specialist Function indicating the selection of a master mode from the MMK backup pages on the IMK.

Request Processor will process the input as it would MMK pushbutton input.

20. The Configurator will notify an Executive task for failures it cannot handle.

21. Demand activation by an EQUIP which determines a situation requiring a "WARN" action (e.g., CCA Shaker, Low Speed Warning Light, etc.).
22. Demand activation by the Executive when a device failure is detected.
23. Demand activation by Handler SPECS for IMK or MPD functions relating to DEK input, MPD checklist activity, new display pages.

This page intentionally left blank.

3.2 Detailed Functional Requirements

This section specifies the detailed functional requirements for the Applications Software.

The software components identified to satisfy these requirements are shown in Figure 3.2-1.

3.2.1 System Control Modules

3.2.1.1 Master Sequencer

The Master Sequencer performs data initialization, and initiates the scheduling and execution of the other System Control Modules.

3.2.1.1.1 Inputs

Input shall be TBD data required for initialization of the Applications Software.

3.2.1.1.2 Processing

Upon activation by the Executive, the Master Sequencer shall

- o initialize mission data and carry out other initialization tasks for the particular software configuration
- o schedule the request processor, configurator, and sub-system status monitor tasks
- o activate the configurator

3.2.1.1.3 Outputs

None.

3.2.1.2 Request Processor

The Request Processor receives and interprets control panel input requests. It is activated 8 times per second.

3.2.1.2.1 Inputs

Input shall consist of

- o MMK Status, Pushbutton # (2 words)
- o IMK Status, Top/Side Key # (2 words)
- o MFDC Pushbutton # (1 word)
- o CCA Status, Pushbutton # (2 words)
- o HCU Status, Pushbutton # (2 words)
- o MMK Backup Mode Select (1 word)




FIGURE 3.2-1 APPLICATION SOFTWARE COMPONENTS

3.2.1.2.2 Processing

The Request Processor shall access the input panel data to determine if any data has changed. If no change has occurred since the last activation, the Request Processor shall terminate.

If the input data from an IMK shows a side key select, the IMK Handler Specialist Function shall be activated; the Configurator shall be activated for IMK top key selections.

Valid pushbutton input from other source devices shall also cause the Configurator to be activated. The following pushbutton input shall be ignored:

- o non-supported pushbuttons (spares)
- o MMK input which would result in an out-of-sequence Master Mode situation (TBD)
- o MMK input identical to current MMK setting (i.e., repeated selection of same pushbutton)

The Request Processor is activated by the IMK Handler Specialist Function whenever the Master Mode backup capability is used. The processing shall be the same as the MMK input.

The Request Processor shall activate the Subsystem Status Monitor whenever the panel mode/health status changes.

3.2.1.2.3 Outputs

None.

3.2.1.3 Configurator

The Configurator controls the moding/operation of the application tasks.

3.2.1.3.1 Inputs

Input shall consist of:

- o control panel input-pushbutton numbers (4 words)
- o equipment failure message (2 words)

3.2.1.3.2 Processing

Upon activation by the Master Sequencer, the Configurator shall schedule and activate the INITIALIZE Operational Sequencer.

When activated by the Request Processor because of MMK select, the Configurator shall

- o cancel the current Operational Sequencer
- o set up the task configuration necessary for the new mode
- o activate the new Operational Sequencer

When activated by the Request Processor because of an HCU, CCA, or MFDC request, the CONFIG shall activate the appropriate Tailored Mode Specialist Function.

When activated by the Request Processor because of an IMK top key select, the CONFIG shall determine whether the new key select is identical to the previous one. If the new key select is different, the Configurator shall

- o cancel the current Brute Force Specialist Function
- o set up the necessary task configuration
- o activate the new Brute Force Specialist Function

If the key select is the same as the previous one (i.e., the IMK top key selected by the crew was backlighted green), the Configurator shall

- o cancel the corresponding Brute Force Specialist Function
- o set up the task configuration necessary for full resumption of the Operational Sequencer corresponding to the current Master Mode
- o activate the Operational Sequencer to initialize IMK CRT displays

When the Configurator is notified by the Sub-System Status Monitor of an equipment health problem, the Configurator shall inform the crew via MPD and either 1) re-configure to a backup or perhaps degraded mode for severe failures or 2) request the crew to take action. The Configurator shall signal the Master Executive for failures that it cannot properly handle.

3.2.1.3.3 Outputs

Output shall consist of

- o Equipment failure message ID (1 word), MPD
- o Equipment failure notification (1 word), EXEC

3.2.1.4 Subsystem Status Monitor

The Subsystem Status Monitor maintains status of the avionics subsystems, and monitors changes in status.

3.2.1.4.1 Inputs

Input shall consist of

- o Control panel status (4 words)
- o Device/sensor status (1 word)

3.2.1.4.2 Processing

The Subsystem Status Monitor is activated by the Request Processor upon a control panel failure or status change, or by an Equipment Process whenever a sensor has failed or is producing invalid/degraded data.

The Subsystem Status Monitor shall store the status to maintain error history and statistics. If an analysis of the data indicates a critical error, the Configurator shall be activated to perform error recovery.

3.2.1.4.3 Outputs

Output shall be a one word message to the Configurator indicating the change in status of the subsystem.

- o Status change message (n words)

3.2.2 Operational Sequencers

An Operational Sequencer (OPS) is a task responsible for the control of a particular mission phase, as determined by "Master Mode". It is scheduled, activated, and cancelled by the Configurator, as a result of crew Master Mode selections.

Operational Sequencers have been identified for the following IDAMST mission modes.

- | | |
|--------------|---------------|
| o Initialize | o Go-Around |
| o Start | o Air Refuel |
| o Takeoff | o TF/TA |
| o Enroute | o Land |
| o Air Drop | o Shutdown |
| o Lapes | o Ground Test |

3.2.2.1 Inputs

Input shall consist of

- o Next Display ID (1 word)

3.2.2.2 Processing

OPS control processing begins when the pilot selects a mission mode by depressing an MMK pushbutton or by depressing an MMK pushbutton or by depressing an IMK side key associated with the master mode backup display page. Processing continues until another master mode is selected or until the OPS is interrupted (suspended) by selecting a Brute Force Spec.

Initial processing common to all Operational Sequencers upon activation by the Configurator because of MMK input shall be

- o Commanding MMK light configuration to correspond to the Master Mode selection
- o Commanding IMK top key light configuration to OFF
- o Initiating tasks to generate those HUD, HSD, MPD displays defined for the master mode
- o Setting a DISP flag to change Master Mode in the MPDG
- o Cancelling the IMK Status DISP if active
- o Displaying a control page on each IMK CRT (this page contains the top level control capability available for the Master Mode)
- o Activating the IMK Status DISP if necessary

Further, OPS processing depends on subsequent IMK side-key activation. The OPS shall display other (lower level) control pages as directed by the crew via side key selection.

When the OPS is notified by the IMK Handler to put up another display page (because of an "advance page" indicator or side key #), the OPS shall

- o Cancel the IMK Status DISP if necessary
- o Display the requested page by activating the IMK Fixed Test DISP
- o Activate the IMK Status DISP if necessary

When a Brute Force Specialist Function is cancelled, the OPS is activated by the Configurator and shall

- o Cancel the IMK Status DISP if active
- o Display the top-level control page on the IMK CRT
- o Activate the IMK Status DISP if necessary
- o Set IMK top key lamps OFF

3.2.2.3 Outputs

Output shall consist of

- o MMK lamp on/off message (1 word)
- o IMK lamp off message (1 word)

3.2.3 Specialist Functions

3.2.3.1 Brute Force Specialist Functions

Brute Force Specialist Functions allow the crew to perform certain mission operations not automatically available to the Current OPS processing. These functions are scheduled, activated, and cancelled by the Configurator as a result of IMK top key selection by the crew.

Brute Force Specialist Functions have been identified for the following IDAMST functions:

- o Navigation
- o Communications
- o Sensors
- o Systems
- o Library
- o Checklist
- o Payload
- o DITS

3.2.3.1.1 Inputs

Input to any Brute Force Specialist Function shall consist of

- o Next display ID (1 word)

3.2.3.1.2 Processing

Brute Force Specialist Function processing begins after being activated by the Configurator as a result of an IMK top key selection. Processing continues until there is another top key selection or until there is a Master Mode change. Initial processing common to all Brute Force Specialist Functions upon activation by the Configurator shall consist of

- o Commanding IMK top key lamp configuration
- o Cancelling the IMK Status DISP if active
- o Initiating tasks to generate any HUD, HSD, MPD displays defined for the particular Brute Force SPEC
- o Displaying a control page on the requesting IMK CRT and activating the IMK Status DISP if necessary; this page contains the top level capability available for the function (i.e., Communication).

Further, Brute Force SPEC processing depends on subsequent IMK side-key activation. The Brute Force SPEC shall display other (lower level) control pages as directed by the crew via side key selection.

When the Brute Force SPEC is notified by the IMK Handler to put up another display page (because of an "Advance Page" indicator or side key #), it shall

- o Cancel the IMK Status DISP if active
- o Display the required page on the IMK CRT
- o Activate the IMK Status DISP if necessary

3.2.3.1.3 Outputs

Output shall consist of

- o IMK lamp control (1 word)

3.2.3.2 Computational Specialist Functions

Computational Specialist Functions carry out cyclic processing, and are either active throughout the mission (e.g., navigation) or throughout a particular mission mode (e.g., CARP).

Computational Specialist Functions have been identified for the following IDAMST functions:

- o navigation
- o steering
- o wind calculation
- o weights and balances

3.2.3.2.1 Navigation Computational Specialist Function

The Navigation SPEC is responsible for keeping track of the aircraft state, using input data from various sensor sources and from the crew. It is activated by the Configurator upon a Master Mode selection by the crew.

The Applications Software navigation function consists of the following sub-functions:

- o control
- o navigation modes:
 - auto
 - INS
 - OMEGA
- o manual update (position)
- o flight director
- o OMEGA
- o magnetic heading
- o CARP
- o rendezvous
- o go-around

3.2.3.2.1.1 Control Subfunction

This subfunction provides overall control of aircraft navigation computation. It is activated four times a second throughout most of the flight.

3.2.3.2.1.1.1 Inputs

Input shall consist of

- o status (n words)
- o device moding (n words)
- o master mode (1 word)
- o navigation mode (1 word)

3.2.3.2.1.1.2 Processing

This subfunction shall control the navigation computation procedure by de-

termining from Master Mode, device status, device moding, etc., the appropriate operational sequence.

3.2.3.2.1.1.3 Outputs

None.

3.2.3.2.1.2 Auto Mode

The Auto Mode subfunction provides for automatic (computer controlled) integrated navigation. The following functions are included:

- o flight planning
- o subsystem management
- o optimum position calculation/update
- o horizontal, vertical guidance calculation
- o performance monitoring
- o map display parameter update
- o augmented ILS

3.2.3.2.1.2.1 Inputs

Inputs for the various Auto mode subfunctions shall consist of .

- o navigation subsystem data, as applicable (n words)
 - LF ADF - bearing
 - UHF ADF - bearing
 - VOR/ILS - bearing, loc/GS deviation
 - Radar Alt - altitude
 - OMEGA - position, velocity
 - Compass - heading
 - TACAN - bearing, distance
 - INS - position, velocity, attitude
 - SKE/ZM - range, bearing
 - Flight Controls - pitch, roll, turn rate, altitude, airspeed, TAS, altitude rate, vertical speed
- o IMK input data (n words)
 - Initialization data
 - Flight plan modifications
 - Subsystem control
 - Position update
- o HCU position update (n words)
- o Marker beacon data (n words)
- o Device status/moding (n words)

3.2.3.2.1.2.2 Processing

Auto navigation processing shall include the following capability:

Flight Planning

- o organize/store appropriate Standard Instrument Departure (SID) and flight plan
- o execute/modify the flight plan as directed

Subsystem Management

- o perform initialization
- o tune radios from flight plan data
- o verify subsystem performance

Optimum Position Calculation/Update

- o combine various NAVAID data to derive optimum position
- o auto update
- o update optimum position with manual input data

Horizontal, Vertical Guidance Calculation

- o compare present position with flight plan to derive guidance information

Performance Monitoring

- o establish and monitor subsystem performance criteria
- o estimate navigation accuracy and compare with mission requirements

Map Display Parameter Update

- o update present position and map display requirements

Augmented ILS (Land Mode)

- o synthesize and smooth ILS data
- o computationally construct approach NAVAID

3.2.3.2.1.2.3 Outputs

Output shall consist of

- o flight instrument display parameters

3.2.3.2.1.3 INS Mode

This subfunction provides navigation capability using only input from INS. Updates can be performed manually.

It is activated by the Control subfunction four times per second whenever the INS mode has been selected.

3.2.3.2.1.3.1 Inputs

Input shall consist of

- o INS data - position, velocity, acceleration (n words)
- o flight plan information (n words)
- o radar updates (n words)
- o visual updates (n words)

3.2.3.2.1.3.2 Processing

Subfunction processing shall provide capability to

- o maintain INS position
- o execute/maintain flight plan and calculate INS guidance outputs
- o INS manual update, including reasonableness tests

3.2.3.2.1.3.3 Outputs

Output shall be inertial position and velocity from which INS guidance signals are derived and are available for display:

- o position and velocity (n words)
- o guidance parameters (n words)

3.2.3.2.1.4 OMEGA Mode

This subfunction provides navigation capability using only input from OMEGA.

It is activated four times per second by the Control subfunction whenever the OMEGA mode has been selected.

3.2.3.2.1.4.1 Inputs

Input shall consist of

- o OMEGA position, velocity (n words)
- o TAS (1 word)
- o heading (1 word)
- o flight plan information (n words)

3.2.3.2.1.4.2 Processing

Subfunction processing shall provide capability to

- o maintain OMEGA position
- o execute/maintain flight plan and calculate OMEGA guidance outputs
- o perform OMEGA smoothing with TAS and heading

3.2.3.2.1.4.3 Outputs

Output shall be OMEGA position and velocity from which OMEGA guidance

signals are derived and are available for display:

- o position, velocity (n words)
- o guidance parameters (n words)

3.2.3.2.1.5 Manual Position Update

This subfunction generates update information from HCU, SKE/ZM, or IMK inputs.

It is activated by the Control subfunction whenever an update is requested.

3.2.3.2.1.5.1 Inputs

Input shall consist of present position

- o latitude, longitude (2 words)

3.2.3.2.1.5.2 Processing

This subfunction shall update position with the input data.

3.2.3.2.1.5.3 Outputs

None.

3.2.3.2.1.6 Flight Director

This subfunction generates flight director commands compatible with HUD to provide guidance to maintain designated flight path.

It is activated by the Control subfunction four times a second throughout the mission if the flight director is functionally switched "on."

3.2.3.2.1.6.1 Inputs

Input shall consist of navigation subsystem data

- o navigation data (n words)

3.2.3.2.1.6.2 Processing

This subfunction shall calculate flight director commands compatible with the HUD.

3.2.3.2.1.6.3 Outputs

Output shall consist of

- o pitch command (1 word)
- o roll command (1 word)
- o speed command (1 word)

3.2.3.2.1.7 OMEGA

The OMEGA subfunction converts OMEGA RF input data to airplane position and velocity parameters. It is activated eight times per second by the Control subfunction if the data is used in the navigation calculations, as determined by current navigation moding.

3.2.3.2.1.7.1 Inputs

Input shall consist of

- o three channels RF (n words)
- o navigation mode (1 word)

3.2.3.2.1.7.2 Processing

This subfunction shall convert the input RF input data to OMEGA position and velocity.

3.2.3.2.1.7.3 Outputs

Output shall consist of

- o position, velocity (n words)

3.2.3.2.1.8 Magnetic Heading

This subfunction calculates magnetic heading.

It is activated four times per second throughout the flight by the Control subfunction.

3.2.3.2.1.8.1 Inputs

Input shall consist of

- o present position (n words)
- o stabilized heading (1 word)
- o stored magnetic variation (n words)

3.2.3.2.1.8.2 Processing

This subfunction shall compute magnetic heading for use in referencing radio navigation aids and displays.

3.2.3.2.1.8.3 Outputs

Output shall consist of

- o magnetic heading (1 word)

3.2.3.2.1.9 CARP

The CARP subfunction calculates the air release point for delivering cargo to a ground target.

It is activated four times per second whenever the AIR DROP Master Mode has been selected.

3.2.3.2.1.9.1 Inputs

Input shall consist of

- o ground target-latitude, longitude, altitude (3 words)
- o cargo type (n words)
- o cargo weight (n words)
- o wind (2 words)
- o relative fix-range, bearing (2 words)
- o aircraft parameters (n words)

3.2.3.2.1.9.2 Processing

CARP shall perform ballistic calculations to derive guidance and display parameters pertaining to a specified airplane-cargo-target situation.

Additionally, CARP shall perform CCIP calculations for display purposes as an aid to pilot when selecting drop point.

3.2.3.2.1.9.3 Outputs

Output shall consist of

- o guidance data (n words)
- o display parameters (n words)

3.2.3.2.1.10 Rendezvous

The Rendezvous subfunction computes guidance and steering parameters to enable rendezvous with other aircraft.

It is activated four times per second whenever the AIR REFUEL Master Mode is in effect.

3.2.3.2.1.10.1 Inputs

Input shall consist of

- o LR radar cursor position - range, bearing (2 words)
- o UHF ADF - bearing (1 word)
- o TACAN - range, bearing (2 words)
- o IMK - heading, position, air speed, etc. (n words)

3.2.3.2.1.10.2 Processing

This subfunction shall determine the availability/applicability of navigation data sources. For limited data, it shall perform necessary processing to obtain display information for manual steering.

When sufficient data is available, the subfunction shall:

- o calculate target position and associated display parameters
- o perform guidance calculation for intercepts and output flight control system and flight director steering data

3.2.3.2.1.10.3 Outputs

Output shall consist of target data and steering commands:

- o target (n words)
- o steering (n words)

3.2.3.2.1.11 Go-Around

The Go-Around subfunction provides information which enables the pilot to perform a go-around during a missed approach. The missed approach parameters are pre-selected prior to the approach.

This subfunction is activated whenever the GO-AROUND Master Mode is in effect.

3.2.3.2.1.11.1 Inputs

Input shall consist of the missed approach parameters:

- o heading set (1 word)
- o altitude set (1 word)
- o course set (1 word)
- o minimum climb gradient (1 word)
- o course-to-fix (1 word)

3.2.3.2.1.11.2 Processing

Processing shall consist of incorporating the pre-selected, missed approach parameters into the navigation-guidance calculations. Parameters subsequently computed for display shall reflect this change in mode.

3.2.3.2.1.11.3 Outputs

Output shall consist of the selected parameter(s) being stored in a Compool:

- o parameters (n words)

3.2.3.2.2 Steering Computational Specialist Function

The Steering function provides guidance signals to the flight control system. It is activated 16 times per second throughout the flight.

3.2.3.2.2.1 Inputs

Input shall consist of pertinent navigation data

- o navigation data (n words)

3.2.3.2.2.2 Processing

The processing consists of calculating steering signals compatible with the flight control system.

3.2.3.2.2.3 Outputs

Output shall consist of

- o pitch steer (1 word)
- o roll steer (1 word)
- o speed command (1 word)

3.2.3.2.3 Wind Computational Specialist Function

The Wind Computational SPEC calculates wind velocities, used in air drop algorithms and various displays. It is activated eight times per second throughout most of the flight.

3.2.3.2.3.1 Inputs

Inputs shall consist of

- o true airspeed (1 word)
- o aircraft velocity components (2 words)
- o heading (1 word)

3.2.3.2.3.2 Processing

The Wind SPEC shall calculate North and East wind velocity components.

3.2.3.2.3.3 Outputs

Output shall consist of

- o North wind velocity component (1 word)
- o West wind velocity component (1 word)

3.2.3.2.4 Weights and Balances Computational Specialist Function

This SPEC calculates weight and balance information for display purposes. It is activated four times per second throughout the flight.

3.2.3.2.4.1 Inputs

Input shall consist of

- o aircraft weight (n words)
- o cargo data (n words)
- o fuel (n words)
- o etc.

3.2.3.2.4.2 Processing

Current aircraft weight and center of gravity shall be calculated based on fuel, fuel distribution, cargo data, etc.

3.2.3.2.4.3 Outputs

Output shall consist of

- o airplane weight (1 word)
- o center of gravity (1 word)

3.2.3.3 Tailored Mode Specialist Functions

Tailored Mode Specialist Functions perform those functions necessary to process crew control requests via IMK (primarily), MFDC, CCA, and HCU. They are activated by the current Handler Specialist Function to process IMK/DEK input and by the Configurator to process other control requests.

The following paragraphs describe identified IMK, MFDC, CCA, and HCU related Tailored Mode SPECS. Complete definition of LIBRARY, CHECKLIST, PAYLOAD, and DITS IMK control functions will result in the identification of additional Tailored Mode SPECS.

3.2.3.3.1 IMK Tailored Mode Specialist Functions

IMK Tailored Mode SPECS are activated by the current Handler SPEC following the receipt of input (either DEK or IMK side key) requiring processing.

IMK Tailored Mode Specialist Functions have been identified for the following IDAMST functions:

- o INS control
- o OMEGA control
- o ILS control
- o radar altimeter control
- o TACAN control
- o ADF control
- o navigation data entry
- o navigation data display
- o manual navigation moding
- o flight director control
- o avionics on/off control
- o CCA control
- o UHF-AM control
- o VHF-AM control
- o VHF-FM control
- o HF/SSB control
- o LR radar control
- o compass control
- o SKE control
- o counter measures control
- o status monitor and control
- o airdrop data entry
- o MFDC control
- o HCU control

The UHF-AM Tailored Mode SPEC, considered representative of the processing performed by IMK Tailored Mode SPECS, is described below. This SPEC processes requests for UHF-AM control, input via IMK. An example of the IMK software function using this SPEC is shown in Figure 3.2-2.




FIGURE 3.2-2 IMK(UHF-AM) SOFTWARE FUNCTION

3.2.3.3.1.1 Inputs

Input shall consist of IMK side key history and, if applicable, a DEK input buffer:

- o present and previous IMK side keys (2 words)
- o DEK input buffer (n words)

Additionally, certain Tailored Mode SPECS shall need status data and/or other data for its processing. The UHF-AM Tailored Mode SPEC, for example, shall require a channel versus frequency table for certain processing.

3.2.3.3.1.2 Processing

The last side key selected shall determine the type of processing required. For the UHF-AM Tailored Mode SPEC, the side keys represent the following control:

1. off
2. T/R
3. T/R+G
4. ADF
5. Guard Xmit
6. channel select
7. frequency select
8. channel preset
9. squelch disable
10. volume

The previous side key shall determine the particular radio to be referenced. For the UHF-AM Tailored Mode SPEC, they represent:

1. UHF-AM #1
6. UHF-AM #2

Processing for side key numbers 1, 2, 3, 5, 9 shall consist of activating the UHF-AM EQUIP to send the proper control message.

Side key number 4 (ADF) select shall cause the status of the normal ADF capability to be checked. If normal ADF is operational, the control request shall be rejected. Otherwise, the UHF-AM EQUIP shall be activated to send the ADF mode control message.

Side key numbers 6, 7, 8, 10 have associated DEK input. The DEK input buffer shall be decoded with respect to the specific side key and checked. If invalid (e.g., out-of-range) the control request shall be rejected. If valid, processing shall consist of:

- o Side key 6 (channel select) - The frequency corresponding to the selected channel is obtained from a frequency versus channel table residing in a Compool. The UHF-AM EQUIP is then requested to send this frequency to the radio.

- o Side key 7 (frequency select) - The UHF-AM EQUIP is requested to send the input frequency to the radio.
- o Side key 8 (channel preset) - DEK input for this side key consists of channel number and frequency. The Tailored Mode SPEC replaces the frequency value currently tabled versus channel number with the input frequency. Side key 8 results only in a Compool update; the UHF-AM EQUIP is not referenced.
- o Side key 10 (volume) - The UHF-AM EQUIP is activated to send the input volume to the radio.

Upon receipt of valid input, the IMK symbol (displayed to indicate that DEK input was necessary) shall be removed by activating the DEK Mark DISP.

3.2.3.3.1.3 Outputs

Output shall be the desired control message to the EQUIP and/or Compool updates:

- o EQUIP control (1 word)
- o update data (n words)

3.2.3.3.2 MFDC Tailored Mode Specialist Function

The MFDC Tailored Mode SPEC provides the logic necessary to control MFDC pushbutton input. It is activated by the configurator when an MPD/HSD pushbutton is pressed. Figure 3.2-3 shows overall MFDC software function.

3.2.3.3.2.1 Inputs

Input shall consist of:

- o pushbutton status, each device (5 words)
- o current pushbutton select (1 word)

3.2.3.3.2.2 Processing

The MFDC Tailored Mode SPEC shall determine whether the input is legal and, if so, implement the desired display control.

The DSMU EQUIP shall be activated if display switching is requested (e.g., switching HSD #1 display to the MPD #1 device).

The HSD DISP shall be activated if display revision is requested (e.g., HSD scaling).

The MDSC EQUIP shall be activated if a video display is requested (e.g., radar).

The LIGHTS DISP shall be activated to command the lamp configuration corresponding to the pushbutton status (as updated with new one).

If the pushbutton request is illegal (TBD) or if it cannot be satisfied




FIGURE 3.2-3 MFDC SOFTWARE FUNCTION

(e.g., radar turned off), an appropriate message shall be output to MPD #3.

3.2.3.3.2.3 Outputs

Output shall be the following control messages to be acted on by an EQUIP:

- o display switching (1 word)
- o display scaling (1 word)
- o radar/SKE/ECM display request (1 word)
- o MPD messages ID (1 word)

3.2.3.3.3 CCA Tailored Mode Specialist Function

The CCA Tailored Mode SPEC provides control logic to handle CCA pushbutton input. It is activated by the configurator whenever the CCA pushbutton is pressed. Figure 3.2-4 shows the overall CCA (pushbutton) software function.

3.2.3.3.3.1 Inputs

Input shall consist of

- o pushbutton identification (1 word)
- o current button status (1 word)

3.2.3.3.3.2 Processing

The CCA Tailored Mode SPEC shall activate the ICS EQUIP to implement the desired control:

- o if hot-mic is "on," the EQUIP is requested to switch it "off"
- o if hot-mic is "off," the EQUIP is requested to turn it "on"

3.2.3.3.3.3 Outputs

Output shall consist of

- o hot-mic on/off control (1 word)

3.2.3.3.4 HCU Tailored Mode Specialist Function

The HCU Tailored Mode SPEC provides control logic to handle HCU display or radar antenna functions. It is activated by the configurator whenever control is requested via the pushbutton selects. Figure 3.2-5 shows the overall HCU software function.




FIGURE 3.2-4 CCA(PUSHBUTTON) SOFTWARE FUNCTION




FIGURE 3.2-5 HCU SOFTWARE FUNCTION

3.2.3.3.4.1 Inputs

Input shall consist of

- o pushbutton number (1 word)
- o pushbutton status (1 word)

3.2.3.3.4.2 Processing

When activated by the configurator, this function shall determine whether the pushbutton input represents a change in the current status from off-to-on. If so, it shall:

- o request cyclic activation of the HCU EQUIP (if inactive)
- o activate the LIGHTS DISP to command the proper light configuration

If the pushbutton input indicates a change in the current status from on-to-off, the HCU Tailored Mode SPEC shall

- o request deactivation of the HCU EQUIP (if active)
- o activate the LIGHTS DISP to turn off the light

3.2.3.3.4.3 Outputs

Output shall consist of

- o light on/off configuration (1 word)

3.2.3.4 Handler Specialist Functions

Handler Specialist Functions control processing for crew-IMK/DEK and crew-MPD/DEK interfaces. They provide the logic to control the display pages associated with the particular device.

There are always two Handler SPECS active: One for the IMK and one for the MPD (for checklist processing).

3.2.3.4.1 IMK Handler SPEC

The IMK Handler SPEC controls processing for all IMK display pages. It is scheduled by the configurator and activated by the request processor (for side key inputs) or by the DEK input EQUIP.

3.2.3.4.1.1 Inputs

Input shall consist of

- o IMK side key number (1 word)
- o table of control information for the page (10 x 2 words)

3.2.3.4.1.2 Processing

When activated by the request processor because of a side key, the IMK Handler Specialist Function shall determine from the display control information whether:

- o DEK input is required
- o a Tailored Mode SPEC should be activated
- o the current OPS or Brute-Force SPEC should be activated to change displays

If DEK input is required for the specific side key number, the IMK Handler shall request cyclic activation of the DEK input EQUIP and displays a symbol on the IMK indicating that DEK input is required. If DEK input is not required for the side key number (and a new display is not requested), the IMK Handler shall activate the appropriate Tailored Mode SPEC. If the side key number is a request for a new display page (advance to lower level, return to higher level), the current OPS or Brute-Force SPEC task shall be notified. (If the DEK EQUIP is active when a side key input is received, it shall be deactivated.)

When activated by the DEK EQUIP, the IMK Handler shall activate the appropriate Tailored Mode SPEC to process the DEK input buffer, and then shall deactivate the DEK EQUIP.

The IMK Handler SPEC shall activate the request processor when the MMK backup capability is used.

3.2.3.4.1.3 Outputs

Output shall consist of:

- o IMK/MPD message ID noting that DEK input is required (1 word)
- o DEK mark control message (1 word)
- o Next display ID (1 word)

3.2.3.4.2 MPD Handler SPEC

The MPD Handler SPEC controls processing for all MPD checklist display pages. It is scheduled by the configurator and activated by the DEK input EQUIP.

3.2.3.4.2.1 Inputs

Input shall consist of:

- o DEK input buffer (n words)
- o table of control information for display page (n x 2 pages)

3.2.3.4.2.2 Processing

When activated by the DEK input EQUIP, the MPD Handler SPEC shall determine the required processing:

- o item checkoff
- o skip item
- o advance page

MPD Handler processing for item checkoff shall consist of displaying a "√" next to the item checked off, and then a "←" opposite the next item in the checkoff sequence.

Skip items shall advance the "←" without checking off the item.

For advance page, the MPD Handler shall activate the MPD Checklist DISP to display the next checklist page.

3.2.3.4.2.3 Outputs

Output shall consist of:

- o DEK mark control message
- o next display ID (1 word)

3.2.4 Display Processes

Display Processes (DISPS) control cockpit displays. When activated, they obtain data/signals generated by the Application Software, perform required formatting, and output the resulting data messages to compools for subsequent transmission to display hardware.

Ten Display Processes have been identified for IDAMST:

- o LIGHTS - Controls lamp on/off for the MMK, HCU, MFDC, IMK, Marker Beacon, Low Speed Warning, Ground Proximity Warning, EFCS Warning
- o INSTRUMENTS - Controls dedicated cockpit instruments: Mach, Air Speed, Vertical Velocity, Altimeter, Accelerometer
- o HUD - Controls HUD for given Master Mode
- o HSD - Controls HSD for given Master Mode
- o MPD CHECKLIST - Controls MPD checklist display pages
- o MPD PARAMETERS/STATUS - Controls processing for the various MPD functional display pages
- o ERROR/WARNING MESSAGES - Controls the outputting of error and warning messages to the crew
- o IMK FIXED TEXT - Controls the display of IMK fixed text pages
- o DEK MARK - Controls DEK check/mark processing pertaining to checklist and data input functions on MPD/IMK
- o IMK STATUS - Controls status displays output to the IMK center partition

3.2.4.1 Lights Display Process

The Lights DISP commands lamp on/off configuration for: a) control panels, b) marker beacon, and c) warning lights. It is activated by the Application Software task responsible for controlling the lamp status of the particular display device.

3.2.4.1.1 Inputs

Input shall consist of

- o device ID (1 word)
- o desired configuration (1 word)

3.2.4.1.2 Processing

The Lights DISP shall format a message to command the desired on/off configuration, and store the message in a compool to be sent to the device.

3.2.4.1.3 Outputs

Output shall consist of

- o lamp on/off command (1 word)

3.2.4.2 Instruments Display Process

The Instruments DISP updates the dedicated cockpit instruments:

- o mach and air speed indicator
- o vertical speed indicator
- o baro altitude indicator
- o g-meter

It is activated 16 times per second throughout the flight.

3.2.4.2.1 Inputs

Input shall consist of

- o flight control system data (n words)
- o minimum/maximum acceleration since reset (2 words)

3.2.4.2.2 Processing

The Instruments DISP shall obtain the input from a compool, calculate the parameters, perform scaling as required, and output the result to a compool for subsequent transfer to the instruments.

3.2.4.2.3 Outputs

Output shall consist of

- o mach number
- o air speed
- o vertical speed
- o baro altitude
- o acceleration (minimum, maximum, current)

3.2.4.3 HUD Display Process

The HUD DISP provides parameters to the MPDG for display on the HUD. It is activated 16 times per second throughout the flight except for Shutdown Mode.

3.2.4.3.1 Inputs

Input shall consist of:

- o parameter data (n words)
- o cursor position (2 words)

3.2.4.3.2 Processing

Upon activation, the HUD DISP shall calculate and/or scale those parameters required for all Master Modes. It then shall process those additional parameters required for the current Master Mode (except those purged by a de-clutter request). The particular parameters calculated for each Mode shall be as shown in Table 3.2-1.

3.2.4.3.3 Outputs

Output shall consist of:

- o parameters corresponding to Master Mode (n words)

3.2.4.4 HSD Display Process

The HSD DISP provides parameters to the MPDG for display on the HSD. It is activated 16 times per second throughout the flight except for Shutdown Mode.

3.2.4.4.1 Inputs

Input shall consist of:

- o parameter data (n words)
- o cursor position (2 words)

3.2.4.4.2 Processing

Upon activation, the HUD DISP shall determine if an HSI display is "assigned" to any MPD. If so, those parameters required by the MPDG to generate the HSI display shall be calculated and/or scaled.

The HUD DISP shall then determine if a MAP display is "assigned" to any MPD. If so, those parameters required by the MPDG to generate the MAP display shall be calculated and/or scaled.

The parameter/functions provided by the MPDG shall consist of:

HSI

distance to waypoint
time to go
heading and heading annunciator
bearing pointers (2)
bearing identifiers

HSI (Continued)

selected heading
selected course
to-from
deviation
vertical deviation path pointer
vertical track change alert
lateral track change alert
offset annunciator
nav. mode annunciator
heading warn
navigation warn

MAP

map scale
way points
navaids
key elevations
projected A/C position
"killer" data
alternate track
airport/target location
(cursor position)

3.2.4.4.3 Outputs

Output shall consist of

- o HSI display parameters (n words)
- o MAP display parameters (n words)

3.2.4.5 MPD Checklist Display Process

The MPD Checklist DISP displays requested checklists. It is activated by the MPD Handler Specialist Function whenever a checklist is to be displayed on an MPD.

3.2.4.5.1 Inputs

Input shall consist of

- o device identification (1 word)
- o checklist identification (1 word)

3.2.4.5.2 Processing

The MPD checklist DISP shall format the MPDG message for displaying the specified checklist on the specified MPD.

3.2.4.5.3 Outputs

Output consists of a control message:

- o MPDG control (1 word)

3.2.4.6 MPD Parameters/Status Display Process

The MPD Parameters/Status DISP controls the various MPD displays. It is activated once per second.

Table 3.2-6 gives the Display numbers which can be displayed on each MPD (e.g., Display #3 can only be shown on MPD #3). Tables 3.2-2 and 3.2-3 show the normal display configuration at the start of a given mission mode. Figure 3.2-6 is an example of a combined nav/comm display page.

3.2.4.6.1 Inputs

Input shall consist of:

- o display requests (2 words)
- o display status (3 words)
- o parameter status (n words)

3.2.4.6.2 Processing

Displays are changed via IMK request; the IMK Handler SPEC processes and stores these requests. At each activation, the MPD Parameters/Status DISP shall check the requests and update the MPD display status (Display number versus MPD number) table.

The DISP shall then obtain the current status for the parameters contained in the up-to-three displays and store them in a Compool for later transfer to the MPDG.

3.2.4.6.3 Outputs

Output shall consist of a) an output buffer to the MPDG containing display ID and parameter status for each and b) updated display status:

- o MPDG data buffer (n words)
- o display status (3 words)

3.2.4.7 Error/Warning Display Process

The Error/Warning DISP controls the outputting of MPD error and warning messages. It is activated by the task which either detects the error or determines the severity of the warning. The messages normally appear on the bottom two lines of the center MPD.

<u>Display</u>	<u>MPD #1 Pilot</u>	<u>MPD #3</u>	<u>MPD #2 Copilot</u>
Nav Status	✓		✓
Comm Status	✓		✓
System Status		✓	
Engine Parameters		✓	
Departure Area Data	✓		
Take Off Parameters			✓
Cruise Parameters			✓
Refuel Status		✓	
Air Drop Flight Parameters	✓		✓
Air Drop Area Data	✓		
Approach Data	✓		
Landing Area Data	✓		
Weight and Balance Data		✓	
Weight and Fuel Data		✓	
Flare Inventory		✓	
Low Speed Parameters			✓
Aircraft Systems Readout		✓	
Warning/Caution		✓	
Flight Data	✓		
LAPES Area Data	✓		
Rendezvous Data	✓		
SID	✓		
STAR	✓		
Delivery System Status		✓	

TABLE 3.2-2 NOMINAL DISPLAY VERSUS MPD ASSIGNMENT


TABLE 3.2-3 NORMAL DISPLAYS AT BEGINNING OF MODE

MASTER MODE	MPD #1 PILOT*	MPD #3 CENTER	MPD #2 COPILOT*
START	-	ENGINE PARAMETERS	-
TAKEOFF	NAV STATUS DEPARTURE AREA DATA	ENGINE PARAMETERS	COMM STATUS TAKEOFF PARAMETERS
ENROUTE	NAV STATUS	ENGINE PARAMETERS	CRUISE PARAMETERS COMM STATUS
AIR DROP	FLIGHT DATA AIR DROP PARAMETERS	AREA DATA ENGINE PARA. DELIVERY SYS. STATUS	NAV STATUS COMM STATUS
LAPES	FLT DATA APPR DATA LAPES AREA DATA	ENGINE PARAMETERS DELIVERY SYS. STATUS	NAV STATUS COMM STATUS
AIR REFUEL	FLT DATA RENDEZVOUS DATA	ENGINE PARAMETERS AIR REFUEL SYS STATUS	NAV STATUS COMM STATUS
TF/TA	-	ENGINE PARAMETERS	NAV STATUS COMM STATUS
GO AROUND	FLIGHT DATA, SID LANDING AREA DATA	ENGINE PARAMETERS	NAV STATUS COMM STATUS
LAND	APPROACH DATA, STAR LANDING AREA DATA	ENGINE PARAMETERS	NAV STATUS COMM STATUS
SHUTDOWN	-	ENGINE PARAMETERS A/C SYSTEMS READOUT	-
GROUND TEST	-	-	-

* MODE-ORIENTED CHECKLISTS SHALL ALSO APPEAR AUTOMATICALLY AT BEGINNING OF MODE.

NAV STATUS	COMM STATUS
MODE AUTO	UHF #1 345.65 T/R
PRES POS	UHF #2 360.00 T/R+G
LAT N 27° 49' 32"	VHF-AM 120.50
LON W136° 27' 49"	VHF-FM 65.25 T/R
ALT 22500 FT	HF OFF
CHECKPOINT 8 DIST 32 NM	LF ADF 500.00
TIME TO GO 4.9 MIN	VHFADF 130.00
TAS 585 KTS	VOCODER CRAD 2 2
GS 527 KTS	IFF NORM 4
UPDATE POSIT CHKPT 9	
LAT N 26° 54' 16"	
LON W137° 29' 53"	
ZULU 15:30:45	

FIGURE 3.2-5 SAMPLE MPD DISPLAY: COMBINED NAV/COMM STATUS



3.2.4.7.1 Inputs

Input shall consist of

- o message number (1 word)

3.2.4.7.2 Processing

Using the input identifier, the Error/Warning DISP shall obtain the message from a compool and add current status, if necessary.

3.2.4.7.3 Outputs

Output shall consist of

- o error/warning message (n words)

3.2.4.8 IMK Fixed Text Display Process

The IMK Fixed Text DISP controls the display of fixed-formatted pages on the IMK. It is activated by an Operational Sequencer or Brute Force Specialist Function wherever a new IMK page is to be displayed. Figure 3.2-7 shows a sample IMK Fixed-Text display.

3.2.4.8.1 Inputs

Input shall consist of

- o page number (1 word)

3.2.4.8.2 Processing

This function shall format a message containing the page ID, and store it for transfer to the A/NSG. The actual "pages" are pre-stored in the A/NSG.

3.2.4.8.3 Outputs

Output shall consist of

- o page number (1 word)

3.2.4.9 DEK Mark Display Process

The DEK Mark DISP provides the capability to add a symbol to a specified line on the IMK or MPD indicating required action, and to delete the symbol when the action has been completed.

The symbol may be a "d" on the IMK to denote required DEK input, which is then removed when valid DEK input is entered. The symbol may be a "✓" on the MPD to denote a checked off item or a "←" to denote the next item in a checkoff sequence.




FIGURE 3.2-7 SAMPLE IMK FIXED - TEXT DISPLAY

It is usually activated by the IMK or MPD Handler Specialist Function to control the symbol display. It is sometimes activated by a Tailored Mode SPEC which determines the successful completion of a data entry.

3.2.4.9.1 Inputs

Input shall consist of:

- o device number (1 word)
- o action - insert, delete (1 word)
- o CRT row, column (1 word)

3.2.4.9.2 Processing

Given the device and requested action, the DEK Mark DISP shall store the appropriate message in a Compool to be sent to the A/NSG or MPDG.

3.2.4.9.3 Outputs

Output shall consist of the A/NSG or MPDG message:

- o control message (1 word)

3.2.4.10 IMK Status Display Process

The IMK Status DISP controls the display of status information in the center partition of the IMK. It is activated once per second to update parameter status if there is an active display. Figure 3.2-8 shows a sample IMK status display.

3.2.4.10.1 Inputs

Input shall consist of the status display ID:

- o display number (1 word)

3.2.4.10.2 Processing

The IMK Status DISP shall access a table which identifies the parameters for the display number. Current status for these parameters shall be obtained from a Compool, formatted and stored in an output buffer for transfer to the A/NSG.

3.2.4.10.3 Outputs

Output shall consist of the A/NSG buffer:

- o parameter status (n words)




FIGURE 3.2-8 SAMPLE IMK STATUS DISPLAY

3.2.5 Equipment Processes

The Applications Software interfaces with IDAMST equipment via Equipment Processes (EQUIPS).

For each sensor providing data to the Application Software, the corresponding input EQUIP will:

- o monitor equipment status and initiate action when a health problem or degraded data is detected
- o perform the processing required to make the parameter(s) available for use by Applications Software tasks
- o generate substitute data values if necessary

Those EQUIPS which output control data to equipment will:

- o perform the processing required to format the appropriate control message

The Equipment Processes identified for IDAMST are shown in Table 3.2-4.

3.2.5.1 UHF-AM Equipment Process

The two UHF-AM radios (AN/ARC-164) are used for military communications and as backup ADF receivers. They provide short-range, line-of-sight, two-way simplex voice communication with ground systems and other aircraft, operating in the 225-399.95 MHz frequency band. When the radio is in backup ADF mode, bearing is obtained via the ADF EQUIP.

The UHF EQUIP is activated by the UHF-AM Tailored Mode SPEC whenever a formatted control message is to be sent to the radio.

3.2.5.1.1 Inputs

Input shall be a message containing radio ID and desired control:

- o radio ID, control input (2 words)

Control capability consists of one of the following:

- o frequency channel pre-set, aligning frequency tuning by channel select
- o manual frequency selection
- o pre-set guard frequency selection
- o operational mode selection (T/R, TR+G, ADF, OFF)

TABLE 3.2-4 EQUIP SUMMARY

<u>Equipment</u>	<u>Activation Rate (per second)</u>	
DEK	8*	(Input)
TACAN	8	(Input)
HCU	16*	(Input)
OMEGA	8	(Input)
FCS	32	(Input)
G-Meter	4	(Input)
INS	4	(Input)
SKE/ZM	4	(Input)
LF/ADF	4	(Input)
UHF/ADF	4	(Input)
Radar ALT	4	(Input)
ILS	4	(Input)
Compass	4	(Input)
Flight Surfaces	2	(Input)
Aircraft Systems	2	(Input)
Caut/Brakes/Gear	2	(Input)
UHF-AM	Demand	(Output)
VHF-AM	Demand	(Output)
VHF-FM	Demand	(Output)
HB/SSB	Demand	(Output)
DSMU	Demand	(Output)
Secure Voice	Demand	(Output)
TACAN	Demand	(Output)
OMEGA	Demand	(Output)
CCA	Demand	(Output)
FCS	16	(Output)
Flares	Demand	(Output)
INS	Demand	(Output)
SKE/ZM	Demand	(Output)
LF/ADF	Demand	(Output)
UHF/ADF	Demand	(Output)
Radar ALT	Demand	(Output)
ILS	Demand	(Output)
Compass	Demand	(Output)
Radar	Demand	(Output)
IRD&W	Demand	(Output)
RHAWS	Demand	(Output)
Avionics On/Off	Demand	(Output)
ICS	8	(Input/Output)
P.A.	8	(Input/Output)
FDR	TBD	(Output)

* Continuous activation only when being used.

- o squelch disable
- o volume control

3.2.5.1.2 Processing

When activated by the UHF-AM Tailored Mode SPEC, the EQUIP shall determine the type of control desired, format the required message, and store it in a compool for subsequent transfer to the radio. Input control data will have been checked by the activating task for invalid/out-of-range conditions, so EQUIP processing shall assume valid data.

3.2.5.1.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.2 VHF-AM Equipment Process

The VHF-AM radio (Wilcox-807A) is used for CCT and civilian communications. It provides two-way simplex 160 nautical mile voice communication in the 118 - 135.975 MHz frequency band over line-of-site propagation paths.

The VHF-AM EQUIP is activated by the VHF-AM Tailored Mode SPEC whenever a formatted control message is to be sent to the radio.

3.2.5.2.1

Input shall be a message containing the desired control:

- o control input (1 word)

Control capability consists of one of the following:

- o manual frequency selection
- o squelch disable
- o volume control
- o on/off control

3.2.5.2.2 Processing

When activated by the VHF-AM Tailored Mode SPEC, the EQUIP shall determine the type of control desired, format the required message, and store it in a compool for subsequent transfer to the radio. Input control data will have been checked by the activating task for invalid/out-of-range conditions, so EQUIP processing shall assume valid data.

3.2.5.2.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.3 VHF-FM Equipment Process

The VHF-FM radio (FM622A) is used primarily for military/CCT communications. It provides short-range line-of-sight, two-way simplex voice communication in the 30 - 75.95 MHz frequency range.

The VHF-FM EQUIP is activated by the VHF-FM Tailored Mode SPEC whenever a formatted control message is to be sent to the radio.

3.2.5.3.1

Input shall be a message containing the desired control:

- o control input (1 word)

Control capability consists of one of the following:

- o on/off control
- o manual frequency selection
- o volume control
- o T/R control
- o re-transmit control
- o home control
- o squelch disable
- o squelch carrier
- o squelch tone

3.2.5.3.2 Processing

When activated by the VHF-FM Tailored Mode SPEC, the EQUIP shall determine the type of control desired, format the required message, and store it in a compool for subsequent transfer to the radio. Input control data will have been checked by the activating task for invalid/out-of-range conditions, so EQUIP processing shall assume valid data.

3.2.5.3.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.4 HF/SSB Equipment Process

The HF/SSB radio (AN/ARC-123) is used for long-range military communications. It provides two-way simplex voice communications at distances up to 2,500 nautical miles, operating in the 2 - 30 MHz frequency band.

The HF/SSB EQUIP is activated by the HF/SSB Tailored Mode SPEC whenever a formatted control message is to be sent to the radio.

3.2.5.4.1

Input shall be a message containing the desired control:

- o control input (1 word)

Control capability consists of one of the following:

- o on/off control
- o manual frequency selection
- o SSB
- o amplitude modulation equivalent
- o frequency shift key
- o continuous wave
- o volume control
- o squelch disable
- o noise blank
- o RF gain control

3.2.5.4.2 Processing

When activated by the HF/SSB Tailored Mode SPEC, the EQUIP shall determine the type of control desired, format the required message, and store it in a com pool for subsequent transfer to the radio. Input control data will have been checked by the activating task for invalid/out-of-range conditions, so EQUIP processing shall assume valid data.

3.2.5.4.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.5 ICS Equipment Process

The Intercommunication Set (AN/AIC-18) provides:

- o two-way voice communication between crew stations
- o interfaces with radio transceivers, navigation receivers, public address amplifier, and maintenance intercom outlets

The ICS allows for selection, control, and distribution of radio systems for airborne/ground station communication and monitoring.

The ICS EQUIP is activated cyclically eight times per second from startup.

3.2.5.5.1 Inputs

Input shall be ICS control panel ID and settings, and hot-mic select from the CCA:

- o hot-mic selection (CCA) (1 word)
- o monitoring (mixer) switches with individual volume controls (n words)
- o hot-listen selection (1 word)
- o mic-talk selection (panel) (1 word)
- o call selection (1 word)
- o aux listen selection (1 word)

3.2.5.5.2 Processing

The EQUIP shall determine if panel setting has changed since the last activation. If the settings are the same, the EQUIP shall terminate. If changed, the EQUIP shall format/store corresponding ICS control messages.

3.2.5.5.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.6 Public Address Equipment Process

The P.A. System (AN/AIC-13) is used for voice announcements in the cargo areas. The P.A. EQUIP is activated cyclically eight times per second from startup.

3.2.5.6.1 Inputs

Input shall be the P.A. control panel output buffer to be monitored by the EQUIP:

- o on/off control
- o speaker selection
- o mixer switch control
- o volume control

3.2.5.6.2 Processing

The EQUIP shall determine if panel setting has changed since the last activation. If the settings are the same, the EQUIP shall terminate. If changed, the EQUIP shall format/store corresponding P.A. control messages.

3.2.5.6.3 Outputs

Output shall be control messages corresponding to the request, and P.A. status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.7 Secure Voice Equipment Process

The Secure Voice System (TSEC/KY-58) encrypts and decrypts VHF/UHF voice communication.

The secure voice EQUIP is activated by the Secure Voice Tailored Mode SPEC whenever on/off control is to be sent to the unit.

3.2.5.7.1 Input

Input shall be a message containing desired control:

- o on/off indication (1 word)

3.2.5.7.2 Processing

This EQUIP shall store the on (or off) control message in a compool for subsequent transfer to the unit.

3.2.5.7.3 Outputs

Output shall be control messages corresponding to the request, and status updates:

- o control command (1 word)
- o status update (1 word)

3.2.5.8 DEK Equipment Process

The DEK Equipment Process controls the DEK input procedure. An eight-times-per-second activation rate is initiated by a Handler Specialist Function whenever DEK input is required for a particular IMK side key function or MPD checklist function. It is deactivated when an ENTER is received or when there is no further need for the input.

3.2.5.8.1 Inputs

Input shall be one character:

- o character (1 word)

which may represent any of the following:

- o digits 0 through 9
- o CLEAR (re-set)
- o CHECK (checklist checkoff - MPD)
- o SPACE (checklist skip function - MPD)
- o PAGE (advance page - MPD)
- o ENTER (end-of-data)
- o NULL (no input)

3.2.5.8.2 Processing

When activated, the DEK EQUIP shall initialize the input buffer. Each activation thereafter (eight/second) the EQUIP shall determine input status, and terminate if there was no input since the last activation.

If the input was a 0 - 9 digit (or its upper case equivalent), and the input buffer isn't full, the character shall be stored; otherwise, the buffer shall

be cleared and a message displayed on the center MPD via the Error/Warning DISP. The maximum size of the input buffer is 20 characters.

If the input is CLEAR, the EQUIP shall clear the buffer.

CHECK, SPACE, PAGE are used for MPD checklist functions; the MPD Handler Specialist Function is activated to control the processing of the input buffer. If the DEK EQUIP is assigned to an IMK Handler, these keys shall be ignored.

ENTER indicates the end of the input data string; the Handler Specialist Function shall be activated to process the input buffer.

3.2.5.8.3 Outputs

Output shall be the final DEK input buffer:

- o input buffer (1 - n word)

packed two characters per word.

3.2.5.9 DSMU Equipment Process

The DSMU controls display distribution and refresh functions. It contains modules which provide five independent raster memory channels to refresh the MPD's, and two independent stroke channels for the HUD's. The display memory is loaded/updated from the MPDG. Switching commands allow sensor video to be displayed in lieu of a display stored in a memory module.

The DSMU EQUIP is activated by the DSMU Tailored Mode SPEC whenever a switching command is to be sent to the DSMU as a result of a crew request via the IMK.

3.2.5.9.1 Inputs

Input shall consist of

- o DSMU switching request (1 word)

3.2.5.9.2 Processing

The DSMU EQUIP shall format the switching command and store in an output buffer for transfer to the DSMU.

3.2.5.9.3 Outputs

Output shall consist of

- o DSMU switching command (1 word)
- o Switching status (1 word)

3.2.5.10 TACAN Equipment Processes

The TACAN System (AN/ARN-118) furnishes data relative to a selected TACAN facility operating in the 962 - 1213 mHz frequency band.

Two TACAN EQUIPS are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats TACAN commands to satisfy control requests.

3.2.5.10.1 TACAN Input EQUIP

This EQUIP processes data from the TACAN system. It is activated eight times per second.

3.2.5.10.1.1 Inputs

Input shall be TACAN data and previous status:

- o bearing (1 word)
- o range (1 word)
- o range rate, to-from indication (1 word)
- o status (1 word)
- o previous status (1 word)

3.2.5.10.1.2 Processing

The input EQUIP shall format and scale the data as necessary, and store the results in a compool. If status has changed, the SSSM shall be activated.

3.2.5.10.1.3 Outputs

Output shall be the formatted data:

- o bearing (1 word)
- o distance (1 word)
- o range rate (1 word)
- o to-from indicator (1 word)
- o course deviation signal (1 word)

3.2.5.10.2 TACAN Output EQUIP

This EQUIP formats control messages to the TACAN. It is activated by the TACAN Tailored Mode SPEC whenever control is requested by a crew member via the IMK.

3.2.5.10.2.1 Inputs

Input shall be control type/value data:

- o on/off
- o channel select
- o mode select
 - o receive
 - o transmit/receive
 - o A/A receive
 - o A/A transmit
- o auto/manual tuning
- o volume
- o course select
- o test capability

3.2.5.10.2.2 Processing

The input EQUIP shall generate the control message corresponding to the type/value input data.

3.2.5.10.2.3 Outputs

Output shall be the control message and status:

- o TACAN control (1 word)
- o Control status update (1 word)

3.2.5.11 HCU Equipment Process

The Hand Controller Unit provides crew members with: 1) the capability to point the radar antenna and 2) data update capability via display cursor positioning.

The HCU EQUIP is activated 16 times per second (whenever an HCU display-select pushbutton is in effect) to process cursor displacements.

3.2.5.11.1 Inputs

Input shall be activate/designate pushbutton and X, Y displacement:

- o pushbutton (1 word)
- o $\Delta X, \Delta Y$ (2 words)

3.2.5.11.2 Processing

The HCU EQUIP shall keep track of the "null", "activate", or "designate" state of the controller pushbutton. The state is initially "null". No calculations are performed until the controller pushbutton is pressed for the first time, changing the state to "activate".

When the state is "activate", the EQUIP shall evaluate the effective cursor position with respect to the selected display, and store these displacements for use by the particular DISP that is to use them. If the antenna control pushbutton is active, and the displacements represent a change from the previous, the Radar Tailored Mode SPEC shall be activated.

When the controller pushbutton is pressed a second time, the state changes to "designate" and no further calculations are performed; the last calculated displacement is left in a compool to be used, for example, in a navigation data update procedure.

3.2.5.11.3 Outputs

Output shall consist of displacement data and pushbutton state:

- o $\Delta X, \Delta Y$ (2 words)
- o state - null, activate, designate (1 word)

3.2.5.12 OMEGA Equipment Processes

The OMEGA Radio Navigation System (AN/ARN-) provides airplane position fixes using the worldwide network of VLF ground transmitters.

Two OMEGA EQUIPS are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats OMEGA commands to satisfy control requests.

3.2.5.12.1 OMEGA Input EQUIP

This EQUIP processes data from the OMEGA system. It is activated eight times per second.

3.2.5.12.1.1 Inputs

Input shall consist of:

- o three channels of RF information

3.2.5.12.1.2 Processing

The OMEGA input EQUIP shall format/scale RF data as

necessary, and store in a compool for use in navigation calculations.

3.2.5.12.1.3 Outputs

Output shall be the OMEGA parameters, properly formatted and scaled, to be stored in a compool:

- o parameters (n words)

3.2.5.12.2 OMEGA Output EQUIP

This EQUIP formats control messages to the OMEGA system. It is activated by the OMEGA Tailored Mode SPEC whenever control is requested by a crew member via the IMK.

3.2.5.12.2.1 Inputs

Input shall consist of

- o On/Off (1 word)
- o Auto/Manual Tuning (1 word)
- o GMT, Date, Latitude, Longitude (4 words)

3.2.5.12.2.2 Processing

The output EQUIP shall generate the control message corresponding to the type/value input data.

3.2.5.12.2.3 Outputs

Output shall be the control message and status.

- o OMEGA Control (1 word)
- o Status Update (1 word)

3.2.5.13 CCA Equipment Process

The Column Control Assembly provides a shaker capability for imminent stall conditions.

The CCA EQUIP is activated by the FCS EQUIP whenever shaker control (on or off) is required.

3.2.5.13.1 Inputs

Input shall consist of

- o Shaker Control Request

3.2.5.13.2 Processing

The CCA EQUIP shall store the control message in a Compool for subsequent transfer to the CCA, and update the CCA status accordingly.

3.2.5.13.3 Outputs

Output shall be control commands and status updates.

- o CCA Shaker On/Off Control (1 word)
- o On/Off Status (1 word)

3.2.5.14 FCS Equipment Process

The Flight Control System provides air data, attitude, and mode and status information. This information is processed by the avionics system to provide steering data for the flight control system.

Two FCS EQUIP's are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP is activated cyclically to send steering data.

3.2.5.14.1 FCS Input EQUIP

The FCS input EQUIP processes data from the flight control system. It is activated 32 times per second.

3.2.5.14.1.1 Inputs

Input shall be FCS output data, and previous status.

- o Air Data (10 words), 3 channels
- o Attitude (5 words), 3 channels
- o Mode and Status (1 word), 3 channels
- o Previous Status (1 word)

3.2.5.14.1.2 Processing

The Equip shall process the data as necessary, and store the results in a Compool. If the status has changed, the SSSM shall be activated. The LIGHTS DISP shall be activated for on/off control of the EFCS Warning Light, as necessary.

Data processing may include scaling, signal source selection, smoothing, algorithm calculations, etc.

3.2.5.14.1.3 Outputs

Output shall consist of

- o Air Data (10 words)
- o Attitude Data (5 words)
- o Mode/Status (1 word)
- o EFCS Light Control (1 word)

3.2.5.14.2 FCS Output EQUIP

The FCS Output EQUIP controls the sending of steering signals to the FCS. It is activated cyclically 16 times per second.

3.2.5.14.2.1 Inputs

Input shall consist of

- o Steering Requests (4 words)

3.2.5.14.2.2 Processing

The output EQUIP shall generate the steering messages and outputs them to a Compool.

3.2.5.14.2.3 Outputs

Output shall consist of

- o Steering Signals (4 words)

3.2.5.15 Flares Dispenser System Equipment Process

The Flares Dispenser System contains four sets of flares which may be dropped as a defensive measure against infrared seeker threats.

The Flares Dispenser System EQUIP is activated by the Flares Dispenser tailored Model SPEC whenever a formatted control message is to be sent to the system.

3.2.5.15.1 Inputs

Input shall be control requests and status.

- o On/Off (1 word)
- o Flare Set # (1 word)
- o Flare Status (2 words)

3.2.5.15.2 Processing

The Flares Dispenser System EQUIP shall generate control messages and store them in a Compool for transmission. The software flare status shall be updated.

3.2.5.15.3 Outputs

Output shall be control commands to the Flares Dispenser System and status.

- o On/Off Command (1 word)
- o Flare Drop Command (1 word)
- o Current Flare Status (2 words)

3.2.5.16 G-Meter Equipment Process

The G-Meter displays 1) current vertical acceleration, 2) the low vertical acceleration since last reset, and 3) the high vertical acceleration since last reset.

The G-Meter EQUIP is activated 4 times per second to monitor the reset button.

3.2.5.16.1 Inputs

Input shall consist of

- o Reset Button Status (1 word)

3.2.5.16.2 Processing

If the reset button shows a change in status, the low vertical acceleration and high vertical acceleration shall be set equal to 1.

3.2.5.16.3 Output

Output shall be new low and high vertical acceleration values.

- o Accelerations (2 words)

3.2.5.17 INS Equipment Processes

The INS (Carousel IV) is a self-contained inertial navigation system (including a digital computer) which provides worldwide aircraft navigation entirely independent of ground communication.

Two INS EQUIP's are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats INS commands to satisfy control requests.

3.2.5.17.1 INS Input EQUIP

This EQUIP processes data from the INS. It is activated 4 times per second.

3.2.5.17.1.1 Inputs

Input shall consist of

- o Aircraft Position and Velocity (6 words)
- o Pitch and Roll (2 words)
- o Calculated Digital Data (n words)
- o Status (1 word)

3.2.5.17.1.2 Processing

The EQUIP shall format and scale the data as necessary, and store the results in a Compool. If the status has changed, the SSSM shall be activated.

3.2.5.17.1.3 Outputs

Output shall consist of

- o Position and Velocity (2 words)
- o Pitch and Roll (2 words)
- o Other Data (n words)

3.2.5.17.2 INS Output EQUIP

This EQUIP formats control messages to the INS. It is activated by the INS Tailored Mode SPEC whenever control is requested by a crew member via the IMK.

3.2.5.17.2.1 Inputs

Input shall consist of

- o Mode (1 word)
- o Auto/Manual Select (1 word)
- o Initial Position (2 words)
- o Way Point Loading (n words)

3.2.5.17.2.2 Processing

The EQUIP shall generate the control message corresponding to the type/value input data.

3.2.5.17.2.2. Outputs

Output shall be the control message and updated control status:

- o INS Control (1 word) and Status (1 word)

3.2.5.18 SKE/ZM Equipment Processes

The Station Keeping Equipment (AN/APN-169) is a cooperative air-to-air station keeping system for flights of up to 36 aircraft. It enables these aircraft to locate and identify one another; and to maintain formation/rendezvous regardless of visibility. The SKE interfaces with the MDSC to provide a formation display.

Two SKE EQUIP's are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats SKE commands to satisfy control requests.

3.2.5.18.1 SKE Input EQUIP

This EQUIP processes data from the SKE. It is activated 4 times per second.

3.2.5.18.1.1 Inputs

Input shall consist of

- o Aircraft Range and Bearing (n words)
- o SKE Status (1 word)

3.2.5.18.1.2 Processing

The EQUIP shall format and scale the data as necessary, and store the results in a Compo1. If the status has changed, the SSSM shall be activated.

3.2.5.18.1.3 Outputs

Output shall consist of

- o Aircraft Range and Bearing (n words)

3.2.5.18.2 SKE Output EQUIP

This EQUIP formats control messages to the SKE. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.18.2.1 Inputs

Input shall be control type/value data:

- o On/Off (1 word)
- o Freq A/B (1 word)
- o In Track Offset (1 word)
- o Altitude Offset (1 word)
- o Cross-Track Offset (1 word)
- o Leader Select (1 word)
- o Proximity Warning Range (1 word)
- o Proximity Warning Tone On/Off (1 word)
- o Master-Follow Select (1 word)
- o Master Indicator (1 word)
- o BITE Test (1 word)
- o ID Function Select (1 word)
- o Range Scale (1 word)
- o Range Mark (1 word)
- o Display Centering (1 word)
- o Blanking (1 word)

3.2.5.18.2.2 Processing

The EQUIP shall generate the control message corresponding to the type/value of the input request.

3.2.5.18.2.3 Outputs

Output shall be the control message and updated control status.

- o SKE Command (1 word) and Status (1 word)

3.2.5.19 LF/ADF Equipment Processes

The LF/ADF (DF-206) provides the navigation calculation with bearing to a selected low frequency radio station.

Two LF/ADF EQUIP's are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats LF/ADF commands to satisfy control requests.

3.2.5.19.1 LF/ADF Input EQUIP

This EQUIP processes data from the LF/ADF unit. It is activated four times per second.

3.2.5.19.1.1 Inputs

Input shall consist of

- o Bearing (1 word)
- o Status (1 word)

3.2.5.19.1.2 Processing

The input EQUIP shall format and scale the bearing input data, and store it in a Compool. If the status has changed, the SSSM shall be activated.

3.2.5.19.1.3 Outputs

Output shall consist of

- o Bearing (1 word)

3.2.5.19.2 LF/ADF Output EQUIP

This EQUIP formats control messages to the LF/ADF. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.19.2.1 Inputs

Input shall be control type/value data.

- o On/Off (1 word)
- o Auto/Manual Select (1 word)
- o Frequency Select (1 word)
- o Test Select (1 word)
- o Volume (1 word)

3.2.5.19.2.2 Processing

The output EQUIP shall generate the control message corresponding to the type/value of the input request.

3.2.5.19.2.3 Outputs

Output shall be the control message and updated control status.

- o LF/ADF Command (1 word) and Status (1 word)

3.2.5.20 UHF/ADF Equipment Processes

The UHF/ADF (DF-301E) provides the navigation calculation with bearing to a selected ultra-high frequency radio station.

Two UHF/ADF EQUIP's are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats UHF/ADF commands to satisfy control requests.

3.2.5.20.1 UHF/ADF Input EQUIP

This EQUIP processes data from the UHF/ADF unit. It is activated four times per second.

3.2.5.20.1.1 Inputs

Input shall consist of

- o Bearing (1 word)
- o Status (1 word)

3.2.5.20.1.2 Processing

The input EQUIP shall format and scale the bearing input data, and store it in a Compool. If status has changed, the SSSM shall be activated.

3.2.5.20.1.3 Outputs

Output shall consist of

- o Bearing (1 word)

3.2.5.20.2 UHF/ADF Output EQUIP

This EQUIP formats control messages to the UHF/ADF. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.20.2.1 Inputs

Input shall be control type/value data.

- o On/Off (1 word)
- o Auto/Manual Select (1 word)
- o Frequency Select (1 word)
- o Test Select (1 word)
- o Volume (1 word)

3.2.5.20.2.2 Processing

The output EQUIP shall generate the control message corresponding to the type/value of the input request.

3.2.5.20.2.3 Outputs

Output shall be the control message and updated control status.

- o UHF/ADF Command (1 word) and Status (1 word)

3.2.5.21 Radar Altimeter Equipment Processes

The two Radar Altimeters (AN/APN-194) are range tracking radars which provide altitude information from 0 - 5000 feet.

Two Radar Altimeter EQUIPS are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats Radar Altimeter commands to satisfy control requests.

3.2.5.21.1 Radar Altimeter Input EQUIP

This EQUIP processes data from the Radar Altimeter. It is activated four times per second.

3.2.5.21.1.1 Inputs

Input shall consist of

- o Status (1 word)
- o Altitude (1 word)
- o Radar altimeter ID (1 word)

3.2.5.21.1.2 Processing

The input EQUIP shall format and scale the altitude input data, and store it in a Compool. If the status has changed, the SSSM shall be activated.

3.2.5.21.1.3 Outputs

Output shall consist of

- o Altitude (1 word)

3.2.5.21.2 Radar Altimeter Output EQUIP

This EQUIP formats control messages to the Radar Altimeter. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.21.2.1 Inputs

Input shall consist of

- o On/off (1 word)
- o Low altitude select (1 word)
- o ID (1 word)
- o Test select (1 word)

3.2.5.21.2.2 Processing

The output EQUIP shall generate the control message corresponding to the type/value of the input request, and store it in a Compool.

3.2.5.21.2.3 Outputs

Output shall consist of

- o radar altimeter command (1 word)

3.2.5.22 ILS Equipment Processes

The Instrument Landing System (AN/ARN-108) is used in conjunction with ground transmitting equipment and airplane flight director calculations to provide display capability for marker beacon, glideslope, and localizer signals.

Two ILS EQUIPS are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats ILS commands to satisfy control requests.

3.2.5.22.1 ILS Input EQUIP

This EQUIP processes data from the ILS unit. It is activated four times per second.

3.2.5.22.1.1 Inputs

Input shall consist of

- o Bearing (1 word)
- o Status (1 word)
- o Localizer/glide slope deviation (2 words)
- o ILS ID (1 word)

3.2.5.22.1.2 Processing

The EQUIP shall format and scale the bearing data, and store it in a Compool. If the status has changed, the SSSM shall be activated.

3.2.5.22.1.3 Outputs

Output shall consist of

- o Bearing (1 word)
- o Localizer/glide slope deviations (2 words)

3.2.5.22.3 ILS Output EQUIP

This EQUIP formats control messages to the ILS. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.22.2.1 Inputs

Input shall consist of

- o On/off (1 word)
- o Auto/manual select (1 word)
- o Frequency select (1 word)
- o Course select
- o MDA select
- o ILS ID

3.2.5.22.2.2 Processing

The EQUIP shall generate the control message corresponding to the type/value of the input request.

3.2.5.22.2.3 Outputs

Output shall consist of

- o ILS command (1 word) and Status (1 word)

3.2.5.23 Compass Equipment Processes

The Magnetic Compass (C-12) provides heading information for navigation.

Two Compass EQUIPs are provided. The input EQUIP is activated cyclically to receive data; the output EQUIP formats Compass Commands to satisfy control requests.

3.2.5.23.1 Compass Input EQUIP

This EQUIP processes data from the Compass unit. It is activated four times per second.

3.2.5.23.1.1 Inputs

Input shall consist of

- o Heading (1 word)
- o Status (1 word)

3.2.5.23.1.2 Processing

The input EQUIP shall format and scale the heading data, and store it in a Compool. If the status has changed, the SSSM shall be activated.

3.2.5.23.1.3 Outputs

Output shall consist of

- o Heading (1 word)

3.2.5.23.2 Compass Output EQUIP

This EQUIP formats control messages to the Compass. It is activated whenever control is requested by a crew member via the IMK.

3.2.5.23.2.1 Inputs

Input shall consist of

- o On/off (1 word)
- o Slaved option (1 word)
- o D.G. (1 word)
- o Set heading (1 word)
- o Set latitude (1 word)

3.2.5.23.2.2 Processing

The output EQUIP shall generate the control message corresponding to the type/value of the input request.

3.2.5.23.2.3 Outputs

Output shall consist of

- o Compass command (1 word)
- o Status (1 word)

3.2.5.24 LR Radar Equipment Processes

The Long Range Radar (AN/APQ-122) provides precise navigation capabilities for long-range ground mapping, weather detection, and beacon interrogation. A high-resolution CRT radar display is available to the crew upon request.

The Radar EQUIP is activated by the Radar Tailored Mode SPEC whenever a formatted control message is to be sent to the unit.

3.2.5.24.1 Inputs

Input shall consist of

- o Mode select (1 word)
- o Frequency select (1 word)
- o Magnetic variation select (1 word)
- o RF power, gain (2 words)
- o Beam (1 word)
- o Azimuth stabilizer (1 word)
- o ISO echo (1 word)
- o Scan select (1 word)
- o Range select (1 word)
- o Fast time on/off (1 word)
- o Sens. time (1 word)
- o Frequency agile mode on/off (1 word)
- o Heading marker intensity (1 word)
- o Range marker intensity (1 word)
- o Sweep intensity (1 word)

3.2.5.24.2 Processing

The EQUIP shall generate the control message corresponding to the type/value of the input request, and store it in a Compool for subsequent transmission to the Long Range Radar.

3.2.5.24.3 Outputs

Output shall consist of

- o Radar command (1 word) and status (1 word)

3.2.5.25 IRD&W Equipment Processes

The Infrared Detection and Warning System is a defensive countermeasure which provides threat information. It interfaces with the MDSC to provide a quadrant-orientated threat display.

The IRDW EQUIP is activated by the IRDW Tailored Mode SPEC whenever a formatted control message is to be sent to the unit.

3.2.5.25.1 Inputs

Input shall consist of

- o on/off (1 word)

3.2.5.25.2 Processing

The EQUIP shall store the on (or off) control message in a Compool for subsequent transfer to the device.

3.2.5.25.3 Outputs

Output shall consist of

- o on/off command

3.2.5.26 RHAWS Equipment Process

The Radar Homing and Warning System (AN/APR-36/37) is a radar-detecting, defensive countermeasure which provides threat information to the crew via MPD display.

The RHAWS EQUIP is activated by the RHAWS Tailored Mode SPEC whenever a formatted control message is to be sent to the unit.

3.2.5.26.1 Inputs

Input shall consist of

- o on/off (1 word)

3.2.5.26.2 Processing

The EQUIP shall store the on (or off) control message in a Compool for subsequent transfer to the device.

3.2.5.26.2 Processing

The EQUIP shall store the on (or off) control message in a Compool for subsequent transfer to the device.

3.2.5.26.3 Outputs

Output shall consist of

- o On/Off Command (1 word)

3.2.5.27 Flight Surfaces Equipment Process

The current positions of controllable flight surfaces (e.g., flaps) are monitored for display and algorithm purposes.

The Flight Surfaces EQUIP is activated 2 times per second to read current position settings of the surfaces.

3.2.5.27.1 Inputs

Input shall consist of

- o Elevator Trim Positions (9 words)
- o Left-Wing Flap/Spoiler Positions (7 words)
- o Right Wing Flaps/Spoiler Positions (7 words)

3.2.5.27.2 Processing

The EQUIP shall process the input data as required, and store the result in a Compool.

3.2.5.27.3 Outputs

Output shall consist of

- o Elevator Trim Positions (9 words)
- o Left Flap Positions (7 words)
- o Right Flap Positions (7 words)

3.2.5.28 Aircraft Sensors Equipment Process

Aircraft sensors provide current status of -

- o Fuel
- o Engines
- o Power
- o Accelerometer

for display.

The Aircraft Sensors EQUIP is activated 2 times a second to read the current sensor output.

3.2.5.28.1 Inputs

Input shall consist of

- o Fuel (n words)
- o Engines (n words)
- o Power (n words)
- o Accelerometer (1 word)

3.2.5.28.2 Processing

The EQUIP shall process the input data as required, and store the results in a Compool.

3.2.5.28.3 Outputs

Output shall consist of

- o Fuel (n words)
- o Engines (n words)
- o Power (n words)
- o Accelerometer (1 word)

3.2.5.29 Brakes/Gear/Caution Equipment Process

The current status of the brake and landing gear systems, and the caution panel, is monitored for display and algorithm purposes.

The Brake/Gear/Caution EQUIP is activated 2 times a second to copy the current status.

3.2.5.29.1 Inputs

Input shall consist of

- o Weight-On-Gear (1 word)
- o Caution Lights (n words)
- o Master Caution Light (1 word)
- o Landing Gear (1 word)
- o Brakes (1 word)
- o Gear-Up and Locked (1 word)
- o Previous Values for the Above (n words)

3.2.5.29.2 Processing

The EQUIP shall process the input data as required, and store the results in a Compool. Changes in the status of any item from its previous value may result in the activation of the Error/Warning DISP.

3.2.5.29.3 Outputs

Output shall consist of

- o Weight-On-Gear (1 word)
- o Caution Lights (n words)
- o Master Caution Light (1 word)
- o Landing Gear (1 word)
- o Brakes (1 word)
- o Gear-Up and Locked (1 word)
- o Message ID (1 word)

3.2.5.30 Avionics On/Off Equipment Process

On/off control is provided for the following avionics equipment.

- | | |
|------------------------------|--------------------------|
| o Counting Accelerometer | o HUD 1 |
| o Gear-Up and Locked - left | o HUD 2 |
| o Gear-Up and Locked - right | o HSD 1 |
| o Weight on Gear - left | o HSD 2 |
| o Weight on Gear - right | o MPD 1 |
| o Stick Shaker 1 | o MPD 2 |
| o Stick Shaker 2 | o MPD 3 |
| o Stab. Trim Position | o MPDG 1 |
| o Flap Position - left | o MPDG 2 |
| o Flap Position - right | o DSMU |
| o Fuel Totalizer | o MDSC |
| o Engine 1 | o MFDC |
| o Engine 2 | o HCU |
| o IRD & W | o MMK |
| o RH & W | o TACAN |
| o Flares Dispenser | o SKE |
| o Long Range Radar | o HF/SSB Radio |
| o Radar Altimeter 1 | o VHF-AM Radio |
| o Radar 2 | o VHF-FM Radio |
| o Magnetic Compass | o UHF-AM Radio 1 |
| o INS | o UHF-AM Radio 2 |
| o OMEGA | o IFF |
| o ILS 1 | o Secure Voice |
| o ILS 2 | o Public Address |
| o LF ADF | o Intercommunication Set |
| o UHF ADF | |

The Avionics On/Off EQUIP is activated by the Avionics On/Off Tailored Mode SPEC whenever On/Off control is requested from the IMK.

3.2.5.30.1 Inputs

Input shall consist of

- o Equipment ID (1 word)
- o On/Off Control (1 word)

3.2.5.30.2 Processing

The EQUIP shall generate the on (or off) message and store in a Compool for subsequent transfer to the specified device.

3.2.5.30.3 Outputs

Output shall consist of

- o On/Off Command (1 word)

3.2.5.31 FDR Equipment Process

The Flight Data Recorder (AN/ASH-31V) is a survivable recorder used for storing a current 30-minute history of voice communications and flight data. A beacon transmitter facilitates recovery after deployment.

The FDR EQUIP is activated cyclically TBD times per second.

3.2.5.31.1 Inputs

Input shall be Compool data to be recorded.

- o Data (n words)

3.2.5.31.2 Processing

At each activation, the FDR EQUIP shall format two channels of data and store it in a Compool for transfer to the FDR.

3.2.5.31.3 Outputs

Output shall be data to be sent to FDR.

- o Data (n words)

3.2.6 Special Requirements

This section contains special requirements imposed on Application Software development.

3.2.6.2 JOVIAL J73

All Applications Software will be coded in the JOVIAL J73 higher order language.

3.2.6.1 Structured Programming

Top-down, structured programming concepts will be used throughout Applications Software development. Software elements will be established which correspond to functions defined in this document.

3.3 Adaptation

This section summarizes the Applications Software requirements with respect to the operating facility, system parameters, and system capacities.

3.3.1 General Environment

Further definition of the IDAMST system design is required prior to completing this portion of the specification. Pending definition the following assumptions are made.

3.3.1.1 IDAMST Core Elements

IDAMST core element hardware including the core element control/displays are assumed to be identical in all AMST aircraft and require no modification or variations in software to adapt the IDAMST OFP and OTP software.

3.3.1.2 Other IDAMST Integrated Hardware

Variations in AMST equipment complement associated with the IDAMST system is expected. It is assumed that the IDAMST OFP and OTP software will be automatically adaptable to hardware variations in the AMST. This will be accomplished through the use of an equipment status word from the IDAMST avionic hardware which identifies the existing hardware configuration. The OFP and OTP software will subsequently adapt to the actual configuration by omitting software functions associated with non-existent avionics hardware elements. The OFP and OTP software will compile a list of active and installed avionic equipment hardware and display list upon command and also write list on DITS recorder for a maintenance record.

3.3.2 System Parameters

Constants and other data pertaining to the particular mission must be available at load time for the Application Software to function at full capability.

3.3.3 System Capacities

Estimated capacity requirements of the Applications Software is summarized in **Table 3.3-1**. These estimates are related to an IDAMST processor like that described in Reference 2.2(c), "Prime Item Product Fabrication Specification for DAIS Processor", and allow a 25% growth margin.

IDAMST Master Processor

	<u>INST</u>	<u>DATA</u>	<u>NOM</u> <u>EXEC.</u>
Top Level Control	7800	5854	304.4
Flight & Propulsion	1900	495	16.0
Communication	1515	339	1.6
Nav. & Guidance	4511	835	6.8
Aircraft System	3580	2200	52.9
Defense	230	29	
Misc	1500	300	
	<u>21136</u>	<u>10053</u>	<u>381.7</u>

IDAMST Monitor Processor

Top Level Control	7800	5470	210.0
Flight & Propulsion	1880	492	16.0
Communication	1515	339	1.6
Nav. & Guidance	4511	835	6.8
Aircraft System	3580	2200	52.9
Defense	230	29	
Misc	1500	300	
	<u>21016</u>	<u>9665</u>	<u>277.3</u>

IDAMST Remote Processor

Top Level Control	2500	2419	108
Flight & Propulsion	75	16	3.2
Nav. & Guidance	5210	431	14.0
Aircraft Systems	2700	326	7.1
Defense	25	6	
Misc	400	100	
	<u>10910</u>	<u>3298</u>	<u>132.3</u>

TABLE 3.3-1 IDAMST STORAGE/TIMING ESTIMATES

This page intentionally left blank.

4.0 QUALITY ASSURANCE PROVISIONS

This section identifies the basic method for accomplishing software verification.

4.1 Introduction

IDAMST CPCIs will incorporate top-down, structured concepts, described briefly below:

Structured Program

A structured program is a computer program constructed of a basic set of control logic figures which provide at least the following: Sequence of two or more operations, conditional branch to one of two operations and return repetition of an operation. A structured program has only one entry and one exit point. A path will exist from the entry to each node and from each node to the exit. In addition, certain practices are associated, such as indentation of source code to represent logic levels, use of intelligent data names and descriptive commentary.

Top-Down Programming

Top-down programming is the concept of performing in hierarchical sequence a detailed design, code, integration and test as concurrent operations.

Top-Down Structured Programs

A top-down structured program is a structured program with the additional characteristics of the source code being logically but not physically segmented in a hierarchical manner and only dependent on code already written. Control of execution between segments is restricted to transfers between vertically adjacent hierarchical segments.

Top-down coding and verification is an ordering of system development which allows for continual integration of the system parts as they are developed and provides for interfaces prior to the parts being developed. At each stage, the code already tested drives the new code, and only external data is required.

In top-down programming, the system is organized into a tree structure of segments. The top segments contain the highest level of control logic and decisions within the program, and either passes control to the next level segments or identifies the next level segments for in-line inclusions. The next level may include stubs. Stubs which are to be replaced eventually with running code may contain a "no operation" instruction or possibly a display statement to the effect that control has been received. The process of replacement of successively lower level stubs with operational code continues until all functions within a system are coded and verified.

In top-down coding and verification, the highest level element is coded first. Coding, checkout, and integration proceed down the hierarchy until the lowest levels have been integrated. This does not imply that all elements at a given level are developed in parallel. Some branches will intentionally be

developed early, e.g., to permit early training and early development of critical functions or hardware/software integration.

Many systems interfaces occur through the data base definition in addition to calling sequence parameters. Top-down programming requires that sufficient data definition statements be coded and that data records be generated before exercising any segment which references them. Ideally, this leads to a single set of definitions serving all the programs in a given application.

This approach provides the ability to evolve the product in a manner that maintains the characteristic of always being operable, extremely modular and always available for successive levels of testing that accompany the corresponding levels of implementation. Exception to the top-down coding and integration approach will be considered on a case-by-case basis.

Each computer program will be coded in a higher order language. Use of assembly or machine language will be restricted to coding of certain executive functions where the higher order language cannot be used.

Real Time Structured Programs

An additional complexity in the IDAMST system is the Real Time, asynchronous communication of structured programs as tasks. Tasks are also organized as a hierarchy. Each task has a Controller Task which is the only task permitted to schedule or cancel the lower level task. However, any task is permitted to activate any other task in IDAMST.

4.2 Computer Program Verification

Computer program verification is the process of determining whether the results of executing a computer program in a test environment agree with the specification requirements. Verification is usually only concerned with the logical correctness of the computer program (i.e., satisfying the functional/performance requirements) and may be a manual or a computer-based process (i.e., testing software by executing it on a computer).

The use of top-down structured programming techniques provide certain program characteristics that may lead to a simplification of the computer program verification process. Top-down integration of the program elements in a CPCI minimizes the use of complex driver routines and replaces them with actual program elements and simple program stubs. It also provides a system in which the computer program is continually being tested as successively lower levels of program elements are integrated and the interfaces between program elements are verified prior to the integration of the next lower level.

4.2.1 Program Element Tests

Program elements are coded in the sequence required for top-down integration. When coding and code review are completed, each program element shall be functionally tested in a stand-alone configuration by the programmer to assure that the element can be executed and that the specified functions are performed. Since program elements are small and are restricted to one entry point and one exit point, the test environment is relatively simple.

4.2.2 CPCI Integration Tests

Following successful completion of the Program Element Tests, the program elements are entered into the Computer Program Library where they are subjected to configuration control procedures. Controlled program elements are compiled/assembled, link-edited and the current CPCI version is made available for integration testing. Integration tests are dynamic tests designed to verify program functions and interfaces between program elements and with the data base. The result is a complete CPCI for which all design features have been verified.

The integration of program elements or tasks into the complete computer program shall be accomplished in a top-down sequence. The highest level elements which contain the highest level controller tasks shall be tested and integrated first. These tasks are the Master Sequencer, Configurator, Request Processor, and Subsystem Status Monitor. Testing and integration shall proceed down the hierarchy until all program elements (e.g., equipment interface functions), have been integrated and the design completely verified.

An important aspect of integration testing of IDAMST will be the invocation and synchronization of the tasks, since these functions do not fall under the structured programming rules.

4.2.3 Formal Software Testing

The purpose of formal testing is to confirm that the computer program performs the functions and satisfies the performance requirement contained in the software requirements specification. Formal testing consists of Preliminary Qualification Tests (PQT) and Formal Qualification Tests (FQT), and are conducted in accordance with Air Force approved test plans.

Pre-Qualification Testing (PQT)

PQT is an incremental process which provides visibility and control of the CPC development during the time period between the Critical Design Review and Formal Qualification Testing.

PQT consists of functional level tests, conducted at the development facility, and using Air Force approved test plans. These tests will use documented procedures, completed by the contractor, and submitted to the Air Force Sufficiently in advance of the scheduled test session to permit review and analysis. They will typically use controlled inputs specifically prepared for the test purpose.

A Pre-Qualification test will generally be conducted for each CPCI function. If a test's cost or time consumption estimates are significantly high, the test will be deferred to FQT unless it is time-critical or performance-critical to the development of the CPCI.

5.0 PREPARATION FOR DELIVERY

Not applicable.

6.0 NOTES

6.1 Growth Items

The specified growth items were evaluated and the impact to the IDAMST configuration was assessed.

6.1.1 Joint Tactical Information Distribution System (JTIDS)


The Joint Tactical Information Distribution System (JTIDS) is a digital, secure, jam-resistant, communication system for real-time command and control of combat operations. JTIDS is planned to interconnect the tactical and air defense elements of all services, including surface and airborne command, control, surveillance and intelligence centers, Navy ships and combat and support aircraft. JTIDS will provide a high degree of interoperability between data collection elements, combat elements and command and control centers within a military theater of operations. Precise signal time-of-arrival measurements, coupled with the transmission of emitter location, are used to generate a common grid coordinate system containing the location of all active net participants. The system uses Time Division Multiple Access (TDMA) to interconnect all system users into one common channel, or network, for distribution of information. Each authorized network element is allocated a dynamic number of transmit time slots within the network reporting cycle as needed for its mission. When not transmitting, each element monitors the transmissions of the other elements and extracts the information as needed. Since the system is nodeless, survivability is enhanced and the system exists as long as two or more elements exist.

The basic JTIDS system for any aircraft will receive, process and display information to the crew and collect, convert and format its own data for broadcast distribution to the net. The baseline JTIDS functions are shown in Figure 6.1-1.

As can be seen from Figure 6.1-1, the two obvious major categories are transmit and receive. Common to both of these functions are the elements of voice, relative navigation and Built-in-Test (BIT). A brief description of the remaining functional elements is contained in the following sections:

Transmit Manual: These are the functions that would require pilot actions in order to initiate transmission. Throughout this study, the functions under this category were deliberately limited due to the constraint of a two-man crew. The only two areas recommended are:

- o Mission Words - These elements are to provide key transmissions to command and control agencies. The messages would concern essential mission decisions.
- o Weather - This element would allow PIREPS from targets or critical rendezvous areas. The pilot would only initiate inputs for visibility, cloud cover and cloud height. The other elements under this function would automatically be formatted from the navigation computer.



BASELINE JTIDS TRANSMIT/RECEIVE FUNCTIONS

FIGURE 6.1-1

Transmit Automatic: These are the functions that would be transmitted automatically as long as the system is operating. The major elements are:

- o Radar (Air Target) - This transmission would provide the net information on a heretofore unknown hostile aircraft. The message would be sent only after the pilot has locked-on an airborne target that is not being reported on the JTIDS network.
- o RHAW - Any RHAW threat received that does not correlate with the threat signals being reported on the JTIDS net would constitute a new message to be formatted and transmitted.
- o Status - The elements under this function would automatically be transmitted, either continuously or intermittently, as the situation dictates.

Receive Tracks: All hostile, unknown and friendly tracks and positions are grouped under this major function. The elements would be received, stored and formatted for display upon pilot commands.

Receive Status: The functions in this category reflect formatted command messages and information concerning the status and weather of various areas of interest. These elements would also be received, stored and formatted for display upon pilot commands.

Unformatted: This category is for received messages that are free text alphanumeric and meet no structured format. The functional area of these messages cannot be categorized as they are unlimited as to content.

The JTIDS computational requirements were analyzed and assessed as follows:

	<u>Words</u>
JTIDS Network Processing	4,250
JTIDS Message Processing	2,925
JTIDS Message Control	1,525
JTIDS Self Test	1,200

Estimated throughput requirements = 110 KOPS.

It is recommended that the JTIDS function be implemented with a dedicated processor because of the computation requirements. Additionally, developmental efforts and interface requirements would be reduced with a dedicated processor.

Assuming a dedicated processor in the JTIDS system, the impact of interfacing JTIDS with the IDAMST system as a growth item is as follows:

- o Data link between JTIDS and IDAMST processors via the multiplexed data bus.
- o IMK and DEK functions will have to be expanded to include JTIDS manual data entry functions.

- o JTIDS display requirements will have to be incorporated into the IDAMST specified displays. Displays requirements fall within three categories: 1) command data; 2) MAP data; and 3) miscellaneous mission data.
- o IDAMST navigation subfunction will have to be modified to utilize the relative navigation capability of the JTIDS system. The accuracy of JTIDS data will be dependent upon the accuracy of the transmitted position and relative navigation calculation. The expected error of the JTIDS mechanization is expected to be insignificant; therefore, JTIDS relative navigation data may be used for updating if JTIDS station positions are accurately known.

6.1.2 Terrain Following/Terrain Avoidance (TF/TA)

A limited TF/TA capability is reflected in the ground proximity warning system mechanization which utilizes radar altimeter data and barometric altitude rate. For a truly effective TF/TA system mechanization, a forward looking, TF/TA type radar is required to sense the terrain over which the airplane is expected to fly. Assuming that some type of TF/TA radar would be installed to provide TF/TA capability, the following will be required to integrate TF/TA capability into the IDAMST configuration:

- o TF/TA radar system control panel requirements have to be allocated to IMK functions or dedicated control panels.
- o TF/TA radar display data would be interfaced with the digital scan converter for formatting compatible with IDAMST CRT display devices.
- o Interface between TF/TA radar and avionics system would include stabilization data to TF/TA radar, TF command data for input to the flight director command calculations for display.
- o TF command data to the flight controls would be routed directly to the flight control system to minimize data lag to enable close coupling with the flight control system.

6.1.3 Global Positioning System (GPS)

The Global Positioning System (GPS) is a satellite navigation system currently in development by the Department of Defense. In its operational deployment, 24 satellites will be orbited at about 11,000 nautical miles to provide Earth coverage for navigation and weapon delivery. At least six satellites will be in view from any location. The satellites will broadcast their identity, position, and highly accurate time. User equipment will select the four most appropriate satellites and solve four equations in four unknowns to display to the user his position in three dimensions and time.

It is presently anticipated that the GPS will be developed as a TACAN hardware replacement with installation and interface requirements to be compatible with the AN/ARN 118 TACAN set. The GPS system will be self-contained with a dedicated processor in the GPS system. A dedicated processor will minimize GPS developmental activities in individual applications by specifying a standard computer interface. Integrating the GPS into the IDAMST configuration will have the following impact:

- o GPS controls and status will have to be integrated into the IMK functions.
- o Data link between GPS and IDAMST processors via the multiplexed data bus. Hardware impact to be minimal if TACAN provisions are utilized.
- o IDAMST navigation subfunction will have to be modified to utilize the GPS data, position and velocity, in determining the aircraft position. The expected accuracy of 100 meters of the low cost GPS will increase the operational capability of the IDAMST configuration.
- o Advanced GPS concepts to provide higher anti-jam capability if required, for the AMST airplane, will increase interface requirements for directional antenna and inertial reference information.

10.0 APPENDIX I: HARDWARE/SOFTWARE SIGNAL LIST

The functional interface between avionics hardware and the mission software is defined in terms of a hardware/software interface. The hardware involved in this interface is listed below:

- Air/Ground System
- Approach Indicating System
- Fire Warning System
- Automatic Braking System
- Flight Surfaces Status System
- Fuel Measurement System
- Avionics Power Control Logic System
- Engine Transducers
- Master Caution System
- Flight Control/Avionics Subsystems
- Long Range Radar
- Radar Altimeters
- Magnetic Compass
- Inertial Navigation System
- OMEGA Navigation System
- Public Address System
- HF/SSB Radio
- VHF/FM Radio
- UHF/AM Radio
- Intercommunication Set
- UHF/AM Radio
- Instrument Landing Systems
- LF ADF
- Intraformation Positioning Set (SKE)
- TACAN
- UHF ADF
- Infrared Detection and Warning System
- Flares Dispenser Unit
- Radar Homing and Warning System
- IDAMST Controls and Displays
- IDAMST Core Elements

A detailed signal-by-signal printout for each hardware system is provided with the following data available from each signal.

INPUT: Signals originating in the avionic hardware

OUTPUT: Signals originating in the mission software

SIGNAL NAME: Brief description of signal

SIGID: Signal identification number - used for bookkeeping purposes

TYPE: Characteristic of signal interface

- 01 single ended discrete
- 02 differential discrete
- 03 switch closure open/gnd
- 04 switch closure open 28V
- 05 single ended dc analog
- 06 differential dc analog
- 07 single ended ac analog
- 08 differential ac analog
- 09 synchro
- 10 serial digital
- 11 pulse converter
- 18 resolver

VOLTAGE RANGE: The electrical voltage minimum and maximum

PARAMETER RANGE: The particular parameter characteristics minimum and maximum

SCALE FACTOR: The parameter relation to the electrical range

RESOLUTION: The percent accuracy of the signal

QUANTIZATION: The number of bits to which the signal is resolved

U/R: The signal update rate is a per second quantity

B/R: The bit rate is the total number of bits per second

The hardware/software interfaces were obtained by examining each hardware unit and listing its characteristics when the following conditions were satisfied:

- o Avionic hardware signals which interfaces with other avionic hardware located in subsystems other than its own.
- o Avionic hardware signals which interface with mission software.
- o Mission software signals which interface with avionic hardware, including controls and displays.

SIGNAL NAME	1	1	0	AIR/GROUND SYSTEM	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	IMPIIT
LOG GEAR SCAUSS)					4316	3					1	1	1	1
SEE LOG PAPER					2700	4	OPEN OR 2AVDC				1	2	2	2
LOG GEAR 03 POS-01					1009	3					1	1	1	1
LOG GEAR 03 POS-02					1010	3					1	1	1	1
LOG GEAR 03 POS-01					1011	3					1	1	1	1
LOG GEAR 03 POS-02					1012	3					1	1	1	1

1	2	0	APPROACH INDICATING SYSTEM*	OUTPUT		
				QUAN	U/R	B/R
STICK NAME	SIGID	TYPE	VOLTAGE RANGE	PAPER-TO-TER RANGE	SCALE FACTOR	RESOLUTION
STICK SWAYER 1	2001	3			1	0 0
STICK SWAYER 2	2002	3			1	0 0

SIGNAL NAME	I	P	FIEE AND SPCKE REVECTION SYSTEM	STAGE	TIME	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	INPUT		
										QUAN	U/R	B/R
ENGINE 1 LOOP A				8001	4					1	2	2
ENGINE 1 LOOP F				8003	4					1	2	2
ENGINE 2 LOOP A				8005	4					1	2	2
ENGINE 2 LOOP B				8007	4					1	2	2
ENGINE 1 LOOP A				8002	4					1	2	2
ENGINE 1 LOOP B				8004	4					1	2	2
ENGINE 2 LOOP A				8006	4					1	2	2
ENGINE 2 LOOP B				8008	4					1	2	2

1 10 0	AUTOMATIC BRAKING SYSTEM			INPUT					
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QVAN	U/R	R/R
ENVI 0410	10001	1					1	1	1
ENVI 0411	10002	3					1	1	1
ENVI 0412	10003	3					1	1	1

1 11 0		FLIGHT SURFACE STATUS SYSTEM			INPUT				
SIGNAL NAME	STGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
STABILIZER TRIP	11002	3					1	2	2
STABILIZER TRIP	11001	3					1	2	2
ELFV POS -	11017	18					14	16	224
ELFV POS +	11018	18					14	16	224
NOSE POS	11019	18					14	16	224
LE FLP EXT AH	11000	3					1	1	1
LE FLP EXT BH	11010	3					1	1	1
LE FLP EXT AL	11011	3					1	1	1
LE FLP EXT BL	11012	3					1	1	1
OUTBOARD FLP POS(L)	11007	18					14	16	224
WT FLP POS (L)	11004	18					14	16	224
US LEFT	11005	18					14	16	224
SPOILER 1L POS	11020	18					14	16	224
SPOILER 2L POS	11021	18					14	16	224
LE FLP INT ER	11013	3					1	1	1
LE FLP INT EP	11014	3					1	1	1
LE FLP INT EL	11015	3					1	1	1
LE FLP INT FL	11016	3					1	1	1
CUTBACK FLP POS(R)	11006	18					14	16	224
WT FLAP POS(R)	11007	18					14	16	224
US RIGHT	11006	18					14	16	224
SPOILER 1R POS	11022	18					14	16	224
SPOILER 2R POS	11023	18					14	16	224

1 12 0 FUEL CG MEASUREMENT SYSTEM		INPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/K	R/R
FUEL IN 1	12001	S	0-24.5 VDC				11	8	88
FUEL IN 2	12002	B	0-24.5 VDC				11	9	88
FUEL IN 3	12003	C	0-24.5 VDC				11	8	88
FUEL IN 4	12004	F	0-24.5 VDC				11	8	88
FUEL IN 5	12005	F	0-24.5 VDC				11	8	88

AVIONICS POWER CONTROL LOGIC SYSTEM									
SIGNAL NAME	SIG#	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	SIAM	U/R	B/R
RPC STATUS	111	13002	3				1	0	0
RPC STATUS	114	13004	3				1	0	0
RPC STATUS	116	13006	3				1	0	0
RPC STATUS	115	13008	3				1	0	0
RPC STATUS	117	13010	3				1	0	0
RPC STATUS	123	13012	3				1	0	0
RPC STATUS	126	13014	3				1	0	0
RPC STATUS	111	13016	3				1	0	0
RPC STATUS	112	13018	3				1	0	0
RPC STATUS	112	13020	2				1	0	0
RPC STATUS	112	13022	3				1	0	0
RPC STATUS	115	13024	3				1	0	0
RPC STATUS	113	13026	3				1	0	0
RPC STATUS	113	13028	3				1	0	0
RPC STATUS	112	13030	3				1	0	0
RPC STATUS	113	13032	3				1	0	0
M1 RPC STATUS	13034		3				1	0	0
M2 RPC STATUS	13036		3				1	0	0
EGT RPC STATUS	13038		3				1	0	0
OIL RPC STATUS	13040		3				1	0	0
CIL RPC STATUS	13042		3				1	0	0
FF RPC STATUS	13044		3				1	0	0
ARC RPC STATUS	13046		3				1	0	0
AL RPC STATUS	13048		3				1	0	0
M2 RPC STATUS	13050		3				1	0	0
EGT RPC STATUS	13052		3				1	0	0
CIL RPC STATUS	13054		3				1	0	0
CIL RPC STATUS	13056		3				1	0	0

1 11 0 AVIONICS POWER CONTROL LOGIC SYSTEM									
SIGNAL NAME	SIG10	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT	QUAN	U/R	B/R
EP STATUS	13058	3					1	0	0
EP1 STATUS	210 13060	3					1	0	0
EP2 STATUS	210 13062	3					1	0	0
EP3 STATUS	210 13064	3					1	0	0
EP4 STATUS	210 13066	3					1	0	0
EP5 STATUS	210 13068	3					1	0	0
EP6 STATUS	250 13070	3					1	0	0
EP7 STATUS	270 13074	3					1	0	0
EP8 STATUS	210 13072	3					1	0	0
EP9 STATUS	230 13076	3					1	0	0
EP10 STATUS	240 13078	3					1	0	0
EP11 STATUS	240 13080	3					1	0	0
EP12 STATUS	240 13082	3					1	0	0
EP13 STATUS	250 13084	3					1	0	0
EP14 STATUS	430 13086	3					1	0	0
EP15 STATUS	250 13088	3					1	0	0
EP16 STATUS	260 13092	3					1	0	0
EP17 STATUS	311 13094	3					1	0	0
EP18 STATUS	320 13096	3					1	0	0
EP19 STATUS	330 13098	3					1	0	0
EP20 STATUS	340 13100	3					1	0	0
EP21 STATUS	360 13102	3					1	0	0
EP22 STATUS	370 13104	3					1	0	0
EP23 STATUS	380 13106	3					1	0	0
EP24 STATUS	340 13108	3					1	0	0
EP25 STATUS	391 13110	3					1	0	0
EP26 STATUS	392 13112	3					1	0	0

1 11 0 AVIONICS POWER CONTROL LOGIC SYSTEM INPUT

SIGNAL NAME	SIGID	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RPC STATUS	411	13114	3			1	0	0
RPC STATUS	411	13116	3			1	0	0
RPC STATUS	420	13114	3			1	0	0
RPC STATUS	420	13120	3			1	0	0
RPC STATUS	430	13122	3			1	0	0
RPC STATUS	430	13124	3			1	0	0
RPC STATUS	450	13126	3			1	0	0
RPC STATUS	460	13128	3			1	0	0
RPC STATUS	460	13132	3			1	0	0
RPC STATUS	460	13132	3			1	0	0
RPC STATUS	470	13134	3			1	0	0
RPC STATUS	480	13136	3			1	0	0
RPC STATUS	480	13138	3			1	0	0
RPC STATUS	480	13140	3			1	0	0
RPC STATUS	511	13142	3			1	0	0
RPC STATUS	512	13144	3			1	0	0
RPC STATUS	513	13146	3			1	0	0
RPC STATUS	514	13148	3			1	0	0
RPC STATUS	520	13150	3			1	0	0
RPC STATUS	531	13152	3			1	0	0
RPC STATUS	5CP	13154	3			1	0	0
RPC STATUS	1MK	13155	3			1	0	0
RPC STATUS	1MK	13158	3			1	0	0
RPC STATUS	1MK	13160	3			1	0	0
RPC STATUS	1MK	13162	3			1	0	0
RPC STATUS	LSW	13164	3			1	0	0
RPC STATUS	GEN	13166	3			1	0	0
RPC STATUS	DEF	13168	3			1	0	0

1 14 0 AVIONICS POWER CONTROL LOGIC SYSTEM										INPUT	
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R		
APC STATUS	MM4	13170	3				1	0	0		
APC STATUS	SYM	13172	3				1	0	0		
APC STATUS	MPDG1	13174	3				1	0	0		
APC STATUS	MMGG2	13176	3				1	0	0		
APC STATUS	SCAU	13178	3				1	0	0		
APC STATUS	APD1	13180	3				1	0	0		
APC STATUS	APD2	13182	3				1	0	0		
APC STATUS	APD3	13184	3				1	0	0		
APC STATUS	APD1	13186	3				1	0	0		
APC STATUS	APD2	13188	3				1	0	0		
APC STATUS	ASD1	13190	3				1	0	0		
APC STATUS	ASD2	13192	3				1	0	0		
APC STATUS	AFDC	13194	3				1	0	0		
APC STATUS	MMU	13196	3				1	0	0		
APC STATUS	MMU	13198	3				1	0	0		
APC STATUS	IMK	13200	3				1	0	0		
APC STATUS	IMK	13202	3				1	0	0		
APC STATUS	IMK	13204	3				1	0	0		
APC STATUS	IMK	13206	3				1	0	0		
APC STATUS	OSMU	13208	3				1	0	0		
APC STATUS	DEK	13210	3				1	0	0		
APC STATUS	DEK	13212	3				1	0	0		
APC STATUS	MMK	13214	3				1	0	0		
APC STATUS	SYM	13216	3				1	0	0		
APC STATUS	MPDG1	13218	3				1	0	0		
APC STATUS	MMDS2	13220	3				1	0	0		
APC STATUS	SCAU	13222	3				1	0	0		
APC STATUS	APD1	13224	3				1	0	0		

1 11 0 AVIONICS POWER CONTROL LOGIC SYSTEM

SIGNAL NAME	STGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R
RPC STATUS	*PD2	13226	3				1	0	0
RPC STATUS	*PD3	13229	3				1	0	0
RPC STATUS	*PD1	13230	3				1	0	0
RPC STATUS	*PD2	13232	3				1	0	0
RPC STATUS	*SD1	13234	3				1	0	0
RPC STATUS	*SD2	13236	3				1	0	0
RPC STATUS	*FDL	13238	3				1	0	0

1 13 0 AVIONICS POWER CONTROL LOGIC SYSTEM*									
SIGNAL NAME	STGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
28 VCC RPE CTL 111	13001	1					1	0	0
28 VCC RPE CTL 114	13003	1					1	0	0
28 VCC RPE CTL 116	13005	1					1	0	0
28 VCC RPE CTL 115	13007	1					1	0	0
28 VCC RPE CTL 117	13009	1					1	0	0
28 VCC RPE CTL 123	13011	1					1	0	0
28 VCC RPE CTL 125	13013	1					1	0	0
28 VCC RPE CTL 1111	13015	1					1	0	0
28 VCC RPE CTL 1112	13017	1					1	0	0
28 VCC RPE CTL 1112	13019	1					1	0	0
28 VCC RPE CTL 1112	13021	1					1	0	0
28 VCC RPE CTL 1113	13023	1					1	0	0
28 VCC RPE CTL 1113	13025	1					1	0	0
28 VCC RPE CTL 1113	13027	1					1	0	0
28 VCC RPE CTL 1122	13029	1					1	0	0
28 VCC AVI RPE CTL	13031	1					1	0	0
28 VCC AVI RPE CTL	13033	1					1	0	0
28 VCC AVI RPE CTL	13035	1					1	0	0
28 VCC EST RPE CTL	13037	1					1	0	0
28 VCC CTL RPE CTL	13039	1					1	0	0
28 VCC CTL RPE CTL	13041	1					1	0	0
28 VCC FF RPE CTL	13043	1					1	0	0
28 VCC AVI RPE CTL	13045	1					1	0	0
28 VCC AVI RPE CTL	13047	1					1	0	0
28 VCC AVI RPE CTL	13049	1					1	0	0
28 VCC EST RPE CTL	13051	1					1	0	0
28 VCC CTL RPE CTL	13053	1					1	0	0
28 VCC CTL RPE CTL	13055	1					1	0	0

1 11 0 AVIONICS POWER CONTROL LOGIC SYSTEM		OUTPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
23 VDC SF RPC CTL	13057	1					1	0	0
304 115VAC RPC CTL	13059	1					1	0	0
24 VDC RPC CTL 210	13061	1					1	0	0
26 VDC RPC CTL 210	13063	1					1	0	0
304 115VAC RPC CTL	13065	1					1	0	0
304 115VAC RPC CTL	13067	1					1	0	0
304 115VAC RPC CTL	13069	1					1	0	0
23 VDC RPC CTL 240	13073	1					1	0	0
24 115VAC RPC CTL	13071	1					1	0	0
24 VDC RPC CTL 230	13075	1					1	0	0
304 115VAC RPC CTL	13077	1					1	0	0
25 VDC RPC CTL 240	13079	1					1	0	0
23 VDC RPC CTL 240	13081	1					1	0	0
304 115VAC RPC CTL	13083	1					1	0	0
24 VDC RPC CTL 250	13085	1					1	0	0
26 VDC RPC CTL 250	13097	1					1	0	0
304 115VAC RPC CTL	13089	1					1	0	0
24 VDC RPC CTL 260	13091	1					1	0	0
24 VDC RPC CTL 311	13093	1					1	0	0
304 115VAC RPC CTL	13095	1					1	0	0
24 VDC RPC CTL 330	13097	1					1	0	0
25 VDC RPC CTL 340	13099	1					1	0	0
28 VDC RPC CTL 360	13101	1					1	0	0
24 VDC RPC CTL 370	13103	1					1	0	0
26 VDC RPC CTL 380	13105	1					1	0	0
115 VDC RPC CTL 380	13107	1					1	0	0
24 VDC RPC CTL 391	13109	1					1	0	0
23 VDC RPC CTL 392	13111	1					1	0	0

INPUT NAME	UNIT	SCALE	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	CHAN	U/R	P/R
28	00	000	CTL	411	13113	1		1	0	0
29	00	000	CTL	411	13115	1		1	0	0
24	00	000	CTL	420	13117	1		1	0	0
25	00	000	CTL	420	13119	1		1	0	0
30	00	000	RPC	CTL	13121	1		1	0	0
24	00	000	CTL	430	13123	1		1	0	0
25	00	000	CTL	450	13125	1		1	0	0
24	00	000	CTL	460	13127	1		1	0	0
25	00	000	CTL	460	13129	1		1	0	0
13	00	000	CTL	460	13131	1		1	0	0
25	00	000	CTL	470	13133	1		1	0	0
24	00	000	CTL	480	13135	1		1	0	0
25	00	000	CTL	480	13137	1		1	0	0
13	00	000	CTL	480	13139	1		1	0	0
24	00	000	CTL	511	13141	1		1	0	0
25	00	000	CTL	512	13143	1		1	0	0
24	00	000	CTL	513	13145	1		1	0	0
25	00	000	CTL	514	13147	1		1	0	0
25	00	000	CTL	520	13149	1		1	0	0
13	00	000	CTL	531	13151	1		1	0	0
24	00	000	CTL	SCP	13153	1		1	0	0
13	00	000	CTL	IPK	13155	1		1	0	0
13	00	000	CTL	IPK	13157	1		1	0	0
24	00	000	CTL	IPK	13159	1		1	0	0
24	00	000	CTL	IPK	13161	1		1	0	0
30	00	000	RPC	CTL	13163	1		1	0	0
24	00	000	CTL	CEK	13165	1		1	0	0
25	00	000	CTL	CPA	13167	1		1	0	0

1 13 0 AVIONICS POWER CONTROL LOGIC SYSTEM										
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	OUTPUT	RESOLUTION	QUAN	U/R	Ø/R
28 100 R2C CTL MKK	13169	1						1	0	0
28 100 R2C CTL SYM	13171	1						1	0	0
3P- 115VAC R2C CTL	13173	1						1	0	0
3P- 115VAC R2C CTL	13175	1						1	0	0
3P- 115VAC R2C CTL	13177	1						1	0	0
3P- 115VAC R2C CTL	13179	1						1	0	0
3P- 115VAC R2C CTL	13181	1						1	0	0
3P- 115VAC R2C CTL	13183	1						1	0	0
3P- 115VAC R2C CTL	13185	1						1	0	0
3P- 115VAC R2C CTL	13187	1						1	0	0
3P- 115VAC R2C CTL	13189	1						1	0	0
3P- 115VAC R2C CTL	13191	1						1	0	0
28 100 R2C CTL AFDC	13193	1						1	0	0
28 100 R2C CTL WND	13195	1						1	0	0
28 100 R2C CTL WND	13197	1						1	0	0
115VAC R2C CTL IMK	13199	1						1	0	0
115VAC R2C CTL IMK	13201	1						1	0	0
28 100 R2C CTL IMK	13203	1						1	0	0
28 100 R2C CTL IMK	13205	1						1	0	0
3P- 115VAC R2C CTL	13207	1						1	0	0
28 100 R2C CTL DEK	13209	1						1	0	0
28 100 R2C CTL DEK	13211	1						1	0	0
28 100 R2C CTL MKK	13213	1						1	0	0
3P- 115VAC R2C CTL	13215	1						1	0	0
3P- 115VAC R2C CTL	13217	1						1	0	0
3P- 115VAC R2C CTL	13219	1						1	0	0
3P- 115VAC R2C CTL	13221	1						1	0	0
3P- 115VAC R2C CTL	13223	1						1	0	0

1 13 0 AVEONICS POWER CONTROL LOGIC SYSTEM		OUTPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
19L 115VAC RPC CTL	13225	1					1	0	0
19M 115VAC RPC CTL	13227	1					1	0	0
19N 115VAC RPC CTL	13229	1					1	0	0
19P 115VAC RPC CTL	13231	1					1	0	0
19Q 115VAC RPC CTL	13233	1					1	0	0
19R 115VAC RPC CTL	13235	1					1	0	0
2A 100 RPC CTL WPC	13237	1					1	0	0

SIGNAL NAME	1 14 0	ENGINE TRANSDUCERS	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RFSOLUTION	QUAN	U/R	R/R	INPUT
ENG 1 REVERSER		14015	3						1	1	1	
ENG 1 #1		14005	11	0-5V					7	8	56	
ENG 1 #2		14007	11	45V					7	8	56	
ENG 1 EST		14009	6	0-400V					11	1	11	
ENG 1 OIL PRES		14013	6	0-17.9V					11	2	22	
ENG 1 OIL BIT		14011	8	6.6V					11	1	11	
FF 1 P		14003	6	0.4-97V					11	2	22	
FF 1 M PULSE		14001	11	0-1.5VDC					10	4	40	
ENG 1 OVERHEAT		14017	3						1	1	1	
ENG 1 AFT WACELLE		14019	3						1	1	1	
ENG 1 NOZZLE		14021	3						1	1	1	
ENG 2 REVERSER		14016	3						1	1	1	
ENG 2 #1		14006	11	0-5V					7	8	56	
ENG 2 #2		14008	11	43V					11	1	11	
ENG 2 EGT		14010	6	0-400V					11	2	22	
ENG 2 OIL PRES		14014	8	0.0-17.9V					11	1	11	
ENG 2 OIL BIT		14012	8	6.6V					11	2	22	
FF 1 P		14004	6	0.4-97V					10	4	40	
FF 1 M PULSE		14002	11	0-1.5VDC					1	1	1	
ENG 2 OVERHEAT		14018	3						1	1	1	
ENG 2 AFT WACELLE		14020	3						1	1	1	
ENG 2 NOZZLE		14022	3						1	1	1	

1 15 0 MASTER CAUTION SYSTEM									
DIGITAL NAME	ICID TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
MASTER CAUTION (P)	15001	3				1	2	2	
REC (P)	15003	3				1	2	2	
ANTIFREEZE (P)	15004	3				1	2	2	
FUEL (P)	15005	3				1	2	2	
OVERHEAD AVIATION (P)	15006	3				1	2	2	
ELECTRICAL (P)	15007	3				1	2	2	
WATER LINE (P)	15009	3				1	2	2	
CENTER AISLE (P)	15009	3				1	2	2	
EPDS (P)	15010	3				1	2	2	
CAUTION RECALL (P)	15011	3				1	2	2	
MASTER CAUTION (C)	15002	3				1	2	2	
REC (C)	15013	3				1	2	2	
ANTIFREEZE (C)	15014	3				1	2	2	
FUEL (C)	15015	3				1	2	2	
OVERHEAD AVIATION (C)	15016	3				1	2	2	
ELECTRICAL (C)	15017	3				1	2	2	
WATER LINE (C)	15018	3				1	2	2	
CENTER AISLE (C)	15019	3				1	2	2	
EPDS (C)	15020	3				1	2	2	
CAUTION RECALL (C)	15021	3				1	2	2	

1 15 0	FLIGHT CTL/AVIONICS SUBSYSTEM	INPUT						
SIGNAL NAME	SIG. TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
TOTAL AIR TEMP.	16027	7				11	2	22
STATIC AIR TEMP.	16030	7				11	2	22
ADC FAIL	27110	1	0 OR 5 VDC	NA	0VDC=ADC OK 5VDC=ADC FAIL	1	0	0
EFCS WARNING (P)	16033	3				1	0	0
EFCS WARNING (C)	16036	3				1	0	0
AIR SPEED	16015	5				11	0	00
AIR SPEED	16016	5				11	0	00
VERTICAL VELOCITY	16022	5				11	0	00
MACH	16014	10				16	0	120
ALTITUDE	16020	10				16	0	120
TRIP AIRSPEED	27111	5		NA		11	32	352
BAROMETRIC ALT	27112	5	0 TO 4 VDC	110 KTS TO 600KT	12.75 FAIL/MV	11	32	352
MACH OUTPUT	27113	5	0 TO 4 VDC	1000 TO 50000 FT	0.19M/VOLT	11	32	352
AIR SPEED	28092	5	0 TO +2.2 VDC	0 TO -2.2 DEG	1VDC/10EG	11	32	352
AIR SPEED	28093	5	0 TO +15 VDC	0 TO 699 KTS	150MV/7KTS	11	32	352
AIR SPEED	28217	5	0 TO +2.2 VDC	0 TO -2.2 DEG	1VDC/10EG	11	32	352
AIR SPEED	28218	5	0 TO +15 VDC	0 TO 499 KTS	150MV/7KTS	11	32	352
TOT AIR SPEED	16024	9				14	32	440
CM AIR DA CPR OUT I	25037	10				32	32	1024
TOTAL AIR TEMP.	16028	7				11	2	22
STATIC AIR TEMP.	16031	7				11	2	22
EFCS WARNING (C)	16034	3				1	0	0
EFCS WARNING (P)	16037	3				1	0	0
AIR SPEED	16018	5				11	0	00
AIR SPEED	16019	5				11	0	00
VERTICAL VELOCITY	16023	5				11	0	00
MACH	16017	10				16	0	120
ALTITUDE	16021	10				16	0	120

1 15 0		FLIGHT CTL/AVIONICS SUBSYSTEM			INPUT				
SIGNAL NAME	STCID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
TOTAL AIR SPEED	16024	9					14	32	448
TOTAL AIR TEMP.	16029	7					11	2	22
STATIC AIR TEMP.	16032	7					11	2	22
DIFFERENTIAL PRESS.	16035	3					1	8	8
DIFFERENTIAL TEMP.	16038	3					1	8	8
TOTAL AIR TEMP.	16026	9					14	32	448

STEP NAME	1 15 0	FLIGHT CTR/AVIONICS SUBSYSTEM	OUTPUT					
			PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/A	B/A
STEP 1	16003	10				80	32	2560
STEP 2	16004	10				80	32	2560
STEP 3	16009	10				80	32	2560

TEST NAME	2	1	0	LOG RANGE	RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT	RESOLUTION	QJAN	U/R	B/R
					VOLTAGE RANGE							
DATA AC (TRACCOMP)	27092	10	0	OR 5 VDC	NA			NA		160	32	5120
DATA DC (TRACCOMP)	27093	10	0	OR 5 VDC	NA			NA		160	32	5120
DATA AD (TRACCOMP)	27094	10	0	OR 5 VDC	NA			NA		16	32	512
DATA AC (TRACCOMP)	27095	10	0	OR 5 VDC	NA			NA		16	32	512
DATA DC (TRACCOMP)	27096	10	0	OR 5 VDC	NA			NA		16	32	512
DATA AD (TRACCOMP)	27097	10	0	OR 5 VDC	NA			NA		16	32	512
DATA AC (TRACCOMP)	21163	3								1	4	4
DATA DC (TRACCOMP)	21164	3								1	4	4
DATA AD (TRACCOMP)	21165	3								1	4	4
DATA AC (TRACCOMP)	21166	3								1	4	4
DATA DC (TRACCOMP)	21167	3								1	4	4
DATA AD (TRACCOMP)	21168	3								1	4	4
TEST RELIABILITY	24057	1		OPEN OR +0.260 VDC	NA			OPEN=TF OK +380VDC=TF NO OK	NA	1	32	32
TEST RELIABILITY	24193	1		OPEN OR +0.380 VDC	NA			OPEN=TF OK +380VDC=TF NO OK	NA	1	32	32
TEST RANGE TEST	24037	4		OPEN OR 28VDC	NA			OPEN=NO RANGE 28VDC RANGE	NA	1	32	32
TEST RANGE TEST	24038	4		OPEN OR 28VDC	NA			OPEN=NO RANGE 28VDC RANGE	NA	1	32	32
TEST RANGE TEST	24173	4		OPEN OR 28VDC	NA			OPEN=NO RANGE 28VDC RANGE	NA	1	32	32
TEST RANGE TEST	24192	5		0 TO +2.2 VDC	0 TO +2.2 DEG			OPEN=NO RANGE 28VDC RANGE	NA	11	32	352
TEST RANGE TEST	21074	5						1VDC/DEF	NA	11	6	80
TEST RANGE TEST	21093	9		0 TO 11.0 VAC					NA	14	64	696

2	1	0	UNIT RANGE	SCALE RANGE	SCALE FACTOR	RESOLUTION	QUAM	U/R	R/R
21075	3	0	VDC				1	4	4
21076	3	0	VDC				1	4	4
21077	3	0	VDC				1	4	4
21078	3	0	VDC				1	4	4
21079	3	0	VDC				1	4	4
21080	3	0	VDC				1	4	4
21081	3	0	VDC				1	4	4
21082	3	0	VDC				1	4	4
21083	3	0	VDC				1	4	4
21084	5	+1.2 TO -3.9	VDC				11	16	176
21085	5						11	16	176
21086	5						11	16	176
21087	5						1	4	4
21088	3	0	VDC				1	4	4
21089	3	0	VDC				1	4	4
21090	3	0	VDC				1	4	4
21091	3	0	VDC				1	4	4
21092	3						1	4	4
21093	3						1	4	4
21094	3						1	4	4
21095	3						1	4	4
21096	3						1	4	4
21097	3						1	4	4
21098	3						1	4	4
21099	3						1	4	4
21100	3						1	4	4
21101	3						1	4	4
21102	3						1	4	4
21103	3						1	4	4
21104	3						1	4	4
21105	3						1	4	4
21106	3						1	4	4
21107	3						1	4	4
21108	3						1	4	4
21109	3						1	4	4
21110	3						1	4	4
21111	1	+5	VDC				1	4	4
21112	3						11	16	176
21113	3						11	16	176
21114	3	+4.3	VDC TO 0				11	16	176
21115	3	+3.0	VDC TO 0				11	16	176

2	1	0	LONG RANGE RADAR.....AN/AP-122	OUTPUT	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R
SYMBOL NAME	SYMBOL	TYPE	VOLTAGE RANGE							
15-DCND	21149	5						11	8	88
15-DCND	21151	5	-15 VDC TO 0					11	8	88
15-DCND	21152	5	+4.5 VDC TO 0					11	8	88
15-DCND	21141	7						11	8	88
NORTH STABILITY	21054	3						1	2	2
FULL (FOURSD) CND	21064	3	6 VDC					1	2	2
SCN (LEFT) (LEFT)	21057	3	28 VDC					1	2	2
SCN (RIGHT) (RIGHT)	21068	3	28 VDC					1	2	2
TRUCK STAB	21063	3	5 VDC					1	32	32
SECTION 1 (1) - SR	21045	8	-1.0V TO +1.2 VAC					11	32	352
SECTION 2 (2) - SCC	21046	6	0 TO 2.2 VAC					11	32	352
SECTION 3 (3) - SCUS	21044	18	0 TO 18 VDC					14	32	448
SECTION 4 (4) - SCV	21020	4	0 TO 26 VDC					1	2	2
SECTION 5 (5) - SCX,Y,Z	21014	9						14	16	224

SI	VAL	NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	Q/HAN	U/R	B/R
2	3	0	2302A	1	0 TO 5 VDC		0VDC=OK 5VDC=FAIL	NA	1	32	32
		MONITORED RELIABILITY	23031	5	0 TO 25 VDC	0-5000 FT	35MV/7FT	7 FEET	11	32	352
		LINERIALIZED ALTITUDE	23032	5	0 TO 25 VDC	0-5000 FT	35MV/7FT	7 FEET	11	32	352
		RAWR ALTITUDE	23027	5	0 TO +25 VDC	0 TO 5,000 FT	35MV/7FEET	7 FEET	11	32	352
		MONITORED RELIABILITY	23066	1	0 TO 5 VDC		0VDC=OK	NA	1	32	32
		LINERIALIZED ALTITUDE	23069	5	0 TO 25 VDC	0-5000 FT	35MV/7FT	FEET	11	32	352
		LINERIALIZED ALTITUDE	23070	5	0 TO 25 VDC	0-5000 FT	35MV/7FT	FEET	11	32	352
		RAWR ALTITUDE	23163	5	0 TO +25 VDC	0 TO 5,000 FT	35MV/7FEET	7 FEET	11	32	352

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	CHAN	U/R	B/R
2 0 0	PADAR	ALTIMETERSAN/APN-1M1 (2)						
SELF TEST	23033	3	GROUND	MA	OPEN=NO SELF TST GND=SELF TST INI	MA	1	8	8

2 3 0 MAGNETIC COMPASS.....C-12

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
PILOT HSI (F)	24028	9					14	0	112
PILOT R34I	B 24119	9					14	0	112
COPILLOT 4JI (F)	24149	9					14	0	112
COPILLOT 3D-1 B	24219	9					14	0	112

2 5 6 INERTIAL NAVIGATION SYSTEM				INPUT					
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
HEADS UP DISPL IN	25015	10					200	2	416
WAY LEADING BAR	25029	1	+28 VDC		28VDC=TRUE		1	4	4
RANGE TO DEST DITS	25023	9		0/9		1/2 MILE PR	14	4	56
RANGE TO DEST TRPS	25024	9		0/90			14	4	56
RANGE TO DEST HOURS	25025	9		0/900			14	4	56
DEST SEL BEARING	25026	9		0/360 DEG	1DEG=1DEG	5 DEG	14	4	56
DEST AZIMUTH	25027	9		0/360 DEG	1DEG=1DEG	5 DEG	14	4	56
ATTIT SEL 3002	25022	1	A/±28 VDC		28VDC=TRUE		1	0	0
REFLECT/ERR	26002	10					32	16	512
SYSTEM ERROR	25030	5		±-10 DEG	150 UA/10 DEG	1/16 DISP	11	32	352
PLAC	25018	9		0/360 DEG	1DEG=1DEG	0.1 DEG R*5	14	32	448
BTCH	25021	9		±-90 DEG	1DEG=1DEG	0.1 DEG R*5	14	64	896

SIGNAL NAME	2	5	0	INERTIAL NAVIGATION SYSTEM	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
I'S POWER ON					25009	1			6ND=TRUE		1	2	2
ATTITUDE MODE					25010	1	26 VDC		28VDC=TRUE		1	2	2
FL CTL 'AV PRL OUT 1					25002	10					64	6	512
CM STR GA CPM OUT 1					25007	10					32	32	1024

2 5 0 OMEGA NAVIGATION SYSTEM		INPUT		QUAN	U/R	B/R
SIGNAL NAME	STIC TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	
OMEGA DISPLAY(P)	26003	10			192	2 384
OMEGA DISPLAY(O)	26004	10			192	2 384

SIGNAL NAME	2	5	C	OMEGA NAVIGATION SYSTEM			OUTPUT					
				SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
OMEGA SYSTEM CLK				26005	4					1	0	0
HEADING/CHT				26002	10					32	16	512
TRUE AIRSPEED				26001	9					14	16	224

SIGNAL NAME	3	2	0	HF/SSB RADIO...AM/ARC=12*	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	P/R
WT 513					32026	2	-5 VDC/+10 VDC		-5VDC=R/+10VDC=X		1	2	2
WT 173					32027	2	+10 VDC/-5 VDC		-5VDC=R/+10VDC=X		1	2	2

SIGNAL NAME	5	2	0	HF/SSB RADIO...ARC=123	STID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R	OUTPUT
ANT CPLR BAND 1					32001	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 2					32002	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 3					32003	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 4					32004	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 5					32005	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 6					32006	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 7					32007	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANT CPLR BAND 8					32008	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ANTENNA PULSE					32009	2	+10 VDC/GND		GND=1/OPEN=0		1	2	2	
ANTENNA PULSE					32010	2	+10 VDC/GND		+10VDC=1/0VDC=0		1	2	2	
AMP/PS BAND 1					32009	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 2					32010	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 3					32011	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 4					32012	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 5					32013	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 6					32014	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 7					32015	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 8					32016	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 9					32017	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 10					32018	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
SSM					32019	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AME					32020	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
FSH					32021	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
GA					32018	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
GUARDED 4 BANDSW					32040	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
GUARDED 3 BANDSW					32041	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
PAVEL LIGHTS					32022	4	OPEN/-5 VDC		-5VDC=1/OPEN=0		1	2	2	
NOISE PULS CONTROL					32024	5	+10 VDC/-5 VDC				11	2	22	

SIGNAL NAME	3	2	0	PF/SSR PART NO.AN/ARC-123	SIGIC	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RF GAIN CONTROL					32029	5	+10 VDC/+5 VDC				11	2	22
STAGE 1 FM CONTROL					32030	5	+10 VDC/+5 VDC				11	2	22
VARIABLE TUNING VOLTAGE					32033	5	+11 VDC/+5 VDC				11	2	22
FAULT TUNING VOLTAGE					32034	5	+11 VDC/+5 VDC				11	2	22
VOLUME CONTROL					32035	0	-5 VDC/0 VDC				11	2	22

AD-A083 113

BOEING AEROSPACE CO SEATTLE WA BOEING MILITARY AIRPL--ETC F/6 9/2
COMPUTER PROGRAM DEVELOPMENT SPECIFICATION FOR IDAMST OPERATION--ETC(U)
NOV 76 F33615-76-C-1099
SPEC-SB-4042 AFAL-TR-76-208-ADD-2 NL

UNCLASSIFIED

3 of 3
AD-A083 113

END
DATE
FILED
5 80
DTIC

3	3	0	VHF/FM RADIO....FM-622	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
			TO-F SQUELCH GROUND	33001	3	OPEN OR GROUND	NA	OPEN=NO SQUELCH	NA	1	0	0
			SQUELCH DISABLE GND	33002	3	OPEN OR GROUND	NA	GND=SQUELCH	NA	1	0	0
			0.05 MC SELECT E	33005	3	OPEN OR GROUND	NA	OPEN=NO DISABLE	NA	1	0	0
			0.05 MC SELECT L	33006	3	OPEN OR GROUND	NA	GND=DISABLE	NA	1	0	0
			0.05 MC SELECT C	33007	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			0.05 MC SELECT B	33008	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
			0.05 MC SELECT A	33009	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			BAUC A 30-52 MC	33010	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
			BAUC B 53-76 MC	33011	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			MC SELECT E	33012	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
			MC SELECT C	33013	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			MC SELECT D	33014	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
			MC SELECT 3	33015	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			MC SELECT 4	33016	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
			R/P/R COUNT	33031	3	OPEN OR GROUND	NA	OPEN=NO SELECT	NA	1	0	0
			VHF PRESS-TO-TALK	33033	3	OPEN OR GROUND	NA	GND=SELECT	NA	1	0	0
								GND=NARROW	NA	1	0	0
								GND=WIDE	NA	1	0	0

SIGNAL NAME	3	4	0	VHF/AM RADIO...HILCOX 807	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	OUTPUT
10MHz FREQ SEL	2004	34001	1	0/1							1	2	2	
10MHz FREQ SEL	2003	34002	1	0/1							1	2	2	
10MHz FREQ SEL	2002	34003	1	0/1							1	2	2	
10MHz FREQ SEL	1001	34004	1	0/1							1	2	2	
1MHz FREQ SEL	2005	34005	1	0/1							1	2	2	
1MHz FREQ SEL	2004	34006	1	0/1							1	2	2	
1MHz FREQ SEL	2003	34007	1	0/1							1	2	2	
1MHz FREQ SEL	2002	34008	1	0/1							1	2	2	
1MHz FREQ SEL	2001	34009	1	0/1							1	2	2	
0.1MHz FREQ SEL	2005	34010	1	0/1							1	2	2	
0.1MHz FREQ SEL	2004	34011	1	0/1							1	2	2	
0.1MHz FREQ SEL	2003	34012	1	0/1							1	2	2	
0.1MHz FREQ SEL	2002	34013	1	0/1							1	2	2	
0.1MHz FREQ SEL	2001	34014	1	0/1							1	2	2	
0.01MHz FREQ SEL	2005	34015	1	0/1							1	2	2	
0.01MHz FREQ SEL	2004	34016	1	0/1							1	2	2	
0.01MHz FREQ SEL	2003	34017	1	0/1							1	2	2	
0.01MHz FREQ SEL	2002	34018	1	0/1							1	2	2	
0.01MHz FREQ SEL	2001	34019	1	0/1							1	2	2	
0.005MHz FREQ SEL	2002	34020	1	0/1							1	2	2	
0.005MHz FREQ SEL	2001	34021	1	0/1							1	2	2	
FREQ SEL	COMP	34022	2	GND/OPEN							1	2	2	
SD DISABLE	COMP	TST	34023	3	GND/OPEN						1	2	2	
PEVCTE	ON/OFF	34024	4	0/277.5 VDC							1	2	2	

SIGNAL NAME	3 5 0	INTERCOMMUNICATION SET	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
FUSH-YO-TA-M			34025	3	GND/OPEN				1	2	2	
LMF PACIO CTRL			36093	3	OPEN 28V CLO GND				1	0	0	

3 6 0 INTERCOMMUNICATION SET

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	U/R	U/R
CTRL POS 5(UHF R)	36006	3	OPEN 28 V CLO GND				1	4	4	4
CTRL POS 3(UHF/AM)	36007	3	OPEN 28 V CLO GND				1	4	4	4
CTRL POS 7	36008	3	OPEN 28 V CLO GND				1	4	4	4
CTRL POS 4(UHF/SSH)	36009	3	OPEN 28 V CLO GND				1	4	4	4
CTRL POS 1 (SPARE)	36030	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 2(UHF R)	36057	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 7 (V-F/AM)	36060	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 7	36061	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 3 (HF/SSH)	36062	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 2(UHF/AM)	36075	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 1 (SPARE)	36054	3	OPEN 28V CLO GND				1	4	4	4
CTRL POS 1	36005	4	28 V				1	4	4	4
CTRL POS 2	36056	4	28 V				1	4	4	4

SIGNAL NAME	SIGID	TYPF	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	OUTPUT	QUAN	U/R	B/R
3 0 0 UMF RATIO...ARC-16									
SEARCH DISABLE	39017	3					1	2	2
*/	39018	3					1	2	2
POWER ON/OFF	39019	3					1	2	2
TOE KEY	39013	3					1	4	4
ADF ENABLE	39014	3					1	4	4
GUARD ON/OFF	39022	3					1	4	4
MY/GUARD INTLK OUT	39024	3					1	4	4
MY/GUARD INTLK IN	39025	3					1	4	4
PRESET FREQ HEAD	39026	3					1	4	4
MY/SAFE INTLCK	39016	4					2	4	4
ALT KEY	39021	3					1	6	6
MY/SEARCH ADJ HI	39003	6					11	6	66
MY/SEARCH ADJ CT	39004	6					11	6	66
CURR SW ADJ HI	39005	6					11	6	66
CURR SW ADJ CT	39006	6					11	6	66
SEARCH DISABLE	39064	3					1	2	2
*/	39065	3					1	2	2
POWER ON/OFF	39066	3					1	2	2
TOE KEY	39060	3					1	4	4
ADF ENABLE	39061	3					1	4	4
GUARD ON/OFF	39069	3					1	4	4
MY/GUARD INTLK OUT	39071	3					1	4	4
MY/GUARD INTLK IN	39072	3					1	4	4
PRESET FREQ HEAD	39073	3					1	4	4
MY/SAFE INTLCK	39063	4					1	4	4
MY KEY	39068	3					1	6	6
MY/SEARCH ADJ HI	39050	6					11	6	66
MY/SEARCH ADJ CT	39051	6					11	6	66

		UMF RADIO.....AM/ARC-16W		OUTPUT					
SIGNAL NAME	3 9 0	SIGID TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
GUARD SG ADJ HI		39052	6				11	0	AA
GUARD SG ADJ CT		39053	6				11	0	BB

SIGNAL NAME	UNIT	INSTRUMENT LANDING SYSTEM.....AN/APM-109 (2)	PARAMETER RANGE	VOLTAGE RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	D/R	INPUT
400 MZ MARKER BEACH	1069	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300MZ MKR REACT	1070	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000MZ MKR BEACH	1071	2	GND/OPEN		GND=1/OPEN=0		1	0	0	
400 -2 MARKER BEACH	1075	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300MZ MKR BEACH	1076	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000MZ MKR BEACH	1077	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
400 MZ MARKER BEACH	1081	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300 MZ MKR BEACH	1086	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000 MZ MKR BEACH	1089	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
400 MZ MARKER BEACH	1078	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300MZ MKR BEACH	1079	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000MZ MKR BEACH	1080	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
LOC INST DEVIATION	1025	6					11	32	352	
LOC FLAG OUTPUT	1026	6					11	32	352	
GS INSTR DEVIATION	1027	6					11	32	352	
GS FLAG OUTPUT	1028	6					11	32	352	
LOC DEVIATION	1029	6					11	32	352	
GS DEVIATION	1030	6					11	32	352	
LOC FLAG OUTPUT	1031	6					11	32	352	
GS FLAG OUTPUT	1032	6					11	32	352	
LOC DEVIATION	1033	6					11	32	352	
GS DEVIATION	1034	6					11	32	352	
400 MZ MARKER BEACH	1072	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300MZ MKR BEACH	1073	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000MZ MKR BEACH	1074	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
400 MZ MARKER BEACH	1051	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
1300 MZ MKR BEACH	1052	3	GND/OPEN		GND=1/OPEN=0		1	0	0	
3000 MZ MKR BEACH	1053	3	GND/OPEN		GND=1/OPEN=0		1	0	0	

4 1 0 INSTRUMENT LANDING SYSTEM.....AN/APH-106 (2)

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
400 MZ MARKER BEACH	41051	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
1300HZ M43 BEACH	41062	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
3000HZ M43 BEACH	41063	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
400 MZ MARKER BEACH	41054	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
1300HZ M43 BEACH	41055	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
3000HZ M43 BEACH	41066	3	GND/OPEN		GND=1/OPEN=0		1	8	8	
LOC FAST DEVIATION	41059	6					11	32	352	
LOC FLAG OUTPUT	41060	6					11	32	352	
GS INSTR DEVIATION	41061	6					11	32	352	
GS FLAG OUTPUT	41062	6					11	32	352	
LOC DEVIATION	41067	6					11	32	352	
GS DEVIATION	41068	6					11	32	352	
LOC DEVIATION	41063	6					11	32	352	
GS DEVIATION	41064	6					11	32	352	
LOC FLAG OUTPUT	41065	6					11	32	352	
GS FLAG OUTPUT	41066	6					11	32	352	

INSTRUMENT LANDING SYSTEM.....AM/APN-10A (P)

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	OUTPUT
1MHz FREQ SEL B	41008	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
1MHz FREQ SEL E	41009	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL A	41010	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL B	41011	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL E	41012	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL C	41013	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
1MHz FREQ SEL D	41042	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
1MHz FREQ SEL E	41043	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL A	41044	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL B	41045	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL E	41046	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL C	41047	3	GND/OPEN		GND=1/OPEN=0		1	2	2	

4 2 0 LF AUTOMATIC DIRECTION FINDER....DF-206

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QJAN	U/R	B/R
PRG DATA 4	42036	9					14	6	112
BRG DATA 5	42037	9					14	6	112

4 3 0 INTRAFORMATION: POSITIONING SET....AM/APN-169A INPUT

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
LAMP TEST GROUND	43015	3					1	1	1
LAMP TEST GROUND	43016	3					1	1	1
LAMP TEST GROUND	43017	3					1	1	1
REC LEFT TURN LP G	43075	3	+5 VDC		GND=1/OPEN=0		1	1	1
REC SLOWDOWN LP GND	43076	3	+5 VDC				1	1	1
REC LETDOWN LP GND	43077	3	+5 VDC				1	1	1
REC EXECUTE LP GND	43078	3	+5 VDC				1	1	1
REC PULLUP LP GND	43079	3	+5 VDC				1	1	1
REC SPEED UP LP GND	43080	3	+5 VDC		GND=1/OPEN=0		1	1	1
REC RIGHT TURN LP G	43081	3	+5 VDC		GND=1/OPEN=0		1	1	1
LEGEND DIM HI	43012	4	5 VDC				1	1	1
MASTER LAMP GND	43070	4	0 OR 5 VDC		OVDC=0/5VDC=1		1	1	1
MASTER LOSTLAMP GND	43071	4	0 OR 5 VDC		OVDC=0/5VDC=1		1	1	1
CAUTION LAMP GND	43072	4	0 OR 5 VDC		OVDC=0/5VDC=1		1	1	1
PROXIMITY WING LP G	43073	4	0 OR 5 VDC		OVDC=0/5VDC=1		1	1	1
LEGEND DIM	43011	5	0 TO 5 VDC				11	1	11
LEGEND DIM	43053	5	0 TO 25 VDC				11	1	11
LEGEND DIM	43054	5	0 TO 28 VDC				11	1	11
TWO INSLDT LCG	43001	3	0 TO 5 VDC				1	2	2
TWO MASTER LCG	43002	3	0 TO 5 VDC				1	2	2
NO GO LGS	43003	3	0 TO 5 VDC				1	2	2
MASTER LAMP LCG	43004	3	0 TO 5 VDC				1	2	2
MASTER LAMP LCG	43005	3	0 TO 5 VDC				1	2	2
XMIT HTTJRV LP CTL	43086	3	5 VDC		GND=1/OPEN=0		1	2	2
XMIT SPEEDUP LP CTL	43088	3	5 VDC		GND=1/OPEN=0		1	2	2
XMIT PULLUP LP CTL	43090	3	5 VDC		GND=1/OPEN=0		1	2	2
XMIT EXECUTE LP CTL	43092	3	5 VDC		GND=1/OPEN=0		1	2	2
XMIT LETDOWN LP CTL	43094	3	5 VDC		GND=1/OPEN=0		1	2	2

4 3 0 INFORMATION POSITIONING SET...AN/APN-169A

SIGID	XY F	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
XMIT FLUADU LP CTL	43096	3	5 VDC	GND=1/OPEN=R		1	2	2	
XMIT LEFT LP CTL	43098	3	5 VDC	GND=1/OPEN=R		1	2	2	
ALTITUDE REFERENCE	43111	5	0 TO 5.5 VDC			11	2	22	
RAMP RATE MAX CONT	43043	5	0 TO 22 VDC			11	8	88	
DIFF ALTITUDE CPT	43112	5				11	32	352	
DELETE SIGNAL	43032	6				11	32	352	

SIGNAL NAME	4	3	0	INFORMATION POSITIONING SET.....AM/APN-169A	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
					VOLTAGE RANGE					
LNG GEAR S(AUSS)	43146	3						1	1	1
LAMP TEST SPOUND	43013	3						1	1	1
LAMP TEST SPOUND	43014	3						1	1	1
FREQ A PSSY	43027	3				GND=1/OPEN=0		1	1	1
FREQ B PSSV	43028	3				GND=1/OPEN=0		1	1	1
RELAY RETU4A	43029	3				GND=1/OPEN=0		1	1	1
1K FT/RANGE MARK	43044	3			OPEN & GND			1	1	1
5K FT/RANGE MARK	43045	3			OPEN & GND			1	1	1
4K FT/RANGE MARK	43046	3			OPEN & GND			1	1	1
2K FT/RANGE MARK	43047	3			OPEN & GND			1	1	1
1K FT/RANGE MARK	43048	3			OPEN & GND			1	1	1
FREQ FICT A	43019	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
FREQ FICT B	43020	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
STRY SW14 POSITION	43021	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
MASTER SIGNAL	43022	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
FOLLOWER SIGNAL	43023	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
BIT TEST	43024	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
BITF TEST COMPL	43025	4			0 TO 5 VDC	0VDC=0/5VDC=1		1	1	1
LESEN BIN	43031	5			0 TO 5 VDC		11	1	11	
RANGE MARK RY CONT	43042	5			0 TO 5 VDC		11	1	11	
RIGHT TURN SWITCH	43067	4			5 VDC	GND=1/5VDC=0		1	2	2
SPEEDUP SWITCH	43089	4			5 VDC	GND=1/5VDC=0		1	2	2
PULLUP SWITCH	43091	4			5 VDC	GND=1/5VDC=0		1	2	2
EXECUTE SWITCH	43093	4			5 VDC	GND=1/5VDC=0		1	2	2
LEFT TURN SWITCH	43095	4			5 VDC	GND=1/5VDC=0		1	2	2
SLOW DOWN SWITCH	43097	4			5 VDC	GND=1/5VDC=0		1	2	2
LEFT HD SWITCH	43099	4			5 VDC	GND=1/5VDC=0		1	2	2
AUDIO DEF	43139	3			0 VDC	GND=1/OPEN=1		1	2	2

4 3 0 INTRAFORMATION POSITIONING SFT.....AN/APN-169A

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	RESOLUTION	GUAN	U/R	B/M	OUTPUT
AUDIO RESET	43140	3	0 VDC		GND=1/OPEN=1	1	2	2	
ID PUSHPUTTON	43105	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
LEADER A/J3ER(TT0A)	43106	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
LEADER A/J3ER(TT04)	43107	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
LEADER A/J3ER(TT02)	43108	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
LEADER A/J3ER(TT01)	43109	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
LEADER A/J3ER(TT10)	43110	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
ALTITUDE 1000	43113	4			SVDC=50"/GND=+-	1	2	2	
ALT OFFSET POLARITY	43114	4			SVDC=+50/GND=-	1	2	2	
TRACK OFFSET (X10K)	43118	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
TRACK OFFSET (Y8K)	43119	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
TRACK OFFSET (X4K)	43120	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
TRACK OFFSET (Y2K)	43121	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
TRACK OFFSET (Y1K)	43122	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
LEFT/RIGHT SWITCH	43123	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y4K)	43124	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y2K)	43125	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y1K)	43126	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y200)	43127	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y400)	43128	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y800)	43129	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
XTR OFFSET (Y100)	43130	4	+5 VDC TO 0 VDC		GND=1/SVDC=0	1	2	2	
LEADER SA (TT205)	43131	4	0 TO 5 VDC		GND=1/SVDC=0	1	2	2	
PROX A/P'S SLIP(S8)	43135	4	0 TO 5 VDC		SVDC=1/GND=0	1	2	2	
PROX A/P'S SLIP(S4)	43136	4	0 TO 5 VDC		SVDC=1/GND=0	1	2	2	
PROX A/P'S SLIP(S2)	43137	4	0 TO 5 VDC		SVDC=1/GND=0	1	2	2	
PROX A/P'S SLIP(S1)	43138	4	0 TO 5 VDC		SVDC=1/GND=0	1	2	2	
ALT OFFSET VOLTAGE	43135	5	+2.7 TO 5.1 VDC			11	2	22	

* 3 0 INFORMATION POSITIONING SET....AN/APM-169A
 SIGNAL NAME SIGID TYPE VOLTAGE RANGE PARAMETER RANGE SCALE FACTOR RESOLUTION GUAN U/R B/R
 PHOTO PLCP OUTPUT 43036 11
 RANGE MARK 43037 11
 SECTORING 10-P OPT 43055 3
 X DEFLECTION 43033 6
 Y DEFLECTION 43034 6

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RT STATUS FLAG	46009	1	0 TO +16-32V				1	1	1
DISTANCE FLAG	46056	1					1	1	1
PAR 1 INTERLOCK OUT	46011	3					1	1	1
SERIAL DATA OUT	46053	10	+/-12 VDC				128	8	1024

SIGNAL NAME	N	S	0	TACAN.....AN/ARN-11A	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	OUTPUT		
										RESOLUTION	QUAN	U/R
TELEARY CONTROL A					46C07	10	+-5 VDC			32	16	512
TELEARY CONTROL B					46008	10	+-5 VDC			32	16	512

SIGNAL NAME	UNIT	HF AUTOMATIC DIRECTION FINDER...AN/AJUF-73	SIGID TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT	QUAN	U/R	B/R
LF CONTROL A4W			47002	5				11	2	22
SYG480	H		47036	9				14	8	112
SYG490	K		47037	9				14	8	112
SYG400	V		47038	9				14	8	112
SYG410	Z		47039	9				14	8	112
SYG420	C		47040	9				14	8	112
TOTAL METER			47001	5				11	16	176

4 7 0 HF AUTOMATIC DIRECTION FINDER...AN/ADF-73
 SIGNAL NAME SIGID TYPE VOLTAGE RANGE PARAMETER RANGE SCALE FACTOR RESOLUTION QUAN U/R G/R
 FUNCTION: SEL ADF 47007 4 0 VDC/+10 VDC
 CAL/VOLICE (3FD CH) 47025 4

4 0 0 UHF AUTOMATIC DIRECTION FINDER...A1/ARA-50 INPUT
 SIGNAL NAME SIGID TYPE VOLTAGE RANGE PARAMETER RANGE SCALE FACTOR RESOLUTION QUAN U/R R/R
 ANTS/A REARRING 48042 9 11.0 VAC 0 TO 360 DEG IDEG/DEG 12 ARC MIN 14 32 448
 SENSITIVITY CONTROL 48004 3 OPEN OR GLO NA OPEN=CONTROL GND=NO CONTROL

UHF AUTOMATIC DIRECTION FINDER.....AM/ARA-90

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/M	B/R	OUTPUT
ANTENNA SWITCHING	48017	3	OPEN OR GND	NA	OPEN=NO SWITCH GND=SWITCH	NA	1	0	0	
ADF ENABLE	49021	3	OPEN OR GND	NA	OPEN=NO ENABLE GND=ENABLE	NA	1	0	0	
ADF TIME CONSTANT	49008	3	OPEN OR GND	NA	OPEN=NO TC GND=TC	NA	1	0	0	
POWER ON	49009	3	OPEN OR GND	NA	OPEN=NO POWER GND=POWER	NA	1	0	0	
CH-FL SQUAD ON	49010	3	OPEN OR GND	NA	OPEN=NOT ON GND=ON	NA	1	0	0	
CH-FL SELECT LOGI	49012	4	OPEN OR 28 VDC	NA	OPEN=NOT SELECT 28VDC=SELECTED	NA	1	0	0	
CH-FL SELECT LOGI	49013	4	OPEN OR 28VDC	NA	OPEN=NOT SELECT 28VDC=SELECTED	NA	1	0	0	

5 1 0		INFRARED DETECTION AND WARNING SYSTEM				PARAMETER RANGE		INPUT		QUAN	U/R	B/R
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R			
CLIP TRFV	51010	1	+5 VDC		5VDC=1/GND=C		1	6	6			
CLIP TRFV	51011	1	+5 VDC		5VDC=1/GND=0		1	6	6			
HIGH-LOW THREAT ID	51012	1	+5 VDC		5VDC=1/GND=0		1	6	6			
CLIP TRFV	51023	1	+5 VDC		5VDC=1/GND=0		1	6	6			
CLIP TRFV	51024	1	+5 VDC		5VDC=1/GND=C		1	6	6			
HIGH-LOW THREAT ID	51025	1	+5 VDC		5VDC=1/GND=0		1	6	6			
TARGET ACQUISITION	51009	4	+5 VDC		5VDC=1/GND=0		1	6	6			
TARGET ACQUISITION	51022	4	+5 VDC		5VDC=1/GND=0		1	6	6			
DISPERSE F. STABLE	52001	4	+28 VDC - GND		28VDC=1/GND=0		1	32	32			
FLARE VOLLEY I	52002	4	+29 VDC - GND		28VDC=1/GND=0		1	32	32			
FLARE VOLLEY III	52004	4	+28 VDC - GND		28VDC=1/GND=0		1	32	32			
FLARE VOLLEY VI	52005	4	+28 VDC - GND		28VDC=1/GND=0		1	32	32			
FLARE VOLLEY II	52003	4	+28 VDC - GND		28VDC=1/GND=0		1	33	33			

5 1 0 INFRARED DETECTION AND WARNING SYSTEM									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
FLARE STATUS 1	51019	*	+26 VDC - GND		26VDC=1/GND=0		1	*	*
FLARE STATUS 2	51019	*	+26 VDC - GND		26VDC=1/GND=0		1	*	*
FLARE STATUS 3	51020	*	+28 VDC - GND		28VDC=1/GND=0		1	*	*
FLARE STATUS 4	51021	*	+26 VDC - RHD		26VDC=1/GND=0		1	*	*

S	Z	Q	FLARES DISPENSER SYSTEM	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	P/R
FLARE	STATJS	1	5101A	4	+28 VDC - RND		28VDC=1/GND=0			1	4	4
FLARE	STATJS	2	51019	4	+28 VDC - RND		28VDC=1/GND=0			1	4	4
FLARE	STATJS	3	51020	4	+28 VDC - GND		28VDC=1/GND=0			1	4	4
FLARE	STATJS	4	51021	4	+28 VDC - RND		28VDC=1/GND=0			1	4	4

5 2 0 FLARES DISPENSER SYSTEM		SIGNAL NAME		SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
DISPENSE FL	ENABLE	52001	4	+2A	VDC	-	RND	28VDC=1/GND=0		1	32	32
FLAPE	VOLLEY I	52002	4	+2B	VDC	-	BND	28VDC=1/GND=0		1	32	32
FLAPE	VOLLEY III	52004	4	+2B	VDC	-	SND	28VDC=1/GND=0		1	32	32
FLAPE	VOLLEY VI	52005	4	+2A	VDC	-	TND	28VDC=1/GND=0		1	32	32
FLAPE	VOLLEY II	52003	4	+2B	VDC	-	RND	28VDC=1/GND=0		1	33	33

5 3 0 RADAR HOVING AND WARNING SYSTEM...AN/APR-36/37

SIGNAL NAME	SIGIN	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	GUAN	U/R	B/R
53001	1	115 VAC	NA	OPEN OR 115 VAC	NA	1	2	2	
53002	1	115 VAC	NA	OPEN OR 115 VAC	NA	1	2	2	
53003	3	115 VAC	NA	115 VAC OR OPEN	NA	1	2	2	
53004	2	25 VDC	NA	25 VDC OR GND	NA	1	2	2	
53005	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2	
53006	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2	
53007	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2	
53061	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53062	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53064	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53066	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53079	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53080	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53085	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53067	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53068	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53069	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53070	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53071	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2	
53073	3	NA	NA	OPEN AND CLOSE	NA	1	2	2	
53074	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53075	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53076	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53077	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53078	3	GROUND	NA	OPEN AND GROUND	NA	1	2	2	
53096	5	0 TO 25 VDC	NA	NA	5	11	16	176	
53097	5	0 TO 25 VDC	NA	NA	5	11	16	176	
53098	5	0 TO 25 VDC	NA	NA	5	11	16	176	

5 3 0 RADAR HOMING AND WARNING SYSTEM...AN/APR-36/37

SIGNAL NAME	SICID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT	QUAN	U/R	B/R
135 DEFLECTION	53069	5	0 TO 25 VDC	NA	NA	5	11	16	176
45 DEFLECTION	53095	5	0 TO 25 VDC	NA	NA	5	11	16	176
225 DEFLECTION	53096	5	0 TO 25 VDC	NA	NA	5	11	16	176
315 DEFLECTION	53097	5	0 TO 25 VDC	NA	NA	5	11	16	176
135 DEFLECTION	53098	5	0 TO 25 VDC	NA	NA	5	11	16	176

3 0 0 RADAR HOMING AND WARNING SYSTEM...AM/APR-15/37
 SIGNAL NAME SIGID TYPE VOLTAGE RANGE PARAMETER RANGE SCALE FACTOR OUTPUT RESOLUTION: QUAN U/R B/R
 115V 0004Z 53002 3 115 VAC NA 115 VAC OR OPEN NA 1 2 2
 01244LE 53072 3 GROUND NA GROUND AND OPEN NA 1 2 2

7 1 0	INSTRUMENT AND AIRCRAFT SYSTEMS	SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT		
								RESOLUTION	QUAN	U/R
		SELF TEST	23013	3	GROUND	NA	OPEN=NO SELF TST NA GND=SELF TST INI	1	0	0
		SELF TEST	23015	3	GROUND	NA	OPEN=NO SELF TST NA GND=SELF TST INI	1	0	0
		SELF TEST	23053	3	GROUND	NA	OPEN=NO SELF TST NA	1	0	0

7	1	0	INSTRUMENT AND AIRCRAFT SYSTEMS			OUTPUT			
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER NAME	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
AIR SPEED	16015	5					11	0	00
AIR SPEED	16016	5					11	0	00
AIR SPEED	16014	10					16	0	128
AIR SPEED	16018	5					11	0	05
AIR SPEED	16019	5					11	0	00
AIR SPEED	16017	10					16	0	128
VERTICAL VELOCITY	16022	5					11	0	00
VERTICAL VELOCITY	16023	5					11	0	00
ALTITUDE	16020	10					16	0	128
ALTITUDE	16021	10					16	0	128
EFCS SERVING (P)	16033	3					1	0	0
EFCS SERVING (C)	16034	3					1	0	0
EFCS SERVING (P)	16035	3					1	0	0
EFCS SERVING (C)	16036	3					1	0	0
EFCS SERVING (P)	16037	3					1	0	0
EFCS SERVING (C)	16038	3					1	0	0

7 * 0 RADIO AIDS TO NAVIGATION SYSTEM									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	OUTPUT	QUAN	U/R	B/R
400 HZ MARKER BEACH	41072	3	GND/OPEN		GND=1/OPEN=0		1	8	8
1300HZ MARKER BEACH	41073	3	GND/OPEN		GND=1/OPEN=0		1	8	8
3000HZ MARKER BEACH	41074	3	GND/OPEN		GND=1/OPEN=0		1	8	8
450 HZ MARKER BEACH	41069	3	GND/OPEN		GND=1/OPEN=0		1	8	8
1500HZ MARKER BEACH	41070	3	GND/OPEN		GND=1/OPEN=0		1	8	8
3000HZ MARKER BEACH	41071	3	GND/OPEN		GND=1/OPEN=0		1	8	8
400 HZ MARKER BEACH	41051	3	GND/OPEN		GND=1/OPEN=0		1	8	8
1300 HZ MARKER BEACH	41052	3	GND/OPEN		GND=1/OPEN=0		1	8	8
3000 HZ MARKER BEACH	41053	3	GND/OPEN		GND=1/OPEN=0		1	8	8

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
175 POWER ON	25009	1					1	2	2	
25000 VDC	25010	1	20 VDC				1	2	2	
25 VDC APC CTL 111	13001	1			GND=TRUE		1	0	0	
25 VDC APC CTL 114	13003	1			2AVDC=TRUE		1	0	0	
25 VDC APC CTL 116	13005	1					1	0	0	
25 VDC APC CTL 115	13007	1					1	0	0	
25 VDC APC CTL 117	13009	1					1	0	0	
25 VDC APC CTL 123	13011	1					1	0	0	
25 VDC APC CTL 126	13013	1					1	0	0	
25 VDC APC CTL 112	13015	1					1	0	0	
25 VDC APC CTL 112	13017	1					1	0	0	
25 VDC APC CTL 112	13019	1					1	0	0	
25 VDC APC CTL 112	13021	1					1	0	0	
25 VDC APC CTL 113	13023	1					1	0	0	
25 VDC APC CTL 113	13025	1					1	0	0	
25 VDC APC CTL 113	13027	1					1	0	0	
25 VDC APC CTL 112	13029	1					1	0	0	
25 VDC APC CTL 112	13031	1					1	0	0	
25 VDC APC CTL 112	13033	1					1	0	0	
25 VDC APC CTL 112	13035	1					1	0	0	
25 VDC APC CTL 112	13037	1					1	0	0	
25 VDC APC CTL 112	13039	1					1	0	0	
25 VDC APC CTL 112	13041	1					1	0	0	
25 VDC APC CTL 112	13043	1					1	0	0	
25 VDC APC CTL 112	13045	1					1	0	0	
25 VDC APC CTL 112	13047	1					1	0	0	
25 VDC APC CTL 112	13049	1					1	0	0	
25 VDC APC CTL 112	13051	1					1	0	0	

6 1 0 IOAMPST PROCESSOR 1		INPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
24 VCC CTL RPC CTL	13053	1					1	0	0
25 VCC CTL RPC CTL	13055	1					1	0	0
26 VCC FF RPC CTL	13057	1					1	0	0
3PH 115VAC RPC CTL	13059	1					1	0	0
25 VCC RPC CTL 210	13061	1					1	0	0
26 VAC RPC CTL 210	13063	1					1	0	0
3PH 115VAC RPC CTL	13065	1					1	0	0
3PH 115VAC RPC CTL	13067	1					1	0	0
3PH 115VAC RPC CTL	13069	1					1	0	0
24 VCC RPC CTL 230	13073	1					1	0	0
2PH 115VAC RPC CTL	13071	1					1	0	0
28 VCC RPC CTL 240	13075	1					1	0	0
3PH 115VAC RPC CTL	13077	1					1	0	0
26 VAC RPC CTL 240	13079	1					1	0	0
29 VCC RPC CTL 240	13081	1					1	0	0
3PH 115VAC RPC CTL	13083	1					1	0	0
28 VCC RPC CTL 250	13085	1					1	0	0
26 VAC RPC CTL 250	13087	1					1	0	0
3PH 115VAC RPC CTL	13089	1					1	0	0
28 VCC RPC CTL 260	13091	1					1	0	0
28 VCC RPC CTL 311	13093	1					1	0	0
3PH 115VAC RPC CTL	13095	1					1	0	0
28 VCC RPC CTL 330	13097	1					1	0	0
29 VCC RPC CTL 340	13099	1					1	0	0
28 VCC RPC CTL 360	13101	1					1	0	0
29 VCC RPC CTL 370	13103	1					1	0	0
28 VCC RPC CTL 380	13105	1					1	0	0
115 VAC RPC CTL 360	13107	1					1	0	0

IDANST PROCESSOR 3									
SIGNAL TYPE	SICID	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	E/R	INPUT
28 VCC R2C C7L 392	13109	1				1	0	0	0
28 VCC R2C C7L 392	13111	1				1	0	0	0
28 VCC R2C C7L 411	13113	1				1	0	0	0
28 VCC R2C C7L 411	13115	1				1	0	0	0
28 VCC R2C C7L 420	13117	1				1	0	0	0
26 VCC R2C C7L 420	13119	1				1	0	0	0
3PH 115VAC R2C C7L	13121	1				1	0	0	0
28 VCC R2C C7L 430	13123	1				1	0	0	0
28 VCC R2C C7L 450	13125	1				1	0	0	0
28 VCC R2C C7L 460	13127	1				1	0	0	0
28 VCC R2C C7L 460	13129	1				1	0	0	0
115VAC R2C C7L 460	13131	1				1	0	0	0
28 VCC R2C C7L 470	13133	1				1	0	0	0
28 VCC R2C C7L 480	13135	1				1	0	0	0
26 VCC R2C C7L 480	13137	1				1	0	0	0
115VAC R2C C7L 480	13139	1				1	0	0	0
28 VCC R2C C7L 511	13141	1				1	0	0	0
28 VCC R2C C7L 512	13143	1				1	0	0	0
28 VCC R2C C7L 513	13145	1				1	0	0	0
28 VCC R2C C7L 514	13147	1				1	0	0	0
28 VCC R2C C7L 520	13149	1				1	0	0	0
115VAC R2C C7L 531	13151	1				1	0	0	0
28 VCC R2C C7L SCP	13153	1				1	0	0	0
115VAC R2C C7L IPK	13155	1				1	0	0	0
115VAC R2C C7L IPK	13157	1				1	0	0	0
26 VCC R2C C7L IPK	13159	1				1	0	0	0
28 VCC R2C C7L IPK	13161	1				1	0	0	0
3PH 115VAC R2C C7L	13163	1				1	0	0	0

A 1 0		IPANST PROCESSOR 1		INPUT					
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
29 VCC RDC CTL	CEA	13165	1				1	0	0
28 VCC RDC CTL	CEA	13167	1				1	0	0
28 VCC RDC CTL	MKN	13169	1				1	0	0
29 VCC RDC CTL	SYM	13171	1				1	0	0
3PM 115VAC RDC CTL		13173	1				1	0	0
3PM 115VAC RDC CTL		13175	1				1	0	0
3PM 115VAC RDC CTL		13177	1				1	0	0
3PM 115VAC RDC CTL		13179	1				1	0	0
3PM 115VAC RDC CTL		13181	1				1	0	0
3PM 115VAC RDC CTL		13183	1				1	0	0
3PM 115VAC RDC CTL		13185	1				1	0	0
3PM 115VAC RDC CTL		13187	1				1	0	0
3PM 115VAC RDC CTL		13199	1				1	0	0
3PM 115VAC RDC CTL		13191	1				1	0	0
26 VCC RDC CTL	RFDC	13193	1				1	0	0
25 VCC RDC CTL	MYD	13195	1				1	0	0
26 VCC RDC CTL	MYD	13197	1				1	0	0
115VAC RDC CTL	1PK	13199	1				1	0	0
115VAC RDC CTL	1MK	13201	1				1	0	0
29 VCC RDC CTL	1PK	13203	1				1	0	0
24 VCC RDC CTL	1PK	13205	1				1	0	0
3PM 115VAC RDC CTL		13207	1				1	0	0
29 VCC RDC CTL	CEA	13209	1				1	0	0
25 VCC RDC CTL	CEK	13211	1				1	0	0
28 VCC RDC CTL	MKN	13213	1				1	0	0
3PM 115VAC RDC CTL		13215	1				1	0	0
3PM 115VAC RDC CTL		13217	1				1	0	0
3PM 115VAC RDC CTL		13219	1				1	0	0

F 1 0		IDA*ST PROCESSOR 1		INPUT					
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
304 115440 RPC CTL	18221	1					1	3	0
304 115440 RPC CTL	18223	1					1	0	0
304 115440 RPC CTL	18225	1					1	0	0
304 115440 RPC CTL	18227	1					1	0	0
304 115440 RPC CTL	18229	1					1	0	0
304 115440 RPC CTL	18231	1					1	0	0
304 115440 RPC CTL	18233	1					1	0	0
304 115440 RPC CTL	18235	1					1	0	0
304 115440 RPC CTL	18237	1					1	0	0
FL CTL ON PUL OUT 1	25002	10					64	0	512
RESISTOR R0169(1)	80169	10					32	0	256
DAYS MICROTIME(10)	80171	10					512	0	4096

Serial Name	SIGID	Type	Voltage Range	Parameter Range	Scale Factor	Resolution	BUAN	U/R	B/R
CD. 604 02 POS-M1	1009	3					1	1	1
CD. 604 02 POS-M2	1010	3					1	1	1
CD. 604 02 POS-L1	1011	3					1	1	1
CD. 604 02 POS-L2	1012	3					1	1	1
ANTH 0411	10001	3					1	1	1
PROBE LOW PRESS	10002	3					1	1	1
3000 0000 0000	10003	3					1	1	1
LE FUP 047 04	11009	3					1	1	1
LE FUP 047 02	11010	3					1	1	1
LE FUP 047 00	11011	3					1	1	1
LE FUP 047 01	11012	3					1	1	1
LE FUP 047 03	11013	3					1	1	1
LE FUP 100 04	11014	3					1	1	1
LE FUP 100 01	11015	3					1	1	1
LE FUP 100 02	11016	3					1	1	1
ENG 1 REVERSE	14015	3					1	1	1
ENG 1 EST	14009	6	0-400MV				11	1	11
ENG 1 OIL 0TY	14011	6	6.8V				11	1	11
ENG 1 OVERHEAT	14017	9					1	1	1
ENG 1 AFT WHEEL	14019	3					1	1	1
ENG 1 0022-E	14021	3					1	1	1
ENG 2 REVERSE	14016	3					1	1	1
ENG 2 EST	14010	6	0-400MV				11	1	11
ENG 2 OIL 0TY	14012	6	6.8V				11	1	11
ENG 2 OVERHEAT	14018	3					1	1	1
ENG 2 AFT WHEEL	14020	3					1	1	1
ENG 2 0022-E	14022	3					1	1	1
ENG 1 OIL 04ES	14013	6	9.9-17.9V				11	2	22

9 1 0 IC8000 PROCESSOR 1

SECT NAME	UNIT	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
FF 100	14023	6	0-4.97V				11	2	22
FF 101	14014	5	9.9-17.9V				11	2	22
FF 102	14004	0	0-4.97V				11	2	22
FF 103	14027	7					11	2	22
FF 104	14010	7					11	2	22
FF 105	14020	7					11	2	22
FF 106	14011	7					11	2	22
FF 107	14009	7					11	2	22
FF 108	14032	7					11	2	22
FF 109	14001	11	0-1.5VDC				10	4	40
FF 110	14002	11	0-1.5VDC				10	4	40
FF 111	14001	5	0-24.5 VDC				11	8	88
FF 112	14002	6	0-24.5 VDC				11	8	88
FF 113	14003	5	0-24.5 VDC				11	8	88
FF 114	14004	6	0-24.5 VDC				11	8	88
FF 115	14005	5	0-24.5 VDC				11	8	88
FF 116	14002	3					1	8	8
FF 117	14004	3					1	8	8
FF 118	14005	3					1	8	8
FF 119	14004	3					1	8	8
FF 120	14010	3					1	8	8
FF 121	14012	3					1	8	8
FF 122	14014	3					1	8	8
FF 123	14016	3					1	8	8
FF 124	14018	2					1	8	8
FF 125	14020	3					1	8	8
FF 126	14022	3					1	8	8
FF 127	14024	3					1	8	8

9 1 0 ICAMST PROCESSOR 1		OUTPUT						
SIGNAL NAME	SIG10 TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RPC STATUS	1113	13025	3			1	0	0
RPC STATUS	1113	13023	3			1	0	0
RPC STATUS	1122	13030	3			1	0	0
AVL RPC STATUS	12032	3				1	0	0
M1 RPC STATUS	13034	3				1	0	0
M2 RPC STATUS	13036	3				1	0	0
EGT RPC STATUS	13038	3				1	0	0
OIL RPC STATUS	13040	3				1	0	0
OIL RPC STATUS	13042	3				1	0	0
FF RPC STATUS	13044	3				1	0	0
AVL RPC STATUS	13046	3				1	0	0
M1 RPC STATUS	13048	3				1	0	0
M2 RPC STATUS	13050	3				1	0	0
EGT RPC STATUS	13052	3				1	0	0
OIL RPC STATUS	13054	3				1	0	0
OIL RPC STATUS	13056	3				1	0	0
FF RPC STATUS	13058	3				1	0	0
RPC STATUS	210	13060	3			1	0	0
RPC STATUS	210	13062	3			1	0	0
RPC STATUS	210	13064	3			1	0	0
RPC STATUS	210	13066	3			1	0	0
RPC STATUS	210	13068	3			1	0	0
RPC STATUS	210	13070	3			1	0	0
FFC STATUS	210	13074	3			1	0	0
RPC STATUS	230	13072	3			1	0	0
RPC STATUS	230	13076	3			1	0	0
RPC STATUS	240	13078	3			1	0	0
RPC STATUS	240	13080	3			1	0	0

OUTPUT

6 F 0 IDAMST PROCESSOR 1

CIRCUIT NAME	SERIAL	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RPC STATUS	240	13092	3				1	0	0
RPC STATUS	250	13084	3				1	0	0
RPC STATUS	250	13096	3				1	0	0
RPC STATUS	250	13068	3				1	0	0
RPC STATUS	260	13090	3				1	0	0
RPC STATUS	260	13092	3				1	0	0
RPC STATUS	311	13094	3				1	0	0
RPC STATUS	320	13096	3				1	0	0
RPC STATUS	310	13094	3				1	0	0
RPC STATUS	340	13100	3				1	0	0
RPC STATUS	360	13102	3				1	0	0
RPC STATUS	370	13104	3				1	0	0
RPC STATUS	340	13106	3				1	0	0
RPC STATUS	390	13108	3				1	0	0
RPC STATUS	391	13110	3				1	0	0
RPC STATUS	392	13112	3				1	0	0
RPC STATUS	411	13114	3				1	0	0
RPC STATUS	411	13116	3				1	0	0
RPC STATUS	420	13118	3				1	0	0
RPC STATUS	420	13120	3				1	0	0
RPC STATUS	430	13122	3				1	0	0
RPC STATUS	430	13124	3				1	0	0
RPC STATUS	450	13126	3				1	0	0
RPC STATUS	460	13128	3				1	0	0
RPC STATUS	460	13130	3				1	0	0
RPC STATUS	450	13132	3				1	0	0
RPC STATUS	470	13134	3				1	0	0
RPC STATUS	460	13136	3				1	0	0

0 1 0 IOMST PROCESSOR 1									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R
APC STATJS	400	13139	3				1	0	0
APC STATJS	400	13140	3				1	0	0
APC STATJS	511	13142	3				1	0	0
APC STATJS	512	13144	3				1	0	0
APC STATJS	513	13146	3				1	0	0
APC STATJS	514	13148	3				1	0	0
APC STATJS	520	13150	3				1	0	0
APC STATJS	531	13152	3				1	0	0
APC STATJS	SCP	13154	3				1	0	0
APC STATJS	IMK	13156	3				1	0	0
APC STATJS	IMK	13158	2				1	0	0
APC STATJS	IMK	13160	3				1	0	0
APC STATJS	IMK	13162	3				1	0	0
APC STATJS	PSMU	13164	3				1	0	0
APC STATJS	UEK	13166	3				1	0	0
APC STATJS	UEK	13168	3				1	0	0
APC STATJS	MMK	13170	3				1	0	0
APC STATJS	SYM	13172	3				1	0	0
APC STATJS	MPDG1	13174	3				1	0	0
APC STATJS	MPDG2	13176	3				1	0	0
APC STATJS	SCAN	13178	3				1	0	0
APC STATJS	SPD1	13180	3				1	0	0
APC STATJS	SPD2	13182	3				1	0	0
APC STATJS	SPD3	13184	3				1	0	0
APC STATJS	HJDI	13186	3				1	0	0
APC STATJS	HJDI	13188	3				1	0	0
APC STATJS	MSD1	13190	3				1	0	0
APC STATJS	MSD2	13192	3				1	0	0

DAYST PROCESSOR 1									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
RPC STATUS	MSDC	13194	3				1	0	0
RPC STATUS	MSD	13195	3				1	0	0
RPC STATUS	MSL	13196	3				1	0	0
RPC STATUS	MSK	13200	3				1	0	0
RPC STATUS	MSN	13202	3				1	0	0
RPC STATUS	MSO	13204	3				1	0	0
RPC STATUS	MSN	13206	3				1	0	3
RPC STATUS	MSW	13208	3				1	0	0
RPC STATUS	MSX	13210	3				1	0	0
RPC STATUS	MSY	13212	3				1	0	0
RPC STATUS	MSZ	13214	3				1	0	0
RPC STATUS	MSA	13216	3				1	0	0
RPC STATUS	MSB	13218	3				1	0	0
RPC STATUS	MSC	13220	3				1	0	0
RPC STATUS	MSD	13222	3				1	0	0
RPC STATUS	MSE	13224	3				1	0	0
RPC STATUS	MSF	13226	3				1	0	0
RPC STATUS	MSG	13228	3				1	0	0
RPC STATUS	MSH	13230	3				1	0	0
RPC STATUS	MSI	13232	3				1	0	0
RPC STATUS	MSJ	13234	3				1	0	0
RPC STATUS	MSK	13236	3				1	0	0
RPC STATUS	MSL	13238	3				1	0	0
ENG 1 P1		14005	11	0-5V			7	8	56
ENG 1 P2		14007	11	0-5V			7	8	56
ENG 2 P1		14006	11	0-5V			7	8	56
ENG 2 P2		14009	11	0-5V			7	8	56
CITS RECORDER(OUT)		07172	10				32	0	256

0 1 0 TOWST PROCESSOR 1		OUTPUT						
SIGNAL NAME	SIGIC TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
ELEV POS L	11017	18				14	16	224
ELEV POS R	11018	18				14	16	224
PITCH POS	11019	18				14	16	224
OUTBOARD F-LP POS(L)	11003	18				14	16	224
IN FLAP POS (L)	11004	18				14	16	224
USA LEFT	11005	18				14	16	224
SPOILER 1L POS	11020	18				14	16	224
SPOILER 2L POS	11021	18				14	16	224
OUTBOARD F-LP POS(R)	11006	18				14	16	224
IN FLAP POS(R)	11007	18				14	16	224
USA RIGHT	11008	18				14	16	224
SPOILER 1R POS	11022	18				14	16	224
SPOILER 2R POS	11023	18				14	16	224
TALF AIR SPEED	16024	9				14	32	448
YOF AIR SPEED	16025	9				14	32	448
TALF AIR SPEED	16026	9				14	32	448
MISSION_READ(OUT)	50170	10				512	64	32768

SIGNAL NAME	8	2	0	IDAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
LAMP TEST SROUND				43013	3						1	1	1	
LAMP TEST SROUND				43014	3						1	1	1	
FREQ A FDSV				43027	3				GND=1/OPEN=0		1	1	1	
FREQ 9 FDSV				43028	3				GND=1/OPEN=0		1	1	1	
RELAY RETURN				43025	3				GND=1/OPEN=0		1	1	1	
16X FT/RANGE MARK				43044	3	OPEN & GND					1	1	1	
8X FT/RANGE MARK				43045	3	OPEN & GND					1	1	1	
4X FT/RANGE MARK				43046	3	OPEN & GND					1	1	1	
2X FT/RANGE MARK				43047	3	OPEN & GND					1	1	1	
1X FT/RANGE MARK				43048	3	OPEN & GND					1	1	1	
FREQUENCY A				43019	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
FREQUENCY B				43020	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
STBY SWTH POSITION				43021	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
MASTER SIGNAL				43022	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
FOLLOWER SIGNAL				43023	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
BITF TEST				43024	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
BITF TEST COMPL				43025	4	0 TO 5 VDC			0VDC=0/5VDC=1		1	1	1	
LEGEND DIM				43031	5	0 TO 5 VDC			0VDC=0/5VDC=1		11	1	11	
RANGE MARK BMT COMT				43042	5	0 TO 5 VDC			0VDC=0/5VDC=1		11	1	11	
100HZ FREQ SEL 2004				34001	1	0/1					1	2	2	
100HZ FREQ SEL 2003				34002	1	0/1					1	2	2	
100HZ FREQ SEL 2002				34003	1	0/1					1	2	2	
100HZ FREQ SEL 1001				34004	1	0/1					1	2	2	
140HZ FREQ SEL 2005				34005	1	0/1					1	2	2	
140HZ FREQ SEL 2004				34006	1	0/1					1	2	2	
140HZ FREQ SEL 2003				34007	1	0/1					1	2	2	
140HZ FREQ SEL 2002				34008	1	0/1					1	2	2	
140HZ FREQ SEL 2001				34009	1	0/1					1	2	2	

SIGNAL NAME	0	2	0	IDAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
0.1MHZ FREQ SEL 2005				34010	1	0/1					1	2	2	
0.1MHZ FREQ SEL 2004				34011	1	0/1					1	2	2	
0.1MHZ FREQ SEL 2003				34012	1	0/1					1	2	2	
0.1MHZ FREQ SEL 2002				34013	1	0/1					1	2	2	
0.1MHZ FREQ SEL 2001				34014	1	0/1					1	2	2	
0.01MHZ FREQ SEL 2005				34015	1	0/1					1	2	2	
0.01MHZ FREQ SEL 2004				34016	1	0/1					1	2	2	
0.01MHZ FREQ SEL 2003				34017	1	0/1					1	2	2	
0.01MHZ FREQ SEL 2002				34018	1	0/1					1	2	2	
0.01MHZ FREQ SEL 2001				34019	1	0/1					1	2	2	
0.0005MHZ FREQ SEL 2002				34020	1	0/1					1	2	2	
0.0005MHZ FREQ SEL 2001				34021	1	0/1					1	2	2	
RECTIFIED PULSE				32031	2	+10 VDC/GND					1	2	2	+10VDC=1/0VDC=0
BIT OUTPUT				32037	2	+10 VDC/0 VDC					1	2	2	
DATA STABILITY				21054	3						1	2	2	
FULL HIGH(3AG) CMD				21066	3	0 VDC					1	2	2	
SCAM MODE (LEFT)				21067	3	25 VDC					1	2	2	
SCAM MODE (RIGHT)				21068	3	28 VDC					1	2	2	
AUT CPLR BAND 1				32001	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 2				32002	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 3				32003	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 4				32004	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 5				32005	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 6				32006	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 7				32007	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AUT CPLR BAND 8				32008	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AMP/PS BAND 1				32009	3	GND/OPEN					1	2	2	GND=1/OPEN=0
AMP/PS BAND 2				32010	3	GND/OPEN					1	2	2	GND=1/OPEN=0

8 7 0 IBM-57 PROCESSOR 2

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	P/R	INPUT
AMP/PS BAND 3	32011	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 4	32012	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 5	32013	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 6	32014	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 7	32015	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 8	32016	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 9	32017	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
AMP/PS BAND 10	32018	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
SSM	32019	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
2ME	32020	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
5S	32021	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
01	32039	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
GUARDRAID P BANDSM	32940	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
GUARDRAID R BANDSM	32941	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
FREQ SEL CONV	34022	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
ST DISAB.F COMM TST	34023	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
SCALECH DISABLE	39017	3					1	2	2	
W/A	39018	3					1	2	2	
POWER ON/OFF	39019	3					1	2	2	
SCALECH DISABLE	39064	3					1	2	2	
W/A	39065	3					1	2	2	
POWER ON/OFF	39066	3					1	2	2	
1MHz FREQ SEL 9	41004	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
1MHz FREQ SEL E	41009	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL A	41010	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
1.1MHz FREQ SEL R	41011	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.1MHz FREQ SEL E	41012	3	GND/OPEN		GND=1/OPEN=0		1	2	2	
0.01MHz FREQ SEL C	41013	3	GND/OPEN		GND=1/OPEN=0		1	2	2	

SIGNAL NAME	Q 2 0	PARAMETER PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
1MHz FREQ SEL B	41042	3	GND/OPEN			GND=1/OPEN=0			1	2	2
1MHz FREQ SEL E	41043	3	GND/OPEN			GND=1/OPEN=0			1	2	2
0.1MHz FREQ SEL A	41044	3	GND/OPEN			GND=1/OPEN=0			1	2	2
0.1MHz FREQ SEL B	41045	3	GND/OPEN			GND=1/OPEN=0			1	2	2
0.1MHz FREQ SEL E	41046	3	GND/OPEN			GND=1/OPEN=0			1	2	2
0.01MHz FREQ SEL C	41047	3	GND/OPEN			GND=1/OPEN=0			1	2	2
PENCIL GND	21020	4	0 TO 26 VDC						1	2	2
PAPER LIGHTS	32022	4	0PER/-5 VDC						1	2	2
RE DFC ON/OFF	34024	4	0/27.5 VDC						1	2	2
RIGHT TURN SWITCH	43087	4	5 VDC						1	2	2
SPEED UP SWITCH	43089	4	5 VDC						1	2	2
PULL UP SWITCH	43091	4	5 VDC						1	2	2
ERASE SWITCH	43093	4	5 VDC						1	2	2
LETTER SWITCH	43095	4	5 VDC						1	2	2
SLIP DOWN SWITCH	43097	4	5 VDC						1	2	2
LEFT TURN SWITCH	43099	4	5 VDC						1	2	2
FUNCTION SEL A/B	47007	4	0 VDC/+10 VDC						1	2	2
COPY/FEED (3.5 IN)	47025	4							1	2	2
NOISE BLK CONTROL	32028	5	+10 VDC/-5 VDC						11	2	22
RF GAIN CONTROL	32029	5	+10 VDC/-5 VDC						11	2	22
SCALCH CONTROL	32030	5	+10 VDC/-5 VDC						11	2	22
VHF-500 TVS VOLTGE	32033	5	+11 VDC/+3V VDC						11	2	22
PARAMP TVS VOLTGE	32034	5	+11 VDC/+3V VDC						11	2	22
VOLUME CONTROL	32035	6	-5 VDC/0 VDC						11	2	22
I. 155-1540	21127	1	26 VDC						1	4	4
DIST FLASHER	46071	1							1	4	4
NO SWITCH 3MS	21075	3	0 VDC						1	4	4
OP. GND	21076	3	0 VDC						1	4	4

8	2	0	IDA*ST PROCLSSOR 2	INPUT	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
STIMUL NAME	SIGID	TYPE	VOLTAGE RANGE							
2KHZ PRF SEL GND	21077	3	0 VDC					1	4	4
1KHZ PRF SEL GND	21078	3	0 VDC					1	4	4
25KHZ PRF SEL GND	21079	3	0 VDC					1	4	4
WEATHER SYS GND	21080	3	0 VDC					1	4	4
AGILE GND	21081	3	0 VDC					1	4	4
STBY GND	21082	3	0 VDC					1	4	4
FTC GND	21088	3	0 VDC					1	4	4
500 MHz REF/ACQ	21115	3						1	4	4
SCAL 0	21089	3	0 VDC					1	4	4
SCAL 1	21091	3	0 VDC					1	4	4
RANGE SEL 3-30/1	21101	3						1	4	4
RANGE SEL 3-30/5	21102	3						1	4	4
RANGE SEL 50/10	21103	3						1	4	4
RANGE SEL 100/20	21104	3						1	4	4
RANGE SEL 200/30	21105	3						1	4	4
BEICO, POS3	21108	3						1	4	4
WEATHER POS3	21109	3						1	4	4
SLAVE/PE-	21169	3						1	4	4
CONTROL POS 5(LINE R)	16006	3	OPEN 28 V CLO GND					1	4	4
CONTROL POS3(LINE/R)	16007	3	OPEN 28 V CLO GND					1	4	4
CONTROL POS7	16008	3	OPEN 28 V CLO GND					1	4	4
CONTROL POS4(LINE/SSB)	16009	3	OPEN 28 V CLO GND					1	4	4
CONTROL POS1 (SPARE)	16030	3	OPEN 28V CLO GND					1	4	4
CONTROL POS 5(LINE R)	16059	3	OPEN 28V CLO GND					1	4	4
CONTROL POS 3 (LINE/AM)	16060	3	OPEN 28V CLO GND					1	4	4
CONTROL POS 7	16061	3	OPEN 28V CLO GND					1	4	4
CONTROL POS 8 (LINE/SSB)	16062	3	OPEN 28V CLO GND					1	4	4
CONTROL POS3(LINE/SSB)	16075	3	OPEN 28V CLO GND					1	4	4

ICAMST PROCESSOR 2									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	D/R
DIST Y TENS	46066	5					11	4	44
DIST Y HUNDIS	46067	5					11	4	44
DIST Y UNITS	46068	5					11	4	44
DIST Y TENS	46069	5					11	4	44
DIST Y HUNDIS	46070	5					11	4	44
AL STAS (IT)	21095	7					11	4	44
GEN 1 (IV)	90025	1					1	8	8
GEN 2 (IV)	90029	1					1	8	8
MF0C1- 1 (IT)	90096	1					1	8	8
MF0C1- 2 (IT)	90099	1					1	8	8
MF0C1- 3 (IT)	90090	1					1	8	8
MF0C1- 4 (IT)	90091	1					1	8	8
MF0C1- 5 (IT)	90092	1					1	8	8
MF0C1- 6 (IT)	90093	1					1	8	8
MF0C1- 7 (IT)	90094	1					1	8	8
MF0C1- 8 (IT)	90095	1					1	8	8
MF0C1- 9 (IT)	90096	1					1	8	8
MF0C1-10 (IT)	90097	1					1	8	8
MF0C1-11 (IT)	90098	1					1	8	8
MF0C1-12 (IT)	90099	1					1	8	8
MF0C1-13 (IT)	90100	1					1	8	8
MF0C1-14 (IT)	90101	1					1	8	8
MF0C1-15 (IT)	90102	1					1	8	8
MF0C1-16 (IT)	90103	1					1	8	8
MF0C1-17 (IT)	90104	1					1	8	8
MF0C1-18 (IT)	90105	1					1	8	8
MF0C1-19 (IT)	90106	1					1	8	8
MF0C1-20 (IT)	90107	1					1	8	8

SIGNAL NAME	8	2	0	IDAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
MF001-21 (IN)					80108	1					1	0	0
MF001-22 (IN)					80109	1					1	0	0
JF001-23 (IN)					80110	1					1	0	0
MF001-24 (IN)					80111	1					1	0	0
MF001-25 (IN)					80112	1					1	0	0
STICK SHAKEP 1					2001	3					1	0	0
STICK SHAKEP 2					2002	3					1	0	0
150-ECHO LEVEL					21150	3					1	0	0
TOP SQUELCH GROUND					33001	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
SQUELCH DISABLE GND					33002	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
0.15 MC SELECT E					33005	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
0.75 MC SELECT D					33006	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
0.15 MC SELECT B					33007	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
0.15 MC SELECT C					33008	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
0.15 MC SELECT A					33009	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
BAND A 10-52 MC					33010	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
BAND A 53-76 MC					33011	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
MC SELECT E					33012	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
MC SELECT C					33013	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
MC SELECT D					33014	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
MC SELECT B					33015	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
MC SELECT A					33016	3	OPEN OR GROUND	NA	GND=0 SQUELCH	NA	1	0	0
HYPER CONV					33031	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
VME PRESS-PC-TALK					33033	3	OPEN OR GROUND	NA	OPEN=0 SQUELCH	NA	1	0	0
EXT KEY					39021	3					1	0	0
ALT KEY					39068	3					1	0	0
ANTENNA SWITCHING					48017	3	OPEN OR GND	NA	OPEN=0 SWITCH	NA	1	0	0
ADF E-LOC					49021	3	OPEN OR GND	NA	GND=0 SWITCH	NA	1	0	0

8	?	0	TOAST PROCESSOR 2	NAME	UNIT	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/M	B/R
				ADP TPC CONSTANT	4400A	3	OPEN OR GND	NA	OPEN=0 TC GND=TC	NA	1	0	0
				ADP TPC	4400B	3	OPEN OR GND	NA	OPEN=0 PC+FR GND=POWER	NA	1	0	0
				ADP TPC BOARD ON	45010	3	OPEN OR GND	NA	OPEN=ACT ON GND=CN	NA	1	0	0
				ADP TPC BOARD OFF	26005	4					1	0	0
				CHARGE SELECT LOG1	4 512	4	OPEN OR 20 VDC	NA	OPEN=NOT SELECT 20VDC=SELECTED	NA	1	0	0
				CHARGE SELECT LOG2	46013	4	OPEN OR 20VDC	NA	OPEN=NOT SELECT 20VDC=SELECTED	NA	1	0	0
				CHARGE SELECT LOG3	46014	4	OPEN OR 20 VDC	NA	OPEN=NOT IF MADE 20VDC=IF MADE	NA	1	0	0
				CHARGE SELECT LOG4	21149	4	OPEN OR 20 VDC	NA	20VDC=IF MADE	NA	1	0	0
				CHARGE SELECT LOG5	21146	5	+4.3 VDC TO 0				11	0	00
				CHARGE SELECT LOG6	21147	5	+3.0 VDC TO 0				11	0	00
				CHARGE SELECT LOG7	21149	5					11	0	00
				CHARGE SELECT LOG8	21151	5	-15 VDC TO 0				11	0	00
				CHARGE SELECT LOG9	21152	5	+4.3 VDC TO 0				11	0	00
				CHARGE SELECT LOG10	46073	5					11	0	00
				CHARGE SELECT LOG11	46074	5					11	0	00
				CHARGE SELECT LOG12	46075	5					11	0	00
				CHARGE SELECT LOG13	46075	5					11	0	00
				CHARGE SELECT LOG14	46077	5					11	0	00
				CHARGE SELECT LOG15	46078	5					11	0	00
				CHARGE SELECT LOG16	46079	5					11	0	00
				CHARGE SELECT LOG17	46090	5					11	0	00
				CHARGE SELECT LOG18	46081	5					11	0	00
				CHARGE SELECT LOG19	46082	5					11	0	00
				CHARGE SELECT LOG20	39003	6					11	0	00
				CHARGE SELECT LOG21	39004	6					11	0	00
				CHARGE SELECT LOG22	39005	6					11	0	00
				CHARGE SELECT LOG23	39006	6					11	0	00
				CHARGE SELECT LOG24	39050	6					11	0	00
				CHARGE SELECT LOG25	39051	6					11	0	00

INPUT

8 2 0 IDAMST PROCESSOR 2

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
GUARD SQ ADJ HI	39052	6					11	0	00
GUARD SQ ADJ CT	39053	6					11	0	00
FLUCT MSI (FI)	24020	9					14	0	112
PILOT ROD#	5 24119	9					14	0	112
COMPASS X	46036	9	26 VAC 400HZ				14	0	112
ORC RWI X	46049	9	26 VAC 400HZ				14	0	112
SCEN (IR)	80165	10					512	0	0096
DSNU (IR)	80009	10					16	0	128
W4 (IR)	80033	10					16	0	128
I* 1 (IV)	80017	10					32	0	256
I* 2 (IV)	80021	10					32	0	256
I* SYMBOL (IN)	80013	10					96	0	768
SCALE A	21092	5	0 VDC				1	16	16
STC RANGE	21085	5					11	16	176
STC EPFA	21086	5					11	16	176
RCWR GAIN	21087	5					11	16	176
ISS-FCMU LEVEL	21126	5					11	16	176
AZ STAB (SIN)	21093	7					11	16	176
AZ STAB (COS)	21094	7					11	16	176
ALTITUDE	21134	7					11	16	176
RFI RANGE	21134	7					11	16	176
YEL CONTROL (X,Y,Z)	21015	9					14	16	224
YEL AIRSPEED	26001	9					14	16	224
TELEMET OUTPUT A	46007	10	+-5 VDC				32	16	512
TELEMET CONTROL B	46008	10	+-5 VDC				32	16	512
PHOTO PCXP OUTPT	43036	11					7	16	112
RANGE MARK	43037	11					7	16	112
AZ COURSOR (SIN,COS)	21122	10					14	16	224

SIGNAL NAME	6 2 0	IC4MST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	INPUT
												OPENHND ON/OK SYNCHND CS/FAIL
H1 OFF FAILED RTN			28171	1	0 OR 5 VDC	NA	OPENHND	NA	1	32	32	
TRACK DIST			21063	3	5 VDC	NA	SYNCHND	NA	1	32	32	
SPECTRUM COMP DPT			43055	3					1	32	32	
X REFLECTION			43033	6					11	32	352	
Y REFLECTION			43034	6					11	32	352	
SECOPY WIDTH STA			21045	6	-1.2V TO +1.2 VAC				11	32	352	
SECOPY WIDTH COS			21046	6	0 TO 2.2 VAC				11	32	352	
STRENGTH CHOS 1			16003	10					40	32	2560	
STRENGTH CHOS 2			16004	10					40	32	2560	
STRENGTH CHOS 3			16009	10					40	32	2560	
DATA BUS			28222	10	0 OR 5 VDC	NA	NA	NA	128	32	4096	
DATA BUS IN			28223	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
DATA BUS TO			28224	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
DATA READY			28225	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
DATA READY			28226	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
DATA CLICK			28227	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
DATA CLICK			28228	10	0 OR 5 VDC	NA	NA	NA	16	32	512	
READY VLS (SPI+CCS)			21044	18	0 TO 18 VDC	NA	NA	NA	14	32	448	
READY VLS (SPI)			21041	18					512	64	32768	
READY VLS (CS)			21042	18					512	64	32768	

SIGNAL NAME	ICAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	OUTPUT
LAMP TEST 3ROU'D		43015	3					1	1	1	
LAMP TEST 3POU'NO		43016	3					1	1	1	
LAMP TEST 3POU'NO		43017	3					1	1	1	
REC LEFT TURN LP G		43075	3	+5 VDC		GND=1/OPEN=0		1	1	1	
REC SUGGESTION LP GND		43076	3	+5 VDC				1	1	1	
REC LETDOWN LP GND		43077	3	+5 VDC				1	1	1	
REC EXECUTE LP GND		43078	3	+5 VDC				1	1	1	
REC PULLUP LP GND		43079	3	+5 VDC				1	1	1	
REC SPEED UP LP GND		43080	3	+5 VDC		GND=1/OPEN=0		1	1	1	
REC RIGHT TURN LP G		43081	3	+5 VDC		GND=1/OPEN=0		1	1	1	
LEGEND DIV HI		43012	4	5 VDC				1	1	1	
MASTER LAMP GND		43070	4	0 OR 5 VDC		0VDC=0/5VDC=1		1	1	1	
MASTER LOSS/LAMP GND		43071	4	0 OR 5 VDC		0VDC=0/5VDC=1		1	1	1	
CAUTION LAMP GND		43072	4	0 OR 5 VDC		0VDC=0/5VDC=1		1	1	1	
PRIORITY ALARM LP G		43073	4	0 OR 5 VDC		0VDC=0/5VDC=1		1	1	1	
LEGEND DIM		43011	5	0 TO 5 VDC				11	1	11	
LEGEND DIM		43053	5	0 TO 28 VDC				11	1	11	
LEGEND DIM		43054	5	0 TO 28 VDC				11	1	11	
RT STATUS FLAG		46009	1	0 TO +18-32V				1	1	1	
DISTANCE FLAG		46056	1					1	1	1	
PAW INTERLOCK OUT		46011	3					1	1	1	
SEC DC POWER		27009	4	OPEN OR 24VDC	NA	OPEN=1 OFF GEAR NA		1	2	2	
ENGINE 1 LOOP A		8001	4					1	2	2	
ENGINE 1 LOOP B		8003	4					1	2	2	
ENGINE 2 LOOP A		8005	4					1	2	2	
ENGINE 2 LOOP B		8007	4					1	2	2	
STABILIZER TRI*		11002	3					1	2	2	
MASTER CAUTION (PI)		15001	3					1	2	2	

0 2 0	ICAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R	OUTPUT
	FLC (P)	15003	3					1	2	2	
	AVT-1FE (P)	15004	3					1	2	2	
	FUEL (P)	15005	3					1	2	2	
	CONVERTER AV (P)	15006	3					1	2	2	
	ELECTRICAL (P)	15007	3					1	2	2	
	HYDRAULIC (P)	15008	3					1	2	2	
	CENTER RISE (P)	15009	3					1	2	2	
	SECS (P)	15010	3					1	2	2	
	CALIBRATION (P)	15011	3					1	2	2	
	MEMO UP DISPL IN 1	25015	10					208	2	+16	
	MEMO DISPLAY (P)	26003	10					192	2	384	
	MT 510	32026	2	-5 VDC/+10 VDC				1	2	2	
	MT 105	32027	2	+10 VDC/+5 VDC				1	2	2	
	FOR -TG-TALK	33025	3	GND/OPEN				1	2	2	
	TR -MASTER LCG	43001	3	0 TO 5 VDC				1	2	2	
	TR -MASTER LCS	43002	3	0 TO 5 VDC				1	2	2	
	TR -CG LCS	43003	3	0 TO 5 VDC				1	2	2	
	MASTER LAPS LCG	43004	3	0 TO 5 VDC				1	2	2	
	MASTER LAPS LCC	43005	3	0 TO 5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43006	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43009	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43090	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43092	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43094	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43096	3	5 VDC				1	2	2	
	MIT -TTJTV LP CTL	43098	3	5 VDC				1	2	2	
	RF CONTROL AM#	47002	5					11	2	22	
	EDGE LIGHT	21137	4	26 VDC				1	2	2	

-5VDC=R/+10VDC=X
+5VDC=R/+10VDC=X

GND=1/OPEN=0
GND=1/OPEN=R
GND=1/OPEN=A
GND=1/OPEN=Q
GND=1/OPEN=0
GND=1/OPEN=R
GND=1/OPEN=0

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
50/10 LAMP RTN	21103	3					1	0	0
10/20 LAMP RTN	21154	3					1	0	0
3-30/5 LAMP RTN	21165	3					1	0	0
5-30/1 LAMP RTN	21166	3					1	0	0
240/30 LAMP RTN	21167	3					1	0	0
R0/5 LAMP RTN	21168	3					1	0	0
WAS HEADING RAD	25029	1	+-24 VDC		24VDC=TRUE		1	0	0
RANGE TO DEST UNITS	25023	9		0/9		1/2 MILE MR	14	0	56
PAGE TO DEST TENS	25024	9		0/90			14	0	56
RANGE TO DEST HOURS	25025	9		0/900			14	0	56
BEST REL BEARING	25026	9		0/360 DEG	10FG=1DEG	5 DEG	14	0	56
WAS RECEIVING	25027	9		0/360 DEG	10FG=1DEG	5 DEG	14	0	56
ADC FAIL	27110	1	0 OR 5 VDC	NA	0VDC=ADC OK 5VDC=ADC FAIL	NA	1	0	0
DATA AD (TRUE/COMP)	27092	10	0 OR 5 VDC	NA		NA	160	32	5120
SEVERE FAILED	21074	5					11	0	60
ATTITUDE 3300	25022	1	A/C+28 VDC				1	0	0
UHF RADIO CTRL	36043	3	OPEN 28V CL0 GND		28VDC=TRUE		1	0	0
405 HZ WAKEUP BEACH	41075	3	GND/OPEN		GND=1/OPEN=0		1	0	0
1300HZ 442 BEACH	41076	3	GND/OPEN		GND=1/OPEN=0		1	0	0
3000HZ 142 BEACH	41077	3	GND/OPEN		GND=1/OPEN=0		1	0	0
405 HZ WAKEUP BEACH	41081	3	GND/OPEN		GND=1/OPEN=0		1	0	0
1300HZ 442 BEACH	41082	3	GND/OPEN		GND=1/OPEN=0		1	0	0
3000HZ 142 BEACH	41093	3	GND/OPEN		GND=1/OPEN=0		1	0	0
405 DATA 4	42036	9					14	0	112
530 DATA 5	42037	9					14	0	112
PAGE RATE MAX COUNT	43043	5	0 TO 22 VDC				11	0	80
SERIAL DATA OUT	46053	10	+-12 VDC				120	0	1024
ST COUNT	47036	9					14	0	112

5	2	0	ICAMST PROCESSOR 2	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R
SYG000	Y	47037	9							14	0	112
SP0000	Y	47038	9							14	0	112
SYG000	Z	47039	9							14	0	112
SYG000	Z	47040	9							14	0	112
SENSITIVITY CONTROL		40009	3	OPEN OR GND	NA		CPEN=CONTROL GND=NO CONTROL SVDC=1/SVDC=0		NA	1	0	0
LOAD TEST		51010	1	+5 VDC						1	0	0
LOAD TEST		51011	1	+5 VDC						1	0	0
REFERENCE TARGET ID		51012	1	+5 VDC						1	0	0
TARGET ACQUISITION		51009	4	+5 VDC						1	0	0
SELF TEST		23015	3	GROUND	NA		OPEN=NO SELF TST GND=SELF TST INT OPEN=NO SELF TST		NA	1	0	0
SELF TEST		23053	3	GROUND	NA				NA	1	0	0
SELF TEST		40156	10							16	0	128
SELF TEST		90010	10							16	0	128
SELF TEST		40034	10							32	0	256
1* 1 (OUT)		80018	10							32	0	256
1* 2 (OUT)		80022	10							32	0	256
1* 2 (OUT)		40037	10							96	0	768
1* 1 (OUT)		90026	10							96	0	768
1* 1 (OUT)		90014	10							16	0	128
1* 1 (OUT)		80063	3							1	0	0
1* 2 (OUT)		90064	3							1	0	0
1* 3 (OUT)		80065	3							1	0	0
1* 4 (OUT)		90066	3							1	0	0
1* 5 (OUT)		30067	3							1	0	0
1* 6 (OUT)		80069	3							1	0	0
1* 7 (OUT)		90069	3							1	0	0
1* 8 (OUT)		90070	3							1	0	0
1* 9 (OUT)		40071	3							1	0	0

DATA PROCESSOR 2

OUTPUT

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
WF01-10 (OUT)	90072	3					1	0	0
WF01-11 (OUT)	90073	3					1	0	0
WF01-12 (OUT)	90074	3					1	0	0
WF01-13 (OUT)	90075	3					1	0	0
WF01-14 (OUT)	90076	3					1	0	0
WF01-15 (OUT)	90077	3					1	0	0
WF01-16 (OUT)	90078	3					1	0	0
WF01-17 (OUT)	90079	3					1	5	0
WF01-18 (OUT)	90080	3					1	0	0
WF01-19 (OUT)	90081	3					1	0	0
WF01-20 (OUT)	90082	3					1	0	0
WF01-21 (OUT)	90083	3					1	0	0
WF01-22 (OUT)	90084	3					1	0	0
WF01-23 (OUT)	90085	3					1	0	0
WF01-24 (OUT)	90086	3					1	0	0
WF01-25 (OUT)	90087	3					1	0	0
CCA 1	90041	3					1	0	0
TULLIG PETER	47001	5					11	16	176
45 DEFLECTION	53065	5	5 TO 25 VDC	NA	NA	5	11	16	176
225 REFLECTION	53087	5	0 TO 25 VDC	NA	NA	5	11	16	176
315 REFLECTION	53088	5	0 TO 25 VDC	NA	NA	5	11	16	176
135 REFLECTION	53089	5	0 TO 25 VDC	NA	NA	5	11	16	176
TRUE AIRSPEED	27111	5		NA		1 KNOT	11	32	352
BAROMETRIC ALT	27112	5	0 TO 4 VDC	118 KTS TO 600KT	12.75 FAIL/MV	25 FEET	11	32	352
WACH OUTPUT	27113	5	0 TO 4 VDC	1000 TO 50000 FT	0.19M/VOLT	±.002M/10.5MV	11	32	352
AIR SPEED	28082	5	0 TO ±2.2 VDC	0 TO -2.2 DEG	1VDC/1DEG	0.5 %	11	32	352
GRUPO	28083	5	0 TO ±15 VDC	0 TO 599 KTS	150MV/7KTS	0.5 %	11	32	352
DATA NO (TRUESCOMP)	27093	10	0 OR 5 VDC	NA		NA	160	32	5120

OUTPUT

A 2 0 IQAMST PROCESSOR 2

SIGNAL NAME	SIGIN	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
DATA AC 10 TRAJSCOM	27094	10	0 OR 5 VDC	NA		NA	16	32	512
DATA AC 11 TRAJSCOM	27095	10	0 OR 5 VDC	NA		NA	16	32	512
DATA ACY TRAJSCOMP	27096	10	0 OR 5 VDC	NA		NA	16	32	512
DATA ACY TRAJSCOMP	27097	10	0 OR 5 VDC	NA		NA	16	32	512
TF RELIABILITY	28057	1	OPEN OR +0.300 VDC	NA	OPEN=1 OK +380VDC=TF NO OK	NA	1	32	32
SET RANGE	28097	4	OPEN OR 28VDC	NA	OPEN=NO RANGE 28VDC=1 RANGE	NA	1	32	32
SET RANGE TEST	28098	4	OPEN OR 28VDC	NA	OPEN=NO TEST 28VDC=1 TEST	NA	1	32	32
AD 100% RELIABILITY	28028	1	0 OR 5 VDC	NA	OVDC=OK	NA	1	32	32
LE 100% ALTITUDE	28031	5	0 TO 25 VDC	0-5000 FT	5VDC=1 FT 35V/7FT	7 FEET	11	32	352
LE 100% ALTITUDE	28032	5	0 TO 25 VDC	0-5000 FT	25V/7FT	7 FEET	11	32	352
HA 100% ALTITUDE	28027	5	0 TO 25 VDC	0 TO 5000 FT	35V/7FEET	7 FEET	11	32	352
AD 100% RELIABILITY	28066	1	0 TO 5 VDC	NA	OVDC=OK	NA	1	32	32
LE 100% ALTITUDE	28769	5	0 TO 25 VDC	0-5000 FT	35V/7FT	FEET	11	32	352
LE 100% ALTITUDE	28770	5	0 TO 25 VDC	0-5000 FT	35V/7FT	FEET	11	32	352
STRAPEL 100%	25050	5		+/-10 DEG	150 UG/10 DEG	1/16 DEG	11	32	352
FULL	25018	9		0/360 DEG	10EG=1DEG	0.1 DEG RMS	14	32	448
LOC 10% DEVIATION	41025	6					11	32	352
LOC FLAG OUTPUT	41024	6					11	32	352
GS 10% DEVIATION	41027	6					11	32	352
GS FLAG OUTPUT	41026	6					11	32	352
LOC DEVIATION	41029	6					11	32	352
GS DEVIATION	41030	6					11	32	352
LOC FLAG OUTPUT	41031	6					11	32	352
GS FLAG OUTPUT	41032	6					11	32	352
LOC DEVIATION	41033	6					11	32	352
GS DEVIATION	41034	6					11	32	352
LOC 10% DEVIATION	41059	6					11	32	352
LOC FLAG OUTPUT	41060	6					11	32	352

6 ? 0 IDAWST PROCESSOR 2		OUTPUT							
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	CHAN	U/R	B/R
GS POSN DEVIATION	41061	6					11	32	352
CS FLAG OUTPUT	41062	6					11	32	352
LQC DEVIATION	41067	6					11	32	352
SS DEVIATION	41069	6					11	32	352
CORRECT SIGNAL	43032	6					11	32	352
AVG. A BEARING	49042	9	11.8 VAC	0 TO 360 DEG	1DEG/DEG	12 ARC MIN	14	32	448
AZIMUTH POS (X,Y,Z)	21043	9	0 TO 11.8 VAC				14	64	896
PRTC	25021	9		+-90 DEG	1DEG=10EG	0.1 DEG RMS	14	64	896
PRPG 1 (DJT)	40002	10					16	64	1024
PRPG 2 (DJT)	40004	10					16	64	1024

8 3 C INST PROCESSOR 3

SEAL NAME	TRIG	YMS	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	CUM	U/R	E/R
AUTIC OFF	43159	3	0 VDC		GND=1/OPEN=1		1	2	2
AUTIC RESET	43160	3	0 VDC		GND=1/OPEN=1		1	2	2
115 VAC	43162	3	115 VAC	NA	115 VAC OR OPEN	NA	1	2	2
GROUND	43162	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2
TO BUS/UTOM	43166	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
LEADER (OFFSET)	43106	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
LEADER (OFFSET)	43107	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
LEADER (OFFSET)	43108	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
LEADER (OFFSET)	43109	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
LEADER (OFFSET)	43110	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
ALITICE VDC	43113	4			SVDC=50*/GND=**		1	2	2
ALT OFFSET (VDC)	43114	4			SVDC=**50/GND=**		1	2	2
TRK OFFSET (VDC)	43119	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
TRK OFFSET (VDC)	43119	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
TRK OFFSET (VDC)	43120	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
TRK OFFSET (VDC)	43121	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
TRK OFFSET (VDC)	43122	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
LEFT/RIGHT SWITCH	43123	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43124	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43125	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43126	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43127	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43128	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43129	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
XTR OFFSET (VDC)	43130	4	+5 VDC TO 0 VDC		GND=1/SVDC=0		1	2	2
LEADER SW (TT205)	43131	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
PROX (PUS SWIP/50)	43135	4	0 TO 5 VDC		GND=1/SVDC=0		1	2	2
PROX (PUS SWIP/50)	43136	4	0 TO 5 VDC		SVDC=1/GND=0		1	2	2

SIGNAL NAME	6	4	0	TRMST PROCESSOR 3	SIGIC	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
PRDY #A3 SAIF#52)	43137	4	0 TO 5 VDC					5VDC=1/GND=0			1	2	2
PRDY #A3 SAIP#51)	43138	4	0 TO 5 VDC					5VDC=1/GND=0			1	2	2
ECITE LIGHT	21137	4	24 VDC								1	2	2
ALT OFFSET VOLTAGE	43115	5	+2.7 TO 5.1 VDC								11	2	22
RANGE DELAY	21119	1	+5 VDC								1	4	4
DE- 1 (I)	A0027	1									1	0	0
LE- 2 (I)	A0031	1									1	0	0
VF-C2- 1 (I)	80139	1									1	0	0
VF-C2- 2 (I)	80139	1									1	0	0
VF-C2- 3 (I)	80140	1									1	0	0
VF-C2- 4 (I)	80141	1									1	0	0
VF-C2- 5 (I)	80142	1									1	0	0
VF-C2- 6 (I)	80143	1									1	0	0
VF-C2- 7 (I)	80144	1									1	0	0
VF-C2- 8 (I)	80145	1									1	0	0
VF-C2- 9 (I)	80146	1									1	0	0
VF-C2-10 (I)	80147	1									1	0	0
VF-C2-11 (I)	80148	1									1	0	0
VF-C2-12 (I)	80149	1									1	0	0
VF-C2-13 (I)	80150	1									1	0	0
VF-C2-14 (I)	80151	1									1	0	0
VF-C2-15 (I)	80152	1									1	0	0
VF-C2-16 (I)	80153	1									1	0	0
VF-C2-17 (I)	80154	1									1	0	0
VF-C2-18 (I)	80155	1									1	0	0
VF-C2-19 (I)	80156	1									1	0	0
VF-C2-20 (I)	80157	1									1	0	0
VF-C2-21 (I)	80158	1									1	0	0

SIGNAL NAME	2	3	6	IPAMST PROCESSOR 3	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	INPUT	RESOLUTION	QUAN	U/R	A/R
MFC02-22 (I%)					AO159	1						1	0	0
MFC02-23 (I%)					AO160	1						1	0	0
MFC02-24 (I%)					AO161	1						1	0	0
MFC02-25 (I%)					AO162	1						1	0	0
3-30 DC LEVEL					21141	7						11	0	00
CONTROL JUP (F)					24149	9						14	0	112
CONTROL 2041 R					24219	9						14	0	112
SC1 (I%)					AO167	10						512	0	4096
CS1 (I%)					AO011	10						16	0	128
AW (I%)					AO035	10						16	0	128
IM 1 (I%)					AO019	10						32	0	256
IM 2 (I%)					AO023	10						32	0	256
IM 3 (I%)					AO015	10						96	0	768
MFC 1 (I%)					AO005	10						512	64	32768
MFC 2 (I%)					AO007	10						512	64	32768

SIGNAL NAME	8	3	0	IDWAST PROCESSOR 3	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	OUTPUT		
											QUAN	U/R	B/R
ENGINE 1 LOOP A					8002	4					1	2	2
ENGINE 1 LOOP B					8004	4					1	2	2
ENGINE 2 LOOP A					8006	4					1	2	2
ENGINE 2 LOOP B					8008	4					1	2	2
STABILIZER TRIM					11001	3					1	2	2
MASTER CAUTION (C)					15002	3					1	2	2
BLC (C)					15013	3					1	2	2
ANTI-ICE (C)					15014	3					1	2	2
FUEL (C)					15015	3					1	2	2
OVERHEAD PANEL (C)					15016	3					1	2	2
ELECTRICAL (C)					15017	3					1	2	2
HYDRAULIC (C)					15018	3					1	2	2
CYCLE SLIDE (C)					15019	3					1	2	2
LEGS (C)					15020	3					1	2	2
CALCUL RECALL (C)					15021	3					1	2	2
OMEGA DISPLAY (C)					26004	10					192	2	384
ALTITUDE REFERENCE					43111	5	0 TO 5.5 VDC				11	2	22
FUSE					53081	1	115 VAC	NA	OPEN OR 115 VAC	NA	1	2	2
FUSE					53082	1	115 VAC	NA	OPEN OR 115 VAC	NA	1	2	2
POWER LAMP					53003	3	115 VAC	NA	115 VAC OR OPEN	NA	1	2	2
ACTIVITY TEST					53004	3	25 VDC	NA	25 VDC OR GND	NA	1	2	2
LATCH TEST					53005	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2
ACTIVITY (INDICATOR)					53006	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2
LATCH (INDICATOR)					53007	3	GROUND	NA	GROUND OR OPEN	NA	1	2	2
ACTIVITY TEST					53061	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2
ACTIVITY LAMP					53062	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2
LATCH LAMP					53064	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2
LATCH TEST					53066	3	GROUND	NA	GROUND AND OPEN	NA	1	2	2

SIGNAL NAME	8	3	0	100MST PROCESSOR 3	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	OUTPUT
DIST Y UNITS					4606A	5					11	4	44	
DIST Y TENS					46069	5					11	4	44	
DIST Y HUNDS					46070	5					11	4	44	
AZ STAR (ST)					21075	7					11	4	44	
400 HZ MARKER BEACH					41017	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
1300 HZ MARKER BEACH					41018	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
3000 HZ MARKER BEACH					41019	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
400 HZ MARKER BEACH					4107A	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
1300 HZ MARKER BEACH					41079	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
3000 HZ MARKER BEACH					41090	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
400 HZ MARKER BEACH					41094	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
1300 HZ MARKER BEACH					41095	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
3000 HZ MARKER BEACH					41096	3	GND/OPEN		GND=1/OPEN=0		1	6	6	
4000 IDENT					51023	1	+5 VDC		5VDC=1/6VDC=0		1	6	6	
6000 IDENT					51024	1	+5 VDC		5VDC=1/6VDC=0		1	6	6	
HIGH-LOW TRIG ID					51025	1	+5 VDC		5VDC=1/6VDC=0		1	6	6	
TRIGGER ADJUSTION					51022	4	+5 VDC		5VDC=1/6VDC=0		1	6	6	
28.00 P. F.					28189	4	CPFN OR 28 VDC	NA	OPEN=NOT TR. MODE 28VDC=TF. MODE		1	6	6	
TO/FROM (A-FROM)					46073	5					11	6	66	
OSCILLATION (LEFT)					46074	5					11	6	66	
TO/FROM (RTD)					46075	5					11	6	66	
OSCILLATION (RIGHT)					46076	5					11	6	66	
NAV FLBS L					46077	5					11	6	66	
NAV FLBS H					4607A	5					11	6	66	
CRS-D					46079	5					11	6	66	
CRS-F					46080	5					11	6	66	
CRS-R					46081	5					11	6	66	
CRS-L					46082	5					11	6	66	

PARAMETER	UNIT	VALUE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	R/R
COMPASS		46086	26 VAC 400HZ				14	8	112
SECT 1 (OUT)		46089	26 VAC 400HZ				14	8	112
SECT 2 (OUT)		46108					16	8	128
SECT 3 (OUT)		46112					16	8	128
SECT 4 (OUT)		46136					32	8	256
SECT 5 (OUT)		46139					32	0	256
SECT 6 (OUT)		46142					32	8	256
SECT 7 (OUT)		46128					96	8	768
SECT 8 (OUT)		46132					96	8	768
SECT 9 (OUT)		46116					16	8	128
SECT 10 (OUT)		46045					1	8	8
SECT 11 (OUT)		46046					1	8	8
SECT 12 (OUT)		46047					1	8	8
SECT 13 (OUT)		46048					1	8	8
SECT 14 (OUT)		46049					1	8	8
SECT 15 (OUT)		46047					1	8	8
SECT 16 (OUT)		46048					1	8	8
SECT 17 (OUT)		46049					1	8	8
SECT 18 (OUT)		46050					1	8	8
SECT 19 (OUT)		46051					1	8	8
SECT 20 (OUT)		46052					11	8	88
SECT 21 (OUT)		46053					11	8	88
SECT 22 (OUT)		46113					1	8	8
SECT 23 (OUT)		46114					1	8	8
SECT 24 (OUT)		46115					1	8	8
SECT 25 (OUT)		46116					1	8	8
SECT 26 (OUT)		46117					1	8	8
SECT 27 (OUT)		46118					1	8	8
SECT 28 (OUT)		46119					1	8	8

IDAMST PROCESSOR 3										OUTPUT		
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	9/R			
MF0C2-8 (OUT)	80120	3					1	0	0			
MF0C2-9 (OUT)	80121	3					1	0	0			
MF0C2-10 (OUT)	80122	3					1	0	0			
MF0C2-11 (OUT)	80123	3					1	0	0			
MF0C2-12 (OUT)	80124	3					1	0	0			
MF0C2-13 (OUT)	80125	3					1	0	0			
MF0C2-14 (OUT)	80126	3					1	0	0			
MF0C2-15 (OUT)	80127	3					1	0	0			
MF0C2-16 (OUT)	80128	3					1	0	0			
MF0C2-17 (OUT)	80129	3					1	0	0			
MF0C2-18 (OUT)	80130	3					1	0	0			
MF0C2-19 (OUT)	80131	3					1	0	0			
MF0C2-20 (OUT)	80132	3					1	0	0			
MF0C2-21 (OUT)	80133	3					1	0	0			
MF0C2-22 (OUT)	80134	3					1	0	0			
MF0C2-23 (OUT)	80135	3					1	0	0			
MF0C2-24 (OUT)	80136	3					1	0	0			
MF0C2-25 (OUT)	80137	3					1	0	0			
CCA 2	80062	3					1	4	8			
N5 REFLECTION	53095	5	0 TO 25 VDC	NA	NA	5	11	16	176			
225 REFLECTION	53096	5	0 TO 25 VDC	NA	NA	5	11	16	176			
315 REFLECTION	53097	5	0 TO 25 VDC	NA	NA	5	11	16	176			
135 REFLECTION	53098	5	0 TO 25 VDC	NA	NA	5	11	16	176			
SCA' A	21092	3	0 VDC				1	16	16			
150-ECHO LEVEL	21126	5					11	16	176			
AZ STAR (ST4)	21093	7					11	16	176			
AZ STAR (CDS)	21094	7					11	16	176			
ALTITUDE	21133	7					11	16	176			

TRANSISTOR PROCESSOR 3									
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/M	S/R
OUT RANGE	21134	7					11	15	176
RELIABILITY (S/N) TEST	21122	18					14	16	224
RELIABILITY	28211	5	0 TO +2.2 VDC	0 TO -2.2 SEC	1VDC/1000	0.5 %	11	32	352
RELIABILITY	28214	5	0 TO +15 VDC	0 TO 500 NTC	1500V/7475	0.5 %	11	32	352
RELIABILITY	28193	1	OPEN OR +0.380 VDC	NA	OPEN/OK	NA	1	32	32
RELIABILITY TEST	28173	4	OPEN OR 0 VDC	NA	2800V/2000 NA OK OPEN/OK 2800V/2000 NA	NA	1	32	32
RELIABILITY	28192	5	0 TO +2.2 VDC	0 TO -2.2 SEC	1VDC/1000	NA	11	32	352
RELIABILITY	28163	5	0 TO +25 VDC	0 TO 5.000 FT	350V/7FEET	7 FEET	11	32	352
RELIABILITY	41063	6					11	32	352
RELIABILITY	41064	6					11	32	352
RELIABILITY	41065	6					11	32	352
RELIABILITY	41066	6					11	32	352
RELIABILITY	43112	5					11	32	352
RELIABILITY	28171	1	0 OR 5 VDC	NA	OPEN/OK ON/OK 5VDC/500 OF/FAIL	NA	1	32	32
RELIABILITY	28222	10	0 OR 5 VDC	NA	NA	NA	128	32	4096
RELIABILITY	28223	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY	28224	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY	28225	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY	28226	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY	28227	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY	28228	10	0 OR 5 VDC	NA	NA	NA	16	32	512
RELIABILITY (DJT)	50006	10					16	64	1024
RELIABILITY (DJT)	90002	10					16	64	1024

SIGNAL NAME	S & D	PARAMS AND DISPLAYS			INPUT				
		SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R
SCM (OUT)		80166	10				16	0	128
SCM (OUT)		80163	10				16	0	128
DSM (OUT)		80010	10				16	0	128
DSM (OUT)		80012	10				16	0	128
MM (OUT)		80024	10				32	0	256
MM (OUT)		80036	10				32	0	256
IM 1 (OUT)		80018	10				32	0	256
IM 2 (OUT)		80022	10				32	0	256
DEK 2 (OUT)		80030	10				96	0	768
IM 1 (OUT)		80020	10				32	0	256
IM 2 (OUT)		80024	10				32	0	256
DEK 1 (OUT)		80026	10				96	0	768
DEK 1 (OUT)		80023	10				96	0	768
DEK 2 (OUT)		80032	10				96	0	768
IM SYMBOL (OUT)		80014	10				16	0	128
IM SYMBOL (OUT)		80016	10				16	0	128
MA 0 COUNTER 1 (OUT)		80043	3				1	0	0
MA 0 COUNTER 2 (OUT)		80044	3				1	0	0
MA 0 COUNTER 3 (OUT)		80045	3				1	0	0
MA 0 COUNTER 4 (OUT)		80046	3				1	0	0
MA 0 COUNTER 5 (OUT)		80047	3				1	0	0
MA 0 COUNTER 6 (OUT)		80048	3				1	0	0
MA 0 COUNTER 7 (OUT)		80049	3				1	0	0
MA 0 COUNTER 8 (OUT)		80050	3				1	0	0
MA 0 COUNTER 9 (OUT)		80051	3				1	0	0
MA 0 COUNTER 10 (OUT)		80052	7				11	0	88
MA 0 COUNTER 11 (OUT)		80053	7				11	0	88
MA 0 COUNTER 12 (OUT)		80170	10				512	64	32768

INST CONTROLS AND DISPLAYS				INPUT					
SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
DIT RECORDER (OUT)	A0172	10					32	0	256
APOS 1 (OUT)	A0002	10					16	64	1024
APOS 1 (OUT)	A0006	10					16	64	1024
APOS 2 (OUT)	A0004	10					16	64	1024
APOS 2 (OUT)	A0009	10					16	64	1024
APOS 1 (OUT)	A0063	3					1	0	0
APOS 2 (OUT)	A0064	3					1	0	0
APOS 3 (OUT)	A0065	3					1	0	0
APOS 4 (OUT)	A0066	3					1	0	0
APOS 5 (OUT)	A0067	3					1	0	0
APOS 6 (OUT)	A0068	3					1	0	0
APOS 7 (OUT)	A0069	3					1	0	0
APOS 8 (OUT)	A0070	3					1	0	0
APOS 9 (OUT)	A0071	3					1	0	0
APOS 10 (OUT)	A0072	3					1	0	0
APOS 11 (OUT)	A0073	3					1	0	0
APOS 12 (OUT)	A0074	3					1	0	0
APOS 13 (OUT)	A0075	3					1	0	0
APOS 14 (OUT)	A0076	3					1	0	0
APOS 15 (OUT)	A0077	3					1	0	0
APOS 16 (OUT)	A0078	3					1	0	0
APOS 17 (OUT)	A0079	3					1	0	0
APOS 18 (OUT)	A0080	3					1	0	0
APOS 19 (OUT)	A0081	3					1	0	0
APOS 20 (OUT)	A0082	3					1	0	0
APOS 21 (OUT)	A0083	3					1	0	0
APOS 22 (OUT)	A0084	3					1	0	0
APOS 23 (OUT)	A0085	3					1	0	0

SIGNAL NAME	6	5	0	IOAPST CONTROLS AND DISPLAYS	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
MFC01-24 (DUT)					80086	3					1	0	0
MFC01-25 (DUT)					80087	3					1	0	0
MFC02- 1 (DUT)					80113	3					1	0	0
MFC02- 2 (DUT)					80114	3					1	0	0
MFC02- 3 (DUT)					80115	3					1	0	0
MFC02- 4 (DUT)					80116	3					1	0	0
MFC02- 5 (DUT)					80117	3					1	0	0
MFC02- 6 (DUT)					80118	3					1	0	0
MFC01- 7 (DUT)					80119	3					1	0	0
MFC02- 8 (DUT)					80120	3					1	0	0
MFC02- 9 (DUT)					80121	3					1	0	0
MFC02-10 (DUT)					80122	3					1	0	0
MFC02-11 (DUT)					80123	3					1	0	0
MFC02-12 (DUT)					80124	3					1	0	0
MFC02-13 (DUT)					80125	3					1	0	0
MFC02-14 (DUT)					80126	3					1	0	0
MFC02-15 (DUT)					80127	3					1	0	0
MFC02-16 (DUT)					80128	3					1	0	0
MFC02-17 (DUT)					80129	3					1	0	0
MFC02-18 (DUT)					80150	3					1	0	0
MFC02-19 (DUT)					80131	3					1	0	0
MFC02-20 (DUT)					80132	3					1	0	0
MFC02-21 (DUT)					80133	3					1	0	0
MFC02-22 (DUT)					80134	3					1	0	0
MFC02-23 (DUT)					80135	3					1	0	0
MFC02-24 (DUT)					80136	3					1	0	0
MFC02-25 (DUT)					80137	3					1	0	0
CCA 1					80661	3					1	0	0

6 4 0	EDMST CONTROLS AND DISPLAYS	INPUT	QUAN	U/R	B/R
SIGNAL NAME	SIGID TYPE VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	
CCA 2	00062 3		1	0	0

SIGNAL NAME	SIGID	TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R	OUTPUT
SCAV (IN)	80165	10					512	0	4096	
SCAR (IN)	80167	10					512	0	4096	
CS-V (IN)	80009	10					16	0	128	
CS-U (IN)	80011	10					16	0	128	
MV (IN)	80033	10					16	0	128	
MV (IN)	80035	10					16	0	128	
I ₁ 1 (IN)	80017	10					32	0	256	
I ₁ 2 (IN)	80021	10					32	0	256	
GE-1 (IN)	80027	1					1	0	0	
I ₁ 1 (IN)	80019	10					32	0	256	
I ₁ 2 (IN)	80023	10					32	0	256	
DE-1 (IN)	80025	1					1	0	0	
DEK 2 (IN)	80029	1					1	0	0	
DE-2 (IN)	80031	1					1	0	0	
I ₁ SYM32 (IN)	80013	10					96	0	768	
I ₁ SYM32 (IN)	80015	10					96	0	768	
MISSION PCDR (IN)	80169	10					32	0	256	
FFC2-1 (IN)	80138	1					1	0	0	
FFC2-2 (IN)	80139	1					1	0	0	
FFC2-3 (IN)	80140	1					1	0	0	
FFC2-4 (IN)	80141	1					1	0	0	
FFC2-5 (IN)	80142	1					1	0	0	
FFC2-6 (IN)	80143	1					1	0	0	
FFC2-7 (IN)	80144	1					1	0	0	
FFC2-8 (IN)	80145	1					1	0	0	
FFC2-9 (IN)	80146	1					1	0	0	
FFC2-10 (IN)	80147	1					1	0	0	
FFC2-11 (IN)	80149	1					1	0	0	

SIGNAL NAME	SCALE	UNIT	PARAMETER RANGE	VOLTAGE RANGE	SCALE FACTOR	OUTPUT	QUAN	U/R	B/R
MECC2-12 (IN)		1	80143				1	0	0
MECC2-17 (IN)		1	80150				1	0	0
MECC2-14 (IN)		1	80151				1	0	0
MECC2-15 (IN)		1	80152				1	0	0
MECC2-16 (IN)		1	80153				1	0	0
MECC2-17 (IN)		1	80154				1	0	0
MECC2-18 (IN)		1	80155				1	0	0
MECC2-19 (IN)		1	80156				1	0	0
MECC2-20 (IN)		1	80157				1	0	0
MECC2-21 (IN)		1	80158				1	0	0
MECC2-22 (IN)		1	80159				1	0	0
MECC2-23 (IN)		1	80160				1	0	0
MECC2-24 (IN)		1	80161				1	0	0
MECC2-25 (IN)		1	80162				1	0	0
DITS REORDER (IN)		10	80171				512	0	4096
MPG 1 (IN)		10	80001				512	64	32768
MPG 1 (IN)		10	80005				512	64	32768
MPG 2 (IN)		10	80003				512	64	32768
MPG 2 (IN)		10	80007				512	64	32768
MECC1- 1 (IN)		1	80048				1	0	0
MECC1- 2 (IN)		1	80089				1	0	0
MECC1- 3 (IN)		1	80090				1	0	0
MECC1- 4 (IN)		1	80091				1	0	0
MECC1- 5 (IN)		1	80092				1	0	0
MECC1- 6 (IN)		1	80093				1	0	0
MECC1- 7 (IN)		1	80094				1	0	0
MECC1- 8 (IN)		1	80095				1	0	0
MECC1- 9 (IN)		1	80096				1	0	0

8 5 0		ICAMST CONTROLS AND DISPLAYS				OUTPUT		
SIGNAL NAME	SIRIO TYPE	VOLTAGE RANGE	PARAMETER RANGE	SCALE FACTOR	RESOLUTION	QUAN	U/R	B/R
MFDC1-10 (IN)	80097	1				1	0	0
MFDC1-11 (IN)	80098	1				1	0	0
MFDC1-12 (IN)	80099	1				1	0	0
MFDC1-13 (IN)	80100	1				1	0	0
MFDC1-14 (IN)	80101	1				1	0	0
MFDC1-15 (IN)	80102	1				1	0	0
MFDC1-16 (IN)	80103	1				1	0	0
MFDC1-17 (IN)	80104	1				1	0	0
MFDC1-18 (IN)	80105	1				1	0	0
MFDC1-19 (IN)	80106	1				1	0	0
MFDC1-20 (IN)	80107	1				1	0	0
MFDC1-21 (IN)	80108	1				1	0	0
MFDC1-22 (IN)	80109	1				1	0	0
JFDC1-23 (IN)	80110	1				1	0	0
MFDC1-24 (IN)	80111	1				1	0	0
MFDC1-25 (IN)	80112	1				1	0	0