## **Naval Research Laboratory**

Stennis Space Center, MS 39529-5004



NRL/MR/7320--02-8289

## **Software Design Document for the Navy Standard Surf Model Version 3.2**

THEODORE R. METTLACH MARSHALL D. EARLE

Neptune Sciences, Inc. Slidell, Louisiana

Y. LARRY HSU

Ocean Dynamics and Prediction Branch Oceanography Division

December 20, 2002

DOCUMENTS

Reproduced From Best Available Copy FROM ORIGINAL

# 20030312 221

Approved for public release; distribution is unlimited.

|   |  |   |  | Form Approved  |  |
|---|--|---|--|--|--|
|   |  |   | e time for reviewing in  | OMB No. 0704-0188  |  |
| Public reporting burden for<br>maintaining the data needs<br>suggestions for reducing the<br>Suite 1204, Arlington, VA 2<br>information if it does not di   | this collection of information<br>ed, and completing and revie<br>his burden to Department of I<br>2202-4302. Respondents sh<br>splay a currently valid OMB of | is estimated to average 1 no<br>wing this collection of informa<br>Defense, Washington Headqu<br>ould be aware that notwithsta<br>control number. PLEASE DO | ation. Send comments regard<br>Jarters Services, Directorate<br>anding any other provision of<br>NOT RETURN YOUR FOR | ding this burden estimation operation of the state of the | te or any other aspect of this collection of information, including<br>ons and Reports (0704-0188), 1215 Jefferson Davis Highway,<br>a subject to any penalty for failing to comply with a collection of<br>DRESS. |
| 1. REPORT DATE (<br>December 20, 20   | DD-MM-YYYY)<br>02  | 2. REPORT TYPE<br>Memorandum F  | Report   |  | 3. DATES COVERED (From - To)   |
| 4. TITLE AND SUB  | TITLE  | <u></u>   | <u>,,</u>  | 1  | 5a. CONTRACT NUMBER  |
| Software Design   | Document for the Na  | vy Standard Surf Mo   | del Version 3.2  | ł  | 5b. GRANT NUMBER   |
|   |  |   |  |  | 5c. PROGRAM ELEMENT NUMBER<br>603207N  |
| 6. AUTHOR(S)  |  |   |  | ł  | 5d. PROJECT NUMBER<br>X2342  |
| Theodore Mettla   | h * Marshall Earle *   | and Y. Larry Hsu  |  | 1  | ie. TASK NUMBER  |
| Theodore Metha  | , will bland 2.110,  |   |  |  | if. WORK UNIT NUMBER   |
| 7. PERFORMING O   | RGANIZATION NAM  | E(S) AND ADDRESS  | (ES)   | . 8  | 8. PERFORMING ORGANIZATION REPORT<br>NUMBER  |
| Naval Research L<br>Oceanography Di<br>Stennis Space Ce   | aboratory<br>vision<br>nter, MS 39529-5004   |   |  |  | NRL/MR/732002-8289   |
| 9. SPONSORING /   | MONITORING AGEN  | CY NAME(S) AND AI   | DDRESS(ES)   |  | IO. SPONSOR / MONITOR'S ACRONYM(S)   |
| Commander, Spa  | ce and Warfare System  | ms Command  |  |  | SPAWAR   |
| PMW 185<br>4301 Pacific Highway OT-1<br>San Diego, CA 92110-3127  |  |   |  |  | 1. SPONSOR / MONITOR'S REPORT<br>NUMBER(S)   |
| 12. DISTRIBUTION / AVAILABILITY STATEMENT   |  |   |  |  |  |
| Approved for put  | olic release; distribution   | on is unlimited.  |  |  |  |
| 13. SUPPLEMENTA   | ARY NOTES  |   |  |  |  |
| *Neptune Science  | es, Inc., 40201 Highw  | ay 190 East, Slidell,   | LA 70461   |  |  |
| 14. ABSTRACT<br>This Software Design Document (SDD) is written for the updated Navy Standard Surf Model, Version 3.2, or SURF 3.2, submitted to the<br>Oceanographic and Atmospheric Master Library (OAML). The new model includes improved wave refraction, modified surf index, and beach<br>slope computations, and many other refinements such as reduced user input. An overview of the surf model and scientific equations for wave and<br>longshore current computations are included. The SDD provides descriptions of software design and code. Detailed explanations of input param-<br>eters and model options are included. |  |   |  |  |  |
| 15. SUBJECT TERI  | MS   |   |  |  |  |
| SDD; OAML; Na   | avy Standard Surf Mo   | odel; Surf  |  |  |  |
| 16. SECURITY CLASSIFICATION OF:   |  |   | 17. LIMITATION<br>OF ABSTRACT  | 18. NUMBER<br>OF PAGES   | 19a. NAME OF RESPONSIBLE PERSON<br>Larry Hsu   |
| a. REPORT   | b. ABSTRACT  | c. THIS PAGE  | UL   | 189  | <b>19b. TELEPHONE NUMBER</b> (include area code) (228) 688 5260  |
| Unclassified  | Unclassified   | Unclassified  |  |  | (220) 088-3200<br>Standard Form 298 (Rev. 8-98)  |
|   |  |   | i  |  | Prescribed by ANSI Std. Z39.18   |

## TABLE OF CONTENTS

| 1.0 | SCO          | PE   | 1      |
|-----|--------------|--|--------|
|     | 1.1<br>1.2   | Identification<br>Document Overview                    | 1<br>1 |
| 2.0 | REF          | ERENCED DOCUMENTS                                      | 1      |
| 3.0 | PRE          | LIMINARY DESIGN  | 3      |
|     | 3.2          | CSCI Overview  | 3      |
|     |              | <ul> <li>3.1.1 Wave and Roller Energy Models</li></ul> | 3      |
|     |              | 3.1.3 Longshore Current Calculations                   | 5      |
|     |              | 3.1.4 Directional Energy Spectra                       | 6      |
|     |              | 5.1.5 Differences between SUKF 5.1 and SUKF 5.2        |        |
| 4.0 | ARC          | HITECTURAL DESIGN                                      | 8      |
| 5.0 | CSC          | I DETAILED DESIGN                                      | 10     |
|     | 5.1          | Program SURF   | 10     |
|     | 5.2          | Subroutine ABORT                                       | 14     |
|     | 5.3          | Subroutine BALANCEQ                                    | 17     |
|     | 5.4          | Subroutine C_FINE                                      | 20     |
|     | 5.5          | Subroutine C_GAMMA                                     | 22     |
|     | 5.6          | Subroutine C_IN_DEP                                    | 23     |
|     | 5.7          | Subroutine C_REGRID                                    | 26     |
|     | 5.8          | Subroutine C_UN  |        |
|     | 5.9          | Subroutine CALC_HB3                                    | 30     |
|     | 5.10         | Subroutine CALCROLL                                    | 32     |
|     | 5.11         | Subroutine CALCSURF                                    | 34     |
|     | 5.12         | Subroutine DEPDKVR                                     | 39     |
|     | 5.15<br>5.14 | Subroutine EQUILPRF                                    | 41     |
|     | 5.14         | Subroutine CET DDV                                     |        |
|     | J.1J<br>5 16 | Subrouting CET DISS                                    |        |
|     | 5.10         | Subrouting CET M                                       |        |
|     | 5.17         | Subroutine CET D                                       |        |
|     | 5.10         |  | 52     |

iii This document contains blank pages that were not filmed

| 5.19 | Subroutine GET_RHS   |                |
|------|----------------------|----------------|
| 5.20 | Subroutine GET_SLOPE |                |
| 5.21 | Subroutine GET_WAVE  | 50<br>58       |
| 5.22 | Subroutine GRID_FRC  | 50<br>60       |
| 5.23 | Subroutine GRIDOUT   | 00             |
| 5.24 | Subroutine GT_P      | 0J<br>65       |
| 5.25 | Subroutine GT SIG H  | 0J<br>67       |
| 5.26 | Subroutine INITLIZE  | 07             |
| 5.27 | Subroutine KLONG     | 07<br>71       |
| 5.28 | Subroutine LIN_1     | 71<br>7/       |
| 5.29 | Subroutine LIN_2     |                |
| 5.30 | Subroutine LIN_3     | 70<br>78       |
| 5.31 | Subroutine LIN_4     | 07<br>08       |
| 5.32 | Subroutine LONG1     | 00<br>         |
| 5.33 | Subroutine MAIN WAV  | 02<br>QA       |
| 5.34 | Subroutine MDSRF1    | 0 <del>1</del> |
| 5.35 | Subroutine MDSRF2    | 00             |
| 5.36 | Subroutine NEW BRK   | 91             |
| 5.37 | Subroutine PERCENT   | 95             |
| 5.38 | Subroutine PRT OUT1  |                |
| 5.39 | Subroutine PRT OUT2  | 100            |
| 5.40 | Subroutine PRT OUT3  | 100            |
| 5.41 | Subroutine PT2       | 102            |
| 5.42 | Subroutine RAD_ST1   | 105            |
| 5.43 | Subroutine RAD_ST2   | 103            |
| 5.44 | Subroutine READRFRC  | 110            |
| 5.45 | Subroutine READSPEC  | 114            |
| 5.46 | Subroutine REFRAC    | 117            |
| 5.47 | Subroutine RN2       | 110            |
| 5.48 | Subroutine S_COEFF   | 121            |
| 5.49 | Subroutine S_NOSURF  | 121            |
| 5.50 | Subroutine S_TIDE    | 126            |
| 5.51 | Subroutine SEAFIT    | 128            |
| 5.52 | Subroutine SETUP     | 131            |
| 5.53 | Subroutine SHORTOUT  | 133            |
| 5.54 | Subroutine SLF_STRT  | 136            |
| 5.55 | Subroutine SRFSETUP  | 139            |
| 5.56 | Subroutine STRFRAC   | 142            |
| 5.57 | Subroutine SUMMARY   | 145            |
| 5.58 | Subroutine SURFCAST  | 148            |
| 5.59 | Subroutine SWLFIT    | 151            |
| 5.60 | Subroutine WAVEFIT   | 153            |
| 5.61 | Subroutine WAVENUM   | 155            |
| 5.62 | Subroutine WEIGHTFN  | 157            |
| 5.63 | Subroutine ZONE1     | 159            |
| 5.64 | Function F2          | 162            |
|      |                      |                |

,

•

.

.

| 5.65       | Function F3                   |     |
|------------|-------------------------------|-----|
| 5.66       | Function INTEGRAT             |     |
| 5.67       | Include File: COMMON.INC      |     |
| ACKNOWLI   | EDGEMENTS                     | 169 |
| APPENDICE  | ES                            | 170 |
| Appendix A | Input and Output File Formats |     |
| Appendix B | Error Message Description     |     |
| Appendix C | Flowchart Symbol Index        |     |
| Appendix D | Acronyms                      |     |

v

,

•

#### SOFTWARE DESIGN DOCUMENT FOR THE NAVY STANDARD SURF MODEL VERSION 3.2

#### 1.0 SCOPE

#### 1.1 Identification

This Software Design Document (SDD) is written for the Navy Standard Surf Model, version 3.2, or SURF 3.2. SURF 3.2 will be called SURF hereafter. SURF provides users with an automated method for determining surf conditions and related environmental parameters. The model produces a standard surf forecast such as breaker height, longshore current, and a modified surf index (MSI) number, which are Navy requirements for littoral operations and amphibious landings (see Joint Surf Manual). The first operational Navy surf forecasting computer model was developed for the Fleet in 1988 (Earle, 1988) to supplement the manual and visual techniques developed in the 1950's. The manual procedures are subjective and do not adequately consider shallow water effects such as wave shoaling and refraction. SURF is a modern numerical model and has been validated by field and laboratory data (Hsu et al. 2000 and 2002).

#### **1.2 Document Overview**

This OAML SDD describes the design, structure, and scientific aspects of the Computer Software Configuration Item (CSCI) titled SURF. This document provides a detailed summary of all Computer Software Units (CSU) or subroutines, input file formats, output file formats, and userspecified options. The SDD is divided into three sections: the Preliminary Design, the Architectural Design, and the Detailed Design.

The Preliminary Design section describes the scientific aspects of SURF including a brief description of the mathematical formulation and theory behind the model. The Architectural Design section outlines the structural design of SURF with a graphical representation of the CSU calling sequence. The Detailed Design section identifies and summarizes the operation of each CSU including detailed listings of input variables, output variables, local variables, calling routines, and called routines and/or called functions.

#### 2.0 REFERENCED DOCUMENTS

Battjes, J.A., Modeling of Turbulence in the Surf Zone, Proceedings of the Symposium on Modeling Techniques, San Francisco, ASCE, pp. 1050-1061, 1975.

COMNAVSURFPAC / COMNAVSURFLANT, Joint Surf Manual, 3840.1B, 1987.

- Dean, R.G. Ocean Engineering Technical Report No. 12, "Equilibrium Beach Profiles: U.S. Atlantic and Gulf Coasts, University of Delaware, 45 pp., 1977.
- Earle, M.D., Surf Forecasting Software Improvements, MEC Systems Corp. contract report: N00014-91-C-6011 to NRL (Formerly Naval Oceanographic and Atmospheric Research Laboratory, NORDA), 1991.
- Earle, M.D., Surf Forecasting Software User's Manual, NRL (Formerly Naval Oceanographic and Atmospheric Research Laboratory, NORDA) Tech. Note 352, ASW Oceanography

Manuscript approved October 11, 2002.

Program Office, 1988.

- Earle, M.D., Surf Forecasting Software Scientific Reference Manual, NRL (Formerly Naval Oceanographic and Atmospheric Research Laboratory, NORDA) Tech. Note 351, ASW Oceanography Program Office, 1988.
- Hsu, Y.L, T.R. Mettlach, and M.D. Earle, Improvement and Validation of the Navy Longshore Current Model, NRL Formal Report, NRL/FR/7320-00-9927, 2000.
- Hsu, Y.L, T.R. Mettlach, and M.D. Earle, Validation Test Report for the Navy Standard Surf Model, NRL Formal Report, NRL/FR/7320-02-10,008, 2002.
- Kraus, N.C., and M. Larson, NMLONG: Numerical Model for Simulating the Longshore Current, Report 1, Model Development and Tests, U.S. Army Waterways Experiment Station, Vicksburg, Mississippi, 143 pp., 1991.
- Lippman, T.C., E.B. Thornton, and A.J.H.M. Reniers, Wave Stress and Longshore Current on Barred Profiles. Proc. of the International Conference on Coastal Research in Terms of Large Scale Experiments, Gdansk, Poland, 401-412, 1995.
- Lippman, T.C., A.H. Brookins and E.B. Thornton, Wave Energy Transformation on Natural Profiles, *Coastal Engineering*, 27, 1-20, 1996.
- Longuet-Higgins, M.S., Longshore Currents Generated by Obliquely Incident Sea Waves, I and II, J. Geophys. Res., 75, 6778-6801, 1970.
- Longuet-Higgins, M.S., and J.S. Turner, An Entraining Plume Model of a Spilling Breaker, J. Fluid Mech., 63(1), 1-20, 1974.
- Mettlach, T.R. and D. A. May, The Accuracy of the Navy Standard Surf Model-Derived Modified Surf Index and its Sensitivity to Nearshore Bathymetric Profile Error, NRL Formal Report, NRL/FR/7240--97-9665, 1997.
- Pierson, W.J., and L. Moskowitz, A Proposed Spectral Form for Fully Developed Wind Seas Based on the Similarity Theory of A.S. Kitaigorodoski, J. Geophys. Res., 69, No. 24, 5181-5190, 1964.

Svendsen, I.A., Wave Heights and Set-up in a Surf Zone. Coastal Engineering, 303-329, 1984.

Svendsen, I.A., Mass Flux and Undertow in a Surf Zone. Coastal Engineering, 347-364, 1984.

- Thornton, E.B. and R.T. Guza, Transformation of Wave Height Distribution, J. Geophys. Res., 88, C10, 5925-5938, 1983.
- Thornton, E.B. and R.T. Guza, Surf Zone Longshore Currents and Random Waves, J. Phys. Oceanogr., 16, 1165-1178, 1986.

#### 3.0 PRELIMINARY DESIGN

#### 3.1 CSCI Overview

SURF is a parametric one-dimensional model based largely on the work of Thornton and Guza (1983, 1986). Thornton and Guza developed several models for random wave processes including a wave height transformation model and a longshore current model. These models contain both numerical and analytical solutions, which provide cross-shore distributions of various parameters such as wave height, longshore current velocity, and wavelength. However, because SURF is one-dimensional, certain approximations are made: (1) straight and parallel bottom contours, (2) depth-uniform currents, (3) wave heights are Rayleigh distributed, (4) linear wave theory is applicable, and (5) directional wave spectra are narrow-banded in frequency and direction.

The model is designed to operate in a variety of modes to provide both military and civilian users with local surf and current forecasts. SURF requires three pieces of information to perform calculations: (1) a depth profile, (2) a directional wave spectrum, and (3) wave refraction information. Each of these required data sources can be accessed externally or generated internally. This design allows for maximum flexibility when using SURF to generate local forecasts where input data may or may not be available. The following subsections outline the scientific principles behind SURF and the inherent fundamental hydrodynamic calculations contained in the model.

#### 3.1.1 Wave and Roller Energy Models

As waves approach the coast, the frictional effect of the sea floor on the organized orbital motion of water particles within a wave causes the wave to break or spill. The flows of spilling breakers can be separated into two layers, an upper layer of turbulent energy, which rides over a lower layer of energy that maintains an organized oscillatory wave motion. The region of turbulent water above the wave is termed a surface roller. The original idea of such a two-layer system was introduced by Longuet-Higgins and Turner (1974) (see also Svendsen (1984 a,b)). SURF incorporates the model of Lippman *et al* (1995, 1996), which produces results consistent with measurements from both a planar and a barred beach. The energy associated with each region of interest is utilized to shoal the incoming waves and drive the longshore current. The energy per unit surface area in a wave is calculated as:

$$E_w = \frac{l}{8} \rho g H_{rms}^2$$

where  $\rho$  is water density and g is the acceleration due to gravity.  $H_{rms}$  is the root-mean-square wave height. The energy per unit area associated with a roller is given as:

$$E_r = \frac{l}{8} \rho c f \frac{H_b^3}{h \tan \sigma}$$

where c is the phase speed of the wave, f is the zero crossing frequency,  $H_b$  is the height of the wave at breaking, h is water depth, and  $\sigma$  is the angle the roller makes with the body of the wave. A

default value of 5 degrees is used for the roller angle.

## 3.1.2 Energy Dissipation in the Surf Zone

As a wave propagates across the surf zone, its energy is dissipated due to bottom friction, wave breaking, turbulence, and wave-current interaction. A formulation of this energy dissipation is given by the energy flux equation:

$$\frac{\partial (E_w c_g \cos \theta)}{\partial x} = - \langle \varepsilon_b \rangle$$

where  $E_w$  is the wave energy,  $c_g$  is the wave group velocity and  $\theta$  is the wave direction relative to shore normal (x positive offshore). The Right Hand Side (RHS) of the above, equation,  $\langle \varepsilon_b \rangle$ , is the ensemble averaged dissipation function. Thornton and Guza (1983) modeled this dissipation function as:

$$<\varepsilon_b>=\frac{1}{4}\rho_g f \frac{B^3}{h} \int H^3 p_b(H) dH$$

where B is an empirical coefficient, and  $p_b(H)$  is the probability distribution for breaking waves described by:

$$p_b(H) = W(H)p(H)$$

where p(H) is a Rayleigh Distribution of wave heights and W(H) is a weighting function resulting in a weighted Rayleigh distribution. Several weighting functions W(H) have been constructed by various authors, the weighting function applied in SURF developed by Thornton and Guza (1986) is given as:

$$W(H) = \left[\frac{H_{rms}}{\gamma h}\right]^4 \left(1 - e^{-\left[\frac{H}{\gamma h}\right]^2}\right)$$

where  $\gamma$  is an empirical factor determined from field data to be 0.42, h is the water depth and H is the wave height. If wave roller energy is considered in the model, the modified energy flux equation is given as:

$$\frac{\partial (E_w c_s \cos \theta)}{\partial x} + \frac{\partial (E_r c \cos \theta)}{\partial x} = -\langle \varepsilon_r \rangle$$

and the dissipation becomes a function of the roller term.

$$<\varepsilon_r>=\frac{1}{4}\rho gf\frac{H_b^3}{h}\cos\sigma\int H^3p_b(H)dH$$

The above equation is solved using a numerical forward stepping and convergence scheme to determine wave and roller energy along with  $H_{rms}$  values at each point.

#### **3.1.3 Longshore Current Calculations**

When waves enter the surf zone at an angle, the shore-parallel component of momentum inherent to wave motion drives a current along the shore. This longshore current can be a significant force inside the surf zone. Calculation of the current velocity is based on radiation stress theory (see Longuet-Higgins, 1970a, 1970b). A general form of the longshore momentum equation is:

$$\tau_y^h + \rho \frac{d}{dx} \left( \mu h \frac{dV}{dx} \right) - \langle \tau_y^b \rangle + \tau_y^w = 0$$

where  $\rho$  is the water density, *h* is the water depth, and *V* is the longshore current. The first term on the left hand side is the radiation stress in the along shore direction exerted by waves on the water given by:

$$\tau_y^h = <\varepsilon_b > \frac{\sin\theta}{c}$$

where  $\varepsilon_b$  is the dissipation function defined in the previous section, c is wave phase speed, and  $\theta$  is the angle of wave approach with respect to x. The second term is the horizontal mixing. The horizontal eddy viscosity  $\mu$  is modeled after Battjes (1975).

$$\mu = Mh\left(\frac{\varepsilon_b}{\rho}\right)^{\frac{1}{3}}$$

in which M is an empirical constant equal to 2. The third term is the mean stress due to bottom friction given by:

$$r_y^b = \rho_{C_f} u V$$

where  $c_f$  is the bottom friction coefficient, u is the magnitude of the near-bottom horizontal wave orbital velocity, and V is the longshore current. Linear wave theory defines the near-bottom waveinduced orbital velocity as:

$$u = \frac{\pi H}{T \sinh(kh)}$$

where H is the wave height, T is the wave period and k is the wave number, which can be calculated using the dispersion relation:

$$\sigma^2 = g k \tanh(k h)$$

where  $\sigma$  is the radian wave frequency and g is gravity. The longshore current equation is solved using a finite difference approach after wave heights, water depths, and wave dissipation values are calculated at each cross-shore grid point in the surf zone.

A major improvement to the longshore current calculation is included in SURF. Hsu et al. (2000) showed that using a variable bottom friction coefficient formulation in the longshore current model provides a significant improvement in longshore current velocities. The depth dependent bottom friction coefficient function is defined as

$$c_{f}(x) = \begin{cases} 0.0035 & ; x \ge \frac{X_{b}}{2} \\ 0.0035 \left( \frac{h \frac{X_{b}}{2}}{h(x)} \right) & ; x < \frac{X_{b}}{2} \end{cases}$$

where x is the offshore distance, h is the local water depth, and  $X_b$  is the distance from the shoreline to the location where ten percent of the waves are breaking.

#### 3.1.4 Directional Energy Spectra

SURF allows users to generate surf forecasts using two different directional wave energy spectrum types. The user can choose from an internally generated wave spectrum or an external wave spectrum. If the internally generated spectrum is selected, a modified Pierson-Moskowitz (1964) spectrum is calculated based on sea and swell conditions defined in the surf model input file.

#### 3.1.5 Differences Between SURF 3.1 and SURF 3.2

There are many code improvements in SURF 3.2. In general, the prolog of each routine in the software was changed to reflect individual changes and in many routines, comments were added, clarified, deleted or corrected, where necessary. The major changes in the software are as follows:

- 1. The lookup table in routine MDSRF2 was corrected to the values in the Joint Surf Manual. There had been seven typographical errors, which produced inconsequential errors in the modified surf index. In the process of correcting these errors, the routine was streamlined and documented better than it had been.
- 2. At the request of Systems Integration Division, Naval Oceanographic Office, the input variable dstart, i.e. the starting depth of the surf computation, was eliminated from the SURF input file. This variable is now automatically calculated in the model from information in the depth profile, the depth of the input waves and the refraction option. The order of input parameters

was re-arranged for clarity.

- 3. The output file of SURF had traditionally produced a profile, or listing, of wavelength through the surf zone but never a listing of wave direction; although, directional variation throughout the surf zone is more operationally relevant than variation in wavelength. Therefore, in the detailed output, wavelength has been replaced by wave direction. This change required adding another routine (lin4) and making minor changes to several other routines. Extra lines were added in the summary part to list the average wavelength and the depth of wave input.
- 4. The routines related to equilibrium profile, starting point, percent of breaking and wave refraction option were improved.
- 5. Several variables, constants and arrays, which are passed through several unnecessary levels of computation, were either eliminated or appropriately moved.
- 6. Superfluous routines associated with experimental versions of SURF were eliminated. These routines allowed an alternative, but unnecessarily complex, calculation of longshore current. Routines b\_head and b\_detail were merged into the summary routine.
- 7. The angle used for initializing the wave transformation through the surf zone was replaced from the direction of the vertically averaged momentum flux to the energy-weighted, mean wave direction. The change was made because, by definition, the former angle limits wave directions to within 45 degrees of shore normal, which was found to be an unrealistic constraint. In changing the definition of the initializing wave angle, it was necessary to increase the bottom friction coefficient from 0.0030 to 0.0035 after re-calibrating the model using field data.
- 8. The cross-shore distance over which bottom slope is calculated for subsequent estimates of breaker type was increased from approximately 6 feet to a one-quarter the wavelength. The maximum distance is limited to 100 ft and the minimum distance is set to 10 ft. A routine (get\_slope) was added for this calculation. This change has effectively reduced the unusually high incidence of estimates of surging breakers.
- 9. The interpolation scheme in the routine grd\_frc was completely re-written to reflect a bilinear interpolation scheme, which is simpler and more efficient than what had been in place.
- 10. The routine refract was improved to proportionally distribute refracted wave energy into adjacent directional bins. Earlier versions of this routine refracted energy into one bin only and thus produced and unrealistic step-like patterns in directional wave spectra.

## 4.0 ARCHITECTURAL DESIGN

The Architectural Design section shows the overall design and the calling sequence for all CSUs of the SURF. Each CSU is shown in the calling sequence with the associated CSU related to each specific unit. Figure (1) presents the path in which each CSU is called and all associated CSUs, which in turn are called from the parent unit. Specific details concerning the criteria for each CSU being called are defined in the Section 5.0: SURF CSU Detailed Design.



#### 5.0 CSCI DETAILED DESIGN

#### 5.1 Program SURF

#### **Program Call:**

SURF()

#### **Summary:**

The SURF routine is the starting point for executing SURF. The routine identifies the input type and controls the reading of data and user selected computation options. The routine calls the main wave parameter calculation routines and controls the output of the resulting data.

| Input Variables: | None. |
|------------------|-------|
|------------------|-------|

Output Variables: None.

#### **Local Variables:**

| alfa                   | Real    | Significant Breaker Height                     |
|------------------------|---------|--|
| bravo                  | Real    | Maximum Breaker Height                         |
| chrlie                 | Real    | Dominant Breaker Period                        |
| dangle                 | Real    | Angle Between Directional Bins                 |
| depname                | Char*40 | Depth Profile File Name                        |
| dsea                   | Real    | Input Direction for Sea Contribution           |
| dstart                 | Real    | Input Starting Depth                           |
| dswell                 | Real    | Input Swell Direction for Internally Generated |
|                        |         | Spectrum                                       |
| dxy1 (points)          | Real    | Corresponding Depths with No Tide              |
| echo                   | Real    | Breaker Angle                                  |
| ehsig                  | Real    | Significant Wave Height from Directional       |
|                        | • .     | Spectrum                                       |
| esowm (dirNum,freqNum) | Real    | Directional Wave Spectrum                      |
| file_dat               | Char*40 | Output File Name *.dat                         |
| file_in                | Char*40 | Input Filename                                 |
| file_out               | Char*40 | Output File Name * out                         |
| file_tmp               | Char*40 | Temporary File                                 |
| foxtrt                 | Real    | Longshore Current Speed and Direction          |
| fracname               | Char*40 | Wave Refraction File Name                      |
| freq (freqNum)         | Real    | Input Wave Spectrum Center Frequencies         |
| freq1 (freqNum)        | Real    | Beginning Frequency Bin Values                 |
| freq2 (freqNum)        | Real    | Ending Frequency Bin Values                    |
|                        |         |  |

| gamma2            | Real                | Beach Orientation, Compass Heading Directly<br>Toward Beach |
|-------------------|---------------------|---|
| golfl             | Real                | Number of Surf Lines  |
| golf2             | Real                | Surf Zone Width   |
| s<br>st fra       | Integer             | Spectrum Type   |
| hsea              | Real                | Input Significant Wave Height for Sea                       |
|                   |                     | Contribution to Pierson Moskowitz Spectrum                  |
| hswell            | Real                | Input Significant Wave Height for Internally                |
|                   | 21011               | Generated Spectrum  |
| idav              | Integer             | Input Day   |
| idirec            | Integer             | Number of Direction Bins in the Input                       |
| hunce             | meger               | Spectrum  |
| ifreq             | Integer             | Number of Frequency Bands in the Input                      |
| meq               | mogor               | Spectrum  |
| izommo            | Integer             | Beach Orientation Rotated 90° from Original                 |
| Igamma            | nneger              | Heading Toward Beach  |
| ihou <del>r</del> | Integer             | Including Toward Deach                                      |
|                   | Deel                | Wind Speed Coded Surf Forecast Value                        |
|                   | Deel                | Wind Direction  |
| IIIIIZ<br>imin    | NCai<br>Integer     | Input Minute  |
| illilli<br>imonth | Integer             | Input Month   |
|                   | Integer             | Input Veer  |
| iyear             | Integer             | Tomporary Value Set to Beach Orientation                    |
| Jgamma            | mieger<br>Charte    | Temporary Character Variable                                |
|                   |                     | Longohora Current Solution (True or False)                  |
|                   | Logical<br>Chart 40 | Longshole Cullent Solution (1102 of Paise)                  |
| Indname           |                     | Input Landing Zone Name                                     |
| nnn               | Integer             | Number of Points in the input Depth Allay                   |
| pct (4)           | Real                | ret (1) - Spilling  |
|                   |                     | pct(1) = Splitting  |
|                   |                     | pct(2) = Plunging   |
|                   |                     | pct(3) = Surging  |
|                   | <b>D</b> 1          | pct (4) = 1 otal  |
| period (freqNum)  | Real                | Period Array (1/Frequency)                                  |
| psea              | Real                | Input wave Period for Sea Contribution to                   |
|                   | <b>_</b> .          | Pierson Moskowitz Spectrum                                  |
| pswell            | Real                | Input Swell Period for Internally Generated                 |
|                   |                     | Spectrum  |
| roller            | Logical             | Roller Usage (True or False)                                |
| self_st           | Char*1              | Self Start Flag (Yes or No)                                 |
| slope             | Real                | Bottom Slope  |
| spectra           | Logical             | Does Input Spectra Exist? (True or False)                   |
| spefile           | Char*40             | Selected Wave Spectrum File Name                            |
| surfy             | Logical             | Significant Wave Heights Greater than                       |
|                   |                     | 0.5 ft? (True or False)                                     |
| tide              | Real                | Input Tide Level  |

| wdir                     | Real   | Input Wind Direction Compass Heading Wind |
|--------------------------|--------|---|
|                          |        | Blows from                                |
| wspđ                     | Real   | Input Wind Speed                          |
| xcoeff (dirNum, freqNum) | Real   | Wave Height Refraction Coefficients       |
| xdelt                    | Real   | Surf Zone Output Interval                 |
| xdelt_gr                 | Real   | Self Adjusting Cross-Shore Grid Step      |
| xfrom (dirNum)           | Real   | Direction Array, Direction Wave Energy    |
|                          |        | Comes From                                |
| xtheta (dirNum,freqNum)  | Real   | Angle Refraction Coefficients             |
| xx1(points)              | Real   | Adjusted Cross-Shore Distances from       |
|                          |        | Depth Profile                             |
| ydepth                   | Char*1 | Input Depth Profile Used? (Yes or No)     |
| ydetail                  | Char*1 | Detailed Output? (Yes or No)              |
| yrefrac                  | Char*1 | Is Refraction Considered in Analysis?     |
|                          |        | (Yes or No)                               |
| ystr                     | Char*1 | Is Straight Coast Refraction Used?        |
|                          |        | (Yes or No)                               |

## Subroutines Called from SURF ():

ABORT CALCSURF DEPDRVR GENSPEC MDSRF1 PRT\_OUT3 READRFRC READSPEC REFRAC SRFSETUP STRFRAC SUMMARY SURFCAST

Figure 2. Program SURF Flowchart



#### 5.2 Subroutine ABORT

#### **Subroutine Call:**

ABORT ()

#### **Summary:**

Subroutine ABORT acts as the single program termination routine. The subroutine handles normal program execution and error interrupt. ABORT is called to stop the execution of the program. If an error interrupt calls ABORT, the error message is generated locally in the calling routine.

Input Variables: None.

Output Variables: None.

Local Variables: None.

Subroutines Called from ABORT ( ):

None.

## ABORT () Called from Subroutines:

C\_IN\_DEP EQUILPRFMAIN\_WAV MDSRF2 NEW\_BRK NONLIN2 PRT\_OUT1 PRT\_OUT2 READRFRC READSPEC SRFSETUP SURF

Figure 3. Subroutine ABORT Flowchart





#### 5.3 Subroutine BALANCEQ

#### **Subroutine Call:**

BALANCEQ (roller, theta, Cg, rhs, hrms1, dp, mean\_freq, xk, hrms2, convg)

#### **Summary:**

Subroutine BALANCEQ computes new wave height value at the next onshore grid cell by performing an iterative solution to the energy equations.

#### **Input Variables:**

| Cg                | Real    | Wave Group Velocity  |
|-------------------|---------|--|
| dp                | Real    | Offshore Water Depth   |
| hrms1             | Real    | Root Mean Square Wave Height   |
| mean_frq          | Real    | Wave Frequency   |
| rhs               | Real    | Right Hand Side of Energy Balance  |
|                   |         | Equation   |
| roller            | Logical | Roller Option Flag (True or False)   |
| theta             | Real    | Wave Angle   |
| xk                | Real    | Wave Number  |
| Output Variables: |         |  |
| convg             | Logical | Convergence Flag (True or False)   |
| hrms2             | Real    | Significant Wave Height at next  |
|                   |         | Onshore Grid   |
| Local Variables:  |         |  |
| avgh              | Real    | Average Wave Height  |
| check             | Real    | Convergence Check  |
| done              | Logical | Flag indicating End of Loop  |
| f3                | Real    | Function which Calculates Total Energy   |
| kount             | Integer | Loop Iteration Counter   |
| lhs               | Real    | Left Hand Side of the Energy Equation  |
| limit             | Logical | Flag for Comparison of the Left & Right Side<br>of the Energy Equation (True or False) |
| lowerh            | Real    | Lower Limit of Wave Height   |
| max_kount         | Integer | Maximum Number of Loop Iterations =1000  |
| oldavgh           | Real    | Previous Average Wave Height Value   |
| pct               | Real    | Convergence Step Value   |
| tol               | Real    | Convergence Tolerance  |
| upperh            | Real    | Upper Limit of the Wave Height   |
|                   |         |  |

Subroutines Called from BALANCEQ ():None

Functions Called from BALANCEQ ():

**F**3

**BALANCEQ () Called from Subroutines:** 

MAIN\_WAV SLF\_STRT





**Figure 4. Subroutine BALANCEQ Flowchart** 

## 5.4 Subroutine C\_FINE

#### **Subroutine Call:**

C\_FINE (ndepth, xxin, zzin, xdelt\_gr, nnn, xx1, dxy1)

#### **Summary:**

Subroutine C\_FINE linearly interpolates the input water depths and offshore distances to an evenly spaced grid. The internally defined grid self-adjusts to maximize spatial resolution without exceeding the array dimensions.

## **Input Variables:**

| ndepth<br>xdelt_gr<br>xxin (points)<br>zzin (points) | Integer<br>Real<br>Real<br>Real | Number of Points in Input Depth Profile<br>Self-Adjusting Cross-Shore Grid Step<br>Cross-Shore Distances<br>Corresponding Depths       |
|--|---------------------------------|--|
| Output Variables:                                    |                                 |  |
| dxy1 (points)<br>nnn<br>xx1 (points)                 | Real<br>Integer<br>Real         | Corresponding Depths without Tide<br>Number of Points in the Input Depth Array<br>Adjusted Cross-Shore Distances from<br>Depth Profile |
| Local Variables:                                     |                                 |  |
| dx 1   | Real                            | Temporary Variable Used in Calculation of<br>Next Grid Point Distance  |
| dx2  | Real                            | Temporary Variable Used in Calculation of<br>Next Grid Point Distance  |
| dxx  | Real                            | Distance Quotient  |
| dzz  | Real                            | Difference Between Depth and<br>Previous Depth   |
| mm   | Integer                         | Counter Variable   |
| mm1  | Integer                         | Counter Variable   |
| mmm  | Integer                         | Counter Variable   |
| nn   | Integer                         | Counter Variable   |
| xlast  | Real                            | Last Distance Offshore from Input Profile  |
| xtemp  | Real                            | Temporary Variable for Cross-Shore Values  |

Subroutines Called from C\_FINE ( ):

None.

#### **C\_FINE ( ) Called from Subroutines:**

#### C\_REGRID





#### 5.5 Subroutine C\_GAMMA

#### **Subroutine Call:**

C\_GAMMA (gamma2, igamma)

#### **Summary:**

Subroutine C\_GAMMA rotates the beach orientation data read from the input file. The user defines the beach orientation as the compass heading of a boat traveling directly toward the shore on a perpendicular line to the coast. The value is then rotated to reflect the orientation of the local coastline with respect to magnetic north.

#### **Input Variables:**

| gamma2                               | Real            | Beach Orientation, Heading Directly<br>Toward Beach                         |  |
|--------------------------------------|-----------------|---|--|
| Output Variables:                    |                 |   |  |
| igamma                               | Integer         | Rotated Beach Orientation   |  |
| Local Variables:                     |                 |   |  |
| gammatp<br>mtemp                     | Real<br>Integer | Temporary Variable Used in Calculation<br>Temporary Variable in Calculation |  |
| Subroutines Called from C_GAMMA ( ): |                 | None.   |  |
| C_GAMMA ( ) Called from Subroutines: |                 |   |  |

DEPDRVR

Figure 6. Subroutine C\_GAMMA Flowchart



#### 5.6 Subroutine C\_IN\_DEP

#### Subroutine Call:

C\_IN\_DEP (depname, spedepth, xdelt\_gr, nnn, xx1, dxy1, dstart)

#### Summary:

Subroutine C\_IN\_DEP reads the depth profile and header information contained in the input data file. The routine identifies the units of measurement used to construct the depth profile and checks the order of the offshore distances. If the data is misaligned, the subroutine will sort and reorder the depths and offshore distances.

#### **Input Variables:**

| depname<br>dstart<br>xdelt_gr        | Char*40<br>Real<br>Real | Depth Profile File Name<br>Input Starting Depth<br>Self Adjusting Cross-Shore Grid Step  |
|--------------------------------------|-------------------------|--|
| Output Variables:                    |                         |  |
| dxy1 (points)<br>nnn<br>xx1 (points) | Real<br>Integer<br>Real | Corresponding Depths without Tide<br>Number of Points in the Input Depth Array<br>Adjusted Cross-Shore Distances from the<br>Depth Profile |
| Local Variables:                     |                         |  |
| al                                   | Real                    | Temporary Variable   |
| a2                                   | Real                    | Temporary Variable   |
| adum                                 | Char*80                 | Temporary Variable, Character String in Input<br>Field   |
| dcal1                                | Real                    | Conversion Factor for Distance Offshore,<br>Convert to Meters  |
| dcal2                                | Real                    | Conversion Factor for Depths Offshore,<br>Convert to Meters  |
| dx                                   | Real                    | Temporary Variable for Distance Offshore<br>from Input File  |
| dz                                   | Real                    | Temporary Variable for Depths  |
| I                                    | Integer                 | Loop Variables   |
| ical1                                | Integer                 | Input from Depth File,   |

Input from Depth File, Units of Distance Offshore 1 = Feet

|               |         | 2 = Meters                                   |
|---------------|---------|--|
|               |         | 3 = Yards                                    |
| ical2         | Integer | Depth Units Input from Depth File            |
|               |         | 1 = Feet                                     |
|               |         | 2 = Meters                                   |
|               |         | 3 = Fathoms                                  |
| instat        | Integer | File Open Status                             |
| j             | Integer | Loop Variables                               |
| k             | Integer | Temporary Variable for Number of Points      |
| line          | Integer | Counter for the Number of Lines in the Input |
|               |         | Depth Profile                                |
| loop          | Integer | Loop Counter                                 |
| ndepth        | Integer | Number of Points in Input Depth Profile      |
| xxin (points) | Real    | Cross-Shore Distances                        |
| zzin (points) | Real    | Corresponding Depths                         |
|               |         |  |

## Subroutines Called from C\_IN\_DEP():

#### ABORT C\_UN C\_REGRID

## C\_IN\_DEP() Called from Subroutines:

#### DEPDRVR



Figure 7. Subroutine C\_IN\_DEP Flowchart

#### 5.7 Subroutine C\_REGRID

#### **Subroutine Call:**

C\_REGRID (ndepth, xxin, zzin, xdelt\_gr, nnn, xx1, dxy1)

#### **Summary:**

Subroutine C\_REGRID examines the cross-shore step size  $(\Delta x)$  of the input depth profile and selects a new step size to optimize the depth and cross-shore distance arrays. The step size is automatically adjusted and the arrays are constructed so the length does not exceed the dimension of the array.

#### **Input Variables:**

| ndepth        | Integer | Number of Points in Depth Profile    |
|---------------|---------|--------------------------------------|
| xdelt_gr      | Real    | Self Adjusting Cross-Shore Grid Step |
| xxin (points) | Real    | Cross-Shore Distances                |
| zzin (points) | Real    | Corresponding Depths                 |

#### **Output Variables:**

| nnn           | Integer | Number of Points in Input Depth Array |
|---------------|---------|---------------------------------------|
| xdelt_gr      | Real    | Self Adjusting Cross-Shore Grid Step  |
| xx1(points)   | Real    | Adjusted Cross-Shore Distances from   |
|               |         | Depth Profile                         |
| xxin (points) | Real    | Adjusted Cross-Shore Distances        |
| zzin (points) | Real    | Corresponding Depths                  |
|               |         |                                       |

#### Local Variables:

None.

## Subroutines Called from C\_REGRID ():

#### C\_FINE

## C\_REGRID ( ) Called from Subroutines:

#### C\_IN\_DEP





#### 5.8 Subroutine C\_UN

#### Subroutine Call:

C\_UN (dcal1, dcal2, ndepth, xxin, zzin, xdelt\_gr, spedepth)

#### Summary:

Subroutine C\_UN converts measurement units of input cross-shore distances, depth arrays, starting depth and the grid step size ( $\Delta x$ ) to meters for internal calculations.

## **Input Variables:**

| dcal1         | Real    | Conversion Factor for Cross-Shore Distances |
|---------------|---------|---|
| dcal2         | Real    | Conversion Factor for Water Depths          |
| dstart        | Real    | Input Starting Depth                        |
| ndepth        | Integer | Number of Points in Input Depth Profile     |
| xdelt_gr      | Real    | Self Adjusting Cross-Shore Grid Step        |
| xxin (points) | Real    | Cross-Shore Distances                       |
| zzin (points) | Real    | Corresponding Depths                        |

#### **Output Variables:**

| spedepth      | Real | Input Starting Depth                 |
|---------------|------|--------------------------------------|
| xdelt_gr      | Real | Self Adjusting Cross-Shore Grid Sten |
| xxin (points) | Real | Cross-Shore Distances                |
| zzin (points) | Real | Corresponding Depths                 |

#### **Local Variables:**

| I                          | Integer | Loop Counter |
|----------------------------|---------|--------------|
| Subroutines Called from C_ | _UN():  | None.        |
|                            |         |              |

#### C\_UN() Called from Subroutines:

C\_IN\_DEP

Figure 9. Subroutine C\_UN Flowchart

. :



#### 5.9 Subroutine CALC\_HB3

#### **Subroutine Call:**

CALC\_HB3 (dp, hrms, p\_flag, hb3)

#### Summary:

Subroutine CALC\_HB3 integrates the wave height distribution for a given root mean square wave height and calculates a term inherent to the roller dissipation function.

#### **Input Variables:**

| dp<br>hrms<br>p_flag | Real<br>Real<br>Logical | Offshore Water Depth<br>Root Mean Square Wave Height Calculation<br>Weighting Factor Flag (True or False) |
|----------------------|-------------------------|---|
| Output Variables:    |                         |   |
| hb3                  | Real                    | Weighting Function for Dissipation Term   |
| Local Variables:     |                         |   |
| hhigh                | Real                    | Maximum Wave Height   |
| hlow                 | Real                    | Minimum Wave Height   |
| integrat             | Real                    | Wave Height Distribution Calculated for a<br>Single Wave at a Specific Location                           |

## Functions Called from CALC\_HB3():

**INTEGRAT** 

## CALC\_HB3 () Called from Subroutines:

CALCROLL GET\_DISS



· · · · ·


# 5.10 Subroutine CALCROLL

## **Subroutine Call:**

# CALCROLL (roller, hrms, dp, fqz, theta, xk, e\_roller)

## Summary:

Subroutine CALCROLL calculates roller energy at a point in the surf zone based on water depth and Wave Height (hrms) at that location.

## **Input Variables:**

| dp<br>fqz<br>hrms<br>roller<br>theta | Real<br>Real<br>Real<br>Logical<br>Real | Offshore Water Depth<br>Zero Crossing Frequency<br>Root Mean Square Wave Height<br>Roller Option Flag (True or False)<br>Wave Angle, Representative of Radiation<br>Stress Angle |
|--------------------------------------|---|--|
| xk                                   | Real                                    | Wave Number  |
| Output Variables:                    |   |  |
| e_roller                             | Real                                    | Roller Contribution to Energy Equation   |
| Local Variables:                     |   |  |
| C                                    | Real                                    | Wave Celerity  |
| hh3                                  | Real                                    | Temporary Roller Variable  |
| n flag                               | Logical                                 | Weighting Function for Dissipation Term  |
| r                                    | Real                                    | weighting Factor Flag (True or False)<br>Roller Energy Multiplier  |

# Subroutines Called from CALCROLL():

## CALC\_HB3

# CALCROLL() Called from Subroutines:

## **GET\_RHS**

F3

# Figure 12. Subroutine CALCROLL Flowchart



## 5.11 Subroutine CALCSURF

## **Subroutine Call:**

CALCSURF (roller, lin\_stress, ehsig, wspd, wdir, tide, ydepth, nnn, dxy1, xx1, ifreq, freq1, freq2, freq, idirec, xfrom, esowm, dstart, igamma, ydetail, iyear, imonth, iday, ihour, imin, xdelt, xdelt\_gr, self\_st, file\_spc, surf, pct, alfa, bravo, chrlie, echo, foxtrt, golf1, golf2, ihtl1, ihtl2, jgamma)

## Summary:

Subroutine CALCSURF acts as the primary driver for the various subroutines, which calculate wave parameters and the longshore current across the surf zone.

# **Input Variables:**

| dstart                 | Real    | Input Starting Depth                       |
|------------------------|---------|--|
| dxy1 (points)          | Real    | Corresponding Depths without Tide          |
| ehsig                  | Real    | Significant Wave Height from               |
|                        |         | Directional Spectrum                       |
| esowm (dirNum,freqNum) | Real    | Directional Wave Spectrum                  |
| freq (freqNum)         | Real    | Input Wave Spectrum Center Frequency       |
| freq1 (freqNum)        | Real    | Beginning Frequency Bin Value              |
| freq2 (freqNum)        | Real    | Ending Frequency Bin Value                 |
| iday                   | Integer | Input Day                                  |
| idirec                 | Integer | Number of Direction Bins in Input Spectrum |
| ifreq                  | Integer | Number of Frequencies in Input Spectrum    |
| igamma                 | Integer | Beach Orientation Rotated 90 Degrees from  |
|                        |         | Original Heading Toward Beach              |
| ihour                  | Integer | Input Hour                                 |
| imin                   | Integer | Input Minute                               |
| imonth                 | Integer | Input Month                                |
| iyear                  | Integer | Input Year                                 |
| lin_stress             | Logical | Longshore Current Solution (True or False) |
| nnn                    | Integer | Number of Points in Input Depth Array      |
| roller                 | Logical | Roller Option Flag (True or False)         |
| self_st                | Char*1  | Self Start Flag (Yes or No)                |
| tide                   | Real    | Input Tide Level                           |
| wdir                   | Real    | Input Wind Direction Compass Heading       |
|                        |         | Wind is Blowing From                       |
| wspd                   | Real    | Input Wind Speed                           |
| xdelt                  | Real    | Surf Zone Output Interval                  |
| xdelt_gr               | Real    | Self-Adjusting Cross-Shore Grid Step       |
|                        |         | server and stop of the stop                |
| xfrom (dirNum)         | Real    | Direction Array, Direction Wave Energy     |
|                        |         | Comes From                                 |

| xx1(points)       | Real   | Adjusted Cross-Shore Distances from<br>Depth Profile |
|-------------------|--------|--|
| ydepth            | Char*1 | Input Depth Profile Used? (Yes or No)                |
| ydetail           | Char*1 | Detailed Output? (Yes or No)                         |
| Output Variables: |        |  |
| alfa              | Real   | Significant Breaker Height                           |
| bravo             | Real   | Maximum Breaker Height                               |
| chrlie            | Real   | Dominant Breaker Period                              |
| echo              | Real   | Breaker Angle  |
| _                 |        |  |

| foxtrt           | Real    | Longshore Current Speed and Direction           |
|------------------|---------|---|
| golf1            | Real    | Number of Surf Lines                            |
| golf2            | Real    | Surf Zone Width                                 |
| ihtl1            | Real    | Wind Speed                                      |
| ihtl2            | Real    | Wind Direction                                  |
| jgamma           | Integer | <b>Temporary Value Set to Beach Orientation</b> |
| pct (4)          | Real    | Percent of Different Breaker Types:             |
|                  |         | pct (1) = Spilling                              |
|                  |         | pct(2) = Plunging                               |
|                  |         | pct(3) = Surging                                |
|                  |         | pct (4) = Total                                 |
| surf             | Logical | Flag for Low/No Surf Conditions                 |
|                  |         | (True or False)                                 |
| Local Variables: |         |   |
| along (points)   | Real    | Horizontal Mixing Parameter from                |
| _                |         | Thornton & Whittord                             |
| b                | Real    | Empirical Factor in Thornton & Guza Wave        |
| · · · ·          |         | Breaking Model (= 1.00)                         |
| bl (points)      | Real    | Bottom Slope                                    |
| blong (points)   | Real    | Bottom Friction for Deep & Shallow Water        |
| C                | Real    | Wave Celerity at Input Starting Depth           |
| cl               | Real    | Eddy Viscosity Coefficient                      |
| c2               | Real    | Bottom Friction Coefficient                     |
| c3               | Real    | Radiation Stress Coefficient  Multiple for      |
|                  |         | Longshore Current Model                         |
| c4               | Real    | Longshore Wind Stress Coefficient  Multiple     |
|                  |         | for Longshore Current Model                     |
| cf .             | Real    | Coefficient of Bottom Friction                  |
| Cg               | Real    | Wave Group Velocity                             |
| clong (points)   | Real    | Wind Stress Contribution to                     |
|                  |         | Longshore Current                               |
| convg            | Logical | <b>Energy Equation Convergence Flag</b>         |
| df               | Real    | Difference Between Adjacent Frequency Bins      |
|                  |         |   |

35

| distmax         | Real         | Farthest Offshore Distance                               |
|-----------------|--------------|--|
| dp              | Real         | Offshore Water Depth                                     |
| dth             | Real         | Difference Between Adjacent Directional Bins             |
| dws_stop        | Integer      | Flag for Shallow Water Directional Wave                  |
| dxy (points)    | Deal         | Spectrum Print Control                                   |
| eh last         | Ncal<br>Dest | Pre-fidal Depth with Tide                                |
|                 | Real         | Point Offshore   |
| ebtemp (points) | Real         | Temporary Roller Dissipation Term<br>Across Transect     |
| file_spc        | Char*40      | File Name of Shallow Water Directional Wave              |
| fqd             | Real         | Peak Frequency at the Center of the Frequency<br>Band    |
| fqz             | Real         | Zero Crossing Frequency                                  |
| ftsq2msq        | Real         | Conversion Factor from Fact Squamd to Materia            |
|                 |              | Squared  |
| h1max           | Real         | Largest Significant Wave Height in the Surf Zone         |
| h2max           | Real         | Largest Maximum Wave Height in the<br>Surf Zone          |
| hrms            | Real         | Root Mean Square Wave Height                             |
| htemp (points)  | Real         | Temporary Variable for Significant Wave<br>Height Values |
| iimax           | Integer      | Number of Calculation Locations                          |
| irealf          | Integer      | Cutoff Index for Printing Shallow Water                  |
|                 | U            | Directional Wave Spectrum                                |
| j               | Real         | Temporary Variable for Cross-Shore Values                |
| j_ii            | Integer      | Index where Wave Probabilities come                      |
|                 |              | Above Threshold  |
| j_ii2           | Integer      | Longshore Current Loop Variable for Outer                |
| k               | Deal         | Edge of Surf Zone  |
| K               | Keal         | Temporary Variable for Significant<br>Wave Height        |
| per             | Real         | Peak Period of Directional Wave Spectrum                 |
| print_spc       | Integer      | Flag to Print Shallow Water Wave Spectrum                |
| ptemp (points)  | Real         | Percentage of Breaking Waves and                         |
|                 |              | Breaker Types  |
| rk (points,4)   | Real         | Matrix of Percentage Breakers and Types                  |
|                 |              | Across the Transect                                      |
| stringout       | Character    | Shallow Water Wave Spectrum Output String                |
| stringsub       | Character    | Temporary String Variable                                |
| sum1            | Real         | Sum of Wave Length in the Surf Zone                      |
| temp            | Real         | Temporary Variable                                       |
| theta           | Real         | Wave Angle   |
| thetal          | Real         | Wave Angle at Input Starting Depth                       |
|                 | 36           |  |

| theta2          | Real    | Wave Angle at Input Starting Depth        |
|-----------------|---------|---|
| v (points)      | Real    | Longshore Current                         |
| vmax            | Real    | Maximum Positive Longshore Current        |
| vmin            | Real    | Maximum Negative Longshore Current        |
| vwind           | Real    | Group Wind Velocity                       |
| wdspd           | Real    | Wind Speed Conversion                     |
| -               |         | Knots to $CM/S = 51.44$                   |
| wid_ii          | Integer | Array Location for Surf Zone Width        |
| width           | Real    | Surf Zone Width                           |
| xk              | Real    | Wave Number                               |
| xktemp (points) | Real    | Temporary Variable for Wave Number        |
| xshift          | Real    | Horizontal Cross-Shore Location           |
| xtemp (points)  | Real    | Temporary Variable for Cross-Shore Values |
| /               |         |   |

Subroutines Called from CALCSURF ():

GT\_SIG\_H INITLIZE KLONG MAIN\_WAV NONLIN PRT\_OUT1 PRT\_OUT2 RAD\_ST1 S\_COEFF S\_NOSURF S\_TIDE SHORTOUT ZONE1

**CALCSURF ( ) Called from Subroutines:** 

**SURF** 





.

### 5.12 Subroutine DEPDRVR

#### **Subroutine Call:**

DEPDRVR (depname, spedepth, xdelt, ydepth, slope, gamma2, nnn, xx1, dxy1, igamma, xdelt\_gr, dstart, ystr)

## **Summary:**

Subroutine DEPDRVR is the driver routine for reconstructing the depth arrays in an optimized step size.

## **Input Variables:**

| depname | Char*40 | Depth Profile File Name                  |
|---------|---------|--|
| dstart  | Real    | Input Starting Depth                     |
| gamma2  | Real    | <b>Beach Orientation Compass Heading</b> |
| •       |         | Directly Toward Beach                    |
| slope   | Real    | Bottom Slope                             |
| xdelt   | Real    | Surf Zone Output Interval                |
| ydepth  | Char*1  | Usage of Input Depth Profile (Yes or No) |
| ystr    | Char*1  | Straight coast refraction flag           |

## **Output Variables:**

| dxy1 (points) | Real    | Corresponding Depths without Tide             |
|---------------|---------|---|
| igamma        | Integer | Beach Orientation Rotated 90 Degrees from the |
| 0             | ·       | Original Heading Toward the Beach             |
| nnn           | Integer | Number of Points in the Input Depth Array     |
| xdelt_gr      | Real    | Self-Adjusting Cross-Shore Grid Step          |
| xx1 (points)  | Real    | Adjusted Cross-Shore Distances from the       |
|               |         | Depth Profile                                 |

#### Local Variables:

None.

#### Subroutines Called from DEPDRVR ():

## EQUILPRF C\_GAMMA C\_IN\_DEP

#### **DEPDRVR ( )Called from Subroutines:**

**SURF** 





**40** <sup>.</sup>

#### 5.13 Subroutine EQUILPRF

#### **Subroutine Call:**

EQUILPRF (wavdep, ystr, rtype, xgrd, numstep, xx1, dxy1, deepest\_depth)

#### Summary:

Subroutine EQUILPRF constructs a depth profile for surf calculations. This equilibrium profile is based on the equation:  $y=Ax^{(2/3)}$ , where A is a coefficient related to sediment grain size or frictional dissipation. This equation was developed by Dean (1977) from a study of more than 200 beach profiles. The "A" coefficient in the equilibrium equation has units of meters, calculations in feet require different values or conversion to feet after initial calculations. Sediment/grain types are denoted by the variable "rtype" which is the index for a value in the array of coefficients defining the following grain sizes:

1 = boulders
2 = cobble
3 = pebbles
4 = granules
5 = very coarse sand
6 = coarse sand
7 = medium sand
8 = fine sand
9 = very fine sand
10 = silt

#### **Input Variables:**

| dpthoff           | Real      | Input Starting Depth                         |
|-------------------|-----------|--|
| numstep           | Integer   | Number of Points in the Input Depth Array    |
| rtype             | Real      | Sediment/ Grain Type                         |
| wavdep            | Real      | Input Wave Depth                             |
| xgrd              | Real      | Self-Adjusting Cross-Shore Grid Step         |
| ystr              | Character | Straight Coast Refraction Logic              |
| Output Variables: |           |  |
| dxy1(points)      | Real      | Corresponding Depths with No Tide            |
| xx1(points)       | Real      | Cross-Shore Distances                        |
| Local Variables:  |           |  |
| a(10)             | Real      | Array of Sediment Coefficients               |
| ause              | Real      | Actual Sediment Type Coefficient for Profile |
| cal1              | Real      | Conversion Factor (Meters)                   |

| distance | Logical | Flag for Equilibrium Depth Bottom |
|----------|---------|-----------------------------------|
| diston   | Real    | Highest Onshore Distance          |
| dpthon   | Real    | Highest Onshore Denth             |
| I        | Integer | Loop Counter                      |
| X        | Real    | Temporary Variable                |
| xone     | Real    | Farthest Point Offshore           |
| Z        | Real    | Temporary Variable                |

# Subroutines Called from EQUILPRF():

ABORT

# EQUILPRF () Called from Subroutines:

DEPDRVR

Figure 14. Subroutine EQUILPRF Flowchart



**43** :

## 5.14 Subroutine GENSPEC

## **Subroutine Call:**

GENSPEC (hsea, psea, dsea, hswell, pswell, dswell, ifreq, idirec, freq1, freq2, xfrom, esowm, period, ehsig, dangle)

## **Summary:**

Subroutine GENSPEC initializes matrices for the creation of an internally generated directional wave spectrum. This wave spectrum has 50 frequencies and 36 directions.

| Input Variables:       |         |  |
|------------------------|---------|--|
| dsea                   | Real    | Input Direction for Sea Contribution         |
| dswell                 | Real    | Input Swell Direction for Internally         |
|                        |         | Generated Spectrum                           |
| hsea                   | Real    | Input Significant Wave Height for Sea        |
|                        |         | Contribution to Pierson Moskowitz Equation   |
| hswell                 | Real    | Input Significant Wave Height for Internally |
|                        |         | Generated Spectrum                           |
| psea                   | Real    | Input Wave Period for Sea                    |
|                        |         | Contribution to Pierson Moskowitz Equation   |
| pswell                 | Real    | Input Swell Period for Internally            |
|                        |         | Generated Spectrum                           |
| Output Voriables       |         |  |
| Output variables:      |         |  |
| dangle                 | Real    | Angle Between Directional Bins               |
| ehsig                  | Real    | Significant Wave Height from                 |
|                        |         | Directional Spectrum                         |
| esowm (dirNum,freqNum) | Real    | Directional Spectrum                         |
| freq (freqNum)         | Real    | Input Wave Spectrum Center Frequencies       |
| freq1 (freqNum)        | Real    | Beginning Frequency Bin Values               |
| freq2 (freqNum)        | Real    | Ending Frequency Bin Values                  |
| idirec                 | Integer | Number of Direction Bins in the              |
|                        |         | Input Spectrum                               |
| ifreq                  | Integer | Number of Frequencies in the                 |
|                        |         | Input Spectrum                               |
| period (freqNum)       | Real    | Period Array (1/Frequency)                   |
| xfrom (dirNum)         | Real    | Direction Array, Direction Wave Energy       |
|                        |         | Comes From                                   |

## **Local Variables:**

df idir ifrq Real Integer Integer Difference between Frequency Bins Direction Loop Counter Frequency Loop Counter

Subroutines Called from GENSPEC ():

WAVEFIT

٠

**GENSPEC ( ) Called from Subroutines:** 

SURF

### Figure 15. Subroutine GENSPEC Flowchart



# 5.15 Subroutine GET\_BRK

## **Subroutine Call:**

. . .

GET\_BRK (ii, nnn, xx1, dxy, xdelt\_gr, hrms, 10, per, xoff, rk, b1, brk10, distmax, p) Summary:

Subroutine GET\_BRK calculates percentage of breakers and percent breaker type given at each point along the transect: p(1) = Spilling, p(2) = Plunging, p(3) = Surging, p(4) = 100\*Sum.

| input Variables:         |         |  |
|--------------------------|---------|--|
| b1 (points)              | Real    | Bottom Slope                             |
| brk10                    | Logical | Flag for First Location where 10% of the |
|                          | - ,     | Waves are Breaking (True or False)       |
| distmax                  | Real    | Farthest Offshore Distance               |
| dxy (points)             | Real    | Adjusted Depths with Tide                |
| hrms                     | Real    | Root Mean Square Wave Height             |
| ii                       | Integer | Index where Wave Probabilities Exceed    |
|                          | Ũ       | Threshold                                |
| per                      | Real    | Peak Period of Directional Wave Spectrum |
| rk (points,4)            | Real    | Matrix of Percentage Breakers and Types  |
|                          |         | Across the Transect                      |
| xdelt_gr                 | Real    | Self-Adjusting Cross-Shore Step          |
| xoff                     | Real    | Distance Offshore                        |
| <b>Output Variables:</b> |         |  |
| bl (points)              | Real    | Bottom Slope                             |
| brk10                    | Logical | Flag for First Location where 10% of the |
|                          | U       | Wayes are Breaking (True or False)       |
| distmax                  | Real    | Farthest Offshore Distance               |
| p (4)                    | Real    | Temporary Array for Breaker              |
|                          |         | Percentage Totals                        |
| rk (points,4)            | Real    | Percent Breaker of Each Type             |
| Local Variables:         |         | ,  |
| beta                     | Real    | Temporary Variable for Bottom Slope      |
|                          |         |  |

Subroutines Called from GET\_BRK ( ):

PERCENT

**GET\_BRK ( ) Called from Subroutines:** 

MAIN\_WAV

Figure 16. Subroutine GET\_BRK Flowchart



·

#### 5.16 Subroutine GET\_DISS

#### **Subroutine Call:**

GET\_DISS (roller, fqz, dp, hrms, p\_flag, diss)

#### **Summary:**

Subroutine GET\_DISS returns the wave dissipation factor. This term is based on a bore dissipation model and can include roller dissipation if selected. The dissipation term is included in the  $\rho$ wave energy balance equation. The wave dissipation is given by:

 $\varepsilon_b = \frac{3\rho g f \sqrt{\pi}}{16h} H^3 rms^* M^* B^3$ 

where  $\rho$  is density, g is gravity, f is bottom friction, h is the water depth, M is a weighting function based on hrms, and B is an empirical factor.

#### **Input Variables:**

| b      | Real    | Empirical Factor in Thornton & Guza Wave |
|--------|---------|--|
|        |         | Breaking Model $= 1.00$                  |
| dp     | Real    | Offshore Water Depth                     |
| fqz    | Real    | Zero Crossing Frequency                  |
| hrms   | Real    | Root Mean Square Wave Height             |
| p flag | Logical | Weighting Factor Flag (True or False)    |
| roller | Logical | Roller Option Flag (True or False)       |
| o      |         |  |

**Output Variables:** 

diss

Real

**Bore or Roller Dissipation Function** 

## **Local Variables:**

hb3 z

Real Real Weighting Function for Dissipation Term Dissipation Function

Subroutines Called from GET\_DISS ( ):

CALC\_HB3

**GET\_DISS ( ) Called from Subroutines:** 

**GET\_RHS** 

ر

Figure 17. Subroutine GET\_DISS Flowchart



## 5.17 Subroutine GET\_M

## **Subroutine Call:**

GET\_M (dp, hrms, m)

## **Summary:**

Subroutine GET\_M calculates the weighting function multiplier.

## **Input Variables:**

| dp                                 | Real      | Offshore Water Depth         |
|------------------------------------|-----------|------------------------------|
| hrms                               | Real      | Root Mean Square Wave Height |
| Output Variables:                  |           |                              |
| m                                  | Real      | Multiplier                   |
| Local Variables:                   | None.     |                              |
| Subroutines Called from G          | ET_M ( ): | None.                        |
| GET_M ( ) Called from Subroutines: |           |                              |
|                                    |           |                              |

WEIGHTFN

Figure 18. Subroutine GET\_M Flowchart



# 5.18 Subroutine GET\_P

# Subroutine Call:

GET\_P (frac, p)

## Summary:

Subroutine GET\_P calculates the percentage of each breaker type and fills the corresponding array elements.

٦.

# **Input Variables:**

| frac (3)           | Real            | Temporary Array for Breaker<br>Percentage Totals   |
|--------------------|-----------------|--|
| Output Variables:  |                 |  |
| p (4)              | Real            | Percent of Different Breaker Types<br>p (1) = Spilling<br>p (2) = Plunging<br>p (3) = Surging<br>p (4) = Total |
| Local Variables:   |                 |  |
| sum                | Real            | Temporary Variable for Total of Percentage Breakers  |
| Subroutines Called | from GET_P ( ): | None.  |
| GET_P() Called fro | om Subroutines: |  |
| PERCENT            |                 | •  |

Figure 19. Subroutine GET\_P Flowchart

---\*



# 5.19 Subroutine GET\_RHS

## **Subroutine Call:**

GET\_RHS (roller, hrms, theta, Cg, dp, xk, b, fqz, xdelt\_gr, rhs, diss)

## **Summary:**

Subroutine GET\_RHS calculates the right hand side of the wave energy equation.

## **Input Variables:**

| b                 | Real    | Empirical Factor in Breaking Model $= 1.0$ |
|-------------------|---------|--|
| Cg                | Real    | Wave Group Velocity                        |
| dp                | Real    | Offshore Water Depth                       |
| fqz               | Real    | Zero Crossing Frequency                    |
| hrms              | Real    | Root Mean Square Wave Height               |
| roller            | Logical | Roller Option Flag (True or False)         |
| theta             | Real    | Wave Angle, Representative of Radiation    |
|                   |         | Stress Angle                               |
| xdelt_gr          | Real    | Self-Adjusting Cross-Shore Grid Step       |
| xk                | Real    | Wave Number                                |
| Output Variables: |         |  |
| J*                | ~ .     |  |

| uiss | Real | Bore or Roller Dissipation Function |
|------|------|-------------------------------------|
| rhs  | Real | Right Hand Side of Energy Equation  |

### Local Variables:

| e_roller | Real    | Roller Contribution to the Energy Equation |
|----------|---------|--|
| e_wave   | Real    | Wave Contribution to the Energy Equation   |
| p_flag   | Logical | Weighting Factor Flag (True or False)      |

# Subroutines Called from GET\_RHS ( ):

CALCROLL GET\_DISS GET\_WAVE

# **GET\_RHS ( ) Called from Subroutines:**

## MAIN\_WAV

-9.52



## 5.20 Subroutine GET\_SLOPE

## **Subroutine Call:**

GET\_SLOPE (h, x, i0, lamda, nnn, beta)

## Summary:

Subroutine GET\_SLOPE gets bottom slope from a depth profile for percent breaker calculations.

# **Input Variables:**

| h     | Real    | Array of depths associated with x (meters)       |
|-------|---------|--|
| lamda | Real    | Wavelength computed from wavenum()               |
| X     | Real    | Array of cross-shore distance (meters)           |
| iO    | Integer | index from x where slope is computed, $x(i0)$    |
| nnn   | Integer | number of elements of arrays h and x with real I |
|       |         | nfo  |

## **Output Variables:**

| Beta             | real    | bottom slope; positive up looking at beach  |
|------------------|---------|---|
| Local Variables: |         |   |
| I                | integer | counter in do loops                         |
| I_last_wet       | integer | index of last underwater in $h(x)$ array    |
| I_inshore        | integer | index of x and h used for slope computation |
| I_offshore       | integer | index of x and h used for slope computation |
| Once_dry         | logical | used in getting i last wet                  |
| Slope_length     | real    | lamda/2.0                                   |

temp sum of slopes

temporary variable

Subroutines Called from GET\_SLOPE ( ):

real

real

none

Temp

# **GET\_RHS ( ) Called from Subroutines:**

SLF\_STRT GET\_BRK

Sum\_of\_slopes





# 5.21 Subroutine GET\_WAVE

## **Subroutine Call:**

GET\_WAVE (hrms, theta, Cg, e\_wave)

## **Summary:**

Subroutine GET\_WAVE calculates wave energy flux using linear wave theory. The wave energy flux is:

$$E = \frac{\rho g H^2}{8} C_s \cos \theta$$

where  $\rho$  is water density, g is gravity, H is wave height, C<sub>g</sub> if group velocity, and  $\theta$  is the wave angle.

## **Input Variables:**

| Cg                                    | Real             | Wave Group Velocity          |
|---------------------------------------|------------------|------------------------------|
| hrms                                  | Real             | Root Mean Square Wave Height |
| theta                                 | Real             | Wave Angle                   |
| <b>Output Variables:</b>              |                  |                              |
| e_wave                                | Real             | Energy Flux                  |
| Local Variables:                      |                  |                              |
| ew                                    | Real             | Wave Energy                  |
| Subroutines Called from GET_WAVE ( ): |                  | None.                        |
| GET_WAVE ( ) Called f                 | rom Subroutines: |                              |
| F3                                    |                  |                              |

GET\_RHS

Figure 22. Subroutine GET\_WAVE Flowchart



# 5.22 Subroutine GRID\_FRC

## **Subroutine Call:**

GRID\_FRC (s, r, ifreq, f, idirec, d, ifreq\_i, fi, idirec\_i, di, si, ri)

## Summary:

Subroutine GRID\_FRC uses a bilinear interpolation scheme to re-grid the refraction and shoaling matrices obtained from subroutine readfrc to the same frequencies and directions associated with the directional wave spectrum obtained from the subroutine readspec.

## **Input Variables:**

| d                   | Real    | direction array associated with input refraction and  |
|---------------------|---------|---|
| di                  | Real    | shoaling matrices (deg +CW from N)<br>direction array associated with wave spectrum, array to |
|                     |         | which input refraction and shoaling matrices are  |
| f                   | Deal    | interpolated (deg +CW from N)   |
| •                   | Real    | shoaling matrices (hertz)   |
| fi                  | Real    | frequency array to which input refraction and shoaling  |
|                     |         | matrices are interpolated (hertz)   |
| idirec              | integer | no. of direction bands in the input   |
|                     |         | refraction and shoaling matrices  |
| idirec_i            | integer | no. of direction bands to which the   |
|                     |         | refraction and shoaling fields will be  |
|                     |         | interpolated  |
| ifreq               | integer | no. of frequency bands in the original  |
|                     |         | refraction and shoaling matrices  |
| ifreq_i             | integer | no. of frequency bands to which the   |
|                     |         | input refraction and shoaling matrices will   |
|                     |         | be interpolated   |
| r(dirnum, freqnum)  | real    | input refraction matrix. (units are degrees   |
|                     |         | +CW from N., energy from)   |
| s(dirnum, freqnum)  | real    | input shoaling matrix (unitless; energy   |
|                     |         | shoaling [k^2])   |
| Output variables:   |         |   |
|                     |         |   |
| n(aimum, rreqnum)   | real    | refraction matrix with same freqs and directions  |
|                     |         | as input directional wave spectrum.(units are degrees   |
|                     |         | (+CW from N., energy from)  |
| si(dirnum, freqnum) | real    | shoaling matrix with the same frees and directions  |
|                     |         | 60 <sup>°</sup>   |

as the input directional wave spectrum. (unitless; energy shoaling [k^2])

### **Local Variables:**

| i  | integer | counter |
|----|---------|---------|
| j  | integer | counter |
| k  | integer | counter |
| m  | integer | counter |
| tl | real    | temp    |
| t2 | real    | temp    |

## Subroutines Called from GRID\_FRC ( ):

none

# **GRID\_FRC ( ) Called from Subroutines:**

Main program surf





### 5.23 Subroutine GRIDOUT

### **Subroutine Call:**

GRIDOUT (ii, xoff1, xtemp, dxy, htemp, ptemp, xktemp, thetatemp, v, dp1, hout1, hmax, pbreak, brkrang, vlng1)

## **Summary:**

Subroutine GRIDOUT linearly interpolates parameters for final output using the user defined cross-shore step width.

#### **Input Variables:**

| dxy (points)      | Real    | Corresponding Depths with Tide                     |
|-------------------|---------|--|
| htemp (points)    | Real    | Temporary Variable for Significant Wave            |
|                   |         | Height Values                                      |
| ü                 | Integer | Index where Wave Probabilities Exceed<br>Threshold |
| ptemp (points)    | Real    | Percentage of Breaking Waves and<br>Breaker Types  |
| xktemp            | Real    | Temporary Variable for Wave Number                 |
| xoff1             | Real    | Distance Offshore                                  |
| xtemp (points)    | Real    | Temporary Variable for Cross-Shore Values          |
| v (points)        | Real    | Longshore Current                                  |
| Output Variables: |         |  |
| dp1               | Real    | Offshore Depth                                     |
| hmax              | Real    | Maximum Wave Height / 10.0                         |
| hout1             | Real    | Significant Wave Height                            |
| pbreak            | Real    | Percentage Breaking Waves                          |
| vlng1             | Real    | Longshore Current Velocity                         |
| wlen              | Real    | Wave Length  |
| Local Variables:  |         |  |
| hrms1             | Real    | Root Mean Square Wave Height                       |

# Subroutines Called from GRIDOUT ():

GT\_P LIN\_1 LIN\_2 LIN\_3

# **GRIDOUT ()** Called from Subroutines:

PRT\_OUT1





## 5.24 Subroutine GT\_P

#### **Subroutine Call:**

GT\_P (ii, hrms1, dp1, xktemp, hout1, hmax)

#### **Summary:**

Subroutine GT\_P initializes matrices for the creation of an internally generated directional wave spectrum. This wave spectrum has 50 frequencies and 36 directions.

## **Input Variables:**

| dp1               | Real    | Offshore Depth                     |
|-------------------|---------|------------------------------------|
| ii                | Integer | Index where Wave Probabilities     |
|                   | -       | Exceed Threshold                   |
| hrms1             | Real    | Root Mean Square Wave Height       |
| xktemp (points)   | Real    | Temporary Variable for Wave Number |
| Output Variables: |         |                                    |
| hmax              | Real    | Maximum Wave Height / 10.0         |

None.

| hmax  | Keal | Maximum wave Height / 10.0 |
|-------|------|----------------------------|
| hout1 | Real | Significant Wave Height    |
| wlen  | Real | Wave Length                |

Real

#### Local Variables:

hdep

Breaking Wave Height at Specific Depth

## Subroutines Called from GT\_P ():

#### **GT\_P()** Called from Subroutines:

GRIDOUT PRT\_OUT1 PRT\_OUT





#### 5.25 Subroutine GT\_SIG\_H

## Subroutine Call:

GT\_SIG\_H (ifreq, idirec, esowm, ehsig)

#### **Summary:**

Subroutine GT\_SIG\_H sums the energy present in the directional wave spectrum and calculates the significant wave height. The significant wave height is defined as:

 $4\sqrt{\sum e(f,\theta)}$ 

Where, e is the directional wave spectrum.

#### **Input Variables:**

| esowm (dirNum,freqNum)<br>idirec<br>ifreq | Real<br>Integer<br>Integer | Directional Wave Spectrum<br>Number of Direction Bins in Input Spectrum<br>Number of Frequencies in Input Spectrum |
|---|----------------------------|--|
| Output Variables:                         |                            |  |
| ehsig                                     | Real                       | Significant Wave Height from<br>Directional Spectrum   |
| Local Variables:                          |                            |  |
| idir                                      | Integer                    | Direction Loop Counter   |
| ifrq                                      | Integer                    | Frequency Loop Counter   |
| sum1                                      | Real                       | Summing Variable for Wave Height   |
| sum2                                      | Real                       | Summing Variable for Wave Height   |

Subroutines Called from GT\_SIG\_H():

None.

## GT\_SIG\_H () Called from Subroutines:

CALCSURF READSPEC WAVEFIT
Figure 26. Subroutine GT\_SIG\_H Flowchart



#### 5.26 Subroutine INITLIZE

#### **Subroutine Call:**

INITLIZE (dp, fqd, Cg, xk, c)

#### **Summary:**

Subroutine INITLIZE calculates wave parameters at the farthest offshore point. Wave celerity is calculated from the dispersion relation given by:

$$\sigma^2 = g k \tanh(k h)$$

where,  $\sigma$  is the angular frequency of the wave ( $2\pi/T$ ), g is gravity, k is wave number, and h is the local

$$C_g = 0.5C(1 + \frac{2kh}{\sinh kh})$$

water depth. Wave group velocity is calculated from the linear wave theory relation given by: where, C is the wave celerity.

#### **Input Variables:**

| dp  | Real | Offshore Water Depth |  |
|-----|------|----------------------|--|
| fqd | Real | Peak Frequency       |  |
|     |      |                      |  |
|     |      |                      |  |

#### **Output Variables:**

| c  | Real | Wave Celerity at Input Depth & Frequency  |
|----|------|---|
| Cg | Real | Group Velocity at Input Depth & Frequency |
| xk | Real | Wave Number at Input Depth & Frequency    |

### Local Variables:

xkd

Real

Deep Water Wave Number

Subroutines Called from INITLIZE ( ):

WAVENUM

**INITLIZE ( ) Called from Subroutines:** 

### CALCSURF

Figure 27. Subroutine INITLIZE Flowchart



#### 5.27 Subroutine KLONG

#### **Subroutine Call:**

KLONG (j\_ii, xdelt\_gr, eb\_last, along, blong, long, c3, iimax, vwind, v)

#### **Summary:**

Subroutine KLONG calculates longshore current velocity using an implicit double sweep method (Tridiagonal Method) based on the work of Kraus and Larson (1991). The central difference equation is of the form:

 $a_i V_{i-1} + b_i V_i - c_i V_{i+1} = r_i$ 

where, V is the longshore current velocity. The coefficients a, b, and c are calculated from wave parameters.

#### **Input Variables:**

| along (points)    | Real    | Horizontal Mixing Parameter                               |
|-------------------|---------|---|
| blong (points)    | Real    | Bottom Friction   |
| c3                | Real    | Radiation Stress Factor for Longshore Current<br>Velocity |
| clong (points)    | Real    | Wind Stress Contribution to                               |
|                   |         | Longshore Current   |
| eb_last           | Real    | Roller Dissipation Term Farthest Offshore                 |
| iimax             | Integer | Number of Calculation Locations                           |
| j_ii              | Integer | Index where Wave Probabilities                            |
| -                 | ,       | Exceed Threshold  |
| vwind             | Real    | Wind Driven Longshore Current Velocity                    |
| xdelt_gr          | Real    | Self-Adjusting Cross-Shore Grid Step                      |
| Output Variables: |         |   |
| v (points)        | Real    | Longshore Current Velocity                                |

## Local Variables:

| Real    | Temporary Variable Used in Longshore  |
|---------|---|
|         | Current Calculation   |
| Real    | Temporary Variables   |
| Real    | Temporary Variables   |
| Real    | Temporary Variables   |
| Real    | Array of Longshore Driving Terms  |
| Real    | Array of Longshore Bottom Friction  |
| Integer | Array Index   |
| Integer | Loop Variable   |
| Integer | Array Index / Loon Variable   |
| Real    | Self-Adjusting Cross-Shore Grid Step  |
|         | Real<br>Real<br>Real<br>Real<br>Real<br>Real<br>Integer<br>Integer<br>Integer<br>Real |

# Subroutines Called from KLONG ():

None.

# KLONG () Called from Subroutines:

CALCSURF

Figure 28. Subroutine KLONG Flowchart



# 5.28 Subroutines LIN\_1

#### **Subroutine Call:**

LIN\_1 (ii, dx, dy, x, y)

#### **Summary:**

Linear interpolation routine used to scale root mean square wave height and water depth to user-defined grid step for output to the summary text file.

### **Input Variables:**

| dx (points)       | Real    | Input X Value                                      |
|-------------------|---------|--|
| dy (points)       | Real    | Input Y Value                                      |
| ii                | Integer | Index where Wave Probabilities<br>Exceed Threshold |
| x                 | Real    | Offshore Point                                     |
| Output Variables: |         |  |
| у                 | Real    | Interpolated Variable                              |
| Local Variables:  |         |  |
| b1                | Real    | Intercept  |
| m                 | Real    | Slope  |
| x1                | Real    | Cross-Shore Value                                  |
| x2                | Real    | Previous Cross-Shore Value                         |
| y1                | Real    | Height Value                                       |
| y2                | Real    | Previous Height Value                              |
|                   |         |  |

# Subroutines Called from LIN\_1 ( ):

None.

LIN\_1 () Called from Subroutines:

GRIDOUT



25.



# 5.29 Subroutines LIN\_2

#### **Subroutine Call:**

LIN\_2 (ii, dx, dy, x, y)

### Summary:

Linear interpolation routine used to scale percent breaking waves to user-defined grid step for output to the summary text file.

## **Input Variables:**

| dx (points)        | Real          | Input X Value                                      |
|--------------------|---------------|--|
| dy (points)        | Real          | Input Y Value                                      |
| ii                 | · Integer     | Index where Wave Probabilities<br>Exceed Threshold |
| x                  | Real          | Offshore Point                                     |
| Output Variables:  |               |  |
| у                  | Real          | Interpolated Variable                              |
| Local Variables:   |               |  |
| b1                 | Real          | Intercept  |
| m                  | Real          | Slope  |
| x1                 | Real          | Cross-Shore Value                                  |
| x2                 | Real          | Previous Cross-Shore Value                         |
| y1                 | Real          | Height Value                                       |
| y2                 | Real          | Previous Height Value                              |
| Subroutines Called | from LIN 2(): | None   |

LIN\_2() Called from Subroutines:

GRIDOUT



 $\hat{v}_{i}$ 

Ç



## 5.30 Subroutine LIN\_3

## Subroutine Call:

LIN\_3 (ii, dx, dy, x, y)

### Summary:

Linear interpolation routine used to scale longshore current velocity distribution to userdefined grid step for output to the summary text file.

### **Input Variables:**

| dx (points)                      | Real    | Input X Value                  |
|----------------------------------|---------|--------------------------------|
| dy (points)                      | Real    | Input Y Value                  |
| ii                               | Integer | Index where Wave Probabilities |
| x                                | Real    | Offshore Point                 |
| Output Variables:                |         |                                |
| у                                | Real    | Interpolated Variable          |
| Local Variables:                 |         |                                |
| b1 .                             | Real    | Intercept                      |
| m                                | Real    | Slope                          |
| x1                               | Real    | Cross-Shore Value              |
| x2                               | Real    | Previous Cross-Shore Value     |
| y1                               | Real    | Height Value                   |
| y2                               | Real    | Previous Height Value          |
| Subroutines Called from LIN_3(): |         | None.                          |

LIN\_3 () Called from Subroutines:

GRIDOUT



1.1



## 5.31 Subroutine LIN\_4

#### **Subroutine Call:**

LIN\_4 (ii, x, y, xi, yi)

# Summary:

Linear interpolation routine used to scale breaker angle to user-defined grid step for output to the summary text file.

### **Input Variables:**

| x (points)<br>y (points)<br>ii<br>xi | Real<br>Real<br>Integer<br>Real | Input X Value<br>Input Y Value<br>Index in x and y arrays<br>Offshore distance |
|--------------------------------------|---------------------------------|--|
| Output Variables:                    |                                 |  |
| yi                                   | Real                            | Interpolated Variable  |
| Local Variables:                     |                                 |  |
| b                                    | Real                            | Intercept  |
| m                                    | Real                            | Slope  |
| x1                                   | Real                            | Cross-Shore Value  |
| x2                                   | Real                            | Previous Cross-Shore Value   |
| y1                                   | Real                            | Height Value   |
| y2                                   | Real                            | Previous Height Value  |

# Subroutines Called from LIN\_4 ():

None.

LIN\_4() Called from Subroutines:

**GRIDOUT** 





# 5.32 Subroutine LONG1

# Subroutine Call:

LONG1 (ii, c1, c2, c3, c4, dp, ebn, hrms, xk, along, blong, clong)

# Summary:

Subroutine LONG1 calculates and outputs longshore current equation coefficients.

# Input Variables:

| cl   | Real    | Eddy Viscosity Coefficient          |
|------|---------|-------------------------------------|
| c2   | Real    | Bottom Friction Coefficient         |
| c3   | Real    | Radiation Stress Coefficient        |
| c4   | Real    | Longshore Wind Stress Coefficient   |
| dp   | Real    | Offshore Water Depth                |
| ebn  | Real    | Roller or Bore Term                 |
| ii   | Integer | Index where Wave Probabilities      |
|      |         | Exceed Threshold                    |
| hrms | Integer | <b>Root Mean Square Wave Height</b> |
| xk   | Integer | Wave Number                         |
|      |         |                                     |

#### **Output Variables:**

| along (points)<br>blong (points)<br>clong (points) | Real<br>Real<br>Real | Horizontal Mixing Parameter<br>Bottom Friction Parameter<br>Wave and Wind Parameters |
|--|----------------------|--|
| Local Variables:                                   | None.                |  |
| Subroutines Called from LONG1 ():                  |                      | None.  |

LONG1 () Called from Subroutines:

## MAIN\_WAV



٢.

.1



## 5.33 Subroutine MAIN\_WAV

#### **Subroutine Call:**

MAIN\_WAV (roller, dxy, xx1, xshift, b, c1, c2, c3, c4, hrms, xdelt\_gr, fqz, nnn, per, xk, fqd, Cg, self\_st, dstart, theta, theta2, xtemp, xktemp, eb\_last, htemp, ptemp, ebtemp, thetatemp, iimax, along, blong, clong, convg, distmax, rk, b1, surf, j\_ii)

#### Summary:

Subroutine MAIN\_WAV is the main driver for coordinating the iterative solution method applied to solve for the wave and current parameters. This approach is necessary because several of the parameters including wave height, wave length, wave celerity, longshore current velocity, and wave induced setup are interdependent, as well as depth dependent.

#### **Input Variables:**

| b            | Real    | Empirical Factor in Breaking Model = 1.0 |
|--------------|---------|--|
| c1           | Real    | Mixing/Eddy Viscosity Coefficient        |
| c2           | Real    | Bottom Friction Coefficient              |
| c3           | Real    | Factor for Radiation Stress              |
| c4           | Real    | Friction Coefficient = $0.0035$          |
| Cg           | Real    | Wave Group Velocity                      |
| dstart       | Real    | Starting Depth from Input File           |
| dxy (points) | Real    | Corresponding Depths with Tide           |
| fqd          | Real    | Peak Frequency at the Center of the      |
|              |         | Frequency Band                           |
| fqz          | Real    | Zero Crossing Frequency                  |
| hrms         | Real    | Root Mean Square Wave Height             |
| nnn .        | Integer | Number of Points in Input Depth Array    |
| per          | Real    | Peak Period of Directional Wave Spectrum |
| roller       | Logical | Roller Option Flag (True or False)       |
| self_st      | Char*1  | Self Start Flag (Yes or No)              |
| theta        | Real    | Wave Angle                               |
| xdelt_gr     | Real    | Self-Adjusting Cross-Shore Grid Step     |
| xk           | Real    | Wave Number                              |
| xshift       | Real    | Horizontal Cross-Shore Location          |
| xx1 (points) | Real    | Adjusted Cross-Shore Distances from      |
|              |         | Depth Profile                            |

# **Output Variables:**

| along (points)   | Real    | Horizontal Mixing Parameter                |
|------------------|---------|--|
| b1 (points)      | Real    | Bottom Slope                               |
| blong (points)   | Real    | Bottom Friction for Deep & Shallow Water   |
| clong (points)   | Real    | Wind Stress Contribution to                |
|                  |         | Longshore Current                          |
| convg            | Logical | Energy Equation Convergence Flag           |
| U                | Ţ.      | (True or False)                            |
| distmax          | Real    | Farthest Offshore Distance                 |
| eb_last          | Real    | <b>Roller Dissipation Term at Farthest</b> |
| _                |         | Point Offshore                             |
| ebtemp (points)  | Real    | <b>Temporary Roller Dissipation Term</b>   |
|                  |         | Across Transect                            |
| htemp (points)   | Real    | Temporary Variable for Significant Wave    |
|                  |         | Height Values                              |
| iimax            | Integer | Number of Calculation Locations            |
| <u>j_</u> ii     | Integer | Index where Wave Probabilities             |
| -                |         | Exceed Threshold                           |
| ptemp (points)   | Real    | Percentage of Breaking Waves &             |
|                  |         | Breaking Types                             |
| rk (points,4)    | Real    | Matrix of Percentage Breakers and Types    |
|                  |         | Across the Transect                        |
| surf             | Logical | Flag for Low/No Surf Conditions            |
|                  |         | (True or False)                            |
| theta            | Real    | Wave Angle                                 |
| theta2           | Real    | Wave Angle at Input Starting Depth         |
| xktemp (points)  | Real    | Temporary Variable for Wave Number         |
| xtemp (points)   | Real    | Temporary Variable for Cross-Shore Values  |
| Local Variables: |         |  |
| brk10            | Logical | Flag Variable to Find First Location Where |
|                  |         | 10% of Waves Are Breaking (True or False)  |
| cg2              | Real    | Additional Wave Group Velocity             |
| check            | Real    | Difference Between Wave Induced            |
|                  |         | Setup Calculations                         |
| conv_count       | Integer | Number of Convergence Iterations           |
| done             | Logical | Loop Control Variable for Main Wave        |
|                  | -       | Calculation Loop (True or False)           |
| dp               | Real    | Offshore Water Depth                       |
| eb               | Real    | Temporary Roller Dissipation Term          |
|                  |         | Across Transect                            |

| etanew (points) | Real    | Wave Induced Setup Estimated at            |
|-----------------|---------|--|
|                 |         | New Location                               |
| etaold (points) | Real    | Wave Induced Setup Estimated at            |
|                 |         | Previous Location                          |
| hrms2           | Real    | Wave Height for Next Onshore Grid Location |
| ii              | Integer | Index where Wave Probabilities             |
|                 |         | Exceed Threshold                           |
| 11              | Real    | Wave Length at Next Onshore Grid Location  |
| 10              | Real    | Wave Length at Grid Cell (1) Offshore      |
| p (4)           | Real    | Array for Breaker Percentage Totals        |
| pct (4)         | Real    | Percent of Different Breaker Types:        |
|                 |         | pct (1) = Spilling                         |
|                 |         | pct(2) = Plunging                          |
|                 |         | pct(3) = Surging                           |
|                 |         | pct(4) = Total                             |
| rhs             | Real    | Right Hand Side of Energy Balance Equation |
| theta0          | Real    | Wave Angle at Grid (1) Offshore            |
| xoff            | Real    | Distance Offshore                          |

# Subroutines Called from MAIN\_WAV ( ):

ABORT BALANCEQ GET\_BRK GET\_RHS LONG1 PT\_2 SLF\_STRT SETUP

# MAIN\_WAV ( ) Called from Subroutines:

### CALCSURF



Figure 34. Subroutine MAIN\_WAV Flowchart

## 5.34 Subroutine MDSRF1

# Subroutine Call:

MDSRF1 (alfa, chrlie, pct, echo, foxtrt, jgamma, ihtl1, ihtl2, file\_out)

# Summary:

Subroutine MDSRF1 calculates and prints the modified surf index number to the output file.

### **Input Variables:**

| alfa<br>chrlie<br>echo<br>foxtrt<br>ihtl1<br>ihtl2<br>jgamma<br>pct (4) | Real<br>Real<br>Real<br>Real<br>Real<br>Integer<br>Real | Significant Breaker Height<br>Dominant Breaker Period<br>Breaker Angle<br>Longshore Current Speed and Direction<br>Wind Speed<br>Wind Direction<br>Temporary Variable set to Beach Orientation<br>Percent of Different Breaker Types:<br>pct (1) = Spilling<br>pct (2) = Plunging<br>pct (3) = Surging |
|---|---|--|
| file_out  | Char*40   | pct (4) = Total<br>Output File Name  |
| Output Variables:   | None.   |  |
| Local Variables:  |   |  |
| idir  | Integer   | Index for Surf Index Wind Direction  |
| index   | Integer   | Breaker Type Indicator for Surf Index  |
| ispd  | Integer   | Index for Surf Index Wind Speed Lookup in<br>Modification Table  |
| m   | Integer   | Temporary Variable, to Rotate Direction  |
| percent   | Real  | Breaker Type Percentage  |
| srfmod  | Real  | Modified Surf Index from Sum of Values<br>Resulting from Navy Modification Tables in<br>MDSRF2()   |
| sum   | Real  | Running Total of Surf Index  |
| sum1  | Real  | Modified Surf Index Value for Wave Angle   |
| sum2  | Real  | Value for Longshore Current  |
| temp  | Real  | Temporary Wave Angle Variable  |
| theta2  | Real  | Rotated Wind Direction   |
| value   | Real  | Modification Number  |

88

wind (3,3,8)

Real

Surf Index Wind Modification Table

### Subroutines Called from MDSRF1 ():

### MDSRF2

# MDSRF1 () Called from Subroutines:

SURF

Figure 35. Subroutine MDSRF1 Flowchart



#### 5.35 Subroutine MDSRF2

### **Subroutine Call:**

MDSRF2 (index, xin, yin, value)

### Summary:

Subroutine MDSRF2 contains the modified surf index (MSI) tables. The MSI number is

calculated using a two dimensional linear interpolation by areas.

### **Input Variables:**

| index             | Integer | Indicator of Breaker Type                 |  |
|-------------------|---------|---|--|
| xin               | Real    | X-Coordination for Surf Index             |  |
|                   |         | Modification Matrix                       |  |
| yin               | Real    | Y-Coordination for Surf Index             |  |
| -                 |         | Modification Matrix                       |  |
| Output Variables: |         |   |  |
| value             | Real    | Returns Modified Surf Index Number        |  |
| Local Variables:  |         |   |  |
| i                 | Integer | Loop Counter or Array Index               |  |
| i1                | Integer | Loop Counter or Array Index               |  |
| i2                | Integer | Loop Counter or Array Index               |  |
| ii                | Integer | Loop Counter or Array Index               |  |
| ix (4)            | Real    | All Values Set to 11.00                   |  |
| ју (4)            | Real    | Values Set to 10.0, 11.0, 11.0, 9.0       |  |
| j                 | Integer | Loop Counter or Array Index               |  |
| j1                | Integer | Loop Counter or Array Index               |  |
| j2                | Integer | Loop Counter or Array Index               |  |
| jj                | Integer | Loop Counter or Array Index               |  |
| temp1             | Real    | Temporary Variable Used for Interpolation |  |
| x (11)            | Real    | MSI Indices                               |  |
| x0 (4,11)         | Real    | Breaker Period Modification table         |  |
| xdata             | Real    | Temporary Index                           |  |
| y (11)            | Real    | MSI Indices                               |  |
| y0 (4,11)         | Real    | Wave Angle Modification table             |  |
| ydata             | Real    | Temporary Index                           |  |
| z (11,11)         | Real    | Breaker Modification Matrix               |  |
| z0 (4,11,11)      | Real    | Whole Breaker Modification Matrix         |  |
| z1 (40)-z11(40)   | Real    | Partial Breaker Modification Arrays       |  |
|                   |         |   |  |

91

| z12 (44)  | Real |
|-----------|------|
| zz0 (484) | Real |

Partial Breaker Modification Array Equivalent to z0 (1,1,1) zz0 (1)

# Subroutines Called from MDSRF2 ( ):

None.

# MDSRF2 () Called from Subroutines:

#### MDSRF1

# Figure 36. Subroutine MDSRF2 Flowchart



## 5.36 Subroutine NEW\_BRK

### Subroutine Call:

NEW\_BRK (iimax, b1, rk, htemp, wid\_ii, p2)

### Summary:

Subroutine NEW\_BRK calculates a new percentage of breaker types from the highest 10% of

the wave heights (hrms) when the bottom slope is positive.

### **Input Variables:**

| b1 (points)       | Real    | Bottom Slope  |
|-------------------|---------|---|
| htemp (points)    | Real    | Temporary Variable for Significant Wave   |
|                   |         | Height Values   |
| iimax             | Integer | Number of Calculation Locations   |
| rk (points,4)     | Real    | Matrix of Percentage Breakers and Types<br>Across the Transect  |
| wid_ii            | Integer | Offshore Location for Surf Zone Width   |
| Output Variables: |         |   |
| p2 (4)            | Real    | Percent of Different Breaker Types -<br>Equivalent to pct (4)<br>p2 (1) = Spilling<br>p2 (2) = Plunging<br>p2 (3) = Surging<br>p2 (4) = Total |
| Local Variables:  |         |   |
| ak1 (points)      | Real    | Temporary Array for Wave Height   |
| bk1 (points)      | Real    | Temporary Array Breaker Type = 1 Spilling   |
| bk2 (points)      | Real    | Temporary Array Breaker Type = 2 Plunging   |
| bk3 (points)      | Real    | Temporary Array Breaker Type = 3 Surging  |
| bk4 (points)      | Real    | Temporary Array Breaker Type = 4 Total<br>Total Percentage of Breakers  |
| i                 | Integer | Loop Counter  |
| ii                | Integer | Loop Counter  |
| nval              | Integer | Number of Positive Slope Occurrences  |
| x1                | Real    | 0.1 % of Highest Breakers to Examine for Type   |
|                   |         |   |

# Subroutines Called from NEW\_BRK ( ):

### ABORT RN2

# NEW\_BRK ( ) Called from Subroutines:

## SHORTOUT

Figure 37. Subroutine NEW\_BRK Flowchart



# 5.37 Subroutine PERCENT

## **Subroutine Call:**

PERCENT (hrms, period, dp, slope, p)

## **Summary:**

Subroutine PERCENT calculates the percentage of each type of breaking wave in the surf

zone.

### **Input Variables:**

| dp<br>hrms<br>period<br>slope | Real<br>Real<br>Real<br>Real | Offshore Water Depth<br>Root Mean Square Wave Height<br>Peak Period<br>Bottom Slope   |
|-------------------------------|------------------------------|---|
| <b>Output Variables:</b>      |                              |   |
| p (4)                         | Real                         | Array of Percentage of Breaker Types<br>pct (1) - Spilling<br>pct (2) - Plunging<br>pct (3) - Surging<br>pct (4) - Total Percentage |
| Local Variables:              |                              |   |
| frac (3)                      | Real                         | Array for Percentage Breaker Totals   |
| gtemp                         | Real                         | Gravity   |
| hhigh                         | Real                         | Upper Bound of Integration  |
| hlow                          | Real                         | Lower Bound of Integration  |
| integrat                      | Real                         | Wave Height Distribution Calculated at a Specific Location  |
| p_flag                        | Logical                      | Weighting Factor Flag (True or Falce)   |
| param                         | Real                         | Integral Multiplier   |

# Subroutines Called from PERCENT ():

GET\_P

Functions Called from PERCENT ():

INTEGRAT

**PERCENT () Called from Subroutines:** 

GET\_BRK SLF\_STRT

Figure 38. Subroutine PERCENT Flowchart



# 5.38 Subroutine PRT\_OUT1

## Subroutine Call:

PRT\_OUT1 (j\_ii, xdelt, iimax, dxy, xtemp, xktemp, thetatemp, htemp, ptemp, v) Summary:

Subroutine PRT\_OUT1 prints columnar data, cross-shore distributions of wave and surf parameters, to the detailed SURF output file when requested by the user. This data is interpolated to the user defined grid step, if possible.

# **Input Variables:**

| dxy (points)            | Real            | Corresponding Denths with Tide   |
|-------------------------|-----------------|--|
| j_ii                    | Integer         | Index where Wave Probabilities   |
| iimax<br>htemp (points) | Integer<br>Real | Exceed Threshold<br>Number of Calculation Locations<br>Temporary Variable for Significant Wave |
| ptemp (points)          | Real            | Height Values<br>Percentage of Breaking Waves &<br>Breaker Tures                               |
| v (points)              | Real            | Longshore Current Velocity   |
| xdelt                   | Real            | Surf Zone Output Interval  |
| xktemp (points)         | Real            | Temporary Wave Number Array  |
| xtemp (points)          | Real            | Temporary Variable for Cross-Shore Values  |
| Output Variables:       | None.           |  |

#### Local Variables:

| dpl    | Real    | Offshore Depth               |
|--------|---------|------------------------------|
| hmax   | Real    | Maximum Wave Height          |
| hout1  | Real    | Significant Wave Height      |
| hrms1  | Real    | Root Mean Square Wave Height |
| ii     | Integer | Array Index Number           |
| jj     | Integer | Iteration Count              |
| pbreak | Real    | Percentage Breaking Wayes    |
| vlng1  | Real    | Longshore Current Velocity   |
| wlen   | Real    | Wave Length                  |
| xoffl  | Real    | Distance Offshore            |
|        |         |                              |

#### Subroutines Called from PRT\_OUT1 ():

ABORT GT\_P GRIDOUT

#### **PRT\_OUT1 ()** Called from Subroutines:

CALCSURF

### Figure 39. Subroutine PRT\_OUT1 Flowchart



### 5.39 Subroutine PRT\_OUT2

## **Subroutine Call:**

PRT\_OUT2 (j\_ii, xdelt, iimax, dxy, xtemp, xktemp, thetatemp, htemp, ptemp, v)

### **Summary:**

Subroutine PRT\_OUT2 writes the detailed surf output.

#### **Input Variables:**

| dxy (points)             | Real    | Corresponding Depths with Tide            |
|--------------------------|---------|---|
| j_ii                     | Integer | Index where Wave Probabilities            |
|                          | C C     | Exceed Threshold                          |
| iimax                    | Integer | Number of Calculation Locations           |
| htemp (points)           | Real    | Temporary Variable for Significant Wave   |
|                          |         | Height Values                             |
| ptemp (points)           | Real    | Percentage of Breaking Wayes and          |
|                          |         | Breaker Types                             |
| v (points)               | Real    | Longshore Current Velocity                |
| xdelt                    | Real    | Surf Zone Output Interval                 |
| xktemp (points)          | Real    | Temporary Wave Number Array               |
| xtemp (points)           | Real    | Temporary Variable for Cross-Shore Values |
| <b>Output Variables:</b> | None.   |   |
| Local Variables:         |         |   |
| dp1                      | Real    | Offshore Depth                            |
| hmax                     | Real    | Maximum Wave Height                       |
| hout1                    | Real    | Significant Wave Height                   |
| hrms1                    | Real    | Root Mean Square Wave Height              |
| іі                       | Integer | Array Index Number                        |
| ij                       | Integer | Iteration Counter                         |
| pbreak                   | Real    | Percentage Breaking Wayes                 |
| vlng                     | Real    | Longshore Current Velocity                |
| wlen                     | Real    | Wave Length                               |
| xoffl                    | Real    | Distance Offshore                         |
|                          |         |   |

# Subroutines Called from PRT\_OUT2 ():

GT\_P ABORT

#### **PRT\_OUT2 ( ) Called from Subroutines:**

#### CALCSURF

#### Figure 40. Subroutine PRT\_OUT2 Flowchart



# 5.40 Subroutine PRT\_OUT3

# Subroutine Call:

PRT\_OUT3 (file\_dat)

# Summary:

Subroutine PRT\_OUT3 writes out the detailed output from the model.

Input Variables:

| file_dat               | Char*40           | Output File name *.dat |
|------------------------|-------------------|------------------------|
| Output Variables:      | None.             |                        |
| Local Variables:       |                   |                        |
| line                   | Char*80           | Temporary String       |
| Subroutines Called fro | om PRT_OUT3 ( ):  | None.                  |
| PRT_OUT3() Called      | from Subroutines: |                        |
| SURF                   |                   |                        |

Figure 41. Subroutine PRT\_OUT3 Flowchart



## 5.41 Subroutine PT2

#### **Subroutine Call:**

PT2 (10, theta0, fqd, dp, theta, xk, 1, Cg)

#### **Summary:**

Subroutine PT2 calculates wave parameters from linear theory relations.

| Cg = nC  | Group Velocity              |
|--|-----------------------------|
| $n = \frac{1}{2} \left[ 1 + \frac{2kh}{\sinh 2kh} \right]$ |                             |
| $\frac{\sin \theta}{C} = \frac{\sin \theta_0}{C_0}$        | Wave angle from Snell's law |

#### **Input Variables:**

| dp     | Real | Offshore Water Depth          |
|--------|------|-------------------------------|
| fqd    | Real | Peak Frequency                |
| 10     | Real | Wave Length at Offshore Point |
| theta0 | Real | Wave Angle at Offshore Point  |
| xk     | Real | Wave Number                   |

#### **Output Variables:**

| Cg    | Real |
|-------|------|
| 1     | Real |
| theta | Real |
| xk    | Real |

#### **Local Variables:**

| Real |
|------|
|      |

**Temporary Variable** 

Group Velocity Wave Length Wave Angle Wave Number

#### Subroutines Called from PT2 ():

WAVENUM

#### PT2() Called from Subroutines:
MAIN\_WAV SLF\_STRT

# Figure 42. Subroutine PT2 Flowchart



#### 5.42 Subroutine RAD\_ST1

#### **Subroutine Call:**

RAD\_ST1 (ifreq, freq, idirec, xfrom, esowm, freq1, freq2, dstart, igamma, theta, hrms, surf, fqd, per, fqz)

#### **Summary:**

Subroutine RAD\_ST1 searches the directional wave spectrum to identify the dominant wave frequency and sums the wave energy directed toward shore. The flux of momentum or Radiation Stress, which contributes to driving the longshore current, is calculated following Thornton and Guza

 $S_{xy}(\theta, f) = E(\theta, f) n(f) \sin \alpha(f) \cos \alpha(f)$ 

#### (1986).

In the above equation  $S_{xy}$  is the Radiation Stress, E is the total energy in the directional wave spectrum, n is the ratio of wave group velocity to wave velocity, and  $\alpha$  is the wave angle. The ratio n from linear wave theory is given by:

$$n = \frac{C_{\ell}}{C} = 0.5 \left( l + \frac{2 k h}{\sinh k h} \right)$$

where,  $C_{g}$  is the group velocity, C is the wave velocity or celerity, k is the wave number and h is the local water depth.

#### **Input Variables:**

| dstart                 | Real    | Input Starting Depth                      |
|------------------------|---------|---|
| esowm (dirNum,freqNum) | Real    | Directional Wave Spectrum                 |
| freq (freqNum)         | Real    | Input Wave Spectrum Center Frequencies    |
| freq1(freqNum)         | Real    | Beginning Frequency Bin Values            |
| freq2 (freqNum)        | Real    | Ending Frequency Bin Values               |
| idirec                 | Integer | Number of Directions in Input Spectrum    |
| ifreq                  | Integer | Number of Frequencies in Input Spectrum   |
| igamma                 | Integer | Beach Orientation Rotated 90 Degrees from |
| -                      | -       | Original Heading Toward Beach             |
| xfrom (freqNum)        | Real    | Direction Array, Direction Wave Energy    |
|                        |         | Comes From                                |

# **Output Variables:**

| fqd              | Real    | Peak Frequency at the Center of the        |
|------------------|---------|--|
| faz              | Deal    | Frequency Band                             |
| hrms             | Real    | Zero Crossing Frequency                    |
| ner              | Real    | Root Mean Square Wave Height               |
| por              | Keai    | Peak Period of Directional Wave Spectrum   |
| Sull             | Logical | Flag for Low or No Surf Conditions         |
| thata            |         | (True or False)                            |
| ucia             | Keal    | Wave Angle                                 |
| Local Variables: |         |  |
| direc            | Real    | Wave Direction                             |
| ees              | Real    | Spectral Density at a Particular           |
|                  |         | Frequency and Direction                    |
| esum             | Real    | Sum of Energy in One Frequency Band        |
|                  |         | Over all Directions                        |
| esumm            | Real    | Sum of All Energy in Directional Spectrum  |
| frd              | Real    | Wave Frequency                             |
| idir             | Integer | Loon Counter                               |
| ifrq             | Integer | Loop Counter                               |
| m                | Integer | Temporary Variable for Rotating Wave Angle |
| maxfrq           | Integer | Frequency at Maximum Spectral Density      |
| summax           | Real    | Frequency Band with Maximum Energy         |
| sumzero          | Real    | Summation of Zero-Crossing Frequency       |
|                  |         | Energy                                     |
| sxy              | Real    | Radiation Stress                           |
| sxysum           | Real    | Sum of Radiation Stress Energy             |
| temp             | Real    | Temporary Variable in Radiation            |
|                  |         | Stress Calculation                         |
| temp2            | Real    | Temporary Variable for Frequency Band with |
|                  |         | Maximum Energy                             |
| theta2           | Real    | Angle Between Wave Ray and Beach           |
|                  |         | Perpendicular Projection                   |
| xk               | Real    | Wave Number                                |
| xkd              | Real    | Wave Number Multiplied by the              |
|                  |         | Local Water Depth                          |

Subroutines Called from RAD\_ST1(): RAD\_ST2 WAVENUM

**RAD\_ST1 ( ) Called from Subroutines:** CALCSURF





# 5.43 Subroutine RAD\_ST2

### **Subroutine Call:**

RAD\_ST2 (freq, sxysum, sumzero, esumm, maxfrq, dstart, theta, hrms, surf, fqd, per, fqz)

## Summary:

Subroutine RAD\_ST2 calculates several parameters based on the total energy in the directional wave spectrum. A check is performed to confirm that wave energy is directed onshore before writing summary information to the output file.

## **Input Variables:**

| dstart<br>esumm<br>freq (freqNum)<br>maxfrq<br>sumzero | Real<br>Real<br>Real<br>Integer<br>Real | Input Starting Depth<br>Sum of All Energy in Directional Spectrum<br>Input Wave Spectrum Center Frequencies<br>Frequency at Maximum Spectral Density<br>Summation of Zero-Crossing<br>Frequency Energy |
|--|---|--|
| sxysum   | Real                                    | Sum of Radiation Stress energy   |
| Output Variables:                                      |   |  |
| fqd  | Real                                    | Peak Frequency   |
| fqz  | Real                                    | Zero Crossing Frequency  |
| hrms   | Real                                    | Root Mean Square Wave Height   |
| per  | Real                                    | Peak Period of Directional Wave Spectrum   |
| surf   | Logical                                 | Logical Flag for Low/No Surf Conditions  |
| theta  | Real                                    | Wave Angle   |
| Local Variables:                                       |   |  |
| hs   | Real                                    | Significant Wave Height  |
| sxy2   | Real                                    | Temporary Wave Energy  |
| temp   | Real                                    | Temporary Variable for Energy  |
| theta3   | Real                                    | Wave Angle in Degrees  |
| xk   | Real                                    | Wave Number Calculated at Peak Frequency<br>and Input Starting Depth   |
| xkd  | Real                                    | Wave Number * Water Depth  |

Subroutines Called from RAD\_ST2():

S\_NOSURF WAVENUM

**RAD\_ST2 ( ) Called from Subroutines:** 

RAD\_ST1

Figure 44. Subroutine RAD\_ST2 Flowchart



### 5.44 Subroutine READRFRC

### **Subroutine Call:**

READRFRC (fracname, ifreq, freq, idirec, xfrom, xcoeff, xtheta)

### Summary:

Subroutine READRFRC reads refraction information from a formatted input file. The matrices contained in these files are used to shoal and refract a directional wave spectrum from an offshore point to a location where depth information is available. The number of frequency bins must not exceed 50 and the number of direction bins must not exceed 180. The directional coverage of the refraction and shoaling coefficients must range from 0 to 360 degrees. Partial coverage over a fraction of the compass (e.g. 180 degree sector) will introduce errors.

## **Input Variables:**

| fracname   | Char*40   | Wave Refraction File  |
|--|---|---|
| Output Variables:  |   |   |
| idwsdirec  | Integer   | Number of rows (Directions) in the<br>Directional Ways Spectrum Matrix  |
| idwsfreq   | Integer   | Number of columns (Frequencies) in the<br>Directional Wave Spectrum Matrix  |
| sdir (dirNum)  | Real  | Directional Wave Spectrum Matrix<br>Direction Array for each bin in the<br>Directional Wave Spectrum  |
| sfreq (freqNum)  | Real  | Center Frequency of each Directional<br>Wave Spectrum   |
| xcoeff (dirNum,freqNum)  | Real  | Wave Becchulin<br>Wave Height Refraction Coefficients   |
| xtheta (dirNum, freqNum)   | Real  | Angle Refraction Coefficients   |
| Local Variables:   |   |   |
| cfmatch<br>cfreq (freqNum)<br>col<br>dangle<br>dir<br>dirin<br>dirin | Logical<br>Real<br>Real<br>Real<br>Real<br>Integer<br>Integer | Flag for Center Frequency Match<br>Center Frequency of each Bin<br>Number of Columns<br>Angle Between Directional Bins<br>Number of Angles<br>X-Coordinates of known values<br>Direction of Wayes                     |
| dirouts (dirNum)<br>dirs (dirNum)<br>dmatch                          | Real<br>Real<br>Logical                                       | <ol> <li>Direction Waves are coming from</li> <li>Direction Waves are going to</li> <li>Interpolated X-Coordinates</li> <li>Temporary Direction Wave Energy Comes From</li> <li>Flag for Directional Match</li> </ol> |

| dr1 Real Initial Direction Bin                                    |      |
|---|------|
|   |      |
| dth Real Temporary Angle Between Directional I                    | Bins |
| dum Real Temporary Variable                                       |      |
| dum2 Real Temporary Variable                                      |      |
| dumstr Char*80 Temporary Variable                                 |      |
| fmatch Logical Flag for Frequency Match                           |      |
| fnum Integer Bin Number   |      |
| found Integer Flag Indicator                                      |      |
| frchk Integer Total Number of Frequencies                         |      |
| frg Real Number of Frequencies                                    |      |
| I Integer Loop Counter  |      |
| ii Integer Counter  |      |
| icol Integer Number of Columns                                    |      |
| idir Integer Loop Counter   |      |
| idirec Integer Number of Rows (Directions) in the                 |      |
| Refraction/Shoaling Matrix  |      |
| ifreq Integer Number of Columns (Frequencies) in the              | e    |
| Refraction/Shoaling Matrix  |      |
| ifrq Integer Loop Counter   |      |
| instat Integer Error Status                                       |      |
| irow Integer Number of Rows                                       |      |
| i Integer Loop Counter  |      |
| ji Integer Counter  |      |
| k Integer Counter   |      |
| kk Integer Counter  |      |
| Ifreq Real Lower Frequency Bin Limit                              |      |
| lowcut Integer Lower Cut Off Limit                                |      |
| mpnt Integer Number of Rows divided by 2                          |      |
| refs (dirNum) Real Temporary Array                                |      |
| rfrtmp (dirNum, freqNum) Real Temporary Matrix for Reversing Wave |      |
| Direction   |      |
| row Real Number of Rows   |      |
| rtmpout (dirNum) Real Interpolated Coordinates                    |      |
| sfreqin (dirNum) Real Temporary Frequency Array                   |      |
| shltmp (dirNum, freqNum) Real Temporary Matrix for Reversing Wave |      |
| Direction   |      |
| splout (dirNum) Real interpolated Y-Coordinates                   |      |
| stmpout (dirNum) Real Interpolated Coordinates                    |      |
| temp (dirNum, freqNum) Real Temporary Variable                    |      |
| temp2 (dirNum, freqNum) Real Temporary Variable                   |      |
| tmpinr (dirNum) Real Temporary Variable                           |      |
| tmpins (dirNum) Real Temporary Variable                           |      |
| ufreq Real Upper Frequency Bin Limit                              |      |
| upcut Integer Upper Cut Off Limit                                 |      |
| xfrom (dirNum) Real Direction Wave Energy Comes From              |      |

Subroutines Called from READRFRC ():

ABORT GENRLSPL

# **READRFRC ()** Called from Subroutines:

SURF





#### 5.45 Subroutine READSPEC

#### **Subroutine Call:**

READSPEC (ifreq, idirec, Cfreq, Lfreq, Ufreq, xfrom, sowm, period, ehsig, dangle, spefile) Summary:

Subroutine READSPEC opens and reads a directional wave spectrum file, which must conform to a specific format, but the number of frequencies and directions can vary. The maximum number of directions is 180 and the maximum number of frequencies is 50. The directions should be evenly spaced, and the frequency bins can be fixed or variable width with units of energy density (m^2/(Hz\*radians)). This energy density matrix is initialized, filled, and converted to units of feet squared inside this subroutine. In addition, the direction of wave energy can be the direction FROM which waves are coming or TO which waves are going as denoted in the tenth header line by a 1 or 2 respectively. The directional wave spectrum must be defined from 0 to 360 degrees. Use of partial directional sectors (e.g. 0 to 180 degrees) will cause errors.

#### Input Variables: None.

#### **Output Variables:**

| Cfreq (freqNum)        | Real    | Center Frequency Bin I imit                |
|------------------------|---------|--|
| dangle                 | Real    | Angle Between Directional Bins             |
| ehsig                  | Real    | Significant Wave Height from               |
|                        |         | Directional Spectrum                       |
| esowm (dirNum,freqNum) | Real    | Directional Wave Spectrum                  |
| idirec                 | Integer | Number of Direction Bins in Input Spectrum |
| ifreq                  | Integer | Number of Frequency Bins in Input Spectrum |
| Lfreq (freqNum)        | Real    | Lower Frequency Bin Limit                  |
| period (freqNum)       | Real    | Period Array (1/Frequency)                 |
| spefile                | Char*40 | Wave Spectrum File Name                    |
| Ufreq (freqNum)        | Real    | Upper Frequency Bin Limit                  |
| xfrom (dirNum)         | Real    | Direction Array, Direction Wave Energy     |
|                        |         | Comes From                                 |

### Local Variables:

| col                  | Real    | Number of Columns                     |
|----------------------|---------|---------------------------------------|
| df                   | Real    | Difference between Upper & Lower Bins |
| dir                  | Real    | Number of Angles                      |
| dirord               | Integer | Direction of Waves                    |
|                      | -       | 1 - Direction Waves are coming from   |
|                      |         | 2 - Direction Waves are going to      |
| đth                  | Real    | Width of Direction Bin                |
| dum                  | Char*1  | Temporary Variable                    |
| dr1                  | Real    | Initial Direction Bin                 |
| fnum                 | Integer | Bin Number                            |
| frq                  | Real    | Number of Frequencies                 |
| ftsq2msg             | Real    | Conversion Factor                     |
| I                    | Integer | Loop Counter                          |
| icol                 | Integer | Number of Columns                     |
| idir                 | Integer | Direction Loop Counter                |
| ifrq                 | Integer | Loop Counter                          |
| instat               | Integer | Error Status                          |
| irow                 | Integer | Number of Rows                        |
| j                    | Integer | Loop Counter                          |
| mpnt                 | Integer | Number of Rows divided by 2           |
| mult                 | Real    | <b>Temporary Calculation Variable</b> |
| row                  | Real    | Number of Rows                        |
| temp (dirNum,dirNum) | Real    | Temporary Array                       |
|                      |         |                                       |

### Subroutines Called from READSPEC ():

### ABORT GT\_SIG\_H

### **READSPEC ( ) Called from Subroutines:**

SURF



Figure 46. Subroutine READSPEC Flowchart

#### 5.46 Subroutine REFRAC

#### **Subroutine Call:**

REFRAC (idirec, ifreq, xfrom, xtheta, xcoeff, esowm, ehsig)

#### **Summary:**

For each frequency and direction bin in the input directional wave spectrum, the shallow water direction band for each deep water direction band is found. Wave energy from each deep water band is multiplied by the combined refraction/shoaling coefficient and moved into the proper shallow water band to provide a shallow water directional spectrum.

#### **Input Variables:**

Subroutines Called from REFRAC ():

None.

# **REFRAC ()** Called from Subroutines:

SURF



## Figure 47. Subroutine REFRAC Flowchart

#### 5.47 Subroutine RN2

### **Subroutine Call:**

RN2 (n, x, y1, y2, y3, y4)

### **Summary:**

Subroutine RN2 calculates percentages of each type of breaker in the surf zone.

### **Input Variables:**

| n           | Integer | Number of Waves Considered Breaking on a |
|-------------|---------|--|
|             | •       | Positive Bottom Slope                    |
| x (points)  | Real    | Temporary Significant Wave Height Array  |
| yl (points) | Real    | Spilling Breaker Type                    |
| y2 (points) | Real    | Plunging Breaker Type                    |
| y3 (points) | Real    | Surging Breaker Type                     |
| y4 (points) | Real    | Total Number of Breakers                 |

### **Output Variables:**

| y1 (points) | Real | Spilling Array Breaker Type |
|-------------|------|-----------------------------|
| y2 (points) | Real | Plunging Array Breaker Type |
| y3 (points) | Real | Surging Array Breaker Type  |
| y4 (points) | Real | Total Array Breaker Type    |

#### **Local Variables:**

| hold | Real    | Temporary Variable Used for Repositioning |
|------|---------|---|
| i    | Integer | Loop Counter                              |
| i    | Integer | Loop Counter                              |
| is · | Integer | Loop Starting Index                       |
| m    | Integer | Number of Waves Considered Breaking on a  |
|      |         | Positive Slope                            |

### Subroutines Called from RN2 ():

None.

# **RN2 ( ) Called from Subroutines:**

### NEW\_BRK





120 ·

#### 5.48 Subroutine S\_COEFF

#### **Subroutine Call:**

S\_COEFF (dp, fqd, hrms, theta, c, xk, wdir, igamma, wdspd, c1,c2, c3, c4, cf, vwind)

#### Summary:

Subroutine S\_COEFF calculates several parameters in the longshore current equation including the Radiation Stress, the bottom stress, and the wind stress. A check is performed to assure that wave induced motion is not dominated by wind effects and a warning message is written to the output file if this condition is violated. An assumption is made that if the wave induced orbital velocity is greater than the wind-forced component of the longshore current, the local conditions are wave dominated.

#### **Input Variables:**

| с      | Real    | Wave Celerity at Input Starting Depth    |
|--------|---------|--|
| dp     | Real    | Water Depth Offshore                     |
| fqd    | Real    | Peak Frequency from Directional Spectrum |
| hrms   | Real    | Root Mean Square Wave Height             |
| igamma | Integer | Beach Orientation, Compass Heading       |
| -      | -       | Directly Toward Beach                    |
| theta  | Real    | Wave Angle                               |
| wdir   | Real    | Input Wind Direction Compass Heading     |
| wdspd  | Real    | Input Wind Speed                         |
| xk     | Real    | Wave Length at Input Starting Depth      |

#### **Output Variables:**

| cl    | Real | Mixing/Eddy Viscosity Coefficient      |
|-------|------|--|
| c2    | Real | Bottom Friction Coefficient            |
| c3    | Real | Factor for Radiation Stress            |
| c4    | Real | Friction Coefficient                   |
| vwind | Real | Wind Driven Longshore Current Velocity |

### Local Variables:

| c4tmp  | Real    | Temporary Variable Used in Wind Velocity   |
|--------|---------|--|
|        |         | Vector Calculation                         |
| cd     | Real    | Coefficient of Drag Used in Wind           |
|        |         | Velocity Calculation                       |
| cf     | Real    | Coefficient of Friction for the Bottom     |
| dwind  | Real    | Sign of Wind Vector (Positive or Negative) |
| m      | Integer | Temporary Variable Used in Rotating        |
|        |         | Wind Angle                                 |
| theta4 | Real    | Rotated Wind Direction                     |
| uorb   | Real    | Wave Particle Orbital Velocity             |
| xn     | Real    | Eddy Viscosity Mixing Coefficient          |

# Subroutines Called from S\_COEFF ( ):

None.

# S\_COEFF ( ) Called from Subroutines:

CALCSURF





### 5.49 Subroutine S\_NOSURF

### **Subroutine Call:**

S\_NOSURF ( hsig, surf )

### Summary:

Subroutine S\_NOSURF is called to determine if local conditions are significant enough to proceed with surf zone calculations. The minimum condition for continuation is that the significant wave height calculated from the directional wave spectrum must be greater than 0.15 m.

### **Input Variables:**

RAD\_ST2

| hsig                                  | Real    | Significant Wave Height                    |
|---------------------------------------|---------|--|
| Output Variables:                     |         |  |
| surf                                  | Logical | Flag to Indicate Low or No Surf Conditions |
| Local Variables:                      | None.   | (True or False)                            |
| Subroutines Called from S_NOSURF ( ): |         | None.                                      |
| S_NOSURF ( ) Called from Subroutines: |         |  |
| CALCSURF                              |         |  |





## 5.50 Subroutine S\_TIDE

### **Subroutine Call:**

S\_TIDE (tide, ydepth, nnn, dxy1, xx1, dxy, xshift)

### Summary:

Subroutine S\_TIDE adds the tidal elevation to each cross-shore point in the input depth profile.

### **Input Variables:**

| dxyl (points)          | Real          | Corresponding Depths without Tide                    |
|------------------------|---------------|--|
| nnn                    | Integer       | Number of Points in Input Depth Array                |
| tide                   | Real          | Tide Level   |
| xx1 (points)           | Real          | Adjusted Cross-Shore Distances from<br>Depth Profile |
| ydepth                 | Char*1        | Usage of Input Depth (Yes/No)                        |
| Output Variables:      |               |  |
| dxy (points)           | Real          | Adjusted Depths with Tide                            |
| xshift                 | Real          | Offshore Distance                                    |
| Local Variables:       |               |  |
| ddiff                  | Real          | Change in Water Denth                                |
| n                      | Integer       | Loop Counter   |
| nn                     | Integer       | Loop Counter   |
| mm                     | Integer       | Loop Counter   |
| xdiff                  | Real          | Change in Cross-Shore Location                       |
| ztide                  | Real          | Tide Level   |
| Subroutines Called fro | m S_TIDE ( ): | None.  |

## **S\_TIDE ( ) Called from Subroutines:**

CALCSURF





### 5.51 Subroutine SEAFIT

#### **Subroutine Call:**

SEAFIT (hsig, per, dir, ifreq, idirec, freq1, freq2, xfrom, esowm)

### Summary:

Subroutine SEAFTT calculates a directional wave spectrum from an input wave height and wave period using a Pierson-Moskowitz spectrum representation and a cosine to the fourth directional spreading function. The modified Pierson-Moskowitz equation (from Pierson and Moskowitz, 1964)

$$E(f) = a g^2 w^{-5} e^{[-b(w_o/w)^4]}$$

provides wave energy at each frequency from the following equation: where :

 $w = 2\pi f$ 

in which f is the wave frequency in Hertz, g is gravity, and U is the wind speed in meters per second measured at 19.5 m above the sea surface. The spectrum E(f) is a vector of spectral densities and it is

$$a = 0.0081$$
$$b = 0.74$$
$$w_o = \frac{g}{U}$$

assumed that each density is integrated from the lower limit of the frequency bin to the upper limit of the frequency bin.

#### **Input Variables:**

| dir             | Real    | Wave Direction                             |
|-----------------|---------|--|
| freq1 (freqNum) | Real    | Beginning Frequency Bin Value              |
| freq2 (freqNum) | Real    | Ending Frequency Bin Value                 |
| hsig            | Real    | Significant Wave Height                    |
| idirec          | Integer | Number of Direction Bins in Input Spectrum |

| ifreq<br>per<br>xfrom (dirNum) | Integer<br>Real<br>Real | Number of Frequencies in Input Spectrum<br>Peak Period of Directional Wave Spectrum<br>Direction Array, Direction Wave Energy |
|--------------------------------|-------------------------|---|
|                                |                         | Comes From  |
| Output Variables:              |                         |   |
| esowm (dirNum,freqNum)         | Real                    | Directional Wave Spectrum   |
| Local Variables:               |                         |   |
| ang                            | Real                    | Temporary Wave Angle  |
| b                              | Real                    | Constant = 0.74   |
| const                          | Real                    | Variable in Pierson-Moskowitz Equation  |
| e                              | Real                    | Variable in Pierson-Moskowitz Equation  |
| enew                           | Real                    | Variable in Pierson-Moskowitz Equation  |
| gu                             | Real                    | Variable in Pierson-Moskowitz Equation  |
| hs                             | Real                    | Set to Significant Wave Height  |
| hsl                            | Real                    | Set to Significant Wave Height  |
| idir                           | Integer                 | Direction Loop Counter  |
| ifrq                           | Integer                 | Frequency Loop Counter  |
| ipm                            | Integer                 | Set to 1  |
| ratio                          | Real                    | Set to 1.0  |
| sprd                           | Real                    | Directional Spreading Factor  |
| sum1                           | Real                    | Temporary Wave Energy Variable  |
| sum2                           | Real                    | Temporary Wave Energy Variable  |
| temp                           | Real                    | Variable in Pierson-Moskowitz Equation  |
| theta                          | Real                    | Wave Angle  |
| val1                           | Real                    | Variable in Pierson-Moskowitz Equation  |
| val2                           | Real                    | Variable in Pierson-Moskowitz Equation  |
| w1                             | Real                    | Wave Frequency at Beginning of Bin  |

Subroutines Called from SEAFIT ( ):

w2

Real

None.

Wave Frequency at End of Bin

SEAFIT () Called from Subroutines:

#### WAVEFIT

# Figure 52. Subroutine SEAFIT Flowchart



#### 5.52 Subroutine SETUP

#### **Subroutine Call:**

SETUP (pkfreq, d1, d2, hrms1, hrms2, eta1, kinit1, eta2)

#### **Summary:**

Subroutine SETUP calculates the change in the nearshore mean water level caused by the onshore flux of momentum or the shore-directed Radiation Stress. The presence of waves causes a change in the total water depth, which is defined by the still water level plus the wave-induced set-up. **Input Variables:** 

| d1 ·                     | Real    | Corresponding Depth                          |
|--------------------------|---------|--|
| d2                       | Real    | Next Corresponding Depth                     |
| eta1                     | Real    | Wave Induced Setup at Present Location       |
| hrms1                    | Real    | Root Mean Square Wave Height                 |
| hrms2                    | Real    | Wave Height at next Onshore Grid Location    |
| kinitl                   | Real    | Wave Number                                  |
| pkfreg                   | Real    | Peak Frequency at the Center of the          |
| <b>1</b> . <b>1</b>      |         | Frequency Band                               |
| <b>Output Variables:</b> |         |  |
| eta2                     | Real    | Wave Induced Setup at New Location           |
| Local Variables:         |         |  |
| avg depth                | Real    | Averaged Depth                               |
| convrg                   | Logical | Set to False                                 |
| el                       | Real    | Total Average Energy for Offshore Wave       |
| e2                       | Real    | Total Average Energy for Wave Shoaled and    |
|                          |         | Refracted Toward the Shore                   |
| en1                      | Real    | Linear Wave Theory Ratio of Group            |
|                          |         | Velocity to Wave Celerity                    |
| en2                      | Real    | Linear Wave Theory Ratio of Group            |
|                          |         | Velocity to Wave Celerity                    |
| eta new                  | Real    | Wave Induced Setup Estimated at              |
| _                        |         | New Location                                 |
| i                        | Integer | Counter                                      |
| <b>k</b> 1               | Real    | First Wave Number Estimate                   |
| k2                       | Real    | Second Wave Number Estimate                  |
| percent_diff             | Real    | Convergence Check                            |
| sxx1                     | Real    | <b>Cross-Shore Directed Radiation Stress</b> |
| sxx2                     | Real    | <b>Cross-Shore Directed Radiation Stress</b> |
| tol                      | Real    | Convergence Tolerance                        |

### Subroutines Called from SETUP (): WAVENUM

### **SETUP ( ) Called from Subroutines:**

#### MAIN\_WAV





#### 5.53 Subroutine SHORTOUT

#### Subroutine Call:

SHORTOUT (wdir, wspd, j, iimax, dxy, xtemp, sum1, k, h1max, h2max, per, pct, theta1, vmax, vmin, width, igamma, b1, rk, htemp, wid\_ii, jgamma, alfa, bravo, chrlie, echo, foxtrt, golf1, golf2, ihtl1, ihtl2)

#### **Summary:**

Subroutine SHORTOUT defines the forecasting output variables.

### **Input Variables:**

| b1 (points)    | Real    | Bottom Slope Array   |
|----------------|---------|--|
| dxy (points)   | Real    | Corresponding Depths with Tide   |
| h1max          | Real    | Largest Significant Wave Height in the Surf Zone                           |
| h2max          | Real    | Largest Maximum Wave Height in the Surf Zone                               |
| htemp (points) | Real    | Temporary Variable for Significant Wave<br>Height Values                   |
| igamma         | Integer | Beach Orientation Rotated 90 Degrees from<br>Original Heading Toward Beach |
| iimax          | Integer | Number of Calculation Locations  |
| i              | Integer | Pre-tidal Depth or Still Water Level                                       |
| k              | Integer | Temporary Variable for Significant<br>Wave Height                          |
| pct(4)         | Real    | Percentage Breaker Array   |
| per            | Real    | Peak Period of Directional Wave Spectrum                                   |
| rk (points, 4) | Real    | Matrix of Percentage Breakers and  |
|                |         | Type of Breakers   |
| sum1           | Real    | Sum of Wave Length in the Surf Zone  |
| thetal         | Real    | Wave Angle at Input Starting Depth   |
| vmax           | Real    | Maximum Positive Longshore   |
|                |         | Current velocity   |
| vmin           | Real    | Maximum Negative Longsnore   |
|                |         | Current Velocity   |
| wdir           | Real    | Input Wind Direction - Compass Heading                                     |
|                | _       | Wind is Blowing From   |
| wid_ii         | Integer | Surf Zone Width Array Index  |
| width          | Real    | Surf Zone Width  |
| wspd           | Real    | Input Wind Speed   |
| xtemp (points) | Real    | Temporary Variable for Cross-Shore Values                                  |

### **Output Variables:**

| alfa   | Real    | Significant Breaker Height            |
|--------|---------|---------------------------------------|
| bravo  | Real    | Maximum Breaker Height                |
| chrlie | Real    | Dominant Breaker Period               |
| echo   | Real    | Breaker Angle                         |
| foxtrt | Real    | Longshore Current Speed and Direction |
| golf1  | Real    | Number of Surf Lines                  |
| golf2  | Real    | Surf Zone Width                       |
| ihtl1  | Real    | Wind Speed                            |
| ihtl2  | Real    | Wind Direction                        |
| jgamma | Integer | Temporary Variable Set to             |
|        | _       | Beach Orientation                     |

## Local Variables:

• •

| 11    | Integer | Temporary Array   |
|-------|---------|---|
| i2    | Integer | Temporary Array   |
| temp1 | Real    | Temporary Variable for Longshore Current                        |
| temp2 | Real    | Maximum Calculation<br>Temporary Variable for Longshore Current |
| xlen  | Real    | Minimum Calculation<br>Average Wave Length in Surf Zone         |

# Subroutines Called from SHORTOUT():

NEW\_BRK

# SHORTOUT () Called from Subroutines:

### CALCSURF





### 5.54 Subroutine SLF\_STRT

### **Subroutine Call:**

SLF\_STRT (theta, xdelt\_gr, hrms, per, fqz, fqd, xx1, dxy, nnn, cg, hrms, xk, j\_ii, 10, theta0, surf)

#### **Summary:**

Subroutine SLF\_STRT shoals and refracts waves from the farthest offshore point to the shoreward point where the percentage of breaking exceeds the surf zone criteria of five percent (5%). If the five percent (5%) threshold is not exceeded, execution halts.

### **Input Variables:**

| D                 | Real    | Empirical Factor in Wave Breaking Model  |
|-------------------|---------|--|
| Cg                | Real    | Wave Group Velocity                      |
| dxy (points)      | Real    | Corresponding Depths with Tide           |
| fqd               | Real    | Peak Frequency at the Center of the      |
|                   |         | Frequency Band                           |
| fqz               | Real    | Zero Crossing Frequency                  |
| hrms              | Real    | Root Mean Square Wave Height             |
| nnn               | Integer | Number of Points in Input Depth Array    |
| per               | Real    | Peak Period of Directional Wave Spectrum |
| self_st           | Char*1  | Self Staring Option (Yes or No)          |
| theta             | Real    | Radiation Stress Angle                   |
| xdelt_gr          | Real    | Self-Adjusting Cross-Shore Grid Step     |
| xk                | Real    | Wave Number                              |
| Output Variables: |         |  |
| Cg                | Real    | Wave Group Velocity                      |
| hrms              | Real    | Root Mean Square Wave Height             |
| j_ii              | Integer | Index where Wave Probabilities           |
|                   | U       | Exceed Threshold                         |
| 10                | Real    | Wave Length Offshore Location            |
| surf              | Logical | Index Where Percentage of Breakers In    |
|                   | C       | Exceeded - Start of Surf Zone            |
| theta0            | Real    | Wave Angle at Grid Offshore Location     |
| xk                | Real    | Wave Number                              |
|                   |         |  |

### Local Variables:

| beta   | Real    | Bottom Slope                              |
|--------|---------|---|
| cg2    | Real    | Group Velocity                            |
| convg  | Real    | Convergence Flag (True or False)          |
| dp     | Real    | Offshore Water Depth                      |
| eb     | Real    | Dissipation Term                          |
| hrms2  | Real    | Root Mean Square Wave Height              |
| ii     | Integer | Array Index                               |
| 1      | Real    | Wave Length                               |
| p (4)  | Real    | Breaker Percentage Array                  |
| rhs    | Real    | <b>Right Hand Side of Energy Equation</b> |
| roller | Logical | Roller Option Flag (True or False)        |
| rstart | Real    | Percent Breaking Wave Criteria            |
| xk0    | Real    | Offshore Wave Number                      |

### Subroutines Called from SLF\_STRT ( ):

BALANCEQ GET\_RHS PERCENT PT2

### SLF\_STRT ( ) Called from Subroutines:

MAIN\_WAV



Figure 55. Subroutine SLF\_STRT Flowchart

#### 5.55 Subroutine SRFSETUP

#### **Subroutine Call:**

SRFSETUP (file\_in, file\_out, fracname, Indname, depname, iyear, imonth, iday, ihour, imin, gamma2, ydepth, slope, ydetail, xdelt, yrefrac, ystr, self\_st, hsea, psea, dsea, hswell, pswell, dswell, wspd, wdir, tide, spefile, file\_dat, file\_tmp, spedepth, file\_spc, spe\_type)

#### **Summary:**

Subroutine SRFSETUP opens input and output files. Input variables are initialized using data

from user-constructed input file. The format of the input file is outlined in Section 6.0.

Input Variables:

None.

#### **Output Variables:**

| depname  | Char*40 | Depth Profile File Name                      |
|----------|---------|--|
| dsea     | Real    | Input Direction for Sea Contribution         |
| dstart   | Real    | Input Starting Depth                         |
| dswell   | Real    | Input Swell Direction for Internally         |
|          | •       | Generated Spectrum                           |
| file_in  | Char*40 | Input File Name                              |
| file_out | Char*40 | Output File Name                             |
| file_dat | Char*40 | Output File Name                             |
| file_spc | Char*40 | Shallow Water Wave Spectrum File Name        |
| file_tmp | Char*40 | Output File Name                             |
| fracname | Char*40 | Wave Refraction File Name                    |
| gamma2   | Real    | Beach Orientation, Compass Heading           |
|          |         | Directly Toward Beach                        |
| gt_frg   | Integer | Spectrum Type                                |
| hsea     | Real    | Input Significant Wave Height for Sea        |
|          |         | Contribution to Pierson Moskowitz Spectrum   |
| hswell   | Real    | Input Significant Wave Height for Internally |
|          |         | Generated Spectrum                           |
| idav     | Integer | Input Day                                    |
| ihour    | Integer | Input Hour                                   |
| imin     | Integer | Input Minute                                 |
| imonth   | Integer | Input Month                                  |
| ivear    | Integer | Input Year                                   |
| Indname  | Char*40 | Input Landing Zone Name                      |
| Dsea     | Real    | Input Wave Period for Sea Contribution to    |
| *        |         | Internally Generated Spectrum                |
| pswell   | Real    | Input Swell Period for Internally            |
| •        |         | Generated Spectrum                           |
| self_st  | Char*1  | Self Start Flag (Yes or No)                    |
|----------|---------|--|
| slope    | Real    | Bottom Slope                                   |
| spedepth | Real    | Depth at Offshore Wave Spectrum                |
| spefile  | Char*40 | Selected Wave Spectrum File Name               |
| spe_type | Integer | 0 if specifie is not blank 1 for blank         |
| tide     | Real    | Input Tide Level                               |
| wdir     | Real    | Input Wind Direction, Compass Heading          |
|          |         | Wind Blows From                                |
| wspd     | Real    | Input Wind Speed                               |
| xdelt    | Real    | Surf Zone Output Interval                      |
| ydepth   | Char*1  | Input Depth Profile Used? (Yes or No)          |
| ydetail  | Char*1  | Detailed Output? (Yes or No)                   |
| yrefrac  | Char*1  | Is Refraction Considered in Analysis?          |
|          |         | (Yes or No)                                    |
| ystr     | Char*1  | Is Straight Coast Refraction Used? (Yes or No) |

## Local Variables:

.

| dumi     | Char*80 | Title Line                         |
|----------|---------|------------------------------------|
| fend     | Integer | File Name Prefix Used for Building |
|          |         | File Names                         |
| file_dat | Char*20 | Additional Output File Name        |
| i        | Integer | Loop Counter                       |
| iopen    | Integer | I/O Status Number                  |
| j        | Integer | Loop Counter                       |

# Subroutines Called from SRFSETUP ():

### ABORT

SRFSETUP () Called from Subroutines:

SURF





## 5.56 Subroutine STRFRAC

#### **Subroutine Call:**

STRFRAC (dstart, ifreq, freq, igamma, idirec, xfrom, spedepth, xcoeff, xtheta)

### **Summary:**

Subroutine STRFRAC calculates wave angle refraction coefficients and combined shoaling and refraction coefficients to propagate wave energy into shallow water.

#### **Input Variables:**

| dstart                   | Real    | Input Starting Depth                       |
|--------------------------|---------|--|
| freq (freqNum)           | Real    | Input Wave Spectrum Center Frequencies     |
| idirec                   | Integer | Number of Direction Bins in Input Spectrum |
| ifreq                    | Integer | Number of Frequency Bins in                |
|                          | •       | Input Spectrum                             |
| igamma                   | Integer | Beach Orientation Rotated 90 Degrees from  |
|                          |         | Original Heading Toward Beach              |
| xfrom (dirNum)           | Real    | Direction Array                            |
| Output Variables:        |         |  |
| xcoeff (dirNum, freqNum) | Real    | Wave Height Refraction Coefficients        |
| xtheta (dirNum, freqNum) | Real    | Wave Angle Refraction Coefficients         |
| Local Variables:         |         |  |
| arg1                     | Real    | Shallow Water Angle (1) - Temporary        |
| direc                    | Real    | Temporary Direction Angle                  |
| frd                      | Real    | Wave Frequency                             |
| idir                     | Integer | Direction Loop Counter                     |
| ifrq                     | Integer | Frequency Loop Counter                     |
| m                        | Integer | Temporary Wave Angle                       |
| noprint                  | Real    | Wave Component Direction                   |
| shoal                    | Real    | Temporary Shoaling Coefficient             |
| shoal2                   | Real    | Temporary Shoaling Coefficient at Input    |
|                          |         | Starting Depth                             |
| thetad                   | Real    | Temporary Wave Angle Variable              |
| thetas2                  | Real    | Temporary Wave Angle Variable              |
| xkd                      | Real    | Temporary Wave Number Variable             |
| xk2                      | Real    | Temporary Wave Number Variable             |

xks2

Real

Temporary Wave Number at Input Starting Depth Wave Number at Input Starting Depth

xksd2

Real

Subroutines Called from STRFRAC ( ):

WAVENUM

**STRFRAC ( ) Called from Subroutines:** 

SURF





#### 5.57 Subroutine SUMMARY

### **Subroutine Call:**

SUMMARY (spedepth, dstart, tide, wspd, wdir, xdelt, yrefrac, ystr, depname, file\_out, fracname, Indname, ydepth, ydetail, gamma2, slope, hsea, psea, dsea, hswell, pswell, dswell, spectra, spefile, spe\_type, file\_tmp)

#### **Summary:**

Subroutine SUMMARY summarizes the input information read to the output file for documentation and forecaster verification. Input Variables:

| depname  | Char*40 | Depth Profile File Name                       |
|----------|---------|---|
| dsea     | Real    | Input Direction for Sea Contribution          |
| dstart   | Real    | Input Starting Depth                          |
| dswell   | Real    | Input Swell Direction for Internally          |
|          |         | Generated Spectrum                            |
| file out | Char*40 | Output File Name *.out                        |
| file_tmp | Char*40 | Tempary Output File Name *.tmp                |
| fracname | Char*40 | Wave Refraction File Name                     |
| gamma2   | Real    | Beach Orientation, Compass Heading Directly   |
| 5        |         | Toward Beach                                  |
| hsea     | Real    | Input Significant Wave Height for Sea         |
|          |         | Contribution to Internally Generated Spectrum |
| hswell   | Real    | Input Significant Wave Height to Internally   |
|          |         | Generated Spectrum                            |
| Indname  | Char*40 | Input Landing Zone Name                       |
| psea     | Real    | Input Wave Period for Sea Contribution to     |
| 1        |         | Internally Generated Spectrum                 |
| pswell   | Real    | Input Swell Period for Internally             |
|          |         | Generated Spectrum                            |
| slope    | Real    | Bottom Slope for a Constructed Depth Profile  |
| spectra  | Logical | Does Input Spectrum Exist? (True or False)    |
| spedepth | Real    | Wave Input Depth                              |
| spefile  | Char*40 | Selected Wave Spectrum File Name              |
| spe type | Integer | 0 if spefile is not blank, 1 for blank        |
| tide     | Real    | Input Tide Level                              |
| wdir     | Real    | Input Wind Direction Compass Heading Wind     |
|          |         | Blows From                                    |
| wspd     | Real    | Input Wind Speed                              |
| xdelt    | Real    | Surf Zone Output Interval                     |
| vdepth   | Char*1  | Input Depth Profile Used? (Yes or No)         |
| vdetail  | Char*1  | Detailed Output? (Yes or No)                  |
| vrefrac  | Char*1  | Is Refraction Considered in Analysis?         |
| J        |         | -   |

145 :

## Char\*1

None.

(Yes or No) Is Straight Coast Refraction Used? (Yes or No)

**Output Variables:** 

Local Variables:

sediment

ystr

Char\*40

Sediment Type

Subroutines Called from SUMMARY ():

None.

# SUMMARY () Called from Subroutines:

SURF

### Figure 58. Subroutine SUMMARY Flowchart



147 :

## 5.58 Subroutine SURFCAST

## **Subroutine Call:**

SURFCAST (pct, depname, Indname, slope, ydepth, alfa, bravo, chrlie, echo, foxtrt, golf1, golf2, ihtl1, ihtl2)

## Summary:

Subroutine SURFCAST reads input variables and provides a short format summary of Navy specified parameters. The subroutine also examines longshore current direction and selects the dominant breaker type.

#### **Input Variables:**

| alfa              | Real    | Significant Breaker Height              |
|-------------------|---------|---|
| bravo             | Real    | Maximum Breaker Height                  |
| chrlie            | Real    | Dominant Breaker Period                 |
| depname           | Char*40 | Depth Profile File Name                 |
| echo              | Real    | Breaker Angle                           |
| foxtrt            | Real    | Longshore Current Speed and Direction   |
| golf1             | Real    | Number of Surf Lines                    |
| golf2             | Real    | Surf Zone Width                         |
| ihtl1             | Real    | Wind Speed Coded Surf Forecast Value    |
| ihtl2             | Real    | Wind Direction                          |
| Indname           | Char*40 | Input Landing Zone Name                 |
| pct (4)           | Real    | Percent of Different Breaker Types      |
|                   |         | pct(1) = Spilling                       |
|                   |         | pct(2) = Plunging                       |
|                   |         | pct(3) = Surging                        |
| _                 |         | pct(4) = Total                          |
| slope             | Real    | Bottom Slope                            |
| ydepth            | Char*1  | Input Depth Profile Used? (Yes or No)   |
| Output Variables: | None.   |   |
| Local Variables:  |         |   |
| foxtmp            | Paal    |   |
|                   | Real    | the Direction                           |
| i                 | Integer | Loop Counter Variable                   |
| jdelt             | Integer | Difference If Any Between 100% and      |
|                   |         | Sum of jp (4)                           |
| jp (4)            | Integer | Temporary Variable Same as nct(4) Array |
|                   |         | 148                                     |

jsum maxp xmax Integer Integer Real Check for Percentages Adding to 100% Indicates Dominant Breaker Type Temporary Variable Used in Dominant Breaker Type Examination

### Subroutines Called from SURFCAST ():

None.

## SURFCAST ( ) Called from Subroutines:

**SURF** 





#### 5.59 Subroutine SWLFIT

#### **Subroutine Call:**

SWLFIT (hsig, per, dir, dangle, ifreq, idirec, period, esowm)

#### **Summary:**

Subroutine SWLFTT superimposes remotely generated swell wave energy onto the existing directional wave spectrum. The existing wave spectrum may be zero or it may contain locally generated sea waves already added by the subroutine SEAFIT.

#### **Input Variables:**

| dangle<br>dir          | Real<br>Real | Angle between Directional Bins<br>Input Swell Direction for Internally<br>Generated Spectrum |
|------------------------|--------------|--|
| hsig                   | Real         | Significant Wave Height  |
| idirec                 | Integer      | Number of Direction Bins in Input Spectrum   |
| ifreq                  | Integer      | Number of Frequency Bins in<br>Input Spectrum  |
| per                    | Real         | Peak Period of Directional Wave Spectrum   |
| period (freqNum)       | Real         | Period Array (1 / Frequency)   |
| Output Variables:      |              |  |
| esowm (dirNum,freqNum) | Real         | Directional Wave Spectrum  |
| Local Variables:       |              |  |
| dl                     | Real         | Temporary Variable for Distributing<br>Wave Energy   |
| d2                     | Real         | Temporary Variable for Distributing<br>Wave Energy   |
| d3                     | Real         | Temporary Variable for Distributing<br>Wave Energy   |
| delt                   | Real         | Temporary Variable for Distributing<br>Wave Energy   |
| diff                   | Real         | Difference between Maximum Wave<br>Period and Array Value of Wave Period                     |
| dmin                   | Real         | Set to 1000.0  |
| energy                 | Real         | Swell Energy   |
| ifrq                   | Integer      | Frequency Loop Counter   |
| jdir                   | Integer      | Swell Direction  |
| jdir1                  | Integer      | Direction Bin Index Number   |
| jdir3                  | Integer      | Direction Bin Index Number   |

jfreq xdir

Integer Real Directional Wave Spectrum Wave Number Wave Direction

## Subroutines Called from SWLFIT ( ):

None.

## SWLFIT ( ) Called from Subroutines:

#### WAVEFIT

## Figure 60. Subroutine SWLFIT Flowchart



#### 5.60 Subroutine WAVEFIT

#### **Subroutine Call:**

WAVEFIT (ifreq, idirec, dangle, hsea, psea, dsea, hswell, pswell, dswell, freq1, freq2, xfrom, period, esowm, ehsig)

#### **Summary:**

Subroutine WAVEFIT initializes the internally generated directional wave spectrum to zero

and calls subroutines SEAFIT and SWLFIT to fill the matrix.

#### **Input Variables:**

| Real    | Angle Between Directional Bins   |
|---------|--|
| Real    | Input Direction for Sea Contribution   |
|         | to Internally Generated Wave Spectrum  |
| Real    | Input Swell Direction for Internally   |
|         | Generated Spectrum   |
| Real    | Beginning Frequency Bin Value  |
| Real    | Ending Frequency Bin Value   |
| Real    | Input Significant Wave Height for Sea  |
|         | Contribution to Internally Generated   |
|         | Wave Spectrum  |
| Real    | Input Significant Wave Height to   |
|         | Internally Generated Spectrum  |
| Integer | Number of Direction Bins in Input Spectrum   |
| Integer | Number of Frequencies in Input Spectrum  |
| Real    | Period Array (1/Frequency)   |
| Real    | Input Wave Period for Sea Contribution   |
| Real    | Input Swell Period for Internally  |
| н.<br>С | Generated Spectrum   |
| Real    | Direction Array, Direction Wave Energy   |
|         | Comes From   |
| Real    | Direction Array, Direction Wave Energy<br>Comes From   |
|         | Real<br>Real<br>Real<br>Real<br>Real<br>Real<br>Real<br>Integer<br>Integer<br>Real<br>Real<br>Real<br>Real<br>Real<br>Real |

#### **Output Variables:**

| ehsig                  | Real | Significant Wave Height from |
|------------------------|------|------------------------------|
| 0                      |      | Directional Spectrum         |
| esowm (dirNum,freqNum) | Real | Directional Wave Spectrum    |

## Local Variables:

idir ifrq Integer Integer Direction Loop Counter Frequency Loop Counter

# Subroutines Called from WAVEFIT ():

GT\_SIG\_H SEAFIT SWLFTT

# WAVEFIT () Called from Subroutines:

GENSPEC

# Figure 61. Subroutine WAVEFIT Flowchart



#### 5.61 Subroutine WAVENUM

#### **Subroutine Call:**

WAVENUM (fq, dp, xk)

#### **Summary:**

The wave dispersion equation is solved for the wave number through numerical iteration. A relative change of less than .0005 is required and the maximum number of iterations is 150. If convergence is not obtained within 150 iterations, a shallow water approximation is employed.

#### **Input Variables:**

| Offshore Water Depth                                |
|---|
| Wave Frequency                                      |
|   |
| Wave Number   |
|   |
| Shallow Water Criteria Constant                     |
| Percent Difference between Wave<br>Number Estimates |
| Estimate of Wave Number                             |
| Loop Counter  |
| Loop Limit - Set to 150                             |
|   |

Subroutines Called from WAVENUM ( ):

None.

#### WAVENUM () Called from Subroutines:

INITLIZE PT2 RAD\_ST1 RAD\_ST2 SETUP STRFRAC





#### 5.62 Subroutine WEIGHTFN

### Subroutine Call:

WEIGHTFN (dp, hrms, h, w\_h)

#### **Summary:**

Subroutine WEIGHTFN calculates the weighting function used to describe the distribution of

breaking waves across the surf zone.

#### **Input Variables:**

| dp   | Real |  |
|------|------|--|
| h    | Real |  |
| hrms | Real |  |

Offshore Water Depth Wave Height Root Mean Square Wave Height

### **Output Variables:**

| w_h |  |
|-----|--|
|-----|--|

**Output Weighting Function** 

#### Local Variables:

| m    | Real | Multiplier         |
|------|------|--------------------|
| temp | Real | Weighting Function |
| tol  | Real | Set to -700.0      |

Real

#### Subroutines Called from WEIGHTFN ():

GET\_M

#### WEIGHTFN () Called from Subroutines:

F2





#### 5.63 Subroutine ZONE1

#### **Subroutine Call:**

ZONE1 (j\_ii, iimax, dxy, xtemp, htemp, ptemp, thetatemp, xktemp, v, distmax, vmax, vmin, thetamin, thetamax, sum1, width, j, k, h1max, h2max, wid\_ii)

#### **Summary:**

Subroutine ZONE1 calculates the preliminary surf forecast values and surf zone parameters.

#### **Input Variables:**

| distmax           | Real    | Farthest Distance Offshore                               |  |  |
|-------------------|---------|--|--|--|
| dxy (points)      | Real    | Pre-Tidal Depth or Still Water Level                     |  |  |
| htemp (points)    | Real    | Temporary Variable for Significant Wave<br>Height Values |  |  |
| iimax             | Integer | Number of Calculation Locations                          |  |  |
| i ii              | Integer | Index where Wave Probabilities                           |  |  |
| <b>9</b> –        | Ũ       | Exceed Threshold   |  |  |
| ptemp (points)    | Real    | Percentage of Breaking Waves and                         |  |  |
|                   |         | Breaker Types  |  |  |
| v (points)        | Real    | Longshore Current  |  |  |
| xktemp (points)   | Real    | Temporary Variable for Wave Number                       |  |  |
| xtemp (points)    | Real    | Temporary Variable for Cross-Shore Values                |  |  |
| Output Variables: |         |  |  |  |
| h1max             | Real    | Maximum Significant Wave Height                          |  |  |
| h2max             | Real    | Maximum Wave Height                                      |  |  |
| j                 | Integer | Array Index Where Maximum Significant                    |  |  |
|                   | •       | Wave Height Occurs                                       |  |  |
| k                 | Integer | Temporary Variable Number of Points in                   |  |  |
|                   | -       | Cross-Shore Transect                                     |  |  |
| suml              | Real    | Summation of Wave Lengths Across the                     |  |  |
|                   |         | Surf Zone  |  |  |
| vmax              | Real    | Maximum Positive Longshore Current                       |  |  |
|                   |         | Velocity   |  |  |
| vmin              | Real    | Maximum Negative Longshore                               |  |  |
|                   |         | Current Velocity   |  |  |
| wid_ii            | Integer | Array Index for X-value at Surf                          |  |  |
|                   | 2       | Zone Boundary  |  |  |
| width             | Real    | Surf Zone Width  |  |  |
|                   |         |  |  |  |

### Local Variables:

| dp1   | Real    | Offshore Depth in Feet              |
|-------|---------|-------------------------------------|
| hdep  | Real    | Limiting Breaking Depth             |
| hmax  | Real    | Temporary Variable for              |
|       |         | Maximum Wave Height                 |
| hout1 | Real    | Temporary Variable for Significant  |
|       |         | Wave Height                         |
| hrms1 | Real    | Root Mean Square Wave Height        |
| ii    | Integer | Loop Index                          |
| ving1 | Real    | Longshore Current Velocity in Knots |
| wlen  | Real    | Wave Length                         |
| xoff1 | Real    | Distance Offshore                   |
|       |         |                                     |

# Subroutines Called from ZONE1 ():

None.

## ZONE1 () Called from Subroutines:

CALCSURF





### 5.64 Function F2

## **Function Call:**

F2 (h, hrms, dp, p\_flag)

## Summary:

Function F2 evaluates the Rayleigh probability distribution function for a given wave height value, for a selected weighting function.

## **Input Variables:**

| dp<br>h<br>hrms<br>p_flag | Real<br>Real<br>Real<br>Logical | Offshore Water Depth<br>Wave Height<br>Root Mean Square Wave Height<br>Weighting Factor Flag (True or False)                       |  |
|---------------------------|---------------------------------|--|--|
| Output Variables:         |                                 |  |  |
| ť2                        | Real                            | Weighted Rayleigh Distribution   |  |
| Local Variables:          |                                 |  |  |
| p_h<br>temp<br>tol<br>w_h | Real<br>Real<br>Real<br>Real    | Rayleigh Probability Distribution<br>Exponent Term in Rayleigh Distribution<br>Tolerance Value Set to -700.0<br>Weighting Function |  |

Subroutines Called from F2 ():

WEIGHTFN

F2 ( ) Called from Functions:

**INTEGRAT** 





## 5.65 Function F3

## **Function Call:**

F3 (hrms, theta, Cg, dp, mean\_freq, xk, roller)

### **Summary:**

Function F3 returns values for the LHS of the energy equation.

## **Input Variables:**

| Cg                | Real           | Wave Group Velocity                        |
|-------------------|----------------|--|
| dp                | Real           | Offshore Water Depth                       |
| hrms              | Real           | Root Mean Square Wave Height               |
| mean_freq         | Real           | Directional Spectrum Value                 |
| roller            | Logical        | Roller Option Flag (True or False)         |
| theta             | Real           | Wave Angle                                 |
| xk                | Real           | Wave Number                                |
| Output Variables  | :              |  |
| ß                 | Real           | Total Energy                               |
| Local Variables:  |                |  |
| e_roller          | Real           | Roller Contribution to the Energy Equation |
| e_wave            | Real           | Wave Contribution to the Energy Equation   |
| Subroutines Calle | d from F3 ( ): |  |
|                   |                |  |

CALCROLL GET\_WAVE

F3 ( ) Called from Subroutines:

BALANCEQ





## 5.66 Function INTEGRAT

#### **Function Call:**

INTEGRAT (xo, xn, hrms, dp, p\_flag)

## Summary:

Function INTEGRAT evaluates an integral numerically using the trapezoidal rule. Function  $\{F2\}$  is called to evaluate the integral at upper and lower limits. The function applies the trapezoidal integration method to estimate the wave height at a particular depth from a weighted distribution.

#### **Input Variables:**

| dp<br>hrms<br>p_flag<br>xn<br>xo | Real<br>Real<br>Logical<br>Real<br>Real | Farthest Offshore Water Depth<br>Root Mean Square Wave Height<br>Weighting Factor Flag (True or False)<br>Upper Limit of Integration = 5 * hrms<br>Lower Limit of Integration = 0.0 |
|----------------------------------|---|---|
| <b>Output Variables:</b>         |   |   |
| integrat                         | Real                                    | Wave Height Distribution Calculated for a Specific Location   |
| Local Variables:                 |   |   |
| delt                             | Real                                    | Step Between Intervals  |
| f_xn                             | Real                                    | f(x) Evaluated at Upper Limit   |
| f_xo                             | Real                                    | f(x) Evaluated at Lower Limit   |
| f2                               | Real                                    | Wave Height Distribution  |
|                                  |   | Weighting Function  |
| i                                | Integer                                 | Loop Variable   |
| numit                            | Integer                                 | Set to 100 - Number of Iterations Examined  |
| 011 <b>0</b> 0                   | <b>D</b> 1                              | Over Integral   |
| -:                               | Keal                                    | Summary Results from Function F2  |
| XI                               | Keal                                    | Integration Step Location   |

# Functions Called from INTEGRAT ():

F2

## **INTEGRAT () Called from Subroutines:**

#### CALC\_HB3 PERCENT

## Figure 67. Function INTEGRAT Flowchart



167

# 5.67 Include File: COMMON.INC

### **Summary:**

The include file COMMON.INC contains all the parameters set for the SURF Model.g

٠.

## **Defined Parameters:**

| dcal      | Real    | 0.3048 - Feet to Meters Conversion          |
|-----------|---------|---|
| degrad    | Real    | PI / 180.0 - Conversion from                |
|           |         | Degrees to Radians                          |
| dirNum    | Integer | 180 - Array Dimension Used for              |
|           |         | Direction Arrays                            |
| freqNum   | Integer | 50 - Array Dimension Used for               |
|           |         | Frequency Arrays                            |
| g         | Real    | 9.8   |
| gamma     | Real    | 0.42 - Empirical Wave Height Factor         |
| iunit     | Integer | Output File Unit                            |
| pi        | Real    | 3.14159265                                  |
| points    | Integer | 500 - Array Dimension Used for all Input    |
|           |         | Depth Arrays                                |
| raddeg    | Real    | 180.0 / pi - Conversion from                |
|           |         | Radians to Degrees                          |
| rho       | Integer | 1030 - Water Density                        |
| rhoair    | Real    | 1.2 - Air Density                           |
| sigma     | Real    | sigma_deg * degrad                          |
| sigma-deg | Real    | 5.0 - Angle in Degrees between Wave and     |
|           |         | Roller in the Thornton/Lippman Model (1996) |
| tpi       | Real    | 2 * 3.14159265                              |
| zone_pct  | Real    | 10% Surf Zone Width Percent of Breaking     |
|           |         | Waves                                       |

#### ACKNOWLEDGEMENTS

Mr. John Murdock from Naval Oceanographic Office provided many useful suggestions to surf model developments. The MSI errors were discovered by Dr. Nathaniel Plant, Marine Geosciences Division, Naval Research Laboratory. The input wave angle improvement was prompted by questions from Dr. Daniel Conley, SACLANT Undersea Research Center, La Spezia, Italy. Mr. David McNeal, Ms. Angela Richardson, and Ms. Lauriane Winsett from Neptune Sciences, Inc. performed compiler checks and revised of the flowcharts. SURF 3.2 was funded under PE 63207N and sponsored by the Space and Naval Warfare Systems Command (SPAWAR). The program manager is Mr. Tom Piwowar.

#### **APPENDICES**

## Appendix A. INPUT AND OUTPUT DATA FORMATS

## 1. Input File Formats and model options

This section gives the formats for the files read or produced by SURF.

#### **1.1 SURF Input File**

The SURF input file contains 12 lines. Some of the lines may be blank; some are required. The format for each line of the input file is al follows:

| Line | Description     | Type    | Units | Range |
|------|-----------------|---------|-------|-------|
| 1    | Input File Name |         |       | Mange |
| -    | Input FIIE Name | Char*40 |       |       |

The entry in line 1 must be the exact name of the input file. The first character of the file name must be in column 1. The file name is limited to 40 characters.

| Line | Description              | Type    | Units | Range |
|------|--------------------------|---------|-------|-------|
| 2    | Date and Time VVVVMUDDUU |         |       | nunge |
| -    | Date and lime illimmodan | Char*10 |       |       |

Line 2 is date-time information in the form YYYYMMDDHH. SURF simply reads this line and prints it out in the output file.

| Line | Description       | Type    | Units | Range |
|------|-------------------|---------|-------|-------|
| 3    | Landing Zone Name | Char*40 |       | nunge |
|      |                   | Char 40 |       |       |

Line 3 is a description of the beach. The string in line 3 cannot be longer than 40 characters or the string will be truncated. This line can be blank, but no information to identify the beach will appear in the output file.

| Line | Description                   | Туре    | Units | Range |
|------|-------------------------------|---------|-------|-------|
| 4    | Input Depth Profile File Name | Char*40 |       |       |

Line 4 is the name of the input depth profile. The depth profile file name is limited to 40 characters.

| Line | Description   | Туре    | Units | Range |
|------|---------------|---------|-------|-------|
| 5    | Sediment Type | Integer |       | 1-10  |

Sand

An entry in line 5 must be given if no depth profile file is included in line 4. If a depth profile is specified in line 4, this line should be left as blank. Allowable entries for bottom composition are as follows

| 1 | = | Boulders     |
|---|---|--------------|
| 2 | = | Cobble       |
| 3 | = | Pebbles      |
| 4 | = | Granules     |
| 5 | = | Very Coarse  |
| ^ |   | <b>0 1 1</b> |

- 6 = Coarse Sand 7 = Medium Sand
- 170

8 = Fine Sand 9 = Very Fine Sand 10 = Silt

| Line | Description                   | Туре | Units   | Range |
|------|-------------------------------|------|---------|-------|
| 6    | Compass Heading Towards Beach | Real | Degrees | 0-359 |

The compass heading toward the beach is the direction from sea to beach, perpendicular to the beach. Some examples of beach orientation are shown in Fig. 1, part (a).

| Line | Description      | Туре | Units | Range |
|------|------------------|------|-------|-------|
| 7    | Wave Input Depth | Real | Feet  | > 0   |

Line 7 is the depth in feet at the location of the input waves. The input waves can be in two formats:

- (1) a directional wave spectrum from a file given in line 8. Straight coast refraction will be applied if the depth is deeper than available depth profile. If line 9 (wave refraction file) is not blank, this depth corresponds to the output depth where transformation coefficients are applied to offshore input wave. Further illustration is included in the section 1.5.
- (2) sea and swell parameters in line 10, which are used to generate a synthetic directional wave spectrum within SURF;

| Line | Description                   | Туре    | Units | Range |
|------|-------------------------------|---------|-------|-------|
| 8    | Input Wave Spectrum File Name | Char*40 |       |       |

Line 8 is the name of the optional input directional wave spectrum file. If a file is entered here then any wave input information line 10 is ignored during SURF execution.

| Line | Description                     | Туре    | Units | Range |
|------|---------------------------------|---------|-------|-------|
| 9    | Input Wave Refraction File Name | Char*40 |       |       |

Line 9 is the name of the input refraction and shoaling file. It should be noted that the depth at the offshore boundary of the wave refraction computation domain should be the same as offshore wave spectrum input depth. A wave spectrum from line 8 or wave input from line 10 will be modified by the refraction angles and shoaling coefficients in this file. If this line is blank, then simple refraction and shoaling based on a straight coast assumption, i.e. parallel bottom contours, will be applied.

| Line | Description          | Туре | Units   | Range           |
|------|----------------------|------|---------|-----------------|
| 10   | Sea Wave Height      | Real | Feet    | > 0             |
|      | Sea Wave Period      | Real | Seconds | <b>, 1 - 30</b> |
|      | Sea Wave Direction   | Real | Degrees | 0 - 359         |
|      | Swell Wave Height    | Real | Feet    | > 0             |
|      | Swell Wave Period    | Real | Seconds | 1 - 30          |
|      | Swell Wave Direction | Real | Degrees | 0 - 359         |

Wave direction is the direction from which waves come in degrees from North. Some examples of wave direction are shown in Fig. 1, part (b). If no directional wave spectrum file is given in line 8 then the model will produce a directional wave spectrum based on the sea and swell parameters given in this line. If a refraction-shoaling file is included then the internally generated spectrum will be refracted and shoaled to the depth in line 7.

| Line | Description    | Туре | Units   | Range   |
|------|----------------|------|---------|---------|
| 11   | Wind Speed     | Real | Knots   | > 0     |
|      | Wind Direction | Real | Degrees | 0 - 359 |

| Tide Elevation | Real  | Feet | + or - |
|----------------|-------|------|--------|
|                | ACCUL | reel | + 01 - |

Line 11 gives wind and tide information. Wind direction is the direction from which wind comes in degrees from North.

| Line | Description         | Туре | Units   | Pango    |
|------|---------------------|------|---------|----------|
| 12   | Output Grid Spaging |      | 0112.00 | Kange    |
| 10   | oucput Grid spacing | Real | Feet    | see note |

An entry must be made in line 12. If line 12 is negative then a short output will be produced. Note: the range of intervals is limited by array sizes and by the surf zone width computed by the model. Error messages will warn the user if the intervals are too small, say less than 2 ft, or too large.



(b) Wave Direction Definition Directions are those from which waves come in degrees relative to North.

Fig. 1 Beach orientation and wave direction definitions.

#### **1.2 Depth File**

| Line        | <b>Description</b>  | <b>Type</b>        | Range                        |
|-------------|---|--------------------|------------------------------|
| 1           | Title   | Char*80            |                              |
| Line 1 is a | simple alphanumeric identifier. The inf   | ormation in this l | ine is not used in SURF.     |
| Line        | <b>Description</b>  | <b>Type</b>        | <b>Range</b>                 |
| 2           | Units for Distance Offshore   | Integer            | 1,2 or 3                     |
| Line 2 ide  | ntifies the units of offshore distances ass<br>1 - Distances in Feet<br>2 - Distances in Meters<br>3 - Distances in Yards | sociated with the  | entries in line 4 and after. |
| Line        | <b>Description</b>  | <b>Type</b>        | Range                        |
| 3           | Units for Depth   | Integer            | 1,2 or 3                     |
| Line 3 ide  | ntifies the units of the depths associated<br>1 - Depths in Feet<br>2 - Depths in Meters<br>3 - Depths in Fathoms         | with the entries i | n line 4 and after.          |
| Line        | Description   | <b>Type</b>        | <b>Range</b>                 |
| 4+          | Index number  | Integer            | 1 - 500                      |

The depth profile is contained in lines 4 and after. The distance coordinate is zero at the water's edge and increases offshore. The depths associated with each distance are positive down. See Appendix B for a sample input depth profile file.

Real

Real

- -

#### **1.3 Directional Wave Spectrum File**

Distance offshore

Depth positive down

The input directional wave spectrum file contains nine preliminary lines of information followed by blocks of data, where each block is associated with a frequency band. The elements of each block are values of spectral energy density in units of meters-squared per hertz per radian.

Lines 1-3 identify the time and location of the spectrum. This information is not used by the model in calculating wave or surf parameters.

| Line | Description       | Туре    | Units   | Range      |
|------|-------------------|---------|---------|------------|
| 1    | Longitude         | Real    | Degrees | -180 - 180 |
| 2    | Latitude          | Real    | Degrees | -90 - 90   |
| 3    | Date - (YYYYMMDD) | Real    |         | ·          |
| Line | Description       | Туре    | Units   | Range      |
| 4    | Number of Angles  | Integer |         | 1 - 180    |

Line 4 gives the number of direction bins in the directional wave spectrum. The number in line 4 must equal the number of rows times the number of columns in line 5.

| Line | Description       | Туре    | Units | Range    |
|------|-------------------|---------|-------|----------|
| 5    | Number of Rows    | Integer |       | + number |
|      | Number of Columns | Integer |       | + number |

This line gives information for reading each block of spectral energy densities. Each block has the same number of elements, which is the number of rows times the number of columns. Note that the number of elements must be an even number. If the input directional wave spectrum has 24 direction bins then acceptable pairs of row-column combinations are : 24 1; 12 2; 6 4; 3 8; 8 3; 4 6; 2 12; 1 24.

| Line | Description            | Туре    | Units | Range  |
|------|------------------------|---------|-------|--------|
| 6    | Number Frequency Bands | Integer |       | 1 - 50 |

Line 6 contains the number of frequency bins in the directional wave spectrum.

| Line | Description       | Туре | Units   | Range   |  |
|------|-------------------|------|---------|---------|--|
| 7    | Initial Direction | Real | Degrees | 0 - 359 |  |

The directional bands associated with the spectrum must increase monotonically. Line 7 gives the initial direction, which will be the smallest angular value in degrees, positive clockwise from North.

| Line | Description            | Туре | Units   | Range   |
|------|------------------------|------|---------|---------|
| 8    | Width of Direction Bin | Real | Degrees | 2 - 180 |

The number of directional bands is given in line 8.

Note: the width of the direction bins in degrees times the number of direction bins must equal 360 degrees.

| Line | Description             | Туре        | Units | Range  |
|------|-------------------------|-------------|-------|--------|
| 9    | Direction of Waves      | Integer     |       | 1 or 2 |
|      | 1 - Direction waves are | coming from |       |        |
|      | 2 - Direction waves are | going to    |       |        |

Following the initial nine lines, are blocks of values of spectral energy density in units of meterssquared per hertz per radian. The first line of each block will contain the lower, center and upper frequency of the frequency band associated with that block. The block of values is a rectangular matrix of values in order from left to right being from left to right in direction in increments of the directional bandwidth given in line 8. The block of data must represent directions covering 360 degrees from the initial directional clockwise. In general, the format of each block is a follows:

| Direc | tional Wave Spectrum - Blocks | are repeated | for each               | Fremiency | Bin |
|-------|-------------------------------|--------------|------------------------|-----------|-----|
| Line  | Description                   | Туре         | Units                  | Range     | DII |
| 10    | Bin Number                    | Integer      |                        | 1 - 50    |     |
|       | Lower Limit of Frequency Bin  | Real         | hertz                  | > = 0     |     |
|       | Center of Frequency Bin       | Real         | hertz                  | > = 0     |     |
|       | Upper Limit of Frequency Bin  | Real         | hertz                  | > = 0     |     |
| 11+   | Directional Wave Spectrum     | Real         | m <sup>2</sup> /Hz/rad | l > = 0   |     |

The elements of each block of values comprising the spectral energy densities for a given frequency are in the form of a rectangular matrix of numbers of the number of rows times the number of columns, as in line 5.

#### 1.4 Input Wave Refraction and Shoaling Input File

Using the input wave refraction and shoaling input file is an advanced procedure. The refraction and shoaling files used to modify an input directional wave spectrum to a spectrum representative of conditions at the depth given in line 7 of the SURF input file.

| Line | Description                | Туре      | Units | Range |
|------|----------------------------|-----------|-------|-------|
| 1    | Header                     | Character |       |       |
| 2    | Header                     | Character |       |       |
| 3    | Input and Output<br>Depths | Real      | Feet  |       |

Lines 1-3 are strings of identifying text. The information is not used in computation. In line 3, input depth is the offshore boundary depth, and output depth corresponds to the depth where the transformation coefficients are saved, i.e. the spedepth of line 7 of surf input file.

| Line | Description            | Туре         | Units   | Range    |
|------|------------------------|--------------|---------|----------|
| 4    | Number of Angles       | Integer      |         | 1 - 180  |
| 5    | Number of Rows         | Integer      |         | + number |
|      | Number of Columns      | Integer      |         | + number |
| 6    | Number of Freq. Bins   | Integer      |         | 1 - 50   |
| 7    | Initial Direction      | Real         | Degrees | 0 - 359  |
| 8    | Width of Direction Bin | Real         | Degrees | 2 - 180  |
| 9    | Direction of Waves     | Integer      |         | 1 or 2   |
|      | 1 - Direction wav      | es are comi  | ng from |          |
|      | 2 - Direction wav      | res are goin | g to    |          |

Lines 4-9 are similar to those in the input directional wave spectrum file.

| Refrac | ction Angles - This section is | repeated for | or each frequ | ency    |
|--------|--------------------------------|--------------|---------------|---------|
| Line   | Description                    | Туре         | Units         | Range   |
| 10     | Bin Number                     | Integer      |               | 1 - 50  |
|        | Lower Limit of Frequency Bin   | Real         | Hertz         | > = 0   |
|        | Center of Frequency Bin        | Real         | Hertz         | > = 0   |
|        | Upper Limit of Frequency Bin   | Real         | Hertz         | > = 0   |
| 11+    | Refraction Angles              | Real         | Degrees       | 0 - 359 |
| End of | E Refraction Angles            |              |               |         |

The elements of each block of values comprising the refraction angles for a given frequency are in the form of a rectangular matrix with the number of rows and columns in line 5. Pad fields with zeros, if necessary.

| Line |     | Descrip | pti | lon |          |              | Туре    | Units | Range |
|------|-----|---------|-----|-----|----------|--------------|---------|-------|-------|
| Line | A+1 | Header  | 1   | for | Shoaling | Coefficients | Char*80 |       |       |
| Line | A+2 | Header  | 2   | for | Shoaling | Coefficients | Char*80 |       |       |
| Line | A+3 | Header  | 3   | for | Shoaling | Coefficients | Char*80 |       |       |

The Line A+ numbering above and below denotes information after the block of refraction angles.

| Shoal | ling Coe | efficients - Thi | s sectio | n is repeated | i for each | frequency |
|-------|----------|------------------|----------|---------------|------------|-----------|
| Line  | Descri   | iption           |          | Туре          | Units      | Range     |
| Line  | A+4      | Bin Number       |          | Integer       |            | 1 - 50    |
|       |          | Lower Limit of   | Freq Bin | Real          | Hertz      | > = 0     |
|       |          | Center of Freq   | Bin      | Real          | Hertz      | > = 0     |
|       |          | Upper Limit of   | Freq Bin | Real          | Hertz      | > = 0     |
Line A+5+ Shoaling Coefficients Real End of Shoaling Coefficients

m²/m²

-----

٩.

The elements of each block of values comprising the shoaling coefficients for a given frequency are in the form of a rectangular matrix of values with the number of rows and columns given in line 5. Pad fields with zeros, if necessary.

Note: The angles and coefficients in this file must be defined over the entire range (0, 360) degrees. A partial sector definition (e.g. 0 to 180 degrees) will cause errors. If the input data are not available over the entire range pad the refraction and direction bins with zeros.

## **1.5 Model Options**

This section gives options in SURF that control wave refraction, equilibrium profile option, and the output files.

## **Wave Refraction Options**

In general, the depth profile should cover depths to around 30 ft. If the depth of input waves is deeper than the deepest depth in the profile, i.e. outside of the profile-covered area, two options are available to consider wave refraction to bring the input waves to the edge of the area over which SURF is to operate. If no bathymetry information is available, straight coast refraction, assuming parallel bottom contours, will be used. If bathymetry information available, one can use the wave modeling option where transformation coefficients for refraction and shoaling are computed. This option is generally only used when the bathymetry is complicated.

As illustrated in Fig. 2, straight coast refraction brings the wave input to the edge of the profile-covered area starting point. It should be noted that if spedepth is inside the profile-covered area, then it becomes starting point. Then no additional wave refraction will be applied. The first output point corresponds to a location where the percent of wave breaking has reached 5%. This avoids a long listing of surf output over long stretches of flat, gently sloping bottoms.



Fig. 2 Illustration of straight coast refraction option. Straight coast refraction brings wave input to the edge of the profile-covered area, i.e. the starting point.

For the wave modeling option, wave models such as REFDIF, STWAVE and SWAN pre-compute needed transformation coefficients for a given bathymetry. Input line 9 specifies the wave refraction file. As illustrated in Fig. 3, the spedepth (input line 7) corresponds to the output depth of the refraction computation. For accuracy, it is requires that the output depth is within the profile-covered area. This is because no additional straight coast refraction will be applied if it falls outside of the profile-covered area. The output depth should not be too shallow (e.g. within the surf zone), because the transformation coefficient approach assumes that no depth induced wave breaking has occurred at the output point. It is recommended that the output depth should be around 25 to 30 ft or deeper depending on the bathymetry and wave conditions. The offshore wave input location needs to be at the same depth as the offshore boundary of the refraction file computation.



٩,



## **Equilibrium Profile Option**

The equilibrium profile, based on sediment size, is used if a depth profile is not available. In the code, its maximum depth, also the starting depth, is set to 10 m, except for the wave refraction file option in which the maximum depth corresponds to spedepth.

### Wave Spectrum Output Option

To obtain an output directional wave spectrum file, place the character "+" in front of the directional wave spectrum file name in line 9 of the basic input file. The output file will give the directional wave spectrum associated with the output point, i.e. the spedepth depth. The output spectrum file will have the same file name as the input file name but with the extension . dws.

#### Short Output

In SURF, the user can control the amount of data in the output file. If line 12 contains a zero or a negative number, a short output, without cross shore profiles of surf parameters, will be produced. The short output is similar in format to naval surf observations.

### 2. Output File Formats

#### 2.1 Basic Output File

The SURF detailed output has three output sections delineated by lines of asterisks. The first section contains input parameters describing the directional wave spectrum. The second section is the coded surf forecast with variables specific to military surf observations. The final section is the optional detailed surf output, which is comprised of a table of cross shore surf zone parameter. These parameters include cross shore distance, depth, wave height, wave breaking, wave angle and longshore current. The filename generated has the same name as the input file but the extension is .out.

#### Section 1

| Line |        | Description                              | Туре        | Units   |
|------|--------|--|-------------|---------|
| Line | 1      | Surf Forecast Header                     | Character   |         |
| Line | 2      | Blank Line                               |             |         |
| Line | 3      | SURF Model Version                       | Character   |         |
| Line | 4      | Date and Time of Forecast                | Character   |         |
| Line | 5      | Output File Name Information             | Character   |         |
| Line | 6      | Landing Zone Name                        | Character   |         |
| Line | 7      | Sight Line Toward Beach                  | Real        | Degrees |
| Line | 8      | Depth Profile Name or Beach Sediment Typ | e Character |         |
| Line | 9      | Wave Input Depth                         | Real        | Feet    |
| Line | 10     | Spectrum Usage Text<br>or                | Character   |         |
|      |        | Sea Wave Height                          | Real        | Feet    |
|      |        | Sea Period                               | Real        | Seconds |
|      |        | Sea Direction                            | Real        | Degrees |
| Line | 11     | Spectrum File Name                       | Character   |         |
|      |        | or                                       |             |         |
|      |        | Swell Wave Height                        | Real        | Feet    |
|      |        | Swell Period                             | Real        | Seconds |
|      |        | Swell Direction                          | Real        | Degrees |
| Line | 12     | Wind Speed                               | Real        | Knots   |
| Line | 13     | Wind Direction                           | Real        | Degrees |
| Line | 14     | Tide Level                               | Real        | Feet    |
| Line | 15     | Blank Line                               | Character   |         |
| Line | 16     | Wave Refraction Option                   | Character   | Line    |
| 17   | Starti | ing Depth Real                           |             | Feet    |
| Line | 18     | Output Interval                          | Real        | ' Feet  |
| Line | 19     | Computational grid Spacing               | Real        | Feet    |
| Line | 20     | Input Spectrum Type                      | Character   |         |
| Line | 21     | Significant Wave Height Offshore         | Real        | Feet    |
| Line | 22     | Wave Peak Period                         | Real        | Seconds |
| line | 23     | Average Wave Direction                   | Real        | Degrees |
| line | 24     | Percent Breaking Waves at Starting Depth | Real        | Percent |

It should be noted that starting depth on line 17 is the depth after offshore waves have brought to the edge of the profile-covered area through either straight coast refraction or refraction file computation. This depth depends on the depth profile, tide and wave input (spedepth) location.

Section 2

Line Description

Туре

Units

| Line | 1  | Code Surf Forecast         | Character |         |
|------|----|----------------------------|-----------|---------|
| Line | 2  | Significant Breaker Height | Real      |         |
| Line | 3  | Maximum Breaker Height     | Real      | reet    |
| Line | 4  | Dominant Breaker Period    | Real      | Feet    |
| Line | 5  | Dominant Breaker Type      | Character | Deconus |
| Line | 6  | Breaker Percentages        | Character | Percent |
| Line | 7  | Breaker Angle              | Real      | Degrees |
| Line | 8  | Littoral Current           | Real      | Vnote   |
| Line | 9  | Number of Surf Lines       | Real      | KIOUS   |
| Line | 10 | Surf Zone Width            | Roal      | Beet    |
| Line | 11 | Wind Speed                 | Real      | reet    |
| Line | 12 | Average wave longth        | Real      | Knots   |
| Line | 12 | Mind Dimention             | Real      | Feet    |
| Time | 13 | wind Direction             | Real      | Degrees |
| Line | 14 | Blank Line                 | Character |         |
| Line | 15 | Modified Surf Index        | Real      |         |

Section 3

| Line                                  |          | Description  | Trme   | <b>77</b> 1 4   |
|---------------------------------------|----------|--|--|-----------------|
| Line                                  | 1        | Blank Line   | The  | UNITS           |
| Line                                  | 2        | Heading - Detailed Surf Output   | Character                                      |                 |
| Line<br>Line                          | 3        | Blank Line<br>Text Heading Line  | Character                                      |                 |
| Line 5<br>Line 6<br>Line 7<br>Line 8- | 5        | <ul> <li>5 Text Heading Line</li> <li>6 Text Heading Line - Units</li> <li>7 Blank Line</li> <li>8-EOF Index Number</li> <li>Distance Offshore</li> <li>Water Depth</li> </ul> | Character<br>Character<br>Character<br>Integer |                 |
|                                       | 7        |  |  |                 |
|                                       | 8-EOF    |  |  |                 |
|                                       |          |  | Real   | Feet<br>Feet    |
|                                       |          | Significant Breaker Height<br>Maximum Breaker Height   | Real   | Feet            |
|                                       |          | Percent Breaking Waves   | Real   | Feet<br>Percent |
|                                       |          | Littoral Current   | Real<br>Real                                   | Degrees         |
|                                       | <b>*</b> |  |  | *41063          |

The first output point in line 8 in section 3 corresponds to a point where percent of wave breaking has reached 5%.

# 2.2 Data Only Output File

The data only output file contains the same information in the same format as the section 3 of the detailed model output, except the file does not contain header information. It is useful in graphic applications.

# 2.3 Shallow Water Directional Wave Spectrum

The shallow water directional wave spectrum output file is created when the first character of line 6 in the basic input file is a "+". This file has the same file name as the input file except that the file extension will be . dws. The first row contains the center frequencies of the directional wave energy spectrum. The first column defines the wave directions of the directional wave energy spectrum. The remaining matrix elements comprise the directional wave energy spectrum.

|                | Description             | Туре | Units       | Range   |
|----------------|-------------------------|------|-------------|---------|
| Row 1          | Frequency Bins          | Real | hertz       | 0 - 0.5 |
| Column 1       | Wave Direction          | Real | degrees     | 0 - 359 |
| Other elements | Spectral Energy Density | Real | m²/(Hz-rad) | 0 - 999 |

# Appendix B. Error Message Descriptions

| Error Message  | Subroutine<br>Generating<br>Error | Suggested Solution to Resolve<br>Error  |
|--|-----------------------------------|---|
| Error 115 - Opening Directional Wave<br>Spectrum File.   | readspec                          | Check wave spectrum file name in<br>the input file- line 5. Verify the<br>location of the spectrum file is the<br>same as the input file.   |
| Error 120 - Opening input file.  | srfsetup                          | Check the name of the input file<br>typed at the command prompt<br>(surf32 < fn.in) or the name<br>typed during execution (Enter<br>fn.in). |
| Error 125 - Opening of Input Depth File.   | c_in_dep                          | Check depth profile file name in<br>the input file - line 4. Verify the<br>location of the depth file is the<br>same as the input file.     |
| Error 130 - Opening Refraction File.   | readrfrc                          | Check refraction file name in the<br>input file - line 6. Verify the<br>location of the refraction file is the<br>same as the input file.   |
| Error 145 - Input depth profile has more data<br>points than allowed. Check depth profile.<br>Program stopped. | c_in_dep                          | The maximum number of depth<br>points allowed is 500. Modify<br>depth input file to contain only 500<br>depth values.                       |
| Error 165 - No sediment type selected for Equilibrium Profile.   | equilprf                          | A Slope/Sediment Type was not set<br>correctly in the input file line 8.<br>The value must be inclusive of 1-10                             |
| Error 170 - No Surf.   | surf                              | Check the heading toward the<br>beach in the input file, line 7 and<br>the spectrum input file. There may<br>be no surf in the area.        |

|  | 1                    | 1  |
|--|----------------------|--|
| Error 180 - Problem gridding to output file.<br>Program stops.   | prt_out1<br>prt_out2 | Check that the input depth profile<br>extends to the beach shoreline and<br>that the tide level - line 12 is not<br>too high.  |
| Error 185 - Problem with wave height values.   | new_brk              | Check the input depth profile. The<br>data may need to be smoothed due<br>to unusual slopes. (Hint: too many<br>negative slopes.)  |
| Error 195 - Significant wave height outside<br>surf zone less than 0.5 ft - no further<br>calculations.  | s_nosurf             | Check the heading toward the beach in the input file - line 7.   |
| Error 200 - Surf forecasts are for situations<br>when waves are more important than winds.<br>This is not the case for input waves and<br>winds. Forecasts may not be valid. | s_coeff              | Check the input wave and wind conditions in the input file - line 11 and line 12.  |
| Error 205 - Water edge not found. Check tide and/or depths. Program stopped.   | s_tide               | The input depth profile must extend<br>to the beach including the addition<br>of a tide, if specified. There must<br>be a depth at either 0.0, an onshore<br>value, or an elevation. |
| Error 210 - Wave direction not toward the beach - no further calculations.   | rad_st2              | Check the heading toward the<br>beach in the input file, line 7 and/or<br>the directional wave spectrum file.  |
| Error 215 - Wave induced set-up not converging to tolerance.   | setup                | The input depth profile must be smoothed.  |
| Error 220 - Wave induced Set-up is not converging. Ending program.   | main_wav             | The input depth profile must be smoothed.  |

# **Appendix C. Flowchart Symbol Index**



# Appendix D. Acronyms

| CNMOC  | Commander, Naval Meteorology and Oceanography Command |
|--------|---|
| CSCI   | Computer Software Configuration Item                  |
| CSU    | Computer Software Unit                                |
| DWS    | Directional Wave Spectrum                             |
| EOF    | End of File   |
| Hz     | Hertz   |
| LHS    | Left Hand Side of Energy Balance Equation             |
| m      | Meter   |
| N      | Newton  |
| MSI    | Modified Surf Index                                   |
| NRL    | Naval Research Laboratory                             |
| OAML   | Oceanographic and Atmospheric Master Library          |
| ONR .  | Office of Naval Research                              |
| RHS    | Right Hand Side of Energy Balance Equation            |
| RSM    | Refraction/Shoaling Matrix                            |
| SPAWAR | Space and Naval Warfare Systems Command               |

۰.