

REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. **PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.**

1. REPORT DATE (DD-MM-YYYY) 09-09-2019	2. REPORT TYPE Interim	3. DATES COVERED (From – To) Jan 1 2016-31 Dec 2018
--	----------------------------------	---

4. TITLE AND SUBTITLE Synergistic Effects of 1064nm Picosecond Pulses and nanosecond Pulsed Electric Fields on Optical Breakdown Thresholds Annual briefing	5a. CONTRACT NUMBER In-house
	5b. GRANT NUMBER
	5c. PROGRAM ELEMENT NUMBER 61102F

6. AUTHOR(S) Zachary Coker	5d. PROJECT NUMBER
	5e. TASK NUMBER
	5f. WORK UNIT NUMBER H0DK

7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) 711 HPW/RHDR	8. PERFORMING ORGANIZATION REPORT NUMBER N/A
---	--

9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES) Air Force Material Command, Air Force Research Laboratory, 711th Human Performance Wing, Human Effectiveness Directorate, Bioeffects Division, Radio Frequency Bioeffects Branch, (711 HPW/RHDR) , 4141 Petroleum Drive, JBSA Fort Sam Houston, Texas 78234-2644	10. SPONSOR/MONITOR'S ACRONYM(S) 711 HPW/RHD_ TSRL-2018-0217, Sept 2018
	11. SPONSOR/MONITOR'S REPORT NUMBER(S) AFRL-RH-FS-OP-2019-0002

12. DISTRIBUTION / AVAILABILITY STATEMENT
Distribution A. Approved for Public Release, TSRL-2018-0207, Sept 2018

13. SUPPLEMENTARY NOTES

14. ABSTRACT

15. SUBJECT TERMS
Nanosecond pulsed electric fields, optical breakdown thresholds

16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT SAR	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON B. lbey
a. REPORT Unclassified	b. ABSTRACT Unclassified	c. THIS PAGE Unclassified			19b. TELEPHONE NUMBER (include area code) N/A



Synergistic Effects of 1064nm Picosecond Pulses and nanosecond Pulsed Electric Fields on Optical Breakdown Thresholds

10 Sept 2018

Zachary Coker, CRFP
711 HPW/RHDR
Bioeffects Division

Integrity ★ Service ★ Excellence

"The opinions expressed on this document, electronic or otherwise, are solely those of the author(s). They do not represent an endorsement by or the views of the United States Air Force, the Department of Defense, or the United States Government."

DRAFT Distribution A: Approved for public release, distribution unlimited, (PA # TSRL 2018-0207, Sept 2018).








Hypothesis



- **Optical breakdown thresholds are influenced by the presence of externally applied nanosecond pulsed electric fields (nsEPs)**
 - Influence of electric field leads to easier cascade/avalanche ionization in condensed matter/liquids
- **Novelty: first investigation into electric field interactions with optical breakdown thresholds on a cell-level study, particularly with cell-level applications & nsEP**





Overview



- **Brief introduction to concepts of nsEP and optical breakdown**
- **Overall goal: answer an underlying question about Physics & interaction of nsEP with optical pulses → future applications**
- **Design of experiment: “what” and “how”**
- **Preliminary results**
- **Technical challenges and efforts to overcome them**
- **Current results**
- **Observations and future direction**



Nanosecond Electric Pulses (nsEP)





What is a nanosecond electric pulse (nsEP)?

• nsEP

- are pulses with a pulse width of less than 1 μs and
- are generated by a large discharge of voltage across a gap, typically delivered between two metal surfaces


• Possible experimental variables

- Pulse width
- Amplitude (electric field)
- Pulse number (multiple pulses)
- Mono/bi-phasic
- Repetition rate





Optical Breakdown & Photoionization




- **What is optical breakdown?**
 - Partial or complete ionization of a material by high-intensity laser irradiation/energy absorption
- **Two mechanisms lead to breakdown:**
 - Multi-photon “deterministic” (typical of ultra-short fs pulses)
 - Cascade or avalanche “probabilistic” (ps-ns pulse duration)
 - requires free electrons in focal volume → absorb energy → collide and ionize atoms/molecules → cascade effect of energy-absorbing electrons
 - Medium with high ionization potential require multi-photon absorption to start cascade breakdown process.
- **Our case: 1064nm 6 picosecond pulse → multi-photon excitation leads to cascade ionization as primary contributor to breakdown**




The Question & Basic Idea

Our primary question: How does nsEP affect breakdown threshold energies for optical breakdown in aqueous media?





Experimental setup




- Attodyne 532-1064 picosecond laser (6ps pulse duration)
- OBIS 632nm probe laser
- Leica DMI4000B microscope
- 20x 0.4NA objective
- Stanford SRS DG535 delay generator (x2)
- Tektronix TDS 3054C Oscilloscope (x2)
- HP E3630A DC power supply
- 1kV high-voltage power supply
- ONDA hydrophone + pre-amp
- Custom nsEP electrode-probes
- Photo-diodes (2x)





Experiment & Detection Methods



Beam splitter to photo-diode for breakdown detection

Photo-diode for breakdown detection

nsEP electrodes

Hydrophone for breakdown pressure-wave detection

nsEP probe to oscilloscope






Optical Pulse and Breakdown Detection



- Delay generator triggers a 600ns nsEP pulse (measured on separate oscilloscope)
- 100ns later, triggers 6ps optical pulse
- 6ps pulse detected by 1st photodiode and triggers second oscilloscope
- Optical pulse passes through sample causing breakdown
- Probe beam deflected by breakdown event, and measured on scope breakdown diode
- μ s later, hydrophone measures pressure wave







Oscilloscope readings






Sample View, nsEP Pulse and Laser Focus





Preliminary Results



- Tested aqueous solutions relevant to cell culture experiments
- nsEP appears to “shift” breakdown probability curve vs pulse energy
- Hydrophone used to initially detect breakdown could be damaged by nsEP
- All-optical system desirable to prevent damage to elements



Initial Observations & Technical Complications




- **Optical breakdown occurred at the lowest power/energy settings for the laser**
- **Laser output appeared to vary day-to-day**
 - Need more reliable attenuation and energy detection
 - Possible there are daily changes in laser mode quality or polarization (unknown)
- **All-optical detection desired to avoid damaging hydrophone with nsEP pulse**
- **Complex solutions could behave differently compared to “simpler” solutions**
 - Lead to testing of pure water and D₂O “heavy water” to compare like-samples
- **Hypothesis: Electric field intensity will have direct impact on results**



Breakdown in “Pure Water” & Dependence on nsEP Intensity

Pure water optical breakdown
with varying nsEP intensity



- **Mili-Q purification system**
 - 18.2 MΩ pure water
 - Higher threshold energy compared to regular water (2.2-3.2 μJ v 3.2-3.9 μJ)
- **Again, nsEP appears to “shift” breakdown probability curve vs pulse energy**
 - nsEP intensity dependent
 - Greater shifts correspond to greater field intensity
 - Could correspond to increased electron mobility and kinetic energy






Breakdown in D₂O “Heavy Water” With nsEP



D2O "Heavy water" optical breakdown
no nsEP vs 830V nsEP



- Heavy water breakdown significantly lower than pure water
 - (1.5-2.3 μJ vs 3.2-3.9 μJ)
 - Causes not yet identified
- Purity likely not the reason, as heavy water ~99.9% pure
- Possibly related to energy band gaps or increased multiphoton ionization
- Heavy water approximately full order of magnitude less absorption at 1064nm





Current Observations






- **Optical breakdown thresholds reduced by nsEP of all strengths**
 - Increased voltage = increased effect (nominally in some samples; lower-V)
- **Substantially different between pure water and heavy water tested**
 - Likely due to impurities in regular water, and chemistry of “heavy water” (?)
 - Increased probability for cascade from impurities in regular water
 - Increased multi-photon ionization in heavy water (?)
- **Laser pulse energy varies pulse-pulse**
 - Energy meter set up to measure each individual pulse (by ratio T:R)
 - Optimizing polarization & clean-up before beam-combining should help
- **All-optical detection with probe-beam deflection and photo-diode**
- **Future work to implement cell-level studies similar to nsEP poration studies using uptake of nano-dye Yo-Pro and Propidium Iodide**



So What's Next?



Future application to cellular-level studies:
Synergy below thresholds?






Combined Optoporation & Electroporation



- **Optoporation: transient perforation in a cell membrane is made using focused ultrashort laser pulses**
- **Electroporation/electropermeabilization: electric field applied to cells in order to increase the permeability of the cell membrane**
- **Investigating the synergistic effects:**
 - **Can we use these two techniques for targeted/specific purposes?**
 - **Electro-optic poration: inhibition or discrete localization?**







Acknowledgements

- Dr. Vladislav Yakovlev
- Dr. Bennett Ibey
- Dr. Caleb Roth
- Dr. Chris Valdez
- Dr. Ronald Barnes
- Dr. Hope Beier
- Mr. Gary Noojin
- Dr. Joel Bixler
- Mr. Joseph Clary
- Dr. Michael Denton
- Ms. Stacey Martens
- Ms. Kaitlin Nelson

Consortium Research Fellows Program

