

AD-A141 546

ORGANOSILANE POLYMERS V HYDROSILYL-MODIFIED  
POLYCARBOSILANE PRECURSORS FO. (U) UNION CARBIDE CORP  
TARRYTOWN NY C L SCHILLING ET AL. SEP 83 TR-83-1

1/1

UNCLASSIFIED


N00014-81-C-0682

F/G 7/3

NL



END  
DATE  
FILMED  
7 84  
DTIC



MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A



OFFICE OF NAVAL RESEARCH  
CONTRACT N00014-81-C-0682  
TECHNICAL REPORT 83-1

ORGANOSILANE POLYMERS, V:

HYDROSILYL-MODIFIED POLYCARBOSILANE

PRECURSORS FOR SILICON CARBIDE

by

C. L. Schilling Jr. and T. C. Williams

Union Carbide Corporation  
Tarrytown, New York 10591

Reproduction in whole or in part is permitted  
for any purpose of the United States Government

This document has been approved for public  
release and sale; its distribution is unlimited

September 1983




84 05 29 039

ORGANOSILANE POLYMERS, V:  
HYDROSILYL-MODIFIED POLYCARBOSILANE  
PRECURSORS FOR SILICON CARBIDE

INTRODUCTION


Several organosilicon polymer approaches to ceramic compositions have recently been developed, including branched polycarbosilane precursors for silicon carbide.<sup>1</sup> These thermoplastic polymers were prepared in high yield through potassium metal dechlorinations of mixtures of vinylic or chloromethyl (ClCH<sub>2</sub>-) chlorosilanes with other methylchlorosilanes in tetrahydrofuran solvent. Monomer mixtures were selected to maximize formation of backbone "SiC" bonds, while maintaining high synthetic yield, tractability, and high yields of silicon carbide ceramic compositions on unconfined pyrolysis. A typical preparation as



shown yields a polymer which, in unfractionated form, provides a 31.4% yield of SiC ceramic composition on pyrolysis.


RESULTS AND DISCUSSION

The substitution of MeSiHCl<sub>2</sub> for Me<sub>2</sub>SiCl<sub>2</sub> in the above preparation provides a somewhat lower yield of tractable polymer, which in turn yields significantly more SiC composition on pyrolysis.





Improved ceramic yields were also obtained when MeSiHCl<sub>2</sub> was substituted for Me<sub>2</sub>SiCl<sub>2</sub> in other copolymerizations.

For example, a linear copolymer prepared from Me<sub>2</sub>SiCl<sub>2</sub>/CH<sub>2</sub>=CHSiMe<sub>3</sub><sup>2</sup> provides a very low ceramic






yield after pyrolysis, while a similar polymer prepared with  $\text{MeSiHCl}_2/\text{CH}=\text{CHSiMe}_3$  provides a significantly higher ceramic yield. Equivalent results are obtained from copolymers prepared from  $\text{Me}_2\text{SiCl}_2$  or  $\text{MeSiHCl}_2$  and  $\text{CH}_2=\text{CHSiMe}_2\text{Cl}$ , or from  $\text{Me}_2\text{SiCl}_2$  or  $\text{MeSiHCl}_2$  and  $\text{CH}_2=\text{CHSiMe}_2\text{CH}_2\text{Cl}$ . In the latter comparison, a 2/1




molar ratio of  $\text{Me}_2\text{SiCl}_2/\text{CH}_2=\text{CHSiMe}_2\text{CH}_2\text{Cl}$  was used, with a 1.5/1 molar ratio of  $\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMe}_2\text{CH}_2\text{Cl}$ .

Since the backbone branching in these polycarbosilane types is responsible for their effective pyrolytic conversion to  $\text{SiC}$ ,<sup>1</sup> it appears that  $\text{MeSiHCl}_2$  provides such branching, either by forming trifunctional  $\text{MeSi}^*$  units during synthesis (with loss of H-groups) or during pyrolysis, by reactions of difunctional  $-\text{MeSiH}-$  groups.

It should be noted that the polymeric units derived from  $\text{CH}_2=\text{CHSiMe}_2\text{Cl}$  or  $\text{CH}_2=\text{CHSiMe}_2\text{CH}_2\text{Cl}$  provide backbone branching at carbon, rather than at silicon, and do not contribute to ceramic yield, while  $\text{CH}_2=\text{CHSiMeCl}_2$  provides units with backbone branching at silicon which do contribute to ceramic yield.



Model reactions suggest that the majority of the hydrosilyl groups are lost in the preparative step. Reaction of 2/1  $\text{Me}_3\text{SiCl}/\text{MeSiHCl}_2$  with K/THF provides a low yield of the tetrasilane,  $\text{MeSi}(\text{SiMe}_3)_3$ ,<sup>3</sup> as the major volatile product, rather than  $\text{MeSiH}(\text{SiMe}_3)_2$ . Proton NMR analyses of the  $\text{MeSiHCl}_2$ -derived copolymers show that about 20% of the hydrosilyl groups remain, while 80% are



converted to trifunctional branching units. The degree of loss of hydrosilyl functionality may be dependent on the active metal, since lithium causes complete loss,<sup>4</sup> while sodium retains most of the hydrosilyl groups,<sup>5</sup> in respective reactions with  $\text{Me}_2\text{SiHCl}$ .



#### POLYMER PROPERTIES

The soluble solid from dechlorination of 0.85/0.3/1.0  $\text{Me}_3\text{SiCl}/\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$  is a colorless resin which thermosets before melting, remaining solid to 300°, at which point pyrolytic degradation commences. TGA Scans of that polymer (Figure I) and the corresponding 0.85/0.3/1.0  $\text{Me}_3\text{SiCl}/\text{Me}_2\text{SiCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$  polymer (Figure II) also demonstrate the higher ceramic yield from the  $\text{MeSiHCl}_2$ -derived polymer. The TGA yield figures are somewhat lower than those obtained from bulk pyrolyses, probably due to the higher TGA heating rate and the small TGA sample size.




A series of polymers were prepared with relatively lower contents of units derived from  $\text{MeSiHCl}_2$ , as in 0.85/0.3/0.3/1.0, 0.85/0.2/0.2/1.0, and 0.85/0.3/0.1/1.0 polymers from  $\text{Me}_3\text{SiCl}/\text{Me}_2\text{SiCl}_2/\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$  monomer mixtures, to provide materials with better melt properties. The latter two polymers were solids at room temperature, remained fluid after melting to 300°, and were melt-spun to preceramic polycarbosilane fibers.<sup>6</sup>

Fractionation of the 0.85/0.3/1.0 terpolymer from  $\text{Me}_3\text{SiCl}/\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$  from THF into nonsolvent acetone provided high and low molecular weight fractions in approximately equal amounts.

The high molecular weight fraction provided 53.5% of SiC ceramic composition on pyrolysis, while the low molecular weight fraction yielded 43.2%. Actual molecular weights were not determined, although the polymers are amenable to analysis by gel permeation chromatography.

These polymers do not provide exact elemental analyses<sup>7</sup> due to oxygen incorporation during hydrolytic termination, loss of hydrogen from  $\equiv\text{SiH}$  groups, and problems in total combustion of preceramic materials.

The major-polymer forming reactions are disilylation of vinyl groups, creation of silylmethylene groups, or formation of silicon-silicon bonds. Model



reactions<sup>1</sup> have shown that formation of  $\equiv\text{Si-C}\equiv$  bonds by the first two reactions is generally favored, and instrumental analyses (IR, NMR, IV) are consistent with that fact.

#### CONCLUSIONS

The use of low levels of  $\text{MeSiHCl}_2$  in modifying potassium-derived polycarbosilanes provides significant improvements in yields and qualities of SiC ceramic compositions obtained therefrom. Most of the  $\text{MeSiHCl}_2$  reacts to form trifunctional  $\text{MeSi}\equiv$  groups, with about 20% being incorporated as difunctional  $-\text{MeSiH}-$  units. Residual hydrosilyl groups provide proportionate in situ cross-linking during pyrolysis.

#### EXPERIMENTAL

All chlorosilanes were freshly distilled before use. THF was reagent grade, dried over Linde 4A molecular sieves. K Metal was purchased as practical grade ingots; all K metal transfers were made under nitrogen in a dry box. All reactions (preparations and pyrolyses) were run under argon or nitrogen. Routine NMR spectra were recorded on a Perkin-Elmer R24A spectrometer - VPC. Analyses were run on a Hewlett-Packard 5840A gas chromatograph. Pyrolyses up to  $700^\circ$  were run in quartz reactors in a Lindberg 54242 tube furnace and those up to  $1200^\circ$  were run in an alumina reactor in a Lindberg 54233 tube furnace. Both furnaces have programmable controllers, which allow attendant-free operation from charging to removal of products. Conversions to SiC compositions were confirmed by x-ray diffraction.

#### Reaction of 1/1 $\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMe}_3$ with K/THF

In a 11 3N RB flask were combined 31.6g (0.81 mol) of K metal and 422.9g anhydrous THF. Flask was fitted with mechanical stirrer (stainless steel blade), thermometer, heating mantle, addition funnel, and nitrogen flow valves. Mixture was heated to reflux ( $66^\circ$ ), melting the K, and addition of a mixture of 38.5g (0.39 mol) of  $\text{CH}_2=\text{CHSiMe}_3$  and 44.3g (0.39 mol) of  $\text{MeSiHCl}_2$  begun and



completed in 40 min., lowering the reflux temperature to 64°. Heating was resumed at reflux for 5-1/2 hr, followed by cooling on wet ice bath, termination with 6.5g H<sub>2</sub>O/48.6g THF solution (dropwise addition), and neutralization with 6.4g conc. HCl. Filtration, trituration, and dissolution of the salts (H<sub>2</sub>O) left a trace amount of insoluble solid product. The THF reaction solution and trituration solvent were dried over MgSO<sub>4</sub>, filtered, and vacuum distilled, yielding 0.38g up to 35°/1.0 mm plus 24.36g (44%) of heavies. VPC Analysis suggested 20.8g (54%) of CH<sub>2</sub>=CHSiMe<sub>3</sub> was unreacted and was removed by stripping. Pyrolysis of the heavies to 1200° in two steps provided 28.5% of SiC composition, showing a weak X-ray diffraction pattern for microcrystalline β-SiC.<sup>8</sup>

A similar copolymer prepared from Me<sub>2</sub>SiCl<sub>2</sub>/CH<sub>2</sub>=CHSiMe<sub>3</sub>,<sup>1,2</sup> provided only 0.3% ceramic on pyrolysis to only 590°.

Reaction of 0.85/0.3/1.0 Me<sub>3</sub>SiCl/MeSiHCl<sub>2</sub>/CH<sub>2</sub>=CHSiMeCl<sub>2</sub> with K/THF

The procedure above was repeated using a 2l flask, 106.4g (2.72 mols) of K metal, 807.1g of tetrahydrofuran, and a mixture of 69.7g (0.64 mol) of Me<sub>3</sub>SiCl, 25.9g (0.225 mol) of MeSiHCl<sub>2</sub>, and 105.9g (0.75 mol) of CH<sub>2</sub>=CHSiMeCl<sub>2</sub>. Workup as above yielded 8.7% of insoluble solid product, 9.5% of volatile products, b.p. up to 65°/0.5 mm, and 74.6% of soluble solid product. Pyrolysis of the latter to 1200° in two steps yielded 51.7% of SiC composition having the correct x-ray diffraction pattern for microcrystalline β-SiC.

Analytical:	% C	% H	% Si	% Cl	% O
Calc'd:	48.33	10.22	41.45	0	0
Found:	45.48	9.10	39.63	0.044	5.65
(% 0 by difference)					

The soluble solid (analysis above) was submitted to Albany International Research Company for spin screening. Under melt spinning conditions, it crosslinked to an insoluble solid.

The procedure was repeated to prepare polymers from 0.85/0.3/0.3/1.0, 0.85/0.2/0.2/1.0, and 0.85/0.3/0.1/1.0 ratios of Me<sub>3</sub>SiCl/Me<sub>2</sub>SiCl<sub>2</sub>/MeSiHCl<sub>2</sub>/CH<sub>2</sub>=CHSiMeCl<sub>2</sub>. The latter two polymers were successfully melt-spun to preceramic fibers. The respective bulk pyrolysis yields of SiC ceramic compositions were 41.6%, 40.8%, and 35.5%.

REFERENCES

- 1a. C. L. Schilling, Jr., J. P. Wesson, and T. C. Williams, Am. Ceram. Soc. Bull. 62, 912 (1983).
- b. J. Poly. Sci., Polym. Symposia, in press.
- c. ONR Technical Report TR-80-1; Chem. Abstr., 95, 170175q (1981).

Reference 1b contains a review of organosilicon polymer routes to SiC ceramics.

2. O. M. Nefedov, et. al., Proc. Acad. Sci. USSR, 154, 76 (1964).
3. W. H. Atwell and D. R. Weyenberg, J. Organometal. Chem., 5, 594 (1966).
4. W. Peterson and B. Arkles, U.S. Patent 4,276,424; June 30, 1981.
5. P. Gerval et. al., Bull. Soc. Chim. France, 1974, p. 1548.
6. Spinning tests performed by Glenn Howland, Albany International Research Co., Dedham, Mass.
7. Elemental analyses by Galbraith Laboratories, Knoxville, Tenn.
8. S. Yajima, et. al., Nature, 279, 706 (1979).

FIGURES

- Figure I TGA of Terpolymer from  
0.85/0.3/1.0 Me<sub>3</sub>SiCl/ MeSiHCl<sub>2</sub>/CH<sub>2</sub>=CHSiMeCl<sub>2</sub>
- Figure II TGA Scan of Terpolymer from  
0.85/0.3/1.0 Me<sub>3</sub>SiCl/Me<sub>2</sub>SiCl<sub>2</sub>/CH<sub>2</sub>=CHSiMeCl<sub>2</sub>

ORGANOSILANE POLYMERS, V

Figure 1

TGA Scan of Terpolymer from 0.85/0.3 /1.0  
 $\text{Me}_3\text{SiCl}/\text{MeSiHCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$





Figure II

TGA Scan of Terpolymer from 0.85/0.3/1.0  
 $\text{Me}_3\text{SiCl}/\text{Me}_2\text{SiCl}_2/\text{CH}_2=\text{CHSiMeCl}_2$



<b>PART NO.</b> 990088 <b>TGA-5637</b> <b>RUN NO.</b> 8 <b>DATE</b> 8/12/82 <b>OPERATOR</b> J. L. ... <b>SAMPLE</b> ... <b>ATM.</b> He <b>FLOW RATE</b> 2.08 ft <sup>3</sup> /hr <i>polymer</i> <i>small weight gain during purge</i>	<b>T-AXIS</b> <b>SCALE</b> °C/m 50 <b>PROG. RATE</b> °C/min 5 <b>HEAT / COOL</b> ISO <b>SHIFT</b> in 0	<b>DTA-DSC</b> <b>SCALE</b> °C/m (mcal/sec)/m <b>WEIGHT</b> mg <b>REFERENCE</b>	<b>TGAV</b> <b>SCALE</b> mg/in 100 <b>SUPPRESSION</b> mg 0 <b>WEIGHT</b> mg 1.40 <b>TIME CONST.</b> sec 1 <b>dY</b> (mg/min)/in 0.2	<b>TMA</b> <b>SCALE</b> mils/in <b>MODE</b> <b>SAMPLE SIZE</b> <b>LOAD</b> g <b>dY</b> (10X) (mils/min)/in	<b>C. SKILLING</b> 22-5614 <b>He, ~ 20 min purge</b> <b>24.3% &lt; 725°C</b>
--	--	--	--	---	--

MEASURED VARIABLE *Any* DUPONT INSTRUMENTS

TEMPERATURE, °C (CHROMEL/ALUMEL)

TECHNICAL REPORT DISTRIBUTION LIST, GEN

	<u>No. Copies</u>		<u>No. Copies</u>
Office of Naval Research Attn: Code 413 800 N. Quincy Street Arlington, Virginia 22217	2	Naval Ocean Systems Center Attn: Technical Library San Diego, California 92152	1
ONR Pasadena Detachment Attn: Dr. R. J. Marcus 1030 East Green Street Pasadena, California 91106	1	Naval Weapons Center Attn: Dr. A. B. Amster Chemistry Division China Lake, California 93555	1
Commander, Naval Air Systems Command Attn: Code 310C (H. Rosenwasser) Washington, D.C. 20360	1	Scientific Advisor Commandant of the Marine Corps Code RD-1 Washington, D.C. 20380	1
Naval Civil Engineering Laboratory Attn: Dr. R. W. Drisko Port Hueneme, California 93401	1	Dean William Tolles Naval Postgraduate School Monterey, California 93940	1
Superintendent Chemistry Division, Code 6100 Naval Research Laboratory Washington, D.C. 20375	1	U.S. Army Research Office Attn: CRD-AA-IP P.O. Box 12211 Research Triangle Park, NC 27709	1
Defense Technical Information Center Building 5, Cameron Station Alexandria, Virginia 22314	12	Mr. Vincent Schaper DTNSRDC Code 2830 Annapolis, Maryland 21402	1
DTNSRDC Attn: Dr. G. Bosmajian Applied Chemistry Division Annapolis, Maryland 21401	1	Mr. John Boyle Materials Branch Naval Ship Engineering Center Philadelphia, Pennsylvania 19112	1
Naval Ocean Systems Center Attn: Dr. S. Yamamoto Marine Sciences Division San Diego, California 91232	1	Mr. A. M. Anzalone Administrative Librarian PLASTEC/ARRADCOM Bldg 3401 Dover, New Jersey 07801	1

DL/413/83/01  
356B/413-2

TECHNICAL REPORT DISTRIBUTION LIST, 356B

Dr. C. L. Schilling  
Union Carbide Corporation  
Chemical and Plastics  
Tarrytown Technical Center  
Tarrytown, New York

Dr. A. G. MacDiarmid  
Department of Chemistry  
University of Pennsylvania  
Philadelphia, Pennsylvania 19174

Dr. E. Fischer, Code 2853  
Naval Ship Research and  
Development Center  
Annapolis, Maryland 21402

Dr. H. Allcock  
Department of Chemistry  
Pennsylvania State University  
University Park, Pennsylvania 16802

Dr. M. Kenney  
Department of Chemistry  
Case Western University  
Cleveland, Ohio 44106

Dr. R. Lenz  
Department of Chemistry  
University of Massachusetts  
Amherst, Massachusetts 01002

Dr. M. David Curtis  
Department of Chemistry  
University of Michigan  
Ann Arbor, Michigan 48105

NASA-Lewis Research Center  
Attn: Dr. T. T. Serafini, MS 49-1  
21000 Brookpark Road  
Cleveland, Ohio 44135

Dr. J. Griffith  
Naval Research Laboratory  
Chemistry Section, Code 6120  
Washington, D.C. 20375

Professor G. Wnek  
Department of Materials Science  
and Engineering  
Massachusetts Institute of Technology  
Cambridge, Massachusetts 02139

Dr. R. Soulen  
Contract Research Department  
Pennwalt Corporation  
900 First Avenue  
King of Prussia, Pennsylvania 19406

Dr. G. Goodman  
Globe-Union Incorporated  
5757 North Green Bay Avenue  
Milwaukee, Wisconsin 53201

Dr. Martin H. Kaufman  
Code 38506  
Naval Weapons Center  
China Lake, California 93555

Dr. C. Allen  
Department of Chemistry  
University of Vermont  
Burlington, Vermont 05401

Professor R. Drago  
Department of Chemistry  
University of Florida  
Gainesville, Florida 32611

Dr. D. L. Venezky  
Code 6130  
Naval Research Laboratory  
Washington, D.C. 20375

Professor T. Katz  
Department of Chemistry  
Columbia University  
New York, New York 10027

Professor James Chien  
Department of Chemistry  
University of Massachusetts  
Amherst, Massachusetts 01002

Professor J. Salamone  
Department of Chemistry  
University of Lowell  
Lowell, Massachusetts 01854

Dr. S. Cooper  
Department of Chemistry  
University of Wisconsin  
750 University Avenue  
Madison, Wisconsin 53706

DL/413/83/01  
356B/413-2

TECHNICAL REPORT DISTRIBUTION LIST, 356B

Professor D. Grubb  
Department of Materials Science  
and Engineering  
Cornell University  
Ithaca, New York 14853

Professor T. Marks  
Department of Chemistry  
Northwestern University  
Evanston, Illinois 60201

Professor C. Chung  
Department of Materials Engineering  
Rensselaer Polytechnic Institute  
Troy, New York 12181

Professor Malcolm B. Polk  
Department of Chemistry  
Atlanta University  
Atlanta, Georgia 30314

Dr. D. B. Cotts  
SRI International  
333 Ravenswood Avenue  
Menlo Park, California 94205

Dr. Kurt Baum  
Fluorochem, Inc.  
680 S. Ayon Avenue  
Azusa, California 91702

Professor H. Hall  
Department of Chemistry  
University of Arizona  
Tucson, Arizona 85721

Professor G. Whitesides  
Department of Chemistry  
Harvard University  
Cambridge, Massachusetts 02138

Professor H. Ishida  
Department of Macromolecular Science  
Case Western University  
Cleveland, Ohio 44106

Dr. K. Paciorek  
Ultrasystems, Inc.  
P.O. Box 19605  
Irvine, California 92715

Professor D. Seyferth  
Department of Chemistry  
Massachusetts Institute of Technology  
Cambridge, Massachusetts 02139

Dr. G. Bryan Street  
IBM Research Laboratory, K32/281  
San Jose, California 95193

CAPT J. J. Auburn, USNR  
AT&T Bell Laboratories  
Room 6F-211  
600 Mountain Avenue  
Murray Hill, New Jersey 07974  
A