

AD-A159 736

CRDC-CR-84011

**OPTICAL PROPERTIES
OF THE METALS AI, Co, Cu, Au, Fe, Pb, Ni,
Pd, Pt, Ag, Ti AND W IN THE INFRARED
AND FAR INFRARED**

by M.A. Ordal
L.L. Long
R.J. Bell
S.E. Bell
R.R. Bell
R.W. Alexander, Jr.
C.A. Ward

UNIVERSITY OF MISSOURI-ROLLA
Rolla, Missouri 65401

AD-A159 736

September 1985

U.S. Army Armament, Munitions & Chemical Command
Aberdeen Proving Ground, Maryland 21010-5423

85 10 01 046

Approved for public release; distribution is unlimited.

Information contained herein is not to be construed as an official Department of Defense document and is not designated by other marking or classification.

Destruction Notice

For classified documents, follow the procedures in DoD 5200.22-M, Industrial Security Manual, Section II-19 or DoD 5200.1-R, Information Security Program Regulation, Chapter IX. For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

Distribution Statement

Approved for public release; distribution is unlimited.

Best Available Copy

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE

REPORT DOCUMENTATION PAGE

| | | | |
|--|---|--|------------------------------------|
| 1a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED | | 1b. RESTRICTIVE MARKINGS | |
| 2a. SECURITY CLASSIFICATION AUTHORITY | | 3. DISTRIBUTION/AVAILABILITY OF REPORT Approved for public release; distribution is unlimited. | |
| 2b. DECLASSIFICATION/DOWNGRADING SCHEDULE | | | |
| 4. PERFORMING ORGANIZATION REPORT NUMBER(S) CRDC-CR-84011 | | 5. MONITORING ORGANIZATION REPORT NUMBER(S) | |
| 6a. NAME OF PERFORMING ORGANIZATION University of Missouri-Rolla | 6b. OFFICE SYMBOL (If applicable) SMCCR-RSP-B | 7a. NAME OF MONITORING ORGANIZATION | |
| 6c. ADDRESS (City, State, and ZIP Code) Rolla, MO 65401 | | 7b. ADDRESS (City, State, and ZIP Code) | |
| 8a. NAME OF FUNDING/SPONSORING ORGANIZATION CRDC | 8b. OFFICE SYMBOL (If applicable) SMCCR-RSP-B | 9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER DAAK11-82-C-0052 | |
| 8c. ADDRESS (City, State, and ZIP Code) Aberdeen Proving Ground, MD 21010-5423 | | 10. SOURCE OF FUNDING NUMBERS | |
| | | PROGRAM ELEMENT NO. 12162622 | PROJECT NO. A552 |
| | | TASK NO. | WORK UNIT ACCESSION NO. |
| 11. TITLE (Include Security Classification) Optical Properties of the Metals Al, Co, Cu, Au, Fe, Pb, Ni, Pd, Pt, Ag, Ti, and W in the Infrared and Far Infrared | | | |
| 12. PERSONAL AUTHOR(S) Ordal, M. A., Long, L. L., Bell, R. J., Bell, S. E., Bell, R. R. | | | |
| 13a. TYPE OF REPORT Contractor | 13b. TIME COVERED FROM 82 May TO 84 May | 14. DATE OF REPORT (Year, Month, Day) 1985 September | 15. PAGE COUNT 55 |
| 16. SUPPLEMENTARY NOTATION Contracting Officer's Representative: Merrill Milham, SMCCR-RSP-B, (301) 671-3854 | | | |
| 17. COSATI CODES | | 18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number) Optical properties of the metals: aluminum, cobalt, copper, gold, iron, lead, nickel, palladium, platinum, silver, titanium, and tungsten | |
| 19. ABSTRACT (Continue on reverse if necessary and identify by block number) Infrared optical constants collected from the literature are tabulated. The data for the noble metals and Al, Pb, and W can be reasonably fit using the Drude model. It is shown that $-\epsilon_1(\omega) = \epsilon_2(\omega) \approx \omega_p^2/(2\omega_\tau^2)$ at the damping frequency $\omega = \omega_\tau$. Also $-\epsilon_1(\omega_\tau) \approx -(1/2) \epsilon_1(0)$ where the plasma frequency is ω_p . | | | |
| 20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input checked="" type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS | | 21. ABSTRACT SECURITY CLASSIFICATION UNCLASSIFIED | |
| 22a. NAME OF RESPONSIBLE INDIVIDUAL BRENDA C. ECKSTEIN | | 22b. TELEPHONE (Include Area Code) (301) 671-2914 | 22c. OFFICE SYMBOL SMCCR-SPS-IR |

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE

12. Personal Authors (Continued)

Alexander, R. W., Jr., and Ward C. A.

18. Subject Terms (Continued)

Infrared
Far infrared

PREFACE

The work described in this report was authorized under Project No. 12162622A552, Smoke Obscurant Systems. This work was started in May 1982 and completed in May 1984.

The use of trade names or manufacturer's names in this report does not constitute endorsement of any commercial products. This report may not be cited for purposes of advertisement.

Reproduction of this document in whole or in part is prohibited except with permission of the Commander, U.S. Army Chemical Research and Development Center, ATTN: SMCCR-SPS-IR, Aberdeen Proving Ground, Maryland 21010-5423. However, the Defense Technical Information Center and the National Technical Information Service are authorized to reproduce the document for U.S. Government purposes.

This report has been approved for release to the public.

Acknowledgments

This work was partially supported by the U.S. Army under Contract No. DAAK-11-82-C-0052. The authors gratefully acknowledge the valuable advice of Drs. Jean M. Bennet, David Begley, David Bryan, Kul Bhasin, and W. F. Parks.

| | |
|---------------------|-------------------------------------|
| Accession For | |
| NTIS GRA&I | <input checked="" type="checkbox"/> |
| DTIC TAB | <input type="checkbox"/> |
| Unannounced | <input type="checkbox"/> |
| Justification | |
| By _____ | |
| Distribution/ _____ | |
| Availability Codes | |
| Avail and/or | |
| Dist | Special |
| A-1 | |



BLANK

CONTENTS

| | Page |
|--|------|
| 1. INTRODUCTION | 7 |
| 2. DEFINITIONS AND EQUATIONS | 8 |
| 3. DETERMINATION OF DRUDE MODEL PARAMETERS | 9 |
| 4. THE DATA | 10 |
| LITERATURE CITED | 53 |

BLANK

OPTICAL PROPERTIES OF THE METALS Al, Co, Cu, Au, Fe, Pb,
Ni, Pd, Pt, Ag, Ti AND W IN THE INFRARED AND FAR INFRARED

1. INTRODUCTION

Many measurements of the optical constants of metals have been made, primarily at near infrared, visible and ultraviolet wavelengths. Sievers and his coworkers¹ have measured Au and Pb in the far infrared. We have compiled this data and have tabulated the real and imaginary parts of the dielectric function, ϵ_1 and ϵ_2 , respectively, the index of refraction, n, and the extinction index, k, for each metal in the infrared. Drude model²⁻⁴ parameters giving a reasonable fit to the data are given for Au, Ag, Cu, Al, Pb, and W. In general, the Drude model is not expected to be appropriate for transition metals in the near and middle infrared, but a good fit to the measurements can be obtained for W with a Drude model dielectric function. A table of ϵ_1 , ϵ_2 , n and k is given for each metal, calculated from the Drude model using parameters obtained from fitting the measured values.

Weaver, Krafka, Lynch, and Koch⁵ have compiled extensive tables of optical properties of metals which have been recently published. Most of their tables do not extend beyond 12 micrometers wavelength; our compilation extends to the longest wavelength for which data is available. For the noble metals, Dold and Mecke⁶ compiled tables of n and k in 1965.

H. E. and J. M. Bennett⁷ have shown that the Drude model fits the measured reflectance of gold, silver and aluminum in the 3 to 30 micrometer wavelength range with one adjustable parameter; i.e., the Drude model parameters were obtained from the dc resistivity and fitted with one free electron per atom for gold and silver and 2.6 free electrons per atom for aluminum. Brändli and Sievers have shown that the Drude model is an excellent fit to their far infrared measurements on lead and provides a good fit for gold with no adjustable parameters.

2. DEFINITIONS AND EQUATIONS

In keeping with infrared spectroscopic notation, all frequencies will be expressed in cm^{-1} . The complex dielectric function, ϵ_c , and the complex index of refraction, n_c , are defined as:

$$\epsilon_c = \epsilon_1 + i\epsilon_2 = n_c^2 = (n + ik)^2. \quad (1)$$

The Drude model dielectric function is

$$\epsilon_c = \epsilon_\infty - \frac{\omega_p^2}{\omega^2 + i\omega\tau} \quad (2)$$

where ω , ω_p and ω_τ have units of cm^{-1} . Separating the real and imaginary parts yields

$$\epsilon_1 = \epsilon_\infty - \frac{\omega_p^2}{\omega^2 + \omega_\tau^2} \quad (3)$$

and

$$\epsilon_2 = \frac{\omega_p^2\omega_\tau}{\omega^3 + \omega\omega_\tau^2} \quad (4)$$

In these equations, the plasma frequency⁸ is

$$\omega_p^2 = 4\pi Ne^2/m^* \quad (5)$$

and the scattering frequency is

$$\omega_\tau(\text{cm}^{-1}) = \frac{1}{2\pi c t} \quad (6)$$

where τ is the electron lifetime in seconds and c is the velocity of light in cm/sec. Note that for low frequencies

$$\epsilon_1(0) \rightarrow - \left[\frac{\omega_p}{\omega_\tau} \right]^2 . \quad (7)$$

The dc conductivity, σ_0 , is related to ω_τ by

$$\sigma_0 = \frac{\omega_p^2}{4\pi\omega_\tau} \quad (8)$$

with σ_0 having units of cm^{-1} . This can be expressed in terms of the dc resistivity, ρ_0 :

$$\sigma_0 (\text{cm}^{-1}) = \frac{1}{2\pi c [p_0 (\text{sec})]} = \frac{9 \times 10^{11}}{2\pi c [p_0 (\Omega \text{ cm})]} \quad (9)$$

In order to analyze the data of Sievers and Brändli,¹ it is convenient to write the surface impedance, $Z(\omega) = R(\omega) + iX(\omega)$, for the Drude model:⁴

$$Z(\omega) = \frac{4\pi}{c} (1-i) \left(\frac{\omega\omega_\tau}{2\omega_p^2} \right)^{\frac{1}{2}} \sqrt{1 - i \frac{\omega}{\omega_\tau}} \quad (10)$$

We shall need only $R(\omega)$:

$$R(\omega) = \frac{4\pi}{c} \left(\frac{\omega\omega_\tau}{2\omega_p^2} \right)^{\frac{1}{2}} \left\{ \frac{-\omega}{\omega_\tau} + \sqrt{1 + \frac{\omega^2}{\omega_\tau^2}} \right\}^{\frac{1}{2}} . \quad (11)$$

3. DETERMINATION OF DRUDE MODEL PARAMETERS

All data in the form of n and k was changed to ϵ_1 and ϵ_2 . Eqs. (3) and (4) were solved for ω_τ , eliminating ω_p :

$$\omega_\tau = \frac{\omega\epsilon_2}{\epsilon_\infty - \epsilon_1} \quad (12)$$

This equation was solved to determine ω_τ using ϵ_1 and ϵ_2 at some frequency ω . Then ω_p was obtained from

$$\omega_p^2 = (\epsilon_\infty - \epsilon_1) (\omega^2 + \omega_\tau^2) \quad (13)$$

Due to a lack of reliable data ϵ_∞ was taken to be unity. Eqs. (11) and (12) were applied to the data at several values of ω to obtain the ω_τ and ω_p values which produced the curve with the best "eyeball" fit to the data.

The one exception to this process was the measurements of Brändli and Sievers¹ for Au and Pb. They reported values of $R(\omega)/Z_0$ where $Z_0 = 4\pi/c$. For the far infrared, Equation (11) reduces to

$$\frac{R(\omega)}{Z_0} = \left(\frac{\omega \omega_\tau}{2\omega_p^2} \right)^{\frac{1}{2}} . \quad (14)$$

ω_τ was obtained from this data using ω_p from the near infrared fit. This value of ω_τ was used for gold and lead rather than the ω_τ obtained from the near infrared fit.

We note from Eq. (12) that the frequency for which $-\epsilon_1(\omega) = \epsilon_2(\omega)$ is very nearly $\omega = \omega_\tau$ since $-\epsilon_1 \gg 1$. With $\omega = \omega_\tau$ both components ($-\epsilon_1$ and ϵ_2) of the dielectric function are $\omega_p^2/(2\omega_\tau^2)$. Thus the Drude parameters, ω_τ and ω_p , can be determined at the crossover from $\omega = \omega_\tau$ and the value of the dielectric function. Note that $-\epsilon_1(0) \approx \omega_p^2/\omega_p^2$; so, $-1/2\epsilon_1(0) \approx -\epsilon_1(\omega_\tau)$.

4. THE DATA

Figures 1 through 12 are plots of $-\epsilon_1(\omega)$ for the 12 metals. The high frequency termination occurs where the Drude model becomes invalid. The solid lines are calculated from the Drude model with the parameters listed in Table 13. Tables 1 through 12 present the collected values of ϵ_1 , ϵ_2 , n , and k . Table 13 summarizes the Drude model parameters from our fit (for Ag, Au, Cu, Al, Pb and W) as well as ω_τ calculated from ω_p and the AIP

handbook⁹ values of the dc resistivity. Dielectric functions for all metals considered in this article except Pb have been tabulated by Weaver et al.⁵ for the uv, visible and near IR.

Finally, we disclaim any physical significance for the Drude model. The intent is only to parametrize the optical constants for these metals even when there is some question as to the physical meaning of the parameters. The transition metals show interband transitions and cannot be fit with a Drude model in the infrared (with the exception of W). Even the noble metals in the IR can have small interband contributions to the dielectric constants.¹⁰

TABLE 1. ALUMINUM (Al)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 3.23E+02 | 3.10E+01 | 3.18E+04 | 4.02E+04 | 9.86E+01 | 2.04E+02 |
| 3.39E+02 | 2.95E+01 | 3.01E+04 | 3.62E+04 | 9.22E+01 | 1.96E+02 |
| 3.71E+02 | 2.70E+01 | 2.68E+04 | 3.03E+04 | 8.26E+01 | 1.83E+02 |
| 4.03E+02 | 2.48E+01 | 2.43E+04 | 2.59E+04 | 7.50E+01 | 1.73E+02 |
| 4.36E+02 | 2.30E+01 | 2.14E+04 | 2.24E+04 | 6.93E+01 | 1.62E+02 |
| 4.68E+02 | 2.14E+01 | 1.95E+04 | 2.01E+04 | 6.52E+01 | 1.54E+02 |
| 5.00E+02 | 2.00E+01 | 1.80E+04 | 1.79E+04 | 6.07E+01 | 1.47E+02 |
| 5.32E+02 | 1.88E+01 | 1.66E+04 | 1.60E+04 | 5.67E+01 | 1.41E+02 |
| 5.81E+02 | 1.72E+01 | 1.50E+04 | 1.38E+04 | 5.20E+01 | 1.33E+02 |
| 6.45E+02 | 1.55E+01 | 1.32E+04 | 1.13E+04 | 4.58E+01 | 1.24E+02 |
| 7.10E+02 | 1.41E+01 | 1.18E+04 | 9.49E+03 | 4.09E+01 | 1.16E+02 |
| 7.74E+02 | 1.29E+01 | 1.05E+04 | 7.89E+03 | 3.62E+01 | 1.09E+02 |
| 8.87E+02 | 1.13E+01 | 8.77E+03 | 5.94E+03 | 3.02E+01 | 9.84E+01 |
| 1.05E+03 | 9.54E+00 | 6.93E+03 | 4.07E+03 | 2.35E+01 | 8.65E+01 |
| 1.21E+03 | 8.27E+00 | 5.58E+03 | 2.86E+03 | 1.86E+01 | 7.70E+01 |
| 1.37E+03 | 7.29E+00 | 4.51E+03 | 2.05E+03 | 1.49E+01 | 6.88E+01 |
| 1.61E+03 | 6.20E+00 | 3.39E+03 | 1.39E+03 | 1.17E+01 | 5.94E+01 |
| 2.02E+03 | 4.96E+00 | 2.25E+03 | 8.28E+02 | 8.59E+00 | 4.82E+01 |
| 2.42E+03 | 4.13E+00 | 1.63E+03 | 5.54E+02 | 6.76E+00 | 4.10E+01 |
| 2.82E+03 | 3.54E+00 | 1.24E+03 | 3.87E+02 | 5.44E+00 | 3.56E+01 |
| 3.23E+03 | 3.10E+00 | 9.71E+02 | 2.80E+02 | 4.45E+00 | 3.15E+01 |
| 4.84E+03 | 2.07E+00 | 4.53E+02 | 9.73E+01 | 2.27E+00 | 2.14E+01 |
| 6.45E+03 | 1.55E+00 | 2.52E+02 | 4.61E+01 | 1.44E+00 | 1.60E+01 |
| 8.07E+03 | 1.24E+00 | 1.54E+02 | 3.02E+01 | 1.21E+00 | 1.25E+01 |
| 1.21E+04 | 8.27E-01 | 6.15E+01 | 4.56E+01 | 2.75E+00 | 8.31E+00 |
| 1.61E+04 | 6.20E-01 | 5.42E+01 | 1.95E+01 | 1.30E+00 | 7.48E+00 |

SOURCE: Reference 11

TABLE 1. ALUMINUM (Al) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------|----------------------|---------------|--------------|----------|----------|
| 3.13E+02 | 3.20E+01 | 2.60E+04 | 5.56E+04 | 1.33E+02 | 2.09E+02 |
| 3.23E+02 | 3.10E+01 | 2.58E+04 | 5.31E+04 | 1.29E+02 | 2.06E+02 |
| 3.33E+02 | 3.00E+01 | 2.56E+04 | 5.08E+04 | 1.25E+02 | 2.03E+02 |
| 3.45E+02 | 2.90E+01 | 2.54E+04 | 4.84E+04 | 1.21E+02 | 2.00E+02 |
| 3.57E+02 | 2.80E+01 | 2.47E+04 | 4.59E+04 | 1.17E+02 | 1.96E+02 |
| 3.70E+02 | 2.70E+01 | 2.45E+04 | 4.36E+04 | 1.13E+02 | 1.93E+02 |
| 3.85E+02 | 2.60E+01 | 2.38E+04 | 4.12E+04 | 1.09E+02 | 1.89E+02 |
| 4.00E+02 | 2.50E+01 | 2.36E+04 | 3.91E+04 | 1.05E+02 | 1.86E+02 |
| 4.17E+02 | 2.40E+01 | 2.31E+04 | 3.64E+04 | 1.00E+02 | 1.82E+02 |
| 4.35E+02 | 2.30E+01 | 2.25E+04 | 3.42E+04 | 9.60E+01 | 1.78E+02 |
| 4.55E+02 | 2.20E+01 | 2.19E+04 | 3.18E+04 | 9.15E+01 | 1.74E+02 |
| 4.76E+02 | 2.10E+01 | 2.10E+04 | 2.93E+04 | 8.68E+01 | 1.69E+02 |
| 5.00E+02 | 2.00E+01 | 2.05E+04 | 2.71E+04 | 8.21E+01 | 1.65E+02 |
| 5.26E+02 | 1.90E+01 | 1.96E+04 | 2.47E+04 | 7.73E+01 | 1.60E+02 |
| 5.56E+02 | 1.80E+01 | 1.88E+04 | 2.24E+04 | 7.24E+01 | 1.55E+02 |
| 5.88E+02 | 1.70E+01 | 1.80E+04 | 2.02E+04 | 6.74E+01 | 1.50E+02 |
| 6.25E+02 | 1.60E+01 | 1.69E+04 | 1.79E+04 | 6.23E+01 | 1.44E+02 |
| 6.67E+02 | 1.50E+01 | 1.58E+04 | 1.58E+04 | 5.71E+01 | 1.38E+02 |
| 7.14E+02 | 1.40E+01 | 1.47E+04 | 1.37E+04 | 5.19E+01 | 1.32E+02 |
| 7.69E+02 | 1.30E+01 | 1.37E+04 | 1.18E+04 | 4.67E+01 | 1.26E+02 |
| 8.33E+02 | 1.20E+01 | 1.24E+04 | 9.88E+03 | 4.15E+01 | 1.19E+02 |
| 9.09E+02 | 1.10E+01 | 1.10E+04 | 8.06E+03 | 3.63E+01 | 1.11E+02 |
| 1.00E+03 | 1.00E+01 | 9.84E+03 | 6.49E+03 | 3.12E+01 | 1.04E+02 |
| 1.11E+03 | 9.00E+00 | 8.41E+03 | 5.02E+03 | 2.63E+01 | 9.54E+01 |
| 1.25E+03 | 8.00E+00 | 7.02E+03 | 3.72E+03 | 2.15E+01 | 8.65E+01 |

SOURCE: Reference 7

| ω (cm $^{-1}$) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------|----------------------|---------------|--------------|----------|----------|
| 1.05E+04 | 9.50E-01 | 6.92E+01 | 2.98E+01 | 1.75E+00 | 8.50E+00 |
| 1.11E+04 | 9.00E-01 | 5.54E+01 | 3.02E+01 | 1.96E+00 | 7.70E+00 |
| 1.18E+04 | 8.50E-01 | 4.68E+01 | 2.97E+01 | 2.08E+00 | 7.15E+00 |
| 1.25E+04 | 8.00E-01 | 4.57E+01 | 2.81E+01 | 1.99E+00 | 7.05E+00 |
| 1.33E+04 | 7.50E-01 | 4.75E+01 | 2.56E+01 | 1.80E+00 | 7.12E+00 |
| 1.43E+04 | 7.00E-01 | 4.66E+01 | 2.17E+01 | 1.55E+00 | 7.00E+00 |
| 1.54E+04 | 6.50E-01 | 4.20E+01 | 1.64E+01 | 1.24E+00 | 6.60E+00 |
| 1.67E+04 | 6.00E-01 | 3.51E+01 | 1.16E+01 | 9.70E-01 | 6.00E+00 |
| 1.82E+04 | 5.50E-01 | 2.77E+01 | 8.09E+00 | 7.60E-01 | 5.32E+00 |
| 2.00E+04 | 5.00E-01 | 2.27E+01 | 5.95E+00 | 6.20E-01 | 4.80E+00 |
| 2.22E+04 | 4.50E-01 | 1.84E+01 | 4.23E+00 | 4.90E-01 | 4.32E+00 |
| 2.50E+04 | 4.00E-01 | 1.52E+01 | 3.14E+00 | 4.00E-01 | 3.92E+00 |

SOURCE: Reference 12

TABLE 2. COPPER (Cu)

| ω (cm ⁻¹) | λ (μm) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------|---------------|--------------|----------|----------|
| 1.05E+04 | 9.50E-01 | 3.87E+01 | 1.62E+00 | 1.30E-01 | 6.22E+00 |
| 1.11E+04 | 9.00E-01 | 3.43E+01 | 1.52E+00 | 1.30E-01 | 5.86E+00 |
| 1.18E+04 | 8.50E-01 | 2.99E+01 | 1.31E+00 | 1.20E-01 | 5.47E+00 |
| 1.25E+04 | 8.00E-01 | 2.57E+01 | 1.22E+00 | 1.20E-01 | 5.07E+00 |
| 1.33E+04 | 7.50E-01 | 2.13E+01 | 1.11E+00 | 1.20E-01 | 4.62E+00 |
| 1.43E+04 | 7.00E-01 | 1.74E+01 | 1.00E+00 | 1.20E-01 | 4.17E+00 |
| 1.54E+04 | 6.50E-01 | 1.33E+01 | 9.49E-01 | 1.30E-01 | 3.65E+00 |
| 1.67E+04 | 6.00E-01 | 9.40E+00 | 1.04E+00 | 1.70E-01 | 3.07E+00 |
| 1.82E+04 | 5.50E-01 | 5.34E+00 | 3.48E+00 | 7.20E-01 | 2.42E+00 |
| 2.00E+04 | 5.00E-01 | 5.08E+00 | 4.26E+00 | 8.80E-01 | 2.42E+00 |
| 2.22E+04 | 4.50E-01 | 4.08E+00 | 3.83E+00 | 8.70E-01 | 2.20E+00 |

SOURCE: Reference 12

| ω (cm ⁻¹) | λ (μm) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------|---------------|--------------|----------|----------|
| 5.00E+02 | 2.00E+01 | 1.35E+04 | 7.61E+03 | 3.16E+01 | 1.20E+02 |
| 5.56E+02 | 1.80E+01 | 1.15E+04 | 6.11E+03 | 2.76E+01 | 1.11E+02 |
| 6.25E+02 | 1.60E+01 | 9.00E+03 | 4.64E+03 | 2.37E+01 | 9.78E+01 |
| 7.14E+02 | 1.40E+01 | 6.80E+03 | 3.36E+03 | 1.98E+01 | 8.48E+01 |
| 8.33E+02 | 1.20E+01 | 5.05E+03 | 2.29E+03 | 1.57E+01 | 7.28E+01 |
| 1.00E+03 | 1.00E+01 | 3.50E+03 | 1.40E+03 | 1.16E+01 | 6.03E+01 |
| 1.25E+03 | 8.00E+00 | 2.20E+03 | 7.28E+02 | 7.66E+00 | 4.75E+01 |
| 1.67E+03 | 6.00E+00 | 1.30E+03 | 3.24E+02 | 4.46E+00 | 3.63E+01 |
| 2.00E+03 | 5.00E+00 | 1.00E+03 | 1.40E+02 | 2.21E+00 | 3.17E+01 |
| 2.50E+03 | 4.00E+00 | 6.22E+02 | 8.80E+01 | 1.76E+00 | 2.50E+01 |

SOURCE: Reference 13

| ω (cm ⁻¹) | λ (μm) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------|---------------|--------------|----------|----------|
| 1.56E+04 | 6.40E-01 | 7.69E+00 | 1.70E+00 | 3.04E-01 | 2.79E+00 |
| 1.67E+04 | 6.00E-01 | 5.98E+00 | 1.70E+00 | 3.44E-01 | 2.47E+00 |
| 1.79E+04 | 5.60E-01 | 4.09E+00 | 2.20E+00 | 5.26E-01 | 2.09E+00 |
| 1.92E+04 | 5.20E-01 | 3.71E+00 | 6.99E+00 | 1.45E+00 | 2.41E+00 |
| 2.08E+04 | 4.80E-01 | 3.10E+00 | 7.01E+00 | 1.51E+00 | 2.32E+00 |
| 2.27E+04 | 4.40E-01 | 2.39E+00 | 6.79E+00 | 1.55E+00 | 2.19E+00 |
| 2.50E+04 | 4.00E-01 | 1.81E+00 | 5.92E+00 | 1.48E+00 | 2.00E+00 |

SOURCE: Reference 14

TABLE 2. COPPER (Cu) (Continued)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 4.24E+03 | 4.25E+03 | 2.97E+01 | 7.16E+01 |
| 4.03E+03 | 2.48E+00 | 3.08E+02 | 6.03E+01 | 1.71E+00 | 1.76E+01 |
| 8.07E+03 | 1.24E+00 | 7.17E+01 | 7.46E+00 | 4.40E-01 | 8.48E+00 |
| 1.21E+04 | 8.27E-01 | 2.76E+01 | 2.74E+00 | 2.60E-01 | 5.26E+00 |
| 1.37E+04 | 7.29E-01 | 1.96E+01 | 1.95E+00 | 2.20E-01 | 4.43E+00 |
| 1.41E+04 | 7.08E-01 | 1.80E+01 | 1.79E+00 | 2.10E-01 | 4.25E+00 |
| 1.45E+04 | 6.89E-01 | 1.63E+01 | 1.70E+00 | 2.10E-01 | 4.04E+00 |
| 1.49E+04 | 6.70E-01 | 1.48E+01 | 1.69E+00 | 2.20E-01 | 3.85E+00 |
| 1.53E+04 | 6.53E-01 | 1.34E+01 | 1.54E+00 | 2.10E-01 | 3.67E+00 |
| 1.61E+04 | 6.20E-01 | 1.04E+01 | 1.75E+00 | 2.70E-01 | 3.24E+00 |

SOURCE: Reference 15

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 1.00E+03 | 1.00E+01 | 2.27E+03 | 1.14E+03 | 1.16E+01 | 4.90E+01 |
| 1.11E+03 | 9.00E+00 | 1.99E+03 | 9.05E+02 | 9.90E+00 | 4.57E+01 |
| 1.25E+03 | 8.00E+00 | 1.66E+03 | 6.72E+02 | 8.10E+00 | 4.15E+01 |
| 1.43E+03 | 7.00E+00 | 1.31E+03 | 4.71E+02 | 6.40E+00 | 3.68E+01 |
| 1.67E+03 | 6.00E+00 | 9.99E+02 | 3.17E+02 | 4.95E+00 | 3.20E+01 |
| 2.00E+03 | 5.00E+00 | 6.95E+02 | 1.92E+02 | 3.60E+00 | 2.66E+01 |
| 2.50E+03 | 4.00E+00 | 4.56E+02 | 1.05E+02 | 2.45E+00 | 2.15E+01 |
| 3.33E+03 | 3.00E+00 | 2.54E+02 | 4.80E+01 | 1.50E+00 | 1.60E+01 |
| 5.00E+03 | 2.00E+00 | 1.12E+02 | 1.80E+01 | 8.50E-01 | 1.06E+01 |
| 6.67E+03 | 1.50E+00 | 6.37E+01 | 9.28E+00 | 5.80E-01 | 8.00E+00 |
| 8.00E+03 | 1.25E+00 | 4.46E+01 | 6.57E+00 | 4.90E-01 | 6.70E+00 |

SOURCE: Reference 6

TABLE 3. GOLD (Au)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 3.13E+02 | 3.20E+01 | 3.69E+04 | 2.54E+04 | 6.28E+01 | 2.02E+02 |
| 3.33E+02 | 3.00E+01 | 3.37E+04 | 2.17E+04 | 5.66E+01 | 1.92E+02 |
| 3.57E+02 | 2.80E+01 | 3.06E+04 | 1.84E+04 | 5.05E+01 | 1.82E+02 |
| 3.85E+02 | 2.60E+01 | 2.73E+04 | 1.53E+04 | 4.46E+01 | 1.71E+02 |
| 4.17E+02 | 2.40E+01 | 2.41E+04 | 1.24E+04 | 3.89E+01 | 1.60E+02 |
| 4.55E+02 | 2.20E+01 | 2.08E+04 | 9.89E+03 | 3.34E+01 | 1.48E+02 |
| 5.00E+02 | 2.00E+01 | 1.77E+04 | 7.67E+03 | 2.82E+01 | 1.36E+02 |
| 5.56E+02 | 1.80E+01 | 1.48E+04 | 5.78E+03 | 2.33E+01 | 1.24E+02 |
| 6.25E+02 | 1.60E+01 | 1.22E+04 | 4.19E+03 | 1.87E+01 | 1.12E+02 |
| 7.14E+02 | 1.40E+01 | 9.51E+03 | 2.86E+03 | 1.45E+01 | 9.86E+01 |
| 8.33E+02 | 1.20E+01 | 7.14E+03 | 1.84E+03 | 1.08E+01 | 8.52E+01 |
| 1.00E+03 | 1.00E+01 | 5.05E+03 | 1.09E+03 | 7.62E+00 | 7.15E+01 |
| 1.25E+03 | 8.00E+00 | 3.29E+03 | 5.68E+02 | 4.93E+00 | 5.76E+01 |
| 1.43E+03 | 7.00E+00 | 2.54E+03 | 3.83E+02 | 3.79E+00 | 5.05E+01 |
| 1.67E+03 | 6.00E+00 | 1.88E+03 | 2.42E+02 | 2.79E+00 | 4.34E+01 |
| 2.00E+03 | 5.00E+00 | 1.31E+03 | 1.41E+02 | 1.95E+00 | 3.62E+01 |
| 2.50E+03 | 4.00E+00 | 8.39E+02 | 7.25E+01 | 1.25E+00 | 2.90E+01 |
| 3.33E+03 | 3.00E+00 | 4.75E+02 | 3.07E+01 | 7.04E-01 | 2.18E+01 |

SOURCE: Reference 7

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 1.05E+04 | 9.50E-01 | 3.72E+01 | 2.32E+00 | 1.90E-01 | 6.10E+00 |
| 1.11E+04 | 9.00E-01 | 3.27E+01 | 2.06E+00 | 1.80E-01 | 5.72E+00 |
| 1.25E+04 | 8.00E-01 | 2.34E+01 | 1.55E+00 | 1.60E-01 | 4.84E+00 |
| 1.43E+04 | 7.00E-01 | 1.57E+01 | 1.35E+00 | 1.70E-01 | 3.97E+00 |
| 1.67E+04 | 6.00E-01 | 8.77E+00 | 1.37E+00 | 2.30E-01 | 2.97E+00 |
| 2.00E+04 | 5.00E-01 | 2.68E+00 | 3.09E+00 | 8.40E-01 | 1.84E+00 |
| 2.22E+04 | 4.50E-01 | 1.57E+00 | 5.26E+00 | 1.40E+00 | 1.88E+00 |

SOURCE: Reference 12

TABLE 3. GOLD (Au) (Continued)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 8.33E+02 | 1.20E+01 | 6.24E+03 | 2.48E+03 | 1.54E+01 | 8.05E+01 |
| 1.00E+03 | 1.00E+01 | 4.42E+03 | 1.55E+03 | 1.15E+01 | 6.75E+01 |
| 1.25E+03 | 8.00E+00 | 2.92E+03 | 8.54E+02 | 7.82E+00 | 5.46E+01 |
| 1.67E+03 | 6.00E+00 | 1.72E+03 | 3.92E+02 | 4.70E+00 | 4.17E+01 |
| 2.00E+03 | 5.00E+00 | 1.23E+03 | 2.30E+02 | 3.27E+00 | 3.52E+01 |
| 2.50E+03 | 4.00E+00 | 7.74E+02 | 1.14E+02 | 2.04E+00 | 2.79E+01 |
| 3.33E+03 | 3.00E+00 | 4.40E+02 | 4.91E+01 | 1.17E+00 | 2.10E+01 |
| 4.00E+03 | 2.50E+00 | 2.99E+02 | 2.84E+01 | 8.20E-01 | 1.73E+01 |
| 5.00E+03 | 2.00E+00 | 1.93E+02 | 1.52E+01 | 5.46E-01 | 1.39E+01 |
| 6.67E+03 | 1.50E+00 | 1.08E+02 | 7.43E+00 | 3.57E-01 | 1.04E+01 |
| 1.00E+04 | 1.00E+00 | 4.50E+01 | 3.01E+00 | 2.24E-01 | 6.71E+00 |

SOURCE: Reference 16

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 9.09E+02 | 1.10E+01 | 3.31E+03 | 1.01E+03 | 8.71E+00 | 5.82E+01 |
| 1.00E+03 | 1.00E+01 | 2.80E+03 | 7.91E+02 | 7.41E+00 | 5.34E+01 |
| 1.11E+03 | 9.00E+00 | 2.32E+03 | 6.04E+02 | 6.21E+00 | 4.86E+01 |
| 1.25E+03 | 8.00E+00 | 1.87E+03 | 4.39E+02 | 5.05E+00 | 4.35E+01 |
| 1.43E+03 | 7.00E+00 | 1.45E+03 | 3.04E+02 | 3.97E+00 | 3.83E+01 |
| 1.67E+03 | 6.00E+00 | 1.08E+03 | 1.99E+02 | 3.01E+00 | 3.30E+01 |
| 2.00E+03 | 5.00E+00 | 7.62E+02 | 1.21E+02 | 2.19E+00 | 2.77E+01 |
| 2.50E+03 | 4.00E+00 | 4.91E+02 | 6.62E+01 | 1.49E+00 | 2.22E+01 |
| 3.33E+03 | 3.00E+00 | 2.78E+02 | 3.11E+01 | 9.30E-01 | 1.67E+01 |
| 5.00E+03 | 2.00E+00 | 1.25E+02 | 1.21E+01 | 5.40E-01 | 1.12E+01 |
| 1.00E+04 | 1.00E+00 | 3.10E+01 | 3.46E+00 | 3.10E-01 | 5.58E+00 |

SOURCE: Reference 17

TABLE 3. GOLD (Au) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------|----------------------|---------------|--------------|----------|----------|
| 1.05E+03 | 9.50E+00 | 2.44E+03 | 1.10E+03 | 1.09E+01 | 5.06E+01 |
| 1.11E+03 | 9.00E+00 | 2.19E+03 | 9.58E+02 | 1.00E+01 | 4.79E+01 |
| 1.18E+03 | 8.50E+00 | 1.98E+03 | 8.86E+02 | 9.72E+00 | 4.56E+01 |
| 1.25E+03 | 8.00E+00 | 1.87E+03 | 6.95E+02 | 7.90E+00 | 4.40E+01 |
| 1.43E+03 | 7.00E+00 | 1.51E+03 | 5.22E+02 | 6.62E+00 | 3.94E+01 |
| 1.54E+03 | 6.50E+00 | 1.37E+03 | 4.10E+02 | 5.48E+00 | 3.74E+01 |
| 1.67E+03 | 6.00E+00 | 1.17E+03 | 3.25E+02 | 4.71E+00 | 3.45E+01 |
| 2.00E+03 | 5.00E+00 | 8.05E+02 | 1.54E+02 | 2.71E+00 | 2.85E+01 |
| 2.22E+03 | 4.50E+00 | 6.35E+02 | 1.15E+02 | 2.28E+00 | 2.53E+01 |
| 2.50E+03 | 4.00E+00 | 5.35E+02 | 8.72E+01 | 1.88E+00 | 2.32E+01 |
| 3.33E+03 | 3.00E+00 | 3.08E+02 | 4.40E+01 | 1.25E+00 | 1.76E+01 |
| 4.00E+03 | 2.50E+00 | 2.07E+02 | 1.99E+01 | 6.90E-01 | 1.44E+01 |

SOURCE: Reference 18

| ω (cm $^{-1}$) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------|----------------------|---------------|--------------|----------|----------|
| 3.14E+01 | 3.18E+02 | 8.62E+04 | 6.23E+05 | 5.21E+02 | 5.98E+02 |
| 3.72E+01 | 2.69E+02 | 8.74E+04 | 5.37E+05 | 4.78E+02 | 5.62E+02 |
| 4.24E+01 | 2.36E+02 | 9.47E+04 | 4.81E+05 | 4.45E+02 | 5.41E+02 |
| 5.00E+01 | 2.00E+02 | 9.18E+04 | 4.00E+05 | 3.99E+02 | 5.01E+02 |
| 6.06E+01 | 1.65E+02 | 9.87E+04 | 3.37E+05 | 3.55E+02 | 4.74E+02 |
| 6.99E+01 | 1.43E+02 | 9.60E+04 | 2.82E+05 | 3.18E+02 | 4.44E+02 |
| 8.00E+01 | 1.25E+02 | 9.97E+04 | 2.47E+05 | 2.89E+02 | 4.28E+02 |
| 9.01E+01 | 1.11E+02 | 1.00E+05 | 2.15E+05 | 2.62E+02 | 4.11E+02 |
| 1.00E+02 | 1.00E+02 | 1.06E+05 | 1.93E+05 | 2.39E+02 | 4.04E+02 |
| 1.10E+02 | 9.09E+01 | 1.03E+05 | 1.68E+05 | 2.17E+02 | 3.88E+02 |
| 1.20E+02 | 8.33E+01 | 1.04E+05 | 1.49E+05 | 1.97E+02 | 3.78E+02 |
| 1.30E+02 | 7.69E+01 | 9.72E+04 | 1.30E+05 | 1.80E+02 | 3.60E+02 |
| 1.40E+02 | 7.14E+01 | 9.66E+04 | 1.14E+05 | 1.63E+02 | 3.51E+02 |
| 1.50E+02 | 6.67E+01 | 8.51E+04 | 1.00E+05 | 1.52E+02 | 3.29E+02 |

SOURCE: Reference 1

TABLE 3. GOLD (Au) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------|----------------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 6.79E+03 | 1.35E+03 | 8.17E+00 | 8.28E+01 |
| 1.21E+03 | 8.27E+00 | 3.07E+03 | 4.12E+02 | 3.71E+00 | 5.56E+01 |
| 1.61E+03 | 6.20E+00 | 1.74E+03 | 1.78E+02 | 2.13E+00 | 4.17E+01 |
| 2.02E+03 | 4.96E+00 | 1.11E+03 | 9.29E+01 | 1.39E+00 | 3.34E+01 |
| 2.42E+03 | 4.13E+00 | 7.73E+02 | 5.51E+01 | 9.90E-01 | 2.78E+01 |
| 2.82E+03 | 3.54E+00 | 5.67E+02 | 3.57E+01 | 7.50E-01 | 2.38E+01 |
| 3.23E+03 | 3.10E+00 | 4.34E+02 | 2.46E+01 | 5.90E-01 | 2.08E+01 |
| 3.63E+03 | 2.76E+00 | 3.42E+02 | 1.74E+01 | 4.70E-01 | 1.85E+01 |
| 4.03E+03 | 2.48E+00 | 2.76E+02 | 1.30E+01 | 3.90E-01 | 1.66E+01 |
| 4.44E+03 | 2.25E+00 | 2.27E+02 | 9.95E+00 | 3.30E-01 | 1.51E+01 |
| 4.84E+03 | 2.07E+00 | 1.90E+02 | 7.72E+00 | 2.80E-01 | 1.38E+01 |
| 5.24E+03 | 1.91E+00 | 1.61E+02 | 6.09E+00 | 2.40E-01 | 1.27E+01 |
| 5.65E+03 | 1.77E+00 | 1.38E+02 | 5.17E+00 | 2.20E-01 | 1.18E+01 |
| 6.05E+03 | 1.65E+00 | 1.19E+02 | 4.15E+00 | 1.90E-01 | 1.09E+01 |
| 6.45E+03 | 1.55E+00 | 1.04E+02 | 3.68E+00 | 1.80E-01 | 1.02E+01 |
| 6.86E+03 | 1.46E+00 | 9.16E+01 | 3.06E+00 | 1.60E-01 | 9.57E+00 |
| 7.26E+03 | 1.38E+00 | 8.12E+01 | 2.70E+00 | 1.50E-01 | 9.01E+00 |
| 7.66E+03 | 1.31E+00 | 7.21E+01 | 2.38E+00 | 1.40E-01 | 8.49E+00 |
| 8.07E+03 | 1.24E+00 | 6.45E+01 | 2.09E+00 | 1.30E-01 | 8.03E+00 |
| 1.21E+04 | 8.27E-01 | 2.48E+01 | 7.97E-01 | 8.00E-02 | 4.98E+00 |
| 1.61E+04 | 6.20E-01 | 9.97E+00 | 8.22E-01 | 1.30E-01 | 3.16E+00 |

SOURCE: Reference 5

TABLE 4. LEAD (Pb)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 6.25E+00 | 1.60E+03 | 1.99E+03 | 4.43E+05 | 4.69E+02 | 4.71E+02 |
| 1.17E+01 | 8.57E+02 | 1.74E+03 | 2.21E+05 | 3.31E+02 | 3.34E+02 |
| 1.78E+01 | 5.63E+02 | 2.21E+03 | 1.64E+05 | 2.85E+02 | 2.89E+02 |
| 2.61E+01 | 3.83E+02 | 2.40E+03 | 1.17E+05 | 2.39E+02 | 2.44E+02 |
| 3.38E+01 | 2.96E+02 | 2.14E+03 | 8.49E+04 | 2.03E+02 | 2.09E+02 |
| 4.41E+01 | 2.27E+02 | 2.10E+03 | 6.44E+04 | 1.77E+02 | 1.82E+02 |
| 5.38E+01 | 1.86E+02 | 2.09E+03 | 5.27E+04 | 1.59E+02 | 1.66E+02 |
| 6.28E+01 | 1.59E+02 | 2.05E+03 | 4.47E+04 | 1.46E+02 | 1.53E+02 |
| 7.19E+01 | 1.39E+02 | 2.01E+03 | 3.87E+04 | 1.35E+02 | 1.43E+02 |
| 7.96E+01 | 1.26E+02 | 2.02E+03 | 3.50E+04 | 1.28E+02 | 1.36E+02 |
| 8.92E+01 | 1.12E+02 | 1.85E+03 | 2.98E+04 | 1.18E+02 | 1.26E+02 |
| 1.02E+02 | 9.80E+01 | 1.71E+03 | 2.51E+04 | 1.08E+02 | 1.16E+02 |
| 1.12E+02 | 8.96E+01 | 1.64E+03 | 2.24E+04 | 1.02E+02 | 1.10E+02 |
| 1.21E+02 | 8.25E+01 | 1.61E+03 | 2.05E+04 | 9.72E+01 | 1.05E+02 |

SOURCE: Reference 1

TABLE 4. LEAD (Pb) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | $-e_1$ | e_2 | n | k |
|------------------------|----------------------|----------|----------|----------|----------|
| 8.33E+02 | 1.20E+01 | 1.04E+03 | 1.99E+03 | 2.46E+01 | 4.05E+01 |
| 9.09E+02 | 1.10E+01 | 9.98E+02 | 1.82E+03 | 2.32E+01 | 3.92E+01 |
| 1.00E+03 | 1.00E+01 | 9.58E+02 | 1.57E+03 | 2.10E+01 | 3.74E+01 |
| 1.11E+03 | 9.00E+00 | 9.32E+02 | 1.34E+03 | 1.87E+01 | 3.58E+01 |
| 1.25E+03 | 8.00E+00 | 8.60E+02 | 1.10E+03 | 1.64E+01 | 3.36E+01 |
| 1.43E+03 | 7.00E+00 | 7.56E+02 | 8.71E+02 | 1.41E+01 | 3.09E+01 |
| 1.67E+03 | 6.00E+00 | 6.53E+02 | 6.58E+02 | 1.17E+01 | 2.81E+01 |
| 2.00E+03 | 5.00E+00 | 5.33E+02 | 4.48E+02 | 9.04E+00 | 2.48E+01 |
| 2.50E+03 | 4.00E+00 | 3.89E+02 | 2.74E+02 | 6.58E+00 | 2.08E+01 |
| 2.86E+03 | 3.50E+00 | 3.17E+02 | 2.01E+02 | 5.39E+00 | 1.86E+01 |
| 3.33E+03 | 3.00E+00 | 2.51E+02 | 1.40E+02 | 4.27E+00 | 1.64E+01 |
| 3.85E+03 | 2.60E+00 | 1.95E+02 | 9.94E+01 | 3.45E+00 | 1.44E+01 |
| 4.00E+03 | 2.50E+00 | 1.83E+02 | 8.95E+01 | 3.22E+00 | 1.39E+01 |
| 4.17E+03 | 2.40E+00 | 1.65E+02 | 8.00E+01 | 3.03E+00 | 1.32E+01 |
| 4.35E+03 | 2.30E+00 | 1.56E+02 | 7.27E+01 | 2.84E+00 | 1.28E+01 |
| 4.55E+03 | 2.20E+00 | 1.42E+02 | 6.42E+01 | 2.63E+00 | 1.22E+01 |
| 4.76E+03 | 2.10E+00 | 1.31E+02 | 5.78E+01 | 2.47E+00 | 1.17E+01 |
| 5.00E+03 | 2.00E+00 | 1.20E+02 | 5.20E+01 | 2.32E+00 | 1.12E+01 |
| 5.88E+03 | 1.70E+00 | 8.61E+01 | 3.58E+01 | 1.89E+00 | 9.47E+00 |
| 6.67E+03 | 1.50E+00 | 6.62E+01 | 2.72E+01 | 1.64E+00 | 8.30E+00 |
| 7.69E+03 | 1.30E+00 | 7.43E-01 | 5.19E+00 | 1.50E+00 | 1.73E+00 |
| 1.00E+04 | 1.00E+00 | 2.64E+01 | 1.47E+01 | 1.38E+00 | 5.32E+00 |
| 1.11E+04 | 9.00E-01 | 1.99E+01 | 1.31E+01 | 1.40E+00 | 4.68E+00 |
| 1.18E+04 | 8.50E-01 | 1.68E+01 | 1.25E+01 | 1.44E+00 | 4.35E+00 |
| 1.25E+04 | 8.00E-01 | 1.45E+01 | 1.23E+01 | 1.50E+00 | 4.09E+00 |
| 1.33E+04 | 7.50E-01 | 1.17E+01 | 1.21E+01 | 1.60E+00 | 3.78E+00 |
| 1.43E+04 | 7.00E-01 | 9.58E+00 | 1.27E+01 | 1.78E+00 | 3.57E+00 |
| 1.54E+04 | 6.50E-01 | 8.67E+00 | 1.34E+01 | 1.91E+00 | 3.51E+00 |
| 1.67E+04 | 6.00E-01 | 8.25E+00 | 1.32E+01 | 1.91E+00 | 3.45E+00 |
| 1.82E+04 | 5.50E-01 | 8.21E+00 | 1.24E+01 | 1.83E+00 | 3.40E+00 |
| 2.00E+04 | 5.00E-01 | 8.00E+00 | 1.12E+01 | 1.70E+00 | 3.30E+00 |
| 2.22E+04 | 4.50E-01 | 8.04E+00 | 9.16E+00 | 1.44E+00 | 3.18E+00 |

SOURCE: Reference 19

TABLE 5. SILVER (Ag)

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 1.67E+04 | 6.00E-01 | 1.54E+01 | 5.80E-01 | 7.40E-02 | 3.92E+00 |
| 1.74E+04 | 5.75E-01 | 1.39E+01 | 5.07E-01 | 6.80E-02 | 3.73E+00 |
| 1.82E+04 | 5.50E-01 | 1.20E+01 | 4.57E-01 | 6.60E-02 | 3.46E+00 |
| 1.90E+04 | 5.25E-01 | 1.08E+01 | 4.08E-01 | 6.20E-02 | 3.29E+00 |
| 2.00E+04 | 5.00E-01 | 9.30E+00 | 3.72E-01 | 6.10E-02 | 3.05E+00 |
| 2.11E+04 | 4.75E-01 | 8.01E+00 | 3.51E-01 | 6.20E-02 | 2.83E+00 |
| 2.22E+04 | 4.50E-01 | 6.81E+00 | 3.34E-01 | 6.40E-02 | 2.61E+00 |
| 2.35E+04 | 4.25E-01 | 5.19E+00 | 3.24E-01 | 7.10E-02 | 2.28E+00 |
| 2.50E+04 | 4.00E-01 | 4.16E+00 | 3.18E-01 | 7.80E-02 | 2.04E+00 |

SOURCE: Reference 34

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 3.13E+02 | 3.20E+01 | 4.44E+04 | 2.06E+04 | 4.78E+01 | 2.16E+02 |
| 3.33E+02 | 3.00E+01 | 3.98E+04 | 1.74E+04 | 4.26E+01 | 2.04E+02 |
| 3.57E+02 | 2.80E+01 | 3.55E+04 | 1.44E+04 | 3.76E+01 | 1.92E+02 |
| 3.85E+02 | 2.60E+01 | 3.10E+04 | 1.17E+04 | 3.28E+01 | 1.79E+02 |
| 4.17E+02 | 2.40E+01 | 2.71E+04 | 9.45E+03 | 2.83E+01 | 1.67E+02 |
| 4.55E+02 | 2.20E+01 | 2.31E+04 | 7.39E+03 | 2.40E+01 | 1.54E+02 |
| 5.00E+02 | 2.00E+01 | 1.95E+04 | 5.67E+03 | 2.01E+01 | 1.41E+02 |
| 5.56E+02 | 1.80E+01 | 1.59E+04 | 4.17E+03 | 1.64E+01 | 1.27E+02 |
| 6.25E+02 | 1.60E+01 | 1.28E+04 | 2.99E+03 | 1.31E+01 | 1.14E+02 |
| 7.14E+02 | 1.40E+01 | 9.90E+03 | 2.02E+03 | 1.01E+01 | 1.00E+02 |
| 8.33E+02 | 1.20E+01 | 7.34E+03 | 1.28E+03 | 7.46E+00 | 8.60E+01 |
| 1.00E+03 | 1.00E+01 | 5.14E+03 | 7.49E+02 | 5.21E+00 | 7.19E+01 |
| 1.25E+03 | 8.00E+00 | 3.32E+03 | 3.87E+02 | 3.35E+00 | 5.77E+01 |
| 1.43E+03 | 7.00E+00 | 2.55E+03 | 2.60E+02 | 2.57E+00 | 5.06E+01 |
| 1.67E+03 | 6.00E+00 | 1.88E+03 | 1.64E+02 | 1.89E+00 | 4.34E+01 |
| 2.00E+03 | 5.00E+00 | 1.31E+03 | 9.56E+01 | 1.32E+00 | 3.62E+01 |
| 2.50E+03 | 4.00E+00 | 8.34E+02 | 4.88E+01 | 8.44E-01 | 2.89E+01 |
| 3.33E+03 | 3.00E+00 | 4.71E+02 | 2.06E+01 | 4.74E-01 | 2.17E+01 |
| 5.00E+03 | 2.00E+00 | 2.10E+02 | 6.15E+00 | 2.12E-01 | 1.45E+01 |

SOURCE: Reference 7

TABLE 5. SILVER (Ag) (Continued)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 1.05E+04 | 9.50E-01 | 4.30E+01 | 1.44E+00 | 1.10E-01 | 6.56E+00 |
| 1.11E+04 | 9.00E-01 | 3.87E+01 | 1.31E+00 | 1.05E-01 | 6.22E+00 |
| 1.18E+04 | 8.50E-01 | 3.42E+01 | 1.17E+00 | 1.00E-01 | 5.85E+00 |
| 1.25E+04 | 8.00E-01 | 2.97E+01 | 9.81E-01 | 9.00E-02 | 5.45E+00 |
| 1.33E+04 | 7.50E-01 | 2.55E+01 | 8.08E-01 | 8.00E-02 | 5.05E+00 |
| 1.43E+04 | 7.00E-01 | 2.13E+01 | 6.93E-01 | 7.50E-02 | 4.62E+00 |
| 1.54E+04 | 6.50E-01 | 1.76E+01 | 5.88E-01 | 7.00E-02 | 4.20E+00 |
| 1.67E+04 | 6.00E-01 | 1.41E+01 | 4.50E-01 | 6.00E-02 | 3.75E+00 |
| 1.82E+04 | 5.50E-01 | 1.10E+01 | 3.65E-01 | 5.50E-02 | 3.32E+00 |
| 2.00E+04 | 5.00E-01 | 8.23E+00 | 2.87E-01 | 5.00E-02 | 2.87E+00 |
| 2.22E+04 | 4.50E-01 | 5.55E+00 | 2.66E+00 | 5.50E-01 | 2.42E+00 |
| 2.50E+04 | 4.00E-01 | 3.72E+00 | 2.90E-01 | 7.50E-02 | 1.93E+00 |

SOURCE: Reference 12

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 8.05E+03 | 1.79E+03 | 9.91E+00 | 9.03E+01 |
| 1.61E+03 | 6.20E+00 | 2.08E+03 | 2.60E+02 | 2.84E+00 | 4.57E+01 |
| 2.42E+03 | 4.13E+00 | 9.29E+02 | 8.60E+01 | 1.41E+00 | 3.05E+01 |
| 3.23E+03 | 3.10E+00 | 5.23E+02 | 4.17E+01 | 9.10E-01 | 2.29E+01 |
| 4.03E+03 | 2.48E+00 | 3.35E+02 | 2.45E+01 | 6.70E-01 | 1.83E+01 |
| 8.07E+03 | 1.24E+00 | 8.15E+01 | 5.06E+00 | 2.80E-01 | 9.03E+00 |
| 1.21E+04 | 8.27E-01 | 3.35E+01 | 3.13E+00 | 2.70E-01 | 5.79E+00 |
| 1.61E+04 | 6.20E-01 | 1.74E+01 | 2.26E+00 | 2.70E-01 | 4.18E+00 |

SOURCE: Reference 15

TABLE 6. COBALT (Co)

| ω (cm $^{-1}$) | λ (μ m) | $-E_1$ | E_2 | n | K |
|------------------------|----------------------|----------|----------|----------|----------|
| 5.00E+02 | 2.00E+01 | 2.44E+03 | 1.57E+03 | 1.52E+01 | 5.17E+01 |
| 5.26E+02 | 1.90E+01 | 2.18E+03 | 1.46E+03 | 1.49E+01 | 4.90E+01 |
| 5.88E+02 | 1.70E+01 | 1.84E+03 | 1.22E+03 | 1.35E+01 | 4.50E+01 |
| 6.67E+02 | 1.50E+01 | 1.51E+03 | 9.07E+02 | 1.12E+01 | 4.05E+01 |
| 7.14E+02 | 1.40E+01 | 1.34E+03 | 7.75E+02 | 1.02E+01 | 3.80E+01 |
| 8.33E+02 | 1.20E+01 | 1.12E+03 | 6.25E+02 | 9.00E+00 | 3.47E+01 |
| 9.09E+02 | 1.10E+01 | 9.97E+02 | 5.28E+02 | 8.10E+00 | 3.26E+01 |
| 1.00E+03 | 1.00E+01 | 8.20E+02 | 4.19E+02 | 7.10E+00 | 2.95E+01 |
| 1.11E+03 | 9.00E+00 | 6.97E+02 | 3.57E+02 | 6.56E+00 | 2.72E+01 |
| 1.25E+03 | 8.00E+00 | 5.42E+02 | 2.78E+02 | 5.80E+00 | 2.40E+01 |
| 1.43E+03 | 7.00E+00 | 4.08E+02 | 2.26E+02 | 5.40E+00 | 2.09E+01 |
| 1.54E+03 | 6.50E+00 | 3.45E+02 | 2.01E+02 | 5.20E+00 | 1.93E+01 |
| 1.67E+03 | 6.00E+00 | 2.81E+02 | 1.75E+02 | 5.00E+00 | 1.75E+01 |
| 1.82E+03 | 5.50E+00 | 2.40E+02 | 1.54E+02 | 4.76E+00 | 1.62E+01 |
| 2.00E+03 | 5.00E+00 | 1.94E+02 | 1.38E+02 | 4.70E+00 | 1.47E+01 |
| 2.22E+03 | 4.50E+00 | 1.36E+02 | 1.20E+02 | 4.78E+00 | 1.26E+01 |
| 2.50E+03 | 4.00E+00 | 9.89E+01 | 1.03E+02 | 4.70E+00 | 1.10E+01 |
| 3.33E+03 | 3.00E+00 | 4.78E+01 | 8.26E+01 | 4.88E+00 | 8.46E+00 |
| 4.00E+03 | 2.50E+00 | 3.48E+01 | 7.96E+01 | 5.10E+00 | 7.80E+00 |

SOURCE: Reference 20

TABLE 6. COBALT (Co) (Continued)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 5.16E+03 | 1.94E+00 | 4.57E+01 | 6.03E+01 | 3.87E+00 | 7.79E+00 |
| 6.21E+03 | 1.61E+00 | 3.97E+01 | 5.24E+01 | 3.61E+00 | 7.26E+00 |
| 7.18E+03 | 1.39E+00 | 3.41E+01 | 4.63E+01 | 3.42E+00 | 6.77E+00 |
| 8.23E+03 | 1.22E+00 | 2.98E+01 | 4.00E+01 | 3.17E+00 | 6.31E+00 |
| 9.19E+03 | 1.09E+00 | 2.59E+01 | 3.46E+01 | 2.94E+00 | 5.88E+00 |
| 1.02E+04 | 9.84E-01 | 2.25E+01 | 3.06E+01 | 2.78E+00 | 5.50E+00 |
| 1.12E+04 | 8.92E-01 | 1.96E+01 | 2.73E+01 | 2.65E+00 | 5.16E+00 |
| 1.22E+04 | 8.21E-01 | 1.74E+01 | 2.47E+01 | 2.53E+00 | 4.88E+00 |
| 1.32E+04 | 7.56E-01 | 1.58E+01 | 2.23E+01 | 2.40E+00 | 4.64E+00 |
| 1.42E+04 | 7.04E-01 | 1.45E+01 | 2.06E+01 | 2.31E+00 | 4.45E+00 |
| 1.52E+04 | 6.59E-01 | 1.32E+01 | 1.92E+01 | 2.25E+00 | 4.27E+00 |
| 1.62E+04 | 6.17E-01 | 1.21E+01 | 1.80E+01 | 2.19E+00 | 4.11E+00 |
| 1.72E+04 | 5.82E-01 | 1.11E+01 | 1.69E+01 | 2.13E+00 | 3.96E+00 |
| 1.82E+04 | 5.49E-01 | 1.04E+01 | 1.57E+01 | 2.05E+00 | 3.82E+00 |
| 1.92E+04 | 5.21E-01 | 9.66E+00 | 1.45E+01 | 1.97E+00 | 3.68E+00 |
| 2.02E+04 | 4.96E-01 | 9.07E+00 | 1.33E+01 | 1.88E+00 | 3.55E+00 |
| 2.12E+04 | 4.71E-01 | 8.35E+00 | 1.23E+01 | 1.81E+00 | 3.41E+00 |
| 2.22E+04 | 4.51E-01 | 7.73E+00 | 1.14E+01 | 1.74E+00 | 3.28E+00 |
| 2.32E+04 | 4.30E-01 | 7.26E+00 | 1.06E+01 | 1.67E+00 | 3.17E+00 |
| 2.42E+04 | 4.13E-01 | 6.71E+00 | 9.82E+00 | 1.61E+00 | 3.05E+00 |
| 2.52E+04 | 3.97E-01 | 6.12E+00 | 9.20E+00 | 1.57E+00 | 2.93E+00 |
| 2.62E+04 | 3.81E-01 | 5.61E+00 | 8.63E+00 | 1.53E+00 | 2.82E+00 |
| 2.72E+04 | 3.68E-01 | 5.09E+00 | 8.13E+00 | 1.50E+00 | 2.71E+00 |
| 2.82E+04 | 3.54E-01 | 4.59E+00 | 7.78E+00 | 1.49E+00 | 2.61E+00 |
| 2.92E+04 | 3.42E-01 | 4.16E+00 | 7.46E+00 | 1.48E+00 | 2.52E+00 |
| 3.02E+04 | 3.31E-01 | 3.82E+00 | 7.12E+00 | 1.46E+00 | 2.44E+00 |
| 3.12E+04 | 3.20E-01 | 3.51E+00 | 6.87E+00 | 1.45E+00 | 2.37E+00 |
| 3.22E+04 | 3.11E-01 | 3.26E+00 | 6.65E+00 | 1.44E+00 | 2.31E+00 |
| 3.32E+04 | 3.01E-01 | 2.99E+00 | 6.48E+00 | 1.44E+00 | 2.25E+00 |
| 3.42E+04 | 2.92E-01 | 2.72E+00 | 6.31E+00 | 1.44E+00 | 2.19E+00 |
| 3.52E+04 | 2.84E-01 | 2.51E+00 | 6.16E+00 | 1.44E+00 | 2.14E+00 |
| 3.62E+04 | 2.76E-01 | 2.29E+00 | 6.02E+00 | 1.44E+00 | 2.09E+00 |
| 3.72E+04 | 2.69E-01 | 2.09E+00 | 5.88E+00 | 1.44E+00 | 2.04E+00 |
| 3.82E+04 | 2.62E-01 | 1.97E+00 | 5.79E+00 | 1.44E+00 | 2.01E+00 |
| 3.92E+04 | 2.55E-01 | 1.78E+00 | 5.71E+00 | 1.45E+00 | 1.97E+00 |
| 4.02E+04 | 2.49E-01 | 1.62E+00 | 5.60E+00 | 1.45E+00 | 1.93E+00 |
| 4.12E+04 | 2.43E-01 | 1.52E+00 | 5.58E+00 | 1.46E+00 | 1.91E+00 |
| 4.22E+04 | 2.37E-01 | 1.41E+00 | 5.56E+00 | 1.47E+00 | 1.89E+00 |
| 4.32E+04 | 2.31E-01 | 1.34E+00 | 5.50E+00 | 1.47E+00 | 1.87E+00 |
| 4.42E+04 | 2.26E-01 | 1.36E+00 | 5.39E+00 | 1.45E+00 | 1.86E+00 |
| 4.52E+04 | 2.21E-01 | 1.38E+00 | 5.29E+00 | 1.43E+00 | 1.85E+00 |
| 4.62E+04 | 2.16E-01 | 1.40E+00 | 5.19E+00 | 1.41E+00 | 1.84E+00 |
| 4.72E+04 | 2.12E-01 | 1.41E+00 | 5.02E+00 | 1.38E+00 | 1.82E+00 |
| 4.82E+04 | 2.07E-01 | 1.32E+00 | 4.84E+00 | 1.36E+00 | 1.78E+00 |
| 4.92E+04 | 2.03E-01 | 1.32E+00 | 4.62E+00 | 1.32E+00 | 1.75E+00 |
| 5.02E+04 | 1.99E-01 | 1.26E+00 | 4.41E+00 | 1.29E+00 | 1.71E+00 |
| 5.12E+04 | 1.95E-01 | 1.20E+00 | 4.21E+00 | 1.26E+00 | 1.67E+00 |
| 5.22E+04 | 1.92E-01 | 1.19E+00 | 3.94E+00 | 1.21E+00 | 1.63E+00 |
| 5.32E+04 | 1.88E-01 | 1.18E+00 | 3.69E+00 | 1.16E+00 | 1.59E+00 |

SOURCE: Reference 21

TABLE 6. COBALT (Co) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | - ϵ 1 | ϵ 2 | n | k |
|------------------------|----------------------|----------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 1.39E+03 | 5.08E+02 | 6.71E+00 | 3.79E+01 |
| 1.05E+03 | 9.54E+00 | 9.05E+02 | 3.29E+02 | 5.38E+00 | 3.06E+01 |
| 1.21E+03 | 8.27E+00 | 6.27E+02 | 2.37E+02 | 4.66E+00 | 2.55E+01 |
| 1.61E+03 | 6.20E+00 | 3.40E+02 | 1.33E+02 | 3.55E+00 | 1.88E+01 |
| 2.02E+03 | 4.96E+00 | 1.97E+02 | 1.16E+02 | 3.98E+00 | 1.46E+01 |
| 2.42E+03 | 4.13E+00 | 1.32E+02 | 9.83E+01 | 4.04E+00 | 1.22E+01 |
| 2.82E+03 | 3.54E+00 | 9.03E+01 | 8.68E+01 | 4.18E+00 | 1.04E+01 |
| 3.23E+03 | 3.10E+00 | 6.54E+01 | 7.74E+01 | 4.24E+00 | 9.13E+00 |
| 3.63E+03 | 2.76E+00 | 4.80E+01 | 6.89E+01 | 4.24E+00 | 8.12E+00 |
| 4.03E+03 | 2.48E+00 | 3.22E+01 | 6.34E+01 | 4.41E+00 | 7.19E+00 |
| 4.84E+03 | 2.07E+00 | 1.35E+01 | 6.02E+01 | 4.91E+00 | 6.13E+00 |
| 5.65E+03 | 1.77E+00 | 6.76E+00 | 6.13E+01 | 5.24E+00 | 5.85E+00 |
| 6.45E+03 | 1.55E+00 | 7.96E+00 | 6.09E+01 | 5.17E+00 | 5.89E+00 |
| 7.26E+03 | 1.38E+00 | 1.10E+01 | 5.88E+01 | 4.94E+00 | 5.95E+00 |
| 8.07E+03 | 1.24E+00 | 1.44E+01 | 5.23E+01 | 4.46E+00 | 5.86E+00 |
| 9.68E+03 | 1.03E+00 | 1.42E+01 | 4.08E+01 | 3.81E+00 | 5.36E+00 |
| 1.21E+04 | 8.27E-01 | 1.50E+01 | 3.08E+01 | 3.10E+00 | 4.96E+00 |
| 1.61E+04 | 6.20E-01 | 1.11E+01 | 1.77E+01 | 2.21E+00 | 4.00E+00 |

SOURCE: Reference 22

TABLE 7. IRON (Fe)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 1.05E+03 | 4.24E+02 | 6.41E+00 | 3.31E+01 |
| 1.05E+03 | 9.54E+00 | 6.79E+02 | 3.36E+02 | 6.26E+00 | 2.68E+01 |
| 1.21E+03 | 8.27E+00 | 4.82E+02 | 2.86E+02 | 6.26E+00 | 2.28E+01 |
| 1.37E+03 | 7.29E+00 | 3.82E+02 | 2.58E+02 | 6.28E+00 | 2.05E+01 |
| 1.61E+03 | 6.20E+00 | 3.19E+02 | 1.34E+02 | 3.68E+00 | 1.82E+01 |
| 1.77E+03 | 5.64E+00 | 2.16E+02 | 1.48E+02 | 4.80E+00 | 1.55E+01 |
| 1.94E+03 | 5.17E+00 | 1.88E+02 | 1.45E+02 | 4.96E+00 | 1.46E+01 |
| 2.10E+03 | 4.77E+00 | 1.62E+02 | 1.36E+02 | 4.98E+00 | 1.37E+01 |
| 2.26E+03 | 4.43E+00 | 1.43E+02 | 1.23E+02 | 4.78E+00 | 1.29E+01 |
| 2.42E+03 | 4.13E+00 | 1.21E+02 | 1.17E+02 | 4.87E+00 | 1.21E+01 |
| 2.58E+03 | 3.87E+00 | 1.11E+02 | 1.09E+02 | 4.73E+00 | 1.15E+01 |
| 2.74E+03 | 3.65E+00 | 9.69E+01 | 1.03E+02 | 4.70E+00 | 1.09E+01 |
| 2.90E+03 | 3.44E+00 | 8.71E+01 | 9.77E+01 | 4.68E+00 | 1.04E+01 |
| 3.06E+03 | 3.26E+00 | 8.00E+01 | 9.32E+01 | 4.63E+00 | 1.01E+01 |
| 3.23E+03 | 3.10E+00 | 7.55E+01 | 8.62E+01 | 4.42E+00 | 9.75E+00 |
| 4.03E+03 | 2.48E+00 | 4.72E+01 | 6.64E+01 | 4.14E+00 | 8.02E+00 |
| 4.84E+03 | 2.07E+00 | 3.29E+01 | 5.46E+01 | 3.93E+00 | 6.95E+00 |
| 5.65E+03 | 1.77E+00 | 2.38E+01 | 4.66E+01 | 3.78E+00 | 6.17E+00 |
| 6.45E+03 | 1.55E+00 | 1.80E+01 | 4.09E+01 | 3.65E+00 | 5.60E+00 |
| 7.26E+03 | 1.38E+00 | 1.42E+01 | 3.63E+01 | 3.52E+00 | 5.16E+00 |
| 8.07E+03 | 1.24E+00 | 1.12E+01 | 3.29E+01 | 3.43E+00 | 4.79E+00 |
| 8.87E+03 | 1.13E+00 | 1.03E+01 | 3.08E+01 | 3.33E+00 | 4.62E+00 |
| 9.68E+03 | 1.03E+00 | 7.65E+00 | 2.76E+01 | 3.24E+00 | 4.26E+00 |
| 1.05E+04 | 9.54E-01 | 6.58E+00 | 2.57E+01 | 3.16E+00 | 4.07E+00 |
| 1.13E+04 | 8.86E-01 | 5.24E+00 | 2.41E+01 | 3.12E+00 | 3.87E+00 |
| 1.21E+04 | 8.27E-01 | 4.91E+00 | 2.30E+01 | 3.05E+00 | 3.77E+00 |
| 1.29E+04 | 7.75E-01 | 3.96E+00 | 2.16E+01 | 3.00E+00 | 3.60E+00 |
| 1.37E+04 | 7.29E-01 | 3.51E+00 | 2.10E+01 | 2.98E+00 | 3.52E+00 |
| 1.45E+04 | 6.89E-01 | 3.45E+00 | 2.02E+01 | 2.92E+00 | 3.46E+00 |
| 1.53E+04 | 6.53E-01 | 3.00E+00 | 1.95E+01 | 2.89E+00 | 3.37E+00 |
| 1.61E+04 | 6.20E-01 | 3.11E+00 | 1.92E+01 | 2.86E+00 | 3.36E+00 |

SOURCE: Reference 22

TABLE 7. IRON (Fe) (Continued)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 5.26E+02 | 1.90E+01 | 1.92E+03 | 1.09E+03 | 1.20E+01 | 4.54E+01 |
| 5.56E+02 | 1.80E+01 | 1.58E+03 | 9.52E+02 | 1.15E+01 | 4.14E+01 |
| 5.88E+02 | 1.70E+01 | 1.41E+03 | 8.70E+02 | 1.11E+01 | 3.92E+01 |
| 6.25E+02 | 1.60E+01 | 1.27E+03 | 8.04E+02 | 1.08E+01 | 3.72E+01 |
| 6.67E+02 | 1.50E+01 | 1.15E+03 | 7.62E+02 | 1.07E+01 | 3.56E+01 |
| 7.14E+02 | 1.40E+01 | 1.06E+03 | 7.18E+02 | 1.05E+01 | 3.42E+01 |
| 7.69E+02 | 1.30E+01 | 9.52E+02 | 6.63E+02 | 1.02E+01 | 3.25E+01 |
| 8.33E+02 | 1.20E+01 | 8.43E+02 | 5.47E+02 | 9.00E+00 | 3.04E+01 |
| 9.09E+02 | 1.10E+01 | 7.20E+02 | 4.48E+02 | 8.00E+00 | 2.80E+01 |
| 1.00E+03 | 1.00E+01 | 6.06E+02 | 3.58E+02 | 7.00E+00 | 2.56E+01 |
| 1.11E+03 | 9.00E+00 | 4.67E+02 | 2.98E+02 | 6.60E+00 | 2.26E+01 |
| 1.25E+03 | 8.00E+00 | 3.46E+02 | 2.56E+02 | 6.50E+00 | 1.97E+01 |
| 1.43E+03 | 7.00E+00 | 2.68E+02 | 1.94E+02 | 5.60E+00 | 1.73E+01 |
| 1.67E+03 | 6.00E+00 | 1.89E+02 | 1.35E+02 | 4.65E+00 | 1.45E+01 |
| 2.00E+03 | 5.00E+00 | 1.39E+02 | 1.04E+02 | 4.15E+00 | 1.25E+01 |
| 2.50E+03 | 4.00E+00 | 8.36E+01 | 8.10E+01 | 4.05E+00 | 1.00E+01 |
| 3.33E+03 | 3.00E+00 | 4.72E+01 | 6.16E+01 | 3.90E+00 | 7.90E+00 |
| 4.17E+03 | 2.40E+00 | 4.01E+01 | 4.37E+01 | 3.10E+00 | 7.05E+00 |
| 5.00E+03 | 2.00E+00 | 2.98E+01 | 3.97E+01 | 3.15E+00 | 6.30E+00 |
| 6.67E+03 | 1.50E+00 | 2.00E+01 | 3.02E+01 | 2.85E+00 | 5.30E+00 |
| 1.00E+04 | 1.00E+00 | 1.51E+01 | 2.08E+01 | 2.30E+00 | 4.52E+00 |

SOURCE: Reference 23

TABLE 8. NICKEL (Ni)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 2.01E+03 | 8.74E+02 | 9.54E+00 | 4.58E+01 |
| 8.87E+02 | 1.13E+01 | 1.68E+03 | 6.79E+02 | 8.12E+00 | 4.18E+01 |
| 9.03E+03 | 1.11E+00 | 1.41E+03 | 5.44E+02 | 7.11E+00 | 3.83E+01 |
| 1.05E+03 | 9.54E+00 | 1.21E+03 | 4.55E+02 | 6.44E+00 | 3.53E+01 |
| 1.13E+03 | 8.86E+00 | 1.04E+03 | 3.82E+02 | 5.83E+00 | 3.28E+01 |
| 1.21E+03 | 8.27E+00 | 9.04E+02 | 3.33E+02 | 5.45E+00 | 3.06E+01 |
| 1.29E+03 | 7.75E+00 | 7.95E+02 | 2.86E+02 | 5.00E+00 | 2.86E+01 |
| 1.37E+03 | 7.29E+00 | 6.98E+02 | 2.51E+02 | 4.68E+00 | 2.68E+01 |
| 1.45E+03 | 6.89E+00 | 6.17E+02 | 2.25E+02 | 4.45E+00 | 2.52E+01 |
| 1.53E+03 | 6.53E+00 | 5.48E+02 | 2.05E+02 | 4.30E+00 | 2.38E+01 |
| 1.61E+03 | 6.20E+00 | 4.88E+02 | 1.85E+02 | 4.12E+00 | 2.25E+01 |
| 1.69E+03 | 5.90E+00 | 4.35E+02 | 1.76E+02 | 4.13E+00 | 2.13E+01 |
| 1.77E+03 | 5.64E+00 | 3.92E+02 | 1.66E+02 | 4.11E+00 | 2.02E+01 |
| 1.86E+03 | 5.39E+00 | 3.54E+02 | 1.60E+02 | 4.14E+00 | 1.93E+01 |
| 1.94E+03 | 5.17E+00 | 3.22E+02 | 1.53E+02 | 4.16E+00 | 1.84E+01 |
| 2.02E+03 | 4.96E+00 | 2.95E+02 | 1.50E+02 | 4.25E+00 | 1.77E+01 |
| 2.10E+03 | 4.77E+00 | 2.73E+02 | 1.46E+02 | 4.29E+00 | 1.71E+01 |
| 2.18E+03 | 4.59E+00 | 2.54E+02 | 1.42E+02 | 4.30E+00 | 1.65E+01 |
| 2.26E+03 | 4.43E+00 | 2.37E+02 | 1.38E+02 | 4.30E+00 | 1.60E+01 |
| 2.34E+03 | 4.28E+00 | 2.22E+02 | 1.32E+02 | 4.26E+00 | 1.55E+01 |
| 2.42E+03 | 4.13E+00 | 2.09E+02 | 1.26E+02 | 4.19E+00 | 1.51E+01 |
| 2.66E+03 | 3.76E+00 | 1.73E+02 | 1.13E+02 | 4.10E+00 | 1.38E+01 |
| 2.82E+03 | 3.54E+00 | 1.54E+02 | 1.05E+02 | 4.03E+00 | 1.31E+01 |
| 2.98E+03 | 3.35E+00 | 1.38E+02 | 9.84E+01 | 3.97E+00 | 1.24E+01 |
| 3.15E+03 | 3.18E+00 | 1.23E+02 | 9.12E+01 | 3.88E+00 | 1.18E+01 |
| 3.23E+03 | 3.10E+00 | 1.16E+02 | 8.78E+01 | 3.84E+00 | 1.14E+01 |
| 3.63E+03 | 2.76E+00 | 8.62E+01 | 8.56E+01 | 4.20E+00 | 1.02E+01 |
| 4.03E+03 | 2.48E+00 | 7.67E+01 | 7.77E+01 | 4.03E+00 | 9.64E+00 |
| 4.44E+03 | 2.25E+00 | 6.44E+01 | 6.96E+01 | 3.90E+00 | 8.92E+00 |
| 4.84E+03 | 2.07E+00 | 5.50E+01 | 6.41E+01 | 3.84E+00 | 8.35E+00 |
| 5.24E+03 | 1.91E+00 | 4.91E+01 | 5.84E+01 | 3.69E+00 | 7.92E+00 |
| 5.65E+03 | 1.77E+00 | 4.31E+01 | 5.37E+01 | 3.59E+00 | 7.48E+00 |
| 6.05E+03 | 1.65E+00 | 3.87E+01 | 4.98E+01 | 3.49E+00 | 7.13E+00 |
| 6.45E+03 | 1.55E+00 | 3.51E+01 | 4.61E+01 | 3.38E+00 | 6.82E+00 |
| 6.86E+03 | 1.46E+00 | 3.17E+01 | 4.26E+01 | 3.27E+00 | 6.51E+00 |
| 7.26E+03 | 1.38E+00 | 2.87E+01 | 3.96E+01 | 3.18E+00 | 6.23E+00 |
| 7.66E+03 | 1.31E+00 | 2.61E+01 | 3.72E+01 | 3.11E+00 | 5.98E+00 |
| 8.07E+03 | 1.24E+00 | 2.36E+01 | 3.51E+01 | 3.06E+00 | 5.74E+00 |
| 8.47E+03 | 1.18E+00 | 2.17E+01 | 3.34E+01 | 3.01E+00 | 5.55E+00 |
| 8.87E+03 | 1.13E+00 | 2.01E+01 | 3.20E+01 | 2.97E+00 | 5.38E+00 |
| 9.28E+03 | 1.08E+00 | 1.90E+01 | 3.05E+01 | 2.91E+00 | 5.24E+00 |
| 9.68E+03 | 1.03E+00 | 1.79E+01 | 2.91E+01 | 2.85E+00 | 5.10E+00 |
| 1.01E+04 | 9.92E-01 | 1.69E+01 | 2.78E+01 | 2.80E+00 | 4.97E+00 |
| 1.05E+04 | 9.54E-01 | 1.60E+01 | 2.66E+01 | 2.74E+00 | 4.85E+00 |
| 1.09E+04 | 9.18E-01 | 1.51E+01 | 2.54E+01 | 2.69E+00 | 4.73E+00 |
| 1.13E+04 | 8.86E-01 | 1.44E+01 | 2.45E+01 | 2.65E+00 | 4.63E+00 |
| 1.17E+04 | 8.55E-01 | 1.40E+01 | 2.36E+01 | 2.59E+00 | 4.55E+00 |
| 1.21E+04 | 8.27E-01 | 1.36E+01 | 2.26E+01 | 2.53E+00 | 4.47E+00 |
| 1.25E+04 | 8.00E-01 | 1.30E+01 | 2.17E+01 | 2.48E+00 | 4.38E+00 |
| 1.29E+04 | 7.75E-01 | 1.27E+01 | 2.09E+01 | 2.43E+00 | 4.31E+00 |

SOURCE: Reference 24

TABLE 8. NICKEL (Ni) (Continued)

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 5.16E+03 | 1.94E+00 | 7.06E+01 | 6.31E+01 | 3.47E+00 | 9.09E+00 |
| 6.21E+03 | 1.61E+00 | 5.35E+01 | 5.00E+01 | 3.14E+00 | 7.96E+00 |
| 7.18E+03 | 1.39E+00 | 4.14E+01 | 4.19E+01 | 2.96E+00 | 7.08E+00 |
| 8.23E+03 | 1.22E+00 | 3.36E+01 | 3.59E+01 | 2.79E+00 | 6.43E+00 |
| 9.19E+03 | 1.09E+00 | 2.81E+01 | 3.14E+01 | 2.65E+00 | 5.93E+00 |
| 1.02E+04 | 9.84E-01 | 2.47E+01 | 2.75E+01 | 2.48E+00 | 5.55E+00 |
| 1.12E+04 | 8.92E-01 | 2.16E+01 | 2.51E+01 | 2.40E+00 | 5.23E+00 |
| 1.22E+04 | 8.21E-01 | 1.96E+01 | 2.25E+01 | 2.26E+00 | 4.97E+00 |
| 1.32E+04 | 7.56E-01 | 1.78E+01 | 2.01E+01 | 2.13E+00 | 4.73E+00 |
| 1.42E+04 | 7.04E-01 | 1.60E+01 | 1.85E+01 | 2.06E+00 | 4.50E+00 |
| 1.52E+04 | 6.59E-01 | 1.42E+01 | 1.70E+01 | 1.99E+00 | 4.26E+00 |
| 1.62E+04 | 6.17E-01 | 1.22E+01 | 1.60E+01 | 1.99E+00 | 4.02E+00 |
| 1.72E+04 | 5.82E-01 | 1.06E+01 | 1.49E+01 | 1.96E+00 | 3.80E+00 |
| 1.82E+04 | 5.49E-01 | 9.35E+00 | 1.39E+01 | 1.92E+00 | 3.61E+00 |
| 1.92E+04 | 5.21E-01 | 8.27E+00 | 1.27E+01 | 1.85E+00 | 3.42E+00 |
| 2.02E+04 | 4.96E-01 | 7.25E+00 | 1.18E+01 | 1.82E+00 | 3.25E+00 |

SOURCE: Reference 21

TABLE 9. PALLADIUM (Pd)

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 2.92E+03 | 4.47E+02 | 4.13E+00 | 5.42E+01 |
| 8.87E+02 | 1.13E+01 | 2.41E+03 | 3.79E+02 | 3.85E+00 | 4.92E+01 |
| 9.68E+02 | 1.03E+01 | 2.02E+03 | 3.25E+02 | 3.60E+00 | 4.51E+01 |
| 1.05E+03 | 9.54E+00 | 1.71E+03 | 2.79E+02 | 3.36E+00 | 4.15E+01 |
| 1.13E+03 | 8.86E+00 | 1.47E+03 | 2.55E+02 | 3.31E+00 | 3.85E+01 |
| 1.21E+03 | 8.27E+00 | 1.27E+03 | 2.24E+02 | 3.13E+00 | 3.58E+01 |
| 1.61E+03 | 6.20E+00 | 6.98E+02 | 1.63E+02 | 3.07E+00 | 2.66E+01 |
| 2.42E+03 | 4.13E+00 | 2.86E+02 | 1.23E+02 | 3.56E+00 | 1.73E+01 |
| 3.23E+03 | 3.10E+00 | 1.58E+02 | 1.13E+02 | 4.27E+00 | 1.33E+01 |
| 4.03E+03 | 2.48E+00 | 1.14E+02 | 9.38E+01 | 4.10E+00 | 1.14E+01 |
| 4.84E+03 | 2.07E+00 | 8.48E+01 | 7.57E+01 | 3.80E+00 | 9.96E+00 |
| 6.45E+03 | 1.55E+00 | 5.37E+01 | 5.40E+01 | 3.35E+00 | 8.06E+00 |
| 8.07E+03 | 1.24E+00 | 3.85E+01 | 4.12E+01 | 2.99E+00 | 6.89E+00 |
| 1.21E+04 | 8.27E-01 | 2.25E+01 | 2.27E+01 | 2.17E+00 | 5.22E+00 |
| 1.61E+04 | 6.20E-01 | 1.44E+01 | 1.46E+01 | 1.75E+00 | 4.18E+00 |

SOURCE: Reference 25

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 5.56E+02 | 1.80E+01 | 7.70E+02 | 6.84E+02 | 1.14E+01 | 3.00E+01 |
| 6.25E+02 | 1.60E+01 | 6.49E+02 | 5.69E+02 | 1.04E+01 | 2.75E+01 |
| 7.14E+02 | 1.40E+01 | 5.64E+02 | 4.74E+02 | 9.30E+00 | 2.55E+01 |
| 8.33E+02 | 1.20E+01 | 4.91E+02 | 3.67E+02 | 7.80E+00 | 2.35E+01 |
| 9.09E+02 | 1.10E+01 | 4.59E+02 | 3.11E+02 | 6.90E+00 | 2.25E+01 |
| 1.00E+03 | 1.00E+01 | 4.04E+02 | 2.56E+02 | 6.10E+00 | 2.10E+01 |
| 1.11E+03 | 9.00E+00 | 3.37E+02 | 1.84E+02 | 4.85E+00 | 1.90E+01 |
| 1.25E+03 | 8.00E+00 | 2.69E+02 | 1.53E+02 | 4.50E+00 | 1.70E+01 |
| 1.43E+03 | 7.00E+00 | 2.22E+02 | 1.33E+02 | 4.30E+00 | 1.55E+01 |
| 1.67E+03 | 6.00E+00 | 1.59E+02 | 8.32E+01 | 3.20E+00 | 1.30E+01 |
| 2.00E+03 | 5.00E+00 | 1.03E+02 | 5.67E+01 | 2.70E+00 | 1.05E+01 |
| 2.50E+03 | 4.00E+00 | 5.68E+01 | 3.45E+01 | 2.20E+00 | 7.85E+00 |
| 3.33E+03 | 3.00E+00 | 2.61E+01 | 2.58E+01 | 2.30E+00 | 5.60E+00 |

SOURCE: Reference 26

TABLE 9. PALLADIUM (Pd) (Continued)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 5.16E+03 | 1.94E+00 | 8.67E+01 | 6.61E+01 | 3.34E+00 | 9.89E+00 |
| 6.21E+03 | 1.61E+00 | 6.47E+01 | 5.17E+01 | 3.01E+00 | 8.59E+00 |
| 7.18E+03 | 1.39E+00 | 5.07E+01 | 4.28E+01 | 2.80E+00 | 7.65E+00 |
| 8.23E+03 | 1.22E+00 | 4.05E+01 | 3.67E+01 | 2.66E+00 | 6.90E+00 |
| 9.19E+03 | 1.09E+00 | 3.37E+01 | 3.19E+01 | 2.52E+00 | 6.33E+00 |
| 1.02E+04 | 9.84E-01 | 2.92E+01 | 2.76E+01 | 2.34E+00 | 5.89E+00 |
| 1.12E+04 | 8.92E-01 | 2.53E+01 | 2.45E+01 | 2.23E+00 | 5.50E+00 |
| 1.22E+04 | 8.21E-01 | 2.27E+01 | 2.14E+01 | 2.06E+00 | 5.19E+00 |
| 1.32E+04 | 7.56E-01 | 2.01E+01 | 1.91E+01 | 1.95E+00 | 4.89E+00 |
| 1.42E+04 | 7.04E-01 | 1.82E+01 | 1.73E+01 | 1.86E+00 | 4.65E+00 |
| 1.52E+04 | 6.59E-01 | 1.63E+01 | 1.59E+01 | 1.80E+00 | 4.42E+00 |
| 1.62E+04 | 6.17E-01 | 1.47E+01 | 1.47E+01 | 1.75E+00 | 4.21E+00 |
| 1.72E+04 | 5.82E-01 | 1.33E+01 | 1.35E+01 | 1.68E+00 | 4.02E+00 |
| 1.82E+04 | 5.49E-01 | 1.21E+01 | 1.26E+01 | 1.64E+00 | 3.84E+00 |
| 1.92E+04 | 5.21E-01 | 1.11E+01 | 1.16E+01 | 1.57E+00 | 3.68E+00 |
| 2.02E+04 | 4.96E-01 | 1.02E+01 | 1.08E+01 | 1.52E+00 | 3.54E+00 |
| 2.12E+04 | 4.71E-01 | 9.36E+00 | 9.90E+00 | 1.46E+00 | 3.39E+00 |
| 2.22E+04 | 4.51E-01 | 8.64E+00 | 9.19E+00 | 1.41E+00 | 3.26E+00 |
| 2.32E+04 | 4.30E-01 | 7.98E+00 | 8.60E+00 | 1.37E+00 | 3.14E+00 |
| 2.42E+04 | 4.13E-01 | 7.41E+00 | 8.06E+00 | 1.33E+00 | 3.03E+00 |
| 2.52E+04 | 3.97E-01 | 6.89E+00 | 7.62E+00 | 1.30E+00 | 2.93E+00 |
| 2.62E+04 | 3.81E-01 | 6.42E+00 | 7.13E+00 | 1.26E+00 | 2.83E+00 |
| 2.72E+04 | 3.68E-01 | 5.97E+00 | 6.80E+00 | 1.24E+00 | 2.74E+00 |
| 2.82E+04 | 3.54E-01 | 5.51E+00 | 6.52E+00 | 1.23E+00 | 2.65E+00 |
| 2.92E+04 | 3.42E-01 | 5.12E+00 | 6.27E+00 | 1.22E+00 | 2.57E+00 |
| 3.02E+04 | 3.31E-01 | 4.81E+00 | 6.00E+00 | 1.20E+00 | 2.50E+00 |
| 3.12E+04 | 3.20E-01 | 4.39E+00 | 5.86E+00 | 1.21E+00 | 2.42E+00 |
| 3.22E+04 | 3.11E-01 | 4.06E+00 | 5.69E+00 | 1.21E+00 | 2.35E+00 |
| 3.32E+04 | 3.01E-01 | 3.80E+00 | 5.50E+00 | 1.20E+00 | 2.29E+00 |
| 3.42E+04 | 2.92E-01 | 3.58E+00 | 5.26E+00 | 1.18E+00 | 2.23E+00 |
| 3.52E+04 | 2.84E-01 | 3.36E+00 | 5.14E+00 | 1.18E+00 | 2.18E+00 |
| 3.62E+04 | 2.76E-01 | 3.12E+00 | 5.07E+00 | 1.19E+00 | 2.13E+00 |
| 3.72E+04 | 2.69E-01 | 3.06E+00 | 4.87E+00 | 1.16E+00 | 2.10E+00 |
| 3.82E+04 | 2.62E-01 | 3.01E+00 | 4.68E+00 | 1.13E+00 | 2.07E+00 |
| 3.92E+04 | 2.55E-01 | 2.89E+00 | 4.51E+00 | 1.11E+00 | 2.03E+00 |
| 4.02E+04 | 2.49E-01 | 2.79E+00 | 4.30E+00 | 1.08E+00 | 1.99E+00 |
| 4.12E+04 | 2.43E-01 | 2.72E+00 | 4.06E+00 | 1.04E+00 | 1.95E+00 |
| 4.22E+04 | 2.37E-01 | 2.65E+00 | 3.82E+00 | 1.00E+00 | 1.91E+00 |
| 4.32E+04 | 2.31E-01 | 2.52E+00 | 3.61E+00 | 9.70E-01 | 1.86E+00 |
| 4.42E+04 | 2.26E-01 | 2.39E+00 | 3.40E+00 | 9.40E-01 | 1.81E+00 |
| 4.52E+04 | 2.21E-01 | 2.25E+00 | 3.24E+00 | 9.20E-01 | 1.76E+00 |
| 4.62E+04 | 2.16E-01 | 2.06E+00 | 3.09E+00 | 9.10E-01 | 1.70E+00 |
| 4.72E+04 | 2.12E-01 | 1.93E+00 | 2.94E+00 | 8.90E-01 | 1.65E+00 |
| 4.82E+04 | 2.07E-01 | 1.80E+00 | 2.78E+00 | 8.70E-01 | 1.60E+00 |

SOURCE: Reference 21

TABLE 10. PLATINUM (Pt)

| ω (cm ⁻¹) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------------|---------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 1.83E+03 | 1.18E+03 | 1.32E+01 | 4.47E+01 |
| 1.05E+03 | 9.54E+00 | 1.25E+03 | 7.28E+02 | 9.91E+00 | 3.67E+01 |
| 1.21E+03 | 8.27E+00 | 9.04E+02 | 5.10E+02 | 8.18E+00 | 3.12E+01 |
| 1.37E+03 | 7.29E+00 | 6.92E+02 | 3.68E+02 | 6.78E+00 | 2.72E+01 |
| 1.61E+03 | 6.20E+00 | 5.39E+02 | 2.83E+02 | 5.90E+00 | 2.40E+01 |
| 2.42E+03 | 4.13E+00 | 2.46E+02 | 1.27E+02 | 3.92E+00 | 1.62E+01 |
| 3.23E+03 | 3.10E+00 | 1.22E+02 | 6.40E+01 | 2.81E+00 | 1.14E+01 |
| 4.03E+03 | 2.48E+00 | 4.42E+01 | 6.03E+01 | 3.91E+00 | 7.71E+00 |
| 4.84E+03 | 2.07E+00 | 1.92E+01 | 6.93E+01 | 5.13E+00 | 6.75E+00 |
| 5.65E+03 | 1.77E+00 | 1.40E+01 | 7.80E+01 | 5.71E+00 | 6.83E+00 |
| 6.45E+03 | 1.55E+00 | 2.14E+01 | 7.48E+01 | 5.31E+00 | 7.04E+00 |
| 8.07E+03 | 1.24E+00 | 2.58E+01 | 5.63E+01 | 4.25E+00 | 6.62E+00 |
| 1.21E+04 | 8.27E-01 | 1.72E+01 | 2.96E+01 | 2.92E+00 | 5.07E+00 |
| 1.61E+04 | 6.20E-01 | 1.13E+01 | 1.87E+01 | 2.30E+00 | 4.07E+00 |

SOURCE: Reference 27

TABLE 10. PLATINUM (Pt) (Continued)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | K |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 8.06E+02 | 1.24E+01 | 1.62E+03 | 9.28E+02 | 1.11E+01 | 4.18E+01 |
| 1.20E+03 | 8.30E+00 | 8.02E+02 | 4.16E+02 | 7.12E+00 | 2.92E+01 |
| 1.61E+03 | 6.20E+00 | 4.75E+02 | 2.30E+02 | 5.14E+00 | 2.24E+01 |
| 2.42E+03 | 4.13E+00 | 2.17E+02 | 1.02E+02 | 3.39E+00 | 1.51E+01 |
| 2.82E+03 | 3.54E+00 | 1.56E+02 | 7.19E+01 | 2.81E+00 | 1.28E+01 |
| 3.23E+03 | 3.10E+00 | 1.08E+02 | 5.24E+01 | 2.45E+00 | 1.07E+01 |
| 3.62E+03 | 2.76E+00 | 6.93E+01 | 4.77E+01 | 2.72E+00 | 8.76E+00 |
| 4.03E+03 | 2.48E+00 | 4.33E+01 | 5.47E+01 | 3.64E+00 | 7.52E+00 |
| 4.44E+03 | 2.25E+00 | 3.09E+01 | 5.59E+01 | 4.06E+00 | 6.88E+00 |
| 4.83E+03 | 2.07E+00 | 2.21E+01 | 6.01E+01 | 4.58E+00 | 6.56E+00 |
| 5.24E+03 | 1.91E+00 | 1.89E+01 | 6.26E+01 | 4.82E+00 | 6.49E+00 |
| 5.65E+03 | 1.77E+00 | 1.86E+01 | 6.35E+01 | 4.88E+00 | 6.51E+00 |
| 6.06E+03 | 1.65E+00 | 2.00E+01 | 6.32E+01 | 4.81E+00 | 6.57E+00 |
| 6.45E+03 | 1.55E+00 | 2.18E+01 | 6.11E+01 | 4.64E+00 | 6.58E+00 |
| 6.85E+03 | 1.46E+00 | 2.37E+01 | 5.74E+01 | 4.38E+00 | 6.55E+00 |
| 7.25E+03 | 1.38E+00 | 2.47E+01 | 5.28E+01 | 4.10E+00 | 6.44E+00 |
| 8.06E+03 | 1.24E+00 | 2.40E+01 | 4.49E+01 | 3.67E+00 | 6.12E+00 |
| 8.85E+03 | 1.13E+00 | 2.22E+01 | 3.87E+01 | 3.35E+00 | 5.78E+00 |
| 9.71E+03 | 1.03E+00 | 2.04E+01 | 3.35E+01 | 3.07E+00 | 5.46E+00 |
| 1.05E+04 | 9.50E-01 | 1.85E+01 | 2.96E+01 | 2.86E+00 | 5.17E+00 |
| 1.12E+04 | 8.90E-01 | 1.68E+01 | 2.63E+01 | 2.68E+00 | 4.90E+00 |
| 1.20E+04 | 8.30E-01 | 1.55E+01 | 2.35E+01 | 2.52E+00 | 4.67E+00 |
| 1.30E+04 | 7.70E-01 | 1.41E+01 | 2.13E+01 | 2.39E+00 | 4.45E+00 |
| 1.37E+04 | 7.30E-01 | 1.30E+01 | 1.93E+01 | 2.27E+00 | 4.26E+00 |
| 1.45E+04 | 6.90E-01 | 1.19E+01 | 1.77E+01 | 2.17E+00 | 4.08E+00 |
| 1.49E+04 | 6.70E-01 | 1.15E+01 | 1.70E+01 | 2.12E+00 | 4.00E+00 |
| 1.54E+04 | 6.50E-01 | 1.11E+01 | 1.64E+01 | 2.09E+00 | 3.93E+00 |
| 1.56E+04 | 6.40E-01 | 1.11E+01 | 1.57E+01 | 2.02E+00 | 3.89E+00 |
| 1.61E+04 | 6.20E-01 | 1.06E+01 | 1.49E+01 | 1.96E+00 | 3.80E+00 |

SOURCE: Reference 28

TABLE 11. TITANIUM (Ti)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 5.00E+02 | 2.00E+01 | 8.43E+02 | 1.17E+03 | 1.73E+01 | 3.38E+01 |
| 5.26E+02 | 1.90E+01 | 6.85E+02 | 1.04E+03 | 1.68E+01 | 3.11E+01 |
| 5.56E+02 | 1.80E+01 | 6.54E+02 | 8.82E+02 | 1.49E+01 | 2.96E+01 |
| 5.88E+02 | 1.70E+01 | 5.96E+02 | 7.67E+02 | 1.37E+01 | 2.80E+01 |
| 6.25E+02 | 1.60E+01 | 5.65E+02 | 7.05E+02 | 1.30E+01 | 2.71E+01 |
| 6.67E+02 | 1.50E+01 | 5.11E+02 | 6.14E+02 | 1.20E+01 | 2.56E+01 |
| 7.14E+02 | 1.40E+01 | 4.74E+02 | 5.25E+02 | 1.08E+01 | 2.43E+01 |
| 8.33E+02 | 1.20E+01 | 3.36E+02 | 3.77E+02 | 9.20E+00 | 2.05E+01 |
| 9.09E+02 | 1.10E+01 | 3.24E+02 | 3.38E+02 | 8.50E+00 | 1.99E+01 |
| 1.00E+03 | 1.00E+01 | 2.81E+02 | 2.90E+02 | 7.85E+00 | 1.85E+01 |
| 1.11E+03 | 9.00E+00 | 2.22E+02 | 2.42E+02 | 7.30E+00 | 1.66E+01 |
| 1.18E+03 | 8.50E+00 | 2.11E+02 | 2.24E+02 | 6.96E+00 | 1.61E+01 |
| 1.25E+03 | 8.00E+00 | 1.76E+02 | 1.94E+02 | 6.56E+00 | 1.48E+01 |
| 1.33E+03 | 7.50E+00 | 1.53E+02 | 1.75E+02 | 6.31E+00 | 1.39E+01 |
| 1.43E+03 | 7.00E+00 | 1.38E+02 | 1.58E+02 | 5.99E+00 | 1.32E+01 |
| 1.54E+03 | 6.50E+00 | 1.17E+02 | 1.37E+02 | 5.63E+00 | 1.22E+01 |
| 1.67E+03 | 6.00E+00 | 9.87E+01 | 1.22E+02 | 5.38E+00 | 1.13E+01 |
| 1.82E+03 | 5.50E+00 | 8.04E+01 | 1.04E+02 | 5.07E+00 | 1.03E+01 |
| 2.00E+03 | 5.00E+00 | 6.06E+01 | 8.94E+01 | 4.87E+00 | 9.18E+00 |
| 2.22E+03 | 4.50E+00 | 4.32E+01 | 7.51E+01 | 4.66E+00 | 8.06E+00 |
| 2.50E+03 | 4.00E+00 | 3.11E+01 | 6.78E+01 | 4.66E+00 | 7.27E+00 |
| 2.86E+03 | 3.50E+00 | 2.25E+01 | 6.00E+01 | 4.56E+00 | 6.58E+00 |
| 3.33E+03 | 3.00E+00 | 1.31E+01 | 5.33E+01 | 4.57E+00 | 5.83E+00 |
| 4.00E+03 | 2.50E+00 | 8.17E+00 | 4.93E+01 | 4.57E+00 | 5.39E+00 |

SOURCE: Reference 20

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 8.07E+02 | 1.24E+01 | 5.21E+02 | 2.35E+02 | 5.03E+00 | 2.34E+01 |
| 9.68E+02 | 1.03E+01 | 3.76E+02 | 1.54E+02 | 3.90E+00 | 1.98E+01 |
| 1.05E+03 | 9.54E+00 | 3.20E+02 | 1.27E+02 | 3.49E+00 | 1.82E+01 |
| 1.21E+03 | 8.27E+00 | 2.38E+02 | 9.43E+01 | 3.00E+00 | 1.57E+01 |
| 1.61E+03 | 6.20E+00 | 1.24E+02 | 4.81E+01 | 2.12E+00 | 1.13E+01 |
| 1.69E+03 | 5.90E+00 | 1.08E+02 | 4.33E+01 | 2.04E+00 | 1.06E+01 |

SOURCE: Reference 29

TABLE 11. TITANIUM (Ti) (Continued)

| ω (cm $^{-1}$) | λ (μ m) | - ϵ_1 | ϵ_2 | n | k |
|------------------------|----------------------|----------------|--------------|----------|----------|
| 5.16E+03 | 1.94E+00 | 1.46E+01 | 3.64E+01 | 3.51E+00 | 5.19E+00 |
| 6.21E+03 | 1.61E+00 | 8.47E+00 | 3.47E+01 | 3.69E+00 | 4.70E+00 |
| 7.18E+03 | 1.39E+00 | 5.63E+00 | 3.21E+01 | 3.67E+00 | 4.37E+00 |
| 8.23E+03 | 1.22E+00 | 4.12E+00 | 3.00E+01 | 3.62E+00 | 4.15E+00 |
| 9.19E+03 | 1.09E+00 | 3.91E+00 | 2.81E+01 | 3.50E+00 | 4.02E+00 |
| 1.02E+04 | 9.84E-01 | 4.54E+00 | 2.66E+01 | 3.35E+00 | 3.97E+00 |
| 1.12E+04 | 8.92E-01 | 4.86E+00 | 2.61E+01 | 3.29E+00 | 3.96E+00 |
| 1.22E+04 | 8.21E-01 | 5.78E+00 | 2.57E+01 | 3.21E+00 | 4.01E+00 |

SOURCE: Reference 21

| ω (cm $^{-1}$) | λ (μ m) | - ϵ_1 | ϵ_2 | n | k |
|------------------------|----------------------|----------------|--------------|----------|----------|
| 2.50E+03 | 4.00E+00 | 3.17E+01 | 6.79E+01 | 4.65E+00 | 7.30E+00 |
| 2.86E+03 | 3.50E+00 | 2.29E+01 | 6.01E+01 | 4.55E+00 | 6.60E+00 |
| 3.33E+03 | 3.00E+00 | 1.44E+01 | 5.21E+01 | 4.45E+00 | 5.85E+00 |
| 4.00E+03 | 2.50E+00 | 8.20E+00 | 4.62E+01 | 4.40E+00 | 5.25E+00 |
| 4.17E+03 | 2.40E+00 | 9.17E+00 | 4.61E+01 | 4.35E+00 | 5.30E+00 |
| 4.35E+03 | 2.30E+00 | 6.94E+00 | 4.25E+01 | 4.25E+00 | 5.00E+00 |
| 4.55E+03 | 2.20E+00 | 7.36E+00 | 4.20E+01 | 4.20E+00 | 5.00E+00 |
| 5.00E+03 | 2.00E+00 | 7.12E+00 | 3.93E+01 | 4.05E+00 | 4.85E+00 |
| 5.56E+03 | 1.80E+00 | 4.76E+00 | 3.73E+01 | 4.05E+00 | 4.60E+00 |
| 5.88E+03 | 1.70E+00 | 5.81E+00 | 3.42E+01 | 3.80E+00 | 4.50E+00 |
| 6.25E+03 | 1.60E+00 | 5.36E+00 | 3.38E+01 | 3.80E+00 | 4.45E+00 |
| 6.45E+03 | 1.55E+00 | 6.56E+00 | 3.33E+01 | 3.70E+00 | 4.50E+00 |
| 6.67E+03 | 1.50E+00 | 4.48E+00 | 3.31E+01 | 3.80E+00 | 4.35E+00 |
| 6.90E+03 | 1.45E+00 | 4.37E+00 | 3.15E+01 | 3.70E+00 | 4.25E+00 |
| 7.14E+03 | 1.40E+00 | 5.04E+00 | 2.98E+01 | 3.55E+00 | 4.20E+00 |
| 7.41E+03 | 1.35E+00 | 3.75E+00 | 2.80E+01 | 3.50E+00 | 4.00E+00 |
| 7.69E+03 | 1.30E+00 | 4.84E+00 | 2.75E+01 | 3.40E+00 | 4.05E+00 |
| 8.00E+03 | 1.25E+00 | 8.47E+00 | 2.90E+01 | 3.30E+00 | 4.40E+00 |
| 8.33E+03 | 1.20E+00 | 5.60E+00 | 2.42E+01 | 3.10E+00 | 3.90E+00 |

SOURCE: Reference 30

TABLE 11. TITANIUM (Ti) (Continued)

| ω (cm ⁻¹) | λ (μ m) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------------|--------------|--------------|----------|----------|
| 1.00E+03 | 1.00E+01 | 2.36E+02 | 3.21E+02 | 9.01E+00 | 1.78E+01 |
| 1.05E+03 | 9.50E+00 | 2.19E+02 | 2.93E+02 | 8.56E+00 | 1.71E+01 |
| 1.11E+03 | 9.00E+00 | 2.18E+02 | 2.51E+02 | 7.56E+00 | 1.66E+01 |
| 1.18E+03 | 8.50E+00 | 2.11E+02 | 2.24E+02 | 6.96E+00 | 1.61E+01 |
| 1.25E+03 | 8.00E+00 | 1.76E+02 | 1.94E+02 | 6.56E+00 | 1.48E+01 |
| 1.33E+03 | 7.50E+00 | 1.53E+02 | 1.75E+02 | 6.31E+00 | 1.39E+01 |
| 1.43E+03 | 7.00E+00 | 1.38E+02 | 1.58E+02 | 5.99E+00 | 1.32E+01 |
| 1.54E+03 | 6.50E+00 | 1.17E+02 | 1.37E+02 | 5.63E+00 | 1.22E+01 |
| 1.67E+03 | 6.00E+00 | 9.87E+01 | 1.22E+02 | 5.38E+00 | 1.13E+01 |
| 1.82E+03 | 5.50E+00 | 8.04E+01 | 1.04E+02 | 5.07E+00 | 1.03E+01 |
| 2.00E+03 | 5.00E+00 | 6.06E+01 | 8.94E+01 | 4.87E+00 | 9.18E+00 |
| 2.22E+03 | 4.50E+00 | 4.34E+01 | 7.52E+01 | 4.66E+00 | 8.07E+00 |
| 2.50E+03 | 4.00E+00 | 3.11E+01 | 6.78E+01 | 4.66E+00 | 7.27E+00 |
| 2.86E+03 | 3.50E+00 | 2.25E+01 | 6.00E+01 | 4.56E+00 | 6.58E+00 |
| 3.33E+03 | 3.00E+00 | 1.31E+01 | 5.33E+01 | 4.57E+00 | 5.83E+00 |
| 4.00E+03 | 2.50E+00 | 8.17E+00 | 4.93E+01 | 4.57E+00 | 5.39E+00 |
| 5.00E+03 | 2.00E+00 | 4.24E+00 | 4.24E+01 | 4.38E+00 | 4.84E+00 |

SOURCE: Reference 31

TABLE 12. TUNGSTEN (W)

| ω (cm $^{-1}$) | λ (μ m) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------|----------------------|---------------|--------------|----------|----------|
| 5.00E+02 | 2.00E+01 | 4.32E+03 | 2.38E+03 | 1.75E+01 | 6.80E+01 |
| 5.26E+02 | 1.90E+01 | 3.70E+03 | 2.05E+03 | 1.63E+01 | 6.30E+01 |
| 5.56E+02 | 1.80E+01 | 3.56E+03 | 1.90E+03 | 1.54E+01 | 6.16E+01 |
| 5.88E+02 | 1.70E+01 | 3.37E+03 | 1.80E+03 | 1.50E+01 | 6.00E+01 |
| 6.25E+02 | 1.60E+01 | 3.32E+03 | 1.91E+03 | 1.60E+01 | 5.98E+01 |
| 6.67E+02 | 1.50E+01 | 3.19E+03 | 1.69E+03 | 1.45E+01 | 5.83E+01 |
| 7.14E+02 | 1.40E+01 | 2.94E+03 | 1.43E+03 | 1.28E+01 | 5.57E+01 |
| 7.69E+02 | 1.30E+01 | 2.65E+03 | 1.13E+03 | 1.07E+01 | 5.26E+01 |
| 8.33E+02 | 1.20E+01 | 2.42E+03 | 1.10E+03 | 1.09E+01 | 5.04E+01 |
| 9.09E+02 | 1.10E+01 | 2.05E+03 | 8.80E+02 | 9.50E+00 | 4.63E+01 |
| 1.00E+03 | 1.00E+01 | 1.65E+03 | 6.85E+02 | 8.25E+00 | 4.15E+01 |
| 1.05E+03 | 9.50E+00 | 1.51E+03 | 5.85E+02 | 7.40E+00 | 3.95E+01 |
| 1.11E+03 | 9.00E+00 | 1.36E+03 | 5.49E+02 | 7.30E+00 | 3.76E+01 |
| 1.18E+03 | 8.50E+00 | 1.18E+03 | 4.48E+02 | 6.40E+00 | 3.50E+01 |
| 1.21E+03 | 8.25E+00 | 1.13E+03 | 4.10E+02 | 6.00E+00 | 3.42E+01 |
| 1.25E+03 | 8.00E+00 | 1.07E+03 | 4.06E+02 | 6.10E+00 | 3.33E+01 |
| 1.29E+03 | 7.76E+00 | 1.01E+03 | 3.49E+02 | 5.40E+00 | 3.23E+01 |
| 1.33E+03 | 7.50E+00 | 9.34E+02 | 3.19E+02 | 5.15E+00 | 3.10E+01 |
| 1.38E+03 | 7.25E+00 | 8.43E+02 | 3.07E+02 | 5.20E+00 | 2.95E+01 |
| 1.43E+03 | 7.00E+00 | 7.72E+02 | 3.03E+02 | 5.35E+00 | 2.83E+01 |
| 1.48E+03 | 6.75E+00 | 6.68E+02 | 2.85E+02 | 5.40E+00 | 2.64E+01 |
| 1.54E+03 | 6.50E+00 | 5.90E+02 | 2.49E+02 | 5.03E+00 | 2.48E+01 |
| 1.60E+03 | 6.25E+00 | 5.42E+02 | 2.33E+02 | 4.90E+00 | 2.38E+01 |
| 1.67E+03 | 6.00E+00 | 4.87E+02 | 2.19E+02 | 4.85E+00 | 2.26E+01 |
| 1.74E+03 | 5.75E+00 | 5.00E+02 | 2.05E+02 | 4.50E+00 | 2.28E+01 |
| 1.82E+03 | 5.50E+00 | 4.82E+02 | 2.01E+02 | 4.48E+00 | 2.24E+01 |
| 1.90E+03 | 5.25E+00 | 4.80E+02 | 1.83E+02 | 4.11E+00 | 2.23E+01 |
| 2.00E+03 | 5.00E+00 | 4.37E+02 | 1.48E+02 | 3.48E+00 | 2.12E+01 |
| 2.11E+03 | 4.75E+00 | 3.81E+02 | 1.32E+02 | 3.33E+00 | 1.98E+01 |
| 2.22E+03 | 4.50E+00 | 3.88E+02 | 1.13E+02 | 2.85E+00 | 1.99E+01 |
| 2.27E+03 | 4.40E+00 | 3.85E+02 | 1.05E+02 | 2.65E+00 | 1.98E+01 |
| 2.38E+03 | 4.20E+00 | 3.55E+02 | 9.50E+01 | 2.50E+00 | 1.90E+01 |
| 2.44E+03 | 4.10E+00 | 3.48E+02 | 8.65E+01 | 2.30E+00 | 1.88E+01 |
| 2.50E+03 | 4.00E+00 | 3.30E+02 | 8.16E+01 | 2.23E+00 | 1.83E+01 |
| 2.56E+03 | 3.90E+00 | 3.15E+02 | 7.95E+01 | 2.22E+00 | 1.79E+01 |
| 2.70E+03 | 3.70E+00 | 2.81E+02 | 7.44E+01 | 2.20E+00 | 1.69E+01 |
| 2.78E+03 | 3.60E+00 | 2.68E+02 | 6.60E+01 | 2.00E+00 | 1.65E+01 |
| 2.94E+03 | 3.40E+00 | 2.35E+02 | 7.19E+01 | 2.32E+00 | 1.55E+01 |
| 3.03E+03 | 3.30E+00 | 2.17E+02 | 6.73E+01 | 2.26E+00 | 1.49E+01 |
| 3.13E+03 | 3.20E+00 | 2.08E+02 | 6.48E+01 | 2.22E+00 | 1.46E+01 |
| 3.23E+03 | 3.10E+00 | 1.97E+02 | 6.25E+01 | 2.20E+00 | 1.42E+01 |
| 3.33E+03 | 3.00E+00 | 1.84E+02 | 7.18E+01 | 2.60E+00 | 1.38E+01 |
| 3.45E+03 | 2.90E+00 | 1.76E+02 | 6.89E+01 | 2.55E+00 | 1.35E+01 |
| 3.57E+03 | 2.80E+00 | 1.80E+02 | 6.26E+01 | 2.30E+00 | 1.36E+01 |
| 3.70E+03 | 2.70E+00 | 1.54E+02 | 5.29E+01 | 2.10E+00 | 1.26E+01 |
| 3.85E+03 | 2.60E+00 | 1.39E+02 | 5.16E+01 | 2.15E+00 | 1.20E+01 |
| 4.00E+03 | 2.50E+00 | 1.28E+02 | 4.71E+01 | 2.05E+00 | 1.15E+01 |
| 4.17E+03 | 2.40E+00 | 1.28E+02 | 4.95E+01 | 2.15E+00 | 1.15E+01 |

SOURCE: Reference 32

TABLE 12. TUNGSTEN (W) (Continued)

| ω (cm ⁻¹) | λ (μm) | ϵ_1 | ϵ_2 | n | k |
|------------------------------|----------------|--------------|--------------|----------|----------|
| 4.35E+03 | 2.30E+00 | 9.80E+01 | 4.04E+01 | 2.00E+00 | 1.01E+01 |
| 4.55E+03 | 2.20E+00 | 8.85E+01 | 3.65E+01 | 1.90E+00 | 9.60E+00 |
| 4.76E+03 | 2.10E+00 | 7.58E+01 | 3.29E+01 | 1.85E+00 | 8.90E+00 |
| 5.00E+03 | 2.00E+00 | 6.09E+01 | 2.80E+01 | 1.75E+00 | 8.00E+00 |
| 5.26E+03 | 1.90E+00 | 4.86E+01 | 2.90E+01 | 2.00E+00 | 7.25E+00 |
| 5.56E+03 | 1.80E+00 | 4.12E+01 | 2.84E+01 | 2.10E+00 | 6.75E+00 |
| 5.71E+03 | 1.75E+00 | 3.89E+01 | 2.62E+01 | 2.00E+00 | 6.55E+00 |
| 5.88E+03 | 1.70E+00 | 3.34E+01 | 2.58E+01 | 2.10E+00 | 6.15E+00 |
| 6.02E+03 | 1.66E+00 | 3.27E+01 | 2.98E+01 | 2.40E+00 | 6.20E+00 |
| 6.25E+03 | 1.60E+00 | 3.88E+01 | 3.51E+01 | 2.60E+00 | 6.75E+00 |
| 6.45E+03 | 1.55E+00 | 2.51E+01 | 2.80E+01 | 2.50E+00 | 5.60E+00 |
| 6.67E+03 | 1.50E+00 | 2.08E+01 | 3.13E+01 | 2.90E+00 | 5.40E+00 |
| 6.90E+03 | 1.45E+00 | 1.75E+01 | 3.09E+01 | 3.00E+00 | 5.15E+00 |
| 7.14E+03 | 1.40E+00 | 1.73E+01 | 3.36E+01 | 3.20E+00 | 5.25E+00 |
| 7.41E+03 | 1.35E+00 | 1.64E+01 | 3.30E+01 | 3.20E+00 | 5.16E+00 |
| 7.69E+03 | 1.30E+00 | 1.53E+01 | 3.23E+01 | 3.20E+00 | 5.05E+00 |
| 8.33E+03 | 1.20E+00 | 1.15E+01 | 2.85E+01 | 3.10E+00 | 4.60E+00 |
| 9.09E+03 | 1.10E+00 | 9.78E+00 | 2.61E+01 | 3.01E+00 | 4.34E+00 |
| 1.00E+04 | 1.00E+00 | 3.25E+00 | 2.10E+01 | 3.00E+00 | 3.50E+00 |

TABLE 12. TUNGSTEN (W) (Continued)

| ω (cm ⁻¹) | λ (μm) | $-\epsilon_1$ | ϵ_2 | n | k |
|------------------------------|----------------|---------------|--------------|----------|----------|
| 4.84E+02 | 2.07E+01 | 5.68E+03 | 5.71E+03 | 3.45E+01 | 8.29E+01 |
| 5.65E+02 | 1.77E+01 | 4.75E+03 | 3.91E+03 | 2.65E+01 | 7.39E+01 |
| 6.45E+02 | 1.55E+01 | 3.83E+03 | 2.73E+03 | 2.09E+01 | 6.53E+01 |
| 7.26E+02 | 1.38E+01 | 3.31E+03 | 2.04E+03 | 1.70E+01 | 6.00E+01 |
| 8.07E+02 | 1.24E+01 | 2.80E+03 | 1.54E+03 | 1.41E+01 | 5.47E+01 |
| 9.68E+02 | 1.03E+01 | 2.05E+03 | 9.37E+02 | 1.01E+01 | 4.64E+01 |
| 1.13E+03 | 8.86E+00 | 1.56E+03 | 6.09E+02 | 7.58E+00 | 4.02E+01 |
| 1.29E+03 | 7.75E+00 | 1.21E+03 | 4.18E+02 | 5.92E+00 | 3.53E+01 |
| 1.61E+03 | 6.20E+00 | 7.86E+02 | 2.19E+02 | 3.87E+00 | 2.83E+01 |
| 2.42E+03 | 4.13E+00 | 3.32E+02 | 6.71E+01 | 1.83E+00 | 1.83E+01 |
| 3.23E+03 | 3.10E+00 | 1.70E+02 | 5.11E+01 | 1.94E+00 | 1.32E+01 |
| 4.03E+03 | 2.48E+00 | 1.09E+02 | 2.95E+01 | 1.40E+00 | 1.05E+01 |
| 4.84E+03 | 2.07E+00 | 6.19E+01 | 1.93E+01 | 1.21E+00 | 7.96E+00 |
| 5.65E+03 | 1.77E+00 | 3.50E+01 | 1.95E+01 | 1.59E+00 | 6.13E+00 |
| 6.45E+03 | 1.55E+00 | 1.57E+01 | 2.18E+01 | 2.36E+00 | 4.61E+00 |
| 7.26E+03 | 1.38E+00 | 1.00E+01 | 2.76E+01 | 3.11E+00 | 4.44E+00 |
| 8.07E+03 | 1.24E+00 | 8.80E+00 | 2.71E+01 | 3.14E+00 | 4.32E+00 |
| 1.21E+04 | 8.27E-01 | -4.33E+00 | 1.94E+01 | 3.48E+00 | 2.79E+00 |
| 1.61E+04 | 6.20E-01 | -4.61E+00 | 2.08E+01 | 3.60E+00 | 2.89E+00 |

SOURCE: Reference 33

TABLE 13. Optical Parameters Found using a Drude Model Fit of the Experimental Dielectric Functions for Six Metals

| | ω_f (cm ⁻¹) for fit of data in IR | ω_T (cm ⁻¹) IR fit | ω_p (cm ⁻¹) IR fit | $-\epsilon_1(0)$ $= -(\omega_p/\omega_T)^2$ | ω_T (cm ⁻¹) from dc resistivities and ω_p | ω_T (cm ⁻¹) crossover on $-\epsilon_1$, ϵ_2 plot |
|----|--|--|--|--|--|---|
| Al | 1.11×10^3 | 6.47×10^2 | 1.19×10^5 | 3.37×10^4 | 6.45×10^2 | 7.00×10^2 |
| Cu | 2.00×10^3 | 2.78×10^2 | 6.38×10^4 | 5.27×10^4 | 1.15×10^2 | 2.55×10^2 |
| Au | 8.06×10^2 | 2.16×10^2 | 7.25×10^4 | 1.13×10^5 | 1.93×10^2 | 2.16×10^2 |
| Pb | 5.00×10^1 | 1.45×10^3 | 6.20×10^4 | 1.33×10^3 | 1.35×10^3 | 1.55×10^3 |
| Ag | 1.00×10^3 | 1.45×10^2 | 7.25×10^4 | 2.50×10^5 | 1.41×10^2 | 1.52×10^2 |
| W | 8.06×10^2 | 4.33×10^2 | 4.84×10^4 | 1.25×10^4 | 2.16×10^2 | 4.30×10^2 |




Fig. 1. Aluminum: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency. The solid line is the Drude model.




Fig. 2. Copper: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency. The solid line is the Drude model.




Fig. 3. Gold: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency. The solid line is the Drude model.




Fig. 4. Lead: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency. The solid line represents the Drude model.




Fig. 5. Silver: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency. The solid line is the Drude model.




Fig. 6. Cobalt: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 7. Iron: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 8. Nickel: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 9. Palladium: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 10. Platinum: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 11. Titanium: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.




Fig. 12. Tungsten: $-\epsilon_1(\omega)$ and $\epsilon_2(\omega)$ vs frequency.
The solid line is the Drude model.

LITERATURE CITED

1. G. Brändli, and A. J. Sievers, Phys. Rev. B 5, 3550 (1972).
2. P. Drude, Theory of Optics. English edition by Longmans, Green and Co., Inc., New York, 1922. Reprinted in paperback by Dover Publications, Inc., New York, 1968.
3. F. Wooten, Optical Properties of Solids. Academic Press, New York, 1972. p. 52.
4. B. Donovan, Elementary Theory of Metals. Pergamon Press, New York, 1967. p. 220.
5. J. H. Weaver, C. Kafka, D. W. Lynch and E. E. Koch, Physics Data, Optical Properties of Metals: Part I: The Transition Metals; Part II: Noble Metals, Aluminum, Scandium, Yttrium, the Lanthanides and the Actinides. (Fachinformationszentrum, 7514 Eggenstein- Leopoldshafen 2, Karlsruhe, Federal Republic of Germany, 1981).
6. B. Dold and R. Mecke, Optik 22, 435 (1965).
7. H. E. Bennett and J. M. Bennett. Optical Properties and Electronic Structure of Metals and Alloys, edited by F. Abeles. North-Holland Publishing Co. in Amsterdam and John Wiley and Sons in New York, 1966; Section II.6, p. 175.
8. H. Ehrenreich and M. H. Cohen, Phys. Rev. 115, 786 (1959).
9. J. Babiskin and J. R. Anderson. Am. Inst. of Phys. Handbook, 2nd Edition. McGraw-Hill Book Co., New York, 1972. p. 39.
10. G. R. Parkins, W. E. Lawrence, and R. W. Christy, Phys. Rev. B 23, 6408 (1981).
11. E. Shiles, T. Sasaki, M. Ino Kuti, and D. Y. Smith, Phys. Rev. B 22, 1612 (1980).
12. L. G. Schulz. J. Opt. Soc. Am. 44, 357 and 362 (1954).
13. A. P. Lenham, and D. M. Treherne. J. Opt. Soc. Am. 56, 683 (1966).
14. P. R. Robusto and R. Braunstein, Phys. Stat. Sol. (b) 107, 443 (1981).
15. H. J. Hagemann, W. Gudat, and C. Kunz, J. Opt. Soc. Am. 65, 742 (1975).

16. G. P. Motulevich and A. A. Shubin, Soviet Phys. JETP 20, 560 (1965).
17. V. G. Padalka and I. N. Shklyarevskii, Opt. Spectry. USSR 11, 285 (1961).
18. G. A. Bolotin, A. N. Voloshinskii, M. M. Kirillova, M. M. Neskov, A. V. Sokolov, and B. A. Charikov, Phys. or Fiz? Met. and Metall. 13, 823 (1962).
19. A. I. Golovashkin and G. P. Motulevich, Soviet Phys. JETP 26, 881 (1968).
20. M. M. Kirillova and B. A. Charikov, Opt. Spectry. 17, 134 (1964).
21. P. B. Johnson and R. W. Christy, Phys. Rev. B 9, 5056 (1974).
22. J. H. Weaver, E. Colavita, D. W. Lynch and R. Rosei, Phys. Rev. B 19, 3850 (1979).
23. G. A. Bolotin, M. M. Kirillova, and V. M. Mayevskiy, Phys. Met. Metall. 27(2), 31 (1969).
24. D. W. Lynch, R. Rosei, and J. H. Weaver. Solid State Commun. 9, 2195 (1973).
25. J. H. Weaver and R. L. Benbow, Phys. Rev. B 12, 3509 (1975).
26. G. A. Bolotin, M. M. Kirillova, L. V. Nomerovannaya, and M. M. Noskov, Fiz. Metal. Metalloved. 23, 463 (1967).
27. J. H. Weaver, Phys. Rev. B 11, 1416 (1975).
28. J. H. Weaver, C. G. Olson, and D. W. Lynch, Phys. Rev. B 10, 501 (1974).
29. D. W. Lynch, C. G. Olson, and J. H. Weaver, Phys. Rev. B 11, 3617 (1975).
30. M. M. Kirillova and B. A. Charikov, Phys. Met. 15, 138 (1963).
31. G. A. Bolotin, A. N. Voloshinskii, M. M. Noskov, A. V. Sokolov and B. A. Charikov, Phys. Met. and Metall. 13, 823 (1962).
32. L. V. Nomerovannaya, M. M. Kirillova, and M. M. Noskov, Opt. Spectry. 17, 134 (1964).

33. J. H. Weaver, C. G. Olson, and D. W. Lynch, Phys. Rev.
B 12, 1293 (1975).
34. E. Kretschmann, Z. Physik 241, 313 (1971).