AFRI-SR-AK-1K-W AFRICT BEAM AND	REF	ORT DOCUMENTATION PAGE			
T. AGENCY USE ONLY <i>Leven 2001/</i> 2. REPORT S. REPOR 4. THE AND SUBTITE 6OCT 04 . FINAL. REPORT - 20. AUG 02 TO 19 AUG 04 4. THE AND SUBTITE S. FUNDING RUMBERS ADAPTIVE LENS INSPIRED BY BIO-VISUAL SYSTEMS F49620-02-1-0426 5. AUTHORIS PERFORMING ORGANIZATION NAMEES AND ADDRESSES DR YU-HWA LO . 7. PERFORMING ORGANIZATION NAMEES AND ADDRESSES REPORT BUMBER UNIVERSITY OF CALIFORNIA, SAN DIEGO REPORT BUMBER ELECTRICAL & COMPUTER ENGINEERING DEPT. SS00 GILMAN DRIVE EBU-1 ROOM 3606 (MS 6407) LA TOLLA, CA 292003-4047 JA OLD, CA 20203-4047 IN SPERSOBREGIONITIONEG ADDRESSES UNIVERSITY OF CALIFORNIA, SAN DIEGO REPORT BUMBER EBU-1 ROOM 3606 (MS 6407) LA TOLLA, CA 292003-4047 JA OLD, CA 20203-4047 IN SERVICE ADDRESSES ACOSTINL 4015 WILSON BLVD., ROOM 713 ARTINGTON, VA 22203-1954 IN SUPPLEMENTAIN NOTES TI. SUPPLEMENTAIN NOTES 2000410021 DURING the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controlable, and scalable to form lenses from 10 um to several	Public reporting burden for this collection of information is esti the collection of information. Send comments regarding this Operations and Reports. 1215 Jefferson Davis Highway, Suite	nated to average 1 hour per response, including the time for r burden estimate or any other aspect of this collection of ir 1204, Arlington, VA 22202-4302, and to the Office of Mana	eviewing instructions, sear Iformation, including sugge Igement and Budget, Papen	0517	<i>i</i> lewing mation
60CT 04 .FINAL REPORT - 20 AUG 02 TO 3 AUG 04 4. THE AND SUBTITE 6. JUNIORS NUMBERS ADAPTIVE LENS INSPIRED BY BIO-VISUAL SYSTEMS F49620-02-1-0426 F. ANTHORS FANTURE COLSPANSION NUMBERS DR YU-HWA LO FANTURE COLSPANSION NUMBERS AND ADDRESSIES UNIVERSITY OF CALIFORNIA, SAN DIDECO ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE EDU-1 ROOM 3606 (MS 6407) LA JOLIA, CA 92003-0407 ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE EDU-1 ROOM 3606 (MS 6407) LA JOLIA, CA 92003-0407 ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE EDU-1 ROOM 3606 (MS 6407) LA OLSTRET REPORT NUMBER ID SPENSORICAMONTORING ACOSR/NL 4000410009 124. INSTRET REPORT NUMBER <	1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE	3. REPOR		
A THE AND GRINTLE ADAPTIVE LENS INSPIRED BY BIO-VISUAL SYSTEMS APPROVEMENT AND ADDRESSES ADAPTIVE LENS INSPIRED BY BIO-VISUAL SYSTEMS APPROVE CALLFORNIA, SAN DIEGO ELECTRICAL & COMPUTER ENGINEERING DEPT. SSOG GILMAN DRIVE EBU-1 ROOM 3666 (MS 6407) LA JOLLA, CA 920093-0407 A SPORSONNOMMONTORING ARGENER MARESSING AFOSR/NL AOSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 TI: SUPPLEMENTARY NOTES DOTES DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TO BISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TA DISTRIBUTION CODE APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TA DISTRIBUTION ENDER AND ADDRESS PORT ADDRESS PORT ADDRESS PORT ADDRESS PORT ADDRESS APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TA DISTRIBUTION CODE APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TO STOR BOY POWER OF ADDRESS PORT ADDRESS POWER. MOST DATABALENCE, DI WAY AND ADDRESS POWER ADDRESS APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED TA BISTRACT (MSMMM 200 WOM/) DATING the DARR BOYS POWER ADDRESS POWER ADDRES		60CT 04	FINAL REPOR	RT - 20 AUG 02 TO 19 AUG 04	
ADAPTIVE LENS INSPIRED BY BIO-VISUAL SYSTEMS E-AUTHOR(S) DR YU-HWA LO PERFORMING ORGANIZATION BAMESI AND ADDRESSES UNIVERSITY OF CALIFORNIA, SAN DIEGO ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE EBU-I ROOM 3606 (MS 0407) LA JOLLA, CA 920093-0407 S-SPONSOBHIGAMONITORING AGGEVEY NAMESI AND ADDRESSES AFOSRINL 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 TI.SUPPLEMENTARY NOTES DURING AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED T3. MISTRACT Meanman 200 worded During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated function unable lenses with an exceedingly wide tuning range and strong lens power. Most tuning teams from fff = 0.70 × 100. The strong lens power and the wide tuning range and strong lens power. Most tuning from fff = 0.70 × 100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the single-chamber fuldic lens structure into multichamber lens structure into and obje were and extended profile and determine and outly device that can achieve an frommer of or and an extremently wide tuning range and strong lens power. Most tuning teams from fff = 0.70 × 100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the sing range range range the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the sing range range reader strong lens power, positive-meniscus, and negative-miniscus, reversibly. H. SUBJECT TERMS IF SECURITY CLASSIFICATION IF	4. TITLE AND SUBTITLE			5. FUNDING NUMBERS	
AUTHORISI DR YU-HWA LO T. PERFORMING DRGARZATION HAMEIST AND ADDRESSIES UNIVERSITY OF CALIFORNIA, SAN DIEGO ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE EBU-1 ROOM 3606 (MS 0407) LA JOLLA, CA 920093-0407 SPONSOBNEGMONITORING AGENCY NAMEIST AND ADDRESSIES AFOSR/NL 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 SPONSOBNEGMONITORING AGENCY NAMEIST AND ADDRESSIES AFOSR/NL 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 SUPPLEMENTARY NOTES LOUGH ACCENTRY NOTES LOUGH ACCENTRY NOTES LOUGH ACCENTRY NOTES LOUGH ACCENTRY NOTES LISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED LA DISTRIBUTION Z00 word9 During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated themerits of PDMS leastomer for lens membranes. The PDMS-based fluidic lens process has hat have been demonstrated duday can only achieve a large f-number (or weak lens power) in the order of 10 to 15. Our manbel lens is the first and only device that can achieve an f-number of 0.7 and an extremely wide tuning range from If# = 0.7 to >10. The strong lens power and the wide tuning range are founder of 0.7 and an extremely wide tuning range from If# = 0.7 to >10. The strong lens power and the wide tuning range are founder of 0.7 and an extremely wide tuning range from If# = 0.7 to >10. The strong lens power and the wide tuning range are founder of 0.7 and an extremely wide tuning range from If# = 0.7 to >10. The strong lens power and the wide tuning range are founder of 0.7 and an extremely wide tuning range from If# = 0.7 to >10. The strong lens power and the wide tuning range in focal distance, f-number, and numerical aperture, but also obtain the extreme structure can be transformed into any of the following structures: plano-conceve double-conceve, positive-meniscus, and negative-miniscus, reversibly. Is SEQUENTY CLASSIFIC	ADAPTIVE LENS INSPIRED	BY BIO-VISUAL SYSTEMS		F49620-02-1-0426	
7. PERFORMING ORGANIZATION NAMERSI AND ADDRESSIES) 8. PERFORMING ORGANIZATION NAMERSI AND ADDRESSIES) 0. UNIVERSITY OF CALIFORNIA, SAN DIEGO 8. PERFORMING ORGANIZATION ELECTRICAL & COMPUTER ENGINEERING DEPT. 9500 GILMAN DRIVE SSOU GILMAN DRIVE 10. SPONSOMICENING ARENY NAMERSI AND ADDRESSIES) AFOSR/NI. 10. SPONSOMICENING ARENY NAMERSI AND ADDRESSIES) AFOSR/NI. 10. SPONSOMICENING ARENY NAMERSI AND ADDRESSIES) AFOSR/NI. 10. SPONSOMINE ON DATA 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 11. SUPPLEMENTARY NOTES 200041021 0009 12a. DISTRIBUTION AVAILABILITY STATEMENT 12a. DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED 12a. DISTRIBUTION CODE 13. ARSTRACT Monimum 200 wordd/ 12a. DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED 12a. DISTRIBUTION CODE 14. ARSTRACT Monimum 200 wordd/ 12a. DISTRIBUTION AVAILABILITY STATEMENT 15. NUMBER 2000 ADDIS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lens is the first and only device	6. AUTHOR(S) DR YU-HWA LO				
LA JOLLA, CA 222003-0407 Its. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESSIES) AFOSR/NL 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 Its. SUPPLEMENTARY NOTES 2000410210009 200040021009 12a. DISTRIBUTION AVAILABILITY STATEMENT Its. DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED Its. DISTRIBUTION CODE 13. ABSTRACT Maximum 200 words/ Its. DISTRIBUTION CODE During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 um to several centimeters in diameter. (b) Whave demonstrated fluidic tunable lenss with an exceedingly wide tuning range and strong lens power. Most tunable lens that have been demonstrated today can only achieve a large f-number of 0.7 and an extremely wide tuning range from t## = 0.7 to > 100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the single-chamber fluic lens structure: plano-convex, plano-concave double-convex, double-concave, positive-meniscus, and negative-miniscus, reversibly. 14. SUBJECT TERMS 15. NUMBER OF PAGES 17. SEQURITY CLASSIFICATION 18. SEQURITY CLASSIFICATION 20. LIMITATION OF ABSTRACT	7. PERFORMING ORGANIZATION NAME(S UNIVERSITY OF CALIFORN ELECTRICAL & COMPUTER 9500 GILMAN DRIVE EBU-1 ROOM 3606 (MS 0407) AND ADDRESS(ES) IIA, SAN DIEGO R ENGINEERING DEPT.)		8. PERFORMING ORGANIZATION REPORT NUMBER	
AFOSR/NL 4015 WILSON BLVD., ROOM 713 ARLINGTON, VA 22203-1954 11. SUPPLEMENTARY NOTES 20041021 009 12. DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE:DISTRIBUTION UNLIMITED 13. ASSTRACT (Maximum 200 works) During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 um to several centimeters in diameter. (b) We have demonstrated fluidic tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lenses that have been demonstrated today can only achieve a large f-number (or weak lens power) in the order of 10 to 15. Our tunable lens is the first and only device that can achieve an f-number (or weak lens power) in the order of 10 to 15. Our tunable lens. (c) We have successfully extended the single-chamber fluidic lens structure into multi-chamber lens structures. As a result, one can not only achieve a wide tuning range in focal distance, f-number, and numerical aperture, but also obtain the extreme structure can be transformed into any of the following structures: plano-convex, plano-concave double-convex, double-concave, positive-meniscus, and negative-miniscus, reversibly. 14. SUBJECT TERMS 15. NUMBER OF PAGES 16. PRICE CODE 17. SECURITY CLASSIFICATION 0F ABSTRACT 18. SECURITY CLASSIFICATION 18. SECURITY CLASSIFICATION 0F ABSTRACT	LA JOLLA, CA 920093-0407 9. Sponsoring/Monitoring Agency N	AME(S) AND ADDRESS(ES)		10. SPONSORING/MONITORING	
20041021 009 12a. DISTRIBUTION AVAILABILITY STATEMENT APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED 12b. DISTRIBUTION CODE 13. ABSTRACT Maximum 200 words/ During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 unt to several centimeters in diameter. (b) We have been demonstrated fluidic unable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lenses that have been demonstrated today can only achieve a large f-number (or weak lens power) in the order of 10 to 15. Our tunable lens is the first and only device that can achieve an f-number of 0.7 and an extremely wide tuning range from f# = 0.7 to >100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the single-chamber fluidic lens structure into multi-chamber lens structures. As a result, one can not only achieve a wide tuning range in focal distance, f-number, on numerical aperture, but also obtain the extreme structure can be transformed into any of the following structures: plano-convex, plano-concave double-concave, positive-meniscus, and negative-miniscus, reversibly. 14. SUBJECT TERMS 15. NUMBER OF PAGES 16. NUMBER OF PAGES 17. SECURITY CLASSIFICATION OF ABSTRACT	AFOSR/NL 4015 WILSON BLVD., ROOM ARLINGTON, VA 22203-195	1 713 4	_		
12.2. DISTRIBUTION AVALABILITY STATEMENT 12.1. DISTRIBUTION CODE APPROVE FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED 13. ABSTRACT (Maximum 200 words) During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 um to several centimeters in diameter. (b) We have demonstrated fluidic tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lens is the first and only device that can achieve an f-number of 0.7 and an extremely wide tuning range from f# = 0.7 to > 100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the single-chamber fluidic lens structure into multi-chamber lens structures. As a result, one can not only achieve a wide tuning range in focal distance, f-number, and numerical aperture, but also obtain the extreme structure can be transformed into any of the following structures: plano-concave double-convex, double-concave, positive-meniscus, and negative-miniscus, reversibly. 14. SUBJECT TERMS 15. NUMBER OF PAGES 14. SUBJECT TERMS 15. NUMBER OF PAGES 15. NUMBER OF PAGES 16. PRICE CODE		1711 7	_ 20041()21 009	
13. ABSTRACT (Maximum 200 words) During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas: (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 um to several centimeters in diameter. (b) We have demonstrated fluidic tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lense to day can only achieve a large f-number (or weak lens power) in the order of 10 to 15. Our tunable lens is the first and only device that can achieve an f-number of 0.7 and an extremely wide tuning range from ff# = 0.7 to > 100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems. (c) We have successfully extended the single-chamber fluidic lens structure into multi-chamber lens structures. As a result, one can not only achieve a wide tuning range in focal distance, f-number, and numerical aperture, but also obtain the extreme structure can be transformed into any of the following structures: plano-convex, plano-concave double-convex, double-concave, positive-meniscus, and negative-miniscus, reversibly. 14. SUBJECT TERMS 15. NUMBER OF PAGES 17. SECURITY CLASSIFICATION 18. SECURITY CLASSIFICATION 0F REPORT 18. SECURITY CLASSIFICATION 0F THIS PAGE 19. SECURITY CLASSIFICATION 0F ABSTRACT 20. LIMITATION OF ABSTRACT	APPROVE FOR PUBLIC REL	EASE: DISTRIBUTION UNL	IMITED		
14. SUBJECT TERMS 15. NUMBER OF PAGES 16. PRICE CODE 16. PRICE CODE 17. SECURITY CLASSIFICATION 19. SECURITY CLASSIFICATION 0F REPORT 0F THIS PAGE	13. ABSTRACT (Maximum 200 words) During the DARPA BOSS I pre- identified and demonstrated the been proven to be simple, contri- have demonstrated fluidic tunal that have been demonstrated too tunable lens is the first and only 0.7 to >100. The strong lens imaging systems. (c) We have structures. As a result, one can but also obtain the extreme stru- double-convex, double-concave	ogram, the UCSD team has ma merits of PDMS elastomer fo collable, and scalable to form l ole lenses with an exceedingly day can only achieve a large f- v device that can achieve an f- power and the wide tuning ran successfully extended the sing a not only achieve a wide tunin cture can be transformed into c, positive-meniscus, and negative	ade substantial progress ir r lens membranes. The F lenses from 10 um to seve wide tuning range and str number (or weak lens po number of 0.7 and an extr age are the keys to many s le-chamber fluidic lens st ng range in focal distance, any of the following struc- tive-miniscus, reversibly.	the following areas: (a) We have PDMS-based fluidic lens process heral centimeters in diameter. (b) V rong lens power. Most tunable len wer)in the order of 10 to 15. Our remely wide tuning range from f# superior and unique functions of ructure into multi-chamber lens , f-number, and numerical apertur ctures: plano-convex, plano-conca	e las We lises = e, ve,
17. SECURITY CLASSIFICATION 18. SECURITY CLASSIFICATION 19. SECURITY CLASSIFICATION 20. LIMITATION OF ABSTRACT 17. SECURITY CLASSIFICATION 0F THIS PAGE 0F ABSTRACT 20. LIMITATION OF ABSTRACT	14. SUBJECT TERMS			15. NUMBER OF PAGES	
17. SECURITY CLASSIFICATION 18. SECURITY CLASSIFICATION 19. SECURITY CLASSIFICATION 20. LIMITATION OF ABSTRACT 0F REPORT 0F THIS PAGE 0F ABSTRACT 20. LIMITATION OF ABSTRACT				16. PRICE CODE	•••
	17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATION OF ABSTRACT	20. LIMITATION OF ABSTR	AC

BEST AVAILABLE COPY

.

د **ا**

Standard Form 298 (Rev. 2-89) (EG) Prescribed by ANSI Std. 239.18 Designed using Perform Pro, WHS/DIOR, Oct 94

FINAL REPORT

Project Title: Adaptive Lens Inspired by Bio-Visual Systems

Award No. F49620-02-1-0426

P.I.: Yuhwa Lo <u>ylo@ece.ucsd.edu</u> Tel: 858-822-3429 Fax: 858-534-0556

1. Projective Objectives

The objectives of our BOSS I research are

- (a) to identify and demonstrate designs and technologies that can meet the performance requirements for bio-inspired adaptive lenses,
- (b) to fabricate and evaluate device prototypes,
- (c) to identify potential issues and technological challenges that may become road blocks for real military and civilian applications,
- (d) to advance the science and technology of bio-inspired adaptive optics which has the potential to create a paradigm shift in the field of optics.

2. Summary of the Accomplishments

During the DARPA BOSS I program, the UCSD team has made substantial progress in the following areas:

- (a) We have identified and demonstrated the merits of PDMS elastomer for lens membranes. The PDMS-based fluidic lens process has been proven to be simple, controllable, and scalable to form lenses from 10 μ m to several centimeters in diameter.
- (b) We have demonstrated fluidic tunable lenses with an exceedingly wide tuning range and strong lens power. Most tunable lenses that have been demonstrated today can only achieve a large f-number (or weak lens power) in the order of 10 to 15. Our tunable lens is the first and only device that can achieve an f-number of 0.7 and an extremely wide tuning range from f# = 0.7 to >100. The strong lens power and the wide tuning range are the keys to many superior and unique functions of imaging systems.
- (c) We have successfully extended the single-chamber fluidic lens structure into multichamber lens structures. As a result, one can not only achieve a wide tuning range in focal distance, f-number, and numerical aperture, but also obtain the extreme flexibility in the form of lens types. We have demonstrated that the same lens structure can be transformed into any of the following structures: plano-convex, plano-concave, double-convex, double-concave, positive-meniscus, and negativemeniscus, reversibly.

- (d) Following the same course of development, we also demonstrated, for the first time, an integrated zoom lens without mechanical moving parts. The device consists of two back-to-back tunable lenses separated by a spacer of a few millimeters in thickness. The two lenses and the spacer substrate are all bonded together during the wafer process, which suggests that the zoom lens can be fabricated using standard microfabrication process like integrated circuits. To achieve the zooming function, the focal distances of both lenses are adjusted. There is no need for changing the distance between the lenses, leading to a more compact design and a structure suitable for integration and miniaturization.
- (e) Due to the combined features of strong lens power, lens type convertibility, and extremely wide tunability, we have demonstrated the unique feature of combining a telephoto system and a reverse telephoto (also known as wide-angle) system in one. This leads to a continuous tuning angle of field-of-view from 7 degrees to 65 degrees.

3. Detailed Technical Discussion

3.1. Basic fluidic lens process and characteristics

Figure 1 shows the basic process of forming fluidic adaptive lenses. We used micromolding technique and plasma-assisted bonding process to form lens chamber and lens membrane. A Si mold master was formed using standard microfabrication and MEMS process. After surface treatment of the Si mold to facilitate demolding, PDMS was deposited to the Si mold. The body of the lens chamber was formed after separating the PDMS material from the Si mold master. To form the lens membrane, another layer of PDMS film was deposited to a Si handle wafer. After oxygen plasma activation of the PDMS surfaces, the PDMS membrane was covalently bonded to the PDMS lens chamber. The lens body was formed after removing the bonded PDMS structure from the Si handle wafer, as shown in Fig. 1(d). The thickness of the PDMS membrane is typically 30 to 100 μ m. The bonded PDMS structure has good quality and uniformity. No fluidic leakage or film delamination was observed for the bonded structure.



Figure 1. Process flow for tunable fluidic lenses.

Figure 2 shows the basic focal length tuning characteristics of fluidic lenses with two different media: DI water (n = 1.33) and sodium chromate (n = 1.50). The lens aperture is 20 mm and the shortest focal distance achieved in this design is 14mm with sodium chromate as the medium. Experiment on lenses of similar design but with different dimensions establishes the rule of thumb that the shortest focal distance is about 70% of the lens aperture. This is, to our knowledge, the widest focal distance tuning range and the shortest focal distance, ever been demonstrated for any types of adaptive lenses. The data of numerical aperture and field of view are shown in Figures 3,4. The numbers are close to the characteristics of fish eyes.



Figure 2. Dependence of focal distance on the fluidic pressure for a 20 mm diameter adaptive plano-convex lens. The data show the measured results for two different lens media, water (n=1.33) and sodium chromate (n=1.55).



Figure 3. Tuning characteristics of numerical aperture (NA) with fluidic pressure for lenses having different membrane thickness.

Besides wide tunability, the lenses need to produce high quality image. Figures 4,5 show the measurements of image resolution using the USAF standard. The measurement was performed at a fixed image distance of 635 mm using a He/Ne laser as the light source. In all lens structures we have investigated, the resolution is greater than 40 line pairs per millimeter (lp/mm), which is comparable to solid-state lenses made of glass and quartz and significantly better than molded plastic lenses. The values of resolution were chosen at a modulation transfer function (MTF) value of 0.5.



Figure 4. Image resolution for plano-convex (a) and biconvex (b) lenses.



Figure 5. Picture of resolution measurement using negative USAF standard on a 20 mm fluidic lens at 43 mm focal distance.

The rapid reduction of the image resolution at low fluidic pressure (or long focal distance) was partly attributed to the reduction of the magnification factor and the resolution limit of the CCD camera. However, we should also point out that part of the reduced resolution could be due to the asymmetric lens shape caused by the gravity of he lens medium. This speculation was supported by the findings that the resolution reduction effect tends to be more pronounced for lenses of larger aperture size and thinner membrane. One way to minimize the effect would be increasing the membrane

thickness with the aperture of the lens. Another way, which is more effective although at the expense of the power consumption of the fluid pump, is to introduce a built-in tensile stress in the elastomer membrane. When the built-in tensile stress is significantly greater than the pressure due to the gravity of the fluid, the shape distortion caused by the gravity effect is negligible.



Figure 6. Photograph for image distortion measurement on a 60 μ m membrane adaptive lens. The dot diameter is 1.00 mm and the center-to-center spacing between dots is 2.00 mm in the grid distortion target.

Figure 6 shows the measurement of image distortion caused by spherical aberration. The standard target pattern has a dot diameter of 1 mm and a dot-to-dot spacing of 2 mm. The photograph was taken when the lens was tuned to a focal distance of 40 mm. Similar image quality was obtained over a wide range of focal distance, suggesting that the image distortion does not impose serious problems on image quality. The photograph (Fig. 6) was achieved with a lens of a uniform membrane thickness. It was found that by using a membrane of specially designed thickness profile, the spherical aberration of the lens can be reduced. However, the control of the thickness profile is technologically challenging and the optimal thickness profile changes with lens aperture and lens medium, making the approach hard to apply in real optical systems. Since one can always use aspherical lenses of fixed properties to eliminate most of spherical aberration, we intend to use a uniform lens membrane to construct optical systems for most of our research.

3.2. Lens type versatility

We have extended the design of simple lenses to more complicated lens structures. One of such examples is the lens with 2 fluidic chambers with valves so the chamber pressure can be controlled separately. A typical structure of such double-chamber lens and the fluidic and electronic control circuits are shown in Fig. 7. The most salient feature of such double-chamber lens is that not only the lens properties but also the lens type can be tuned. By controlling the pressure of each lens chamber, the value of which can be positive or negative relative to the ambient, one can achieve any of the following lens types: plano-convex, plano-concave, biconvex, biconcave, positive meniscus, negative meniscus. Figure 8 shows one example how different lens types can be obtained via control of the pressure of the lens chambers.



Figure 7. Diagram of the double-chamber fluidic lens and the peripheral control circuit. Depending on the sign and magnitude of the pressure in each chamber, the same lens can be made into different lens types.



Figure 8. Demonstration of lens type convertibility among biconvex, meniscus, plano-convex, and plano-concave lenses.

Such extreme versatility is beyond what has been demonstrated by any other types of adaptive lenses and may have significant impact on optics industry. For one thing, one can use one standard double-chamber fluidic lens to replace myriad types of lenses fabricated for specific applications, thus cutting down the inventory and production cost tremendously. For another thing, one can functionally integrate optic systems of very different or even opposite functions into one system. We will discuss the latter point in more detail next.

3.3. Integrated single-chip zoom lens

Zoom lenses are perhaps the most desirable but technologically challenging devices for any miniature imaging systems. The ability of fast zooming and high zoom ratio is critical to target recognition, motion detection, and tracking. A typical imaging system needs a zoom ratio of 3-6, and some special systems may require a zoom ratio greater than 10 or even as high as 30. In current systems, zooming is achieved by varying the distance between two lenses. An apparent drawback of such design is the requirement of large range (several millimeters or centimeters) mechanical motion, which makes zoom lens systems clumsy, expensive, and difficult to integrate into an array form. Here we devised a different zoom lens using the tunable properties of the lenses. The zoom lens consists of two back-to-back tunable fluidic lenses, separated by a substrate spacer. The lenses and the substrate spacer are bonded together using the plasma-activated bonding process, so the process is done in wafer scale and zoom lens arrays can be fabricated. Analysis shows that the zoom ratio can be represented as a function of image distance, object distance, focal distances of the front (object side) and back (image side) lenses, and the lens spacing. For all practical applications, we can assume that the object distance approaches infinity. Then the changeable parameters are image distance, lens spacing, and the focal lengths. Instead of physically changing the image distance and lens spacing as people do with conventional zoom lenses, we can achieve the same zooming effect by varying the focal distances of the front and the back lenses. The zoom ratio can be approximated as

$$ZR = 1 + d/i + d/[fm]$$
(1)

The second term in Eq. (1) is the ratio of the lens spacing, d, and the image distance, i, defined as the physical distance between the image plane and the plane of the rear lens. The third term in Eq. (1) is the additional contribution from the lens type versatility, where |fin| is the minimal magnitude of the focal distance the lens can achieve as a concave lens. Without the flexibility in lens type, the third term vanishes and the achievable zoom ratio is reduced. For a design of 5 mm image distance, 6 mm lens spacing and a minimal magnitude of the focal distance of 4 mm, we can achieve a zoom ratio of 3.7, which is compared favorably to optical zoom lenses in digital cameras. Should high index fluid is used to replace DI water as the lens medium, a zoom ratio greater than 5 can be readily achieved. The detailed analysis of the design and projected performance of fluidic zoom lens is shown in the Appendix.



Figure 9. Demonstration of the zooming effect of an integrated fluidic zoom lens. Zooming was achieved without changing the spacing between lenses.

Figure 9 shows the photograph of the test setup for "integrated fluidic zoom lens". The zoom lens is mounted on a holder and connected to the external fluidic control circuit. The fluidic control circuit, including valves, pumps, and sensors, can be integrated with the zoom lens into a compact module although they are discrete components in the

current setup. Figure 10 shows an example of the zooming function for the integrated zoom lens. Due to a more conservative design, a zoom ratio of 1.5 was demonstrated on this device. An improved lens design using similar fabrication process produces a much higher zoom ratio, as shown in Figure 11 and Table 1.



Figure 10. Photograph of the test setup for integrated fluidic zoom lens.



Figure 11. Image of an 4x7 LED array obtained by a tunable fluidic zoom lens. The yellow bars at the bottom of each photo are of the same length, so the size of the image represents the (de)magnification achieved by zooming.

Object (mm)	Image (mm)	Zoom Ratio
250	50	3.05
250	30	4.18
1000	50	3.58
1000	30	4.44

Table 1. Zoom ratios demonstrated by an integrated fluidic zoom lens at different image distances.

3.4 Integration of telephoto and reverse telephoto system: tunable FoV

Besides zooming, tunable field-of-view is another important feature for surveillance cameras. Achieving a wide range of field of view has been one of the main project goals for DARPA BOSS initiative, as depicted in the original BAA. The UCSD team has tried to develop a zoom lens system with a widest tuning range in field-of-view. As a result of technology and design optimization, we have demonstrated a zoom lens system with a tunable field-of-view from 7-degrees to 65-degrees.

To formally characterize the field-of-view, we use the established criteria in photography for telephoto systems and reverse telephoto (wide-angle) systems. The definition of a telephoto system is that its "effective focal length (EFL)" is greater than the "overall physical length (OAL)", measured from the first surface of the lens to the image plane (i.e. EFL/OAL >1). On the other hand, the definition of a reverse telephoto (wide angle) system is that the "back focal length (BFL)" is larger than the "effective focal length (EFL)" or BFL/EFL > 1. Under these formal criteria, many of the so-called telephoto cameras in the commercial market are not really telephoto systems. Furthermore, to our best knowledge, there are no commercial cameras that can work both as a telephoto camera and as a wide-angle (fish-eye) camera without physically replacing the lens set. In contrast, figure 12 shows that, because of the extremely wide tuning range and lens type convertibility, the zoom lens system made of our tunable lenses can function as a telephoto system and as a reverse telephoto system using the same set of optics, a feat that has never been demonstrated before!



Figure 12. Demonstration of a tunable zoom lens with a wide field-of-view (from 7 degrees to 65 degrees) that can be used as a telephoto system and a reverse telephoto (wide-angle) system.

As indicated by the yellow dots in Fig. 12, when the effective focal length becomes shorter than 55mm (for 20mm aperture), the condition of BFL/EFL > 1 is satisfied and the system functions as a true reverse telephoto system. At the minimal EFL of 20 mm, the BFL/EFL ratio rises to 1.5 and the widest field-of-view of 65 degrees (as indicated in the "red stars" in Fig. 12) is achieved. Following the trace of the "black triangles", we find that OAL/EFL < 1 when the effective focal length is longer than 80mm, making the system a true telephoto system. At the longest achievable effective focal distance of 120 mm, a minimal ratio of 0.5 is achieved, corresponding to a field-of-view of 7 degrees. Therefore, we have demonstrated that the tunable lenses allow us to construct a system that can be continuously tuned between a telephoto system and a reverse telephoto system.

4. Discussions

Our research in the BOSS I program has been extremely productive and exciting. As summarized in the previous sessions, many ground breaking results and technology breakthroughs were made. As a result of our research, the state of the art of tunable

11

lenses has been advanced significantly. On the other hand, equally important to the technical community are many lesions and issues learned in the course of our research endeavor. These lessons and issues, as to be discussed next, provide insight and direction for our future research.

- (a) We have found that the high permeability of the PDMS lens membrane could lead to loss of fluid by evaporation. To avoid this problem, one should choose other elastomer including different types of PDMS and perhaps more importantly, choose lens fluid of low vapor pressure. We have found different kinds of oil (e.g. lubrication oil) with essentially zero vapor pressure and adequate transparency, index of refraction, and viscosity. One remaining issue for applying such fluid to the lens is its compatibility with the membrane material.
- (b) From the photograph of the lens setup in Fig. 10, it becomes obvious that although the zoom lens is compact and can be made using microfabrication process, the control circuit including the fluidic pumps, tubing, connectors, pressure sensors, valves, etc. takes a much larger space than the lenses themselves. To apply the technology to real systems, we need to fabricate the entire fluidic control circuit in a space comparable to the lenses and using microfabrication techniques. Fortunately, there has been significant progress made in microfluidics and bioMEMS that shed light on the integration of these fluidic devices with the lenses.
- (c) For high performance imaging systems made of solid lenses, all lens surfaces are antireflecting (AR) coated. Experimental and simulation results show that with multiple reflections at different lens surfaces, the MTF value could be reduced by as much as 30%, yielding a significant penalty in image resolution. However, it is nontrivial to perform AR coating to the outer and inner surfaces of the membrane since the shape of the membrane varies during operation. Conventional ceramic AR coating for solid lenses is not applicable here, and new coating techniques have to be developed. Two promising techniques for AR coating are polymer coating invented by the MIT group and the moss eye patterns. Detailed evaluation of both techniques will be performed in collaboration with the MIT group and the RSC group in the BOSS II program.
- (d) Concerning the lens characterization, we have so far only investigated the shapeinduced aberration. The effect of chromatic dispersion caused by the membrane and the lens medium has not been studied. To compensate for chromatic dispersion, we believe the most effective way might be using diffractive optics, which typically requires a less number of elements than refractive optics. It would be worthwhile to investigate how diffractive lenses can be incorporated into the refractive fluid lenses using molding process.

5. Publications and Patents

Patent Disclosure

1. "Fluidic Adaptive Eye Correction Lenses and Zoom Lens" D. Y. Zhang and Yu-Hwa Lo, provisional patent was filed in March 30, 2004.

Journal Papers

- D. Y. Zhang, V. Lien, Y. Berdichevsky, J. Choi, and Y. H. Lo, "fluidic adaptive lens with high focal length tunability", Applied Physics Letters, vol. 82, no. 19, 3171-2 (2003)
- 2. Zhang DY. Justis N. Lien V. Berdichevsky Y. Lo YH. "High-performance fluidic adaptive lenses," Applied Optics. 43(4): pp. 783-787, 2004 Feb 1.
- 3. Zhang D, Justis N, Lo YH. "Fluidic Adaptive lens of transformable lens type," Applied Physics Letters, vol. 84, no. 21, May 24, 2004, pp. 4194-4196.
- 4. De-Ying Zhang, Nicole Justis, Yu-Hwa Lo, "Fluidic Zoom-Lens-System-on-a-Chip with Wide Field-of-View Tuning Range," accepted for publication in IEEE Photonics Technology Letters.
- 5. Zhang D, Justis N, Lo YH. "<u>Integrated fluidic adaptive zoom lens</u>", accepted for publication in Optics Letters.

Deleted: Bio-inspired
Deleted: Compact

Refereed Conference Papers

- 1. D. Y. Zhang, N. Justis, and Y. H. Lo, "Versatile lens type tunability in fluidic adaptive lens", IEEE LEOS Conference Proceedings, Tucson, Arizona, October 2003.
- 2. D. Y. Zhang and Y. H. Lo, "Focal length tunable fluidic adaptive lens", CLEO Conference Proceedings, Baltimore, Maryland, 1-5 June 2003.
- 3. D. Y. Zhang, N. Justis, and Y. H. Lo, "Fluidic zoom lens without lens motion", Submitted to 2004 CLEO Conference.
- N. Justis, D. Y. Zhang, Y. Berdichevsky, and Y. H. Lo, "Thin film modification for bio-inspired dynamic microfluidic lenses," MRS Proceedings, Boston, MA, November, 2003.
- 5. D. Y. Zhang, N. Justis, and Y. H. Lo, "Fluidic adaptive zoom lens without lens motion," CLEO 2004 Proceedings, May 16-21, 2004, San Francisco, CA.

6. Technology Transfer

As a result of the BOSS program, we have filed one provisional patent through UCSD. The patent has raised significant interests in imaging and biomedical industry. Agilent, the world's largest supplier of camera modules for cellular phones and PDAs, has expressed interest in licensing the technology. Agilent has offered to develop the technology into a fully manufacturable process for commercialization. On the other hand, AMO, the world's largest company for implanted lenses after cataract removal is prepared to enter a collaboration and licensing agreement with the UCSD group to develop biocompatible adaptive implanted lenses.

Separately, investment communities have shown interest to fund a startup company to commercialize the miniature zoom lens for camera phones and PDAs. The PI also received funding from von Liebig Center of UCSD School of Engineering to commercialize the technology.

Finally, one postdoc and one PhD student sponsored by the BOSS I program will work for government laboratories or private sectors to transfer their knowhow to DoD and industry.

Appendix

I. Abstract

This analysis shows that lens type tunability that allows change of a convex lens into a concave lens can enhance the zoom ratio and reduce the depth of the system.

II. Analysis

We use the following notations in the analysis: l_1 : object distance, l_2 : image plane distance, d: lens spacing, f_1 : focal distance of the front (object side) lens, f_2 : focal distance of the back (image side) lens, $\Phi_1 = 1/f_1$, $\Phi_2 = 1/f_2$,

 $\Phi = 1/f$: power of the zoom lens system, ZR (zoom ratio).

We have

$$\Phi_{2} = \frac{1}{l_{2}} + (1 + \Phi_{1} \ l_{1}) / (\Phi_{1} \ l_{1} \ d + d - l_{1})$$
(1)
$$\Phi = (-\frac{d}{l_{2}}) \left\{ [\Phi_{1} + (\frac{d-2}{l_{1}})/(2 \ d \ l_{1})]^{2} - (\frac{d^{2}}{l_{1}} + \frac{d}{l_{2}})/(4\frac{d^{2}}{l_{1}} \ l_{1}^{2}) \right\} / (\Phi_{1} + (\frac{d-1}{l_{1}})/(d \ l_{1})$$

In most situations, we can assume that l_1 approaches infinity, then Eqs. 1,2 can be greatly simplified as

$$\Phi_2 = 1/f_2 = 1/l_2 + 1/(d - f_1)$$
(3)
$$\Phi = 1/f = (f_1 - d) / (f_1 l_2)$$
(4)

To form an image on the image plane, $\Phi > 0$ but Φ_1 or Φ_2 does not need to be all positive. This suggests that there is a possibility for extending the zoom ratio with lens type tunability that enables the sign change for either Φ_1 or Φ_2 .

Let us first look at how the power of the zoom lens varies with f_1 by taking $d\Phi/d f_1$.

From Eq. (4), we find

$$d\Phi/d f_1 = (f_1)^{-2} (d/l_2)$$
 (5)

Since both d and l_2 are positive, we have proved that Φ increases monotonically with f_1 . According to Eq. (4), $\Phi = 0$ when $f_1 = d$, hence we can conclude that in order to achieve a positive Φ , f_1 has to be greater or equal to d.

(2)

Next we try to find Φ_{max} . Since F increases monotonically with f_1 , we obtain Φ_{max} as f_1 approaches infinity. From Eq. 4, we obtain:

$\Phi_{max} = 1/l_2$ (as f_1 approaches infinity)	(6-a)
$\Phi_{\min} = 0$ (when $f_1 = d$)	(6-b)

However, we have to be careful with the result in Eq. (6), which suggests an infinite zoom ratio. We need to assure that for (6-a) and (6-b), the focal distance of the second lens, f_2 , falls in a reasonable and technologically achievable range. In the following, we will try to find the corresponding value of f_2 for different values of Φ and f_1 .

Region 1: $d+l_2 < f_1 < infinity$

From Eq. (3), we have $1/(d + l_2) < \Phi < 1/l_2$. From Eq. (4), we have infinity $> f_2 > l_2$.

That is

 $\Phi_{\text{max}} = 1/l_2$ when $f_1 = \text{infinity}, f_2 = l_2$;

 $\Phi_{\min} = 1/(d + l_2)$ when $f_1 = d + l_2$, $f_2 = infinity$.

Assuming that the lens technology allows us to tune f_1 , f_2 so the above focal distances can be achieved, we can achieve a zoom ratio

$$ZR = l + d/l_2$$
 (7)

Equation (7) shows the maximal possible zoom ratio one can achieve with lenses having a wide tuning range but without the lens type conversion capability. In other words, the lenses always have a convex profile.

If the lens technology allows for lens type conversion so its focal distance can become negative, then we can reach the second region with an extended zoom ratio.

Region 2: $d < f_1 < d+l_2$

In the ideal situation, when $f_1 = d$, we have $\Phi = 0$ (from Eq. 4) and $f_2 = 0$ (from Eq. 3). This would have produced a zoom ratio of infinity except that it is impossible to obtain $f_2 = 0$ for any lens design. To calculate the practically achievable zoom ratio, we assume that the minimal magnitude of the negative focal distance for the second lens is f_m .

When the second lens is turned into a negative lens, its focal distance has to satisfy the following condition:

 $f_2 < f_m < 0$

From Eqs. (3,4) and under the condition that $d < f_1 < d+l_2$, we can obtain the following relations

$$f_1 > d - l_2 f_m / (l_2 - f_m)$$
 if we require $f_2 < f_m$ (8)

 $\Phi_{\min} = [l_2 + d(1 - l_2/f_m)]^{-1} \quad \Phi_{\min} \text{ is obtained when the equality in (8) holds}$ (9)

and

4

4

$$ZR = \Phi_{max} / \Phi_{min} = 1 + d/l_2 - d/f_m$$
(10)

Comparing Eq. (10) with Eq. (7), we draw the conclusion that the zoom ratio is increased by an amount of $d/|f_m|$ with the lens type tunability.