

ECBC

Fate of 2-Chloro Ethyl Ethyl Sulfide on 13X Molecular Sieve Adsorbent Implications for Regenerative Filtration

2003 Joint Scientific Conference on
Chemical & Biological Defense
Research

Michael Parham

Research and Technology Directorate
Edgewood Chemical Biological Center

17 November 2003



Report Documentation Page

*Form Approved
OMB No. 0704-0188*

Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.

1. REPORT DATE 19 NOV 2003	2. REPORT TYPE N/A	3. DATES COVERED -	
4. TITLE AND SUBTITLE Fate of 2-Chloro Ethyl Ethyl Sulfide on 13X Molecular Sieve Adsorbent Implications for Regenerative Filtration		5a. CONTRACT NUMBER	
		5b. GRANT NUMBER	
		5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)		5d. PROJECT NUMBER	
		5e. TASK NUMBER	
		5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Research and Technology DirectorateEdgewood Chemical Biological Center		8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)		10. SPONSOR/MONITOR'S ACRONYM(S)	
		11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited			
13. SUPPLEMENTARY NOTES See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical & Biological Defense Research, 17-20 November 2003. , The original document contains color images.			
14. ABSTRACT			
15. SUBJECT TERMS			
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	UU
			18. NUMBER OF PAGES 27
			19a. NAME OF RESPONSIBLE PERSON



ECBC


Introduction

- Regenerative filtration technology offers the promise of greater capacity and breadth of chemical protection than the currently fielded single pass filtration technology.
- Many past and current regenerative filtration prototypes utilize zeolite adsorbents such as 13X molecular sieve.
- The current carbon based adsorbent knowledge base must be expanded to include adsorbate-adsorbent interaction under regenerative filtration conditions.



Objective

- Evaluate the behavior of 2-chloro ethyl ethyl sulfide (CEES), a mustard (HD) simulant, on 13X molecular sieve under thermal regeneration conditions.





Approach

- Expose a packed bed of 13X to a vapor challenge of CEES until it reaches saturation.
- Purge the saturated bed with reverse flow and introduce step-wise heating.
- Evaluate at conditions relevant to regenerative filtration.
 - Examine effect of preloaded water.
 - High face velocity (several times that of M48).
 - Restrained adsorbent bed.



Preparation of 13X adsorbent

CEES feed concentration	200 mg/m ³ (43 ppm)
Temperature	50 C
Bed depth	3 cm
Flow rate	50 LPM (21.1 C, 1 atm)
Face velocity	51.8 cm/s
Dew point	<-80 C to 0 C




ECBC

Experimental


Purge of 13X adsorbent

Temperature	50 C to 125 C
Bed depth	3 cm
Flow rate	25 LPM (21.1 C, 1 atm)
Face velocity	25.8 cm/s @ 50 C
Dew point	<-80 C

Breakthrough of CEES on 13X Adsorbent
 43 ppm CEES challenge, 51.8 cm/s velocity, 3 cm bed depth, <-80 C dew point




**Chemical Loading From Single Pass Breakthroughs
on 13X with Preloaded Water**






- Identification of purge components
 - Sample 1
 - GC FID
 - One low retention time peak, no other detectable peaks
 - GC/MS suggests presence of following compounds
 - Ethanethiol
 - Thiirane
 - Thiophene
 - Diethyl sulfide
 - Diethyl disulfide (oxidation product of ethanethiol)
 - CEES
 - Sample 2
 - GC FID
 - CEES peak and two unidentified peaks
 - GC/MS suggests presence of following compounds
 - Ethyl vinyl sulfide
 - CEES
 - Confirmed presence of ethyl vinyl sulfide by matching retention time and response with standard.

**Regeneration of saturated 13X adsorbent
Temperature Programmed Desorption 50 to 125 C**



Regeneration of saturated 13X Adsorbent
Temperature Programmed Desorption 50 C to 125 C
Cumulative Desorbed Mass




Results


Mass balance

Dew Point	Mass loaded (g)	CEES recovered (g)	Reaction products (g)	Total recovery (%)	Mass balance (%)
< -80 C	7.40	0.04	2.59	36	99
-40 C	6.81	0.06	2.01	31	100
-20 C	6.24	0.03	2.37	38	101


Results




2-chloroethyl ethyl sulfide



HCl H₂O



(2-chloroethyl)(ethyl)[2-(ethylthio)ethyl]sulfonium




ethyl[2-(ethylthio)ethyl](2-hydroxyethyl)sulfonium


CEES and potential hydrolysis products




thiirane




thiophene



diethyl sulfide




ethanethiol



diethyl disulfide

Maximum generation 95-120 C

Maximum generation 122 C



ethyl vinyl sulfide

Decomposition products



Summary

- One decomposition product identified: ethyl vinyl sulfide.
 - Requires a 122 C bed temperature for desorption.
 - Purges at long times with first order kinetics.
- Several other possible desorption products suggested by data.
 - GC FID method does not allow resolution of 0.64 min RT peak.
 - Possible products are fragments or cyclic derivatives of CEES.
 - Temperature at which the desorption concentration peaks, rises with increased preloaded water (95-120 C).
 - Purges at long times with second order kinetics.



Conclusions

- CEES undergoes hydrolysis and decomposition under conditions relevant to regenerative filtration on 13X adsorbent.
- Less than 1% of loaded CEES is purged as CEES, which is <2% of the total purge mass.
- 13X adsorbent is not fully regenerated when tested with CEES under the test conditions (<50%).
- Future work
 - Test mustard under similar conditions.
 - Literature suggests mustard may be less reactive but produce analogous (mustard chemistry) decomposition products.
 - Design apparatus for screening desorption properties (reactivity, dynamics, equilibrium) for regenerative filtration adsorbent candidates under a wide variety of conditions. This would be an important engineering tool for regenerative filtration system design.



ECBC




Acknowledgements

- US Army Edgewood Chemical Biological Center
 - Alex Balboa
 - Leonard Buettner
 - Michael Causey
- Guild Associates, Inc.
 - Roy Brown
 - James Kotary
- Geo-Centers, Inc.
 - Kathy Matson



Background

- Hydrolysis of 2-chloroethyl ethyl sulfide in solution*





- First order kinetics dominate when CEES is infinitely dilute.
- Major hydrolysis products are HEES and HCl.

* Yang, Y., et al., “Mechanisms of Interactions of 2-chloroethyl sulfides with Water.”, CRDEC-SP-88013, Nov 1987



Background

- Hydrolysis of 2-chloroethyl ethyl sulfide in solution.
 - For higher concentrations of CEES, reaction proceeds to equilibrium of CEES, HEES, and EHT.






ECBC

Background

- Hydrolysis of 2-chloroethyl ethyl sulfide in solution.
 - For higher concentrations of CEES, reaction proceeds to equilibrium of CEES, HEES, and EHT.





Background

	CEES $\text{CH}_3\text{CH}_2\text{SCH}_2\text{CH}_2\text{Cl}$	Mustard $\text{S}(\text{CH}_2\text{CH}_2\text{Cl})_2$
Molecular weight	124.6	159.1
Boiling point	157.1 C	227.8 C
Specific gravity	1.07 @ 25 C	1.27 @ 20 C
Water solubility*	$4.85 * 10^{-2}$ M	$4.44 * 10^{-3}$ M
Hydrolysis products	HCl, HEES, EHT, sulfonium salts	HCl, CH, TG, sulfonium salts

* Yang, Y. et al., “Solubility Properties and Rates of Solution of Mustard Gas and 2-Chloroethyl ethyl sulfide”, CRDEC-TR-88043, February 1988



Background

- Behavior of neat HD on NaY (13X)* [room temp]
 - $\text{HD} + \text{H}_2\text{O} \rightarrow \text{CH} + \text{TG} \rightarrow \text{CH-TG}$
- Thermal desorption of HD from CSC carbon**
 - Combination of hydrolysis and thermal decomposition
 - Decomposition products 1,2 dichloroethane, 2-chloroethanol, 1,4 thioxane, 1,4 dithiane, sulfides, ethers
 - Only low level concentrations examined.


* Wagner, G.W., Bartram, P. W., “Reactions of VX, HD, and Their Simulants with NaY and AgY Zeolites. Desulfurization of VX on AgY.”, Langmuir. 1999, 15, 8113-8118

** Karwacki, C. J., et al., “Effect of Temperature on the Desorption and Decomposition of HD from Activated Carbon.”, ERDEC-TR-555, Dec 1998.



ECBC

Experimental






ECBC

Experimental


- Analytical equipment.
 - Preparation and purge of adsorbent bed.
 - Continuous feed and effluent signal.
 - Direct FID voltage output.
 - Discrete feed and effluent signal.
 - GC fid, 110 c.
 - HP-1701 column (14%-cyanopropyl-phenyl)-methylpolysiloxane).
 - Sampling of bagged purge effluent.
 - Transfer at 25 C at 500 ml/min on Tenax.
 - Desorb contents to GC/MS with FID detector.

**Adsorbent Regeneration
Concentration
CES-13X-D (25 Jul 03)**




Results

Adsorbent Regeneration
 Concentration
 CES-13X-D (25 Jul 03)



Adsorbent Regeneration
Concentration
CES-13X-D (25 Jul 03)



ECBC

