

# REPORT DOCUMENTATION PAGE

Form Approved  
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. **PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.**

<b>1. REPORT DATE (DD-MM-YYYY)</b> Jan 2014		<b>2. REPORT TYPE</b> Briefing Charts		<b>3. DATES COVERED (From - To)</b> Jan 2014- Jan 2014	
<b>4. TITLE AND SUBTITLE</b>  Glass Transition Temperature Measurement for Undercured Cyanate Ester Networks: Challenges, Tips, and Tricks				<b>5a. CONTRACT NUMBER</b> In-House	
				<b>5b. GRANT NUMBER</b>	
				<b>5c. PROGRAM ELEMENT NUMBER</b>	
<b>6. AUTHOR(S)</b>  Josiah T. Reams, Andrew J. Guenther, Kevin R. Lamison, Joseph M. Mabry				<b>5d. PROJECT NUMBER</b>	
				<b>5e. TASK NUMBER</b>	
				<b>5f. WORK UNIT NUMBER</b> Q0BG	
<b>7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)</b>  Air Force Research Laboratory (AFMC) AFRL/RQRP 10 E. Saturn Blvd. Edwards AFB CA 93524-7680				<b>8. PERFORMING ORGANIZATION REPORT NO.</b>	
<b>9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES)</b> Air Force Research Laboratory (AFMC) AFRL/RQR 5 Pollux Drive Edwards AFB CA 93524-7048				<b>10. SPONSOR/MONITOR'S ACRONYM(S)</b>	
				<b>11. SPONSOR/MONITOR'S REPORT NUMBER(S)</b> <b>AFRL-RQ-ED-VG-2014-001</b>	
<b>12. DISTRIBUTION / AVAILABILITY STATEMENT</b> Distribution A: Approved for Public Release; Distribution Unlimited					
<b>13. SUPPLEMENTARY NOTES</b> Briefing Charts presented at 34th High Temple Workshop, Sedona, AZ, January 29, 2014. PA#14045					
<b>14. ABSTRACT</b> Briefing Charts					
<b>15. SUBJECT TERMS</b>					
<b>16. SECURITY CLASSIFICATION OF:</b>			<b>17. LIMITATION OF ABSTRACT</b>  SAR	<b>18. NUMBER OF PAGES</b>  21	<b>19a. NAME OF RESPONSIBLE PERSON</b> J. Mabry
<b>a. REPORT</b> Unclassified	<b>b. ABSTRACT</b> Unclassified	<b>c. THIS PAGE</b> Unclassified			<b>19b. TELEPHONE NO</b> (include area code) 661-275-5857



# GLASS TRANSITION TEMPERATURE MEASUREMENT FOR UNDERCURED CYANATE ESTER NETWORKS: CHALLENGES, TIPS, AND TRICKS

29 January 2014

Josiah T. Reams<sup>1</sup>, Andrew Guenther<sup>2</sup>, Kevin R. Lamison<sup>1</sup>,  
Joseph M. Mabry<sup>2</sup>

<sup>1</sup>ERC Incorporated

<sup>2</sup>Aerospace Systems Directorate, Air Force Research Laboratory

Ph: 661/275-8020; e-mail: [andrew.guenther@us.af.mil](mailto:andrew.guenther@us.af.mil)



# Outline



- Background:
  - What Does “Cured” Mean?
  - Importance of  $T_G$ : More Than Just Ceiling Temperatures
- Why can it be difficult to measure  $T_G$  ?
  - “High  $T_G$ ” + Easy to Process = Sensitivity
  - Vitrification + “Cure” = Undercure
  - Undercure + Sensitivity = Unstable  $T_G$
  - “Blind to Chemistry” = Will Miss *In-Situ* Changes
- How to not miss a  $T_G$



Acknowledgements: Air Force Office of Scientific Research, Air Force Research Laboratory – Program Support; AMG team members (AFRL/RQRP); Dr. Matthew Davis (NAWCWD) – preparation of ESR-255, FlexCy, and 1,2,4 DHT-CE



# Cyanate Esters for Next-Generation Aerospace Systems



Glass Transition Temperature  
200 – 400 °C (dry)  
150 – 300 °C (wet)

High  $T_g$

Onset of Weight Loss:  
> 400 °C with High Char Yield


Resin Viscosity Suitable for Filament Winding / RTM

Ease of Processing

Resistance to Harsh Environments

Good Flame, Smoke, & Toxicity Characteristics



Compatible with Thermoplastic Tougheners and Nanoscale Reinforcements



Low Water Uptake with Near Zero Coefficient of Hygroscopic Expansion



# Thermosetting Polymers Have a $T_G$ Envelope – Not Just a $T_G$





A. R. Berens and I. M. Hodges, *Macromolecules* **1982**, 15, 756 (digitized data from Fig. 2)

- The glass transition temperature of a thermoplastic such as PVC exhibits a nearly fixed value regardless of processing-induced changes to the system
- In contrast, the glass transition temperature of a thermosetting polymer can vary over a wide range of temperatures depending on how the polymer is processed
- A change in the extent of cure = a change in  $T_G$



# DSC + diBenedetto = $T_G$ Estimated During the Scan





- In a thermosetting polymer with only one kind of network formation and negligible side reactions, the conversion may be determined at every point in the scan.
- By plugging the conversion into the diBenedetto equation, the  $T_G$  may also be determined at every point during the scan.
- Only when the sample temperature and  $T_G$  coincide is the  $T_G$  detectable (and even then it may be masked by cure).
- Just because no  $T_G$  is visible does not mean  $T_G$  lies outside the scan range.







# Vitrification Can Prevent Complete Conversion to Cyanurate



- In highly rigid cyanate esters, the  $T_G$  often increases beyond the cure temperature, leading to “vitrification.”
- Vitrification leads to a characteristic “L-shaped” DSC curve, which is often mistaken for a peak with a tilted baseline.
- To utilize the diBenedetto equation, FT-IR in combination with DSC is needed to measure conversion.
- **Modulated DSC proves that cure is still in progress at the very end of the scan.**



# “Cured” Cyanate Esters Are Usually Just Vitrified Samples





- When conversion exceed about 65%, vitrified samples have the same physical appearance and handling characteristics at room temperature regardless of the extent of cure.
- Vitrification implies that isothermal cure is very slow, but the “L-shaped” DSC indicates that significant marginal cure is achieved by heating the sample.
- **Whenever a vitrified sample is heated to a temperature between  $\sim T_{cure}$  and  $T_{G\infty}$  for the first time, it will undergo additional cure, increasing  $T_G$ .**





# Why Do Vitrified Cyanate Esters Cure Readily?




- Large enthalpy of reaction = high thermodynamic driving force (true of all stable, single-product cure systems)
- High sensitivity of  $T_g$  to conversion (true of all high-temperature, easily processed resins)
- Some facilitation of cure by catalysts is also possible.



# Effect of Heating Rate on $T_G$ of Vitrified LECy





Primaset® LECY, Catalyzed



- Data shown are for multi-cycle dynamic TMA experiments
- $T_{G\infty}$  for catalyzed LECy reported at 290 °C (loss peak)
- Note how only samples that have not previously been above  $T_{G\infty}$  show variability



# DSC of Vitrified LECy (Cured @ 210 °C for 24 hours)



LECy catalyzed with 160 ppm Cu  
(as Cu-AcAc) + 2 phr nonylphenol

The diBenedetto equation is used to find  $T_G$  assuming complete cure by 350 °C



- Because the  $T_G$  begins to change just as the sample temperature and the  $T_G$  converge, the typical signal associated with a  $T_G$  in DSC scans is not observed.
- As soon as the vitrified sample nears  $T_G$ , it de-vitrifies, which allows cure to resume. The resumption of cure increases  $T_G$ , creating a situation in which the  $T_G$  changes as the sample temperature changes.
- In this case, the heating rate of 10 °C / min. is fast enough, and the rate of cure slow enough, that the  $T_G$  does not change much before it is measured.



# Dynamic TMA and DSC Scans of Vitriified ESR255




Uncatalyzed



- Sample cured at 210 °C for 24 hours
- While dynamic TMA (heating at 10 °C / min.) seems to indicate a very high “as cured”  $T_G$ , it cannot determine whether cure has taken place *in-situ*.
- DSC, however, at 10 °C / min. shows that cure starts at around 250 C, thus the  $T_G$  is changing while the measurement is taking place due to *in-situ* cure.
- Even though cyanate esters can cure at temperatures below  $T_G$ , a  $T_G$  exceeding the cure temperature by > 100 °C would be unprecedented.




# DSC Scans of Vitrified FlexCy at 10 °C / min. and 50 °C / min



- Note how much more distinct the transition between cure in the glassy and rubbery states is when using a rapid heating rate.
- At higher heating rates, there is less time available to cure in the glassy state, thus the  $T_G$  increases to a lesser extent, allowing the scan temperature to “overtake” it more suddenly.
- It is the sudden “cascade” of motion that makes the  $T_G$  appear clearly, as a “de-vitrification” rather than as a transition.



# Dynamic TMA Scan @ 50 °C / min. of Vitrified ESR255




- Sample cured at 210 °C for 24 hours
- Heating at 50 °C / min. allows the sample to get close enough to the “as cured”  $T_G$ , that an initial drop in stiffness is recorded.
- Immediately afterward, however, cure resumes and takes place rapidly, pushing the  $T_G$ , well beyond the limits of the experiment (controlled by onset of degradation).
- Even very rapid heating rates may not stop *in-situ* cure.





# Trianethole-Based Cyanate Esters and Related Compounds




- Compound 10 is an isomer of compound 9 (1,3,5 vs. 1,2,4 substitution); all compounds were prepared by Dr. Matthew Davis at NAWCWD.

Reagents & conditions: a) 1. Br<sub>2</sub>, THF, 0 °C; 2. KO<sup>t</sup>Bu, THF, 0 °C to reflux; b) TMSCl, 5% Pd/C, dioxane, reflux; c) pyridine, POCl<sub>3</sub>, H<sub>2</sub>O, reflux; d) BrCN, TEA, acetone, -20 °C; e) BuLi, Et<sub>2</sub>O, hexanes, rt; f) CoI<sub>2</sub>, ZnBr<sub>2</sub>, Zn, MeCN; g) pyridineHCl, reflux.




# “Wet” TMA of 1,2,4 DHT-CE (80% Conversion Prior to Immersion)



- Sample cured at 210 °C for 24 hrs, then immersed in 85 °C DI water for 96 hrs.
- Samples retain 50-80% of the water weight gain after heating to 200 °C (FT-IR confirms –OH remains present), best guess is 2 mol water / 100 mol monomer – OCN.
- FT-IR confirms increase in stiffness due to *in-situ* cure, not drying. Dry  $T_G = 235$  °C.




# FT-IR Data on Wet 1,2,4 DHT-CE (87% Conversion Prior to Immersion)



- Careful sample prep + high # of scans = quantifiable results!
- Residual -OCN to carbamate conversion, and destruction of carbamate clearly seen.




# Bubble Growth in Wet Resin Samples



Bubble Forms, creates pressure gradient in matrix


Growth criteria:  
 $r^2 P^* \phi / \mu D > \sim 1$

Note:  $\mu$  is practically infinite for  $T < T_G$






$T < T_G$

High modulus resin contains pressure; diffusion quickly dissipates bubble; cracks may initiate.



$T > T_G$

Lower modulus resin yields and flows, allowing bubble to grow; new gas swept into bubble counters pressure drop.






# Comparison of Dry and Wet TMA Measurements of $T_G$



## Dry TMA



- Often requires heating well past final cure temperature
- Inert, dry conditions favor in-situ cure
- “Blind” to chemical changes
- No cascade effects to help identify  $T_G$

## Wet TMA



- Plasticization and degradation drop  $T_G$  to near / below cure temperature
- Carbamate formation dilutes remaining -OCN groups, slows down *in-situ* cure
- Bubble formation can confirm system is above  $T_G$
- Must consider geometry and mass transport effects

- Lists applicable to cyanate esters only; effects on other resins depend on the nature of the cure chemistry.




# Summary



- The attainable  $T_G$  in a cyanate ester thermosetting resin is not a fixed quantity but varies over an envelope determined by the degree of conversion and the limits of mechanical and chemical stability of the cure network, so the  $T_G$  can change while you attempt to measure it.
- Because most “cured” cyanate ester samples are really undercured but vitrified, they tend to cure quickly whenever heated past their previous maximum cure temperature. Additional cure will always increase the  $T_G$ . Thus, performing an ASTM standard test for  $T_G$  on a “cured” cyanate ester is an excellent way to make the  $T_G$  change while you attempt to measure it.
- The best way to measure  $T_G$  is to find a technique that is sensitive to an irreversible cascade effect; the onset of heat given off by residual cure in a DSC with a fast heating rate is an excellent way to accurately measure an “as cured”  $T_G$ .
- Interestingly, for cyanate esters, the effects of water exposure, including a drop in  $T_G$  to near or below the final cure temperature, conversion of residual  $-OCN$  to carbamate, and bubble formation make it easier to measure  $T_G$  in wet samples, despite the important mass transfer effects.





# AFRL

THE AIR FORCE RESEARCH LABORATORY  
LEAD | DISCOVER | DEVELOP | DELIVER

