

# REPORT DOCUMENTATION PAGE

Form Approved  
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. **PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.**

<b>1. REPORT DATE (DD-MM-YYYY)</b> July 2015		<b>2. REPORT TYPE</b> Briefing Charts		<b>3. DATES COVERED (From - To)</b> July 2015-August 2015	
<b>4. TITLE AND SUBTITLE</b> Ionic Liquid Microemulsions, Templates for Directing Morphology of Cellulose Biopolymer Nanoparticles (Briefing Charts)				<b>5a. CONTRACT NUMBER</b> In-House	
				<b>5b. GRANT NUMBER</b>	
				<b>5c. PROGRAM ELEMENT NUMBER</b>	
<b>6. AUTHOR(S)</b> Jeffrey R. Alston, Joseph M. Mabry				<b>5d. PROJECT NUMBER</b>	
				<b>5e. TASK NUMBER</b>	
				<b>5f. WORK UNIT NUMBER</b> Q0BG	
<b>7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)</b> Air Force Research Laboratory (AFMC) AFRL/RQRP 10 E. Saturn Blvd. Edwards AFB, CA93524-7680				<b>8. PERFORMING ORGANIZATION REPORT NO.</b>	
<b>9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES)</b> Air Force Research Laboratory (AFMC) AFRL/RQR 5 Pollux Drive Edwards AFB CA 93524-7048				<b>10. SPONSOR/MONITOR'S ACRONYM(S)</b>	
				<b>11. SPONSOR/MONITOR'S REPORT NUMBER(S)</b> AFRL-RQ-ED-VG-2015-290	
<b>12. DISTRIBUTION / AVAILABILITY STATEMENT</b> Distribution A: Approved for Public Release; Distribution Unlimited.					
<b>13. SUPPLEMENTARY NOTES</b> Briefing Charts presented at 250th ACS National Meeting; Boston, MA; 16-20 August 2015. PA#15438.					
<b>14. ABSTRACT</b> Briefing Charts					
<b>15. SUBJECT TERMS</b>					
<b>16. SECURITY CLASSIFICATION OF:</b>			<b>17. LIMITATION OF ABSTRACT</b>  SAR	<b>18. NUMBER OF PAGES</b>  14	<b>19a. NAME OF RESPONSIBLE PERSON</b> Joseph Mabry
<b>a. REPORT</b> Unclassified	<b>b. ABSTRACT</b> Unclassified	<b>c. THIS PAGE</b> Unclassified			<b>19b. TELEPHONE NO (include area code)</b> 661-275-5857

# AFRL

THE AIR FORCE RESEARCH LABORATORY  
LEAD | DISCOVER | DEVELOP | DELIVER



# Ionic Liquid Microemulsions, Templates for Directing Morphology of Cellulose Biopolymer Nanoparticles

August 19, 2015

Jeffrey R Alston<sup>1\*</sup>, Joseph M. Mabry<sup>2</sup>

<sup>1</sup>Air Force Research Laboratory

<sup>2</sup>National Research Council

[jeffrey.alston.ctr@us.af.mil](mailto:jeffrey.alston.ctr@us.af.mil)



# Outline



- Background on Cellulose and Ionic Liquids
- Materials and Methods
- Results: Designing an IL/Cellulose  $\mu$ emulsion
- Results: Light Scattering Studies
- Conclusions to Date and Future Work



Acknowledgements: Air Force Office of Scientific Research, Air Force Research Laboratory – Program Support, STAR Program, National Research Council





# Introduction to nano Cellulose

Cellulose is the most abundant natural polymer on Earth

- Inexpensive
- Chemically stable
- Nontoxic
- Biodegradable
- Modifiable

INSOLUBLE






# ILs can Dissolve Cellulose



- Cellulose is intra and inter-molecularly connected by hydrogen bonds, and is insoluble in water and most organic solvents
- Solvent dissolution is necessary in multistep processes
- Drastic conditions such as the viscose method are used for the dissolution of cellulose
- ILs form electron donor-acceptor complexes with hydroxyl groups of cellulose resulting in separation and dissolution




A. Pinkert et al. / Chem. Rev. 2009, 109, 6712–6728



# Introduction to microemulsions



- Microemulsions are transparent, isotropic, and thermodynamically stable dispersions of two immiscible liquids stabilized by surfactant.
- Applications in chemical reactions and materials syntheses with some peculiar advantages.
- Recently, ILs have replaced water and/or traditional organic solvents to prepare novel IL-based microemulsions
- Similar to “classic” microemulsions, gradual substructural transition from microdroplets to a bicontinuous structure spans the single-phase microemulsion region.




MP  $\approx$  70 °C


1-Butyl-3-methylimidazolium chloride ([bmim][Cl])



# Cellulose Nanoparticles



Typical Nanocellulose Morphologies




T. Suzuki et al. / Journal of Colloid and Interface Science 418 (2014) 126–131

Emulsion Directed Cellulose Morphology  
(NOT nanocellulose)



# μEmulsion Structure Control




V. Singh et al. / Asian J Pharm 2013;7:1-7

- Microemulsions are thermodynamically stable, clear, colloidal dispersions immiscible liquids, stabilized by surfactant.
- Microemulsions typically have a droplet diameter of approximately 100 nm or less.
- Can be tuned to have cylindrical shapes or several bicontinuous structures





# Related Work: ILs and Cellulose



*T. Suzuki et al. / Journal of Colloid and Interface Science 418 (2014) 126–131*

Micron-sized cellulose particles prepared by the “solvent releasing method” (SRM). Precipitated from Cellulose–[Bmim]Cl–N,N-dimethylformamide (DMF) droplets dispersed in hexadecane (HD) containing dissolved surfactant.

**Q: Can cellulose particle size and morphology be precisely controlled by creating a true IL-Cellulose microemulsion?**



# Materials & Methods



Microemulsion: Quasi-Ternary phase diagram constructed with BmimCl/Span80/Tween20/Sunflower Oil. Warm emulsion technique adapted at 50 °C, for reduced viscosity.

Cellulose Solution: 10 % wt. Microcrystalline cellulose (Sigma Aldrich) dissolved in 10 % wt. DMF:BmimCl solution, for reduced viscosity

Particle Formation: Two methods explored.

Frozen phase centrifugation followed by solvent removal  
Anti-Solvent precipitation

Analysis: Direct observation (OM/SEM), Particle Surface contrast (interferometry), time-resolved small angle laser light scattering.


1. Particles cast of surface
2. Size, formation and growth vs antisolvent addition
3. Particle morphology and its relationship to processing




# Exploring the Phase Diagram



- Establishing phase diagram for IL-cellulose  $\mu$ E
- Start with fixed ratios and dilute with IL
- Use visual observation and DLS to identify phases
- Repeat with Cellulose solutions




Dilution Line C: Showing Phase transition from a single isotropic phase (1- 3) through a 3 phase region (4 & 5) to 2 phases (6).






# Particle Size Results

- Dynamic Light Scattering measures the hydrodynamic radius of  $\mu\text{E}$  as well as particles in solution
- Particles deposited on Si wafer can be measured with Interferometer and SEM



Nanoparticle measurements by Interferometer



SEM of Cellulose Particle  
*T. Suzuki et al. / Journal of Colloid and Interface Science 418 (2014) 126–131*

number	water, wt %	TX-100, wt %	bmimPF <sub>6</sub> , wt %	R	D <sub>h</sub> , nm
1	83.7	15.0	1.1	0.17	8.3
2	78.1	20.3	1.6	0.17	8.5
3	71.8	26.2	2.0	0.17	9.0
4	83.3	15.1	1.6	0.24	12.6
5	77.1	20.7	2.2	0.24	12.8
6	70.5	26.7	2.8	0.24	11.9
7	81.5	15.7	2.8	0.41	18.9
8	74.8	21.4	3.8	0.41	18.3
9	68.9	26.4	4.7	0.41	17.9

Representative results  $\mu\text{E}$  size measurements by DLS

*Y. Gao et al. / Langmuir 2005, 21, 5681-5684*



# Conclusions

- Recent work suggests microemulsions can be used to control cellulose particle morphology.
- Size can be controlled by the adjustment of solvent/surfactant ratios.
- Interferometry may be a useful tool for particle characterization



# Future Work

- Continued study of IL-Cellulose microemulsion formulation and phase structures
  - Conductivity and SAXS measurements
  - Study the final particle morphology vs microemulsion structure
- Studies of the solubility of cellulose in different ILs, ie. changing anions (acetate) or alkyl chains
- Measuring the crystallinity of nanocellulose particles using Xray diffractometry (XRD)
- Continued work on particle recovery methods
- Nanoparticle functionalization via known cellulose chemistry