Army Research Laboratory



An Electrolyte for Low-Temperature Applications of Lithium and Lithium-Ion Batteries

Wishvender K. Behl and Edward J. Plichta

ARL-TR-1705

September 1998

19980901 01

DTIC QUALITY INSPECTED 1

Approved for public release; distribution unlimited.

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

1.

Citation of manufacturer's or trade names does not constitute an official endorsement or approval of the use thereof.

Destroy this report when it is no longer needed. Do not return it to the originator.

Army Research Laboratory

Adelphi, MD 20783-1197

ARL-TR-1705

September 1998

An Electrolyte for Low-Temperature Applications of Lithium and Lithium-Ion Batteries

Wishvender K. Behl Sensors and Electron Devices Directorate, ARL

Edward J. Plichta CECOM, Fort Monmouth

Approved for public release; distribution unlimited.

Abstract

An electrolyte consisting of a 1.0-molar solution of lithium hexafluorophosphate (LiPF₆) in 1:1:1 ethylene carbonate (EC)-dimethyl carbonate (DMC)-ethyl methyl carbonate (EMC) is proposed for low-temperature applications. The new electrolyte has good conductivity and electrochemical stability. Lithium and lithium-ion cells using the new electrolyte were found to be operable at temperatures down to -40 °C.

Contents

۰.

Introduction	. 1
Experimental Procedure	. 1
Results and Discussion	. 2
Conclusions	6
Distribution	7
Report Documentation Page	9

Figures

Conductivities of 1.0-molar solutions of LiPF ₆ in ternary solvent mixture				
EC-DMC-EMC as function of percentage volume of EMC at 25 °C	2			
2. Conductivities of 1.0-molar solutions of LiPF ₆ in EMC, 1:1 EC-DMC,				
and 1:1:1 EC-DMC-EMC as function of temperature	3			
Linear sweep voltammograms obtained at glassy carbon electrode at scan rate				
of 20 mV/s in 1.0-molar solutions of LiPF ₆ in EMC, 1:1 EC-DMC,				
and 1:1:1 EC-DMC-EMC				
Typical voltage-time curve for cell I for first discharge and following				
charge-discharge cycle at constant current of 1 mA using 1.0-molar solution				
of LiPF ₆ in 1:1:1 EC-DMC-EMC as electrolyte				
Typical discharge curves for cell II at constant current of 1 mA at various				
temperatures using 1.0-molar solution of LiPF, in 1:1:1 EC-DMC-EMC				
as electrolyte				
Typical discharge curves for cell III at constant current of 1 mA at various	-			
temperatures using 1.0-molar solution of LiPF, in 1:1:1 EC-DMC-EMC				
as electrolyte	5			
	Conductivities of 1.0-molar solutions of LiPF ₆ in ternary solvent mixture EC-DMC-EMC as function of percentage volume of EMC at 25 °C Conductivities of 1.0-molar solutions of LiPF ₆ in EMC, 1:1 EC-DMC, and 1:1:1 EC-DMC-EMC as function of temperature Linear sweep voltammograms obtained at glassy carbon electrode at scan rate of 20 mV/s in 1.0-molar solutions of LiPF ₆ in EMC, 1:1 EC-DMC, and 1:1:1 EC-DMC-EMC Typical voltage-time curve for cell I for first discharge and following charge-discharge cycle at constant current of 1 mA using 1.0-molar solution of LiPF ₆ in 1:1:1 EC-DMC-EMC as electrolyte Typical discharge curves for cell II at constant current of 1 mA at various temperatures using 1.0-molar solution of LiPF ₆ in 1:1:1 EC-DMC-EMC as electrolyte Typical discharge curves for cell III at constant current of 1 mA at various temperatures using 1.0-molar solution of LiPF ₆ in 1:1:1 EC-DMC-EMC as electrolyte			

Introduction

Various Army missions require lithium and lithium-ion batteries that can operate at temperatures down to -40 °C. Because the electrolytes presently used in commercial lithium-ion batteries freeze at about -30 °C, considerable attention is being given to finding cosolvents for these electrolytes to increase their liquidus range. Recently, ethyl methyl carbonate (EMC) was found to be a useful cosolvent^{1–3} in binary solutions with propylene carbonate (PC) and ethylene carbonate (EC), because of its low freezing point (-55 °C). In this study, we used EMC as a cosolvent with EC and dimethyl carbonate (DMC) in ternary solutions to increase the liquidus range of the lithium-ion battery electrolyte. Thus, Li/LiCoO₂ and graphite/LiCoO₂ button cells that use a 1.0-molar solution of lithium hexafluorophosphate (LiPF₆) in 1:1:1 EC-DMC-EMC as the electrolyte were found to be operable at temperatures down to -40 °C. Further, the new electrolyte was found to have good conductivity, as well as good electrochemical stability. The results are summarized in this report.

Experimental Procedure

LiPF₆ (from Hashimoto, Japan) and SFG-44 graphite (from Timcal) were used as received. EC, DMC, and EMC (all from Grant Chemicals) were dried over molecular sieves before use. Lithium foil (20 mil thick, from the Cypress-Foote Mineral Company), packed over argon, was opened in an argon-filled dry box (from the Vacuum Atmosphere Company) with a moisture content of less than 0.5 ppm.

The electrolyte conductivities were measured with a Wayne Kerr model 6425 precision bridge at a frequency of 1 kHz in sealed Jones-type conductivity cells. Cell constants were determined by a standard KCl solution. An environmental chamber (manufactured by Tenney, Jr.) controlled the temperature for the conductivity and cell studies.

We fabricated lithium and lithium-ion cells using a 1.0-molar solution of LiPF_6 in 1:1:1 EC-DMC-EMC in a button cell configuration. The cell component specifications and button cell assembly details have been described previously.⁴ All electrode disks were 0.51 mm thick and 15.7 mm in diameter. Lithium electrodes were cut from a lithium foil and pressed onto nickel screen (Exmet 5 Ni 6-3/0A). Graphite electrodes with a theoretical capacity of 24 mAh were fabricated with the use of 10 wt.%

⁴E. J. Plichta and S. Slane, "Conductivity of lithium imide in mixed aprotic solvents for lithium cells," J. Power Sources **69**, 41 (1997).

¹M. Ue and S. Mori, "Mobility and ionic association of lithium salts in propylene carbonate-ethyl methyl carbonate mixed solvents," J. Electrochem. Soc. **142**, 2577 (1995).

²Y. Ein-Eli, S. R. Thomas, V. Koch, D. Aurbach, B. Markovsky, and A. Schechter, "Ethylmethylcarbonate, a promising solvent for Li-ion rechargeable batteries," J. Electrochem. Soc. **143**, L273 (1996).

³Y. Ein-Eli and V. R. Koch, "Li-ion battery electrolytes formulated for low temperature applications," Proceedings of the Workshop for Battery Exploratory Development, pp 253–259, Burlington, VT (July 1997).

PTFE (Teflon) binder. The electrode mixture was spread on a copper foil current collector. We made lithium cobalt oxide electrodes with a theoretical capacity of 42 mAh by mixing 80 wt.% LiCoO₂ with 10 wt.% Vulcan CX-72R carbon and 10 wt.% PTFE and spreading the paste on an aluminum screen current collector. The cells were fabricated with a Celgard 2402 separator (0.05 mm thick and 1.9 cm in diameter). The cells were cycled by an Amel model 546 galvanostat/electrometer, and the currents applied to the cell were verified with a Fluke model 8640A digital multimeter. We performed voltammetric scans using an EG&G PAR potentiostat/galvanostat (model 273). The experiments were computer-controlled with the use of EG&G PAR electrochemical analysis software (model 270).

Results and Discussion

The electrolyte in commercial lithium-ion cells generally consists of a 1.0molar solution of LiPF₆ in 1:1 EC-DMC (50:50 vol.%). The electrolyte freezes at about -30 °C, so the commercial lithium-ion cells cannot be used in several military applications that require operation at lower temperatures. We have, therefore, employed EMC as a cosolvent to increase the liquidus range of the electrolyte used in commercial cells.

The conductivities of 1.0-molar solutions of LiPF₆ in 1:1 EC-DMC containing 0 to 100 vol.% EMC were measured at 25 °C, and the data are plotted in figure 1. It is seen that the electrolyte conductivity decreases from ~0.011 to ~0.004 S/cm as the concentration of EMC is increased from 0 to 100 vol.%. However, the decrease in electrolyte conductivity is only minimal in the initial stages, and the conductivity of a 1.0-molar solution of LiPF₆ in 1:1:1 EC-DMC-EMC is close to the conductivity in a 1:1 EC-DMC solution.

We found the freezing point of a 1.0-molar solution of LiPF₆ in 1:1:1 EC-DMC-EMC to be approximately -50 °C compared to the freezing point of approximately -30 °C for the electrolyte using a 1:1 EC-DMC, binary solvent mixture. The conductivities of 1.0-molar solutions of LiPF₆ in EMC, 1:1 EC-DMC, and 1:1:1 EC-DMC-EMC were also measured in the

Figure 1. Conductivities of 1.0-molar solutions of LiPF₆ in ternary solvent mixture EC-DMC-EMC as function of percentage volume of EMC at 25 °C.



temperature range of -40 °C to 55 °C. The data are plotted in figure 2 as a function of temperature.

The conductivities of the EMC solutions at all temperatures are too low to consider these solutions as electrolytes for lithium or lithium-ion batteries. However, EMC can be used as a cosolvent for the commercial electrolyte consisting of a 1.0-molar solution of LiPF₆ in 1:1 EC-DMC to increase its liquidus range. The conductivities of the electrolyte using the ternary solvent mixture are, however, slightly lower at temperatures above –20 °C (fig. 2) compared to the conductivities of electrolytes using the binary solvent mixture.

The electrochemical stabilities of solutions of LiPF₆ in EMC, 1:1 EC-DMC, and 1:1:1 EC-DMC-EMC were examined by recording linear sweep voltammograms at smooth glassy carbon electrodes (electrode area: 0.0792 cm^2). Typical voltammograms obtained at a scan rate of 20 mV/s are presented in figure 3. It is seen that all three solutions are electrochemically stable up to a potential of about 4.5 V, although the anodic currents in EMC solutions are much smaller than those observed in the EC-DMC and EC-DMC-EMC solutions.



Electrode potential vs. Li ref. (V)

The new electrolyte was evaluated in the following cells:

Li/electrolyte/SFG-44 graphite	(I)
Li/electrolyte/LiCoO ₂	(II)
SFG-44 graphite/electrolyte/LiCoO ₂	(III)

Cell I was used to determine the reversible and irreversible capacity of the graphite electrode in button cells. The cell was discharged at a constant current of 1 mA to 0.01 V, which resulted in the intercalation of lithium into graphite. The total cell reaction may be represented as

$$x \operatorname{Li} + 6C \leftrightarrow \operatorname{Li}_{r} C_{6} \tag{1}$$

The cell was then cycled between the voltage limits of 0.01 and 1.5 V, and the voltage-time plots for the first discharge and the following chargedischarge cycle are shown in figure 4. This plot is similar to plots observed by other workers for lithium/graphite cells using nonaqueous electrolytes.^{3,5} The capacities of the graphite electrode during the initial discharge and the following charge-discharge cycle were found to be 354.4, 322.7, and 323.9 mAh/g, respectively. Thus, the irreversible capacity during the first discharge was ~31.7 mAh/g. After the initial discharge, the capacity of the graphite electrode was found to be approximately the same for the charge and discharge cycles.

The reversible capacity of \sim 323 mAh/g for the graphite electrode was found to be comparable to the capacity reported by other workers⁵ for graphite electrodes.



³Y. Ein-Eli and V. R. Koch, "Li-ion battery electrolytes formulated for low temperature applications," Proceedings of the Workshop for Battery Exploratory Development, pp 253–259, Burlington, VT, July 1997.

⁵S. Megahed and B. Scrosati, "Lithium-ion rechargeable batteries," J. Power Sources **51**, 79 (1994).

Cells II and III were used to study the performance of the lithium and lithium-ion cells at different temperatures using a 1.0-molar solution of LiPF₆ in 1:1:1 EC-DMC-EMC as the new electrolyte. The cell reactions in cells II and III, respectively, may be represented as

$$x \operatorname{Li} + \operatorname{Li}_{1-x} \operatorname{CoO}_2 \leftrightarrow \operatorname{LiCoO}_2$$
, and (2)

$$\operatorname{Li}_{x}C_{6} + \operatorname{Li}_{1-x}\operatorname{CoO}_{2} \leftrightarrow 6C + \operatorname{LiCoO}_{2}.$$
(3)

Both cells II and III were assembled in the discharged state and were first charged to a voltage of 4.15 V at a constant current of 1 mA. The discharge curves obtained at 25 °C, -20 °C, and -40 °C at a constant discharge current of 1 mA for cells II and III are presented in figures 5 and 6.

It can be seen that both cells II and III are operable at temperatures down to -40 °C. The capacity of the lithium-ion cell (fig. 6) at -40 °C was, however, found to be only a fraction of the capacity obtained at 25 °C. This may be attributed to the poor performance of the graphite-lithium anode at -40 °C, since the capacity of the lithium cell (fig. 5) at the same temperature was found to be about 52 percent of the capacity obtained at 25 °C.



Time (hr)

Conclusions

Ethyl methyl carbonate was found to be a useful cosolvent to increase the liquidus range of the LiPF₆ solutions in 1:1 EC-DMC at low temperatures. Thus, a 1.0-molar solution of LiPF₆ in 1:1:1 EC-DMC-EMC was found to possess good conductivity and electrochemical stability. Lithium and lithium-ion cells using the new electrolyte were found to be operable at temperatures down to -40 °C.

Distribution

Admnstr Defns Techl Info Ctr Attn DTIC-OCP 8725 John J Kingman Rd Ste 0944 FT Belvoir VA 22060-6218

Ofc of the Dir Rsrch and Engrg Attn R Menz Pentagon Rm 3E1089 Washington DC 20301-3080

Ofc of the Secy of Defns Attn ODDRE (R&AT) G Singley Attn ODDRE (R&AT) S Gontarek The Pentagon Washington DC 20301-3080

OSD Attn OUSD(A&T)/ODDDR&E(R) R Trew Washington DC 20301-7100

Commander Army Materiel Cmnd Attn AMCDE-SC 5001 Eisenhower Ave Alexandria VA 22333-0001

CECOM Attn PM GPS COL S Young FT Monmouth NJ 07703

CECOM Night Vsn/Elect Sensors Dirctrt Attn AMSEL-RD-NV-D FT Belvoir VA 22060-5806

Commander CECOM R&D Attn AMSEL-IM-BM-I-L-R Techl Lib Attn AMSEL-IM-BM-I-L-R Stinfo Ofc (3 copies) FT Monmouth NJ 07703-5703

CECOM RDEC Elect System Div Dir Attn J Niemela FT Monmouth NJ 07703

CECOM Sp & Terrestrial Commetn Div Attn AMSEL-RD-ST-MC-M H Soicher FT Monmouth NJ 07703-5203 Deputy for Sci & Techlgy Attn Ofc, Asst Sec Army (R&D) Washington DC 30210

Dir ARL Battlefield Envir Dirctrt Attn AMSRL-BE White Sands Missile Range NM 88002-5501

Hdqtrs Attn DAMA-ARZ-D F D Verderame Washington DC 20310

Hdqtrs Dept of the Army Attn DAMO-FDT D Schmidt 400 Army Pentagon Rm 3C514 Washington DC 20301-0460

MICOM RDEC Attn AMSMI-RD W C McCorkle Redstone Arsenal AL 35898-5240

US Army Avn Rsrch, Dev, & Engrg Ctr Attn T L House 4300 Goodfellow Blvd St Louis MO 63120-1798

Dir US Army CECOM Rsrch, Dev, & Engrg FT Monmouth NJ 07703-5201

US Army Edgewood Rsrch, Dev, & Engrg Ctr Attn SCBRD-TD J Vervier Aberdeen Proving Ground MD 21010-5423

US Army Info Sys Engrg Cmnd Attn ASQB-OTD F Jenia FT Huachuca AZ 85613-5300

US Army Materiel Sys Analysis Agency Attn AMXSY-D J McCarthy Aberdeen Proving Ground MD 21005-5071

US Army Natick Rsrch, Dev, & Engrg Ctr Acting Techl Dir Attn SSCNC-T P Brandler Natick MA 01760-5002

Dir US Army Rsrch Ofc 4300 S Miami Blvd Research Triangle Park NC 27709

Distribution (cont'd)

US Army Rsrch Ofc Attn AMXRO-ICA B Mann PO Box 12211 Research Triangle Park NC 27709-2211

US Army Simulation, Train, & Instrmntn Cmnd Attn J Stahl 12350 Research Parkway Orlando FL 32826-3726

US Army Tank-Automtv & Armaments Cmnd Attn AMSTA-AR-TD C Spinelli Bldg 1 Picatinny Arsenal NJ 07806-5000

US Army Tank-Automtv Cmnd Rsrch, Dev, & Engrg Ctr Attn AMSTA-TA J Chapin Warren MI 48397-5000

US Army Test & Eval Cmnd Attn R G Pollard III Aberdeen Proving Ground MD 21005-5055

US Army Train & Doctrine Cmnd Battle Lab Integration & Techl Dirctrt Attn ATCD-B J A Klevecz FT Monroe VA 23651-5850

US Military Academy Dept of Mathematical Sci Attn MAJ D Engen West Point NY 10996

Nav Rsrch Lab Attn Code 2627 Washington DC 20375-5000

Nav Surface Warfare Ctr Attn Code B07 J Pennella 17320 Dahlgren Rd Bldg 1470 Rm 1101 Dahlgren VA 22448-5100

GPS Joint Prog Ofc Dir Attn COL J Clay 2435 Vela Way Ste 1613 Los Angeles AFB CA 90245-5500 Marine Corps Liaison Ofc Attn AMSEL-LN-MC FT Monmouth NJ 07703-5033

USAF Rome Lab Tech Attn Corridor W Ste 262 RL SUL 26 Electr Pkwy Bldg 106 Griffiss AFB NY 13441-4514

DARPA Attn B Kaspar Attn L Stotts 3701 N Fairfax Dr Arlington VA 22203-1714

Advry Grp on Elect Devices Attn Documents (2 copies) Crystal Sq 4 1745 Jefferson Davis Hwy Ste 500 Arlington VA 22202

ARL Electromag Group Attn Campus Mail Code F0250 A Tucker University of Texas Austin TX 78712

Dir for MANPRINT Ofc of the Deputy Chief of Staff for Prsnnl Attn J Hiller The Pentagon Rm 2C733 Washington DC 20301-0300

Palisades Instit for Rsrch Svc Inc Attn E Carr 1745 Jefferson Davis Hwy Ste 500 Arlington VA 22202-3402

US Army Rsrch Lab Attn AMSRL-CI-LL Techl Lib (3 copies) Attn AMSRL-CS-AL-TA Mail & Records Mgmt Attn AMSRL-CS-AL-TP Techl Pub (3 copies) Attn AMSRL-DD COL T A Dunn Attn AMSRL-SE-DC W Behl (25 copies) Adelphi MD 20783-1197

REPORT D	OCUMENTATIO		Form Approved			
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including surgestions for reduction this burden to Washington Headquireters Services. Services Directory to the constraint of the						
Davis Highway, Suite 1204, Arlington, VA 2 1. AGENCY USE ONLY (Leave blank)	2202-4302, and to the Office of Management a 2. REPORT DATE September 199	ad Budget, Paperwork Reduction Pro 3. REPORT TYPE 8 Final, from	and Dates covered June 1997 to May 1998			
 4. ТПТLE AND SUBTITLE An Electrolyte for Low-T Lithium-Ion Batteries 6. АИТНОВ(S) Wishvender K. Behl (AR 	Femperature Applications of L, Edward J. Plichta (CEC	Df Lithium and	5. FUNDING NUMBERS DA PR: AH94 PE: 62705A			
7. PERFORMING ORGANIZATION NAME(U.S. Army Research Lab Attn: AMSRL-SE-DE 2800 Powder Mill Road Adelphi, MD 20783-119	s) AND ADDRESS(ES) oratory email: (wbehl@ 97	arl.mil)	8. PERFORMING ORGANIZATION REPORT NUMBER ARL-TR-1705			
9. SPONSORINGMONITORING AGENCY I U.S. Army Research Lab 2800 Powder Mill Road Adelphi, MD 20783-11	NAME(S) AND ADDRESS(ES) Oratory 97		10. SPONSORING/MONITORING AGENCY REPORT NUMBER			
11. SUPPLEMENTARY NOTES ARL PR: 8NE6V1 AMS code: 622705.H94	4		J			
12a. DISTRIBUTION/AVAILABILITY STATE Approved for public re	MENT lease; distribution unlimite	d.	12b. DISTRIBUTION CODE			
13. ABSTRACT (Maximum 200 words) An electrolyte consisting of a 1.0-molar solution of lithium hexafluorophosphate (LiPF ₆) in 1:1:1 ethylene carbonate (EC)-dimethyl carbonate (DMC)-ethyl methyl carbonate (EMC) is proposed for low-temperature applications. The new electrolyte has good conductivity and electrochemical stability. Lithium and lithium-ion cells using the new electrolyte were found to be operable at temperatures down to -40 °C.						
14. SUBJECT TERMS Ethylene carbonate, dim hexafluorophosphate	ethyl carbonate, ethyl met	hyl carbonate, lithiu	15. NUMBER OF PAGES 15 16. PRICE CODE			
17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATION	DN 20. LIMITATION OF ABSTRACT			
Unclassified	Unclassified	Unclassified	UL			

.