


**OIL RESPONSE IN FAST WATER
CURRENTS: A DECISION TOOL**



December
2002



**U.S. COAST GUARD
RESEARCH AND DEVELOPMENT CENTER
GROTON, CT 06340-6048**

DISTRIBUTION STATEMENT A
Approved for Public Release
Distribution Unlimited

20030714 163

NOTICE

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for its contents or use thereof.

The United States Government does not endorse products or manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the object of this report.

This report does not constitute a standard, specification, or regulation.



Marc B. Mandler, Ph.D.
Technical Director
United States Coast Guard
Research & Development Center
1082 Shennecossett Road
Groton, CT 06340-6048

U.S. Coast Guard Research and Development Center
1082 Shennecossett Road, Groton, CT 06340-6048

Report No. CG-D-03-03

**Oil Response in Fast Water Currents:
A Decision Tool**



December 2002



This document is available to the U.S. public through the
National Technical Information Service, Springfield, VA 22161

Prepared for:

U.S. Department of Transportation
United States Coast Guard
Marine Safety and Environmental Protection (G-M)
Washington, DC 20593-0001

Technical Report Documentation Page

| | | | | | |
|--|--|---|--|--|------------------|
| 1. Report No. CG-D-03-03 | | 2. Government Accession Number | | 3. Recipient's Catalog No. | |
| 4. Title and Subtitle OIL RESPONSE IN FAST WATER CURRENTS: A DECISION TOOL | | | | 5. Report Date December 2002 | |
| | | | | 6. Performing Organization Code Project No. 4120.12 | |
| 7. Author(s) Kurt Hansen, Peter Tebeau | | | | 8. Performing Organization Report No. R&DC 572 | |
| 9. Performing Organization Name and Address U.S. Coast Guard Research and Development Center 1082 Shennecossett Road Groton, CT 06340-6048 | | Potomac Management Group 510 King Street Alexandria, VA 22314 | | 10. Work Unit No. (TRAVIS) | |
| | | | | 11. Contract or Grant No. | |
| 12. Sponsoring Organization Name and Address U.S. Department of Transportation United States Coast Guard Marine Safety and Environmental Protection (G-M) Washington, DC 20593-0001 | | | | 13. Type of Report & Period Covered Final Report | |
| | | | | 14. Sponsoring Agency Code Commandant (G-MOR) U.S. Coast Guard Headquarters Washington, DC 20593-0001 | |
| 15. Supplementary Notes The R&D Center's technical point of contact is Kurt Hansen, 860-441-2865, email: khansen@rdc.uscg.mil. | | | | | |
| 16. Abstract (MAXIMUM 200 WORDS) This decision tool is a companion manual for the report, "Oil Response in Fast Currents, A Field Guide" (Report CG-D-01-02). This booklet provides tables, pictures and figures, mostly from out of the guide, that can be used to make decisions in the field or command post. Users should refer to the guide for additional details concerning decision methods, techniques and equipment. | | | | | |
| 17. Key Words fast water response, oil spill response, decision tool | | | | 18. Distribution Statement This document is available to the U.S. public through the National Technical Information Service, Springfield, VA 22161 | |
| 19. Security Class (This Report) UNCLASSIFIED | | 20. Security (This page) UNCLASSIFIED | | 21. No. of Pages 28 | 22. Price |

Form DOT F 1700.7 (8/72) Reproduction of form and completed page is authorized

OVERVIEW OF THE OIL SPILL RESPONSE: FAST WATER DECISION TOOL

Purpose

This document provides oil spill response personnel with a job aid for organizing and implementing oil spill containment and cleanup measures in a fast water environment. Fast water refers to any situation where river, harbor or estuary surface current velocities are expected to exceed one knot. Experience and research have shown that special strategies and tactics are warranted in channeling, containing and recovering spilled oil, and safety should be a main concern.

This decision tool is a companion document to the more comprehensive report, "Oil Spill Response in Fast Currents, a Field Guide," published by the Coast Guard R&D Center in 2002, which is available from the National Technical Information Service in Springfield, VA. This decision tool assumes that the user will have read and understood the material contained in the parent Field Guide. This tool has been limited to essential graphics and tables to refresh the responder's memory, allow him/her to quickly assess the situation and formulate an action plan, and communicate this plan to other personnel.

Organization

The decision tool is organized to provide information for developing fast water response strategies. This process is depicted in the decision flow diagram in Figure 1. For each step in the process, the necessary input information and options are specified. Tables and figures provide the primary options open to the responder, and graphically depict various boom and skimmer tactics for oil exclusion, diversion and recovery. In addition, a set of easy to use graphics and tables is provided to allow the responder to compute key deployment parameters such as boom length, deflection angles, mooring line tension and the number of anchors required.

Relation to Other Spill Response Documents and Resources

In addition to familiarity with the Field Guide, responders should be familiar with the basic National Interagency Incident Management System/Incident Command System (NIIMS/ICS) spill response doctrine as outlined in the USCG Incident Management Handbook. The Area Contingency Plan should also be available and consulted for information on sensitive resource locations and environmental data such as anticipated current velocities, oil behavior and natural collection points. The responder should also consult with the NOAA Scientific Support Coordinator (SSC), local First Responders, as well as harbor masters and local mariners to gather information to verify the viability of the strategy and tactics arrived at using this decision tool.

Figure 1. Fast water response decision chart.




Table 1a. Assess overall situation.

| Selection Factor | Related Sub-Factors | Info Sources |
|-------------------------------|---|--|
| Nature of the spill | <ul style="list-style-type: none"> • Amount and type of oil • Time and place of oil impact (ETA) • Weathering/emulsion issues • History of spills | <ul style="list-style-type: none"> • PolReps • Area Contingency Plan • NOAA SSC |
| Weather forecast | <ul style="list-style-type: none"> • Wind affects oil drift and sea state • Rain affects currents in rivers and coastal areas • Temperature, oil evaporation rate and people endurance • Visibility | <ul style="list-style-type: none"> • On-Scene Observations • Local forecasts • Marine forecasts • NOAA SSC |
| Type and Nature of Water body | <ul style="list-style-type: none"> • River, lake, swamp, inlet, bay, ocean, etc. • Presence of debris or ice • Navigable or not, traffic type & density | <ul style="list-style-type: none"> • NOAA Charts • Local Responders |

Table 1b. Determine waterway characteristics and flow regime.

| Selection Factor | Related Sub-Factors | Info Sources |
|-------------------------|---|---|
| Shoreline | <ul style="list-style-type: none"> • River (winding, width, etc.), estuary, strait, headland, harbor, inlet, island, etc. • Natural collection points • Sensitive areas | <ul style="list-style-type: none"> • Area Contingency Plan • NOAA Charts/ ESI Maps |
| Environment | <ul style="list-style-type: none"> • Current speed and direction • Tidal action: height, cycle time, reversing currents, slack water, etc. • Waves: height, wave direction, period, breaking or non-breaking, etc. | <ul style="list-style-type: none"> • On-Scene Observations • Real-time Measurements • NOAA SSC |
| Bottom | <ul style="list-style-type: none"> • Water depth and contours • Bottom type (relating to habitat damage and anchoring potential) | <ul style="list-style-type: none"> • NOAA Hydro Charts • ESI Maps |

Table 1c. Identify critical location, strategy, and operational areas and problems.

| Selection Factor | Related Sub-Factors | Info Sources |
|--|--|--|
| Man-made structures and commercial enterprises | <ul style="list-style-type: none"> • Piers, breakwaters, bulkheads, bridges, etc. • Water intakes (drinking water, desalination, etc.) • Floating houses, casinos, commercial and recreational traffic • Commercial logs, fish hatcheries, etc. • High volume water traffic | <ul style="list-style-type: none"> • NOAA Hydro Charts • Local harbormaster • Port authority • Area Contingency Plan |
| Shoreline type | <ul style="list-style-type: none"> • Salt marshes and mangroves, sheltered tidal flats, sheltered rocky coasts, exposed tidal flats and vegetation, gravel beaches, beaches • Other threatened or historical areas | <ul style="list-style-type: none"> • Area Contingency Plan • NOAA SSC • ESI Maps |
| Accessibility | <ul style="list-style-type: none"> • Land accesses (bridges, roads, shoreline grade, shoreline vegetation, etc.) • Water access (boat ramps, marinas, fuel, boat draft, specialty vehicles such as jet boats, air cushion vehicles, airboats, etc.) • Air accesses (airports and areas for helicopters) • Approval may be needed | <ul style="list-style-type: none"> • NOAA Hydro Charts • Local harbormaster • Port authority • Area Contingency Plan |
| Debris/Ice | <ul style="list-style-type: none"> • Collection and disposal procedures • Natural Collection Points | <ul style="list-style-type: none"> • First Responders • Area Cont. Plan |
| Safety | <ul style="list-style-type: none"> • Personnel Safety • Site specific issues such as accidental ignition sources | <ul style="list-style-type: none"> • First Responders • Area Contingency Plan |

Table 1d. Select tactics based on flow regime, strategy and operational area.

| Selection Factor | Related Sub-Factors | Info Sources |
|---|--|---|
| Available resources/ Logistics (Response Time to Plan and Deploy) | <ul style="list-style-type: none"> • Response organizations: On Scene Coordinator (OSC), Responsible Party (RP), Oil Spill Response Organization (OSRO), etc. • Estimated Time of Deployment (ETD) • Response equipment, locations and availability (effectiveness in the fast-water conditions) • Boats (HP for speed & towing in currents) • Response personnel, their training, location & availability (experience in swift currents) • Logistics support network & equipment • Repair and Maintenance facilities • Communications | <ul style="list-style-type: none"> • USCG Incident Management Handbook • Area Contingency Plan • Vessel/Facility Response Plan • Local OSRO |

Table 2a. Fast current scenarios and tactics in rivers/canal (non-tidal).

| Scenario | Amplifying Information | Tactics |
|---|---|--|
| Rivers/Canal (Non-Tidal): Depth is greater than typical boom skirt depth. May have tidal influence, but current always goes in same direction | Current speed dependent Vessel traffic dependent | <ul style="list-style-type: none"> • Single Diversion Boom (Figure 2) • Current < 2 knots use boom skirt of 12 inches • Current > 2 knots use boom skirt 6 inches or less |
| | Currents > 2 knots | <ul style="list-style-type: none"> • Cascading Diversion Boom (Figure 4) • Use short skirts, short boom lengths and sufficient overlap |
| | Collection areas available on both sides | <ul style="list-style-type: none"> • Chevron Booms (Figures 6-7) • Open for vessel traffic • Closed if no traffic |
| | Currents < 2 knots and river is wide | <ul style="list-style-type: none"> • Single Diversion Boom • Exclusion Boom for Sensitive Areas (Figure 5) • Encircle & Divert to Collection Area |
| | Sufficient room to maneuver | Skimmers for Collection (Figures 10-11) |
| | Vessels not available | Boom Vane or Flow Diverters (Figure 9) |
| | Special Conditions Isolated Areas | Air and Water Jets Sorbents and Pom-Poms |

Table 2b. Fast current scenarios and tactics in rivers/canals-(tidal).

| Scenario | Amplifying Information | Tactics |
|--|---|---|
| Depth is greater than typical boom skirt depth Current reverses direction | Current speed dependent Vessel traffic dependent Special methods needed to compensate for tides | <ul style="list-style-type: none"> • Diversion Boom – need double set (Figure 2) • Current < 2 knots use boom skirt of 12 inches • Current > 2 knots use boom skirt 6 inches or less |
| | Currents > 2 knots | <ul style="list-style-type: none"> • Cascade Boom - may need double set (Figure 4) • Use short skirts, short boom lengths and sufficient overlap |
| | Collection areas available on both sides | <ul style="list-style-type: none"> • Chevron - may need double set (Figures 6-7) • Open for vessel traffic • Closed if no traffic |
| | Currents < 2 knots and river is wide | Encircling |
| | Isolated Areas Sufficient room to maneuver | Sorbents and Pom-Poms Skimmers (Figures 10-11) |
| | Vessels not available | Boom Vane or Flow Diverters (Figure 9) |
| | Special Conditions Isolated Areas | Air and Water Jets Sorbents and Pom-Poms |

Table 2c. Fast current scenarios and tactics in small streams and coastal areas.

| Scenario | Amplifying Information | Tactics |
|---|--------------------------------------|--|
| Small streams, creeks, culverts: Depth is less than boom skirt depth | Dependent upon flow rate | <ul style="list-style-type: none"> ▪ Single Diversion for volume flow greater than about 10 cubic feet/second (Figure 2) |
| | Block for low volume flow | <ul style="list-style-type: none"> • Sealing • Fill • Dams (Figures 12-13) • Weirs |
| | Design for volume Low Flow | <ul style="list-style-type: none"> ▪ Overflow/Underflow dams ▪ Sorbents and Pom-Poms |
| Coastal Areas: Near shore wave dependent Includes near shore and straits Various depths Usually tidal | | <ul style="list-style-type: none"> ▪ Single Diversion Boom Current < 2 knots use boom skirt of 12 inches if no waves |
| | Currents > 2 knots | <ul style="list-style-type: none"> • Cascade Boom (Figure 4) • Use short boom lengths and sufficient overlap |
| | Currents < 2 knots and river is wide | <ul style="list-style-type: none"> ▪ Encircling |
| | Sufficient room to maneuver | <ul style="list-style-type: none"> ▪ Skimmers (Figures 10-11) |
| | Isolated Areas | <ul style="list-style-type: none"> ▪ VOSS/SORS ▪ Sorbents and Pom Poms |

Table 2d. Fast current scenarios and tactics in harbors/bays and harbor entrances.

| Scenario | Amplifying Information | Tactics |
|---|---|--|
| Harbors/Bays: Near shore wave dependent Depth is usually greater than typical boom skirt depth | Use river techniques in specific areas Current speed dependent Vessel traffic dependent | <ul style="list-style-type: none"> • Single Diversion Boom (Figure 2) • Current < 2 knots use boom skirt of 12 inches if no waves • Current > 2 knots use boom skirt 6 inches or less if no waves |
| | Currents > 2 knots | <ul style="list-style-type: none"> • Cascade Boom (Figure 4) • Use short skirts, short boom lengths and sufficient overlap |
| | Currents < 2 knots and area is large | <ul style="list-style-type: none"> ▪ Encircling |
| | Sufficient room to maneuver | <ul style="list-style-type: none"> ▪ Skimmers (Figures 10-11) |
| | Special Conditions Isolated Areas | <ul style="list-style-type: none"> ▪ Air and Water Jets ▪ Sorbents and Pom-Poms |
| Breach ways and Harbor Entrances: Various depths, Usually tidal | Current speed, vessel traffic and wave dependent | <ul style="list-style-type: none"> • Single Diversion Boom (Figure 2) • Current < 2 knots use boom skirt of 12 inches if no waves • Current > 2 knots use boom skirt 6 inches or less if no waves |
| | Currents > 2 knots | <ul style="list-style-type: none"> • Cascade Boom (Figure 4) • Use short skirts (if no waves), short boom lengths and sufficient overlap |
| | Collection areas available on both sides | <ul style="list-style-type: none"> • Chevron Boom (Figures 6-7) • Open for vessel traffic • Closed if no traffic |
| | Block for low volume flow | <ul style="list-style-type: none"> • Sealing • Fill • Dams • Weirs |
| | Vessels not available | <ul style="list-style-type: none"> ▪ Boom Vane or Flow Diverters (Figure 9) |
| | Design for volume | <ul style="list-style-type: none"> ▪ Overflow/Underflow dams (Figures 12-13) |
| | Isolated Areas | <ul style="list-style-type: none"> ▪ Sorbents and Pom-Poms |

SAFETY

Oil spill response is an inherently hazardous operation. It involves handling a hazardous material in a marine environment often under less than ideal sea and weather conditions. Deploying, operating and retrieving heavy and cumbersome oil spill response equipment routinely requires physical exertion and subjects responders to heat and cold stress. Responding to spills in fast water environments imposes additional hazards due to the extreme loads placed on equipment and the danger of personnel being swept away in the fast currents. Coast Guard personnel must perform Operational Risk Management (ORM) as outlined in COMDTINST M35003 before initiating response actions. (see process below).

Operational Risk Management Process

1. Identify Mission Tasks
2. Identify Hazards
3. Assess Risks
4. Identify Options Tables
5. Evaluate Risk vs. Gain
6. Execute Decision
7. Monitor Situation

Table 3 summarizes the major hazards, potential injuries and risk control measures associated with fast-water oil spill response. The water hazards are defined in some detail as these are the single most dangerous hazards associated with fast water response.

If an individual should accidentally fall in the water, there are a number of things that both the victim and rescuers should remember:

- Don't swim against the current. Swim perpendicular.
- Swim on back, feet downstream.
- Use hands and feet to fend off obstructions.
- Do not tie rope around swimmer or rescuer.
- Angle rescue lines down current.
- Stay on upstream side of the line.
- Never clip into the line.

Table 3. Fast-water oil spill response hazard summary.

| Hazard | Injury Potential | Control |
|---------------------------------|--|---|
| Slips, Trips and Falls | Broken limbs, lacerations, head injuries | Awareness, protective clothing, safety lines |
| Ergonomic | Back injury, joint injuries, hernias | Proper lifting methods, lifting devices |
| Heat and Cold Stress | Frost bite, hypothermia, heat stroke | Proper clothing, nutrition, rest, & medical monitoring |
| Flammability – Fire & Explosion | Death, severe burns, broken limbs, loss of eyes | Awareness, proper ventilation, monitoring |
| Oil Toxicity | Eye/skin irritation, nausea, dizziness, long term effects | Air monitoring, respiratory protection, gloves, coveralls |
| Line Hazards | Death, loss of limbs & eyes, broken limbs | Adequate line strength, safety observer, knife available |
| Heavy Equipment Hazards | Damage to eyes, hearing loss, exhaust inhalation, cuts and abrasions | Eye and ear protection, secure loose clothing, stay clear of danger points/ exhaust |
| Water (drowning) | <p>Critical - death, hypothermia</p> <p>Consider the following:</p> <ul style="list-style-type: none"> • Don't swim against current, swim perpendicular • Swim on back, feet downstream • Use hands and feet to fend off obstructions • Do not tie rope around swimmer or rescuer • Angle rescue lines down current • Stay on upstream side of the line • Never clip into the line | <ul style="list-style-type: none"> • Buddy System • Life jackets • Cold weather gear • Fall restraints • Life rings, boat hooks • Rescue boats • Avoid waders • Bicycle helmets can be substituted for hardhats only if no overhead hazards exists • Avoid slip on fireman boots • Avoid loose clothing |




Figure 2. Single diversion boom.




Figure 3. Double boom.




Figure 4. Cascade boom.




Figure 5. Exclusion boom.




Figure 6. Open chevron boom.




Figure 7. Closed chevron boom.




Figure 8. Boom deflectors can be used without multiple anchors.




Figure 9. Boom vane deploys and retrieves deflection boom from shore to allow vessel passage.




Figure 10. The NOFI Vee Sweep™ with tapered channel separator.




Figure 11. Wide-mouth V-shape boom with attached skimmer.




Figure 12. Earth underflow dam.




Figure 13. Overflow dam.

HYDRODYNAMIC CONSIDERATIONS AND BOOMING RESOURCES

In assessing the overall feasibility of implementing a fast water booming tactic, it is necessary to determine key hydrodynamic parameters and assess the adequacy of on-scene resources based on these parameters. The definition's process for accomplishing this is depicted in Figure 14, which outlines a procedure for determining the necessary parameters.

Definitions:

- Current Speed (V in knots) and Water Depth (D in feet)
- Profile Length-width that needs to be boomed: This is the value X in the bottom of figure 15.
- Maximum Deployment Angle of the boom (from Figure 15 or Table 4),
- Minimum Length of Boom required (Lboom from Table 4),
- Total Force exerted on the boom (Tboom from Table 4), and
- Number of Anchor Points (AP#) required assuming a minimum of 50 feet of spacing (AP# from Table 4).

Mooring Line:

A conservative estimate of the total length of mooring line (Lline) required per anchor point is $D \times 7$. The tension on each mooring line is estimated by $T_{line} = T_{boom} / AP\#$.

The tension on each mooring line should then be checked against the lines Nominal Breaking Strength (from Table 5) and the Holding Power of each anchor (from Table 6). The value of the T_{line} should be less than both these values.

Boat Horsepower:


The horsepower required (HPmin) for a deployment vessel to maintain the boom at this deployment angle in the current can be estimated as follows:

- For an outboard motor: $HP_{min} = T_{boom}/15$
- For an inboard motor: $HP_{min} = T_{boom}/20$
- For a jet drive motor: $HP_{min} = T_{boom}/10$

Anchoring:

Examples of anchoring techniques are shown in Figures 16-18.

Figure 14. Hydrodynamic considerations and booming requirements.







Figure 15. Maximum boom deployment angles required to prevent oil entrainment.

Table 4. Boom Hydrodynamics Table for 100 foot profile. (For larger values of X, values of Lboom, Tboom and AP# can be easily calculated by multiplying by the multiple of 100 feet (X feet/100 feet)).

| Time to Drift 100 Feet (Seconds) | Velocity (Knots) | Max Boom Deflection Angle (Degrees) | Boom Length Required for 100 ft. Profile to Current (feet) | T=Total Force on Boom (pounds) | | | | | | Anchors if Placed every 50 ft. or less |
|----------------------------------|------------------|-------------------------------------|--|--------------------------------|--------------------|----------------------------|-------------------|----------------------------|--------------------|--|
| | | | | (without Waves) K=2 | | | (with Waves) K=4 | | | |
| | | | | per 100 ft. of boom length | | per 100 ft. of boom length | | per 100 ft. of boom length | | |
| | | | | 6 inch boom draft | 12 inch boom draft | 18 inch boom draft | 6 inch boom draft | 12 inch boom draft | 18 inch boom draft | |
| 100 | 0.5 | 90 | 100 | 25 | 50 | 75 | 50 | 100 | 150 | 3 |
| 60 | 1.0 | 45 | 150 | 71 | 141 | 212 | 142 | 282 | 424 | 4 |
| 40 | 1.5 | 30 | 225 | 112 | 225 | 338 | 224 | 450 | 676 | 6 |
| 30 | 2.0 | 20 | 300 | 137 | 274 | 410 | 274 | 548 | 820 | 7 |
| 20 | 3.0 | 13 | 450 | 202 | 405 | 607 | 404 | 810 | 1214 | 10 |
| 15 | 4.0 | 10 | 625 | 284 | 567 | 851 | 568 | 1134 | 1702 | 14 |
| 12 | 5.0 | 8 | 725 | 348 | 696 | 1004 | 696 | 1392 | 2008 | 16 |
| 10 | 6.0 | 7 | 875 | 438 | 877 | 1316 | 876 | 1574 | 2632 | 18 |

Equations for Boom Force (Tboom) in Table 4

For a quick approximate load on a boom that is anchored at an angle of between 10 and 30 degrees to the current, use the following formula:

$T = K * A * V^2$ where: T = tensile force, lb_t
 K = constant, lb_t / (ft² x knots²)
 A = projected area of the submerged portion of the boom, ft²
 V = tow speed, knots

The projected area of the boom was calculated based on the boom draft, and the length of the boom normal to the water current (i.e., the direction of travel):

$A = d * L * \sin \theta$ where: A = projected area of the submerged portion of the boom, ft²
 d = boom draft, feet
 L = boom length, feet (100 ft)
 θ = diversion angle (10°, 20°, 30°)

Table 5. Nominal line breaking strengths (pounds).

| Diameter (inches) | Manila | Polypropylene (Three-Strand) | Nylon (Triple Strand) | Nylon (Double Braid) | Polyester (Double Braid) |
|-------------------|--------|------------------------------|-----------------------|----------------------|--------------------------|
| 5/16 | 900 | 1700 | 2300 | 3400 | 2400 |
| 1/2 | 2380 | 3800 | 5600 | 8500 | 5750 |
| 5/8 | 3960 | 5600 | 8910 | 15200 | 9000 |
| 1 | 9000 | 13000 | 23000 | 26500 | 26800 |
| 2 | 22500 | 32000 | 60000 | 74000 | 69900 |

Table 6. Anchor holding power as a multiple of dry weight for 100 pounds.

| Anchor Type | Soft Soils | Hard Soils |
|----------------|------------|------------|
| Danforth/LWT | 12.6 | 31.6 |
| STATO/NAVMOOR | 27.7 | 25-33 |
| Navy Stockless | 3.5 | 11 |




Figure 16. Typical boom mooring configuration.




Figure 17. Mooring boom with multiple anchors.




Figure 18. Typical shoreline boom mooring system using posts.

Table 7. Fast water worksheet.

| FAST WATER WORK-SHEET | | 1. Incident Name: | | 2. Date/time prepared: | | | | 3. Operational Period | | | | 4. Attachments | |
|---|---|--|---|---------------------------|---|-------------|---|--|---|---|---|---|--------------------|
| 5. Fast Water Type | Rivers/Canals (non-tidal) <input type="checkbox"/> Rivers/Canals (tidal) <input type="checkbox"/> Small Streams/Culverts/Creeks <input type="checkbox"/> Coastal areas <input type="checkbox"/> Harbors/Bays <input type="checkbox"/> Breakwaters and Harbor entrances <input type="checkbox"/> Other (specify): | | | | | | | | | | | | |
| 6. Background Info | Oil Type | Oil Amount | Temperature of | Humidity % | Evaporation in 24 hours % | Wind (mph) | Visibility (Ft) | Rain, Sleet, Snow | Water (°F) | Other | | | |
| 7. Safety Hazards | Confined Space <input type="checkbox"/> Noise <input type="checkbox"/> Heat Stress <input type="checkbox"/> Cold Stress <input type="checkbox"/> Electrical <input type="checkbox"/> Animal/Plant/Insect <input type="checkbox"/> Ergonomic <input type="checkbox"/> Ionizing Rad <input type="checkbox"/> Slips/Trips/Falls <input type="checkbox"/> Struck by <input type="checkbox"/> Water <input type="checkbox"/> Violence <input type="checkbox"/> Excavation <input type="checkbox"/> Biomedical waste and/or needles <input type="checkbox"/> Fatigue <input type="checkbox"/> Other (specify): | | | | | | | | | | | | |
| 8. Personal Protection | Life Jackets <input type="checkbox"/> Oil resistant gloves <input type="checkbox"/> Shoulder length resistant gloves <input type="checkbox"/> Level D <input type="checkbox"/> Eye protection <input type="checkbox"/> Cold WX Gear <input type="checkbox"/> Level C <input type="checkbox"/> Splash Suits <input type="checkbox"/> Hearing protection <input type="checkbox"/> Fall protection <input type="checkbox"/> Water <input type="checkbox"/> Sun screen <input type="checkbox"/> Wet Suits <input type="checkbox"/> Dry Suits <input type="checkbox"/> Portable first aid kits <input type="checkbox"/> Other (specify): | | | | | | | | | | | | |
| 9. Potential Booming Locations | ETA Oil Impact | Natural Collection Point | Shoreline wave energy | Current Speed & Direction | Access | Water Depth | Tidal Influence | Bottom Amenable to Anchors | Debris, Ice | Shore Sensitivity | Historical Economic Concern | Nav Traffic | Strategy Selection |
| | Yes <input type="checkbox"/> No <input type="checkbox"/> | Yes <input type="checkbox"/> No <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | | Land <input type="checkbox"/> Water <input type="checkbox"/> Air <input type="checkbox"/> | | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | Yes <input type="checkbox"/> No <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | |
| | Yes <input type="checkbox"/> No <input type="checkbox"/> | Yes <input type="checkbox"/> No <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | | Land <input type="checkbox"/> Water <input type="checkbox"/> Air <input type="checkbox"/> | | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | Yes <input type="checkbox"/> No <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | High <input type="checkbox"/> Med <input type="checkbox"/> Low <input type="checkbox"/> | |
| 10. Selection Strategies | Current < 2 Knots Current > 2 Knots Collection Possible on Opposite Sides | | | | | | | | | | | | |
| Rivers/Canals (non-tidal) | Single Diversion Booming (Skirt < 12 inches) (SDB < 12 inches) (SDB < 6 inches) (SDB < 6 inches) Cascade Booming (CSC) | | | | | | | | | | | | |
| Rivers/Canals (tidal) | Single Diversion Booming (Skirt < 12 inches) (SDB < 12 inches) (SDB < 6 inches) (SDB < 6 inches) Cascade Booming (CSC) | | | | | | | | | | | | |
| Small Streams/Creeks/Culverts | Double SDB < 12, ECB, SRB Fill, Dams, Weirs Underflow/Overflow Dams (UFD/OFD) | | | | | | | | | | | | |
| Coastal Areas | ENC, SDB < 12 (no waves), SRB SDB < 12, ECB, SRB | | | | | | | | | | | | |
| Harbor/Bays | SDB < 12, ECB, SRB, Fill, Dams, Weirs, UFD, OFD | | | | | | | | | | | | |
| Breakwaters/Harbor Entrances | Double SDB < 6, CSC SK SK (small) SK SK | | | | | | | | | | | | |
| Prepared by: _____ of _____ Page _____ of _____ | | | | | | | | | | | | | |

Table 8. Conversion tables.

CONVERSIONS AND EQUIVALENTS

| AREA (s=statute, n=nautical) | | |
|------------------------------|--------|-------------------------|
| Multiply | by | to derive |
| meters ² | 10.76 | feet ² |
| feet ² | 0.0929 | meters ² |
| kilometers ² | 0.386 | s. miles ² |
| s. miles ² | 2.59 | kilometers ² |
| s. miles ² | 0.7548 | n. miles ² |
| n. miles ² | 1.325 | s. miles ² |
| kilometers ² | 0.2916 | n. miles ² |
| n. miles ² | 3.430 | kilometers ² |

| TEMPERATURE | |
|-------------|-----------|
| Calculate | To derive |
| 5/9(°F-32°) | °C |
| 9/5°C+32° | °F |

| VOLUME | | |
|-------------------|--------|---------------------|
| multiply | by | to derive |
| barrels | 42 | gallons |
| barrels | 5.615 | feet ³ |
| barrels | 158.9 | liters |
| barrels | 0.1589 | meters ³ |
| feet ³ | 7.481 | gallons |
| gallons | 3.785 | liters |

| WEIGHT | | |
|-------------|-------|-----------|
| multiply | by | to derive |
| kilograms | 2.205 | pounds |
| metric tons | 0.984 | long tons |
| metric tons | 1,000 | kilograms |
| metric tons | 2,205 | pounds |
| long tons | 1,016 | kilograms |
| long tons | 2240 | pounds |
| short tons | 907.2 | kilograms |
| short tons | 2,000 | pounds |

| DENSITY ESTIMATIONS | | | |
|---------------------|------------------|---------|---|
| | Barrels/Long Ton | | Notes: |
| | Range | Average | |
| Crude Oils | 6.7 - 8.1 | 7.4 | <ul style="list-style-type: none"> 1 Long Ton equals 2,200 lbs. As a general approximation, use 7 bbl. (300 U.S. gallons) per metric ton of oil. 6.4 barrels/long ton is neutrally buoyant in fresh water. Open ocean neutral buoyancy values are generally in the 6.21-6.25 barrels/long ton range. |
| Aviation Gasolines | 8.3 - 9.2 | 8.8 | |
| Motor Gasolines | 8.2 - 9.1 | 8.7 | |
| Kerosenes | 7.7 - 8.3 | 8.0 | |
| Gas Oils | 7.2 - 7.9 | 7.6 | |
| Diesel Oils | 7.0 - 7.9 | 7.5 | |
| Lubricating Oils | 6.8 - 7.6 | 7.2 | |
| Fuel Oils | 6.6 - 7.0 | 6.8 | |
| Asphaltic Bitumens | 5.9 - 6.5 | 6.2 | |

Specific Gravity of 1 or an API of 10 equals the density of fresh water.

| | | |
|--|-----|---|
| Specific Gravity < 1 or an API > 10 indicates product is lighter than fresh water. API Gravity = (141.5/Specific Gravity) - 131.5 | | |
| Weight of Fresh Water: pounds/gallon | 8.3 | Note: Exact weight depends on temperature and salinity. |
| Weight of Sea Water: pounds/gallon | 8.5 | |

| OIL THICKNESS ESTIMATIONS | | | | |
|--|------------------------|---------|---------------------------------|------------------------------|
| Standard Term | Approx. Film Thickness | | Approx. Quantity of Oil in Film | |
| | Inches | Mm | | |
| Barely Visible | 0.000015 | 0.00004 | 25 gals/mile ² | 44 liters/km ² |
| Silvery | 0.00003 | 0.00008 | 50 gals/mile ² | 88 liters/km ² |
| Slight Color | 0.00006 | 0.00015 | 100 gals/mile ² | 176 liters/km ² |
| Bright Color | 0.00012 | 0.0003 | 200 gals/mile ² | 351 liters/km ² |
| Dull | 0.00004 | 0.001 | 666 gals/mile ² | 1,168 liters/km ² |
| Dark | 0.00008 | 0.002 | 1,332 gals/mile ² | 2,237 liters/km ² |
| Thickness of light oils: 0.0010 inches to 0.0010 inches. | | | | |
| Thickness of heavy oils: 0.10 inches to 0.010 inches. | | | | |

| COMMONLY-USED EQUATIONS | |
|---|---|
| Circle: Area = 3.14 x radius ² Circumference = 3.14 x diameter | Cylinder/Pipe/Tank Volume = 3.14 x radius ² x length |
| | Rectangle/Square Area = length x width |
| Sphere/Tank Area = 4 x 3.14 x radius ² Volume = 1.33 x 3.14 x radius ³ | Cube/Block/Tank Volume = length x width x height |